

EUTECTIC EC-10

OIL-FIRED WATER BOILERS/NO. 2 OIL

INSTALLATION AND OPERATING INSTRUCTIONS

SAFETY WARNING:
KEEP BOILER AREA CLEAR AND FREE FROM COMBUSTIBLE MATERIALS, GASOLINE AND OTHER FLAMMABLE VAPORS AND LIQUIDS. FAILURE TO ADHERE TO ABOVE SAFETY WARNING, MAY RESULT IN PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.



CONTENTS	PAGE
Ratings and Dimensions	2
Installation Requirements:	
Boiler Location	3
Clearances	3 & 4
Chimney Requirements	3
Air Supply and Venting	3-7
Controls and Accessories	7
Piping for Water Units	7
Installing Burner	8
Oil Supply Piping	8
Wiring the Boiler	8
Vent Piping and Draft Regulator	8
Operating Instructions:	
Precautions Before Starting	8
Start-up	8
Cleaning and Filling New Water Boiler	9
Care and Maintenance:	
Extended Shutdown	9
Freezing Protection	10
Oil Burner	10
General Maintenance	10
Wiring Diagrams	11-13
Burner Data	14-17
Appendix A-G	18-20

IMPORTANT: The installation of this equipment must conform to the requirements of the authority having jurisdiction or, in the absence of such requirements, to the Installation of Oil Burning Equipment, CSA B139, latest edition. The installation must also conform to the additional requirements in this Slant/Fin Instruction Manual. Where there is any difference, the more stringent requirement shall govern.

In addition, where required by the authority having jurisdiction, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers, No. CSD-1 or CSA B149.1-00 for natural gas and propane. If there is any conflict in the above requirements, then the more stringent requirement will apply.

THIS MANUAL MUST BE LEFT WITH OWNER AND SHOULD BE HUNG ON OR ADJACENT TO THE BOILER FOR REFERENCE.

IMPORTANT: This boiler must be installed, serviced and repaired by a trained, experienced, service technician, licensed for the installation and servicing of oil burning hot water heating system equipment or otherwise qualified by the authorities having jurisdiction over the installation.

SERVICE COMPANY

Name _____

Address _____

Telephone _____

Model # _____

Serial # _____

Figure 1: Dimensions




TABLE 1: Ratings and Dimensions

BOILER MODEL NO.	OIL INPUT † §				GROSS OUTPUT*				NET OUTPUT*				CHIMNEY SIZE I.D. ROUND X HEIGHT				AFUE %	DIMENSIONS											
																		APPROX. OVERALL LENGTH		BOILER LENGTH		BOILER LENGTH		FLUE DIA		DISTANCE BETWEEN LEGS		FLUE OUTLET LENGTH	
																		"A"		"B"		"C"		"D"		"E"		"F"	
mL/s	GPH	Watts	BTU/H	kW	MBH	kW	MBH	kW	MBH	mm x m	(in X ft.)	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.						
EC-13A	0.68	0.65	26,672	91,000	23	79	20	69	152 x 4.6	6 x 15	87	914	36	25	22-1/4	686	27	127	5	300	11-13/16	51	2						
EC-13B	0.74	0.70	28,724	98,000	25	85	22	74	152 x 4.6	6 x 15	86	914	36	25	22-1/4	686	27	127	5	300	11-13/16	51	2						
EC-14A	0.84	0.80	32,827	112,000	29	98	25	85	152 x 4.6	6 x 15	87	1041	41	686	27	813	32	127	5	427	16-13/16	51	2						
EC-14B	0.95	0.90	36,931	126,000	32	109	28	95	152 x 4.6	6 x 15	86	1041	41	686	27	813	32	127	5	427	16-13/16	51	2						
EC-15A	1.05	1.00	41,034	140,000	36	123	31	107	152 x 4.6	6 x 15	87	1168	46	819	32-1/4	940	37	127	5	554	21-13/16	51	2						
EC-15B	1.16	1.10	45,137	154,000	39	134	34	117	152 x 4.6	6 x 15	86	1168	46	819	32-1/4	940	37	127	5	554	21-13/16	51	2						
EC-16A	1.21	1.15	47,189	161,000	41	141	36	123	152 x 4.6	6 x 15	87	1295	51	946	37-1/4	1067	42	152	6	681	26-13/16	102	4						
EC-16B	1.32	1.25	51,293	175,000	45	152	39	132	152 x 4.6	6 x 15	86	1295	51	946	37-1/4	1067	42	152	6	681	26-13/16	102	4						

Maximum operating pressure 414 kPa (60 psi).

All boilers hydrostatically tested — A.S.M.E.

* For forced hot water heating systems where the boiler and all piping are located within the area to be heated, the boiler may be selected on the basis of net capacity output. The net output ratings shown are based on an allowance for piping and pickup of 1.15 (water). Gross capacity output is divided by the allowance to obtain net rating. The Slant/Fin Technical Service department should be consulted before selecting a boiler for unusual piping and pickup requirements such as intermittent system operation, extensive piping, etc.

† Ratings apply to the use of light oil at 11 000 W/L (140,000 Btu per gallon) and apply only when burner models listed on pages 13 and 16 of this manual are used, and are properly adjusted to produce 13% CO₂.

§ Boiler models have two firing rates. The boiler is factory shipped at the lower firing rate. To obtain the higher firing rate, refer to the boiler installation instructions for the appropriate field adjustments.

All dimensions subject to normal manufacturing tolerance.

NOTE: All boilers under 87.9 kW (300,000 Btu/h) input are tested and certified for A.F.U.E. capacities.

THE INSTALLATION INSTRUCTIONS IN THIS MANUAL ARE ABBREVIATED. SEE THE FRONT COVER OF THIS MANUAL FOR REFERENCES TO CODES AND STANDARDS.

BOILER LOCATION

CAUTION: NEVER BURN GARBAGE OR PAPER IN THE UNIT, AND NEVER LEAVE COMBUSTIBLE MATERIAL AROUND IT.

Provide a level, solid foundation for the boiler. Location should be near the chimney so that the Flue Pipe Connector or Breeching to the chimney is short and direct.

- A. The foundation must be capable of supporting the weight of the boiler when filled with water:

Boiler Size	Approximate Total Weight of Boiler Assembly*, filled with water	
	kg	lbs
EC-13	160	353
EC-14	193	426
EC-15	227	501
EC-16	261	575

* Includes burner, circulator and controls

- B. The EC-10 Boiler has full wet base sections which surround fire-box for maximum heat absorption of burning fuel, and low floor temperature.
- C. If boiler is to be located over buried conduit containing electric wires or telephone cables, consult local codes or the National Board of Fire Underwriters for specific requirements.

MINIMUM CLEARANCE

Provide accessibility clearance of 610mm (24") from surfaces requiring servicing (top and front) and 508mm (20") on any side requiring passage. The boiler shall be installed with the following MINIMUM clearances from combustible materials:

- A. CHIMNEY CONNECTOR- 457mm (18")
- B. BACK AND SIDES- 152mm (6") EXCEPT as limited by 457mm (18") clearance from chimney connector

NOTE: Except in closets and alcoves, clearances above in (A) and (B) may be reduced by providing forms of protection as specified in NFPA 31, latest edition.

See bottom of page 4 for clearance diagrams.

CHIMNEY REQUIREMENTS (see CSA B139, latest edition, section 7)

- A. The chimney must be constructed in accordance with all local applicable codes and the National Board of Fire Underwriters. See boiler models and rating table shown on page 2 for chimney sizes.
- B. Check chimney condition. Existing chimneys and stacks may have deteriorated; without repairs their use would be hazardous. Before connecting to an old chimney or stack:
 1. Clean it.
 2. Inspect it thoroughly.
 3. Remove obstructions.
 4. Replace worn sections of metal stacks.
 5. Seal bad masonry joints.
 6. Repair damaged lining.
- C. Breeching area must not be reduced at connection into chimney. Breeching must be inserted into, but not beyond, inside of chimney liner.
- D. Chimney height shall extend at least .914m (3 feet) above where it passes through the roof of the building, and at least .610m (2 feet) above any ridge within 3.05m (10 feet) of the chimney.
- E. The use of a vent cap, where permitted by code, gives additional protection against adverse wind conditions and precipitation.
- F. Flue Connection: Connect flue pipe between top of boiler and chimney. Horizontal sections of flue pipe must be pitched upward to the chimney at least 20mm/m (1/4" per foot). Flue must be inserted into, but not extend beyond, the inside wall of the chimney flue. Draft regulator is not required but may be installed if conditions warrant it. Install draft regulator in flue pipe, as shown in figure 2.

CAUTION: AN OIL-FIRED UNIT SHALL BE CONNECTED TO A VENT HAVING SUFFICIENT DRAFT AT ALL TIMES TO ENSURE SAFE AND PROPER OPERATION OF THE UNIT.

AIR SUPPLY AND VENTILATION (see CSA B139, latest edition, Section 7)

Sufficient air for combustion and ventilation in the boiler room must be provided. Failure to do this will result in poor combustion, heavy sooting and health hazards. Any oil-fired boiler must have a steady draft* and an ample supply of combustion air at all times during firing. If air supply or chimney draft* is unreliable, CO₂ and overfire draft* will change unpredictably.

DO NOT vent this boiler to the same chimney flue used by a fireplace or coal or wood burning furnace or boiler. The draft* produced by solid fueled devices varies tremendously between high fire and low fire:

(continued on page 5)





Figure 2. Barometric Draft Regulator Location

Sufficient space shall be left clear around the boiler. Do not stack items on or near the appliance within the required clearances to combustibles.

● EC-10



Boiler	A mm	A inch
EC-13	565	22-1/4
EC-14	692	27-1/4
EC-15	819	32-1/4
EC-16	946	37-1/4

In modern, weather stripped, energy-saving buildings or older buildings which have been modified similarly, natural infiltration may not supply enough air for combustion, particularly if other fuel burning appliances, exhaust fans or draft inducers are competing for the same air supply. Fireplaces, other solid fuel burning appliances and exhaust fans consume great quantities of air; if air supply is not ample, such an appliance will create a downdraft in the oil-fired boiler flue. This can create a hazardous condition. Flue gases can be sucked out of the chimney through the vent regulator into the living space. DO NOT operate this boiler and a solid fuel burning appliance at the same time, unless the solid fuel burner is provided with its own outside air supply.

See Table 2, "Provisions for Combustion and Ventilation Air Supply" for determining need and method of providing air for combustion and ventilation.

If fly screen must be used over air supply openings, areas calculated should be doubled; the screen should be inspected and cleaned frequently to maintain free air flow.

Protect air openings against closure by snow, debris, etc. Openings such as doors or windows, if used, must be locked open.

* Draft is negative or suction pressure

TABLE 2: Provisions for Combustion and Ventilation Air Supply. See CSA B139, latest edition, section 7, for more detailed information.

	Boiler Location	Air Supply	Action Required
2.1	Unconfined space	Is there sufficient air for combustion by natural infiltration (see NOTE (1), "Test..." below)?	NONE
2.2	Unconfined space	If there is NOT sufficient air for combustion by natural infiltration due to tight construction or other conditions, then it REQUIRES AIR FROM OUTDOORS. SEE "ACTION REQUIRED" column at right. See Notes (1) and (2) below.	Provide air from outdoors directly through a permanent outside wall opening or openings with a free open area of not less than 645 mm ² /1172W (1 sq. in. per 4000 Btu/hr) of TOTAL input of ALL fuel burning appliances in the building. See Note (1) and (3).
2.3	Confined space	If there is sufficient air for combustion from within building but it comes from outside of the confined space, see "ACTION REQUIRED" column at right. See Note (1) below.	The confined space shall be provided with two permanent air openings, one near the top of the enclosure and one near the bottom. EACH opening shall have a free air opening of not less than 645 mm ² /293 W (1 sq. in. per 1000 Btu/hr.) of TOTAL input of ALL fuel burning appliances within the enclosure. The two openings shall freely communicate with the interior areas of the building which in turn would have to have adequate infiltration of air from outdoors. See Notes (1, 3) and Figure 3a.
2.4	Confined space	If there is NOT sufficient air for combustion due to tight construction or other conditions it REQUIRES AIR FROM OUTDOORS. SEE "ACTION REQUIRED" column at right. See NOTE (2) below.	(a) Air from the outdoors shall be provided to the confined space by two permanent openings, one in or near the top of the enclosure space and one in or near the bottom. The openings shall communicate directly, or by means of ducts, with outdoors or to such spaces (crawl or attic) that freely communicate with outdoors (See figures 3b, 3c and 3d). (b) Where directly communicating with outdoors or by means of vertical ducts, each opening shall have a free area of not less than 645 mm ² /1172 W (1 sq. in. per 4,000 Btu/hr.) or 5964 mm ² /litre/hr (35 sq. in. per gal. per hr.) of total input rating of all appliances in the enclosure. If horizontal ducts are used, each opening shall have a free area of not less than 645 mm ² /586 W (1 sq. in. per 2,000 Btu/hr.) or 11928 mm ² /Litre/hr (70 sq. in. per gal. per hr.) of total input of all appliances in the confined space. See Figures 3b, 3c and 3d.

- (1) Test for sufficient air for combustion by infiltration by running this boiler for 30 minutes under all of the following conditions and at the same time: a) all doors, windows and other like openings must be closed, b) all fuel burning appliances should be FIRING, c) all exhaust fans and clothes dryers turned ON. At the above conditions the CO₂, smoke and draft readings must be normal. (CO₂ between 11% and 13%, smoke between ZERO and a TRACE, draft between 0.5 mm (.02") W.C. and 1.0 mm (.04") W.C. negative pressure.)
- (2) Aside from tight construction, some of the conditions that steal air for combustion from a boiler are other fuel burning appliances, exhaust fans and clothes dryers.
- (3) Generally, louvers made of wood have a free open area of 20% and those made of metal have a 60% to 70% free open area. Screens also reduce the open area of the louvers.




Figure 3a. Appliances located in confined spaces. Air from inside the building. See Table 2 (2.3).




Figure 3b. Appliances located in confined spaces. Air from outdoors. See Table 2 (2.4).




Figure 3c. Appliances located in confined spaces. Air from outdoors through ventilated attic. See Table 2 (2.4).




Figure 3d. Appliances located in confined spaces. All air from outdoors through ventilated crawl space and outlet air to ventilated attic. See Table 2 (2.4).

The opening size recommendation just given is for guidance only. It is the installer's responsibility to provide air for combustion and ventilation to all appliances, under all operating conditions, for each installation. See CSA B139, latest edition, Section 7 for more specific details.

INSTALLING CONTROLS AND ACCESSORIES ON BOILER UNITS

Notes: Jacket must be installed on boiler units prior to installation of trim.

WATER BOILER TRIM, see page 2, figures 1 and 2 for tapping locations.

WATER PIPING FOR HOT WATER HEATING BOILERS

I. CIRCULATING SYSTEM

- A. **FORCED CIRCULATION** hot water heating system: Use the top tapping as supply tapping, and use the rear bottom tapping for the return.
- B. A **FLOW CONTROL VALVE** will prevent gravity circulation and is required when an external tankless heater, an indirect water heater or multiple circulators are installed.

II. AIR CONTROL SYSTEMS

- A. **DIAPHRAGM-TYPE COMPRESSION TANKS** are used to control system pressure in an **AIR ELIMINATING SYSTEM**: an automatic air vent is used to REMOVE air from the system water. (See figure 4)
If system pressure needs further control, add an additional tank or install a larger capacity tank.
The automatic air vent should be installed in the top of the boiler, as in figure 4 and at radiation high points.

- B. **CONVENTIONAL COMPRESSION TANKS** (non-diaphragm type) are used to control system pressure in an **AIR COLLECTING SYSTEM**. Within the system, after initial start-up and venting, air is collected in the tank and acts in contact with the water to control pressure. Air is not vented from this system except at radiation high points.

If system pressure needs further control, add another tank in parallel with the original tank or install a large capacity tank. Locate the tank at the inlet end of the pump near the boiler.

- C. **HOT WATER RADIATION VENTING** - Manual air vents should be installed at the top of all "drops" (where piping goes downward). Air must be vented or purged from all zone lines to permit proper system heating.
- D. **PUMP LOCATION** - Locating low-head pump(s) on return to boiler is only acceptable in residences of one or two stories. The pump location shown in figure 4 is required in large, multi-story building installations, especially when high-head pumps are used and is also recommended for all applications.

IMPORTANT: Hot water heating systems containing high water volume, such as would occur with cast iron radiation, require special care with air elimination.

The circulator should be located on the boiler supply pipe and the expansion tank and air scoop should be located near the pump suction. Use the alternate circulator location on return for low-head pumps and one or two story buildings ONLY.




Figure 4. Air Eliminating System or Air Collecting System. Pipe off the relief valve and drain outlet to a safe place.

DOMESTIC HOT WATER

For Indirect-fired storage water heater application, see Slant/Fin publication HWT-10A and Installation manual HWT-40. The installation manual includes several control systems and relay centers for space and domestic water heating in addition to plumbing.

INSTALLING THE BURNER

See Burner Data, pages 13-16, and Burner Manual supplied with burner. If burner is not mounted as received, mount to boiler, placing flange over mounting studs. Use gasket between flange and boiler. Distance between flange and nose of burner must be as shown on pages 13-16. Check to see that nozzle and settings are as given in burner data tables, pages 13-16.

CAUTION: Do Not use gasoline, crankcase drainings, or any oil containing gasoline.

OIL SUPPLY PIPING

Install the oil tank or tanks and piping from tank to burner. Follow local codes and practices, INSTALLATION OF OIL BURNING EQUIPMENT, NFPA 31, latest edition, and the instruction sheet attached to the oil burner pump. A one-pipe system should be used for gravity-fed fuel systems and for lift systems, where the total lift is less than 8 feet. Where the total lift is greater than 8 feet, a two-pipe system must be used. In some instances, local codes may require a two-pipe system for below grade fuel oil tanks. Be sure to set up the fuel oil pump for the piping system used; follow the instructions attached to the pump. Be sure to include a good quality, low pressure drop fuel oil filter in the supply line from the tank. This is necessary, especially at low fuel oil flow rates (small nozzle sizes), to prevent nozzle plugging. Fuel oil shutoff valves should be installed at the burner on the supply (and return if two-pipe) to facilitate servicing.

WIRING THE BOILER

(see Canadian Electric Code CSA-C22.1, Part 1—latest edition)

- A. The wiring diagrams for the burner and boiler may be found on pages 11 and 12.
- B. 24 volt control wiring should be approved Safety Circuit wire, protected as needed.
- C. Power supply wiring to the burner must be 14 gauge, as required, and should have a properly fused disconnect switch. 120 volt wiring to pumps and safety controls must also be 14 gauge. Wire must be enclosed in approved conduit.
- D. The wires supplying power to the burner MUST go through the quick disconnect plugs provided with the boiler.
- E. All wiring must be installed in compliance with the National Electric Code, or any local or insurance codes having jurisdiction.

Wiring to the boiler must come through an emergency power isolation switch with a clearly marked red switch plate. This switch should be located so that it is apparent to the homeowner when entering the basement or other boiler area. The homeowner should be made familiar with operating the toggle to provide or stop the power to the boiler.

VENT PIPING AND DRAFT REGULATOR

(see CSA B139, latest edition, Section 7)

- A. Vent connectors must be the same diameter as the boiler flue collar. (See page 2)

- B. Vent pipes and breeching must be pitched upward a minimum of 20mm/m (1/4" per foot).
- C. Connect vent pipe to the chimney using as few elbows as possible and as short as possible within CSA B139, latest edition, Section 7 or authority.
- D. Horizontal vent connector into the chimney should not be inserted beyond the inside wall of the chimney.
- E. Install barometric draft regulator on horizontal breeching, near chimney, with hinge horizontal and face vertical conditions permitting as in Figure 3a. See Figure 3b as a second choice. See manufacturer's instructions packed in carton with barometric draft regulator.
- F. If two or more appliances are used on the same chimney, see CHIMNEY, page 3.
- G. Make up all joints with minimum air leaks, secure with sheet metal screws.

PRECAUTIONS BEFORE STARTING OIL BURNER

Make a positive check of A through F before starting burner:

- A. Boiler and system are full of water. All air is vented from system. See below.
- B. All wiring is completed. See page 11.
- C. Oil supply is connected to the burner; nozzle is installed correctly; oil valve is open at tank.
- D. Main cast iron door on which burner is mounted is bolted shut and fiberglass rope seal is making good contact.
- E. Smokepipe is connected to chimney.
- F. All combustible materials are cleared away.
- G. Combustion air supply is provided. See page 3.
- H. Burner settings are adjusted as per pages 8, 9, 13-16 and as shown on boiler jacket.

START-UP (COMBUSTION TEST INSTRUMENTS MUST BE USED) THIS BOILER IS A POSITIVE PRESSURE BOILER.

- A. Make sure the boiler is installed and wired properly and is full of water.
- B. The observation port cover is mounted on the hinged burner mounting door. NEVER touch the port cover or any surrounding surfaces with hands. Surfaces may be HOT. Use tools. Loosen the 2 screws and swing cover until window is directly below pivot (and tighten 2 screws) to observe through window. Loosen the 2 screws and swing cover until slot is directly below pivot (and tighten 2 screws) to be able to insert probe through slot. See the burner instructions for bleeding air, etc. Step away from the boiler and start the oil burner.
- C. IMMEDIATELY, set burner air bands to obtain a bright fire without smoke or oil stain. Set the DRAFT REGULATOR to obtain 0.51 – 1.02mm (.02" – .04") draft at the breeching.
- D. Tighten the observation door screw. Allow the burner to fire for at least one hour total firing time, to bake out the volatile binders in the combustion chamber before taking final combustion readings.
- E. By alternate adjustment of the barometric draft regulator, the burner air regulation and head regulation devices (whichever apply), set for a zero to a trace of smoke and 12% CO₂. Then open the air bands or shutter (whichever apply) an additional 3.2mm (1/8"). This should result in zero smoke with NO raw oil on the smoke paper and a smooth light-off. DO NOT ATTEMPT TO SET FIRE BY EYE. Flame retention burners may appear efficient and smoke free from an inefficient 7% up to an overly high 14% CO₂. However, a very low CO₂ can also result in poor ignition and raw (unburned) oil entering the fire box. At very high CO₂, any slight decrease in air flow for any reason will cause incomplete combustion, with high smoke and dry soot formation in the fire box.

- F. Once burner and draft have been set up, then smoke, CO₂ and stack temperature should be checked and recorded. If smoke is greater than trace, review the burner instructions and replace the nozzle if necessary. Normal smoke to be expected is zero to a trace.
- G. Make sure that the observation port cover is closed and the two screws are tightened.

CLEANING AND FILLING A NEW WATER BOILER

- I. There are a number of commercial preparations available from your distributor for cleaning and for corrosion protection conditioning the internal (waterside) surfaces of boilers. Follow the preparation manufacturer's instructions. **DANGER:** Use caution when handling chemicals and draining hot water from a boiler. Scalding water and/or chemicals can cause permanent injury to the skin, eyes and respiratory system.
- II. Filling and venting the water boiler after cleaning
 - A. Refill the system with fresh water.
 - B. Bring water temperature to at least 82°C (180° F) promptly.
 - C. Circulate water through entire system.
 - D. Vent the system, including the radiation.
 - E. The boiler is now ready to be put into service or on standby.
 - F. If brand name air-control devices are used, venting instructions furnished with the devices should be followed.

III. Safety check for control system
 High limit control test: Set thermostat high enough for boiler water temperature to reach high limit control setting. When this temperature is reached, the high limit switch should open, and the burner should shut off automatically. If the high limit does not operate to shut off the burner, the high limit or the wiring is faulty. Repair or replace immediately.


CARE AND MAINTENANCE

- I. EXTENDED SHUTDOWN, CLEANING OR REMOVAL OF BOILER FROM SERVICE.
DANGER: Use CAUTION when handling chemicals and draining hot water from a boiler. Scalding water and/or chemicals can cause permanent injury to the skin, eyes and respiratory system.
 - A. Shut down burner by disconnecting all electrical power to the burner by turning OFF the BURNER EMERGENCY SWITCH of this boiler. After shutting down burner, while the boiler is still hot [82°C to 93°C (180°F to 200°F)], drain water from the bottom of the boiler until it runs clear.

- B. Provide corrosion protection conditioning to the boiler water in the heating system. There are a number of commercial heating system preparations available from your distributor. Follow the preparation manufacturer's instructions.

II CLEANING OF BOILER

- 1. To clean the fireside boiler surfaces, first shut down burner by disconnecting all electrical power to the burner by turning OFF the OIL BURNER EMERGENCY SWITCH of this boiler in order to perform the following in (a) through (h) below.
 - a. Remove the flue pipe from the boiler flue collar clean thoroughly.
 - b. Inspect the entire vent connector back to the chimney and clean if necessary.
 - c. Inspect the chimney for soot, debris and other unsafe conditions of the chimney and take the necessary action.
 - d. Remove the boiler jacket front panel to open burner door as follows:
 - 1. Lift the window.
 - 2. Unscrew the two front panel side attachment screws.
 - 3. Unclip the front panel from the clips and notches near the top, and pull it towards you.
 - 4. Remove the front panel from the notches in the bottom of the side panels.



- e. The burner mounting door must be fully open to clean the flue passages and the combustion chamber. If the oil line is not flexible enough it should be disconnected from the burner during the cleaning process. The flexible electric conduit connected from the junction box on the boiler to the burner via a plastic connector must be disconnected from the burner by grasping the

VOLUME OF WATER IN STANDARD PIPE OR TUBE

Nominal Pipe Size	Standard Steel Pipe				Type L Copper Tube			
	Schedule No.	Inside Diameter	Volume per linear unit.		Inside Diameter	Volume per linear unit.		
mm in.		mm in.	L/m	U.S.G/ft.	mm in.	L/m	U.S.G/ft.	
10 3/8	—	—	—	—	11 0.430	0.093	0.0075	
13 1/2	40	16 0.622	0.195	0.0157	14 0.545	.0150	0.0121	
16 5/8	—	—	—	—	17 0.666	0.225	0.0181	
19 3/4	40	21 0.824	0.344	0.0277	20 0.785	0.311	0.0251	
25 1	40	27 1.049	0.557	0.0449	26 1.025	0.532	0.0429	
32 1 1/4	40	35 1.380	0.967	0.0779	32 1.265	0.810	0.0653	
38 1 1/2	40	41 1.610	1.315	0.106	38 1.505	1.147	0.0924	
51 2	40	53 2.067	2.159	0.174	50 1.985	1.998	0.161	
64 2 1/2	40	63 2.469	3.090	0.249	63 2.465	3.078	0.248	
76 3	40	78 3.068	4.765	0.384	75 2.945	4.393	0.354	

plastic half of the connector closest to the flexible conduit and gently pulling it in the direction of the conduit until it is disconnected. Remove all four 13 mm hex head screws on the sides of the swinging door. You will need a 13 mm open end or box wrench. Open the door to completely expose the combustion chamber for thorough cleaning and for inspection of main cast iron burner door insulation and burner door fiberglass sealing rope. If combustion chamber parts above are badly deteriorated then replace with original factory parts available at your distributor.

- f. Use the flue brush* to clean the flue passages and combustion chamber.
Remove cast iron baffle plates for cleaning [3 baffle plates in EC-13, 2 baffle plates in EC-14 & 15, 0 baffle plates in EC-16]. A wire brush may be used to remove any carbon accumulation that may have developed in the combustion chamber. Vacuum the loose soot and debris from the boiler. Clean and replace baffle plates. Inspect the burner combustion head. Clean if necessary and make sure all the adjustments are correct (See burner data pages for the burner installed). Replace oil nozzle with the new one and re-adjust electrodes. To insure proper burner operation **ONLY THE NOZZLES SPECIFIED IN THIS MANUAL OR ON THE BURNER LABEL SHOULD BE USED FOR REPLACEMENT.**
- g. Close main cast-iron burner door (door on which burner is mounted). Make sure that the entire seal (fiberglass rope) is making good contact with the boiler casting when replacing the four 13 mm hex head screws and tightening.
- h. Replace boiler jacket front panel.

* A flue brush (triangular shape) is supplied with boiler. Replacements are available from dealer or hardware stores.

CAUTION: ALWAYS KEEP THE OIL SUPPLY VALVE SHUT OFF IF THE BURNER IS SHUT DOWN FOR AN EXTENDED PERIOD OF TIME.

II. PROVIDING PROTECTION FOR FREEZING

Anti-freeze is sometimes used in hydronic heating systems to protect against freeze-up in the event of power failure, or safety control shutdown when the building is unoccupied. It should be recognized that unless the building is kept above freezing temperature by some means, the plumbing system is not protected.

PROPYLENE GLYCOL is used in the quick-freeze food industry; it is practically non-toxic. Its use may be permitted when indirect water heaters are used. When anti-freeze must be used, inhibited propylene glycol is recommended. Useful information on the characteristics, mixing proportions, etc. of glycol in heating systems is given in Technical Topics No. 2A, available from the Hydronics Division of GAMA, 35 Russo Place, Berkeley Heights, NJ 07922. Consult glycol manufacturers for sources of propylene glycol.

DO NOT USE ETHYLENE GLYCOL BECAUSE IT IS TOXIC.

III. OIL BURNER

All service to the oil burner, oil filter, oil strainer, etc., should be performed by a professionally trained service person. Inspect and clean annually and following any period of improper operation. Re-check and adjust settings as specified for burner model and nozzle size. Set burner air and draft regulator, using test instruments to obtain recommended CO2 and draft without smoke. See the Burner Data page in this manual that corresponds to the burner installed.

IV. GENERAL MAINTENANCE


These operations are recommended to be performed at regular intervals:

- A. **BOILER HEATING SURFACES:** clean off all coatings found. Reseal covers.
- B. **BOILER CONTROLS:** check contacts, settings, correct functioning.
- C. **PIPING:** check piping and accessories for leaks.
- D. **CHIMNEY or STUB VENT and BREECHING:** check for obstructions and leaks.
- E. **COMBUSTION AIR TO BURNER:** check for continued POSITIVE supply of air as required. Air needs are greatest in coldest weather. Refer to AIR SUPPLY, page 3.
- F. **WATER SYSTEM:** check
 - 1. System to be full of water and pressure to remain stable (between 83 kPa and 173 kPa [12 psi and 25 psi]).
 - 2. Air-control system: noise and air binding in radiation should not occur.
 - 3. Water lines: slightest leaks should be corrected.
- G. **BOILER ROOM AIR SUPPLY:** air vents should be open and free of obstruction. See page 3.

WATER CONTENT OF BOILER


EC-13		EC-14		EC-15		EC-16	
L	USG	L	USG	L	USG	L	USG
18.9	5	24.6	6.5	30.3	8	36.1	9.5

Honeywell L 7248C-1030 Aquastat Control and Honeywell R7184P Primary Single Zone Wiring, if equipped.




47-0013

- ⚠ ELECTRICAL POWER SUPPLY PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED BY CODES.
- ⚠ CONTROL CASE MUST BE CONNECTED TO EARTH GROUND. USE GROUNDING SCREW PROVIDED.
- ⚠ B1 IS 6.4mm (1/4") TAB TERMINAL.
- ⚠ GROUNDING CONDUCTOR: TWO GREEN GROUND WIRES ARE FACTORY CONNECTED TO THE GREEN GROUND SCREW IN THIS BOX. CONNECT THESE WIRES TO THIS SCREW TOGETHER WITH THE TWO GREEN FACTORY CONNECTED GREEN GROUND WIRES.



Honeywell L 7248C-1030 Aquastat Control Multiple Zoned (Circulator or Zone Valve)



⚠ ELECTRICAL POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED BY CODES.


⚠ CONTROL CASE MUST BE CONNECTED TO EARTH GROUND. USE GROUNDING SCREW PROVIDED.

⚠ B1 IS 1/4IN. TAB TERMINAL.

⚠ GROUNDING CONDUCTOR: TWO GREEN GROUND WIRES ARE FACTORY CONNECTED TO THE GREEN GROUND SCREW IN THIS BOX. FIELD WIRE A GROUNDED CONDUCTOR TO THIS SCREW TOGETHER WITH THE TWO GREEN FACTORY CONNECTED GREEN GROUND WIRES.

47-0007

Honeywell L 7248C-Single Zone or Riello Burner



LEGEND

FOR SINGLE AND MULTIPLE ZONED DIAGRAMS

FACTORY WIRING

FIELD WIRING

LINE VOLTAGE

- ⚠ ELECTRICAL POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED BY CODES.
- ⚠ CONTROL CASE MUST BE CONNECTED TO EARTH GROUND. USE GROUNDING SCREW PROVIDED.
- ⚠ B1 IS 1/4 IN. TAB TERMINAL.
- ⚠ GROUNDING CONDUCTOR: A GREEN GROUND WIRE IS FACTORY CONNECTED TO THE GREEN GROUND SCREW IN THIS BOX. FIELD WIRE A GROUND CONDUCTOR TO THIS SCREW TOGETHER WITH THE THE GREEN FACTORY CONNECTED GREEN GROUND WIRE.
- ⚠ WHEN USING MULTIPLE ZONES S/F-10 CONTROL SHOULD BE SET TO DHW PRIORITY.
- ⚠ WHEN USING MULTIPLE ZONED CIRCULATOR METHOD THE CIRCULATOR MUST BE REMOVED FROM THE TB1 CONNECTION.

Honeywell L7248L WITH SF-10 (Tekmar 1012-19) Control.
 SHOWN WITH OPTIONAL MULTIPLE ZONED WIRING METHODS.

BURNER DATA—BECKETT BURNERS FOR PACKAGED BOILERS ONLY

Boiler Model	Burner Model	Blast Tube	Firing Rate		Nozzles			Oil Pump		Approx. Head Setting †	Approx. Air Shutter Setting †	Approx. Air Band Setting	
			L/hr.	GPH	Size L/hr. GPH	Angle & Type	MFR.	kPa	(PSIG)				
EC-13	AFG(MB)	L2	2.46	0.65	1.89	0.5	60*AS	Danfoss	1172	170	n/a	# 9	Closed
			2.65	0.7	1.89	0.5	60*AS	Danfoss	1345	195	n/a	# 10	Closed
			2.46	0.65	1.89	0.5	60*W	Delavan	1172	170	n/a	# 9	Closed
			2.65	0.7	1.89	0.5	60*W	Delavan	1345	195	n/a	# 10	Closed
EC-14	AFG(MB)	L2	3.02	0.8	2.46	0.65	60*W	Delavan	1034	150	n/a	# 10	# 3
			3.40	0.9	2.84	0.75	60*W	Delavan	1000	145	n/a	# 8.5	Closed
EC-15	AFG(MB)	L1	3.78	1	2.84	0.75	60*B	Delavan	1227	178	n/a	# 10	# 1
			4.16	1.1	3.21	0.85	60*B	Delavan	1158	168	n/a	# 10	# 3
EC-16	AFG(MB)	V1	4.35	1.15	3.21	0.85	60*W	Delavan	1276	185	# 0	# 9	Closed
			4.35	1.15	3.21	0.85	60*B	Hago	1276	185	# 0	# 9	Closed

† Air shutter and head settings shown are approximate ONLY. See "START-UP" on page 8.

NOTES:

- (1) Use 2 Slot air band for all models.
- (2) See "PRECAUTIONS BEFORE STARTING OIL BURNERS" and "START-UP" on page 8 and burner figures on this page.
- (3) All burner models shown are single stage.
- (4) EC-13 and EC-14 are supplied with low fire baffle (Beckett # 5880) installed. Remove it when using 3.4 L/hr (.90 GPH).
- (5) Use 3-3/8" U static disc for EC-13 and EC-14. Use 2-3/4" U static disc for EC-15 an EC-16.

It is suggested that due to the positive pressure observed in the chamber that the air tube hole and any other passages of the flue gas leakages be sealed to avoid combustion gas fumes from leaking into the boiler room.

SEE TABLE FOR CORRECT SETTINGS

SHUTTER ADJUSTMENT. SHUTTER OPENS WHEN ROTATED CLOCKWISE. EXAMPLE SHOWN AT N° 6 POSITION. EMBOSSED AIR BAND ADJUSTMENT OPENS WHEN ROTATED CLOCKWISE. EXAMPLE SHOWN AT N° 2 POSITION.




Figure 7.




Figure 8.

Check/Adjust “Z” Dimension – L1 & L2 Heads




Figure 9.

Head Adjustment L1 & L2 Beckett Head

1. See figure above. The important “Z” dimension is the distance from the leading edge of the head to the end of the air tube. This distance for L1 and L2 heads is 35mm (1-3/8”) if the tube has a straight shroud or 44mm (1-3/4”) if the air tube has a conic shroud. The “Z” dimension is factory set for burners shipped with the air tube installed. Even if factory set, verify that the “Z” dimension has not been changed.
2. Use the following procedure to adjust the “Z” dimension, if it is not correct:
 - Turn off power to the burner
 - Disconnect the oil connector tube from the nozzle line.
 - Refer to figure. Loosen the splined nut from the nozzle line. Loosen the hex head screw securing the escutcheon plate to the burner housing.
 - Place the end of a ruler at the leading edge of the head and, using a straight edge across the end of the air tube, measure the distance to the end of the tube. A Beckett T501 gauge may also be used.
 - Slide the nozzle line forward or back until this dimension is 35mm (1-3/8”) for L1 & L2 heads if the tube has a straight shroud, or 44mm (1-3/4”) if the air tube has a conic shroud.
 - Tighten the hex head screw to secure the escutcheon plate to the burner chassis. Then tighten the splined nut and attach the oil connector tube.
3. Recheck the “Z” dimension periodically when servicing to ensure the escutcheon plate has not been moved. You will need to reset the “Z” dimension if you replace the air tube or nozzle line assembly.

Check/Adjust “Z” Dimension – V1 Heads




Figure 10.

Head Adjustment V1 Beckett Head

1. See figure above. The important “Z” dimension is the distance from the leading edge of the head to the end of the air tube. This distance for V1 heads is 44mm (1-3/4”). The “Z” dimension is factory set for burners shipped with the air tube installed. Even if factory set, verify that the “Z” dimension has not been changed.
2. Use the following procedure to adjust the “Z” dimension, if it is not correct:
 - Turn off power to the burner.
 - Disconnect the oil connector tube from the nozzle line.
 - See figure above. Loosen the splined nut from the nozzle line. Loosen the hex head screw securing the head adjusting plate to the burner housing.
 - Loosen the acorn nut. Move the head adjusting plate until the “O” lines up with the reference indicator on the housing, and retighten the hex head screw. Place the end of a ruler at the leading edge of the head and, using a straight edge across the end of the air tube, measure the distance to the end of the tube. A Beckett T501 gauge may also be used.
 - Slide the nozzle line forward or back until this dimension is 44mm (1-3/4”) for V1 heads. Tighten the acorn nut.
 - Tighten the hex head screw to secure the head adjusting plate to the burner chassis. Then tighten the splined nut and attach the oil connector tube.
3. Recheck the “Z” dimension periodically when servicing to ensure the escutcheon plate has not been moved. You will need to reset the “Z” dimension if you replace the air tube or nozzle line assembly.

**BURNER DATA - RIELLO BURNERS FOR PACKAGED BOILERS ONLY
(RIELLO R-40 SERIES W/SHORT TUBE)**


Boiler Model	Burner Model	Blast Tube	Firing Rate		Nozzles				Oil Pump		Approx. Head Setting †	Approx. Air Setting †
			L/hr	GPH	Size L/hr	GPH	Angle & Type	MFR.	kPa	(PSIG)		
EC-13	F-3	#271T1 6" Tube	2.46	0.65	2.08	0.55	80*A	Delavan	965	140	1	3.75
			2.65	0.7	2.08	0.55	80*A	Delavan	1117	162	1	4.1
EC-14	F-5	#271T1 6" Tube	3.02	0.8	2.46	0.65	60*B	Delavan	1034	150	0	2.3
			3.40	0.9	2.84	0.75	60*B	Delavan	1000	145	1	2.5
EC-15	F-5	#271T1 6" Tube	3.78	1.00	3.21	0.85	60*W	Delavan	952	138	1	2.6
			4.16	1.1	3.21	0.85	60*W	Delavan	1158	168	1	3
EC-16	F-5	#271T1 6" Tube	4.35	1.15	3.21	0.85	60*B	Delavan	1276	185	2	2.8
			4.73	1.25	3.78	1.00	60*B	Delavan	1069	155	2	3.2

† Air shutter and head settings shown are approximate ONLY. See START-UP page 8. Seal joint between flange and air tube with a suitable high temperature sealant.

NOTE: Insertion depth is 127mm (5").

It is suggested that due to the positive pressure observed in the chamber that the air tube hole and any other passages of the flue gas leakages be sealed to avoid combustion gas fumes from leaking into the boiler room.

Figure 11A. Riello 40 Series. Model F-3 & F-5 Electrode Setting



BURNER DATA - RIELLO (continued)

REGULATION OF THE TURBULATOR AND AIR SHUTTER FOR PROPER COMBUSTION


Turbulator Setting

1. Loosen nut ①, then turn the screw ②, until the index marker ③ is aligned with the correct index number.
2. Retighten the retaining nut ①.

TURBULATOR SETTINGS - RIELLO 40 SERIES

The numbers on the casting are there to denote the high and low end of the scale - in all cases the first mark is "Zero". The air/oil ratio depends on accurate setting of the turbulator disc. Be careful when making this adjustment as an incorrect setting will result in an unsatisfactory installation. See figure 12A and 12B.

Figure 12A. Model F-5



1. Regulation of the combustion air flow is made by adjustment the manual AIR ADJUSTMENT PLATE ④ after loosening the FIXING SCREWS ③&⑤. The initial setting of the air adjustment plate should be made according to figure 13.
2. The proper number on the manual AIR ADJUSTMENT PLATE ④ should line up with the SETTING INDICATOR ② on the fan housing cover. Once set, the air adjustment plate should be secured in place by tightening SCREWS ③ and ⑤.
3. The final position of the air adjustment plate will vary on each installation. Use instruments to establish the proper settings for maximum CO₂ and a smoke reading of zero.

NOTE: Variations in flue gas, smoke, CO₂ and temperature readings may be experienced when the burner cover is put in place. Therefore, the burner cover **MUST** be in place when making the final combustion instrument readings, to ensure proper test results.

Figure 13. Model F-3, F-5 Air Adjustment





Figure 12B. Model F-3



SETTING THE AIR ADJUSTMENT PLATE

Note: For F-3 and F-5 models, the air shutter is operated on a 120V 60 Hz. motor, the burner will not operate until the air shutter is in its fully open position.

APPENDIX A
THERMOSTATIC BYPASS VALVE

Thermostatic bypass valves type TV are designed to allow boilers to reach their optimum operating temperature quickly and to prevent cool/cold return temperatures from affecting them.

Operation/Installation: The thermostat within the "TV" valve allows full flow through the bypass until the predetermined temperature is reached.


Start Up: With the balancing valve on the bypass fully open, operate the boiler until it reaches its normal operating temperature. If hot water does not automatically flow to the system then adjust (throttle) the bypass balancing valve until

flow (hot water) to the system is established. If flow is already to the system, no adjustment is required.


Return Mounting: On the return "TV" allows full bypass until the return temperature reaches 46 degrees Celsius (115 degrees Fahrenheit). "TV" will begin opening while maintaining a 46 degrees Celsius (115 degrees Fahrenheit) minimum return temperature. When return temperatures reach approximately 54 degrees Celsius (130 degrees Fahrenheit) most of the flow will be through the system.

Mounting: "TV" can be installed in any position. An adjustable balancing valve (or ball valve) must be installed on the bypass.

TYPICAL MOUNTING



TYPICAL RETURN VALVE MOUNTING



SIZE	S/F PART NO.	OPEN TEMP.	A	A/2	Kv	Cv	WEIGHT
25 mm (1") NPT (female x female)	116040	46 °C 115 °F	107 mm 4.2"	53 mm 2.1"	8.96	10.5	1.5 kg 3.3 lb
32 mm (1-1/4") NPT (female x female)	116041	46 °C 115 °F	114 mm 4.5"	57 mm 2.25"	13.99	16.4	2.0 kg 4.4 lb
38 mm (1-1/2") NPT (female x female)	116042	46 °C 115 °F	119 mm 4.7"	60 mm 2.35"	17.23	20.2	2.4 kg 5.3 lb

Max. operating pressure 6 bar (85 psi) Maximum operating temperature 110°C (230°F)

The flow factor Kv is the number of cubic meters per hour of water at 20°C which will flow through the valve with a pressure drop of 1kg/cm² (1 bar).

The flow coefficient Cv is the flow of water at 60°F in US gallons per minute at a pressure drop of 1lb/in² across the valve.

APPENDIX B
THERMOSTAT HEAT ANTICIPATOR SETTINGS

Fixed anticipator thermostats are not adjustable.

Adjustable anticipator thermostats, depending on thermostat model, may be adjustable from a .18 to a .9 setting by moving a pointer on the anticipator.

The higher the anticipator setting (towards .9) the longer it will take for the thermostat to respond to a change in room temperature. Too high a setting and the boiler will be slow to respond to a temperature change in the room. This can cause the room temperature to drop to an uncomfortable level before the boiler starts. This may generate homeowner complaints.

The lower the anticipator setting (toward .18) the faster the thermostat will respond to a change in room temperature. Too low a setting and the boiler will short cycle. Boiler short cycling will cause unnecessary wear on the equipment and in the case of oil boilers it can lead to poor combustion and more frequent cleaning of the combustion area.

It is important to understand what the thermostat is controlling and then determine the amp rating of that relay, gas valve, zone valve or control. This information is usually stamped somewhere on the component. A properly set anticipator will allow the system to operate at its maximum effectiveness.

APPENDIX C
USE OF NON-OXYGEN DIFFUSION BARRIER UNDERFLOOR TUBING

The boiler warranty does not cover leaks resulting from corrosion caused by the use of underfloor plastic tubing without an oxygen diffusion barrier. Systems must have the non-oxygen diffusion barrier tubing separated from the boiler with a heat exchanger,

Slant/Fin recommends the use of underfloor plastic tubing with an oxygen diffusion barrier. Other system components may also require protection from oxygen permeation.

APPENDIX D

WATER QUALITY

Recent investigations of boilers which were installed in hard water areas, revealed that mineral deposits had accumulated at the bottom of the heat exchanger. In addition, sludge, scale and other solid contaminants were present in boilers installed in older systems or where the water was supplied from a well. This accumulation —observed to be 64 mm (2-1/2") or more – creates an insulating layer that drastically affects boiler efficiency by reducing the transmission of heat through this primary transfer surface and causes extreme metal temperatures that eventually crack the heat exchanger.

Note: DOMESTIC TANKLESS HOT WATER COILS ARE HIGHLY SUSCEPTIBLE TO THIS CONTAMINATION

THE TERMS OF THE BOILER WARRANTY WILL NOT APPLY TO FAILURES ENCOUNTERED UNDER THESE CIRCUMSTANCES.

RECOMMENDATIONS:

On all installations in hard water areas:

1. The system should be thoroughly inspected for leaks which must be repaired however minor they may be.

2. The initial water charge of the system must be treated to reduce its hardness to an acceptable level.
3. Where a continuous fresh supply of hard water is fed to the system as with process or steam boilers, it is essential that:
 - a) The feed water is treated to reduce the level of hardness to a point where no significant deposition occurs in the boiler.
 OR
 - b) The treated boiler water circulates through a closed circuit heat exchanger which in turn will heat the distribution system water.

In addition to the aforementioned, older systems and those supplied from wells may require that a filter or strainer be incorporated in the circuit at some point on the return line closest to the boiler. Suitable water treatment filters are commercially available for this purpose.

WE STRONGLY RECOMMEND THAT YOU CONVEY THIS VITAL INFORMATION TO ALL PARTIES CONCERNED.

APPENDIX E

A low water cut-off may be required by local codes. If the boiler is installed above the radiation level, a low water cut-off device must

be installed in all instances. Do not install an isolation valve between the boiler and the low water cut-off.

APPENDIX F:

REMOVAL OF EXISTING BOILER FROM COMMON VENT SYSTEM

- a. Seal any unused openings in the common venting system.
- b. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.
- c. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building. Turn on clothes dryer and any appliance not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. DO NOT operate a summer exhaust fan. Close fireplace dampers.
- d. Place in operation the appliance being inspected Follow the lighting instructions. Adjust thermostat so appliance will operate continuously.
- e. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar or pipe.
- f. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their previous conditions of use.
- g. Any improper operation of the common venting system should be corrected so the installation conforms with the National Fuel Gas Code, ANSI Z223.1-latest edition or CSA B149.1-00 for natural gas and propane. When resizing any portion of the common venting system, the common venting system should be resized to approach the minimum size as determined using the appropriate tables in Appendix G in the National Fuel Gas Code, ANSI Z223.1-latest edition or CSA B149.1-00 for natural gas and propane.




APPENDIX G

EC-10 SERIES BOILERS – INSTRUCTIONS TO REVERSE DOOR OPENING

Reverse the direction of opening of the burner door.

When the boiler leaves the factory, the burner door opens towards the right. To open the burner door towards the left remove the boiler's jackets and perform the following steps:

1. Loosen the top and bottom nuts ① with a 13mm open wrench.
2. Remove the upper and lower hinges ②. You may have to loosen the cast iron hinge pin ③ to facilitate removal of the lower hinge.
3. Remove the cast iron hinge pin ③ which is attached by two 13 mm bolts ④.
4. Re-install the two bolts in the original right hand side holes. Remove the two 13mm bolts ⑤ from the left side and use them to loosely install the cast iron hinge pin ③ on the left side of the burner door.



5. On the left side of the burner door loosen the two nuts on the burner door hinge pins ⑥ and install the upper and lower hinges ②. Tighten the two nuts to secure the hinges and the two 13 mm bolts on the cast iron hinge pin.

©Slant/Fin Corp. 2007.

Slant/Fin®

SLANT/FIN LTD/LTEE, 6450 Northam Drive, Mississauga, Ontario L4V 1H9
 • Phone: (905) 677-8400 / FAX: (905) 677-1829 Order Desk Fax: (905) 677-9015
 www.slantcan.ca / E-mail: orderdesk@slantfin.ca info@slantfin.ca