

PARTS LIST

Refer to the Exploded View Drawing for the location of parts listed below

ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	SCREWM4*10	37	WASHER
2	BUSHING	38	TRIGGERASSEMBLY
3	EXHAUSTCOVER	39	TRIGGERPIN
4	WASHER	40	SCREW M4*16
5	SCREW M5*20	41	WASHER
6	SPRINGWASHER 5	42	OBLIQUEBLOCK
7	CYLINDERCAP	43	SCREW M4*25
8	GASKET	44	DRIVEGUIDE
8a	SPRING	45	LIMITEDBLACK
9	VALVESEAT	46	SLIDEPLATE
10	O-RING 15.7*2	47	BUSHING
11	O-RING 38.8*3	48	SCREW
12	VALVE	49	DRIVEGUIDE
13	O-RING 33.5*3.5	50	SPRING PIN 2.5*12
14	STOPPEDWASHER	51	MOVABLEMAGAZINE
15	COLLAR	52	FEEDERSHOE
16	O-RING 50.5*2.5	53	SPRING
17	O-RING28.3*3	54	FIXEDMAGAZING
18	PISTONASSEMBLY	55	NUTM4
19	CYLINDER	56	MAGAZINGPLATE
20	O-RING 36.3*2.5	57	SCREW M4*6
21	O-RING 35.3*2.5	58	SCREW M4*14
22	BUMPER	59	SPRINGPIN
23	BODY	60	SPRING
24	JOINTGUIDE	61	LOCK
25	SAFEGUIDE	62	JOINTGUIDE
26	SPRING	63	WASHER
27	SAFEBRACKET	64	STOPPEDSCREW
28	SPRING PIN3*26	65	SUPPORT
29	SEAL	66	NUT
30	TRIGGERVALVEHEAD	67	SCREW
31	O-RING 15*1.9	68	SOFTGRIPSLEEVE
32	TRIGGERVALVEGUIDE	69	GASKET
33	O-RING 5.5*1.5	70	ENDCAP
34	SPRING	71	WASHER4
35	TRIGGERVALVESTEM	72	AIRPLUG
36	SPRING		

OPERATING INSTRUCTIONS


18G FLOORING STAPLER

MODEL: 10023321

CONTENTS

SUMMARY -----	1
SPECIFICATIONS -----	1
SAFETY WARNINGS & CAUTIONS -----	1
UNPACKING -----	2
SETTING -----	2
CONNECTING THE TOOL TO AN AIR SUPPLY -----	3
LOADING THE FASTENERS -----	3
OPERATING THE TOOL -----	3
REGULAR MAINTENANCE -----	3
TROUBLE SHOOTING -----	4
EXPLODED VIEW DRAWING -----	5
PARTS LIST -----	6

EXPLODED VIEW DRAWING



TROUBLE SHOOTING

STOP USING THE TOOL IMMEDIATELY IF ANY OF THE FOLLOWING PROBLEMS OCCUR. SERIOUS PERSONAL INJURY COULD OCCUR. ANY REPAIRS OR REPLACEMENTS MUST BE DONE BY A QUALIFIED PERSON OR AN AUTHORIZED SERVICE CENTER ONLY.

PROBLEM	PROBLEM CAUSE	SOLUTION
Air leaking at Trigger area	1. O-ring in trigger valve is damaged. 2. Trigger valve head is damaged. 3. Trigger valve stem, seal or O-ring is damaged.	1. Check and replace O-ring. 2. Check and replace trigger valve head. 3. Check and replace trigger valve stem, seal or O-ring.
Air leaking between body and drive guider	Damaged bumper.	Check and replace bumper.
Air leaking between body and cylinder cap	1. Screw loose. 2. Damaged gasket.	1. Tighten screws. 2. Check and replace gasket.
Blade driving fastener too deeply	1. Worn bumper . 2. Air pressure is too high.	1. Replace bumper. 2. Adjust the air pressure.
Runs slowly or has power loss	1. Insufficient oil. 2. Insufficient air supply. 3. Broken spring in cylinder cap. 4. Exhaust port in cylinder cap is blocked.	1. Lubricate as instructed. 2. Check air supply. 3. Replace spring. 4. Replace damaged internal parts.
Tool skips a fastener	1. Worn bumper or damaged spring (53). 2. Dirt in drive guider. 3. Inadequate airflow to tool. 4. Worn or dry O-ring on piston. 5. Cylinder cap seal leaking.	1. Replace bumper or pusher spring. 2. Clean drive channel of front plate. 3. Check hose and compressor fittings. 4. Replace O-ring or lubricate. 5. Replace seal.
Fasteners are jammed	1. Joint guider is worn. 2. Fasteners are wrong size or damaged. 3. Magazine or front plate screws are loose. 4. Blade in piston assembly is damaged.	1. Replace joint guider. 2. Use the recommended and undamaged fasteners. 3. Tighten screws. 4. Replace piston assembly.
Tool will not drive down tight	1. Worn blade in piston assembly. 2. Lack of power. 3. Slow cycling and loss of power.	1. Replace piston assembly. 2. Adjust to adequate air pressure. 3. Check cylinder cap spring for broken coils or reduced length. Check if exhaust port of cylinder cap is restricted.

READ ALL INSTRUCTIONS BEFORE OPERATING THE TOOL

SUMMARY

You will need the instructions for the safety warning and cautions, assembly instructions, operating and maintaining procedures, exploded view drawing and parts list. Keep your invoice with these instructions. Keep the instructions and invoice in a safe and dry place for future reference.

SPECIFICATIONS

Characteristic	Value
Minimum Operating Air Pressure	60 PSI
Maximum Operating Air Pressure	100 PSI
Stapler Length Range	3/8" -- 1/4"
Stapler Size	18 Gauge
Stapler Capacity	100
Air Inlet	1/4" NPT
Air Consumption	3.8 CFM
Tool Weight	3.59 lbs

SAFETY WARNINGS & CAUTIONS

- KEEP WORKING AREA CLEAN.** Cluttered areas invite injuries.
- DON'T ALLOW CHILDREN AT THE WORKING AREA.** Don't let them handle the tool.
- DO NOT OPERATE THIS TOOL IF UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.** Read warning label on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not attempt to operate.
- USE SAFETY GLASSES.** Safety glasses should conform to ANSI Z87.1 specifications. Before operating, wear safety glasses against flying debris from the front and side. Safety glasses should be worn when loading, operating, unloading or servicing this tool.
- USE EAR PROTECTION.** The working area may be exposed to high noise levels that can lead to hearing damage.
- NEVER USE OXYGEN COMBUSTIBLE GASES, BOTTLED GASES OR HIGH PRESSURE COMPRESSED GAS AS A POWER SOURCE FOR THIS TOOL.** The tool may explode and cause serious injury.
- DRESS SAFELY.** Protective gloves and nonskid footwear or safety shoes are recommended when working with and operating this tool. Don't wear loose clothing or jewelry. They can get caught in moving parts. Also, wear a protective hair covering to prevent long hair from getting caught in the tool.
- DO NOT FIRE INTO HARD MATERIALS.** Do not attempt to shoot toward hard or brittle material such as concrete, steel or tile.
- WHEN OPERATING TOOL.** keep the proper footing and balance to avoid damage resulting from losing balance.
- CHECK DAMAGED PARTS.** Before using tool, carefully check if there is any part damaged.
- REPLACE PARTS AND ACCESSORIES.** Only allow the use of the same replacement parts while servicing. Approved accessories and replacement parts are available.
- KEEP ALERT.** Watch what you are doing. Use common sense. Do not operate any tool when you are tired.

13. **STORE THE TOOL.** When not in use, tool should be cleaned, fully assembled and then, stored in a dry location to reduce rust. For safety, keep out of reach of children.
14. **OUTDOOR EXTENSION CORDS.** When air compressor is used outdoors, use only rounded jacket extension cords intended for outside use. See manufacturer's manual for the AWG required for the compressor's amperage draw.
15. **PAY ATTENTION TO AIR HOSE AND THEIR CONNECTIONS.** Don't trip over hoses. Make sure all connections are tight.
16. **AFTER LOADING THE FASTENERS.** never point the tool at yourself or bystanders.
17. **USE THE CORRECT AIR CONNECTOR.** The connector on the tool must not hold pressure when the air supply is disconnected. If the wrong fitting is used, the tool can be charged with air after being disconnected and still be able to drive a fastener.
18. **WHEN CONNECTING THE AIR.** The tool may possibly fire the fasteners as soon as you plug it in to air hose. Therefore, remove all the fasteners before connecting to the air.
19. **DO NOT DEPRESS THE TRIGGER WHEN LOADING.**
20. **IF THE FASTENERS ARE JAMMED.** Disconnect the tool from the air and remove the jammed fasteners.

WARNING: The warning, caution, and instructions explained in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that COMMON SENSE AND CAUTION ARE FACTORS WHICH CANNOT BE BUILT INTO THIS PRODUCT, BUT MUST BE SUPPLIED BY THE OPERATOR.

UNPACKING

When unpacking, check and make sure that all the accessories are included. If anyone is missed or broken, please call seller for help. Refer to the follow lists.

Description	Qty
Stapler	1
S3 Hex Key	1
S4 Hex Key	1
Air Tool Oil	1
Operating instruction	1
Teflon Tape	1

SETTING

Your air tool is fully assembled when you receive it. Before using it, attach the air line and desired air system accessories. See Figure 1 for the recommended accessories and connection order. Be sure the air hose is depressurized when installing or removing adapters to the air line.




Figure 1
2

CONNECTING THE TOOL TO AN AIR SUPPLY

1. Determine if the tool needs oil and, if necessary, place two drops of oil in the AIR PLUG(72) as shown in Figure 2. If you are using an automatic in-line oiler, check and add oil if necessary.
2. Turn the compressor on and set the regulator to the proper pressure for the size and type of fastener being used.
3. Connect the tool to the air supply (see Setup for air supply connection recommendations).




Figure 2

LOADING THE FASTENERS

1. Depress the LOCK(60) to release the MOVABLE MAGAZINE (51) and pull the magazine out fully as shown in Figure 3.
2. Place a full clip of the specified type and size fasteners on the FIXED MAGAZINE (54), up to 100 fasteners may be loaded in the magazine.
3. Push the MOVABLE MAGAZINE ASSEMBLY forward until it is locked.




Figure 3

OPERATING THE TOOL

Test the driving depth in a sample piece of wood before using. If the fasteners are being driven too far or not far enough, adjust the regulator to provide less air pressure or more air pressure.

1. Connect the tool to the air supply. Make sure the air pressure is in correct range denoted in section of SPECIFICATIONS.
2. Load fastener as above the direction given in the section called LOAD THE FASTENER.
3. Hold the Body (23) and press the Drive guide (44) to work surface, be sure the tool is straight and then gently depress the Trigger (38) to drive the fastener.
4. Lift the tool off the work surface.

REGULAR MAINTENANCE

1. Frequent, but not excessive, lubrication is required for best performance. Oil added through the airline connection will lubricate internal parts. An automatic airline oiler is recommended but oil may be added manually before every operation or after about 1 hour of continuous use. Only a few drops of oil at a time are necessary. Too much oil will collect inside the tool and be blown out during the exhaust cycle. **ONLY USE PNEUMATIC TOOL OIL.** Do not use detergent oil or additives, as these lubricants will cause accelerated wear to the seal in the tool.
2. Use a small amount of oil on all moving surface and pivots.
3. Dirt and water in the air supply are major causes of pneumatic tool wear. Use a filter/oiler for better performance and longer life. The filter must have adequate flow capacity for the specific application. Consult the manufacturer's instructions for proper maintenance of your filter.
4. Keep tools clean for better and safer performance. Use nonflammable cleaning solutions (**CAUTION:** Such solutions may damage O-ring and other tool parts) only if necessary- **DO NOT SOAK.**