

PME 500

Rated Capacity Indicator, Rated Capacity Controller, Machine Envelope Controller

Operators Manual



Your safety, your profit, our commitment

This guide describes operation of the

PROLEC PME LIFTING AND MACHINE ENVELOPE SAFETY SYSTEM FOR CON-
STRUCTION PLANT

Model covered :	PART No.	MODEL Ref
	PME500	PME500 - RCI / RCC / MEC SYSTEM

Prolec supports a nationwide network of fully trained service engineers. Warranty claims, service work, technical information and spare parts are available by contacting :

Prolec Ltd	Telephone	+44 (0) 1202 681190
25 Benson Road	Fax	+44 (0) 1202 67790
Nuffield Industrial Estate	E-mail	service@prolec.co.uk
Poole Dorset BH17 0GB		

DURING NORMAL OPERATION THE SAFE WORKING LOAD OF A CRANE SHOULD NOT BE EXCEEDED. THEREFORE THE WARNING OF OVERLOAD SHOULD NOT BE USED AS A NORMAL OPERATING FACILITY. IT SHOULD BE NOTED THAT CERTAIN STATUTORY REQUIREMENTS DO NOT PERMIT THE SAFE WORKING LOAD TO BE EXCEEDED EXCEPT FOR THE PURPOSE OF TESTING.

THIS RATED CAPACITY INDICATOR / CONTROLLER (RCI, RCC) IS NOT SUITABLE FOR USE IN EXPLOSIVE ATMOSPHERES. ADJUSTMENT BY UNAUTHORISED PERSONS WILL INVALIDATE ANY WARRANTY OR CERTIFICATION SUPPLIED. IF A PROBLEM ARISES WHICH CANNOT BE RECTIFIED USING THIS GUIDE, AUTHORISED SERVICE SHOULD BE SOUGHT.

THIS DEVICE IS CERTIFIED TO MEET CURRENT UK & EC SAFETY REGULATIONS FOR LIFTING OPERATIONS.

Any alterations or modifications to machine components which affect this system and any system component failure must be reported to Prolec Ltd or via the machine convertor/ service agreement holder. This manual must be kept with the product and be passed on to any subsequent user of the product.

Whilst every effort has been made to ensure the accuracy of the information supplied in this manual, Prolec Ltd cannot be held responsible for any errors or omissions.

Manufacturers original instructions.

Table of contents

1	Use of this Document	8
2	Notices	8
3	System Identification	9
4	Operating and Restriction Situation Recommendations	10
	4.1 MEC Override	10
5	Operating Instructions	11
	5.1 Power Up	11
	5.2 Using the Display	12
	5.3 User Login	13
	5.4 User Logout	14
6	Top Menu	14
	6.1 Tool Selection Menu	15
7	Rated Capacity Indicator / Controller	16
	7.1 Introduction	16
	7.2 Operation within the Safe Working Load	17
	7.3 Approach to Overload	17
	7.4 Stability Indication Overload	18
	7.4.1 Hydraulic Limit Indication	18
	7.5 Stability Control Overload	19
	7.5.1 Hydraulic Limit Control	19

Continued

Table of contents (continued)

7.6	Overload / Hydraulic Limitation Control Override	20
7.6.1	Soft Override	20
7.6.2	Master Override Key Switch	20
7.7	Lift Mode Menu	21
7.8	Lifting Point Selection	21
7.9	Lifting Duties	22
7.10	Load Chart Menu	23
7.11	Safe Working Area Indication	24
7.12	Lifting Mode - Non Lifting Mode	25
7.13	Alternative Lifting Mode Screens	26
8	Envelope Monitoring	27
8.1	Height Limit	28
8.1.1	Height Limits Menu	28
8.1.2	Height Limit Setting - Known Height	29
8.1.3	Height Limit Setting - Using Current Highest Point	30
8.1.4	Machine Envelope Controller (MEC) - Height	31
8.2	Max Radius Limit	
8.2.1	Max Radius Limits Menu	32
8.2.2	Max Radius Limit Setting - Known Radius	33
8.1.3	Max Radius Limit Setting - Using Current Furthest Point	34
8.1.4	Machine Envelope Controller (MEC) - Max Radius	35
8.3	Min Radius Limit	
8.3.1	Min Radius Limits Menu	36

Continued

Table of contents (continued)

8.3.2	Min Radius Limit Setting - Known Radius	37
8.3.3	Min Radius Limit Setting - Using Current nearest Point	38
8.3.4	Machine Envelope Controller (MEC) - Min Radius	39
8.4	Low Limit	
8.4.1	Low Limits Menu	40
8.4.2	Low Limit Setting - Known Radius	41
8.4.3	Low Limit Setting - Using Current Lowest Point	42
8.4.4	Machine Envelope Controller (MEC) - Low	43
8.5	Slew Limits Menu	44
8.5.1	Angular Slew Restriction - Using current Slew Angle	45
8.5.2	Virtual Wall Restriction - using virtual wall	47
8.5.3	Twin Virtual Wall Restriction - using twin virtual wall	49
8.5.4	Multipoint Wall Restriction - using Multipoint Wall	51
8.5.5	Machine Envelope Controller (MEC) - Slew / Wall	54
9	System Messages	55
9.1	On Screen Messages	55
9.2	LED and Internal Alarm Warnings	56
10	Daily checks	56
11	Repair	56

Table of contents (continued)

12	Test / Diagnostics	57
	12.1 Relay Function Test	57
	12.2 Slew Angle	58
	12.3 Beacon, LED Alarm Function Test	58
13	System Information	59
14	Display Settings	59
	14.1 Day / Night Mode	60
	14.2 Select Display Machine	60
	14.3 Select Safe Working Area Indication	61
	14.4 Select Language	62
15	User Login	62
	15.1 User Login Setup	62
	15.2 Add New User to Login	63
	15.3 Edit User Details	64
	15.4 Select User to Delete	65
	15.5 Edit User Access Code	66
	15.6 Enable / Disable Users	66
16	Taking Product out of Operation	66
17	Service and Repair	66
	17.1 Maintenance Review	66
18	Definitions / Glossary	67

1 Use of this Document

This user guide is intended for persons familiar with the use of construction plant undertaking lifting operations.



WARNING denotes information about particular risks which may be generated by certain applications, by using certain fittings, and about additional protective measures which are necessary for such applications.

Caution, care, risk situation



HAZARD Actions that can lead to serious injury or death

2 Notices



Adjustment by unauthorised persons will invalidate any warranty or certification supplied. If an error condition is displayed which cannot be rectified using this guide, halt any operation, seek authorised service immediately and do not continue operation until the fault has been remedied.

3 System Identification



The PME system provides two primary safety functions

1. Lifting Stability
2. Machine Envelope Monitoring

Both safety functions are achieved through real time monitoring some or all of the machine's moving parts (booms, other articulations, turret etc) and its environment (ground pitch and inclination, load etc) and actively determining the safety of the current operation where appropriate limits have been set.

The Lifting Stability function falls into two sub classes



- Rated capacity indicators (RCI) warn of potential instability when the machine is involved in lifting operations. Any motion which reduces the safe working load will not be inhibited at any time.



- Rated capacity controllers (RCC) prevent instability when the machine is involved in lifting operations. This is achieved by hydraulically stopping unsafe movements of the machine which could cause the machine to tip.

The Machine Envelope Monitoring function has a single class



- Machine envelope controllers (MEC) prevent movements that would bring parts of the machine into hazardous areas, most notably height restrictions when working under overhead wires.

During operation the indicators on the left are displayed on the screen to clearly identify the function supported by your PME500. Functions may not be available i.e. when in non-lifting mode or when envelope monitoring is switched off, if this is the case a cross will be painted over the relevant function icon.

Combinations of these functions may be present, it is essential that the functions of the system installed are identified and understood.

4 Operating and Hazard Situation Recommendations



Operating Recommendations

When using envelope monitoring:

- When setting a slew restriction, make sure any implement attached is in its least favourable position
- Check for correct operation once the restriction or restriction have been set
- Reduce operating speed
- Do not move the equipment quickly when close to a restriction
- Do not operate the machine in a reckless manor
- Do not travel with a restriction set
- Do not travel
- Reset the slew restriction if the machine is relocated

When operating the machine as a crane:

- Ensure Lift Mode is selected during lifting operations
- Operate the machine at a sensible speed
- Take extra care when travelling with a load attached
- Do not operate the machine in a reckless manner

Hazard Situation Recommendations

In a limit hazard state:

- Return the control levers to neutral once a limit has been reached if appropriate
- Operate the machine at a slow speed
- Do not travel

4.1 MEC Override



The system can optionally be fitted with a key operated master override switch. Turning the switch to the override position will allow normal operation of any of the hydraulic services regardless of safety status. When the unit is in override the external alarms will stay active, and the beacon (if fitted) will indicate that the machine is overridden, the red LED will flash and an 'In Override' message will appear on the display.

5 Operating Instructions

5.1 Power Up

The PME system automatically powers up when the machines ignition is switched on. The in-cab unit incorporates a 4.3" high resolution LCD display and is controlled with three buttons at each side. Three status LEDs and an internal alarm provide further information.



The system will perform a self check at start up:

1. All LEDs will flash, the internal display alarm and the external alarm will sound.
2. The RED LED will light indicating the system is starting and performing a self test.
3. Once the self test is complete, the GREEN LED will light and the system will become active. A safety warning message is displayed, pressing any button activates Lifting Mode. Any previous limits set will be enabled. The system is now ready for use.
4. The system can be configured to require a user login - if this is enabled, see section 5.3.

If the RED LED remains lit, a fault has been detected, halt any operation, seek authorised service immediately and do not continue operation until the fault has been remedied.




The display is secured to the machine using a flexible ball mounting allowing easy adjustment for personal viewing preference.

5.2 Using the Display

The display is operated by using the buttons adjacent to a function icon. The buttons can open a sub menu, turn a function ON or OFF, set a value, toggle through multiple screens, no one button has a single function. The button icon will turn black/purple when the button has been activated. Note that the image of the machine is fixed and does not follow the movement of the machine.

Multifunction buttons:
The action of the button is indicated by the adjacent icon.



A secondary symbol can appear in the top left corner of an icon, these mean :



The plus symbol indicates a sub menu will be opened if selected.



The cycle symbol indicates that multiple features are available.



The on/off symbols indicate if a feature is ON or OFF. Red is ON and grey is OFF.

Help is available for each button. To access the help, push and hold the button for three seconds. The help screen can be cleared by pressing any of the six buttons. PME is still active when displaying help messages, if the Lifting Mode is active and or a height limit is set any alarm or warning condition will be indicated.




5.3 User Login

If PME has been configured to work with the built-in user list, the system will prompt for a user login pass code. Select the user name required and the login code screen will appear.



Using the arrow buttons to enter a valid pass code. The previous pass code digits will be replaced with a star as the code is entered. Press the TICK button to confirm the login pass code. If a valid pass code is entered the system will commence normal operation.




If an incorrect login code is entered, a failure screen will be displayed. Press the TICK button to return to the Select User screen.



5.4 User Logout

If a user is logged in as the current user, they can select the logout screen by holding an exit key down for three seconds.



Once logout has been confirmed the login screen will be automatically displayed. Press the CROSS button to stay logged in, the screen will return to that previously shown.

6 Top Menu


The Top Menu screen allows access to all the system functions. To reveal the icons, if hidden, press any button. To return to the Top Menu from a sub menu press the EXIT button until the Top Menu is displayed.

Top Menu button functions:

- Limits menu
- Lifting menu
- Tool selection
- Test / Diagnostics
- Lifting Mode ON and OFF
- Hide icons




To hide the icons when at the Top Menu, press the EXIT button once more.



6.1 Tool Selection Menu



The system can monitor the position of a tool and so be calibrated with, one or multiple tools. If more than one tool has been calibrated, it will be manually selected via the Select tool selection screen shown below. Use the arrow buttons to select the required tool and confirm using the TICK button. Example tools are shown in the listing.



Different tools allow for monitoring of the tool point and the tool width only, other extremities are not taken into account.


When setting any limit the tool fitted should be set to its least favourable position.

If no tool or tools have been calibrated this screen will not be accessible and any implement attached will not be monitored.

7 Rated Capacity Indicator / Controller

7.1 Introduction



The PME500 RCI/RCC has been designed to meet European requirements for the provision of rated capacity indicators. PME500 ensures that the maximum lifting capacity over the range of a machine working envelope can be utilised. The system will always start up in Lifting Mode. See section 4 for operating advice when using construction plant as a crane. The Lifting Mode feature can be used in conjunction with envelope monitoring, see section 8. In this mode, the beacon (if fitted) will indicate that the Lifting Mode functionality is active.




1. Lift point radius is the horizontal distance in metres from the slew centre line to the lifting point.
2. Current lifting duty in use.
3. Current lift point in use.
4. Safe Directional indicators. The triangles on both sides of each piece of equipment and slew arrows indicate if it is safe GREEN, or unsafe RED to move the relevant articulation and direction in that direction under overload condition occurs. Triangles also indicate safe direction of movement when in breach of a height limit. A value red border indicates that the articulation is limited by hydraulic capacity and not by machine stability.
5. RCI / RCC - MEC indicators (see section 3)
6. Maximum Safe Working Load (SWL) for the current lifting point height and radius combination. The value is given in metric tonnes.
7. SWL percentage bar graph indicating the percentage of the current load to the maximum available safe working load.
8. Load on Hook (LOH) shows the current load in tonnes suspended from the lifting point.

The SWL as displayed assumes that the load is suspended directly below the lifting point. The weight of the tool or tools, if fitted, (e.g. Bucket, quick hitch etc) are included in the SWL and LOH values if they were taken into consideration when the system was calibrated. The bucket cylinder and control linkage is assumed to be present.

7.2 Operation within the Safe Working Load



  With the Lifting Mode active, the current lifting point radius and the maximum safe working load for that radius are shown.




If the load is less than 95% of the maximum safe working load

- The load capacity indicator will be green
- The green LED will be lit

7.3 Approach to Overload

  With the Lifting Mode active, if the load is greater than 95% of the maximum safe working load the system will warn the machine is approaching the lifting capacity at the current height and radius.



If the load is greater than 95% of the maximum safe working load.

- The load capacity indicator will be amber
- The amber LED will be lit
- The internal alarm will sound
- The message shown here will be displayed.




In the event of an approach to overload or an overload condition, the lifting point should only be moved in a direction that increases the safe working load. See section 4 for further information.

7.4 Stability Indication Overload



The system indicates an overload condition via internal and external alarms only - no motion is cut.




If the load is greater than 105% of the maximum safe working load

- The load capacity indicator will be red
- The red LED will flash
- The internal and external alarm will sound
- The message shown here will be displayed
- Unsafe motion is indicated by RED arrows, safe motion is indicated by GREEN arrows

7.4.1 Hydraulic Limit Indication

If a particular lift is limited by hydraulic capacity rather than stability, the directional indicator on the articulation in question will have a **RED** border. Hydraulic limitation is more likely to occur at short radii.




In the event of an approach to overload or an overload condition, the lifting point should only be moved in a direction that increases the safe working load. See section 4 for further information.

7.5 Stability Control Overload



Where an overload condition occurs the machine hydraulics will be locked to prevent any further dangerous movements. Only those movements that allow safer operation remain active. The radius cannot be increased and the load cannot be raised. The internal and external alarms will sound in conjunction with visual indicators on the display.




If the load is greater than 105% of the maximum safe working load

- The load capacity indicator will be red
- The red LED will flash
- The internal and external alarm will sound
- The message shown here will be displayed
- Motion control of the machine will operate, motion cut is indicated by RED arrows, safe motion is indicated by GREEN arrows

7.5.1 Hydraulic Limitation Control

The system will cut motion to the appropriate articulation in a hydraulic limit state via internal and external alarms in conjunction with visual indicators on the display.

*Where an overload condition occurs the machine hydraulics will be locked to prevent any further dangerous movements. Only those movements that allow safer operation remain active. The radius cannot be increased and the load cannot be raised.




After three seconds a soft override will become available, see section 7.6.1



In the event of an approach to overload or an overload condition, the lifting point should only be moved in a direction that increases the safe working load. See section 4 for further information.


7.6 Overload / Hydraulic Limitation Control Override

7.6.1 Soft Override

 After three seconds a soft override button will replace the Lifting Mode button. If soft override is utilised, the machine hydraulics will be re-enabled. However, the external alarm will stay active, the red LED will flash, and the beacon (if fitted) will switch off. Once the alarm condition has been corrected the RCC will automatically clear the override request and revert to normal operation.



7.6.2 Master Override key Switch


 The system can optionally be fitted with a key operated Master override switch. Turning the switch to the override position will allow normal operation of any of the hydraulic services regardless of safety status. When the unit is in override the external alarms will stay active, and the beacon (if fitted) will indicate that the machine is overridden, the red LED will flash and an In Override message will appear on the display. See section 4.1 for further details.



7.7 Lift Mode Menu



The Lifting Mode function has various features which may be available if configured at installation. The configuration will depend on the operating procedures of the machine owner. If only one duty, lifting point and or tool has been calibrated, the relevant icon will not be displayed.



Lifting point selection


Displays load chart(s)

Exit to previous screen

7.8 Lifting Point Selection



The current lifting point is indicated on Lifting Mode screen. The system can be calibrated with just one lifting point for use in any duty. If more than one lifting point has been calibrated, it will be manually selected via the lifting point selection screen shown below. Use the arrow buttons to select the required lifting point and confirm using the TICK button. Example lifting points are shown in the listing.



Exit without change

Moves highlighter UP

Accept highlighted lifting point

Moves highlighter DOWN

Multiple lifting points allow different lifting capacities to be achieved, altering the lifting point will not affect the current duty selected (See section 7.9).

7.9 Lifting Duties


The current duty is indicated on the Lifting Mode screen. The system can be calibrated with just one duty for use throughout 360 degrees of slew, most machines will be calibrated in this way.

If more than one duty has been calibrated, it will either be selected by slew angle or automatically selected using a switch or other input.




Equipment based duties may be axle status, support blade stabiliser position, telescopic extension position, and or secondary equipment. These lists are not exhaustive. Altering the duty will not affect the current lifting point selected (See section 7.8).

Over Side Duty



Slew angle based duties may be Over Side and Over Front / Rear lifting arcs for increased lifting capacity. Example above shows Safe Working Area switched on (See section 7.11, 14.2)

7.10 Load Chart Menu



PME can display the load chart for the currently selected lifting duty and lifting point. *If the machine is equipped with a hydraulically adjustable boom, both maximum and minimum charts will be available. Hydraulically adjustable booms allow the machine to reach the same point in space (i.e. height and radius combination) with a variety of different equipment angles. The minimum loads shown refer to the least favourable angle combination. When load charts are being displayed, machine safety status is still monitored.


The screenshot shows a grid of SWL values for different lifting points. The grid has columns for radius (1.0 to 12.0) and rows for height (0.0 to 10.0). A red border highlights a specific cell at height 4.0 and radius 1.0. Below the grid, the duty name 'Duty: 360deg - Lift Point: Tool Pin' and hydraulic limits for 'Boom' and 'Arm' are visible. On the right side, there are control buttons for information, ON/OFF, and exit.

Callouts and their descriptions:


- Lifting point Radius**: Points to the top row of the grid.
- Lifting point Height**: Points to the left column of the grid.
- Hydraulically limited SWL**: Points to the red-bordered cell at height 4.0 and radius 1.0.
- Duty name and Lifting point name**: Points to the text 'Duty: 360deg - Lift Point: Tool Pin'.
- SWL values**: Points to the numerical data in the grid.
- *Displays maximum load chart**: Points to the top right corner of the grid.
- Switches information bar ON [ON icon] and OFF [OFF icon]**: Points to the information and power buttons.
- Exit to previous menu**: Points to the back arrow button.

If a particular lift is limited by hydraulic capacity rather than stability, the directional indicator on the articulation in question will have a **RED** border. The maximum load for duties limited by stability is stated as a percentage of the 'tipping load' and in a standard installation will be 75%.

7.11 Safe Working Area Indication




Safe working area indication displays the where a load can be safely moved using the plan view. It can be turned on and off in Displays Setting screen 4. (See section 7.8, 14.2)



With Safe Working Indication ON:
 The Green area indicates the safe zone
 The Hatched area indicates the hazard zone


Any green area is safe and any hatched area is unsafe.



With Safe Working Indication ON:
 Over Front duty
 Over Side Duty
 Over Rear Duty

This feature does not indicate duties automatically switched using proximity switches such as extending sections or stabilisers.

The hatched area uses the LOH value and the SWL value for all slew based duties to calculate the green and hatched area.




7.12 Lifting Mode - Non Lifting Mode





When the machine is not being used for lifting operations it can be put into 'Non Lifting Mode' available from the Top Menu screen.

When in Non Lifting Mode, the system still monitors all machine activity and safety status but will NOT warn of overload conditions. In this mode, the beacon (if fitted) will indicate that the Lifting Mode functionality is NOT active. Lifting mode cannot be activated if the LOH value exceeds a predefined weight. Envelope Limit monitoring will remain active if any limit has been set.




Lifting Mode ON



Note Lift Mode button is not accessible

Lifting Mode OFF



RCI / RCC



OFF: when operating with an inactive limit the indicator will have a cross painted on it.









When in Non Lifting Mode, the screen states NON-LIFTING MODE on the hazard warning tape and a red cross appears in the RCI RCC indicator - lifting operations should not be attempted in this state. The beacon (if fitted) will be off.

7.13 Alternative Lifting Mode Screens



Alternative Lifting Mode screens can be selected from the Display Settings screen (See section 13). The three selectable screens show safe working load, load on hook, lifting point radius and bar graph or dial indicating the proximity of the current load to the maximum available safe working load. Pressing the EXIT button will hide the icons. Press any button to reveal the icons.




8 Envelope Monitoring



PME500 is configured for Machine Envelope Control (MEC) only. MEC will warn and prevent equipment motion. MEC is achieved by interacting with the machines hydraulics, this allows motion to be cut to any section of equipment that has reached a restriction but allow other sections to operate unhindered unless they too reach the set restriction.

When setting a limit, either by entering a known value or by positioning the machine at the desired limit, make sure any implement attached is in its least favourable position as the system is unaware of any implement fitted.

PME500 can monitor the highest, furthest, nearest, lowest part of the machine and slew angle taking into consideration the counterweight when used with a virtual wall type restriction, but may not be unaware of any implement fitted therefore make sure any implement attached is in its least favourable position.



MEC



OFF: when operating with an inactive limit the indicator will have a cross painted on it.



ON: when operating with an active limit the indicator will not have a painted on cross on it.

Care should be taken to test that the limit or limits are set correctly.

Observe the operational limitations given in section 4.



8.1 Height Limit

8.1.2 Height Limit Menu




A height limit can be set by entering a known height on the keypad or by manually moving the machine to the desired limit.

Current highest point. Only displayed if a height limit is set.

Switches height monitoring ON  and OFF 

Enter a height

Set height limit using current highest part of equipment




Exit to previous menu




Using the height Limits Menu, the height limit can be switched ON and OFF (a Confirm Operation screen will be displayed, see sections 8.1.2 to enter a known height and section 8.1.3 for setting the limit by moving the machine).




With a height limit set, the screen will display normally display the current highest point value. To display the current limit value, exit to the full screen and hold any button for three seconds, the value will then turn blue indicating it is the current limit value.




8.1.2 Height Limit Setting - Known Height



A known limit can be entered into the display:



Press the 'Enter a value' button



Once a height limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.

8.1.3 Height Limit Setting - Using Current Highest Point



Move equipment to required height limit and press this button




To set the height limit using the machine, move the equipment to the desired maximum height, and press the 'current highest point' button. A confirmation box will appear reporting the height set. Press the TICK button to





8.1.4 Machine Envelope Controller (MEC) - Height



If any of the equipment enters the approach limit* an 'Approaching max height' message will appear, the internal alarm will beep and the amber LED will be lit. If any of the equipment reaches the height limit, the appropriate motions will be controlled.





 MEC systems will cut motion to any section of equipment that has reached a limit but allow other sections to operate unhindered unless they too reach the set limit.



*The approach limit is configurable at point of calibration, check system operation before commencing work.

See sections 4.1 and 7.6 for hydraulic override details.



  Once a height limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.



8.2.1 Max Radius Limit

8.2.1 Max Radius Limit Menu




A max radius limit can be set by entering a known radius on the keypad or by manually moving the machine to the desired limit.

Switches max radius monitoring

ON  and OFF 

Enter a value

Set radius limit using current farthest part of equipment



Current furthest point. Only displayed if a max radius limit is set.


Exit to previous menu



Using the Max Radius Limits Menu, the max radius limit can be switched ON and OFF, a max radius limit can be set to a known value, or the max radius limit can be set to the current farthest point.

See sections 8.2.2 to enter a known max radius and section 8.2.3 for setting the limit by moving the machine.

With a Max radius limit set, the screen will display normally display the current furthest point value. To display the current limit value, exit to the full screen and hold any button for three seconds, the value will then turn blue indicating it is the current limit value.




Once a max radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.2.2 Max Radius Limit Setting - Known Radius



A known limit can be entered into the display:




Press the 'Enter a value' button




Use the UP and DOWN arrows to increase and decrease the highlighted number. Use the LEFT and RIGHT arrows to move the highlighter to the left and to the right.





 Once a max radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.



8.2.3 Max Radius Limit Setting - Using Current furthest Point



Move equipment to required max radius limit and press this button

To set the max radius limit using the machine, move the equipment to the desired radius, and press the 'current farthest point' button. A confirmation box will appear reporting the radius set. Press the TICK button to continue.




  Once a max radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.2.4 Machine Envelope Controller (MEC) - Max Radius



If any of the equipment enters the approach limit* an 'Approaching max radius' message will appear, the internal alarm will beep and the amber LED will be lit. If any of the equipment reaches the max radius limit, the appropriate motions will be controlled.



MEC systems will cut motion to any section of equipment that has reached a limit but allow other sections to operate unhindered unless they too reach the set limit.



*The approach limit is configurable at point of calibration, check system operation before commencing work.

See sections 4.1 and 7.6 for hydraulic override details.



Once a max radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.3 Min Radius

8.3.1 Min Radius Limit Menu




A min radius limit can be set by entering a known radius on the keypad or by manually moving the machine to the desired limit.

Switches min radius monitoring

ON  and OFF 

Enter a height

Set min radius limit using current nearest part of equipment




Exit to previous menu

Current nearest point. Only displayed if a height limit is set.



Using the Min Radius Limits Menu, the min radius limit can be switched ON and OFF, see sections 8.3.2 to enter a known min radius and section 8.3.3 for setting the min radius by moving the machine.

With a Min radius limit set, the screen will display normally display the current nearest point value. To display the current limit value, exit to the full screen and hold any button for three seconds, the value will then turn blue indicating it is the current limit value.




Once a min radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.

8.3.2 Min Radius Limit Setting - Known Min Radius




A known min radius can be entered into the display:



Press the 'Enter a value' button



Use the UP and DOWN arrows to increase and decrease the highlighted number. Use the LEFT and RIGHT arrows to move the highlighter to the left and to the right.




Once a min radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.



8.3.3 Min Radius Limit Setting - Using Current nearest Point



Move equipment to required min radius limit and press this button



To set the min radius limit using the machine, move the equipment to the desired minimum radius, and press the 'current nearest point' button. A confirmation box will appear reporting the radius set. Press the TICK button to continue.




Once a min radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.3.4 Machine Envelope Controller (MEC) - Min Radius



If any of the equipment enters the approach limit* an 'Approaching min radius' message will appear, the internal alarm will beep and the amber LED will be lit. If any of the equipment reaches the min radius limit, the appropriate motions will be controlled.



MEC systems will cut motion to any section of equipment that has reached a limit but allow other sections to operate unhindered unless they too reach the set limit.



*The approach limit is configurable at point of calibration, check system operation before commencing work.


See sections 4.1 and 7.6 for hydraulic override details.



Once a min radius limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the current limit. Always check that the current limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.

8.4 Low Limits

8.4.1 Low Limit Menu



A low limit can be set by entering a known height on the keypad or by manually moving the machine to the desired limit.

Switches low monitoring
ON and OFF

Enter a value

Set low limit using current lowest part of equipment

Exit to previous menu

Current lowest point. Only displayed if a low limit is set.



Using the Low Limits Menu, the low limit can be switched ON and OFF, a low limit can be set to a known value, or the low limit can be set to the current lowest point.

See sections 8.4.2 to enter a known low and section 8.4.3 for setting the limit by moving the machine.

With a Low limit set, the screen will display normally display the current furthest point value. To display the current limit value, exit to the full screen and hold any button for three seconds, the value will then turn blue indicating it is the current limit value.




Once a low limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the limit. Always check that the low limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.

8.4.2 Low Limit Setting - Known Low Menu



A known low limit can be entered into the display:



Press the 'Enter a value' button




Use the UP and DOWN arrows to increase and decrease the highlighted number. Use the LEFT and RIGHT arrows to move the highlighter to the left and to the right.





Once a low limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the limit. Always check that the low limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.

8.4.3 Low Limit Setting - using Current Low



Move equipment to required low limit and press this button

To set the low limit using the machine, move the equipment to the desired low height, and press the 'current lowest point' button. A confirmation box will appear reporting the height set. Press the TICK button to continue.




Once a low limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the limit. Always check that the low limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.4.4 Machine Envelope Controller (MEC) - Low



If any of the equipment enters the approach limit* an 'Approaching min height' message will appear, the internal alarm will beep and the amber LED will be lit. If any of the equipment reaches the low limit, the appropriate motions will be controlled.



MEC systems will cut motion to any section of equipment that has reached a limit but allow other sections to operate unhindered unless they too reach the set limit.



*The approach limit is configurable at point of calibration, check system operation before commencing work.

See sections 4.1 and 7.6 for hydraulic override details.






Once a low limit set, the internal alarm will sound and the RED LED will light if the equipment exceeds the limit. Always check that the low limit activates at the set point. The restriction cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4.


8.5 Slew Limits Menu




Slew restriction can be set by manually moving the machine to the desired limit. Slew limits screen shown here. Do not travel once a slew limit has been set.

Switches slew monitoring ON  and OFF 

Press this button to start the setup procedure 




Select Slew restriction type 

Current hazard zone shown if a slew limit is ON.

Exit to previous menu 




Using the Slew Limits Menu, the Slew limit can be switched ON and OFF (a Confirm Operation screen will be displayed). The type of slew restriction can be selected and is be set by moving the machine.



With the slew limit ON:

The Green area indicates the safe zone

The Hatched area indicates the hazard zone



The type of slew restriction cannot be altered if a limit is currently ON. The warning message must be acknowledged.




If altering the type of slew Restriction the current limit will be lost. If the slew limit was not successfully set then a warning message which must be acknowledged will be displayed.




8.5.1 Angular Slew Limit Setting - using Current Slew Angle



Select angular slew limiting, follow the on screen instructions. Do not travel once a slew limit has been set.




Press this button to start the setup procedure



Step One


Step by step instructional banner

Extend equipment as appropriate



Step two

Move to the left slew limit, press any button to set the left limit. A marker will be placed to indicate its position




Continued on next page

Step three


Move to the right slew limit, press any button to set the left limit. Another marker will be placed here

Slew left restriction marker



Step four



Press any button to complete.



The hatched hazard zone will be shown on the main screen.

Check the limits are working as required.

Safe Directional indicators. The left and right arrows indicate if it is safe GREEN, or unsafe RED to slew in that direction



Once slew limits are set, the internal alarm will sound and the RED LED will light if the equipment exceeds the either limit. Always check that the slew limit activates at the set points. The restriction cannot be deactivated if in the alarm state. Do not travel. Observe the operational limitations given in section 4. Do not travel once a slew limit has been set.


8.5.2 Virtual Wall Limit Setting - using Virtual Wall



Select single vertical wall limiting, follow the on screen instructions. Do not travel once a slew limit has been set.




Press this button to start the setup procedure



Step One

Step by step instructional banner


Move the dipper to one end of the virtual wall, press any button to set the limit. A marker will be placed here.



Step two

Move the dipper to the other end of the virtual wall, press any button to set the limit.


Virtual wall marker



Continued on next page


Step three

Move the equipment away from the limit and press any button to complete.




The hatched hazard zone will be shown on the main screen.

Check the limit is working as required.



Safe Directional indicators. The triangles indicate if it is safe GREEN, or unsafe RED to movement a particular articulation.

Safe Directional indicators. The left and right arrows indicate if it is safe GREEN, or unsafe RED to slew in that direction.



Once slew limits are set, the internal alarm will sound and the RED LED will light if the equipment exceeds the either limit. Always check that the slew limits activates at the set points. The limits cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4. Do not travel once a slew limit has been set.


8.5.3 Twin Virtual Wall Limit Setting - using Twin Virtual Walls



Select twin vertical wall limiting, follow the on screen instructions. Do not travel once a slew limit has been set.

Set to twin Virtual Wall


Press this button to start the setup procedure



Step One

Step by step instructional banner


Move the end of the dipper to one end of the FIRST virtual wall, press any button. A marker will be placed here.



Step two


Move the end of the dipper to the other end of the FIRST virtual wall, press any button. A marker will be placed here.

Virtual wall marker




Step three

Move the end of the dipper to one end of the SECOND virtual wall, press any button. A marker will be placed here.




Step four

Move the dipper to the other end of the SECOND virtual wall, press any button. A marker will be placed here.




Step four

Move the equipment away from the limit and press any button to complete.




The hatched hazard zones will be shown on the main screen.

Check the limits are working as required.



Safe Directional indicators. The triangles indicate if it is safe GREEN, or unsafe RED to movement a particular articulation.

Safe Directional indicators. The left and right arrows indicate if it is safe GREEN, or unsafe RED to slew in that direction.




Once slew limits are set, the internal alarm will sound and the RED LED will light if the equipment exceeds the either limit. Always check that the slew limits activates at the set points. The limits cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4. Do not travel once a slew limit has been set.



8.5.4 Multipoint Envelope Restriction- using Multipoint Wall



Select multipoint envelope restriction, follow the on screen instructions. Do not travel once a slew limit has been set.




Any number of points can be used, four are shown in the example below.



Step One





Move the end of the dipper to the FIRST point of the box, press any button. A marker will be placed here.




Step two

Move the end of the dipper to the SECOND point of the box, press any button. A marker will be placed here.



Step three

Move the end of the dipper to the THIRD point of the box, press any button. A marker will be placed here.




Step four

Confirm if another position is needed, the tick is selected in this example




Step five

Move the end of the dipper to the FORTH point of the box, press any button. A marker will be placed here.




Step six

Confirm if another position is needed, the cross is selected in this example



Step seven


Move the end of the dipper the equipment away from the limit and press any button to complete.




Continued on next page

The hatched hazard zones will be shown on the main screen.

Check the limits are working as required.



Safe Directional indicators. The triangles indicate if it is safe GREEN, or unsafe RED to movement a particular articulation.




Safe Directional indicators. The left and right arrows indicate if it is safe GREEN, or unsafe RED to slew in that direction.





Once slew limits are set, the internal alarm will sound and the RED LED will light if the equipment exceeds the either limit. Always check that the slew limits activates at the set points. The limits cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4. Do not travel once a slew limit has been set.


8.5.5 Machine Envelope Controller (MEC) - Slew and Virtual Wall



If the equipment enters the approach limit* an 'Approaching slew limit' message will appear, the internal alarm will beep and the amber LED will be lit.




If the equipment reaches the limit, the appropriate motion will be controlled.





- The safe directional indicators will be red. Unsafe motion is indicated by RED arrows/triangles, safe motion is indicated by GREEN arrows/ triangles
- The red LED will flash
- The internal alarm will sound
- A warning message will be displayed

*The approach limit is configurable at point of calibration, check system operation before commencing work.

 See sections 7.6 for hydraulic override details.



  Once slew limits are set, the internal alarm will sound and the RED LED will light if the equipment exceeds the either limit. Always check that the slew limits activates at the set points. The limits cannot be deactivated if in the alarm state. Observe the operational limitations given in section 4. Do not travel once a slew limit has been set.

9 System Messages

9.1 On Screen Messages








Approaching max height	Highest point of equipment within *0.5m of set limit
Maximum height exceeded	Equipment has reached/exceeded set limit
Approaching max radius	Furthest point of equipment within *0.5m of set limit
Maximum radius exceeded	Equipment has reached/exceeded set limit
Approaching min radius	Nearest point of equipment within *0.5m of set limit
Minimum radius exceeded	Equipment has reached/exceeded set limit
Approaching min height	Lowest point of equipment within *0.5m of set limit
Minimum height exceeded	Equipment has reached/exceeded set limit
Approaching Slew limit	Equipment within *10 degrees or 0.5m of set limit
Slew Limit exceeded	Equipment has reached/exceeded set limit
Approaching SWL	95 percent of the maximum safe working load
Overload	105 percent of the maximum safe working load
Hydraulic Limit	Pressure in the lift rams is in excess of 87% of main relief valve pressure
In Override	Override has been activated (Soft or master Key)

*The approach limit is configurable at point of calibration, check system operation before commencing work.

PME continuously monitors the presence and condition of the safety controller and sensors. If the safety controller or any sensor fails an error message box will appear at the bottom of the display. In the event of a failure, the cab mounted beacon (if fitted) will indicate that the system is NOT active, the display red LED will flash and the internal and external alarms will sound.

9.2 LED and Internal Alarm Warnings

The table below shows the state of the three LEDs on the display and the internal alarm with respect to system status.

LED and Internal Alarm status	System status
	Off
	Start up, Power Down
	Operational: System OK, no warnings, hazards, or errors
	Warning: Approach to overload or envelope limit
	Hazard; Overload or breach of an envelope limit
	Maintenance: Engineering access active
	Error: PME hardware/software error, or sensor failure

10 Daily Checks

- Display - check for damage and correct operational
- Safety Controller - check for damage and correct operational
- Sensors and sensor cabling - check for damage
- Connectors - check for damage
- Alarm / beacon functionality
- Automatic Duty Selection

See section 11 for test / diagnosis features. If an issue is discovered which cannot be rectified using this guide, halt any operation, seek authorised service immediately and do not continue operation until the fault has been remedied.

11 Repair

Once a repair has been carried out and tested, the following must be checked:

<u>Required Checks</u>	<u>Section</u>
Angles Check	12.1
Relay Check	12.2
Alarm, LED and Beacon Check	12.3
Maintenance review	16.1

12 Test / Diagnostics



The system test function is available from the main operating screen. This option allows the functionality of the system to be verified, and basic troubleshooting to be performed. In this mode, the amber LED will flash to indicate that the system is in maintenance mode. The system will continue to monitor any limits that are active and the Lifting Mode (if active) will continue to monitor machine safety status. Alarm conditions and warnings / controls will be issued as normal.

The screenshot shows the 'Test/Diagnostics Menu' with a table of sensor data and several control icons. The table is as follows:

Name	Sensor	Raw	Actual	Status
Boom Base	Piston	176.40	N/A	OK
Boom Base	Rod	0.00	N/A	OK
Boom	AS7	69.78	-44.10	OK
Arm	AS7	34.01	-23.39	OK
Platform	Slew	-20.00	34.62	OK

Below the table, the 'Machine Error Status' is shown as 'OK'. The menu includes several icons: a stethoscope (Relay / LED test), a beacon (Beacon and Alarm test), a smartphone (Display options), a gear (System information), a plus sign (Code protected access to supervisor features), and a door (Exit to previous menu). A label 'Equipment sensor angle' points to the table.

The image shown is an example only. The exact contents of the sensor list will depend on machine type and PME specification.

12.1 Relay Function Test




The screenshot shows a panel of lights and buttons labeled 'Link/Ign Fail'. The panel includes a red light, a blue light, and several other indicators. A blue arrow points to the right, and a green arrow points to the left. A door icon is at the bottom right.


Operate show status of feature

Exit to previous menu

12.2 Slew Angle



Boom = Slew angle
 Arm = Slew angle
 Platform = Slew angle




Exit to previous menu


12.3 Beacon, LED Alarm Function Test




Press the Beacon button to activate the alarm



Press the Alarm button to activate the LEDs



Press the Alarm button to activate the beacon



13 System Information



Information regarding the system can be found from this menu.

The screenshot shows the 'License Information' menu with the following callouts:

- Software Version**: Points to the information icon (i) in the top left.
- License information**: Points to the license key text: 'License Key: 1F020A6F7A7F7F020A03'.
- Distributor information**: Points to the distributor icon (person) in the bottom left.
- LOLER information**: Points to the LOLER icon (document) in the top right.
- Machine information**: Points to the machine icon (excavator) in the middle right.
- Exit to previous menu**: Points to the back arrow icon in the bottom right.

14 Display Settings



The display brightness, button click volume, and the displayed machine colour and type can be adjusted from this menu.

The screenshot shows the 'Display Settings' menu with the following callouts:

- Adjust button click volume**: Points to the volume icon (speaker with X) in the top left.
- Select day / night mode**: Points to the day/night mode toggle with 'ON' and 'OFF' labels and corresponding icons.
- Select machine colour / type**: Points to the machine selection area showing 'SLW' and a yellow excavator icon.
- Alternative Lifting Mode screen selection (See section 6.7)**: Points to the alternative lifting mode icon (circular dial) in the top right.
- Language selection**: Points to the language selection icons (flags) in the middle right.
- Exit to previous menu**: Points to the back arrow icon in the bottom right.

14.1 Day / Night Mode



To make viewing the display more comfortable at night, the display brightness can be switched to a preset 'night mode'. The system will default to day mode on power up.

Select day / night mode:

Day mode ON Full display brightness		Night mode ON Reduced display brightness	
--	--	---	--

14.2 Select Display Machine



An appropriate machine type for the display can be selected from this list.

Exit without change

			Moves highlighter UP
			Accept highlighted
			Moves highlighter DOWN


↓

			Moves highlighter UP
			Accept highlighted turret
			Moves highlighter DOWN


14.3 Select Safe Working Area Indication



Safe working area indication displays the where a load can be safely moved using the plan view. It can be turned on and off in Displays Setting screen 4. (See section 7.8, 7.11)



Any green area is safe and any hatched area is unsafe.



With Safe Working Indication ON:
The Green area indicates the safe zone
The Hatched area indicates the hazard zone

The hatched area uses the LOH value and the SWL value for all slew based duties to calculate the green and hatched area.

This feature does not indicate duties automatically switched using proximity switches such as axles, extending sections or stabilisers.

14.4 Select Language



An appropriate machine type for the display can be selected from this list.

Exit without change

Moves highlighter UP

Accept highlighted language

Moves highlighter DOWN

The screenshot shows a 'Select Language' menu with options: Dutch, English (highlighted), French, German, and Russian. Navigation arrows (UP, DOWN) are on the right, and a checkmark icon is on the right of the highlighted option. A left-pointing arrow icon is on the left of the menu, with a callout 'Exit without change'.

15 User Login

15.1 User Login Setup



Requires supervisor access rights.

Add new user

Select user to edit

Select user to delete

Edit user login code

Select user(s) to be displayed on login screen


Exit to previous menu

The screenshot shows a 'User Settings Menu' with a central image of a yellow excavator. On the left, there are three user icons with callouts: 'Add new user' (plus icon), 'Select user to edit' (wrench icon), and 'Select user to delete' (minus icon). On the right, there are three icons with callouts: 'Edit user login code' (key icon), 'Select user(s) to be displayed on login screen' (checkbox icon), and 'Exit to previous menu' (left arrow icon). The menu also displays technical data: LOH:2.04t, 41%, SWL:5.01t.

15.2 Add New User to Login



Requires supervisor access code




15.3 Edit User Details



Requires supervisor access rights.

Cancel without change



Moves highlighter UP

Select highlighted user

Moves highlighter DOWN



Toggle to / from keyboard

Moves highlighter to right

Accept displayed name

Highlight cross and press tick to exit without change




Scroll up though highlighted digits/ letters

Moves highlighter to left

Scroll down though highlighted digits/ letters



Return to previous screen



Moves highlighter UP

Select highlighted Privilege


Moves highlighter DOWN



Cancel without change

Moves highlighter to right / Hold to delete digit

Accept displayed value



Increases highlighted digit

Moves highlighter to left / Hold to delete digit

Decreases highlighted digit

15.4 Select User to Delete



Requires supervisor access rights.

		Moves highlighter UP
Exit without change		Delete highlighted
		Moves highlighter DOWN

15.5 Edit User Access Code



Requires supervisor access rights.

		Moves highlighter UP
Exit without change		Accept highlighted user
		Moves highlighter DOWN



Cancel without change				Increases highlighted digit
Moves highlighter to right / Hold to delete digit				Moves highlighter to left / Hold to delete number
Accept displayed value				Decreases highlighted digit

15.6 Enable / Disable Users



Requires supervisor access rights

The screenshot shows a 'Select User(s)' window with a list of users: Fred Smith [OPERATOR], Steve Higgins [OPERATOR], and Artie Tate [OPERATOR]. The window has several controls: a green checkmark icon, a red 'X' icon, a green checkmark icon, and a blue arrow icon. Callouts point to these controls with the following text:

- Select / deselect (pointing to the top-left checkbox)
- Cancel without change (pointing to the red 'X' icon)
- Select / deselect (pointing to the bottom-left checkbox)
- Edit user login code (pointing to the blue arrow icon)
- Select user(s) to be displayed on login screen (pointing to the green checkmark icon)
- Exit to previous menu (pointing to the blue arrow icon)

16 Taking Product out of Operation



Prolec Limited is committed to complying with the upcoming European Directive of RoHS (Restriction of Certain Hazardous Substances) and WEEE (Waste from Electrical and Electronic Equipment). PME is subject to the WEEE directive, therefore PME or any component must be returned to Prolec Ltd for correct disposal or recycling.

The display and safety controller are fitted with internal batteries and must not be disposed of in landfill.

17 Service and Repair

PME has very few user serviceable parts. The safety controller has internal fuses that, in the event of a blown fuse, can be replaced. The service section describes daily, monthly and yearly checks that must be carried out to ensure safe operation of the system.

17.1 Maintenance Review

Due to nature of the PME system operating environment, changes in usage can occur. Prolec Ltd must be notified of any changes in the pattern of use of the system for consideration.

Any alterations or modifications to machine components which affect the system must be reported to Prolec Ltd or via the service agreement holder.

To aid in the use of PME, all appropriate technical bulletins relating to PME are to be assessed and implemented as appropriate. This information is available from Prolec Ltd.

Prolec Ltd must be informed of any Prolec system component failure. Be it directly or via the service agreement holder.

Technical consultation is available to the user, contact Prolec Ltd or the service agreement holder.

Prolec Ltd	Telephone	+44 (0) 1202 681190
25 Benson Road	Fax	+44 (0) 1202 677909
Nuffield Industrial Estate	Email	service@prolec.co.uk
Poole Dorset BH17 0GB		

18 Definitions / Glossary

Definitions of words used to ensure understanding

P/N	Part Number
Boom	First articulation connected to turret
Arm	Second articulation
Artic	Second articulation of a hydraulically adjustable boom (luffing boom, knuckle boom, two piece boom)
Turret	Section of machine above the undercarriage
Undercarriage	Section which the tracks/wheels attach too
Track	continuous band of treads, metal or rubber covered
Wheeled excavator	An excavator fitted with wheels
Tracked excavator	An excavator fitted with tracks, also known as
Bucket	Digging attachment
Attachment	Tool fixed to the dipper other than a bucket
SC	Safety Controller
MMI	Man Machine Interface (i.e. Display)
CAN cable	Cable connecting system components
Angle sensor	Sensor detecting current equipment angle
Pitch	Longitudinal base machine angle (fore / aft)
Roll	Lateral base machine angle (side to side)
Motion Cut	Direct control of component hydraulic service
Power Supply	DC supply voltage
Ram	Hydraulic Cylinder
Blade	heavy metal plate on the front of the machine, used for stability and moving material
Stabiliser	Hydraulically powered arms that can be lowered and raised to increase the Stability of the machine
Counterweight	Weight attached to the rear of an excavator to increase digging force and lifting capacity
Pivot pin	Point at which the articulations rotate about
Relay	Electronic device to operate motion cut valve

562500-000, Issue1.0, May 2013

**Prolec Ltd
25 Benson Road
Nuffield Industrial Estate
Poole
England
BH17 0GB
Tel: +44 (0)1202 681190
E-mail: service@prolec.co.uk**

Prolec Ltd® is a James Fisher Company