

# TROUBLESHOOTING

## ENGINE

Complaint	Symptom and possible causes	Remedy
<p><b>Engine will not start or is hard to start.</b></p>	<p><b>Compression too low</b></p> <ol style="list-style-type: none"> <li>1. Worn cylinder.</li> <li>2. Worn piston ring.</li> <li>3. Worn valve guide or improper valve seating.</li> <li>4. Loose spark plug.</li> <li>5. Broken, cracked, or damaged piston.</li> <li>6. Slow cranking starter motor. (DR-Z400E)</li> <li>7. Mistimed valves.</li> <li>8. Tappet clearance out of adjustment.</li> </ol> <p><b>Spark plug not sparking</b></p> <ol style="list-style-type: none"> <li>1. Damaged spark plug.</li> <li>2. Damaged spark plug cap.</li> <li>3. Fouled spark plug.</li> <li>4. Wet spark plug.</li> <li>5. Defective ignition coil.</li> <li>6. Open or short in high-tension cord.</li> <li>7. Defective generator.</li> <li>8. Defective CDI unit.</li> </ol> <p><b>No fuel reaching the carburetor</b></p> <ol style="list-style-type: none"> <li>1. Clogged fuel tank vent hose.</li> <li>2. Clogged or defective fuel valve.</li> <li>3. Defective carburetor needle valve.</li> <li>4. Clogged fuel hose.</li> <li>5. Clogged fuel filter.</li> </ol>	<p>Replace. Replace. Repair or replace. Tighten. Replace. See electrical section. Adjust. Adjust.</p> <p>Replace. Replace. Clean or replace. Clean and dry or replace. Replace. Replace. Replace. Replace.</p> <p>Clean or replace. Clean or replace. Replace. Clean or replace. Clean or replace.</p>
<p><b>Engine stalls easily.</b></p>	<ol style="list-style-type: none"> <li>1. Fouled spark plug.</li> <li>2. Defective generator.</li> <li>3. Defective CDI unit.</li> <li>4. Clogged or defective fuel valve.</li> <li>5. Clogged carburetor jet.</li> <li>6. Tappet clearance out of adjustment.</li> </ol>	<p>Clean or replace. Replace. Replace. Clean or replace. Clean. Adjust.</p>

Complaint	Symptom and possible causes	Remedy
<b>Engine is noisy.</b>	<p><b>Excessive valve chatter</b></p> <ol style="list-style-type: none"> <li>1. Excessive tappet clearance.</li> <li>2. Weak or broken valve spring.</li> <li>3. Worn camshaft.</li> <li>4. Worn or burnt camshaft journal.</li> </ol> <p><b>Noise seems to come from the piston</b></p> <ol style="list-style-type: none"> <li>1. Worn piston.</li> <li>2. Worn cylinder.</li> <li>3. Carbon buildup in combustion chamber.</li> <li>4. Worn piston pin or piston pin bore.</li> <li>5. Worn piston ring or ring groove.</li> </ol> <p><b>Noise seems to come from the cam chain</b></p> <ol style="list-style-type: none"> <li>1. Stretched cam chain.</li> <li>2. Worn cam chain sprocket.</li> <li>3. Improperly working cam chain tensioner.</li> </ol> <p><b>Noise seems to come from the clutch</b></p> <ol style="list-style-type: none"> <li>1. Worn countershaft spline.</li> <li>2. Worn clutch hub spline.</li> <li>3. Worn clutch plate teeth.</li> <li>4. Distorted clutch plate.</li> <li>5. Weak clutch damper.</li> <li>6. Weak clutch spring.</li> </ol> <p><b>Noise seems to come from the crankshaft</b></p> <ol style="list-style-type: none"> <li>1. Rattling bearing.</li> <li>2. Worn or burnt crank pin bearing.</li> <li>3. Worn or burnt journal bearing.</li> <li>4. Excessive thrust clearance.</li> </ol> <p><b>Noise seems to come from the transmission</b></p> <ol style="list-style-type: none"> <li>1. Worn or rubbing gear.</li> <li>2. Worn countershaft spline.</li> <li>3. Worn driveshaft spline.</li> <li>4. Worn or rubbing primary gear.</li> <li>5. Worn bearing.</li> </ol>	<p>Adjust. Replace. Replace. Replace.</p> <p>Replace. Replace. Clean. Replace. Replace.</p> <p>Replace cam chain and sprockets. Replace cam chain and sprockets. Repair or replace.</p> <p>Replace countershaft. Replace clutch hub. Replace clutch plate. Replace. Replace primary driven gear. Replace.</p> <p>Replace. Replace. Replace. Replace thrust bearing.</p> <p>Replace. Replace countershaft. Replace driveshaft. Replace. Replace.</p>
<b>Clutch slips.</b>	<ol style="list-style-type: none"> <li>1. Clutch cable out of adjustment.</li> <li>2. Weak or broken clutch spring.</li> <li>3. Worn or distorted clutch pressure plate.</li> <li>4. Distorted clutch plate.</li> </ol>	<p>Adjust. Replace. Replace. Replace.</p>
<b>Clutch drags.</b>	<ol style="list-style-type: none"> <li>1. Clutch out of adjustment.</li> <li>2. Some clutch springs are weak, while others are not.</li> <li>3. Worn or distorted clutch pressure plate.</li> <li>4. Distorted clutch plate.</li> </ol>	<p>Adjust. Replace. Replace. Replace.</p>
<b>Transmission will not shift.</b>	<ol style="list-style-type: none"> <li>1. Broken gearshift cam.</li> <li>2. Distorted gearshift fork.</li> <li>3. Worn gearshift pawl.</li> </ol>	<p>Replace. Replace. Replace.</p>
<b>Transmission will not shift back.</b>	<ol style="list-style-type: none"> <li>1. Broken gearshift shaft return spring.</li> <li>2. Rubbing or stuck gearshift shaft.</li> <li>3. Worn or distorted gearshift fork.</li> </ol>	<p>Replace. Repair or replace. Replace.</p>

Complaint	Symptom and possible causes	Remedy
<b>Transmission jumps out of gear.</b>	<ol style="list-style-type: none"> <li>1. Worn gear.</li> <li>2. Worn or distorted gearshift fork.</li> <li>3. Weakened gearshift stopper spring.</li> <li>4. Worn gearshift pawl.</li> </ol>	Replace. Replace. Replace. Replace.
<b>Engine idles poorly.</b>	<ol style="list-style-type: none"> <li>1. Tappet clearance out of adjustment.</li> <li>2. Improper valve seating.</li> <li>3. Worn valve guide.</li> <li>4. Worn camshaft.</li> <li>5. Excessive spark plug gap.</li> <li>6. Defective ignition coil.</li> <li>7. Defective generator.</li> <li>8. Defective CDI unit.</li> <li>9. Incorrect float chamber fuel level.</li> <li>10. Clogged carburetor jet.</li> </ol>	Adjust. Repair or replace. Replace. Replace. Adjust or replace. Replace. Replace. Replace. Adjust float height. Clean.
<b>Engine runs poorly in high-speed range.</b>	<ol style="list-style-type: none"> <li>1. Weak valve spring.</li> <li>2. Worn camshaft.</li> <li>3. Insufficient spark plug gap.</li> <li>4. Mistimed valves.</li> <li>5. Ignition not advanced sufficiently due to poorly working timing advance circuit.</li> <li>6. Defective ignition coil.</li> <li>7. Defective generator.</li> <li>8. Defective CDI unit.</li> <li>9. Low float chamber fuel level.</li> <li>10. Dirty air cleaner element.</li> <li>11. Clogged fuel hose, resulting in inadequate fuel supply to carburetor.</li> </ol>	Replace. Replace. Regap or replace. Adjust. Replace CDI unit.  Replace. Replace. Replace. Adjust float height. Clean or replace. Clean and prime.
<b>Exhaust smoke is dirty or thick.</b>	<ol style="list-style-type: none"> <li>1. Excessive amount of engine oil.</li> <li>2. Worn cylinder.</li> <li>3. Worn piston ring.</li> <li>4. Worn valve guide.</li> <li>5. Scored or scuffed cylinder wall.</li> <li>6. Worn valve stem.</li> <li>7. Defective valve stem oil seal.</li> <li>8. Worn oil ring side rail.</li> </ol>	Check level and drain. Rebore or replace. Replace. Replace. Replace. Replace valve. Replace. Replace oil ring.
<b>Engine lacks power.</b>	<ol style="list-style-type: none"> <li>1. Insufficient tappet clearance.</li> <li>2. Weak valve spring.</li> <li>3. Mistimed valves.</li> <li>4. Worn cylinder.</li> <li>5. Worn piston ring.</li> <li>6. Improper valve seating.</li> <li>7. Fouled spark plug.</li> <li>8. Incorrect spark plug.</li> <li>9. Clogged carburetor jet.</li> <li>10. Incorrect float chamber fuel level.</li> <li>11. Dirty air cleaner element.</li> <li>12. Air leakage from intake pipe.</li> <li>13. Excessive amount of engine oil.</li> </ol>	Adjust. Replace. Adjust. Replace. Replace. Repair or replace. Clean or replace. Replace. Clean. Adjust float height. Clean or replace. Tighten or replace. Check level and drain.

Complaint	Symptom and possible causes	Remedy
<b>Engine overheats.</b>	<ol style="list-style-type: none"> <li>1. Carbon buildup on piston crown.</li> <li>2. Insufficient amount of engine oil.</li> <li>3. Defective oil pump.</li> <li>4. Clogged oil circuit.</li> <li>5. Float chamber fuel level too low.</li> <li>6. Air leakage from intake pipe.</li> <li>7. Incorrect engine oil.</li> </ol>	<p>Clean.  Check level and add.  Replace.  Clean.  Adjust float height.  Tighten or replace.  Change.</p>

## CARBURETOR

Complaint	Symptom and possible causes	Remedy
<b>Starting difficulty.</b>	<ol style="list-style-type: none"> <li>1. Clogged starter jet.</li> <li>2. Clogged starter jet passage.</li> <li>3. Air leaking from joint between starter body and carburetor.</li> <li>4. Air leaking from carburetor joint or vacuum hose joint.</li> <li>5. Improperly working starter (enricher) plunger.</li> </ol>	<p>Clean.  Clean.  Tighten, adjust, or replace gasket.  Tighten or replace defective part.  Adjust.</p>
<b>Idling or low-speed trouble.</b>	<ol style="list-style-type: none"> <li>1. Clogged or loose pilot jet.</li> <li>2. Clogged or loose pilot air jet.</li> <li>3. Air leaking from carburetor joint, vacuum pipe joint, or starter.</li> <li>4. Clogged pilot outlet port.</li> <li>5. Clogged bypass port.</li> <li>6. Starter (enricher) plunger not fully closed.</li> </ol>	<p>Clean or tighten.  Clean or tighten.  Tighten or replace defective part.  Clean.  Clean.  Adjust.</p>
<b>Medium or high-speed trouble.</b>	<ol style="list-style-type: none"> <li>1. Clogged main jet.</li> <li>2. Clogged main air jet.</li> <li>3. Clogged needle jet.</li> <li>4. Improperly working throttle valve.</li> <li>5. Clogged fuel filter.</li> </ol>	<p>Clean.  Clean.  Clean.  Adjust.  Clean or replace.</p>
<b>Overflow and fuel level fluctuations.</b>	<ol style="list-style-type: none"> <li>1. Worn or damaged needle valve.</li> <li>2. Broken needle valve spring.</li> <li>3. Improperly working float.</li> <li>4. Foreign matter on the needle valve.</li> <li>5. Incorrect float chamber fuel level.</li> </ol>	<p>Replace.  Replace.  Adjust or replace.  Clean or replace with needle valve seat.  Adjust float height.</p>

## CHASSIS

Complaint	Symptom and possible causes	Remedy
<b>Steering is heavy.</b>	<ol style="list-style-type: none"> <li>1. Overtightened steering stem nut.</li> <li>2. Broken bearing in steering stem.</li> <li>3. Distorted steering stem.</li> <li>4. Low tire pressure.</li> </ol>	Adjust. Replace. Replace. Regulate.
<b>Handlebar wobbles.</b>	<ol style="list-style-type: none"> <li>1. Loss of balance between right and left front forks.</li> <li>2. Distorted front fork.</li> <li>3. Distorted front axle.</li> <li>4. Twisted tire.</li> </ol>	Adjust or replace. Repair or replace. Replace. Replace.
<b>Front wheel wobbles.</b>	<ol style="list-style-type: none"> <li>1. Distorted wheel rim.</li> <li>2. Worn front wheel bearing.</li> <li>3. Defective or incorrect tire.</li> <li>4. Loose front axle nut.</li> <li>5. Incorrect fork oil level.</li> </ol>	Replace. Replace. Replace. Tighten. Adjust.
<b>Front suspension too soft.</b>	<ol style="list-style-type: none"> <li>1. Weak spring.</li> <li>2. Insufficient fork oil.</li> <li>3. Improper suspension setting.</li> </ol>	Replace. Check level and add. Adjust.
<b>Front suspension too stiff.</b>	<ol style="list-style-type: none"> <li>1. Excessively viscous fork oil.</li> <li>2. Excessive fork oil.</li> <li>3. Improper suspension setting.</li> </ol>	Replace. Check level and drain. Adjust.
<b>Front suspension too noisy.</b>	<ol style="list-style-type: none"> <li>1. Insufficient fork oil.</li> <li>2. Loose front suspension fastener.</li> </ol>	Check level and add. Tighten.
<b>Rear wheel wobbles.</b>	<ol style="list-style-type: none"> <li>1. Distorted wheel rim.</li> <li>2. Worn rear wheel bearing.</li> <li>3. Defective or incorrect tire.</li> <li>4. Worn swingarm bearing.</li> <li>5. Loose rear axle nut.</li> <li>6. Loose rear suspension fastener.</li> </ol>	Replace. Replace. Replace. Replace. Tighten. Tighten.
<b>Rear suspension too soft.</b>	<ol style="list-style-type: none"> <li>1. Weak rear shock absorber spring.</li> <li>2. Rear shock absorber leaks oil.</li> <li>3. Improper suspension setting.</li> </ol>	Replace. Replace. Adjust.
<b>Rear suspension too stiff.</b>	<ol style="list-style-type: none"> <li>1. Improper suspension setting.</li> <li>2. Bent rear shock absorber shaft.</li> <li>3. Worn swingarm bearing and rear suspension related bearing.</li> </ol>	Adjust. Replace. Replace.
<b>Rear suspension too noisy.</b>	<ol style="list-style-type: none"> <li>1. Loose rear suspension fastener.</li> <li>2. Worn swingarm bearing and rear suspension related bearing.</li> </ol>	Tighten. Replace.

## BRAKES

Complaint	Symptom and possible causes	Remedy
<b>Brake power insufficient.</b>	<ol style="list-style-type: none"> <li>1. Leakage of brake fluid.</li> <li>2. Worn brake pad.</li> <li>3. Oil on brake pad surface.</li>   <li>4. Worn brake disc.</li> <li>5. Air in hydraulic system.</li> </ol>	Repair or replace. Replace. Clean brake disc and brake pads. Replace. Bleed.
<b>Brake squeaks.</b>	<ol style="list-style-type: none"> <li>1. Carbon adhesion on brake pad surface.</li> <li>2. Tilted brake pad.</li> <li>3. Damaged wheel bearing.</li> <li>4. Worn brake pad.</li> <li>5. Foreign material in brake fluid.</li> <li>6. Clogged return port of master cylinder.</li>   <li>7. Loose front or rear axle nut.</li> </ol>	Clean surface with sandpaper. Readjust brake pad position or replace. Replace. Replace. Change brake fluid. Disassemble and clean master cylinder. Tighten.
<b>Brake lever or pedal stroke excessive.</b>	<ol style="list-style-type: none"> <li>1. Air in hydraulic system.</li> <li>2. Insufficient brake fluid.</li>   <li>3. Incorrect brake fluid.</li> </ol>	Bleed. Check level and add. Bleed any air. Change.
<b>Brake fluid leaks.</b>	<ol style="list-style-type: none"> <li>1. Loose connection joint.</li> <li>2. Cracked hose.</li> <li>3. Worn piston seal.</li> <li>4. Worn secondary cup.</li> </ol>	Tighten. Replace. Replace. Replace.
<b>Brake drags.</b>	<ol style="list-style-type: none"> <li>1. Rusty part.</li> <li>2. Insufficient brake lever or brake pedal pivot lubrication.</li> </ol>	Clean and lubricate. Lubricate.

## ELECTRICAL

Complaint	Symptom and possible causes	Remedy
<b>No sparking or poor sparking.</b>	<ol style="list-style-type: none"> <li>1. Defective ignition coil.</li> <li>2. Defective spark plug.</li> <li>3. Defective generator.</li> <li>4. Defective CDI unit.</li> </ol>	Replace. Replace. Replace. Replace.
<b>Spark plug is wet or quickly becomes fouled with carbon.</b>	<ol style="list-style-type: none"> <li>1. Excessively rich air/fuel mixture.</li> <li>2. Excessively high idling speed.</li> <li>3. Incorrect gasoline.</li> <li>4. Dirty air cleaner element.</li> <li>5. Incorrect spark plug (cold type).</li> </ol>	Adjust carburetor. Adjust carburetor. Change. Clean or replace. Change to hot type spark plug.
<b>Spark plug quickly becomes fouled with oil or carbon.</b>	<ol style="list-style-type: none"> <li>1. Worn piston ring.</li> <li>2. Worn piston.</li> <li>3. Worn cylinder.</li> <li>4. Excessive valve-stem-to-valve-guide clearance.</li> <li>5. Worn valve stem oil seal.</li> </ol>	Replace. Replace. Replace. Replace. Replace.
<b>Spark plug electrodes overheat or burn.</b>	<ol style="list-style-type: none"> <li>1. Incorrect spark plug (hot type).</li> <li>2. Overheated engine.</li> <li>3. Loose spark plug.</li> <li>4. Excessively lean air/fuel mixture.</li> </ol>	Change to cold type spark plug. Tune-up. Tighten. Adjust carburetor.
<b>Generator does not charge.</b>	<ol style="list-style-type: none"> <li>1. Open or short in lead wires, or loose lead connections.</li> <li>2. Shorted, grounded, or open generator coil.</li> <li>3. Shorted or punctured regulator/rectifier.</li> </ol>	Repair, replace, or connect properly. Replace. Replace.
<b>Generator charges but charging rate is below the specifications.</b>	<ol style="list-style-type: none"> <li>1. Lead wires tend to get shorted or open-circuited or loosely connected at terminal.</li> <li>2. Grounded or open-circuited stator coils or generator.</li> <li>3. Defective regulator/rectifier.</li> <li>4. Defective battery cell plates.</li> </ol>	Repair or tighten. Replace. Replace. Replace battery.
<b>Generator overcharges.</b>	<ol style="list-style-type: none"> <li>1. Internal short-circuit in the battery.</li> <li>2. Damaged or defective regulator/rectifier.</li> <li>3. Poorly grounded regulator/rectifier.</li> </ol>	Replace battery. Replace. Repair, replace, or connect properly.
<b>Unstable charging.</b>	<ol style="list-style-type: none"> <li>1. Lead wire insulation frayed due to vibration, resulting in intermittent shorting.</li> <li>2. Internally shorted generator.</li> <li>3. Defective regulator/rectifier.</li> </ol>	Repair or replace. Replace. Replace.
<b>Starter button does not work. (DR-Z400E)</b>	<ol style="list-style-type: none"> <li>1. Run down battery.</li> <li>2. Defective switch contact.</li> <li>3. Brushes do not seat properly on the commutator in the starter motor.</li> <li>4. Defective starter relay.</li> <li>5. Wiring connections loose or disconnected.</li> </ol>	Recharge or replace. Replace. Repair or replace. Replace. Tighten or repair.

**BATTERY (DR-Z400E)**


Complaint	Symptom and possible causes	Remedy
<b>Sulfation or spots on surfaces of cell plates.</b>	<ol style="list-style-type: none"> <li>1. Cracked battery case.</li> <li>2. Battery has been left in a run-down condition for a long time.</li> </ol>	<p>Replace. Replace.</p>
<b>Battery runs down quickly.</b>	<ol style="list-style-type: none"> <li>1. Incorrect charging method.</li> <li>2. Battery cell plates have lost much of their active material as a result of overcharging.</li> <li>3. Internally shorted battery.</li> <li>4. Excessively low battery voltage.</li> <li>5. Battery is too old.</li> <li>6. Dirty container top and sides.</li> </ol>	<p>Check generator, regulator/rectifier circuit connections, and make necessary adjustment to obtain specified charging operation. Replace battery and correct charging system. Replace. Charge. Replace. Clean.</p>
<b>Battery sulfation.</b>	<ol style="list-style-type: none"> <li>1. Incorrect charging rate. (When not in use, the battery should be checked at least once a month and properly charged if necessary, to avoid sulfation.)</li> <li>2. The battery was left unused in a cold climate for too long.</li> </ol>	<p>Replace.  Replace the battery if badly sulfated.</p>




# WIRING DIAGRAM

## DR-Z400







**WIRE COLORS**  
 B ..... Black  
 Bl ..... Blue  
 G ..... Green  
 Gr ..... Gray  
 O ..... Orange  
 R ..... Red  
 W ..... White  
 Y ..... Yellow  
 B/W ..... Black with White tracer  
 B/Y ..... Black with Yellow tracer




DR-Z400E










DR-Z400E



DR-Z400

# CABLE ROUTING




VIEW A (0 - 0.004 in)



VIEW D

VIEW C

Set boot to clutch cable after clutch cable setting to stopper.




VIEW B





Clutch cable must be passed to the left of breather hose.

## FUEL HOSE AND FUEL TANK MOUNTING




# OIL RETURN TANK HOSE ROUTING





- ① Face the tip of clip to the front
- ② Face the tip of clip to the bottom

# COOLING SYSTEM HOSE ROUTING




- ① Face the tip of clip to the top
- ② Face the tip of clip to the bottom
- ③ Face the tip of clip to the right side
- ④ Face the head of screw to the front side
- ⑤ Face the head of screw to the back side
- ⑥ Face the head of screw to the right side










## FRONT BRAKE HOSE ROUTING
















































## REAR BRAKE HOSE ROUTING



# SPECIAL TOOLS

 <p><b>09900-00401</b> Hexagon wrench set</p>	 <p><b>09900-00410</b> Hexagon wrench set</p>	 <p><b>09900-06104</b> Snap ring pliers</p>	 <p><b>09900-06105</b> Snap ring pliers</p>	 <p><b>09900-06108</b> Snap ring pliers</p>
 <p><b>09900-09004</b> Impact driver set</p>	 <p><b>09900-20101</b> Vernier calipers</p>	 <p><b>09900-20103</b> Vernier calipers</p>	 <p><b>09900-20202</b> Micrometer (25 – 50 mm)</p>	 <p><b>09900-20204</b> Micrometer (75 – 100 mm)</p>
 <p><b>09900-20205</b> Micrometer (0 – 25 mm)</p>	 <p><b>09900-20508</b> Cylinder gauge set</p>	 <p><b>09900-20602</b> Dial gauge (1/1000 mm)</p>	 <p><b>09900-20605</b> Dial calipers (1/100 mm, 10 – 34 mm)</p>	 <p><b>09900-20606</b> Dial gauge (1/100 mm)</p>
 <p><b>09900-20701</b> Magnetic stand</p>	 <p><b>09900-20803</b> Thickness gauge</p>	 <p><b>09900-20805</b> Tire depth gauge</p>	 <p><b>09900-21304</b> V-block set (100 mm)</p>	 <p><b>09900-22301</b> Plastigauge</p>
 <p><b>09900-22302</b> Plastigauge</p>	 <p><b>09900-22403</b> Small bore gauge (18 – 35 mm)</p>	 <p><b>09900-25008</b> Multi circuit tester set</p>	 <p><b>09910-32812</b> Crankshaft installer</p>	 <p><b>09910-60611</b> Universal clamp wrench</p>

 <p><b>09913-50121</b> Oil seal remover</p>	 <p><b>09913-70210</b> Bearing installer set</p>	 <p><b>09915-63310</b> Adapter</p>	 <p><b>09915-64510</b> Compression gauge set</p>	 <p><b>09915-70610</b> Adapter</p>
 <p><b>09915-74510</b> Oil pressure gauge set</p>	 <p><b>09916-10911</b> Valve lapper set</p>	 <p><b>09916-14510</b> Valve lifter</p>	 <p><b>09916-14910</b> Attachment</p>	 <p><b>09916-20610</b> Seat cutter (N-121)</p>
 <p><b>09916-21110</b> Valve seat cutter set</p>	 <p><b>09916-22420</b> Valve seat cutter (N-128)</p>	 <p><b>09916-22430</b> Valve seat cutter (N-114)</p>	 <p><b>09916-24311</b> Solid pilot (N-100-5.0)</p>	 <p><b>09916-34542</b> Reamer handle</p>
 <p><b>09916-34570</b> Valve guide reamer (5.0 mm)</p>	 <p><b>09916-34580</b> Valve guide reamer (10.8 mm)</p>	 <p><b>09916-44310</b> Valve guide remover</p>	 <p><b>09916-53360</b> Valve guide installer attachment</p>	 <p><b>09916-84511</b> Tweezers</p>
 <p><b>09920-13120</b> Crankcase separating tool</p>	 <p><b>09920-53740</b> Clutch sleeve hub holder</p>	 <p><b>09921-20210</b> Bearing remover</p>	 <p><b>09921-20220</b> Bearing remover set</p>	 <p><b>09923-73210</b> Bearing remover</p>

 <p><b>09923-74510</b> Bearing remover</p>	 <p><b>09924-84510</b> Bearing installer set</p>	 <p><b>09924-84521</b> Bearing installer set</p>	 <p><b>09925-18010</b> Steering bearing installer</p>	 <p><b>09930-30102</b> Sliding hammer</p>
 <p><b>09930-31921</b> Rotor remover set</p>	 <p><b>09930-44913</b> Rotor holder</p>	 <p><b>09940-14911</b> Steering stem nut wrench</p>	 <p><b>09940-14960</b> Steering stem nut wrench socket</p>	 <p><b>09940-34520</b> T handle</p>
 <p><b>09940-34581</b> Attachment F</p>	 <p><b>09940-52841</b> Front fork inner rod holder</p>	 <p><b>09940-52861</b> Front fork oil seal installer</p>	 <p><b>09940-54821</b> Front fork assembly tool</p>	 <p><b>09940-94922</b> Stopper plate</p>
 <p><b>09941-34513</b> Bearing installer</p>	 <p><b>09941-50111</b> Bearing remover</p>	 <p><b>09941-54911</b> Bearing outer race remover</p>	 <p><b>09941-74910</b> Bearing installer</p>	 <p><b>09943-74111</b> Fork oil level gauge</p>

## TIGHTENING TORQUE

### ENGINE

ITEM	N-m	kgf-m	lb-ft
Cylinder head cover bolt	14	1.4	10.0
Spark plug	11	1.1	8.0
Cylinder head bolt	M10	46	33.5
	M6	10	7.0
Cylinder head side bolt	14	1.4	10.0
Cylinder nut	10	1.0	7.0
Decompression shaft bolt (DR-Z400)	10	1.0	7.0
Decompression shaft lever nut (DR-Z400)	23	2.3	16.5
Camshaft journal holder bolt	10	1.0	7.0
Balancer shaft nut	50	5.0	36.0
Primary drive gear nut	110	11.0	79.5
Generator rotor nut	100	10.0	72.5
Clutch sleeve hub nut	70	7.0	50.5
Gearshift arm stopper	19	1.9	13.5
Gearshift cam driven gear bolt	24	2.4	17.5
Cam chain tension adjuster bolt	10	1.0	7.0
Cam chain tensioner mounting bolt	10	1.0	7.0
Cam chain tensioner spring holder bolt	8	0.8	6.0
Engine oil drain plug (on the crankcase)	21	2.1	15.0
Engine oil drain bolt (on the frame)	18	1.8	13.0
Engine oil level bolt	6	0.6	4.5
Crankcase bolt	11	1.1	8.0
Oil strainer (on the frame)	23	2.3	16.5
Oil hose union bolt	23	2.3	16.5
Radiator air bleeder bolt	6.0	0.6	4.3
TDC plug	23	2.3	16.5
Engine mounting nut	66	6.6	47.5
Engine mounting bracket nut	40	4.0	29.0
Exhaust pipe bolt and nut	23	2.3	16.5
Muffler connection bolt	20	2.0	14.5
Muffler mounting bolt	23	2.3	16.5
Engine sprocket nut	110	11.0	79.5
Intake pipe union	8	0.8	6.0
Fuel valve mounting bolt	4.4	0.44	3.2


## CHASSIS

ITEM	N-m	kgf-m	lb-ft
Handlebar clamp bolt	23	2.3	16.5
Front fork upper clamp bolt	30	3.0	21.5
Front fork lower clamp bolt	32	3.2	23.0
Steering stem head nut	90	9.0	65.0
Front fork cap bolt	23	2.3	16.5
Front fork damper rod bolt	80	8.0	58.0
Front fork inner rod locknut	22	2.2	16.0
Front brake master cylinder mounting bolt	10	1.0	7.0
Rear brake master cylinder mounting bolt	10	1.0	7.0
Brake hose union bolt (front & rear)	23	2.3	16.5
Front brake caliper mounting bolt	26	2.6	19.0
Brake pad mounting pin (front & rear)	18	1.8	13.0
Brake caliper plug (front & rear)	2.5	0.25	1.8
Brake air bleeder valve (front & rear)	7.5	0.75	5.5
Rear brake rod locknut	18	1.8	13.0
Rear brake pedal bolt	29	2.9	21.0
Brake disc mounting bolt (front & rear)	10	1.0	7.0
Front axle nut	42	4.2	30.5
Front axle pinch bolt	18	1.8	13.0
Seat rail mounting nut (upper)	35	3.5	25.5
Seat rail mounting bolt (lower)	35	3.5	25.5
Rear axle nut	E-03, 28	100	72.5
	The other countries	110	79.5
Rear sprocket nut	30	3.0	21.5
Drive chain roller mounting bolt (upper & lower)	40	4.0	29.0
Spoke nipple (front & rear)	3	0.3	2.0
Swingarm pivot nut	77	7.7	55.5
Rear shock absorber compression adjuster assembly	30	3.0	21.5
Rear shock absorber spring adjuster lock ring	90	9.0	65.0
Rear shock absorber mounting nut (upper & lower)	55	5.5	40.0
Cushion lever mounting nut (center)	100	10.0	72.5
Cushion lever mounting nut (front)	100	10.0	72.5
Cushion rod mounting nut	100	10.0	72.5
Side stand bolt	50	5.0	36.0
Side stand nut	55	5.5	40.0


## TIGHTENING TORQUE CHART

For other nuts and bolts not listed in the preceding page, refer to this chart:


Bolt Diameter Ⓐ (mm)	Conventional or "4" marked bolt			"7" marked bolt		
	N·m	kgf·m	lb·ft	N·m	kgf·m	lb·ft
4	1.5	0.15	1.0	2.3	0.23	1.5
5	3	0.3	2.0	4.5	0.45	3.0
6	5.5	0.55	4.0	10	1.0	7.0
8	13	1.3	9.5	23	2.3	16.5
10	29	2.9	21.0	50	5.0	36.0
12	45	4.5	32.5	85	8.5	61.5
14	65	6.5	47.0	135	13.5	97.5
16	105	10.5	76.0	210	21.0	152.0
18	160	16.0	115.5	240	24.0	173.5



Conventional bolt



"4" marked bolt



"7" marked bolt

## SERVICE DATA

### VALVE + GUIDE

Unit: mm (in)

ITEM	STANDARD		LIMIT
Valve diameter	IN.	36 (1.42)	—
	EX.	29 (1.14)	—
Tappet clearance (when cold)	IN.	0.10 – 0.20 (0.0039 – 0.0079)	—
	EX.	0.20 – 0.30 (0.0079 – 0.0118)	—
Valve-guide-to-valve-stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve stem deflection	IN. & EX.	—	0.35 (0.014)
Valve guide I.D.	IN. & EX.	5.000 – 5.012 (0.1969 – 0.1973)	—
Valve stem O.D.	IN.	4.975 – 4.990 (0.1959 – 0.1965)	—
	EX.	4.955 – 4.970 (0.1951 – 0.1957)	—
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve stem thickness	IN. & EX.	—	0.5 (0.02)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length (IN. & EX.)	INNER	—	32.6 (1.28)
	OUTER	—	36.3 (1.43)
Valve spring tension (IN. & EX.)	INNER	56 – 64 N (5.6 – 6.4 kgf, 12.3 – 14.1 lbs) at length 27.4 mm (1.08 in)	—
	OUTER	126 – 145 N (12.6 – 14.5 kgf, 27.7 – 32.0 lbs) at length 30.9 mm (1.22 in)	—



**CAMSHAFT + CYLINDER HEAD**

Unit: mm (in)

ITEM	STANDARD		LIMIT
Cam height	IN.	36.910 – 36.960 (1.4531 – 1.4551)	36.610 (1.4413)
	EX.	36.880 – 36.930 (1.4520 – 1.4539)	36.580 (1.4402)
Camshaft journal oil clearance	IN. & EX.	0.019 – 0.053 (0.0007 – 0.0021)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	22.012 – 22.025 (0.8666 – 0.8671)	—
Camshaft journal O.D.	IN. & EX.	21.972 – 21.993 (0.8653 – 0.8659)	—
Camshaft runout	IN. & EX.	—	0.10 (0.004)
Cam chain pin (at arrow “3”)	15th pin		—
Cylinder head distortion	—		0.05 (0.002)
Cylinder head cover distortion	—		0.05 (0.002)
Decompression cable play (DR-Z400)	0 – 0.1 (0 – 0.004)		—

**CYLINDER + PISTON + PISTON RING**

Unit: mm (in)

ITEM	STANDARD			LIMIT
Compression pressure (DR-Z400E) (Automatic decompression actuated)	1 000 kPa (10.0 kgf/cm <sup>2</sup> , 142 psi)			—
Piston-to-cylinder clearance	0.030 – 0.040 (0.0012 – 0.0016)			0.120 (0.0047)
Cylinder bore	90.000 – 90.015 (3.5433 – 3.5439)			Nicks or scratches
Piston diameter	89.965 – 89.980 (3.5419 – 3.5425) Measure 15 (0.6) from the skirt end			89.880 (3.5386)
Cylinder distortion	—			0.05 (0.002)
Piston ring free end gap	1st	R	Approximately 6.9 (0.27)	5.5 (0.22)
	2nd	R	Approximately 11.5 (0.45)	9.2 (0.36)
Piston ring end gap	1st & 2nd	0.08 – 0.20 (0.003 – 0.008)		0.50 (0.020)
Piston-ring-to-piston-ring-groove clear- ance	1st	—		0.180 (0.007)
	2nd	—		0.150 (0.006)

ITEM	STANDARD		LIMIT
Piston ring groove width	1st	0.78 – 0.80 (0.0307 – 0.0315) 1.30 – 1.32 (0.0512 – 0.0520)	—
	2nd	0.81 – 0.83 (0.0319 – 0.0327)	—
	Oil	2.01 – 2.03 (0.0791 – 0.0799)	—
Piston ring thickness	1st	0.71 – 0.76 (0.0280 – 0.0299) 1.08 – 1.10 (0.0425 – 0.0433)	—
	2nd	0.77 – 0.79 (0.0303 – 0.0311)	—
Piston pin bore	20.002 – 20.008 (0.7875 – 0.7877)		20.030 (0.7886)
Piston pin O.D.	19.995 – 20.000 (0.7872 – 0.7874)		19.980 (0.7866)

### CONROD + CRANKSHAFT

Unit: mm (in)

ITEM	STANDARD	LIMIT
Conrod small end I.D.	20.010 – 20.018 (0.7878 – 0.7881)	20.040 (0.7890)
Crank-web-to-crank-web width	62.0 ± 0.1 (2.441 ± 0.004)	—
Conrod deflection	—	3.0 (0.12)
Conrod big end side clearance	0.30 – 0.65 (0.012 – 0.026)	1.0 (0.04)
Conrod big end width	21.95 – 22.00 (0.864 – 0.866)	—
Crankshaft runout	—	0.08 (0.003)

### OIL PUMP

Unit: mm (in)

ITEM	STANDARD	LIMIT
Oil pump reduction ratio	2.220 (74/25 × 20/16 × 12/20)	—
Oil pressure (at 60°C, 140°F)	Above 40 kPa (0.4 kgf/cm <sup>2</sup> , 5.7 psi) Below 140 kPa (1.4 kgf/cm <sup>2</sup> , 19.9 psi) at 3000 r/min	—

**CLUTCH**

Unit: mm (in)

ITEM	STANDARD	LIMIT
Clutch lever play	10 – 15 (0.4 – 0.6)	—
Clutch drive plate thickness (No. 1 & No. 2)	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
Clutch drive plate claw width (No. 1 & No. 2)	13.7 – 13.8 (0.539 – 0.543)	13.2 (0.520)
Clutch drive plate distortion	—	0.10 (0.004)
Clutch spring free length	—	49.9 (1.96)

**TRANSMISSION + DRIVE CHAIN**

Unit: mm (in) Except ratio

ITEM	STANDARD	LIMIT	
Primary reduction ratio	2.960 (74/25)	—	
Final reduction ratio	3.357 (47/14)	—	
Gear ratios	Low	2.285 (32/14)	—
	2nd	1.733 (26/15)	—
	3rd	1.375 (22/16)	—
	4th	1.090 (24/22)	—
	Top	0.863 (19/22)	—
Gearshift-fork-to-gearshift-fork-groove clearance	0.1 – 0.3 (0.004 – 0.012)	0.5 (0.02)	
Gearshift fork groove width	No. 1, No. 2 & No. 3	4.8 – 4.9 (0.189 – 0.193)	—
Gearshift fork thickness	No. 1, No. 2 & No. 3	4.6 – 4.7 (0.181 – 0.185)	—
Drive chain	Type	RK520KZO	—
	Links	112	—
	20-pitch length	—	319.4 (12.57)
Drive chain slack	40 – 50 (1.6 – 2.0)	—	

**CARBURETOR**

ITEM	SPECIFICATION			
	DR-Z400		DR-Z400E	
	E-01	E-03, 28	E-01	E-03, 28
Carburetor type	KEIHIN FCR39H	←	←	←
Bore size	39 mm (1.5 in)	←	←	←
I.D. No.	29F0	29F1	29F3	29F4
Idle r/min	1800 ± 100 r/min	←	←	←
Float height	9.0 ± 1.0 mm (0.35 ± 0.04 in)	←	←	←
Main jet (M.J.)	#165	#142	#165	#142
Main air jet (M.A.J.)	#200	←	←	←
Jet needle (J.N.)	OBDXP-4th	←	←	←
Needle jet (N.J.)	2.9 mm (0.11 in)	←	←	←
Slow jet (S.J.)	#45	←	←	←
Slow air jet (S.A.J.)	#60	←	←	←
Air jet (A.J.)	#90	←	←	←
Pilot screw (P.S.)	1 1/2 turns out	←	←	←
Throttle cable play	2 – 4 mm (0.08 – 0.16 in)	←	←	←

**RADIATOR + ENGINE COOLANT**

ITEM	STANDARD/SPECIFICATION	NOTE
Radiator cap valve opening pressure	95 – 125 kPa (0.95 – 1.25 kgf/cm <sup>2</sup> , 13.5 – 17.8 psi)	
Engine coolant type	Use an antifreeze/coolant compatible with aluminum radiators, mixed with distilled water only, at the ratio of 50:50	
Engine coolant capacity	1 250 ml (1.3 US qt, 1.1 Imp qt)	

**BRAKE + WHEEL**

Unit: mm (in)

ITEM	STANDARD/SPECIFICATION		LIMIT
Rear brake pedal height	5 (0.2)		—
Brake disc thickness	Front	3.0 ± 0.2 (0.118 ± 0.008)	2.5 (0.10)
	Rear	4.5 ± 0.2 (0.177 ± 0.008)	4.0 (0.16)
Brake disc runout	Front & Rear	—	0.30 (0.01)
Master cylinder bore	Front	11.000 – 11.043 (0.4331 – 0.4348)	—
	Rear	12.700 – 12.743 (0.5000 – 0.5017)	—
Master cylinder piston diameter	Front	10.957 – 10.984 (0.4314 – 0.4324)	—
	Rear	12.657 – 12.684 (0.4983 – 0.4994)	—
Brake caliper cylinder bore	Front	27.000 – 27.050 (1.0630 – 1.0650)	—
	Rear	27.000 – 27.050 (1.0630 – 1.0650)	—
Brake caliper piston diameter	Front	26.900 – 26.950 (1.0591 – 1.0610)	—
	Rear	26.900 – 26.950 (1.0591 – 1.0610)	—
Brake fluid type	DOT 4		—
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)
Wheel rim size	Front	1.60 × 21	—
	Rear	2.15 × 18	—
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)

**TIRE**

Unit: mm (in)

ITEM	STANDARD/SPECIFICATION		LIMIT
Cold inflation tire pressure (Solo riding)	Front	100 kPa (1.0 kgf/cm <sup>2</sup> , 14 psi)	—
	Rear	100 kPa (1.0 kgf/cm <sup>2</sup> , 14 psi)	—
Tire size	Front	80/100 – 21 51M	—
	Rear	110/100 – 18 64M	—
Tire tread depth	Front	—	4.0 (0.16)
	Rear	—	4.0 (0.16)

**SUSPENSION**

Unit: mm (in)

ITEM	STANDARD/SPECIFICATION		LIMIT
Front fork stroke	288 (11.3)		—
Front fork spring free length	510.6 (20.1)		500 (19.7)
Front fork oil level (without spring)	122 (4.8)		—
Front fork oil type	SUZUKI FORK OIL SS-05 or an equivalent fork oil		—
Front fork oil capacity (each leg)	720 ml (24.3 US oz, 25.4 Imp oz)		—
Front fork damping force adjuster	Rebound	15 clicks out	—
	Compression	12 clicks out	—
Rear shock absorber gas pressure	900 kPa (9.0 kgf/cm <sup>2</sup> , 128 psi)		—
Rear shock absorber oil type	SUZUKI REAR SUSPENSION OIL SS-25 or an equivalent suspension oil		—
Rear shock absorber oil capacity	380 ml (12.8 US oz, 13.4 Imp oz)		—
Rear shock absorber spring pre-set length	258.0 (10.2)		—
Rear shock absorber damping force adjuster	Rebound	13 clicks out	—
	Compression	12 clicks out	—
Rear wheel travel	295 (11.6)		—
Swingarm pivot shaft runout	—		0.3 (0.01)

**ELECTRICAL**

Unit: mm (in)

ITEM		SPECIFICATION		NOTE
Spark plug	Type	NGK: CR8E DENSO: U24 ESR-N		
	Gap	0.7 – 0.8 (0.028 – 0.031)		
Spark performance	Over 8 (0.3) at 1 atm.			
Ignition coil resistance	Primary	0.1 – 1.0 $\Omega$		Terminal – Ground
	Secondary	12 – 20 k $\Omega$		Plug cap – Terminal
Ignition coil primary peak voltage	More than 150 V ( $\oplus$ :B/W, $\ominus$ :B/Y)			
Generator coil resistance	Signal coil	0.05 – 0.20 $\Omega$		B – W
	Pickup coil	390 – 600 $\Omega$		G – BI
	Charging coil	0.50 – 1.25 $\Omega$		Y – Y
Pickup coil peak voltage	More than 10.0 V ( $\oplus$ :BI, $\ominus$ :G)			DR-Z400
	More than 5.0 V ( $\oplus$ :BI, $\ominus$ :G)			DR-Z400E
Signal coil peak voltage	More than 1.0 V ( $\oplus$ :B, $\ominus$ :W)			DR-Z400
	More than 1.4 V ( $\oplus$ :B, $\ominus$ :W)			DR-Z400E
Generator no-load voltage (when engine is cold)	More than 55 V (AC) at 5 000 r/min (Y–Y)			DR-Z400
	More than 75V (AC) at 5 000 r/min (Y–Y)			DR-Z400E
Regulated voltage	12.5 – 14.0 V at 5 000 r/min			DR-Z400
	13.5 – 15.0 V at 5 000 r/min			DR-Z400E
Generator maximum output	150 W at 5 000 r/min			DR-Z400
	200 W at 5 000 r/min			DR-Z400E
Starter relay resistance	3 – 5 $\Omega$			DR-Z400E
Battery	Type designation	GT7B-4		DR-Z400E
	Capacity	12 V 23.4 kC (6.5 Ah)/10 HR		

**WATTAGE**

Unit: W

ITEM	SPECIFICATION
Headlight	55
Taillight	LED

**FUEL + OIL**

ITEM	SPECIFICATION		NOTE
Fuel type	Use only unleaded gasoline of at least 90 pump octane ( $\frac{R+M}{2}$ ). Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10 % ethanol, or less than 5 % methanol with appropriate cosolvents and corrosion inhibitor is permissible.		E-03, 28
	Gasoline used should be graded 95 octane or higher. An unleaded gasoline is recommended.		E-01
Fuel tank including reserve	10.0 L (2.6 US gal, 2.2 Imp gal)		
reserve	2.3 L (0.6 US gal, 0.5 Imp gal)		
Engine oil type	SAE 10 W-40, API SF or SG		
Engine oil capacity	Change	1 700 ml (1.8 US qt, 1.5 Imp qt)	
	Filter change	1 800 ml (1.9 US qt, 1.6 Imp qt)	
	Overhaul	1 900 ml (2.0 US qt, 1.7 Imp qt)	