

TROUBLESHOOTING

FI SYSTEM MALFUNCTION CODE AND DEFECTIVE CONDITION

(☞ 4-27 to -29)

ENGINE

Complaint	Symptom and possible causes	Remedy
Engine will not start or is hard to start	<p>Compression too low</p> <ol style="list-style-type: none"> 1. Valve clearance out of adjustment 2. Worn valve guides or poor seating of valves 3. Mistiming valves 4. Excessively worn piston rings 5. Worn-down cylinder bores 6. Too slowly starter motor cranks 7. Poor seating of spark plugs <p>Plug not sparking</p> <ol style="list-style-type: none"> 1. Fouled spark plugs 2. Wet spark plugs 3. Defective ignition coils 4. Defective CKP sensor 5. Defective ECM 6. Open-circuited wiring connections 7. Open or short in high-tension cords <p>No fuel reaching the intake manifold</p> <ol style="list-style-type: none"> 1. Clogged fuel filter or fuel hose 2. Defective fuel pump 3. Defective fuel pressure regulator 4. Defective fuel injector 5. Defective fuel pump relay 6. Defective ECM 7. Open-circuited wiring connections <p>Incorrect fuel/air mixture</p> <ol style="list-style-type: none"> 1. TP sensor out of adjustment 2. Defective fuel pump 3. Defective fuel pressure regulator 4. Defective TP sensor 5. Defective CKP sensor 6. Defective IAP sensor 7. Defective ECM 8. Defective ECT sensor 9. Defective IAT sensor 10. Clogged ISC valve air passage way 	<p>Adjust. Repair or replace. Adjust. Replace. Replace. See electrical section. Retighten.</p> <p>Clean. Clean and dry. Replace. Replace. Replace. Repair or replace. Replace.</p> <p>Clean or replace. Replace. Replace. Replace. Replace. Replace. Check and repair.</p> <p>Adjust. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace or replace.</p>

Complaint	Symptom and possible causes	Remedy
Engine idles poorly	<ol style="list-style-type: none"> 1. Valve clearance out of adjustment 2. Poor seating of valves 3. Defective valve guides 4. Worn down camshaft 5. Too wide spark plug gaps 6. Defective ignition coils 7. Defective CKP sensor 8. Defective ECM 9. Defective TP sensor 10. Defective fuel pump 11. Imbalanced throttle valve 12. Damaged or cracked vacuum hose 13. Damaged or clogged ISC valve 14. ISC bad learning 	<p>Adjust. Replace or repair. Replace. Replace. Adjust or replace. Replace. Replace. Replace. Replace. Adjust. Replace. Replace or repair. Reset learned value.</p>
Engine stalls often	<p>Incorrect fuel/air mixture</p> <ol style="list-style-type: none"> 1. Defective IAP sensor or circuit 2. Clogged fuel filter 3. Defective fuel pump 4. Defective fuel pressure regulator 5. Defective ECT sensor 6. Defective thermostat 7. Defective IAT sensor 8. Damaged or cracked vacuum hose 9. Damaged or clogged ISC valve <p>Fuel injector improperly operating</p> <ol style="list-style-type: none"> 1. Defective fuel injectors 2. No injection signal from ECM 3. Open or short circuited wiring connection 4. Defective battery or low battery voltage <p>Control circuit or sensor improperly operating</p> <ol style="list-style-type: none"> 1. Defective ECM 2. Defective fuel pressure regulator 3. Defective TP sensor 4. Defective IAT sensor 5. Defective CKP sensor 6. Defective ECT sensor 7. Defective fuel pump relay 8. Defective ISC valve 9. ISC bad learning <p>Engine internal parts improperly operating</p> <ol style="list-style-type: none"> 1. Fouled spark plugs 2. Defective CKP sensor or ECM 3. Clogged fuel hose 4. Out of adjustment valve clearance 	<p>Repair or replace. Clean or replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace or repair. Replace. Repair or replace. Repair or replace. Replace or recharge. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Reset learned value. Clean. Replace. Clean. Adjust.</p>

Complaint	Symptom and possible causes	Remedy
Noisy engine	Excessive valve chatter	
	1. Too large valve clearance	Adjust.
	2. Weakened or broken valve springs	Replace.
	3. Worn rocker arm or cam surface	Replace.
	4. Worn and burnt camshaft journal	Replace.
	Noise seems to come from piston	
	1. Worn down pistons or cylinders	Replace.
	2. Carbon combustion chambers fouled with carbon	Clean.
	3. Worn piston pins or piston pin bore	Replace.
	4. Worn piston rings or ring grooves	Replace.
	Noise seems to come from timing chain	
	1. Stretched chain	Replace.
	2. Worn sprockets	Replace.
3. Tension adjuster not working	Repair or replace.	
Noise seems to come from clutch		
1. Worn splines of countershaft or hub	Replace.	
2. Worn teeth of clutch plates	Replace.	
3. Distorted clutch plates, driven and drive	Replace.	
4. Worn clutch release bearing	Replace.	
Noise seems to come from crankshaft		
1. Rattling bearings due to wear	Replace.	
2. Worn and burnt big-end bearings	Replace.	
3. Worn and burnt journal bearings	Replace.	
4. Too large thrust clearance	Replace thrust bearing.	
Noise seems to come from balancer		
1. Worn and burnt journal bearings	Replace.	
Noise seems to come from transmission		
1. Worn or rubbing gears	Replace.	
2. Worn splines	Replace.	
3. Worn or rubbing primary gears	Replace.	
4. Worn bearings	Replace.	
Noise seems to come from water pump		
1. Too much play on pump shaft	Replace.	
2. Worn or damaged impeller shaft	Replace.	
3. Worn or damaged mechanical seal	Replace.	
4. Contact between pump case and impeller	Replace.	

Complaint	Symptom and possible causes	Remedy
Engine lacks power	<p>Defective engine internal/electrical parts</p> <ol style="list-style-type: none"> 1. Loss of valve clearance 2. Weakened valve springs 3. Valve timing out of adjustment 4. Worn piston rings or cylinders 5. Poor seating of valves 6. Fouled spark plugs 7. Incorrect spark plugs 8. Clogged fuel injectors 9. TP sensor out of adjustment 10. Clogged air cleaner element 11. Imbalanced throttle valve synchronization 12. Sucking air from throttle valve or vacuum hose 13. Too much engine oil 14. Defective fuel pump or ECM 15. Defective CKP sensor and ignition coils <p>Defective control circuit or sensor</p> <ol style="list-style-type: none"> 1. Low fuel pressure 2. Defective TP sensor 3. Defective IAT sensor 4. Defective CKP sensor 5. Defective GP switch 6. Defective IAP sensor 7. Defective ECM 8. TP sensor out of adjustment 9. Defective ISC valve 10. Imbalanced throttle valve synchronization 	<p>Adjust. Replace. Adjust. Replace. Repair. Clean or replace. Replace. Replace. Adjust. Clean or replace. Adjust. Repair or replace. Drain out excess oil. Replace. Replace.</p> <p>Repair or replace. Replace. Replace. Replace. Replace. Replace. Replace. Adjust. Replace. Adjust.</p>
Engine overheats	<p>Defective engine internal parts</p> <ol style="list-style-type: none"> 1. Heavy carbon deposit on piston crowns 2. Not enough oil in the engine 3. Defective oil pump or clogged oil circuit 4. Sucking air from intake pipes 5. Use incorrect engine oil 6. Defective cooling system <p>Lean fuel/air mixture</p> <ol style="list-style-type: none"> 1. Short-circuited IAP sensor/lead wire 2. Short-circuited IAT sensor/lead wire 3. Sucking air from intake pipe joint 4. Defective fuel injectors 5. Defective ECT sensor <p>Other factors</p> <ol style="list-style-type: none"> 1. Ignition timing is too advanced due to defective timing advance system (ECT sensor, GP switch, CKP sensor and ECM) 2. Drive chain is too tight 3. ISC bad learning 	<p>Clean. Add oil. Replace or clean. Repair or replace. Change. See radiator section.</p> <p>Repair or replace. Repair or replace. Repair or replace. Replace. Replace.</p> <p>Replace. Adjust. Reset learned value.</p>

Complaint	Symptom and possible causes	Remedy
Dirty or heavy exhaust smoke	<ol style="list-style-type: none"> 1. Too much engine oil in the engine 2. Worn piston rings or cylinders 3. Worn valve guides 4. Scored or scuffed cylinder walls 5. Worn valves stems 6. Defective stem oil seal 7. Worn oil ring side rails 	<p>Check with inspection window, drain out excess oil.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p>
Slipping clutch	<ol style="list-style-type: none"> 1. Weakened clutch springs 2. Worn or distorted pressure plate 3. Distorted clutch plates 4. Clutch release screw out of adjustment 	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Adjust.</p>
Dragging clutch	<ol style="list-style-type: none"> 1. Some clutch spring weakened while others are not 2. Distorted pressure plate or clutch plates 3. Clutch release screw out of adjustment 	<p>Replace.</p> <p>Replace.</p> <p>Adjust.</p>
Transmission will not shift	<ol style="list-style-type: none"> 1. Broken gearshift cam 2. Distorted gearshift forks 3. Worn gearshift pawl 	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p>
Transmission will not shift back	<ol style="list-style-type: none"> 1. Broken return spring on shift shaft 2. Rubbing or stickily shift shaft 3. Distorted or worn gearshift forks 	<p>Replace.</p> <p>Repair or replace.</p> <p>Replace.</p>
Transmission jumps out of gear	<ol style="list-style-type: none"> 1. Worn shifting gears on driveshaft or countershaft 2. Distorted or worn gearshift forks 3. Weakened stopper spring on gearshift stopper 4. Worn gearshift cam stopper plate 	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p>

RADIATOR (COOLING SYSTEM)

Complaint	Symptom and possible causes	Remedy
Engine overheats	<ol style="list-style-type: none"> 1. Not enough engine coolant 2. Radiator core clogged with dirt or scale 3. Faulty cooling fan 4. Defective cooling fan relay, or open- or short-circuited 5. Defective ECM 6. Defective ECT sensor 7. Clogged water passage 8. Air trapped in the cooling circuit 9. Defective water pump 10. Use incorrect coolant 11. Defective thermostat 12. Damaged ISC valve 13. ISC bad learning 	<p>Add coolant.</p> <p>Clean.</p> <p>Repair or replace.</p> <p>Repair or replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Clean.</p> <p>Bleed air.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Reset learned value.</p>
Engine overcools	<ol style="list-style-type: none"> 1. Defective ECT sensor 2. Extremely cold weather 3. Defective thermostat 4. Defective cooling fan relay, or open- or short-circuited 5. Defective ECM 	<p>Replace.</p> <p>Put on the radiator cover.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace.</p>

CHASSIS

Complaint	Symptom and possible causes	Remedy
Heavy steering	<ol style="list-style-type: none"> 1. Overtightened steering stem nut 2. Broken bearing in steering stem 3. Distorted steering stem 4. Not enough pressure in tires 	Adjust. Replace. Replace. Adjust.
Wobbly handlebars	<ol style="list-style-type: none"> 1. Loss of balance between right and left front forks 2. Distorted front fork 3. Distorted front axle or crooked tire 4. Loose steering stem nut 5. Worn or incorrect tire or wrong tire pressure 6. Worn bearing/race in steering stem 	Adjust. Repair or replace. Replace. Adjust. Adjust or replace. Replace.
Wobbly front wheel	<ol style="list-style-type: none"> 1. Distorted wheel rim 2. Worn front wheel bearings 3. Defective or incorrect tire 4. Loose axle or axle pinch bolt 5. Incorrect front fork oil level 6. Incorrect front wheel weight balance 	Replace. Replace. Replace. Retighten. Adjust. Adjust.
Front suspension too soft	<ol style="list-style-type: none"> 1. Weakened springs 2. Not enough fork oil 3. Wrong weight fork oil 	Replace. Replenish. Replace.
Front suspension too stiff	<ol style="list-style-type: none"> 1. Too viscous fork oil 2. Too much fork oil 3. Bent front axle 	Replace. Drain excess oil. Replace.
Noisy front suspension	<ol style="list-style-type: none"> 1. Not enough fork oil 2. Loose bolts on suspension 	Replenish. Retighten.
Wobbly rear wheel	<ol style="list-style-type: none"> 1. Distorted wheel rim 2. Worn rear wheel bearings or swingarm bearings 3. Defective or incorrect tire 4. Worn rear suspension bearings 5. Loose nuts or bolts on rear suspension 6. Loose rear axle nut 7. Incorrect rear wheel weight balance 	Replace. Replace. Replace. Replace. Retighten. Retighten. Adjust.
Rear suspension too soft	<ol style="list-style-type: none"> 1. Weakened spring of shock absorber 2. Leakage of oil from shock absorber 3. Improperly rear suspension setting 	Replace. Replace. Adjust.
Rear suspension too stiff	<ol style="list-style-type: none"> 1. Bent shock absorber shaft 2. Bent swingarm pivot shaft 3. Worn swingarm and rear suspension bearings 4. Improperly rear suspension setting 	Replace. Replace. Replace. Adjust.
Noisy rear suspension	<ol style="list-style-type: none"> 1. Loose nuts or bolts on rear suspension 2. Worn swingarm and suspension bearings 	Retighten. Replace.

BRAKES

Complaint	Symptom and possible causes	Remedy
Insufficient brake power	<ol style="list-style-type: none"> 1. Leakage of brake fluid from hydraulic system 2. Worn pads 3. Friction surfaces of pad are dirty oil or dust 4. Worn disc 5. Air in hydraulic system 6. Not enough brake fluid in the reservoir 	Repair or replace. Replace. Clean disc/pads or replace. Replace. Bleed air. Replenish.
Brake squeaking	<ol style="list-style-type: none"> 1. Carbon adhesion on pad surface 2. Tilted pad 3. Damaged wheel bearing 4. Loosen front wheel axle or rear wheel axle 5. Worn pads 6. Foreign material in brake fluid 7. Clogged return port of master cylinder 	Repair surface with sandpaper. Correct pad fitting or replace. Replace. Tighten to specified torque. Replace. Replace brake fluid. Disassemble and clean master cylinder.
Excessive brake lever stroke	<ol style="list-style-type: none"> 1. Air in hydraulic system 2. Insufficient brake fluid 3. Improper quality of brake fluid 	Bleed air. Replenish fluid to specified level; bleed air. Replace with correct fluid.
Leakage of brake fluid	<ol style="list-style-type: none"> 1. Insufficient tightening of connection joints 2. Cracked hose 3. Worn piston and/or cup 	Tighten to specified torque. Replace. Replace piston and/or cup.
Brake drags	<ol style="list-style-type: none"> 1. Rusty part 2. Insufficient brake lever or brake pedal pivot lubrication 	Clean and lubricate. Lubricate.

ELECTRICAL


Complaint	Symptom and possible causes	Remedy
No sparking or poor sparking	<ol style="list-style-type: none"> 1. Defective ignition coils 2. Defective spark plugs 3. Defective CKP sensor 4. Defective ECM 5. Defective TO sensor 6. Open-circuited wiring connections 	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Check and repair.</p>
Spark plug soon become fouled with carbon	<ol style="list-style-type: none"> 1. Mixture too rich 2. Excessively high idling speed 3. Incorrect gasoline 4. Dirty air cleaner element 5. Too cold spark plugs 	<p>Inspect FI system.</p> <p>Inspect FI system.</p> <p>Change.</p> <p>Replace.</p> <p>Replace with hot type plug.</p>
Spark plug become fouled too soon	<ol style="list-style-type: none"> 1. Worn piston rings 2. Worn piston or cylinders 3. Excessive clearance of valve stems in valve guides 4. Worn stem oil seal 	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p>
Spark plug electrodes overheat or burn	<ol style="list-style-type: none"> 1. Too hot spark plugs 2. Overheated the engine 3. Loose spark plugs 4. Too lean mixture 	<p>Replace with cold type plugs.</p> <p>Tune up.</p> <p>Retighten.</p> <p>Inspect FI system.</p>
Generator does not charge	<ol style="list-style-type: none"> 1. Open- or short-circuited lead wires, or loose lead connections 2. Short-circuited, grounded or open generator coil 3. Short-circuited or punctured regulator/rectifier 	<p>Repair or replace or retighten.</p> <p>Replace.</p> <p>Replace.</p>
Generator does charge, but charging rate is below the specification	<ol style="list-style-type: none"> 1. Lead wires tend to get shorted or open-circuited or loosely connected at terminals 2. Grounded or open-circuited generator coil 3. Defective regulator/rectifier 4. Defective cell plates in the battery 	<p>Repair or retighten.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace the battery.</p>
Generator overcharges	<ol style="list-style-type: none"> 1. Internal short-circuit in the battery 2. Damaged or defective regulator/rectifier 3. Poorly grounded regulator/rectifier 	<p>Replace the battery.</p> <p>Replace.</p> <p>Clean and tighten ground connection.</p>
Unstable charging	<ol style="list-style-type: none"> 1. Lead wire insulation frayed due to vibration, resulting in intermittent short-circuiting 2. Internally shorted generator 3. Defective regulator/rectifier 	<p>Repair or replace.</p> <p>Replace.</p> <p>Replace.</p>
Starter button is not effective	<ol style="list-style-type: none"> 1. Run down battery 2. Defective switch contacts 3. Brushes not seating properly on starter motor commutator 4. Defective starter relay/starter interlock switch 5. Defective main fuse 	<p>Repair or replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace.</p> <p>Replace.</p>


BATTERY

Complaint	Symptom and possible causes	Remedy
“Sulfation”, acidic white powdery substance or spots on surface of cell plates	<ol style="list-style-type: none"> 1. Cracked battery case 2. Battery has been left in a run-down condition for a long time 	<p>Replace the battery.</p> <p>Replace the battery.</p>
Battery runs down quickly	<ol style="list-style-type: none"> 1. Trouble in the charging system 2. Cell plates have lost much of their active material as a result of overcharging 3. Internal short-circuit in the battery 4. Too low battery voltage 5. Too old battery 	<p>Check the generator, regulator/rectifier and circuit connections and make necessary adjustments to obtain specified charging operation.</p> <p>Replace the battery and correct the charging system.</p> <p>Replace the battery.</p> <p>Recharge the battery fully.</p> <p>Replace the battery.</p>
Battery “sulfation”	<ol style="list-style-type: none"> 1. Incorrect charging rate (When not in use batteries should be checked at least once a month to avoid sulfation) 2. The battery was left unused in a cold climate for too long 	<p>Replace the battery.</p> <p>Replace the battery if badly sulfated.</p>


WIRING HARNESS, CABLE AND HOSE ROUTING

WIRING HARNESS ROUTING






10 N·m
(1.0 kgf·m, 7.0 lbf·ft)




Route the generator lead wire between the crankcase and starter motor and pass it over the crankcase.

Do not pinch the lead wires




Do not strongly pull the generator lead wire to the coupler side.




130 N·m
(13.0 kgf·m, 94.0 lbf·ft)

Gear position switch

6.5 N·m
(0.65 kgf·m, 4.5 lbf·ft)




13 N·m
(1.3 kgf·m, 9.5 lbf·ft)




1.5 N·m
(0.15 kgf·m, 1.0 lbf·ft)

Do not slacken.




5.5 N·m
(0.55 kgf·m, 4.0 lbf·ft)




11 N·m
(1.1 kgf·m, 8.0 lbf·ft)

Do not pinch the lead wire at this area








CABLE ROUTING



①	Throttle cable No.1	⑨	Left handlebar switch	*7	3 mm (0.12 in)
②	Throttle cable No.2	⑩	Frame	*8	Pass the clutch cable into the clutch cable guide.
③	Clutch cable	*1	Pass the throttle cables over the water bypass hose ⑤.		
④	Cable guide	*2	Pass the throttle cables to the right side of head pipe.		
⑤	Water bypass hose	*3	Pass the clutch cable to the left side of head pipe.		
⑥	Clutch cable guide	*4	7 mm (0.28 in)		
⑦	Bracket	*5	Within 1 turn counterclockwise.		
⑧	Right frame head cover	*6	Make sure the clutch cable is not contacted to the water hose and cylinder head cover cap.		

ITEM	N·m	kgf·m	lbf·ft
Ⓐ	4.5	0.45	3.5

INTAKE SYSTEM HOSE ROUTING






① Fuel feed hose	⑥ Washer
② ISC valve hose	*1 White mark
③ Intake pipe clamp	*2 Clamp end should face left side.
④ Outlet tube clamp	*3 Pass the IAP sensor hose #1 between the fuel feed hose.
⑤ Air cleaner lower mounting bolt	



ITEM	N·m	kgf·m	lbf·ft
Ⓐ	10	1.0	7.0
⑤	5.5	0.55	4.0



FUEL TANK DRAIN HOSE ROUTING





VIEW A

①	Fuel tank water drain hose	*2	Pass the hoses to the forward of frame.
②	Fuel tank breather hose No.1	*3	Connect the reservoir tank overflow hose ⑥ to the narrow side of 3 way joint ⑤.
③	Fuel tank breather hose No.2	*4	Pass the fuel tank breather hose No.2 to left side of the fuel tank water drain hose.
④	Fuel tank breather hose No.3	*5	Align the white making on the hoses with the clamp.
⑤	3-way joint	*6	Match the direction of 3-way joint and hoses.
⑥	Reservoir tank overflow hose	*7	White marking
*1	Set the fuel tank water drain hose and fuel tank breather hose No.1 with lengthwise backward.	*8	To fuel tank.


COOLING SYSTEM HOSE ROUTING





When clamping the fuel tank water drain hose, clamp the fuel tank water drain hose in this order (① → ② → ③).

IGNITION COIL INSTALLATION




① Ignition coil #1	*1	Pass the high tension cord behind the throttle cable guide.
② Ignition coil #2	*1	Pass the high tension cord behind the throttle cable guide.
③ Spark plug cap	*2	Pass the high tension cord under the fuel hose.
④ High tension cord	*2	Pass the high tension cord under the fuel hose.
⑤ Clamp		



ITEM	N-m	kgf-m	lbf-ft
A	6.5	0.65	4.5

FRONT BRAKE HOSE ROUTING




①	Brake hose	
*1	Pass the brake hose as shown.	*3 After the brake hose union has contacted the stopper, tighten the union bolt.
*2	Clamp the brake hose firmly.	



ITEM	N-m	kgf-m	lbf-ft
Ⓐ	23	2.3	16.5

REAR BRAKE HOSE ROUTING




VIEW A

①	Rear brake master cylinder	*1	Clamp ends should face as shown.
②	Rear brake hose	*2	Insert the reservoir tank hose to the union firmly.
③	Rear brake reservoir tank hose	*3	White paint faces outside before binding the clamp.
④	Pin	*4	After the brake hose union has contacted the stopper, tighten the union bolt.
⑤	Rear brake pedal		
⑥	Washer		
⑦	Cotter pin		



ITEM	N·m	kgf·m	lbf·ft
(A)	23	2.3	16.5
(B)	27	2.7	19.5
(C)	6	0.6	4.5
(D)	18	1.8	13.0

PAIR (AIR SUPPLY) SYSTEM HOSE ROUTING




①	PAIR control solenoid valve	*2	The clamp end should face downward.
②	PAIR reed valve	*3	The clamp end should face left side.
③	Air cleaner box	*4	The clamp end should face upward.
*1	White mark		




ITEM	N·m	kgf·m	lbf·ft
Ⓐ	10	1.0	7.0

FUEL TANK INSTALLATION



① Fuel tank	*2 Hung on projection part firmly.
② Fuel tank center cover	*3 Clean the surface before attaching the cushion.
③ Fuel tank cover	*4 Keep clearance 2 – 4 mm (0.08 – 0.16 in) between the fuel tank and fuel tank covers ②, ③, ④.
④ Fuel tank front cover	
*1 Apply adhesive agent.	*5 Insert the cushion to the bracket firmly.


MUFFLER & EXHAUST PIPE INSTALLATION



①	HO2 sensor	*2	The chamfer side of connector face the muffler side.
②	Muffler		
③	Rear muffler cover	*3	Contact the connector ④ to the stopper.
④	Connector	*4	Install the connector ④ to the exhaust pipe ⑤
⑤	Exhaust pipe		and then install the muffler ②.
*1	Apply muffler seal.		


ITEM	N·m	kgf·m	lbf·ft
Ⓐ	23	2.3	16.5
Ⓑ	25	2.5	18.0
Ⓒ	10	1.0	7.0
Ⓓ	17	1.7	12.5

SEAT LOCK CABLE ROUTING




①	Seat lock cable	*2	The tip of the cable is cylindrical shaped.
②	Clamp	*3	The tip of the cable is spherical shaped.
③	Flame	*4	Set the cable firmly.
*1	The lock part of clamp over the frame.	*5	Align the lib of seat lock assembly and groove of each parts.

FRONT FENDER INSTALLATION




① Front fender	③ Washer (RH only)
② Front stabilizer	*1 The embossed lettering of the front stabilizer must face lower side

FRONT LICENSE PLATE INSTALLATION (Only for P-12)



① Front license plate	② Clamp
-----------------------	---------


FRONT SIDE REFLEX REFLECTOR INSTALLATION (Only for P-24)



①	Reflex reflector	③	Washer
②	Reflector bolt	④	Front fork


ITEM	N·m	kgf·m	lbf·ft
② (A)	4.5	0.45	3.5
② (B)	1.8	0.18	1.5

FRAME COVER INSTALLATION



①	Frame upper cover (LH)	⑨	Frame head cover (RH)
②	Frame upper cover (RH)	⑩	Rear fender
③	Frame upper cover (CENTER)	⑪	Pillion rider handle
④	Frame front cover (LH)	*1	To footrest bracket.
⑤	Frame front cover (RH)	*2	To air cleaner box.
⑥	Frame cover (LH)	*3	To frame.
⑦	Frame cover (RH)	*4	To fuel tank.
⑧	Frame head cover (LH)	*5	To fuel tank cover.


FRAME INSTALLATION



①	Frame down tube
②	Frame
③	Engine mounting bracket

ITEM	N-m	kgf-m	lbf-ft
A	60	6.0	43.5
B	50	5.0	36.0


SIDE-STAND INSTALLATION



*1 Install the spring as shown.

ITEM	N-m	kgf-m	lbf-ft
A	40	4.0	29.0
B	10	1.0	7.0


CENTER STAND INSTALLATION (For P-12)



①	Center stand	③	Center stand cushion
②	Center stand spring	*1	Do not apply grease to the flange and thread part.

ITEM	N·m	kgf·m	lbf·ft
Ⓐ	60	6.0	43.5

REAR BRAKE PEDAL INSTALLATION




①	Brake pedal	⑥	Rear brake master cylinder
②	Footrest bracket	⑦	Circlip
③	Brake pedal spring	⑧	Washer
④	Brake switch spring	*1	Measuring position.
⑤	Brake switch		



ITEM	N·m	kgf·m	lbf·ft
Ⓐ	10	1.0	7.0
Ⓑ	18	1.8	13.0


HANDLEBARS INSTALLATION



①	Front brake master cylinder	*1	Set the boss of handlebar holder into the hole of upper bracket.
②	Clutch lever holder	*2	punch mark.
③	Handlebar holder	*3	Align the matching surface of front brake master cylinder with punch mark.
④	Guide	*4	Align the matching surface of clutch lever holder with punch mark.
⑤	Front brake hose		


ITEM	N-m	kgf-m	lbf-ft
Ⓐ	16	1.6	11.5
Ⓑ	6	0.6	4.5
Ⓒ	10	1.0	7.0
Ⓓ	6.5	0.65	4.5
Ⓔ	23	2.3	16.5
Ⓕ	1	0.1	0.5

HEADLIGHT COVER INSTALLATION



①	Headlight lower cover	④	Headlight side cover (RH)
②	Headlight upper cover	⑤	Headlight housing brace
③	Headlight side cover (LH)	⑥	Cushion

HEADLIGHT INSTALLATION






①	Headlight unit	④	Headlight side cover (LH)
②	Combination meter assembly	⑤	Headlight side cover (RH)
③	Headlight upper cover	⑥	Headlight housing brace




ITEM	N·m	kgf·m	lbf·ft
Ⓐ	6	0.6	4.5

FRONT TURN SIGNAL LIGHT INSTALLATION



VIEW B

RH





VIEW A

LH




①	Front turn signal light (RH)	③	Radiator reservoir tank	*2	Pass the front turn signal lead wire behind the front turn signal light.
②	Front turn signal light (LH)	*1	Coupler position.		

REAR COMBINATION LIGHT INSTALLATION




①	Brake/Tail light		Cut the tip of clamp after clamping the lead wires.		
②	Rear fender	*1	After clamping the rear turn signal light lead wire and license plate light lead wire, pass the lead wires inside the hole of the rear fender. Do not slacken.		
③	Rear frame center cover				
④	License plate light	*2			
⑤	Rear turn signal light		When installing the TO sensor, do not damage the brake/tail light bracket.		
⑥	TO sensor	*3	Set the cushion of brake/tail light to the rib of the rear frame center cover.		
					
		ITEM	N·m	kgf·m	lbf·ft
		Ⓐ	7	0.7	5.0

REGULATOR/RECTIFIER INSTALLATION




























VIEW A
















①	Regulator/Rectifier	④	Clamp	*2	Pass the regulator/rectifier lead wire along the frame. Do not slacken.
②	Bracket	⑤	ECM	*3	Clamp the regulator/rectifier lead wire at root of the connector.
③	Clamp	*1	Install the clamp to the bracket.		

SPECIAL TOOLS

 <p>09900-06107 Snap ring pliers (Open type)</p>	 <p>09900-06108 Snap ring pliers (Close type)</p>	 <p>09900-18710 Hexagon socket (12 mm)</p>	 <p>09900-20101 Vernier calipers (150 mm)</p>	 <p>09900-20102 Vernier calipers (200 mm)</p>
 <p>09900-20202 Micrometer (25 – 50 mm)</p>	 <p>09900-20203 Micrometer (50 – 75 mm)</p>	 <p>09900-20205 Micrometer (0 – 25 mm)</p>	 <p>09900-20530 Cylinder gauge set</p>	 <p>09900-20602 Dial gauge</p>
 <p>09900-20605 Dial calipers (10 – 34 mm)</p>	 <p>09900-20607 Dial gauge</p>	 <p>09900-20701 Dial gauge chuck</p>	 <p>09900-20803 Thickness gauge</p>	 <p>09900-20805 Tire depth gauge</p>
 <p>09900-21304 V blocks</p>	 <p>09900-22301 Plastigage (0.025 – 0.076 mm)</p>	 <p>09900-22302 Plastigage (0.051 – 0.152 mm)</p>	 <p>09900-22403 Small bore gauge (18 – 35 mm)</p>	 <p>09900-25008 Multi circuit tester set</p>
 <p>09900-25009 Needle-point probe set</p>	 <p>09904-41010 SUZUKI Diagnostic system set</p>	 <p>09910-60611 Universal clamp wrench</p>	 <p>09913-10750 Compression gauge adapter</p>	 <p>09913-50121 Oil seal remover</p>

<p>09913-70210 Bearing installing set (10 – 75 φ)</p>	<p>09915-40620 Oil filter wrench</p>	<p>09915-64512 Compression gauge</p>	<p>09915-72410 Oil pressure gauge attachment</p>	<p>09915-74521 Adapter hose</p>
<p>09915-77331 Oil pressure gauge (1 000 kPa)</p>	<p>09916-10911 Valve lapper set</p>	<p>09916-14510 Valve lifter</p>	<p>09916-14910 Valve lifter attachment</p>	<p>09916-84511 Tweezer</p>
<p>09917-14910 Tappet adjust driver</p>	<p>09917-47011 Vacuum pump gauge set</p>	<p>09920-53740 Clutch sleeve hub holder</p>	<p>09921-20210 Bearing remover (12 mm)</p>	<p>09921-20240 Bearing remover set</p>
<p>09923-73210 Bearing remover</p>	<p>09923-74511 Bearing remover</p>	<p>09924-84510 Bearing installer set</p>	<p>09925-18011 Bearing installer</p>	<p>09930-10121 Spark plug wrench set</p>
<p>09930-11950 Torx® wrench (T25H)</p>	<p>09930-30104 Rotor remover sliding shaft</p>	<p>09930-31921 Rotor remover set</p>	<p>09930-40113 Flywheel rotor holder</p>	<p>09930-44521 Rotor holder</p>

 <p>09930-82720 Mode selection switch</p>	 <p>09940-14911 Steering stem nut socket wrench</p>	 <p>09940-34520 T type handle</p>	 <p>09940-34581 Front fork assembling attachment (F)</p>	 <p>09940-40211 Fuel pressure gauge adapter</p>
 <p>09940-40220 Fuel pressure gauge attachment</p>	 <p>09940-52861 Front fork oil seal installer set</p>	 <p>09940-92720 Spring scale</p>	 <p>09941-34513 Bearing installer</p>	 <p>09941-54911 Bearing outer race remover</p>
 <p>09941-74911 Steering race installer</p>	 <p>09943-74111 Front fork oil level gauge</p>	 <p>99565-01010-028 CD-ROM Ver.28</p>		

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.

NOTE:

When order the special tool, please confirm whether it is available or not.

TIGHTENING TORQUE ENGINE

ITEM		N·m	kgf·m	lbf·ft
Cylinder head cover bolt	(Initial)	10	1.0	7.0
	(Final)	14	1.4	10.0
Cylinder head bolt		25	2.5	18.0
Cylinder head cover cap bolt		10	1.0	7.0
Cylinder side bolt		10	1.0	7.0
Primary drive gear nut		70	7.0	50.5
Exhaust pipe bolt		23	2.3	16.5
Exhaust connecting bolt		17	1.7	12.5
Muffler support bolt		23	2.3	16.5
Muffler chamber support bolt		23	2.3	16.5
Muffler front cover screw		10	1.0	7.0
Muffler rear cover stay bolt		10	1.0	7.0
Muffler rear cover bolt		10	1.0	7.0
Muffler body cover screw		10	1.0	7.0
Speed sensor rotor bolt		23	2.3	16.5
Speed sensor bolt		4.5	0.45	3.5
Speed sensor bracket bolt		10	1.0	7.0
Engine sprocket nut		120	12.0	87.0
Engine mounting nut		55	5.5	40.0
Engine mounting bracket nut		60	6.0	43.5
Crank balancer bolt		50	5.0	36.0
Valve clearance adjuster lock-nut		10	1.0	7.0
Camshaft sprocket bolt		15	1.5	11.0
Spark plug		11	1.1	8.0
Throttle cable nut		4.5	0.45	3.0
Camshaft journal holder bolt		10	1.0	7.0
Cam chain tension adjuster cap bolt		8	0.8	6.0
Cam chain tension adjuster mounting bolt		10	1.0	7.0
Cam chain tensioner bolt		10	1.0	7.0
PAIR reed valve cover bolt		10	1.0	7.0
Generator cover plug		11	1.1	8.0
Clutch cover bolt		10	1.0	7.0
Clutch sleeve hub nut		50	5.0	36.0
Clutch release adjuster lock-nut		5.5	0.55	4.0
Clutch cable adjuster lock-nut		4.5	0.45	3.0
Valve timing inspection plug		21	2.1	15.0
Starter clutch bolt		26	2.6	19.0
Generator cover bolt		10	1.0	7.0
Generator rotor bolt		130	13.0	94.0
Generator stator set bolt		11	1.1	8.0
Gearshift cam stopper bolt		10	1.0	7.0
Gearshift cam stopper plate bolt		11	1.1	8.0

ITEM		N·m	kgf·m	lbf·ft
Shift cam bearing retainer screw		10	1.0	7.0
Oil pressure switch		13	1.3	9.5
Oil filter		20	2.0	14.5
Oil pressure switch lead wire bolt		1.5	0.15	1.0
Gearshift arm stopper		19	1.9	13.5
Gearshift fork shaft plug		25	2.5	18.0
Oil pressure regulator		28	2.8	20.0
Oil filter union bolt		15	1.5	11.0
Oil separator plate bolt		10	1.0	7.0
Engine sprocket cover bolt		10	1.0	7.0
Ignition coil nut		6.5	0.65	4.5
Gearshift lever shaft		40	4.0	29.0
Gearshift link arm bolt		10	1.0	7.0
Crankshaft journal bolt	(M: 8) (Initial)	15	1.5	11.0
	(Final)	26	2.6	19.0
Crankcase bolt	(M: 6)	11	1.1	8.0
	(M: 8)	26	2.6	19.0
Oil gallery plug	Cylinder head	10	1.0	7.0
	Lower crankcase	25	2.5	18.0
Oil drain plug		23	2.3	16.5
Oil pump mounting bolt		10	1.0	7.0
Conrod cap bolt	(Initial)	15	1.5	11.0
	(Final)	90° (1/4 turn)		
Breather cover bolt		10	1.0	7.0
Oil strainer bolt		10	1.0	7.0
Oil pan bolt		10	1.0	7.0
Starter motor mounting bolt		10	1.0	7.0
Starter motor lead wire bolt		2.7	0.27	2.0
Headlight mounting screw		6	0.6	4.5

FI SYSTEM AND INTAKE AIR SYSTEM

ITEM	N·m	kgf-m	lbf-ft
GP switch mounting bolt	6.5	0.65	4.5
CKP sensor mounting bolt	5.5	0.55	4.0
Fuel delivery pipe mounting screw	5	0.5	3.5
Fuel pump mounting bolt	10	1.0	7.0
HO2 sensor	25	2.5	18.0
EVAP canister bracket mounting bolt	10	1.0	7.0
EVAP canister holder screw	5.5	0.55	4.0
EVAP system purge control solenoid valve mounting nut	7	0.7	5.0
Air cleaner upper mounting bolt	10	1.0	7.0
Air cleaner lower mounting bolt	5.5	0.55	4.0

COOLING SYSTEM

ITEM	N·m	kgf-m	lbf-ft
Impeller securing bolt	8	0.8	6.0
Water pump cover screw	5.5	0.55	4.0
Water pump mounting bolt	10	1.0	7.0
Water pump air bleeder bolt	6	0.6	4.5
Water jacket plug	25	2.5	18.0
Cooling fan motor assembly mounting bolt	7	0.7	5.0
Cooling fan mounting nut	1.1	0.11	1.0
ECT sensor	18	1.8	13.0
Cooling fan motor mounting screw	2.7	0.27	2.0
Radiator assembly mounting bolt	10	1.0	7.0
Reservoir tank mounting bolt	6	0.6	4.5
Reservoir tank bracket mounting bolt	10	1.0	7.0
Cylinder head water outlet pipe bolt	10	1.0	7.0
Water hose clamp screw	1.5	0.15	1.0
Thermostat connector cap bolt	10	1.0	7.0





CHASSIS

ITEM	N·m	kgf-m	lbf-ft
Steering stem head nut	65	6.5	47.0
Steering stem nut	23 N·m (2.3 kgf-m, 16.5 lbf-ft) then turn counterclockwise 0 – 1/4		
Front fork upper clamp bolt	23	2.3	16.5
Front fork lower clamp bolt	33	3.3	24.0
Front fork cap bolt	23	2.3	16.5
Front fork damper rod bolt	30	3.0	21.5
Front axle	65	6.5	47.0
Front axle pinch bolt	23	2.3	16.5
Handlebar clamp bolt	16	1.6	11.5
Handlebar holder bolt	23	2.3	16.5

Front brake master cylinder holder bolt	10	1.0	7.0
Front brake caliper mounting bolt	26	2.6	19.0
Front brake caliper sliding pin A	23	2.3	16.5
Front brake caliper sliding pin B	13	1.3	9.5
Front brake pad mounting pin	18	1.8	13.0
Front brake pad pin plug	2.5	0.25	2.0
Brake hose union bolt	23	2.3	16.5
Front brake lever pivot bolt	1	0.1	0.5
Front brake lever pivot bolt lock-nut	6	0.6	4.5
Air bleeder valve (Front and Rear brake caliper)	6	0.6	4.5
Brake disc bolt (Front)	18	1.8	13.0
Brake disc bolt (Rear)	23	2.3	16.5
Rear brake caliper mounting bolt	23	2.3	16.5
Rear brake caliper sliding pin	27	2.7	19.5
Rear brake pad mounting pin	18	1.8	13.0
Rear brake pad pin plug	2.5	0.25	2.0
Rear brake master cylinder mounting bolt	10	1.0	7.0
Rear brake master cylinder rod lock-nut	18	1.8	13.0
Front footrest bracket mounting bolt	23	2.3	16.5
Swingarm pivot nut	65	6.5	47.0
Rear shock absorber mounting nut (Upper)	50	5.0	36.0
Rear shock absorber mounting nut (Lower)	84	8.4	61.0
Rear axle nut	65	6.5	47.0
Rear sprocket nut	49	4.9	35.5
Side-stand nut	40	4.0	29.0
Side-stand bolt	10	1.0	7.0
Frame down tube bolt/nut	50	5.0	36.0
Rear turn signal light mounting nut	7	0.7	5.0
Front reflector bolt (For P-24)	4.5	0.45	3.5
Front reflex reflector (For P-24)	1.8	0.18	1.5
Clutch lever holder bolt	10	1.0	7.0
Clutch lever pivot nut	6.5	0.65	4.5
Bank sensor bolt	18	1.8	13.0
Center stand nut (For P-12)	60	6.0	43.5

TIGHTENING TORQUE CHART

Each fastener should be tightened to the torque specified in "TIGHTENING LIST". If no description or specification is provided, refer to the following tightening torque chart for the applicable torque for each fastener.

Strength	Unit	Thread diameter (Nominal diameter) [Ⓐ] [mm]								
		4	5	6	8	10	12	14	16	18
A equivalent of 4T strength fastener without flange 	N·m	1.5	3.0	5.5	13	29	45	65	105	160
	kgf-m	0.15	0.3	0.55	1.3	2.9	4.5	6.5	10.5	16.0
	lbf-ft	1.0	2.0	4.0	9.5	21.0	32.5	47.0	76.0	115.5
A equivalent of 4T strength fastener with flange 	N·m	1.7	3.3	6	14	32	50	72	116	176
	kgf-m	0.17	0.33	0.6	1.4	3.2	5.0	7.2	11.6	17.6
	lbf-ft	1.0	2.5	4.5	10.0	23.0	36.0	52.0	84.0	127.5
A equivalent of 7T strength fastener without flange and small crown shape bolt *1 	N·m	2.3	4.5	10	23	50	85	135	210	240
	kgf-m	0.23	0.45	1.0	2.3	5.0	8.5	13.5	21.0	24.0
	lbf-ft	1.5	3.5	7.0	16.5	36.0	61.5	97.5	152.0	173.5
A equivalent of 7T strength fastener with flange except small crown shape bolt 	N·m	2.5	5	11	25	55	94	149	231	264
	kgf-m	0.25	0.5	1.1	2.5	5.5	9.4	14.9	23.1	26.4
	lbf-ft	2.0	3.5	8.0	18.0	40.0	68.0	107.5	167.0	191.0

*1: Small crown shape bolt (crown shape bolt with flange either "Ⓐ = 5 & Ⓑ = 7" or "Ⓐ = 6 & Ⓑ = 8")

SERVICE DATA

VALVE + GUIDE

Unit: mm (in)

ITEM	STANDARD		LIMIT
Valve diam.	IN.	27.0 (1.06)	—
	EX.	22.5 (0.89)	—
Valve clearance (when cold)	IN.	0.05 – 0.10 (0.002 – 0.004)	—
	EX.	0.17 – 0.22 (0.007 – 0.009)	—
Valve guide to valve stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve guide I.D.	IN. & EX.	5.000 – 5.012 (0.1969 – 0.1973)	—
Valve stem O.D.	IN.	4.975 – 4.990 (0.1959 – 0.1965)	—
	EX.	4.955 – 4.970 (0.1951 – 0.1957)	—
Valve stem deflection	IN. & EX.	—	0.35 (0.014)
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve head thickness	IN. & EX.	—	0.5 (0.02)
Valve stem end length	IN. & EX.	—	2.2 (0.09)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length (IN. & EX.)	INNER	—	32.1 (1.26)
	OUTER	—	31.8 (1.25)
Valve spring tension (IN. & EX.)	INNER	58.2 – 71.2 N (6.0 – 7.3 kgf, 13.2 – 16.1 lbs) at length 28.0 mm (1.10 in)	—
	OUTER	158.7 – 182.5 N (16.2 – 18.6 kgf, 35.7 – 41.0 lbs) at length 31.5 mm (1.24 in)	—

CAMSHAFT + CYLINDER HEAD

Unit: mm (in)

ITEM	STANDARD		LIMIT
Cam height	IN.	33.34 – 33.38 (1.313 – 1.314)	33.04 (1.301)
	EX.	33.05 – 33.09 (1.301 – 1.303)	32.75 (1.289)
Camshaft journal oil clearance	0.032 – 0.066 (0.0013 – 0.0026)		0.150 (0.0059)
Camshaft journal holder I.D.	22.012 – 22.025 (0.8666 – 0.8671)		—
Camshaft journal O.D.	21.959 – 21.980 (0.8645 – 0.8654)		—
Camshaft runout	—		0.10 (0.004)
Rocker arm I.D.	IN. & EX.	12.003 – 12.018 (0.4726 – 0.4731)	—
Rocker arm shaft O.D.	IN. & EX.	11.986 – 11.994 (0.4719 – 0.4722)	—
Cylinder head distortion	—		0.10 (0.004)

CYLINDER + PISTON + PISTON RING

Unit: mm (in)

ITEM	STANDARD		LIMIT	
Compression pressure	1 300 – 1 700 kPa (13 – 17 kgf/cm ² , 185 – 242 psi)		1 000 kPa (10 kgf/cm ² , 142 psi)	
Compression pressure difference	—		200 kPa (2 kgf/cm ² , 28 psi)	
Piston-to-cylinder clearance	0.04 – 0.05 (0.001 – 0.002)		0.120 (0.0047)	
Cylinder bore	53.500 – 53.515 (2.1063 – 2.1069)		53.590 (2.1098)	
Piston diam.	53.455 – 53.470 (2.1045 – 2.1051) Measure at 10 mm (0.4 in) from the skirt end.		53.380 (2.1016)	
Cylinder distortion	—		0.10 (0.004)	
Piston ring free end gap	1st	1R	Approx. 5.3 (0.21)	4.2 (0.17)
	2nd	2R	Approx. 4.6 (0.18)	3.6 (0.14)
Piston ring end gap	1st		0.20 – 0.32 (0.008 – 0.013)	0.50 (0.020)
	2nd		0.20 – 0.32 (0.008 – 0.013)	0.50 (0.020)
Piston ring-to-groove clearance	1st		—	0.180 (0.0071)
	2nd		—	0.150 (0.0059)
Piston ring groove width	1st		1.01 – 1.03 (0.0398 – 0.0406)	—
	2nd		1.01 – 1.03 (0.0398 – 0.0406)	—
	Oil		2.01 – 2.03 (0.0791 – 0.0799)	—
Piston ring thickness	1st		0.97 – 0.99 (0.0382 – 0.0390)	—
	2nd		0.97 – 0.99 (0.0382 – 0.0390)	—
Piston pin bore	15.002 – 15.008 (0.5906 – 0.5909)		15.030 (0.5917)	
Piston pin O.D.	14.996 – 15.000 (0.5904 – 0.5906)		14.980 (0.5898)	

CONROD + CRANKSHAFT

Unit: mm (in)

ITEM	STANDARD		LIMIT
Conrod small end I.D.	15.006 – 15.014 (0.5908 – 0.5911)		15.040 (0.5921)
Conrod big end side clearance	0.10 – 0.20 (0.004 – 0.008)		0.30 (0.012)
Conrod big end width	19.95 – 20.00 (0.7854 – 0.7874)		—
Crank pin width	20.10 – 20.15 (0.7913 – 0.7933)		—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)		0.080 (0.0031)
Crank pin O.D.	30.976 – 31.000 (1.2195 – 1.2205)		—
Crankshaft journal oil clearance	0.016 – 0.040 (0.0006 – 0.0016)		0.080 (0.0031)
Crankshaft journal O.D.	29.976 – 30.000 (1.1802 – 1.1811)		—
Crankshaft thrust bearing thickness	Right side	2.450 – 2.625 (0.0965 – 0.1033)	—
	Left side	2.450 – 2.475 (0.0965 – 0.0974)	—
Crankshaft thrust clearance	0.050 – 0.105 (0.0020 – 0.0041)		—
Crankshaft runout	—		0.05 (0.002)

CRANK BALANCER

Unit: mm (in)

ITEM	STANDARD	LIMIT
Crank balancer journal oil clearance	0.020 – 0.044 (0.0008 – 0.0017)	0.080 (0.0031)
Crank balancer journal O.D.	27.976 – 28.000 (1.0660 – 1.1024)	—
Balancer spring free length	—	10.3 (0.41)

OIL PUMP

ITEM	STANDARD	LIMIT
Oil pressure (at 60 °C, 140 °F)	200 – 500 kPa (2 – 5 kgf/cm ² , 28 – 71 psi) at 3 000 r/min	—

CLUTCH

Unit: mm (in)

ITEM	STANDARD / SPECIFICATION		LIMIT
Clutch cable play	10 – 15 (0.39 – 0.59)		—
Clutch release screw	1 turn counterclockwise		—
Drive plate thickness	No. 1 and 2	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
	No. 3	3.42 – 3.58 (0.135 – 0.141)	3.12 (0.123)
Drive plate claw width	No. 1 and 2	15.9 – 16.0 (0.626 – 0.630)	15.2 (0.598)
	No. 3	15.98 – 16.05 (0.629 – 0.632)	15.2 (0.598)
Driven plate distortion	No. 1, 2 and 3	—	0.10 (0.004)
Clutch spring free length	38.5 (1.528)		36.6 (1.441)

TRANSMISSION + DRIVE CHAIN

Unit: mm (in) Except ratio

ITEM	STANDARD		LIMIT
Primary reduction ratio	3.238 (68/21)		—
Final reduction ratio	3.286 (46/14)		—
Gear ratios	Low	2.417 (29/12)	—
	2nd	1.529 (26/17)	—
	3rd	1.182 (26/22)	—
	4th	1.043 (24/23)	—
	5th	0.909 (20/22)	—
	Top	0.808 (21/26)	—
Shift fork to groove clearance	0.10 – 0.30 (0.004 – 0.012)		0.50 (0.020)
Shift fork groove width	5.0 – 5.1 (0.197 – 0.201)		—
Shift fork thickness	4.8 – 4.9 (0.189 – 0.193)		—
Drive chain	Type	DID520VF	
	Links	116 links	—
	20-pitch length	—	320.5 (12.62)
Drive chain slack	20 – 30 (0.8 – 1.2)		—
Gearshift lever height	28 – 38 (1.1 – 1.5)		—

THERMOSTAT + RADIATOR + FAN + COOLANT

ITEM	STANDARD/SPECIFICATION		NOTE
Thermostat valve opening temperature	Approx. 88 °C (190 °F)		—
Thermostat valve lift	4.5 mm (0.18 in) and over at 100 °C (212 °F)		—
ECT sensor resistance	20 °C (68 °F)	Approx. 2.45 kΩ	—
	50 °C (122 °F)	Approx. 0.811 kΩ	—
	80 °C (176 °F)	Approx. 0.318 kΩ	—
	110 °C (230 °F)	Approx. 0.142 kΩ	—
Radiator cap valve opening pressure	93 – 123 kPa (0.93 – 1.23 kgf/cm ² , 13.2 – 17.5 psi)		—
Cooling fan operating temperature	OFF→ON	Approx. 105 °C (221°F)	—
	ON→OFF	Approx. 100 °C (212 °F)	—
Engine coolant type	Use an antifreeze/coolant compatible with aluminum radiator, mixed with distilled water only, at the ratio of 50:50.		—
Engine coolant	Reserve tank side	Approx. 250 ml (0.3/0.2 US/lmp qt)	—
	Engine side	Approx. 1 100 ml (1.2/1.0 US/lmp qt)	—

INJECTOR + FUEL PUMP + FUEL PRESSURE REGULATOR

ITEM	STANDARD	NOTE
Injector resistance	11.5 – 12.5 Ω at 20 °C (68 °F)	
Fuel pump discharge amount	97.2 ml (3.3/3.4 US/lmp oz) or more/10 sec.	
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	

FI SENSORS

ITEM	STANDARD		NOTE
CKP sensor resistance	150 – 230 Ω		
CKP sensor peak voltage	1.5 V or more		When cranking
IAP sensor input voltage	4.5 – 5.5 V		
IAP sensor output voltage	Approx. 2.6 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.4 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
TO sensor resistance	25.0 – 26.0 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V or more		From 1st to Top
GP switch resistance	Approx. 500 Ω or more		
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	80 V or more		When cranking
HO2 sensor output voltage	0.4 V or less at idle speed		
	0.6 V or more at 5 000 r/min		
HO2 sensor heater resistance	6.7 – 9.5 Ω at 23 °C (73 °F)		
PAIR control solenoid valve resistance	18 – 22 Ω at 20 °C (68 °F)		
EVAP purge control solenoid valve resistance	Approx. 32 Ω at 20 – 30 °C (68 – 86 °F)		
ISC valve resistance	Approx. 20 Ω at 20 °C (68 °F)		

THROTTLE BODY

ITEM	STANDARD / SPECIFICATION
Bore size	26 mm (1.02 in)
I.D. No.	48H1
Idle r/min	1 400 \pm 100 r/min
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)

ELECTRICAL

Unit: mm (in)

ITEM		STANDARD / SPECIFICATION		NOTE
Firing order		1.2		
Spark plug	Type	NGK: CR7E DENSO: U22ESR-N		
	Gap	0.7 – 0.8 (0.028 – 0.031)		
Spark performance		Over 8 (0.3) at 1 atm.		
CKP sensor resistance		150 – 230 Ω		
CKP sensor peak voltage		1.5 V or more		
Ignition coil resistance	Primary	3.4 – 4.6 Ω		Terminal – Terminal
	Secondary	11.05 – 14.95 k Ω		Plug cap – Terminal
Ignition coil primary peak voltage		80 V or more		
Generator coil resistance		0.2 – 0.9 Ω		
Generator no-load voltage (When engine is cold)		60 V (AC) or more at 5 000 r/min		
Starter motor brush length	Standard	10 (0.39)		
	Limit	6.5 (0.26)		
Regulated voltage		14.0 – 15.5 V at 5 000 r/min		
Starter relay resistance		3 – 6 Ω		
GP switch voltage		0.6 V or more (From 1st to Top)		
Battery	Type designation	YTX9-BS		
	Capacity	12 V 28.8 kC (8 Ah)/10 HR		
Fuse size	Headlight	15 A		
	Signal	10 A		
	Ignition	10 A		
	Fuel	10 A		
	Main	30 A		

WATTAGE

Unit: W

ITEM		SPECIFICATION
Headlight	HI	60
	LO	55
Position		5 × 2
Brake/Tail light		21/5
Turn signal light		10 × 4
License plate light		5
Combination meter light		LED
Turn signal indicator light		LED
High beam indicator light		LED
Neutral indicator light		LED
FI indicator light		LED
Oil pressure indicator light		LED
Engine coolant temp. indicator light		LED
Engine rpm indicator light		LED

BRAKE + WHEEL

Unit: mm (in)

ITEM	STANDARD / SPECIFICATION		LIMIT
Rear brake pedal height	38 – 48 (1.5 – 1.9)		—
Brake disc thickness	Front	4.8 – 5.2 (0.189 – 0.205)	4.5 (0.18)
	Rear	4.3 – 4.7 (0.169 – 0.185)	4.0 (0.16)
Brake disc runout	—		0.30 (0.012)
Brake master cylinder bore & piston diam	Front	Approx 11.0 (0.43)	—
	Rear	Approx 14.0 (0.55)	—
Brake caliper cylinder bore & piston diam	Front	Leading	Approx 27.0 (1.06)
		Trailing	
	Rear	Approx 38.2 (1.50)	—
Brake fluid type	DOT 4		—
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)
Wheel rim size	Front	17 M/C × MT 3.00	—
	Rear	17 M/C × MT 4.00	—
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)

TIRE

ITEM	STANDARD / SPECIFICATION		LIMIT
Cold inflation tire pressure (Solo riding)	Front	250 kPa (2.50 kgf/cm ² , 36 psi)	—
	Rear	250 kPa (2.50 kgf/cm ² , 36 psi)	—
Cold inflation tire pressure (Dual riding)	Front	250 kPa (2.50 kgf/cm ² , 36 psi)	—
	Rear	250 kPa (2.50 kgf/cm ² , 36 psi)	—
Tire size	Front	110/80-17 M/C 57H	—
	Rear	140/70-17 M/C 66H	—
Tire type	Front	IRC RX-01F D	—
	Rear	IRC RX-01R	—
Tire tread depth (Recommended depth)	Front	—	1.6 (0.06)
	Rear	—	2.0 (0.08)

SUSPENSION

Unit: mm (in)

ITEM	STANDARD / SPECIFICATION	LIMIT
Front fork stroke	120 (4.72)	—
Front fork spring free length	275.9 (10.86)	270 (10.6)
Front fork oil level (without spring, outer tube fully compressed)	136 (5.4)	—
Front fork oil type	SUZUKI FORK OIL G10 or equivalent	—
Front fork oil capacity (each leg)	338 ml (11.4/11.9 US/Imp oz)	—
Front fork inner tube O.D.	37 (1.46)	—
Rear shock absorber spring adjuster	3rd position	—
Rear wheel travel	120 (4.7)	—
Swingarm pivot shaft runout	—	0.3 (0.01)

FUEL + OIL

ITEM	SPECIFICATION		NOTE
Fuel type	Gasoline used should be graded 91 octane or higher. An unleaded gasoline is recommended.		
Fuel tank capacity	Including reserve	13.3 L (3.5/2.9 US/Imp gal)	
	Fuel mark indicator blinking	9.3 L (2.4/2.0 US/Imp gal)	
Engine oil type	SAE 10W-40, API SG or higher with JASO MA		
Engine oil capacity	Change	2.1 L (2.2/1.8 US/Imp qt)	
	Filter change	2.4 L (2.5/2.1 US/Imp qt)	
	Overhaul	2.4 L (2.5/2.1 US/Imp qt)	