



COMSEN PARKS CONTROL USER MANUAL

TABLE OF CONTENTS

1. INTRODUCTION.....	3
2. SYSTEM REQUIREMENTS.....	4
3. SOFTWARE PROFILE.....	5
4. WORKING WITH COMSEN PARKS CONTROL.....	6

INTRODUCTION

This User Guide provides clear and concise information on how to use the Comsen Parks Control (CPC) software.

Its purpose is to show the user how to use the software effectively in the shortest possible time. Guided steps in managing the many and varied functions are provided.

Included are detailed descriptions and illustrations of the different options presented. Answers and solutions to the most common problems that may arise are easy to find. The user will be able to use the application efficiently using this tool. The User guide ensures that your Remote Management Utility management system is working optimally for your Park.

SYSTEM REQUIREMENTS

The Comsen Parks Control software is web based and runs on all standard web browsers on computer platforms such as Windows, MacOS and Linux.

The Comsen Control Server module is networked into your local system using a standard network cable connected to a local computer or network router.

SOFTWARE PROFILE

WHAT IS COMSEN PARKS CONTROL?

Comsen Parks Control (CPC) is the management software that comes with the Comsen Control Remote Utilities Management (CCRUM) system used to control and meter utilities such as energy and water. Utilising the software, you control and manage the data CPC provides remotely.

The application is installed on the Consen Server module and linked to the Park control centre network allowing the operation and management of each and every site remotely.

THE BENIFITS CPC PROVIDES?

Utilising the CCRUM System and CPC software the user has total management of each site of the park. This gives you effective control over all services provided with complete information of incidents and alarms that occur.

The software's graphical interface is customised with the installation of either an aerial photograph or suitable graphical layout of each park which facilitates management tasks.

CPC lets you know the exact consumption of water and energy utilities at each site in real time. All site utilities and lighting can be enabled or disabled directly from the Park control centre. CPC also supplies instant information on notifications, alerts and detection of vehicles on their site.

CPC can allow the Park to provide its users with the ability to activate and deactivate their own site utilities and lighting and view their consumption and alerts using an App installed on their smartphone or tablet. This service when offered by the Park improves customer satisfaction.

Other interesting features in which CPC improves process control and integrated management of the park are:

- Management of prepaid utilities
- Detects presence of the vehicle on the site
- Creating graphs and consumption statistics
- Scheduling management of lighting
- Integration with other vendors software programs is possible using the professional API interface available
- Ease of management differentiation of park sites by park area, site size or defined groups of customers
- Price management of utilities.

WORKING WITH COMSEN MARINA CONTROL

The following pages is a detailed explanation on how to use CPC effectively. It has been divided into the different sections of CPC functionalities:


1. Starting CPC.....	7
2. Site symbol explanation.....	9
3. Selecting one or more sites.....	11
4. Changing site Information.....	14
5. Utility activation or deactivation.....	15
6. User management.....	16
7. Prepayment management.....	17
8. Lighting control.....	19
9. Changing the access Password.....	21
10. Changing the Interface appearance.....	22
11. Maintenance - controller detection.....	23
12. Control of Indicator monitoring.....	24
13. Creating Setup Report.....	26
14. Generating Consumption Graphs.....	27
15. Commands and Notifications.....	29
16. Logout and close CPC.....	31

1. Starting CPC.

When you start the CPC program the Home login screen is displayed:



To access the control functions click the “Log In” option below the page header. This displays the “Access Panel”, where you must enter your user name and password:



Then click the Access button. If the data entered is correct, the main application screen will appear:



The main screen is divided into several sections:

In the middle is the aerial or Map view displaying all available sites of the Park. This display can also be changed to the Matrix view where all the sites are displayed sorted by their site identification number.

On the left at the top of the screen are the map *Navigation Control Buttons*. These allow the map navigation by zooming in and out, moving up or down and left or right to display the map in the desired view. The map can also be dragged by moving the mouse with the left button pressed and zoomed in and out by turning the mouse wheel.

On the right of the screen is the *Right panel* that allows interaction with the application. This panel is used for selecting the Map or Matrix views and also displays all commands sent and notifications received by the CCRUM.

The Top panel is displayed in the top middle of screen. Selecting the various icons of this panel allows control of the global functions of CPC described further in this manual. This panel changes appearance when a site is selected.

2. Site symbol explanation.

Each site point displays information about its current status. Different coloured symbols represent the current state of each site.

a) INDICATORS OF THE STATE OF SITE

Normal

If everything is functional and vehicle with the CCRUM Locator is present its site status is *Normal*.


In this case a white utility symbol will be seen:



Absent

If everything is functional and a vehicle is fitted with the CCRUM Locator, when the vehicle is *not* present its site status is *Absent*.

In this case the symbol is displayed as an outline:



Site without coverage

If the system fails to detect the sites CCRUM controller the site status is deemed unreachable or *site without coverage*.

In this case the system creates an alarm to report the status in *Notifications tab* of the *Right panel* and shows a yellow vessel in the position.



Protections Off (Circuit breaker)


If the sites circuit breaker is switched off or trips the site status is deemed Protections Off.


In this case the system creates an alarm to report the alarm in *Notifications tab* of the *Right panel* and shows a red vessel in the position.





b) INDICATORS POWER AND WATER UTILITIES

Each site indicates the status of the power and water utilities at all times by displaying icons over the utility symbol. This icons changes colour as the supply status changes:

 = site power supply is *Active*

 = site power supply is *Inactive*

 = site water supply is *Active*

 = site water supply is *Inactive*.

3. Selecting one or more sites.

Site selection is indicated by an outline surrounding the utility symbol. Site selection can be achieved in several different ways:

a) SELECT USING AERIAL MAP VIEW OF THE PARK.

From the aerial map view simply mouse-hover over utility symbol of the desired site and click the left-button to select that site.



Click the lowest button on the map *Navigation Control Button menu* to allow multiple sites to be selected. Drag the mouse over the map area with the left button pressed to select multiply sites



Click the *Navigation Control Button* again to return to map navigation mode.

b) SELECT USING MATRIX VIEW OF THE SITES.

Click the *Matrix* button in the Right Panel to display the sites in a sequentially numbered list starting from the first site.



Hover over the desired utility symbol and click the left mouse button to select that site. In the example below site #32 is selected.



Drag the mouse over the matrix area with the left button pressed to select multiply sites.


Click the *Map* button in the right panel to return the aerial map view.

c) SELECT SITE USING GROUP IN TOP PANEL.


An icon called Group is shown in the top panel:



Clicking on this icon will open a new window titled Select. This allows one or more sites to be selected depending on the characteristics of site.



In the Select window there are various tabs which can be selected. Each tab offers a drop-down menu from which the options can be selected.



Single: allows the selection of one site by entering the site number in the input box or selecting from the drop down list.

Area: allows the selection of all sites assigned to a designated area within the park.

Size: allows selection of all sites that have the selected Area. For this option to be viable the site size needs to be entered at initial setup.

Group: allows selection of all sites of the same group. Groups can setup according to the parks individual needs.

Type: allows selecting of sites designated as Permanent or Casual.

All: allows selection of all sites at the park.

Clicking select will close the window and show the aerial map view of the park with the selected sites indicated by outline around the site symbol on sites 84-92 as shown below.



4. Changing site Information.

When a new customer is assigned to a site the site information can be changed to reflect correct details of the new tenant.

Select the site to be modified, as discribed in Section 3 above. Once selected the top menu changes to show the details of the selected site.



Click on the Information icon (indicated on the bottom row, left). The information window appears which has two selectable tabs, *General* and *Information*.

General Tab.

A screenshot of a software window titled 'Information'. It has two tabs: 'General' (selected) and 'Location'. Under the 'General' tab, there are four labels: 'Area:', 'Size:', 'Group:', and 'Site type:'. Each label is followed by a drop-down menu. At the bottom of the window, there are two buttons: 'Update general Information' and 'Cancel'.

The desired information can be entered by clicking on the drop down menu for each item and selecting the appropriate item.


Location Tab.

A screenshot of the same 'Information' window, but with the 'Location' tab selected. Under the 'Location' tab, there are two sections: 'Status:' and 'Supplies auto management:'. Each section has two buttons: 'ON' and 'OFF'. At the bottom of the window, there are two buttons: 'Update location' and 'Cancel'.

Set the Status to ON to inform the system that a CCRUM Locator module is installed in the vehicle at the selected site. Supplies auto management ON indicates that the utilities will be automatically activated when the CCRUM Locator is detected and off when not.

5. Utility activation or deactivation.

Utilities at each site can be activated or deactivated at any time. Select the desired site as described in section 3 above. Once selected the top menu changes to show the selected site information.



Water consumption and control.



Description:

- The water droplet is coloured blue when supply is activated and grey when deactivated
- The counter displays the current water meter reading
- On: when clicked activates the water supply
- Off: when clicked deactivates the water supply.


Power consumption and control.



Description:

- The power plug is coloured yellow when supply is activated and grey when deactivated
- The counter displays the current power meter reading
- On: when clicked activates the power supply
- Off: when clicked deactivates the power supply.

Power and water control.




Description:

- On: when clicked activates both the water and power supply
- Off: when clicked deactivates both the water and power supply.


6. User management control.

CCRUM allows site users to control their own supply via the CC site app when installed on their smartphone or tablet. User management activates this function and controls what features the user can access.

To use this function select the desired site and then click the User icon from the top menu as indicated below:



The following window appears:



- Control ON / OFF: This determines if the user of a site can control the site using the CC site app. When control is on the User icon to the right turns green and is red when off
- Password: Used to set password for user access control
- Actuation: Allows the user to activate the water and power utilities
- Supplies Graph: Allows the user the generate a graph of their utilities usage
- User Notifications: Sets the notifications that the user will receive.

Once you have selected the desired settings, click Accept.

7. Prepayment management.

CPC allows independent control for prepaid management at each site. To use this function select the desired site and then click the User icon from the top menu as indicated below:




The Prepayment window allows management of the site prepayment utilities. It has two selectable tabs Prepayment and Supplies prices:

Prepayment Tab:

- Payment ON/OFF: enables or disables the prepayment facility
- Associate Supplies: selects which utilities apply to prepaid amount
- Reload Amount: Enter the amount of prepayment paid
- Prepaid Left (\$): Select for the user receives a notification of much prepayment remains
- Warning Threshold (\$): Sets the threshold of prepayment amount before the user receives a PrePaid Left notification.

Supplies prices:



The screenshot shows a 'Prepayment' dialog box with a close button (X) in the top right corner. Inside the dialog, there are two tabs: 'Prepayment' and 'Supply prices'. The 'Supply prices' tab is selected and highlighted in orange. Under this tab, there are two input fields. The first is labeled 'Water Tariff (\$ / m3)' and has a numeric input field with the value '0'. The second is labeled 'Electricity Price (\$ / Kwh)' and also has a numeric input field with the value '0'. At the bottom of the dialog, there are two buttons: 'Update supplies tariff' and 'Cancel'.

- Water Tariff (\$/m3): Sets the tariff in dollars for a cubic metre of water (1000L)
- Electricity Price (\$/Kwh): Sets the price in dollars for 1 kilowatt hour of electricity.


8. Lighting control.

CPC allows extensive control of courtesy lighting. To use this function select the desired site and select the courtesy lighting control icon:




The Lighting control windows allows control of the courtesy lighting via three tabs Manual, Auto and Solar:

Manual Tab:




With manual lighting control the courtesy lighting can be switched ON or OFF at any time.

Auto Tab:




With Auto Lighting control the system will switch the courtesy lighting ON and OFF at the selected times on the selected days.

Solar Tab:



With Solar lighting is selected the courtesy lighting will be operated by the solar control if installed.

When the desired lighting control is selected click the Accept button on the bottom of the window and a confirmation window is displayed.



Click OK on the confirmation window to complete the desired action.

9. Changing the access Password.

The password for the application is assigned in the initial installation. To change the password select the password icon from the top menu when no site is selected:



When selected the Password window is displayed:

A dialog box titled "Password" with a close button (X) in the top right corner. Inside the dialog, the text "Change Password" is displayed. Below this, there are three input fields: "Previous Password", "New Password", and "Re-enter the new password". At the bottom of the dialog, there are two buttons: "Set Password" and "Cancel".

For the password change to be successful you must enter the previous password first. Then enter new password and to avoid errors re-enter the password. Then click the Set Password button to register the change in the database. The new password is now required the next time CPC is started.

10. Changing the Interface appearance.

The appearance of the screen interface can be changed to one of 24 preset themes. Select the interface icon from the top menu when no site is selected:



When selected the interface window is displayed:




Select the drop down menu and scroll through the available themes. When the desired theme is located select that theme by clicking on it. Click the Close button to close the window and application screen will be displayed using the theme selected.

11. Maintenance - controller detection.

The maintenance option allows global detection of all CCRUM controllers. Select the maintenance icon from the top menu when no site is selected:



When selected the maintenance window is displayed:



To initiate the detection process click the Detect Control Units button. The maintenance window will close and the system will start the process.

The command will become visible under the Command tab in the right panel. Clicking on the command will display the detection details:




12. Control of Indicator monitoring.

The CCM system can be set to monitor the systems water and power supply indications for each site. Select the indicator icon from the top menu with the desired site selected:



When selected the Indicator monitoring window is displayed:



The window has Energy and Water tabs that allow control of monitoring for each supply. Click on either tab to configure the desired monitoring setting. Both tabs are identical in appearance except the Energy tab value is in Wh (watt hours) and the Water tab value is L (litres).

When monitoring is set to OFF the options are greyed out. When monitoring is set to ON the options become available as displayed below:

The first row selects activation threshold value for monitoring and the time interval of the monitoring. The threshold fields are:

- Absolute value
- Difference
- Above in watt/hours or litres
- Below value in watt/hours or litres
- Interval that monitoring is carried out.

The second row selects the Activation period that monitoring is carried out. The activation fields are:


- Always
- Interval with a user defined begin and end time.

13. Creating Setup Report.

The setup of one or more sites can be displayed on the screen and the data can be exported in CSV file format for use outside the application. Select the Setup report icon from the top menu with one or more sites selected:



The Setup Report window is opened displaying the current data:




- Number of site and other information such as area, size and group are displayed first
- Energy Supply section displays a brief summary of the supply such as the activation status, meter reading, prepaid tariff, prepaid status and when the last update was made
- Water Supply section displays a brief summary of the supply such as the activation status, meter reading, prepaid tariff, prepaid status and when the last update was made.

If you want to export the report to a file in CSV format, click the Generate CSV button on the bottom of the window and the file will be saved on your computer to the browser downloads folder.

14. Generating Consumption Graphs.

Graphs of the various supply statistics can be displayed on the screen and the data can be exported in CSV file format for use outside the application. Select the Statistic icon from the top menu with the desired site selected.



The Consumption Graphs setup window is displayed:

Consumption Graphs

Supply type
☒ Water ☐ Energy

Value type
☐ L ☒ m3

Measurement type
☒ Consumption ☐ Meter

Measure Resolution
Minute

Kind of representation
☒ Separately ☐ All together

Dates Range
From: To:

Energy

Supply type
☐ Water ☒ Energy

Value type
☐ Wh ☒ Kwh

Generate graph **Cancel**

Use the Consumption graph window to select the following:

- Supplies type, Water or Energy
- Value type, L or m3 (water) or Wh or kWh (energy)
- Measurement type, Consumption or Meter reading
- Measurement resolution, minutes to years
- Kind of representation, Separately or All together
- Date range, Select either date From or date To fields and the following date and time selection window will be displayed:

Consumption Graphs [X]

Supp [Water]

Value [L]

Meas [2] (July 2015)

Time of day
Meas 00:00
 Minute []
 Hour []

Kind [Sep]
 Mins []

Dates [Now] [Accept]
 From: [] To: []


[Generate graph] [Cancel]

- Enter the required start year, month, day, hour and minutes for both the From and To date range fields.

Once all the appropriate fields are selected click the Generate Graph button that appears on the bottom of the window and a graph of the selected supply is displayed. On the bottom left side of the graph is the CSV button. Selecting the CSV will generate a file with all the statistical data in the download directory of the browser being used. This information can be imported for use in other programs.

15. Commands and Notifications.


On the right side of the home screen is Selection panel where the Command Tab and Notification Tabs are displayed.




Selecting the Command Tab displays all the commands of all operations in the Park. These commands include courtesy light operations, utilities activation and deactivation and movements of vehicles fitted with the CCRUM locator module.

Selecting the Tab Notifications displays all alarms and notifications generated by the system. Clicking on any notification will display a window showing the full details of the notification (as shown below). These details include the type of notification, information, warning or alarm along with date and time of the notification, the relevant site and if the notification has been confirmed.


The notification can be validated to show that it has been taken into account by pressing the Validate button on the bottom of the window.



The Selection panel includes the option to search the Commands and Notifications by selecting the search button on the bottom of the panel.



Once search is selected the appearance of the Selection Panel will change to present several options:



To display the desired Commands and Notification select the required date range in the From and To fields. Then select the desired search criteria by checking the appropriate items.

Once the desired options are selected, click Accept to display the commands and notifications that meet the selection criteria.

16. Logout and close CPC.

Once all control and management is completed the application can be closed. Select the User icon in the top right of the screen:



Once selected a small window will appear with the user name to the left of the logo. Click on this icon to close the application.



There is also the option of leaving the application without logging off by simply closing the browser window in the normal manner.