

# 4-noks®



---

## User Manual



# **ZMONITOR**

Tool for managing parametric controllers

# INDICE

1. PRESENTATION.....	4
MINIMUM SYSTEM REQUIREMENTS.....	4
DEVICES TO BE MANAGED ZMONITOR.....	5
2. INSTALLATION .....	6
3. LANGUAGE.....	8
4. MAIN SCREEN.....	8
5. MAIN MENU .....	9
6. FUNTION KEYS .....	9
7. DESCRIPTION OF DEVICES.....	10
8. DISPLAY AREA PROJECT .....	10
9. DISPLAY AREA REGISTER.....	11
10. CONNECTION GATEWAY TO A PC .....	11
Connection PC-USB Gateway.....	12
Connection PC-Gateway 485 .....	12
Connection PC-GATEWAY ETHERNET .....	12
11. JOIN DEVICES .....	13
Getting Started .....	13
JOIN.....	13
12. ADDING THIRD PARTY DEVICE through BRIDGE-485 DEVICE.....	15
13. AUTOMATIC DEVICE SCAN (only GATEWAY MODBUS RTU).....	17
LOG FUNCTION.....	18
14. SAVE PROJECT .....	19
15. OPEN PROJECT .....	19
16. TUTORIAL .....	19
Turn on Relay (on ZR-PLUG-M device).....	19
Impostazione soglie temperatura (esempio su TCM).....	20
17. REFRESH Register.....	20
18. DEBUG .....	20
19. COSA FARE IN CASO DI .....	21

## IMPORTANT WARNINGS



BEFORE INSTALLING OR HANDLING THE DEVICE PLEASE CAREFULLY READ AND FOLLOW THE INSTRUCTIONS DESCRIBED IN THIS MANUAL.

The device that this software is dedicated to has been developed to operate risk-free and for a specific purpose, as long as:

the software is installed, programmed, run and maintained according to the instructions in this manual and by qualified personnel;

all the conditions prescribed in the installation and user manual of the appliance in question are observed.

All other uses and modifications made to the device that are not authorized by the manufacturer are considered improper.

Liability for injury or damage caused by the incorrect use of the device lies exclusively with the user.

# 1. PRESENTATION

ZMONITOR is the new software developed by 4-noks for managing parametric controllers.

With a simple and intuitive user interface, ZMONITOR allows the complete configuration of the parameters available to the supervisor on a wide range of 4-NOKS devices, with the ability to install and configure third-party devices.

The software can also be used to manage to record temporal parameters and save them in CSV format.

## MINIMUM SYSTEM REQUIREMENTS

### Hardware Requirements:

- Processor: Pentium IV 1.0 GHz or higher.
- RAM: 1 GB.
- Hard disk: at least 100 MB free.
- One free USB port for the USB GATEWAY
- One 485 port available for GATEWAY 485
- Network interface card or access to a network ETHERNET

### Software Requirements:

Operating system: Microsoft ® Windows ® XP Professional SP2, Windows ® Vista, Windows 8

**WARNING:** you must log in as an administrator user on the computer to install the software correctly.

## DEVICES TO BE MANAGED ZMONITOR

ZMONITOR permette la gestione dei parametri dei dispositivi riportati nelle tabelle seguenti.

### GATEWAYS

ZC_GW_USB	2053
ZC_GW_ETH	2051
ZC_GW_485	2051

### DEVICES

	Ver. FW	Ver. Manuale
ZR_TID		
ZR_PLUG	2053	
ZR_SWITCH	2053	
ZR_HMETER	2054	
ZR_BIDCI	2053	
ZR_TIDCI.D	2053	
ZR_TIREL2"	2051	
ZR_ES	2053	
ZR_AIC	2053	
ZR_AIV	2054	
ZED_THL	2053	
ZED_THI	2053	
ZED_TID	2053	
ZED_TIDCI	2053	
ZED_TCM	2054	
ZED_TCMR	2053	
ZED_TCMH	2053	
ZED_TCMHR	2051	
ZED_3IAC	2053	
ZED_3IACR	2053	
ZED_ICC	2053	


### DEVICES THIRD PARTY

CVM-MINI

## 2. INSTALLATION




**WARNING:** you must uninstall previous versions. Select *Uninstall* from the menu START ZMONITOR.

**WARNING:** Sometimes it is necessary to install the program 2 times.




The site [www.4-noks.com](http://www.4-noks.com) find a link where you can download the latest version of the software. After downloading the zipped folder of ZMONITOR and it is opened, you have to click (as administrator) on the file "setup.exe" installation package to start the wizard process.




**CAUTION:** Be sure to run the setup file with Administrator privileges.




...the installer's program will ask for confirmation to proceed ... (accept the license terms)



The next window allows you to choose which folder to install the software ZMONITOR, after choosing the address in which to install the program, press the NEXT button to continue




...the software is automatically installed and is created on the desktop and program menus, shortcut icon for the file ZMONITOR.exe.




### 3. LANGUAGE

To change the language go to *IMPOSTAZIONI* or *Settings* menu



### 4. MAIN SCREEN

This is the screen that presents the user ZMONITOR



Legend


1	Main Menu
2	Function Keys
3	Project Area
4	Status Bar (comunication status)
5	Display area Logs
6	Status Bar




## 5. MAIN MENU

Provides access to the following function:


FILE:











TOOLS:



SETTINGS:






## 6. FUNTION KEYS

Adds a device (gateway that is generic device)			Reset the device (the device selected)	
Delete a device (any selected devices)			Network Open / Close network (applies only to Gateway)	
Update the registers of all device			Network Setup (applies only to Gateway)	
View level radio			Disassociate network	


## 7. DESCRIPTION OF DEVICES

The devices that we insert in the projects are of three types:


GATEWAY		Its task is to interface between the outside world and the network of family devices ZB-Connection (is also known as co-ordinator).Exclusive product 4-noks.
End DEVICE		Generic device, including third parties. ZB-Connection devices permitted or generic devices that communicate over the Bridge 485-485 4-noks (MODBUS protocol).
Bridge		Its task is to allow communication with peripherals modbus standard through the use of the radio network ZB-Connection.

## 8. DISPLAY AREA PROJECT

Each project is characterized by at least one GATEWAY and a sensor associated with him. It can add several GATEWAY also of the same type, each with a different logical ID. The display is a tree, where the nodes are composed of or GATEWAY BRIDGE.



In addition to the description of the device, in parentheses shows the address.

**NOTE:**  BIDCI (20) means that the device is not reachable. In this case the device as described BIDCI at 20.

**NOTE:** GATEWAY may correspond to different addresses are the same.

**ATTENZIONE:** for each gateway devices associated with it cannot have identical addresses.

## 9. DISPLAY AREA REGISTER


Address	Description	Value
0	Device Type	1
1	Firmware Version (Major/Minor)	2051
2	Transmission Counter	285
3	Signal Level of the last message recei...	69
4	Battery Level (V)	3,564
5	Light Rms(expressed in Lux)	94
6	Temperature	21,6
7	Light(expressed in Lux)	93
8	Humidity (expressed in % Relative Hu...	35
9	Seconds passed since receiving last ...	4
10	Counter of messages received from G...	131
11	Gateway message receiving instant ti...	210
12	Signal Level of the last message recei...	62


This area is divided into three columns: Register Address, Description, Value. The types of records is divided by color. It is not allowed to add or delete records, while the column Value / Value we set records. Some settings require multiple actions on multiple records simultaneously. Some registers are read-only: Input and Input Status register (those on white background). Coil Status (on green background) and Holding Register are editable.

## 10. CONNECTION GATEWAY TO A PC


To create a network, the first thing is always to connect and insert a GATEWAY.

For each project can have multiple GATEWAY also of the same type, each with different logical address. For GATEWAY's connections refer to the 0 instructions.



To insert a GATEWAY, in the project, select "New Project" and then click on  (Add new device).

Select the type of GATEWAY (USB, Ethernet or 485), personalize it with a name and assign the logical address.




Select the serial port and speed. This parameter is set by four DIP switches on the board (dip #4 to OFF => 9600bps; dip # 4 to ON => 19200bps). Confirm by pressing "Add".

## Connection PC-USB Gateway

In the case of USB Gateway set the logical address, communication port and speed.

The logical address is set on the dip switches on the board (they are the first 3 dip and addresses range from 1 to 7).




Confirm by clicking on the Add.



## Connection PC-Gateway 485

In the case of 485 GATEWAY set the logical address, communication port and speed.




The logical address is set on the dip switches on the board (they are the first 3 dip and addresses range from 1 to 7).

Confirm by clicking on the Add.




## Connection PC-GATEWAY ETHERNET

In the case of ETHERNET GATEWAY is important to know its address or rather its TCP HOST.




The TCP PORT remains the "502".

Confirm by clicking on the Add.



## 11. JOIN DEVICES

Select the node to insert GATEWAY devices associated with this network.




**CAUTION:** Each device associated with a Gateway must have unique address.

### Getting Started

The gateway must have created a network. Read the instructions for the gateway or giving the

Set Network command . It is recommended that the Automatic selection.




Confirm with OK.

**NOTE 1:** Devices should be entered one at a time unless their address is not selectable via DIP or keyboard (such as TCM). The risk is to have devices with the same address (you will have conflicts about the data).

### JOIN

**NOTE 2:** To join the devices push the button aboard the Gateway, or using the "Open / Close

Network" command . Remember to close the network using the same command.

Make sure that the device is entered into the network: as a test, the gateway has a single flashing LED.

Select the just joined device, from the dropdown menu. Identify a meaningful name to the device. Write the logical address. Confirm by Add button

Add

Refer to the instructions to locate and then to assign an address

**Note:** do not leave any device with address 16 or 127. This is because when you want to add another device you will have a data conflict.

At this point the display area will be populated registers its values.

**Important:** it is useful to stimulate the device to a reception of the data, otherwise you have to wait the reception of the next packet

THI Sala Riunioni (ZED_THI ID=66)		
Address	Description	Value
0	Tipo Dispositivo	3
1	Versione Firmware (Major/Minor)	2051
2	Contatore dei messaggi trasmessi dal dispositivo	125
3	Livello segnale radio dell'ultimo messaggio ricevuto dal dispositivo	47
4	Livello di Batteria (in millesimi di volt)	3,528
6	Temperatura (in decimi di grado centigrado)	22,5
8	Umidità (espressa in % Umidità Relativa)	50
9	Secondi passati dalla ricezione dell'ultimo messaggio	4
10	Contatore dei messaggi ricevuti dal Gateway	112
11	Istante di ricezione messaggio da parte del Gateway (100*ore+minuti)	44
12	Livello del segnale radio dell'ultimo messaggio ricevuto dal gateway (dB+100)	55
13	Indirizzo del Gateway	24626
0	Password di comando (1)	0
1	Tempo di trasmissione (espresso in secondi)	20

Now you can add another device.

## 12. ADDING THIRD PARTY DEVICE through BRIDGE-485 DEVICE

In addition to the ZB-CONNECTION radio devices, you can insert third-party devices if connected through a 4-noks BRIDGE. In particular, devices with MODBUS protocol 485. The gateway node must enter a BRIDGE. The Bridge must be configured through their DIP switches on the board, and the only setting parameters are communication (Baud Rate, Parity, and Stop bits).

There are no addresses to be set.




After deciding to enter a BRIDGE, set him a name and a logical address. The latter is not important for the purposes of network, but only to be able to identify


Click on add 

At this point, we have created another node on the network. For example 

Select to add a device and give the command add new.

Ora lo selezioniamo per aggiungere un dispositivo e diamo il comando aggiungi nuovo

dispositivo . In questa nuova finestra scegliamo un dispositivo che eventualmente era stato creato precedentemente nella stessa sessione di esecuzione dell'applicativo,




Oppure scegliamo la voce CUSTOM\_DEV, e gli diamo un nome e il suo indirizzo logico.

La voce CUSTOM\_DEV ci aiuterà per inserire un dispositivo uguale in un altro indirizzo. In pratica a questo dispositivo saranno associati i registri che saranno aggiunti.

Ora procedere alla definizione dei suoi registri.

L'area dei registri risulta vuota. Utilizzare il comando Aggiungi registro e riempire l'area.




Scegliere il tipo di registro, il suo indirizzo e la sua descrizione.

Dare l'OK. 

**IMPORTANTE:** i registri vanno immessi progressivamente partendo dal primo.

L'inserimento dei registri è utile. Infatti uno stesso dispositivo potrà essere selezionato in un secondo tempo senza dover riconfigurare tutti i registri.



**IMPORTANTE:** salvare il progetto.

Nel momento in cui inseriamo un dispositivo uguale è sufficiente scegliere lo stesso, assegnarli un altro nome con un indirizzo diverso e i registri saranno ripresi


In questo documento il dispositivo scelto è CUSTOM\_DEV1.

**NOTA:** la configurazione dei registri non viene esportata nei nuovi progetti.



Come si vede a lato si è ripreso il CUSTOM\_DEV1, è stato dato un altro nome e il suo indirizzo.



Dopo aver dato il comando aggiungi, sono stati ripresi i registri impostati in precedenza (vedi immagine sotto).






### 13. AUTOMATIC DEVICE SCAN (only GATEWAY MODBUS RTU)

From the Tools menu choose the command "Automatic devices scan"



Select the serial port and begin with



Select the device, and click OK. It will create a node.

The seek finds only GATEWAY Modbus RTU connect by the door that we have selected.


From seek are excluded GATEWAY ETHERNET.

## LOG FUNCTION

It's possible to generate a LOG file for the different registers.


The output file is an .CSV.

Select the output file to be created, the device and its registers. Also choose the period upgrade. Start the LOG. The generated file is a simple text file formatted




## 14. SAVE PROJECT

To save your work, click "Save Project" from the *File menu*. The filename extension will *.zmx*



## 15. OPEN PROJECT

Jobs saved are obtained with "Open Project" from the *File menu*



## 16. TUTORIAL

### Turn on Relay (on ZR-PLUG-M device)

Example: To close the relay contact, go to the register described as "the electrical load is ON" and set to "YES". If the relay was set to OFF then it will be activated.

5	Contatore (parte bassa)	0
6	Contatore (Parte alta)	<input type="radio"/> Si
0	Attivazione della Password di comando	Il carico elettrico è impostato su ON <input checked="" type="radio"/> No
1	Il carico elettrico è impostato su ON	Invia <input type="button" value="X"/>
0	Il carico elettrico è impostato su OFF	

To open the relay contacts move to the register described as "Electrical load is set OFF" and set its value to "YES "

You can know the status of the relay, the register described as "output state (0=off, 1=On)

1	I dati misurati sono resettati a zero	0
5	I dati misurati sono salvati in memoria non-volatile	0
0	Stato uscita (0=off; 1=on)	On
1	Stato Stand-by Killer (1=On/0=Off)	Off


## Impostazione soglie temperatura (esempio su TCM)

To set the activation type of operation HOT, change the value of register described as Set\_Caldo (°C or °F). The entered value admits the decimal point.

3	Valore massimo permesso per i set-point (°C o °F)	32,0
4	Isteresi_Caldo (°C o °F)	Set_Caldo (°C o °F)
5	Isteresi_Freddo (°C o °F)	
6	Set_Caldo (°C o °F)	18,0
7	Set_Freddo (°C o °F)	20,0

## 17. REFRESH Register


With this setting is' can enable the automatic refresh the settings menu. In This data is updated. The validity of the data depends on the time of transmission each device.




NOTE: in the case of networks with many devices can be delays in updating.

## 18. DEBUG

With this command, you can intercept the communication with its description of every single packet.



## 19. COSA FARE IN CASO DI .....

Problema	Causa probabile	Cosa fare
dispositivo non raggiungibile  BIDCI (20)	dispositivo non raggiungibile	assicurarsi che il dispositivo sia acceso, oppure attendere la trasmissione successiva

For any suggestions or problem please send an email to:

[info@4-noks.com](mailto:info@4-noks.com)

4-noks reserves the right modify or change its products without prior warning

## NOTE

4-NOKS s.r.l.  
Via per Sacile, 158  
-31018- Francenigo di Gaiarine (TV)  
Phone: (+39) 0434 768462 - Fax: (+39) 0438 694617  
[www.4-noks.com](http://www.4-noks.com) - e-mail: [info@4-noks.com](mailto:info@4-noks.com)