



**Acoustic
Research
Labs Pty Ltd**

Level 7 Building 2 423 Pennant Hills Rd
Pennant Hills NSW AUSTRALIA 2120
Ph: +61 2 9484 0800 A.B.N. 65 160 399 119
www.acousticresearch.com.au

User Manual

Ngara

Real Time Sound Acquisition System

Issue Number: 2.12

Date: 21/3/2014

Issue Status

<i>Issue</i>	<i>Author</i>	<i>Description</i>	<i>Date</i>
0	J. Aguero	Draft	21/11/2007
1.0	J. Aguero	First Issue – Released with V1.6 Logger	25/08/2008
1.1	K. Williams	First Issue – Review	01/09/2008
2.1	J. Aguero	Second Issue – Released with V2.1 Logger	23/04/2009
2.2	J. Aguero	Updated for V5 Logger	26/05/2009
2.3	J. Aguero	Updated for V7.05 Logger	26/11/2009
2.4	A. Skeates-Udy	Updated for Firmware V.8.04	18/02/2011
2.5	M. Wastell	Updated for switch to USB drive and minor host changes	23/09/2011
2.6	A. Rutherford	Addition of the 3G Digi [®] modem details	05/10/2011
2.7	L. Hudson	Added to Operating Ngara Remotely to include Email settings	23/07/2012
2.8	L. Hudson	Added “Keep Alive” settings for modems	5/9/2012
2.9	L. Hudson	Iphone App	29/10/2012
2.10	L. Hudson	USB 3 not compatible, lubricant on posts	12/11/2012
2.11	L. Hudson	Updated the modem set up	7/3/2014
2.12	L. Hudson	Removed iPhone app, edited power up section	21/3/2014

TABLE OF CONTENTS

TABLE OF CONTENTS	3
1 INTRODUCTION	6
1.1 Scope.....	6
1.2 Overview.....	6
1.3 Applicable Standards.....	6
2 REFERENCE SPECIFICATIONS	7
2.1 Acoustic Reference Conditions	7
2.2 Environmental Reference Conditions	7
2.3 Adjustments to Indicated Levels.....	7
2.4 Extreme Inputs.....	7
2.5 Nominal A-Weighted Sound Levels.....	8
3 GENERAL DESCRIPTION OF LOGGER.....	9
3.1 Weather Proof Case	9
3.2 12V DC Battery.....	9
3.3 USB Disk Drive	10
3.3.1 USB Disk Layout	10
3.3.2 Accessing USB Data	14
3.3.3 Maintaining Disk Access Speeds	14
3.4 Ngara	14
3.4.1 Enclosure Back.....	14
3.4.2 Enclosure Front	15
3.4.3 Enclosure Top	15
3.5 Microphone	16
3.5.1 Mounting Options	16
3.5.2 Frequency Response	16
3.5.3 Directional Response	17
3.5.4 Thermal Characteristics	17
3.5.5 Humidity Characteristics.....	18
3.5.6 Reduction of Wind Noise by Windscreen.....	18
3.5.7 Specifications	19
3.6 Host Software	20
4 OPERATING NGARA LOCALLY	21
4.1 Available User Interface	21
4.2 Powering the Unit	21
4.3 Menu Structure	22
4.4 Configuration Menu Item (Menu 1).....	23
4.4.1 Idle Timeout.....	23
4.4.2 Anc Time out	23
4.4.3 Net Config.....	23
4.4.4 Net Password	25
4.4.5 Time and Date	25
4.4.6 Sys Cal	26
4.4.7 Exit.....	26
4.5 Logging Menu Item (Menu 2)	27
4.5.1 Start Session	27
4.5.2 Stop Session	27
4.5.3 Take Ref	28
4.5.4 Change Disk.....	28
4.5.5 WAV Setup.....	29
4.5.6 Tweight Setup.....	29
4.5.7 Trigger Setup.....	29

4.5.8	Flush Logs	30
4.5.9	Exit.....	30
4.6	Status Menu Item (Menu 3)	31
4.6.1	Show Status	31
4.6.2	Live SPL	31
4.6.3	Max SPL.....	31
4.6.4	Short L_{eq}	31
4.6.5	Long L_{eq}	31
4.6.6	RMS Detection	31
4.6.7	Exit.....	31
4.7	Disk Menu Item (Menu 4)	32
4.7.1	Disk Status	32
4.7.2	List Sessions	32
4.7.3	Disk Size.....	32
4.7.4	Disk Free	32
4.7.5	Format Disk	32
4.7.6	Exit.....	32
4.8	Status and Idle Screen	33
4.8.1	Time and Date	33
4.8.2	Logger State	33
4.8.3	Session State	33
4.8.4	Session Errors	33
4.8.5	Disk State	34
4.8.6	Main Battery State	34
4.8.7	Backup Battery State.....	34
4.8.8	Logger Temperature.....	35
4.8.9	Low Backup Battery Warning	35
4.8.10	Default Configuration Warning	35
4.8.11	Time not Set Warning.....	35
4.8.12	Found Internal Log File Warning	35
4.8.13	HCI Connection Status.....	35
4.8.14	FTP Connection Status	35
4.8.15	Wave Record Mode.....	35
4.8.16	Triggering Mode	35
5	OPERATING NGARA REMOTELY	36
5.1	Installation of Host Software	36
5.2	Main Screen.....	37
5.2.1	Linking to a logger	37
5.2.2	The Results Group	38
5.2.3	The Status Group	38
5.2.4	The General Information Group	39
5.3	Changing Logger Configuration.....	40
5.3.1	General Logger Configuration Tab.....	40
5.3.2	Wave File Configuration Tab.....	41
5.3.3	Trigger Configuration Tab	42
5.3.4	Alarm Clock Tab	46
5.3.5	AUX Output Tab	46
5.3.6	UDP Output Tab.....	47
5.3.7	Advanced Configuration Options.....	48
5.3.8	Email Tab	49
5.4	Logger Time.....	50
5.5	System Calibration.....	50
	Note - A steady signal must first be detected before the "OK" button is enabled	50
5.6	Logger Shutdown.....	51
5.7	Logger Reboot.....	51
5.8	Logger Control.....	52
5.8.1	Starting a Session	52
5.8.2	Stopping a Session	52



5.8.3	Taking a Reference Level	53
5.8.4	Changing Disk	53
5.9	Disk Operations	54
5.9.1	Detail Storage Media View	54
5.9.2	Downloading Session Data	54
5.9.3	Remotely Formatting a USB Drive	55
5.9.4	Performing Statistical Analysis	56
5.9.5	Re-Constitution of wave file data.....	57
5.9.6	Re-Formatting a USB Device	57
6	NETWORK CONFIGURATION OPTIONS	58
6.1	Direct Connection to PC – Configuration 1	58
6.2	Direct Connection to PC – Configuration 2	59
6.3	Connection to a Local Area Network (LAN)	60
6.4	Connection to a Wide Area Network (WAN)	61
6.5	Connection using 3G device.....	62
6.5.1	Setting up with Data Security	63
6.5.2	Setting up without Data Security	69
6.5.3	Setting up with a static IP address	69
6.5.4	“Keep Alive” Setting.....	70

1 INTRODUCTION

1.1 Scope

This document provides a description of the functions provided by the Ngara logger platform. All displays, user tools, facilities and capabilities are herein.

1.2 Overview

The Ngara Sound Acquisition System offers full measurement flexibility, simultaneously producing the following acoustic measurements –

- Fast or Slow SPL-A
- Fast or Slow SPL-C
- L_{eq-A}
- L_{eq-C}

In addition to the above measurements the Ngara platform is able to store raw audio data to a USB disk drive, capable of post processing the majority of your acoustic needs. All of this is achieved in a low power 12-volt environment.

Simple control and configuration of Ngara can be accomplished through the on-board Liquid Crystal display (LCD) and push-button interface.

More advanced control functions are made available through the remote host software. This may include:

- Alarm functions
- Triggering events
- Auxiliary Output Configuration
- Virtual Private Networking

The logged data is saved as a formatted list of Sound Pressure Level measurements in a “Comma Separated Variable” (CSV) file. Samples are taken every 100ms. The data gathered is capable of being post processed to produce any required statistical representation of the data obtained.

Both CSV file data and raw data (wav file) are split into 1-hour long files. A new file is created every hour, on the hour, with each logging session stored into separate directories.

1.3 Applicable Standards

- AS 1259.1:1990 & AS 1259.2:1990
 - Type 1
- IEC 61672.3:2006
 - Class 1
- AS / NZS CISPR 22:2006
 - Class A

2 REFERENCE SPECIFICATIONS

2.1 Acoustic Reference Conditions

The reference sound pressure level and frequency to be used when calibrating the Ngara logger are:

- Level – 94dB
- Frequency – 1kHz
- Reference Direction – Along centre axis of microphone/preamplifier

Note that the 94dB SPL is also to be used as the starting SPL for all level linearity tests.

Linear operating range:

- 25 – 110 dB (A / C) for AS1259
- 25 – 120 dB (A / C) for IEC 61672.3

Self generated noise:

- Microphone Noise Floor ~ 20 dB(A) typically
- Electronic Noise Floor ~ 20 dB(A) typically with microphone short circuit

2.2 Environmental Reference Conditions

Reference environmental conditions used for specifying the performance of the Ngara logger are:

- Air Temperature – 23°C
- Static Pressure – 101.325 kPa
- Relative Humidity – 50%
- Settling Time – 10 seconds
- Time interval to stabilize after changes to environmental conditions – 5 minutes

2.3 Adjustments to Indicated Levels

Calibration is performed using the remote host software (Section 5.5) or via the push button interface (Section 4.4.6).

Recommended calibration components –

- Acoustic Calibrator – NC-74

Using the above calibrator a reference tone at 94dB (A) is equal to 94.00dB (A) as seen by Ngara.

2.4 Extreme Inputs

- Maximum Acoustic Input – ~125dB
- Maximum Electrical Input – ~11V (peak-to-peak)
- Allowable Supply Voltage – 10.8 to maximum 14V DC
(Logger will shutdown at 10.8V)



2.5 Nominal A-Weighted Sound Levels

FREQUENCY (HZ)	IDEAL	NGARA	DIFFERENCE	ALLOWABLE
31.5	-39.4	-39.7	-0.3	+/- 2.0
1 000	0	0	0	+/- 1.1
4 000	+1	+1.1	+0.1	+/- 1.6
8 000	-1.1	-0.9	-0.2	+ 2.1 / -3.1
12 500	-4.3	-6.4	-2.1	+ 3.0 / - 6.0

3 GENERAL DESCRIPTION OF LOGGER

Ngara is a Class 1 instrument (IEC 61672.3:2006), Type 1 (AS1259.1:1990 & AS1259.2:1990) consisting of the following components –

- Weather proof case
- 12V DC Battery
- USB Storage Device
- Ngara Instrument
- Microphone & Pre-Amp
- Host Software – Required for advanced features only

3.1 Weather Proof Case

Ngara is housed in a rugged weatherproof case. To open the case, unclip the two latches at the front of the case.

When closing the weatherproof case, ensure the microphone lead is carefully guided through the cut out provided.

Failure to carefully guide the cable through the cut out provided will cause irreparable internal damage to the microphone cable.

To attach the microphone post, simply screw the base of the post into the mounting found on the lid.

On the outside of each latch, a reinforced hole is provided to allow for security measures such as padlocks, chains etc.

3.2 12V DC Battery


Ngara can be configured to operate using two different sized batteries. The configurable battery sizes include –

- 24Ahr – Allows for up to a maximum of 2 weeks of continual CSV data only logging, and up to 1 week worth of CSV and WAV file data recording.
- 12Ahr – Allows for up to a maximum of 1 week of continual CSV data only logging

The above figures are a guide only and assume use of a fully charged battery.

The above is also dependant on available disk space.

Battery status can be viewed using the LCD or the remote control software. Main battery voltage is indicated as a percentage calculated using the following relationship.



Note – Real life battery discharge rates are not linear, thus you will find battery voltage dropping much faster as the voltage decreases.

3.3 USB Disk Drive


Ngara will store all logging data to an external USB storage device.

As a general guide, the following can be used –

- 8Gb of space required per day for continual raw data and CSV logging
- 40Mb of space required per day for continual CSV data logging

Note: USB 3.0 is not compatible. Only USB 2.0 works with Ngara.

3.3.1 USB Disk Layout



Session Directory

Each newly created session is stored as a separate directory within the USB disk.

Each session directory contains the following:

- Session log file
 - Record errors during the logging session.
- Session information file
 - Used to store logger configuration during the logging session.
- Data directories
 - Directories in which logging data is stored.

Data Directories

A new data directory is created once the number of files within the current data directory reaches a high water mark. This is currently set to 900. This is done to avoid the WinCE 5.0 limitation of 999 files per directory - 999 files may be reached during a triggered session.

CSV Data

Logged data, stored in 100ms blocks.

Files are rotated every hour on top of the hour, with filenames corresponding to time and date.

The following is the CSV header information stored into each CSV file.

Session Name	20090524_194427
Logger Serial Number	878001
Date	24/05/2009
Hour	19
Temperature	28

Time	SPL-A	SPL-C	LEQ-A	LEQ-C	Signal Condition	Battery
------	-------	-------	-------	-------	------------------	---------

Data is stored into each CSV file every 100ms.

<i>Time-stamp</i>	– In the format <mm:ss:msec>
<i>SPL values</i>	– SPL values taken as a “snapshot” every 100ms.
<i>L_{eq} values</i>	– L _{eq} values time averaged over the 100ms period.
<i>Signal Condition</i>	– Indicates signal condition at time of snapshot.
<i>Battery</i>	– Indicates battery voltage at time of snapshot.

Continuous PCM Data

Continuously recorded wave data, if selected by the user.

Files are rotated every hour on top of the hour, with filenames corresponding to time and date.

Data is stored as single channel 16-bit data. If the signal condition field states signal is in the high range the data needs to be multiplied by the logger’s saved multiplication factor.

Triggered PCM Data

Files are rotated in the event that a triggered wave files exceeds two hours duration.

Data is stored as single channel 16-bit data. If the signal condition field states signal is in the high range the data needs to be multiplied by the logger’s saved multiplication factor.

Session Log File

Session information messages, along with any session errors are displayed within the log file.

Ngara maintains a copy of this log file in its internal memory. This allows correct error logging, even in the event the USB connection is lost.

If no disk errors are encountered during a session, the internal log file is always flushed to the USB disk. However, if there were errors found, the log file must be manually flushed at the end of the session.

Session Information File

Session settings are also stored to the session directory.

Tag	Type	Description	Example
SERIAL	char string	Logger serial number (MAC Address – Not including ARL's OUI which is 0050C2)	LOGGER SERIAL : 878000
DATE MANUFACTURED	char string	Logger date of manufacture in the following format "DD/MM/YYYY"	DATE MANUFACTURED : 22/05/08
VERSION	char string	Logger software version	VERSION : V1.2
CALIBRATION	float	Logger calibration (absolute)	CALIBRATION : 11.21
RANGE MULTIPLIER	float	Logger range multiplier calibration (absolute)	RANGE MULTIPLIER : 13.6
SESSION NAME	char string	Session Name	SESSION NAME : <i>a_session</i>
SESSION START	char string	Session start time. In the format "DD/MM/YYYY HH:MM:SS"	SESSION START : 10/02/2008 18:00:00
SESSION END	char string	Session end time. In the format "DD/MM/YYYY HH:MM:SS"	SESSION END : 24/02/2008 18:00:00
TWEIGHT	char string	Time Weighting <ul style="list-style-type: none"> • 125ms • 1s 	TWEIGHT : 125ms
WAVE REC	char string	Wave file recording on or off	WAVE RECORDING : ON
WAVE FREQ	char string	Wave file sampling frequency. <ul style="list-style-type: none"> • 48kHz • 12kHz 	WAVE FILE FREQ : 48kHz
WAVE DEPTH	char string	Wave file number of bits. <ul style="list-style-type: none"> • 16bit • 8bit 	WAVE FILE DEPTH : 16bit
WAVE RANGING	char string	Wave file auto ranging. <ul style="list-style-type: none"> • ON • OFF 	WAVE RANGING : ON
TRIG SETTING	char string	Triggering setting <ul style="list-style-type: none"> • ON • OFF 	TRIG SETTING : ON

Tag	Type	Description	Example
TRIG TYPE	char string	Current trigger type <ul style="list-style-type: none"> • Level SPLA • Level SPLC • Level LEQA • Level LEQC • Stat SPLA • Stat SPLC • Stat LEQA • Stat LEQC • Time • RMS 	TRIG TYPE : Level SPLA
TRIG LEVEL	float	Required trigger level. In the units set in TRIG TYPE entry	TRIG LEVEL : 94.0
TRIG ON	int	Required “ON” time for level trigger. Number of seconds a level trigger needs to be set before an actual trigger is set.	TRIG ON : 5
TRIG OFF	int	Required “OFF” time for level trigger. Number of seconds a level trigger needs to be off before an actual trigger is reset.	TRIG OFF : 5
TRIG PERCENTILE	int	Percentile used for statistical trigger	TRIG PERCENTILE : 95
TRIG STAT PERIOD	int	Statistics duration (in minutes) period for statistical trigger	TRIG STAT PERIOD : 5
TRIG PRE REC LENGTH	int	Number of seconds to record BEFORE trigger event	TRIG PRE REC LENGTH : 15
TRIG POST REC LENGTH	int	Number of seconds to record AFTER trigger event	TRIG POST REC LENGTH : 10
TRIG TMR START	char string	Start time for timer trigger. In the format “DD/MM HH:MM:SS”	TRIG TMR START : 01/02 00:00:00
TRIG TMR END	char string	End time for timer trigger In the format “DD/MM HH:MM:SS”	TRIG TMR END : 10/02 18:00:00
TRIG TMR RPT	char string	Repeat mode for timer trigger <ul style="list-style-type: none"> • Hourly • Daily 	TRIG TMR RPT : DAILY

Disk Record Files

The disk format information file maintains a small record of valid sessions found of disk and drive speed parameters. Ngara maintains a record of sessions stored within the hard drive to determine if sessions have been deleted. To increase disk performance, Ngara will not allow the use of a disk which has had sessions deleted. ***Disks are to be formatted using Ngara only.***

NOTE: NGARA IS NOT COMPATIBLE WITH USB 3.0. NOT ALL USB DRIVES ARE COMPATIBLE WITH NGARA, ONLY USE THE USB DRIVE SUPPLIED WITH THE UNIT.

3.3.2 Accessing USB Data

It is not necessary to download the data using Ngara. The USB disk is formatted using a FAT32 structure and thus is Windows compatible. Note: USB 3.0 is not compatible. Only USB 2.0 works with Ngara.

However, if access to Ngara is not achievable, data can be downloaded using the host program, or via a setup FTP server.

3.3.3 Maintaining Disk Access Speeds

Due to the nature of a FAT32 file system, disk fragmentation increases disk access speed. It is therefore recommended NOT to delete sessions from drives, but rather format the drive using either Ngara or the host software.

3.4 Ngara

The electronics are housed in a silver aluminium enclosure. The unit is classified as per Group X for susceptibility to radio frequency fields and has been tested to AS/NZS CISPR 22, and thus is approved for connection to any network.

Note: *The electronic circuitry contains many calibration settings that are essential for Ngara to operate correctly. Opening the enclosure will void the unit's calibration and warranty.*

There are no user serviceable parts inside the enclosure.

3.4.1 Enclosure Back

The back of the enclosure contains the following connections –

- Power/Aux connector (4-pin)
- Ethernet communications port (RJ-45)
- USB ports (2x USB ports)

The RJ45 can be accessed to provide a communications link to Ngara. The USB ports allow the connecting and disconnecting of a storage device. The power connector should not require any attention during normal operation.

Note: *Data **WILL** be lost if the storage device is removed during a logging session. Please refer to section 4.5.4 for details on ensuring there is no data loss.*




Figure 1 - Logger Enclosure Back

3.4.2 Enclosure Front

The front of the enclosure is provided with the following connector –

- Microphone Connector

Inserting the plug and screwing it in until firm connects the microphone lead to Ngara.





Figure 2 - Logger Enclosure Front

3.4.3 Enclosure Top

The top of the enclosure houses the local user interface. The local user interface consist of the following items –

- A Liquid Crystal Display (LCD)
- A <WAKE-UP> pushbutton –Used to control the power to peripheral devices
- A <SELECT> pushbutton – Used to scroll through menu items
- An <ENTER> pushbutton – Used to select menu items

Please refer to section 4 for details on the local interface provided.



3.5 Microphone

Ngara uses a UC-53A RION microphone attached to a NH-17 with 5 metre cable, preamplifier.

These components comply with the specifications of AS1259 and IEC 61672 and as such are highly sensitive. Whilst they have *some* resistance to environmental effects, care should be taken when the microphone is to be exposed to rain and other extremes in weather.

Wind and rain shields are available as an option for Ngara.


3.5.1 Mounting Options

To achieve compliance with the stated standards the supplied UC-53A microphone and NH-17 preamplifier must be mounted to the end of the supplied microphone post.

To make these posts easy to set up and pull apart, we recommend dipping the post screws in a lubricant, such as vasoline. This makes the posts easier to screw into each other and it also stops them from becoming stuck after being left in the field for a few days.

3.5.2 Frequency Response

The frequency response of a sound field microphone is expressed as the frequency response in the reference direction of incidence (0°). The diagram below shows an example for the frequency response of a UC-53A microphone.




3.5.3 Directional Response

The directional characteristic of a microphone is a measure of its differing sensitivity for sound waves arriving from various angles. Since the pre-polarised condenser microphone used in Ngara is a pressure sensitive type, it should be equal in all directions.

However, refraction and cavity effects cause a certain microphone directional response at high frequencies


The diagram below shows the directional response for the UC-53A microphone.



3.5.4 Thermal Characteristics


The thermal characteristics of a microphone include indicate how sensitivity changes at various temperatures. This is influenced by the choice of materials and the design of microphone. Normally materials with a linear expansion coefficient are used.

The diagram below shows the thermal characteristics of a UC-53A microphone at 250Hz.




3.5.5 Humidity Characteristics

The humidity characteristics of a microphone indicate how sensitivity changes at various humidity levels. The diagram below shows the humidity characteristics for a UC-53A microphone at 250Hz.




3.5.6 Reduction of Wind Noise by Windscreen


During outdoor measurements wind noise can falsify measurement results. To counter such problems, the recommended windscreen WS-10 should be mounted on the microphone. The characteristics of the WS-10 windscreen are shown below. The attenuation of wind noise produced by the windscreen is about 25dB with frequency weighting A and 15dB with frequency weighting C.




Frequency weighting A



Frequency weighting C



Frequency response of wind noise measured with windscreen WS-10 mounted on a microphone.



The diagram above shows the influence of windscreen WS-10 on acoustical properties of microphone (referred to microphone response without windscreen).

The influence of the windscreen WS-10 on the acoustic performance of the microphone is within +/-1.0dB up to 12.5 kHz.

3.5.7 Specifications

Model	– UC-53A
Nominal Diameter	– ½ inch
Sensitivity	– -28dB (0dB = 1V / Pa)
Frequency Response	– 10 to 20 000 Hz
Capacitance	– 12pF
Diaphragm Type	– Titanium alloy foil
Temperature Coefficient	– +0.005 dB/°C (at 250Hz)
Humidity-dependant Sensitivity Change:	
	– 0.1dB or less (at 250Hz, RH below 95%, no condensation)
Dimensions	– 13.2 diameter x 12mm



3.6 Host Software

This application runs on most computers using the Microsoft Windows XP, Vista and 7 operating environment.

The software provides the user with a graphical interface for all Ngara operations, and also enables the control from a remote location via Ethernet/internet.

For details on the host software refer to section 5.

4 OPERATING NGARA LOCALLY

The Ngara noise logger provides local interfacing capabilities allowing the user to –

- Configure logging parameters
- Start/Stop logging sessions
- Display current configuration information
- Display current logger status and results information
- Carry out disk operations

4.1 Available User Interface

The local interface provided by Ngara consists of the following:

- A Liquid Crystal Display (LCD)
- A <WAKE-UP> pushbutton –Used to control the power to peripheral devices
- A <SELECT> pushbutton – Used to scroll through menu items
- An <ENTER> pushbutton – Used to select menu items

The <SELECT> and <ENTER> push buttons have been configured to allow the user to keep buttons depressed to simulate multiple push button presses.

4.2 Powering the Unit

To turn Ngara on, press and hold the wake-up button until “NGARA” is displayed on the LCD.

Note: if the power cable has been unplugged or the Ngara has been turned off, please wait 1-2 minutes before trying to turn the Ngara back on.

4.3 Menu Structure




Figure 4 - Menu Structure

The menu provided follows a “tree” structure.

Cycling through each menu item is achieved through the <SELECT> push button, whilst selecting a menu item is achieved through the <ENTER> pushbutton.

4.4 Configuration Menu Item (Menu 1)

4.4.1 Idle Timeout

The idle timeout menu item allows toggling of the idle time out setting either ON or OFF.

The idle timeout setting is preset to 2minutes. If this timeout is reach Ngara will power down if not recording.

To change the current timeout settings, the following steps must be carried out –

1. Activate menu item by pressing <ENTER>
2. Ngara will display current setting. Toggle setting using the <SELECT> button.
3. Confirm selection by pressing <ENTER>

4.4.2 Anc Time out

The ancillary timeout menu item allows toggling of the ancillary time out setting either ON or OFF.

The ancillary timeout setting is preset to 2minutes. If this timeout is reached, Ngara will power down its Ethernet port whilst recording and not connected to a remote host.

To change the current timeout settings, the following steps must be carried out –

1. Activate menu item by pressing <ENTER>
2. Ngara will display current setting. Toggle setting using the <SELECT> button.
3. Confirm selection by pressing <ENTER>

4.4.3 Net Config

Net Configuration allows the set up of the Ethernet interface.

To enter Net Config menu item press <ENTER>

IP Mode Menu Item

There are three modes in which the Ethernet interface may operate:

1. **DHCP**
Ngara will obtain an IP address, gateway and net mask via a DHCP server.
2. **Automatic**
Ngara will set a Windows Auto-IP configuration compatible IP address.
3. **Manual**
The Ethernet interface can be configured with a static IP address, along with a gateway and a net mask.

Please consult with your network administrator to determine the most appropriate network settings for your Ngara.

To change the IP mode of operation, the following steps must be carried out -

1. Activate the “IP Mode” menu item by pressing <ENTER>
2. Ngara will display current setting
Pressing <SELECT> will scroll through allowable settings (DHCP, Auto, Manual)
Pressing <ENTER> will store changes

Curr Address Menu Item (Automatic and DHCP Modes only)

Refreshes Ethernet interface and re-configures IP address. Similar to windows' "Network Repair" command.

At the completion of this, the current logger IP address is displayed on the LCD.

To view currently assigned IP address, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display its IP address
Pressing <SELECT> will have no effect
Pressing <ENTER> will exit

IP Address Menu Item (Manual Mode only)

Required Manual IP address of logger – Used when IP mode is set to "Manual"

To set current IP address, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display its current IP address
3. Each digit must be entered separately - selected digit is shown by cursor
Pressing <SELECT> will increase selected digit by one.
Pressing <ENTER> will confirm current digit and move to next digit
4. Once the final digit is reached, pressing <ENTER> will confirm entered address

Netmask (Manual Mode only)

Required Manual Netmask of logger – Used when IP mode is set to "Manual"

To set current Netmask, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display current Netmask
3. Each digit must be entered separately - selected digit is shown by cursor
Pressing <SELECT> will increase selected digit by one.
Pressing <ENTER> will confirm current digit and move to next digit
4. Once the final digit is reached, pressing <ENTER> will confirm entered Netmask

Gateway (Manual Mode only)

Required Manual Gateway address of logger – Used when IP mode is set to "Manual"

To set current Gateway IP address, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display current Gateway
3. Each digit must be entered separately - selected digit is shown by cursor
Pressing <SELECT> will increase selected digit by one.
Pressing <ENTER> will confirm current digit and move to next digit
4. Once the final digit is reached, pressing <ENTER> will confirm entered gateway

4.4.4 Net Password

This menu item allows the set-up a six-digit password for remote PC connection.

To set current network password, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display current password
3. Each digit must be entered separately - selected digit is shown by cursor
Pressing <SELECT> will increase selected digit by one.
Pressing <ENTER> will confirm current digit and move to next digit
4. Once the final digit is reached, pressing <ENTER> will confirm entered password

4.4.5 Time and Date

Allows the date and time stored in Ngara to be updated.

Note: This menu item is not accessible once in logging mode.

To set current date and time, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display a snapshot of the date and time when the <ENTER> button was pressed
3. The Date must be entered first, followed by the time. Time is entered as a 24hr value.
4. Each allowable number must be entered separately - selected number is shown by cursor
Pressing <SELECT> will increase selected number by one.
Pressing <ENTER> will confirm current number and move to next number
5. Once the final number (seconds) is reached, pressing <ENTER> will confirm entered date and time

Notes -

- Numbers are clipped to a pre-determined range (1 to 31 for day, 1 to 12 for month etc)
However, it is possible to enter invalid date configurations (i.e. 31 day, 02 month) In this instance an error message will appear stating "Invalid Parameter"
- Year number has been set to clip at 2030, returning to 2000.

4.4.6 Sys Cal

Allows Ngara to calibrate to a known source

To calibrate, the following steps must be carried out -

1. Apply reference tone (1kHz @ 94dB is recommended)
2. Activate calibration mode by pressing <ENTER>
3. Ngara will wait until the expected level is entered using <SELECT> and <ENTER>
Pressing <SELECT> increases the value of each selected digit by 1
Pressing <ENTER> selects the next digit.
4. Once the expected level is entered, the user is given the chance to confirm or cancel calibration. "Y" confirms entered value, "N" cancels calibration.
Pressing <SELECT> toggles between "Y" and "N"
Pressing <ENTER> accepts value.

Note: This menu item is not accessible once in logging mode.

4.4.7 Exit

This menu item returns to the top-level menu structure.

To return to the top level menu structure, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>

4.5 Logging Menu Item (Menu 2)

4.5.1 Start Session

This menu item starts a logging session.

As this session is started through the local interface instead of a remote PC, the session name cannot be entered, thus Ngara creates a name based on current date and time.

A session will not be able to be started if any of the following conditions are met:

- There is no valid disk found, or
- Logger time has not been set by the RTC due to an internal battery fault

Upon selection of this menu item, an instantaneous results message will be displayed on the LCD for two seconds to confirm that the session has started or has failed to start.

Note: This menu item will not appear if a session is running.

Previous session settings (Trigger settings, timers, etc) are stored in internal memory and are remembered each time the unit is turned on.

To start a session using the LCD, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will create a session name based on date and time
3. Once the session has started a "Session Running" message will appear on the LCD. If the session cannot be started, an error message will appear on the LCD.

4.5.2 Stop Session

This menu item stops a logging session.

Upon selection of this menu item, a "Session Flushing" message will appear on the display to indicate final flushing of data to disk is taking place. Upon completion of the data flushing, Ngara will return to the top-level menu structure.

Note: This menu item will not appear if no session is running.

To stop a session using the LCD, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will indicate the internal memory is being flushed to the USB storage device
3. Once the internal memory has been cleared, the LCD will return to the top level menu item.

4.5.3 Take Ref

This menu item allows the recording of a reference level.

Upon selection of this menu item, a message will appear on the display indicating the levels to be recorded to the log file. **Both** A and C weighted levels are recorded to the log file.

Pressing the <SELECT> pushbutton will re-take the reference levels.

Pressing the <ENTER> pushbutton will accept and record the reference levels.

A reference tone may be recorded during **any** stage of the logging session.

Note: This menu item will not appear if no session is running.

**The user is not prompted to record reference tones at any stage during a logging session.
The user is able to take an unlimited number of reference tones throughout the logging session.**

If wave file recording is enabled, a one second recording of the reference tone is stored as a wave file which can be played back to obtain reference levels on measuring equipment (it is suggested wave file is played back in "loop" mode using your favourite player)

To take a reference tone using the LCD, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will indicate the current measured levels (both A and C) which will be stored
Pressing <SELECT> will re-take the reference levels
Pressing <ENTER> will store the reference tone

4.5.4 Change Disk

This menu item allows the flushing of the current logging session, without stopping the session.

This allows the change over of storage devices without any loss of data.

Upon selection of this menu item, a "Session Flushing" message will appear on the display to indicate flushing of data to disk is taking place. Once this is completed, the user will be prompted to "Swap Disk".

Note: This menu item will not appear if no session is running.

To swap a USB storage device using the LCD, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will indicate the internal buffers are being flushed to disk by displaying "Session Flushing"
3. A "Swap Disk" message appears once the internal buffers have all been written to disk. The user then has 10 seconds to swap the USB storage device.
4. Ngara then checks the new USB storage device to determine if it is useable. A session error will be displayed on the LCD if the USB storage device is not useable.

4.5.5 WAV Setup

This menu item toggles the recording and format of raw data. This can be set to any of the following:

- OFF
- 48kHz – 16bit, auto-ranged
- 12kHz – 16bit, auto-ranged
- 12kHz – 8bit, single-range
- Noise Camera Compatible (48kHz – 16bit, single-range)

Note: This menu item will not appear if a session is running.

To change the wav file recording setup, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display current setting
Pressing <SELECT> will scroll through allowable settings
(OFF, 48kHz, 12kHz, 12kHz-16bit, NCam)
Pressing <ENTER> will store changes

4.5.6 Tweight Setup

This menu item toggles the time weighting applied. This may be set to any of the following:

- 125ms
- 5ms

Note: This menu item will not appear if a session is running.

To change the wav file recording setup, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>
2. Ngara will display current setting
Pressing <SELECT> will scroll through allowable settings (12ms, 5ms)
Pressing <ENTER> will store changes

4.5.7 Trigger Setup

This menu item toggles the stored trigger settings ON or OFF only. Trigger settings can only be altered using the remote host software, this menu item allows the user to disable or enable these settings only.

Note: This menu item will not appear if a session is running.

To change the enable or disable triggering, the following steps must be carried out –

1. Activate menu item by pressing <ENTER>
2. Ngara will display current setting. Toggle setting using the <SELECT> button.
3. Confirm selection by pressing <ENTER>

4.5.8 Flush Logs

This menu item appears only once erroneous log files have been found within internal storage memory. This menu item allows the user to flush the internal log files to an attached USB device.

The log files stored internally do not contain any header information found within the USB log files, however they are stored using session names to enable quick identification (in the same manner the USB log files are stored)

The internal log files will be moved to a directory named “Incomplete Log” Files within the USB drive, the directory will be created if it does not exist.

Note: This menu item will not appear if a session is running, or no internal log files are found.

To flush internal log files, the following steps must be carried out –

1. Activate menu item by pressing <ENTER>
2. Ngara will display an error message if an error was encountered.

Note: A valid drive must be inserted into Ngara’s USB port

4.5.9 Exit

Return to top menu structure.

To return to the top level menu structure, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>

4.6 Status Menu Item (Menu 3)

4.6.1 Show Status

This menu item scrolls through current logger operation, configuration and errors (if any). Refer to Section 4.8 for details.

Once within this menu item, pressing <SELECT> will scroll through each item. Pressing <ENTER> will exit from the status screen.

4.6.2 Live SPL

Displays the current SPL. Both A and C weighted. An overload condition is indicated with an '^'.

Once within this menu item, pressing <SELECT> has no effect, pressing <ENTER> will exit.

This display is updated once a second.

4.6.3 Max SPL

Displays maximum SPL for both A and C weighted level. An overload condition is indicated with an '^'.

Once within this menu item, pressing <SELECT> will reset the display, pressing <ENTER> will exit.

This display is updated once a second.

4.6.4 Short L_{eq}

Displays current short (100ms time averaged) L_{eq} . Both A and C weighted. An overload condition is indicated with an '^'.

Once within this menu item, pressing <SELECT> has no effect, pressing <ENTER> will exit.

This display is updated once a second.

4.6.5 Long L_{eq}

Displays current long (Time Averaged) L_{eq} . Both A and C weighted.

Averaging starts once menu item is entered. An overload condition is indicated with an '^'.

Once within this menu item, pressing <SELECT> will re-start the averaging time and reset any overload condition, pressing <ENTER> will exit.

This display is updated once a second.

4.6.6 RMS Detection

Displays current and peak RMS algorithm results. An overload condition is indicated with an '^'.

Once within this menu item, pressing <SELECT> will reset the display, pressing <ENTER> will exit.

This display is updated once a second.

4.6.7 Exit

Return to top menu structure. To return to the top level menu structure, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>

4.7 Disk Menu Item (Menu 4)

4.7.1 Disk Status

Displays current disk status, which can be any of the following:

- Unknown Disk
- Disk Powering up
- Disk Removed
- Disk Present
- Disk Present – Format Required

Once within this menu item, pressing <ENTER> exits the menu item. <SELECT> has no effect.

4.7.2 List Sessions

Displays current saved sessions found on disk.

Once within this menu item, pressing <ENTER> exits the menu item, pressing <SELECT> scrolls through the found session names.

4.7.3 Disk Size

Displays current disk total size in days.

Once within this menu item, pressing <ENTER> exits the menu item. <SELECT> has no effect.

4.7.4 Disk Free

Displays current disk free space in days.

Once within this menu item, pressing <ENTER> exits the menu item. <SELECT> has no effect.

4.7.5 Format Disk

Formats currently inserted disk. A confirmation option is presented before formatting proceeds.

The <SELECT> pushbutton is used to toggle between Y and N during confirmation, the <ENTER> pushbutton is used to confirm the selection.

Note: This menu item will not appear if a session is running.

4.7.6 Exit

Return to top menu structure.

To return to the top level menu structure, the following steps must be carried out -

1. Activate menu item by pressing <ENTER>

4.8 Status and Idle Screen

The idle screen is displayed when the following occurs:

- Through the “Show Status” menu item, or
- Ngara is idle for more than 120 seconds, or
- connecting the remote PC application

The screen circulates through current logger information and any warnings or errors that may be present.

It is possible to speed up circulation by using the <SELECT> pushbutton. It is also possible to exit the idle screen by pressing the <ENTER> pushbutton, unless a remote PC connection is found. In this case the *HCI Connection* status screen is displayed.

Not all screens may appear as some screens are skipped if no valid information is present. For example the HCI Connection Status screen is skipped if no remote PC is connected.

4.8.1 Time and Date

Current time and date is displayed.

Format: [DAY/MONTH HOUR: MIN: SEC]

4.8.2 Logger State

Current logger state is displayed. This may be any of the following:

- Logger Init
- Logger Standby
- Logger Recording

4.8.3 Session State

Current session state is displayed. This may be any of the following:

- Session Running
- Session Flushing
- Disk Error
- Disk Removed

Note: This screen is skipped if there is no session started.

4.8.4 Session Errors

Current session error is displayed. This may be any of the following:

- Disk Full Error
- Disk Write Error
- Disk Format Error

Note: This screen is skipped if there is no session error.

4.8.5 Disk State

Current disk state is displayed. This may be any of the following:

- Disk Unknown
- Disk Powering Up
- Disk Removed
- Disk Format Required
- Disk Present

4.8.6 Main Battery State

Displays main battery voltage as a percentage.




Figure 5 Main Battery Assumptions

4.8.7 Backup Battery State

Displays backup battery voltage as a percentage.




Figure 6 Backup Battery Assumptions

4.8.8 Logger Temperature

Displays internal logger temperature in degrees Celsius.

4.8.9 Low Backup Battery Warning

“WARN: RTC Batt”

Logger backup battery low warning message.

Displayed only when backup battery voltage is lower than 2.7V.

Please contact Acoustic Research Labs if this warning appears.

4.8.10 Default Configuration Warning

“WARN: Config”

Logger configuration not loaded from internal flash warning message.

Displayed only when logger configuration failed to load correctly.

Please contact Acoustic Research Labs if this warning appears.

4.8.11 Time not Set Warning

“WARN: RTC Time”

Logger time not properly set at start-up warning message.

Please contact Acoustic Research Labs if this warning appears.

4.8.12 Found Internal Log File Warning

“WARN: Log File”

Internal session log file found.

4.8.13 HCI Connection Status

Displays a “HCI Connected” message whilst a remote PC connection is detected.

Note: This screen is skipped if there is no remote connection detected.

4.8.14 FTP Connection Status

Displays a “FTP Connected” message whilst a remote FTP connection is detected.

Note: This screen is skipped if there is no FTP connection detected.

4.8.15 Wave Record Mode

Displays current wave file recording mode.

4.8.16 Triggering Mode

Displays current triggering configuration.

Note: This screen is skipped if triggering is not enabled.

5 OPERATING NGARA REMOTELY

The Ngara noise logger provides remote interfacing capabilities through the use of specialised software allowing the user to –

- Configure logging parameters
- Configure triggering and alarm parameters
- Start/Stop logging sessions
- Display current configuration information
- Display current logger status and results information
- Carry out disk operations
- Calibrate Logger

Note – Loggers running software version 5.00 and above must use host software version 2.1 and above.

5.1 Installation of Host Software

The installation of the host software is carried out using the installation USB provided or by downloaded the software from Acoustic Research Labs website. The USB should Auto Run once inserted in the USB drive. If this is not the case, it can be manually started by double clicking on the file “autorun.exe” found on the root directory of the USB.



Figure 7 - Main Installation Screen

The install package will create shortcuts to both the desktop and the start menu.

Installation is now complete.

5.2 Main Screen




Figure 8 - Main Program Window

The main window of the application displays the data Ngara is gathering. It also displays any current logger warnings along the bottom status bar.

These warnings cannot be reset.

Please contact Acoustic Research Labs if any warning messages appear.

5.2.1 Linking to a logger

The software can connect to any Ngara, as long as the software is told where to look. This is dependant on the network configuration settings set on the Ngara unit using the LCD screen (refer to Section 4.4.3)

Knowing a units IP address, is similar to knowing a phone number before placing a phone call. It is with this address that the remote host knows where to “find” Ngara.

If the Ngara can be found within a local network **and** is set to DHCP mode (refer to Section 4.4.3), Ngara may also be accessed using the following address name “ngara-XXXXXX”, where XXXXXX is the unit’s serial number. This name is then converted to an IP address by the DHCP server, thus saving the need to remember IP address numbers.

For details of **very basic** network configurations please refer to Section 6, as there are numerous network configuration options please consult with your local network administrator for other possibilities.

This section will assume that a correct network topology has been implemented, and the units IP address is known.

To link to a Ngara –

1. Enter loggers IP Address
2. Press the Link Button
3. A password prompt will appear – Enter loggers remote password
4. Connection will be established

To disconnect from a remote logger –

1. Press the Disconnect button or close the application

5.2.2 The Results Group

Through the results group it is possible to view all of the current results simultaneously.




Figure 9 – Logger Results Groups

Through the results group it is also possible to –

- Change current time weighting – Only available whilst in standby mode
- Enable maximum hold markers through the tick boxes provided
- Reset the maximum hold markers through the push button provided

Note that the displays are updated every 100ms

5.2.3 The Status Group

General logger status messages can be viewed through the status group box.




Figure 10 – Status Group

The status group shows the following information –

- Current Logger State – Standby / Logging
- Current Session State – Running / Error / etc...
- Current Logger Operations – Determine if logger is busy (i.e.: Formatting a Disk)
- Current Disk State – Removed / Present / Format Required
- Current Session Error – Displays Error Information during a logging session (if any)
- Session Name – Current name of running logging session

5.2.4 The General Information Group

The general information group displays current battery states along with date and time of logger, and current logger's serial number.




General Logger Information	
Back-Up Battery :	100.0 %
Main Battery :	100.0 %
Serial Number :	200000
Date - 07/01/2008 Time - 10:19:30	

Figure 11 - General Information Group

5.3 Changing Logger Configuration

Logger configuration can be updated by navigating to the following menu item

File → Logger Configuration → Change Configuration




All settings are stored in internal memory and are remembered during power cycles.

5.3.1 General Logger Configuration Tab

Ngara configuration tab allows general configuration changes to be made.


1. Idle Timeout –
 Logger automatically turns off whilst in standby and no activity is detected after 2 minutes.
2. Ancillary Timeout –
 Logger powers off its Ethernet interface to reduce power consumption if no network activity is detected for more than 2 minutes. In the event of an Ethernet power down timeout, it can be manually re-enabled by pressing the wake-up button, or automatically re-enabled through the use of the alarm clock function.
3. Network configuration settings can be updated. Please refer to Section 6 for details on network configuration options.



5.3.2 Wave File Configuration Tab

The session configuration tab allows the selection of the wave file recording mode. Allowable modes include –

1. High Resolution Wave File – 48kHz 16-bit
2. Low Resolution Wave File – 12kHz 16-bit
3. Lower Resolution Wave File – 12kHz 8-bit
4. Noise Camera Compatible Wave File
5. Off




5.3.3 Trigger Configuration Tab

Raw wave file triggering modes can be adjusted through the Trigger Parameters tab. Triggering can be set as one of the following –

1. At a predetermined SPL or L_{eq} Level
2. Once a predetermined Percentile reaches a required level
3. At a predetermined RMS Level (RTA Engine brake analysis)
4. Timer based
5. Remote Push Button


5.3.3.1 Setting an SPL or L_{eq} Level Trigger

The following example illustrates the parameters required to enable a level trigger.




In the above example a level of 60dB-A must be reached for 5 seconds before triggering is asserted. When trigger is set, 30 seconds of internal buffered data is recorded.

The trigger is reset when the level falls below 60dB-A for more than 5 seconds. Once reset Ngara records a further 20 seconds of raw data.



5.3.3.2 Setting an SPL or L_{eq} Percentile Trigger

The following example illustrates the parameters required to enable a percentile trigger.




Ngara can be set to continually monitor the current percentile levels over a given time period.

In the above example a level of 60dB-A must be reached within L95. This percentile is calculated over a 5 minute period. This period can only be set to a **maximum** of 5 minutes, in one minute blocks.


When trigger is set, 30 seconds of internal buffered data is recorded. This buffer can be set to a maximum of 480seconds (8 minutes)

Once the L95 falls below 60dB-A, Ngara records a further 20 seconds of raw data.




5.3.3.3 Setting an RMS Trigger (For Engine Brake Analysis)

The following example illustrates how to set an engine brake trigger.




In this example, Ngara will set a trigger event as soon as the RMS is greater than 3.12. It will then record 7 seconds of internal buffered data, followed by 8 seconds of raw data after the trigger event.



5.3.3.4 Setting a Time Based Trigger


The following example illustrates how to set time based wave file recording.



The timer module can be set up to repeat on an hourly or daily basis. Ngara will trigger and record a wave file for the configured time period.

5.3.3.5 Setting a Remote Push Button Trigger

The following example illustrates how to set a remote push button trigger wave file recording.



Ngara will trigger and record a wave file for the pre and post time periods once it detects a push button trigger event.


NOTE: THIS REQUIRES AN INTERNAL MODIFICATION AND CANNOT BE USED AT THE SAME TIME AS THE 3G MODEM POWER SUPPLY.

5.3.4 Alarm Clock Tab

Ngara is capable of setting an alarm clock that may be implemented to conserve battery power.

It can be set up to power itself on, log for a certain time period, and turn itself off. The settings for the logging session may be set up using any of the previous tabs.

It can also be set up to control the power to its Ethernet port to conserve battery whilst logging (*Power Eth.*).



As an example:


The Ethernet interface would normally be off whilst logging to conserve battery, but it would turn on daily at 4:00pm for one hour to allow for remote interrogation.

5.3.5 AUX Output Tab

Ngara is capable of supplying 12V DC @ 1A to power external devices.

The output can be set up in a very similar fashion to the wave file triggers (refer to section 5.3.3)

It can also be set up to follow the alarm clock, when the alarm clock is used to control power to the Ethernet port. This allows the 12V DC output to be used to control power to an external 3G modem.




As an example:

The Ethernet interface would normally be off whilst logging to conserve battery, but it would turn on daily at 4:00pm for one hour via the alarm clock interface. When the Ethernet interface is turned on, 12V DC is also supplied to the 3G modem via the AUX output.

5.3.6 UDP Output Tab

Ngara is capable of sending results information to listeners via User Datagram Protocol (UDP).



The IP address and port number is the “*SEND TO*” address that the Ngara unit will channel the information into.

Note – Using IP address “255.255.255.255” will cause Ngara to send broadcast messages to all network devices.

The output data can only be ONE of the 5 results that Ngara calculates, along with the optional raw data sample values.

The raw data sample values sent will match the configuration set in the wave file configuration tab (refer to section 5.3.2), thus may not always be 48 kHz.

Note – Whilst the output of raw data is enabled, a session cannot be started as Ngara will not have enough processing power to write the raw sample values to both USB and Ethernet.

Please contact Acoustic Research Labs for UDP message structures.


5.3.7 Advanced Configuration Options

Advanced configuration options include -

- **Simple Network Time Protocol (SNTP) –**
When Ngara is connected to the internet, it can synchronise its clock with an external time server. This option must be used with extreme care as very large time changes during a logging session may result in some loss of data. ARL recommend using this setting only when Ngara is configured in a non-logging configuration, for example, when Ngara is used solely to relay results via UDP. Secondary server address may be left blank if not required.
Note – For V7.06 onwards, Ngara supports variable SNTP refresh rates. These are set to pre determined values using a provided sliding bar.
- **Remote Server Logon –**
Address of remote virtual private network server and authentication credentials.
- **File Transfer Protocol Setup (FTP)**
Ngara can share the contents of the USB drive operating as a FTP server. The server is only operational whilst in standby mode as this ensures the drive remains ON and disk access is restricted to only FTP operations.


Restrictions –

- Username and password can only contain numbers and letters
- The FTP server was written to be compatible with the freely available “FileZilla” client



5.3.8 Email Tab

Ngara email tab allows users to set Leq levels which will send an email detailing the time at which the given Leq level was reached and what the Leq was. Up to 5 email addresses can be listed.



The screenshot shows the 'Configuration' dialog box with the 'Email' tab selected. The 'Enable' checkbox is checked. Under 'Alarm Settings', the 'Frequency Weight' is set to 'A' and the 'Interval' is set to '15' minutes. There are four rows for 'Ln' and 'Leq' levels, each with a checkbox, a text input field, a percentage sign, and another text input field. The 'Server Settings' section includes fields for 'SMTP Server', 'From Email', and five 'To Email' addresses (1-5). At the bottom are 'OK', 'Cancel', and 'Apply' buttons.

5.4 Logger Time


Logger time can be updated by navigating to the following menu item

File → Logger Configuration → Set Time



All settings are stored in internal memory and are remembered during power cycles.

Logger date and time, along with current logger GMT time zone information can be updated.




The date/time and time zone information can be entered manually, or the “PC Time” button provided can be used. This sets the current time/date and time zone to match that of the PC being used.

5.5 System Calibration

Internal calibration factors can be updated by navigating to the following menu item

File → Logger Configuration → Calibrate



All settings are stored in internal memory and are remembered during power cycles.




After applying a 1 kHz reference level, enter in the expected reading (in dB) and the logger will perform a system calibration.

Note - A steady signal must first be detected before the “OK” button is enabled

5.6 *Logger Shutdown*

The logger can be forced to power down by navigating to the following menu item

File → Sleep ...




Note – Ngara waits for any running disk and memory operations before shutting down

5.7 *Logger Reboot*

For logger versions V7.06 it is possible to remotely reboot by navigating to the following menu item

File → Reboot ...



5.8 Logger Control

Main logger control is achieved through the Session Control menu item.

Through this menu item it is possible to do any one of the following

- Start a logging session
- Stop a logging session
- Record reference levels
- Flush current internal buffers to disk

Indication of the results of each command can be viewed through Ngara status information group as described in section 5.2.3.


5.8.1 Starting a Session

The logger can be set to start a session by navigating to the following menu item

Session Control → Start



A new window will pop up, allowing the new session to be named. Current logger configuration can be viewed and/or changed by clicking on the “Update Configuration” button.




Indication of the start session command can be viewed through the logger's status information group.

5.8.2 Stopping a Session

The logger can be set to stop a session by navigating to the following menu item

Session Control → Stop



Indication of the stop session command can be viewed through the logger's status information group.

Note – The internal buffers must be flushed before Ngara returns back to the Standby state

5.8.3 Taking a Reference Level

Reference levels can be recorded to the log file by navigating to the following menu item

Session Control → Take Reference



A secondary window will pop up giving the user a change to confirm or re-take the reference level.



Note – Ngara does not prompt the user to take a reference level at any stage of the logging session. Ngara is capable of storing many reference levels throughout the course of a running session.

5.8.4 Changing Disk

Internal buffers can be flushed ready for a disk swap over by navigating to the following menu item

Session Control → Change Disk



A window will pop up giving the user an indication when the disk is ready to be swapped.

5.9 Disk Operations

Main data storage functions can be found under the Disk menu item.


Through this menu item it is possible to do any one of the following

- Get current storage media detailed information – capacities shown in days
- Download session data
- Format current disk
- Perform statistical analysis on 100ms session data
- Re-Constitute Wave Files
- Re-Format Ngara Drive

5.9.1 Detail Storage Media View

A detailed view of current USB storage device can be seen by navigating to the following menu item

Disk → Get Detail Info




A detail window will pop up with details on current inserted USB device.

5.9.2 Downloading Session Data


Session data can be downloaded via the Ethernet interface by navigating to the following menu item

Disk → Download Session Stats



Only the CSV files can be downloaded using the remote user interface, as the downloading of raw audio files would create excessive network traffic.

Note – Accessing session files can also be achieved by plugging in the USB storage device directly to a free USB port on a computer.



The data can be downloaded in two formats


1. A detailed CSV file –
 This includes 100ms SPL and L_{eq} samples for both A and C weighting and is a mirror download of what is found on the USB storage device.
2. Direct Statistics –
 The Ngara logger works out required statistics before sending data through network (greatly reduces network traffic)

Due to the large amount of data stored, it is highly recommended to directly browse the stored sessions on the USB storage device.

5.9.3 Remotely Formatting a USB Drive

A USB device which is attached to Ngara may be formatted by navigating to the following menu item


Disk → Remote Format




5.9.4 Performing Statistical Analysis

A Ngara session directory (100ms CSV files) can be converted to a statistical representation of the data by navigating to the following menu item


Disk → Gather EL-XXX Statistics



Statistical analysis is performed on an entire logging session that can be found locally on the host computer. This can be either after a detailed download, or by browsing the contents of the USB disk used to record the session.



5.9.5 Re-Constitution of wave file data



Wave Files


The recorded 48 kHz wave files are linear from the noise floor of the instrument to approximately 97dB @ 1kHz. From 97dB to 120dB the gain has been reduced to allow 100dB of dynamic range within 16-bits.

In order to see the full dynamic range within the wave file, the user is required to reconstitute each wave file. This involves the conversion of each sample into 32 bit values.

Calibration factors are used from the stored data to reconstitute the 48 kHz file to 32-bits displaying linear 100dB dynamic range.

Winamp is recommended for playback of the 32-bit wave files, as this is the only player that can handle 32-bit floating point samples that are greater than +/- 1.0.

5.9.6 Re-Formatting a USB Device



A drive which has been previously formatted by a Ngara can be re-formatted using a PC.

This clears all data on the drive and updates the drive format information file.

NOTE: A DRIVE MUST ALWAYS BE FIRST FORMATTED USING NGARA. NGARA DETERMINES SPECIFIC DRIVE SPIN UP TIMES WHICH CANNOT BE DETERMINED USING A PC.

NOTE: NGARA IS NOT COMPATIBLE WITH USB 3.0. NOT ALL USB DRIVES ARE COMPATIBLE WITH NGARA, ONLY USE THE USB DRIVES SUPPLIED WITH THE UNIT.

6 NETWORK CONFIGURATION OPTIONS

Remote connection to Ngara is achieved using the Ethernet port provided.

Care must be taken to ensure Ngara has not disabled the network connection. This can be easily checked by visually inspection the lights provided on the Ethernet connector once a physical connection to a network has been established.

In the event the Ethernet interface is disabled, it can be re-enabled by disabling the ancillary timeout delay (Refer to section 4.4.2.) or by pushing the wake-up button.

Default port numbers used are –

- 3000 – Logger Control
- 3001 – Session Downloads

The following sections cover only some of the allowable configurations. Due to the vast number of different network configurations possible, not all possibilities have been covered.

Please consult your network administrator for details on any existing network, and the options available for adding an extra device to the network.

6.1 Direct Connection to PC – Configuration 1




Figure 12 – Direct Connection Example

The above figure illustrates a possible connection method between a logger and a computer fitted with a network card.

It is imperative that a crossover type network cable be used in this instance.

Logger:

- Set Logger Network configuration to use Automatic Mode – See Section Net Config
- IP Address is automatically set.

Computer:

- Should be set to auto configure.

Linking to Ngara is then achieved by entering the IP address allocated to the unit. The address allocated by Ngara can be viewed through the LCD using the menu items provided.

Please contact your network administrator to enable Windows Auto-IP configuration utility.

6.2 Direct Connection to PC – Configuration 2




Figure 13 – Direct Connection Example

The above figure illustrates a possible connection method between a logger and a host computer which is not fitted with a network card, or its current network card is already being utilised.

The above configuration has been tested with the following USB to Ethernet converter

- D-Link
USB 2.0 Ethernet Adapter
DUB-E100
Software Version: V3.30
Hardware Version: B1

Logger:

- Can set Logger to use DHCP IP Mode if host computer is already connected to a network.
See Section - Net Config
- Must set logger to use Automatic or Manual mode if host computer is not connected to a network.

Computer:

- If host computer is already connected to a network, a network bridge may be required between the two network connections.
- Must set IP Address, Netmask and Gateway if host computer is not connected to a network

Linking to Ngara is then achieved by entering the IP address allocated to Ngara, or by using "ngara-XXXXXX", where XXXXXX is the Ngara serial number.

Please contact your network administrator to create a network bridge or to determine if a DHCP server is running on the existing LAN.

6.3 Connection to a Local Area Network (LAN)




Figure 14 – LAN Connection Example

The above figure illustrates a possible connection method between a logger and an existing LAN.

Special care must be taken in setting up the network settings on Ngara to ensure there are no network conflicts with other computers on the network. The easiest way to achieve this (if a DHCP server is running on the modem/router) is to set Ngara to DHCP IP mode.

Most routers/modems support both crossover and straight through type network cables, thus any may be used in this instance. Refer to the documentation provided with the modem/router to ensure the correct network cable is used.

Logger:

- Can use “DHCP” IP Mode, care must be taken whilst using “Manual” mode to ensure there are no conflicts with other computers on the network. See Section - Net Config
- When using “DHCP” mode, IP Address, Netmask and Gateway are set automatically.

Computer:

- No changes required.

Linking to Ngara is then achieved by entering the IP address allocated to Ngara, or by using “ngara-XXXXXX”, where XXXXXX is the Ngara serial number.

To access Ngara through the Wide Area Network (WAN) the IP address for the modem must be known, and ports 3000-3001 must be forwarded by the modem to Ngara. Refer to the documentation provided with the modem/router for details on how this is achieved.

6.4 Connection to a Wide Area Network (WAN)




Figure 15 – WAN Connection Example

The above figure illustrates a possible connection method between a logger and a WAN using a modem.

Special care must be taken in setting up the network settings on Ngara to ensure there are no network conflicts. The easiest way to achieve this (if a DHCP server is running on the modem) is to set Ngara to automatic IP mode.

Most modems support both crossover and straight through type network cables, thus any may be used in this instance. Refer to the documentation provided with the modem/router to ensure the correct network cable is used.

Logger:

- Can use “DHCP” IP Mode, care must be taken whilst using “Manual” mode to ensure there are no conflicts with other computers on the network. See Section - Net Config
- When using “DHCP” mode, IP Address, Netmask and Gateway are set automatically.

Linking to Ngara is then achieved by entering the IP address allocated to the **modem**. It is recommended to obtain a static IP address for the modem as a dynamic address may change every couple of days.

To access Ngara, ports 3000-3001 must be forwarded to Ngara by the modem. Refer to the documentation provided with the modem for details on how this is achieved.

6.5 Connection using 3G device




Figure 16 – 3G Connection Example

The above figure illustrates a possible connection method between a logger and a 3G network using a 3G router.

The 3G router allows a number of different USB modem devices to be connected to Ngara using its Ethernet interface.

Special care must be taken in setting up the network settings on Ngara to ensure there are no network conflicts. The easiest way to achieve this (if a DHCP server is running on the modem) is to set Ngara to automatic IP mode.

Most modems support both crossover and straight through type network cables, thus any may be used in this instance. Refer to the documentation provided with the modem/router to ensure the correct network cable is used.

A 3G modem will be required to use the Ngaras power connector, as to not drain the battery.

NOTE: THIS IS AN INTERNAL MODIFICATION AND CANNOT BE USED AT THE SAME TIME AS THE REMOTE PUSH BUTTON TRIGGER.

Logger:

- Can use “DHCP” IP Mode, care must be taken whilst using “Manual” mode to ensure there are no conflicts with other computers on the network. See Section - Net Config
- When using “DHCP” mode, IP Address, Netmask and Gateway are set automatically.


Due to the nature of 3G devices, their network address (IP address) will always be private. That is, they cannot be contacted, rather they contact you. Because of this, there are extra requirements when setting up a 3G connection.

6.5.1 Setting up with Data Security

Ngara can be setup to act as a Virtual Private Network (VPN) Client. This allows Ngara to log into a remote server, with user name and password. This point to point secure tunnel ensures no third party can view data passing between the server and the client.

Ngara utilises standard port number 1723 for its Point to Point Tunneling (PPTP) protocol.

Ngara Logon Settings –




The dotted area above shows the data entry fields required to be filled in to configure Ngara as a VPN client.

- Server – IP Address of remote server to log into
- Username and Password – Log on credentials


Ngara power Settings –

In order to maximise battery life, Ngara can be setup to control power to the modem/router configuration. Alarm clock settings can be used to control power to both the Ethernet port, and the 12V DC auxiliary output.



The above example shows how to control power to the Ethernet port by using the alarm clock function. In the example, the Ethernet port will be turned on between 3pm and 5pm every Monday.

Ngara will try to initiate a VPN connection if enabled under the advanced settings tab whenever the Ethernet port is turned on. Connection attempts are made in one minute intervals to allow modem and router stabilisation.




The 12V DC AUX output can be setup to follow the Ethernet port as shown in the example above. This will cause the AUX output to turn on between 3pm and 5pm every Monday.

Server Settings –

There are numerous ways to set up a Virtual Private Network (VPN) server, both with hardware specific devices and software based solutions.

This manual will only cover the VPN server which is shipped with Windows XP. For other solutions, please contact your network administrator.


Setting up the VON server is achieved through the “Network Connections” window.



Start the new connection wizard by double clicking on the “New Connection Wizard” icon. Click Next when prompted.




Select "Setup an Advanced Connection" and click Next.




Select "Accept Incoming Connections" and click Next.



Do not select any additional devices, as we will be using the Ethernet port only. Click Next.




Select “Allow Virtual private Connections” and click Next.




Select the username and password which will be used to confirm identity.



Select “Internet Protocol (TCP/IP)” and click the properties button.




Ngara will never specify its own IP address, so ensure this option is left unchecked. It is possible to set up the server so any time Ngara logs into the network, it will appear with the same IP address. This option is network dependant, if unsure; please consult with your network administrator.




Continue clicking Next and Finish to finalise the setup of the VPN server.



Once the server has been successfully setup, an icon showing the server is waiting for incoming connections will appear on the "Network Connections" window.





The modem used to connect the server to the internet must forward all incoming activity on port 1723 to the server's IP address.

Linking to Ngara is then achieved by entering the IP address allocated by the VPN server into the host software. This can be viewed by viewing the properties page of the established connection.

6.5.2 Setting up without Data Security

In some cases, it may not be possible to open the point to point tunnel protocol port 1723. In these instances, data security will not be possible; however a connection may still be established.

One way to achieve this is by using a third party service such as www.dyndns.com which allows Ngara to be accessed using a domain name, rather than its IP address.

Please consult with your network administrator to ensure the router and Ngara are setup correctly, as they may already have a preferred third party dynamic DNS service.

6.5.3 Setting up with a static IP address

Some wireless providers now support public static IP addressing.

This then only requires the user to type in the given IP address (supplied by your ISP) into the Ngara remote host software.

6.5.3.1 Setting up with a 3G modem and Static IP address

Using a 3G SIM card with a static IP address will make connecting to the Ngara much easier.

Go to the Ngara's configuration and set the following:

- Idle Time Out: OFF
- Ancillary Time Out: OFF

Under Net Config, set the following:

- IP mode – "Manual"
- IP address – 192.168.000.010
- Netmask – 255.255.255.0
- Gateway – 192.168.000.001

To setup 3G modem and the Ngara, some settings on the 3G modem need to be changed, these are;


- Allow port forwarding on the modem for ports 3000-3001 in TCP+UDP protocol
- Allow port forwarding on the modem for port 21 in TCP protocol

(These are accessed in the modem's configuration interface, Advanced -> Port Forwarding)

Local IP Address	Protocol	From Port	To Port	Select
192.168.0.10	TCP+UDP	3000-3001	3000-3001	<input type="checkbox"/>
192.168.0.10	TCP	21	21	<input type="checkbox"/>

As well as these setting changes, the provider for the 3G service needs to be entered, along with any other necessary information (such as APN, username and password) need to be entered. This can be entered on Network-> WAN.

(These are accessed in the modem's configuration interface by selecting WAN on the menu)



Choose the 3G service provider, and enter the relevant information for that provider underneath.

Once this has been set up, connect the modem with the Ngara through their Ethernet ports, turn on the power and wait for the modem and the Ngara to initiate. The Ngara can then be accessed through the 3G network by using the host ngara software and typing the static IP address for the SIM card, the host software will then connect to the ngara and be able to start and stop sessions and behave just like it would if connected directly to a computer.

6.5.4 “Keep Alive” Setting

This is to make sure that router is on-line all the time. If enable is chosen, the router will ping the nominated IP address with interval time and IP set by user on 1st or 2nd or both server. The ‘ping fail’ count is incremented only if all configured servers fail to respond. If the count reaches the preset value then the router will be reset and re-connect again.

Log into the IP address at ETM Pacific, open Network and then select WAN. Scroll down to where it says “Keep Alive”. Choose an interval of your choice (no shorter than 5 minutes) and a fail count. Set the 1st server to “www.google.com”. Click “Apply Changes”.

(For example, if you set the interval to 15 minutes and the fail count to 4, every 15 minutes the connection of your modem will be checked and if the configured servers fail to respond after 4 attempts (1 hour), then the modem will reset itself.)

Keep Alive :

Interval : minutes (no shorter than 5 minutes.)

Fail count : times

1st Server :

2nd Server :