

# Operating Instructions

UTM 220



## Foreword

We are pleased to welcome you as a new customer of our Sophos UTM hardware appliances.

To install and configure the hardware appliance you can use the following documents:

- ▶ Hardware Quick Start Guide: Connection to the system peripherals in a few steps
- ▶ Operating Instructions: Notes on the security and commissioning of the hardware appliance
- ▶ Administration Guide: Installing and configuring the software appliance

The Hardware Quick Start Guide and the Security Notes are also delivered in printed form together with the hardware appliance. The instructions must be read carefully prior to using the hardware and should be kept in a safe place.

You may download all user manuals and additional documentation from the support webpage at: [astaro.com/support](http://astaro.com/support)

## Security Symbols



The following symbol and its meaning appears in the Hardware Quick Start Guide, Security Notes and in these Operating Instructions.

Caution and Important Note. If these notes are not correctly observed:

- ▶ This is dangerous to life and the environment
- ▶ The appliance may be damaged
- ▶ The functions of the appliance will be no longer guaranteed
- ▶ Sophos shall not be liable for damages arising from a failure to comply with the security notes

## Designed Use

The hardware appliances are developed for use in networks. The UTM 220 model may be operated as a standalone appliance. The hardware appliance can be used in commercial, industrial and residential environments.

The UTM 220 model belongs to the appliance group A.

The hardware appliance must be installed pursuant to the current installation notes. Otherwise failure-free and safe operation cannot be guaranteed. The EU declaration of conformity is available at the following address:

Astaro GmbH & Co. KG - a Sophos company  
Amalienbadstr. 41/Bau 52  
76227 Karlsruhe  
Germany

## CE Labeling, FCC and Approvals

The UTM 220 appliance complies with FCC Class A, CE, C-Tick, VCCI and UL.



**Important Note:** For computer systems to remain CE and FCC compliant, only CE and FCC compliant parts may be used. Maintaining CE and FCC compliance also requires proper cable and cabling techniques.

## Operating Elements and Connections

### Sophos UTM 220 (rev.5)



## Controls

Power (LED Display)	
Green	Power on
Green	HDD (Hard disk access)

LEDs on each Ethernet connector			
Link LED	Green	Constantly	1. The Ethernet port is receiving power. 2. Good connection between the Ethernet port and hub.
		Off	1. The adapter and switch are not receiving power. 2. No connection between both ends of network. 3. Network drivers have not been loaded or do not function correctly.
Activity LED	Yellow	Flashing	The adapter is sending or receiving network data. The frequency of the flashes varies with the amount of traffic.
		Off	No activity

### LCD and Control Keys

The Sophos UTM 220 has an LCD and an operating unit with four membrane keys. In the LCD, 16 characters per line can be displayed. The display contains in three cycling views information on the hardware and specific system states.

\*\*\* Astaro \*\*\*  
Security Gateway

After the security appliance has booted this message is displayed.

ASG ver. 8.000  
CPU i686 1001 MB

Sophos UTM version  
CPU type and RAM size

Busy 27.0%  
Load 0.0

CPU load (bar)  
OS load (bar)

10 days 01:43:17  
Load 0.0

Uptime  
Network load (bar)

### With the membrane keys three actions can be executed

- **Factory reset:** All settings are reset to the factory settings. The factory reset function sets all of the configuration settings and options to their original state. All data entered after the initial installation will be deleted, including the HTTP proxy cache, the entire email queue, accounting and reporting data, passwords, and uninstalled Up2Date packages. The version of the software will not change. That is, all firmware and pattern updates that have been installed will be retained.
- **Reboot machine:** The security appliance is rebooted. The reboot action will shut down the system completely and reboot.
- **Shut down:** The security appliance is shut down. The shut down action allows you to turn off the system, and allows you to cleanly stop all running services.

### The keys have the following functions



The current menu is left. When the key is pressed a couple of times, the modifications are discarded and the initial state will be displayed.



Those keys are used to switch between the different menus and/or characters.



Pressing executes the configured action.

### Starting factory reset

1. Press the Enter key.
2. Press the ▼ key.  
The following message will be displayed: All data erased
3. Press the Enter key.  
The following message will be displayed: Are you sure?  
With the up/down keys you can select Yes (y) or No (n).
4. Press the Enter key to confirm your settings.  
The factory reset action will now start.

### Starting reboot machine

1. Press the Enter key.
2. Press twice on the ▼ key.  
The following message will be displayed: Rebooting
3. Press the Enter key.  
The following message will be displayed: Are you sure?  
With the up/down keys you can select Yes (y) or No (n).
4. Press the Enter key to confirm your settings.  
The reboot machine action will now start.

### Starting shut down

1. Press the Enter key.
2. Press triply on the ▼ key.  
The following message will be displayed: Shutting down
3. Press the Enter key.  
The following message will be displayed: Are you sure?  
With the up/down keys you can select Yes (y) or No (n).
4. Press the Enter key to confirm your settings.  
The shut down action will now start.

## Putting into Operation



**Caution:** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

### Scope of Supply

The supplied parts are indicated in the Hardware Quick Start Guide.

## Mounting Instructions

The UTM 220 appliance is designed for use in racks. Please consider the following security tips:



**Important Note:** The appliance is designed for use in rack systems. Functional reliability outside of a rack cannot be guaranteed.



## Warnings and Precautions

The appliance can be operated safely if you observe the following notes and the notes on the appliance itself.

## Rack Precautions

- ▶ Ensure that the leveling jacks on the bottom of the rack are fully extended to the floor with the full weight of the rack resting on them.
- ▶ In single rack installation, stabilizers should be attached to the rack.
- ▶ In multiple rack installations, the racks should be coupled together.
- ▶ Always make sure the rack is stable before extending a component from the rack.
- ▶ You should extend only one component at a time—extending two or more simultaneously may cause the rack to become unstable.

## General Server Precautions

- ▶ Review the electrical and general safety precautions that came with the components you are adding to your appliance.
- ▶ Determine the placement of each component in the rack before you install the rails.
- ▶ Install the heaviest server components on the bottom of the rack first, and then work up.
- ▶ Allow the hot plug hard drives and power supply modules to cool before touching them.
- ▶ Always keep the rack's front door, all panels and server components closed when not servicing to maintain proper cooling.

### Rack Mounting Considerations

- › **Ambient operating temperature:** If installed in a closed or multi-unit rack assembly, the ambient operating temperature of the rack environment may be greater than the ambient temperature of the room. Therefore, you should install the equipment in an environment compatible with the manufacturer's maximum rated ambient temperature.
- › **Reduced airflow:** Equipment should be mounted into a rack with sufficient airflow to allow cooling.
- › **Mechanical loading:** Equipment should be mounted into a rack so that a hazardous condition does not arise due to uneven mechanical loading.
- › **Circuit overloading:** Consideration should be given to the connection of the equipment to the power supply circuitry and the effect that any possible overloading of circuits might have on overcurrent protection and power supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- › **Reliable ground:** Reliable grounding must be maintained at all times. To ensure this, the rack itself should be grounded. Particular attention should be given to power supply connections other than the direct connections to the branch circuit (i.e., the use of power strips, etc.).

### Rack Mounting Instructions

To mount the appliance to the rack you need the delivered rack-mount brackets. There are a variety of rack units on the market, which may mean the assembly procedure will differ slightly. You should also refer to the installation instructions that came with the rack unit you are using.

**Important Note:** Make sure you use the screws supplied with the rack-mount brackets. Using the wrong screws could damage the hardware appliance and would invalidate your warranty. The rack model UTM 220 is not delivered with rails. Please observe the mounting instructions for your rack.



#### 1. Attach the rack-mount brackets to the appliance

Place the appliance on a hard, flat surface with the front panel facing you.

Attach the rack-mount brackets to the left and right side of the appliance with the supplied screws.

Make sure the brackets are properly attached to the appliance.

### 2. Choose the rack location

Leave enough clearance in front of the rack so that you can open the front door completely (~60 cm/25 inches).

Leave approximately 80 cm/30 inches of clearance in the back of the rack to allow for sufficient airflow and ease in servicing.

This product is for installation only in a restricted access location (no capitalization) (dedicated equipment rooms, service closets and the like).

### 3. Slide the appliance into the rack.

### 4. Attach the brackets to the rack with the appropriate screws (not included).

### Connection and Configuration

How to connect the appliance is described in the Hardware Quick Start Guide. For configuration you can follow the initial setup wizard described in the WebAdmin Quick Start Guide or cancel it and perform a manual setup (see the Sophos UTM Administration Guide).

## Serial Console

You can connect a serial console to the COM port of the Sophos UTM hardware appliances. You can use, for instance, the Hyperterminal terminal program which is included with most versions of Microsoft Windows to log on to the appliance console. Use the provided RJ45 to DB9 adapter cable to connect the console to your hardware appliance.

The required connection settings are:

Bits per second: 38,400, Data bits: 8, Parity: N (none), Stop bits: 1. Access via the serial console is activated by default on ttyS1. The connections of the appliances and the respective functionality are listed in chapter "Operating Elements and Connections."

United Kingdom Sales:  
Tel: +44 (0)8447 671131  
Email: sales@sophos.com

North American Sales:  
Toll Free: 1-866-866-2802  
Email: nasales@sophos.com

Australia & New Zealand Sales  
Tel: +61 2 9409 9100  
Email: sales@sophos.com.au

Boston, USA | Oxford, UK

© Copyright 2012. Sophos Ltd. All rights reserved.  
All trademarks are the property of their respective owners.

Sophos Operating Instructions 02.12v1.dNA

