

# **HD IP IR High Speed Dome Camera**

## **User Manual**

### **SST-AV-ARYA**



Read the user manual carefully before using this product



## **Important Safeguards**

1. During the course of transportation and storage, the product should be avoided from incorrect operations such as heavy pressing, strong vibration, soaking etc, which may cause damage to the unit.
2. The product is designed for wall-mount and pendant-mount installation, it can not be installed upside-down. And the module should be handled properly so as not to bring about mechanical problems affecting the integrative functions of it.
3. Do not let any foreign objects or liquid infiltrate into the unit, which may damage the machine.
4. Please follow all electrical standards for safety when it is being connected and adopt the particular power supply which is provided with the unit. The product's RS-485 and video signal adopt TVS-class lightning damage preventing technology, which can effectively prevent such pulse signal damage caused by lightning under 500W or electric surge. RS-485 and video signal should be kept enough distance from high voltage equipments and cables when they are in transmission, and necessary steps should be taken to prevent lightning damage or power surge.
5. No matter the unit is running or not, the camera should never be aimed at the sun or object with extremely bright light. Otherwise, the camera's CCD might be permanently damaged.
6. There are no parts inside the unit which can be repaired by the users themselves. When mechanical problems arise, do not be in a haste to do any repairing, please refer to the User's Manual to find the trouble. If causes can not be located, please refer servicing to qualified professionals. All servicing must be done by authorized personnel.

# Table of Content

1. Technical Data .....	- 6 -
1.1 Dome Camera Technical Data .....	- 6 -
1.2 Internal Camera Technical Parameters .....	- 7 -
1.3 Internet Technical Parameters .....	- 10 -
2. Characteristics .....	- 12 -
2.1 Dome Camera Characteristics .....	- 12 -
2.2 Network Characteristics .....	- 12 -
3. Device Installation and Internet Connection .....	- 13 -
3.1 The outer shape and dimension of Dome Camera .....	- 13 -
3.2 Wall-mounted Dome Camera Installation .....	- 15 -
3.3 Installation for Pendant-mount Camera .....	- 17 -
3.4 Sketch Map For Inside Camera .....	- 20 -
3.5 Main External Interface For High Speed Camera .....	- 20 -
3.6 Alarm Input/Output Connection And Installation .....	- 21 -
3.7 Network Connection Method .....	- 23 -
3.7.1 Direct Connect Mode .....	- 23 -
3.7.2 Network Connect Mode .....	- 23 -
3.8 Power On .....	- 24 -
4. Camera Function Setting .....	- 25 -
4.1 Camera Protocol, Bit Rate, Address Setting .....	- 25 -
4.2 Camera Function Setting Form .....	- 25 -
5. IE Log In Interface .....	- 27 -
5.1 Login Home Page .....	- 27 -
5.1.1 Device Log In .....	- 27 -
5.1.2 Home Page Instruction .....	- 30 -
5.1.3 Home Page Instruction .....	- 31 -
5.2 System Setting .....	- 35 -
5.2.1 Basic Information .....	- 35 -
5.2.2 User Manage .....	- 36 -

5.2.3	Serial Port .....	- 37 -
5.2.4	Device Record .....	- 38 -
5.2.5	Net Record .....	- 40 -
5.2.6	Time Setting.....	- 41 -
5.2.7	Multiple Device .....	- 42 -
5.2.8	System Status.....	- 43 -
5.2.9	IR Sensor .....	- 44 -
5.2.10	IR Setting.....	- 44 -
5.2.11	Auto Update.....	- 45 -
5.2.12	System Log .....	- 46 -
5.2.13	Auto Update.....	- 47 -
5.3	Audio Video .....	- 48 -
5.3.1	Video Channel .....	- 48 -
5.3.2	Video Set .....	- 48 -
5.3.3	Video Mask.....	- 49 -
5.3.4	Audio Settings .....	- 51 -
5.3.5	Extend Configuration.....	- 51 -
5.4	Network Settings .....	- 52 -
5.4.1	Ethernet.....	- 52 -
5.4.2	PPPOE .....	- 53 -
5.4.3	DDNS Settings.....	- 53 -
5.4.4	Port.....	- 54 -
5.4.5	Network Check .....	- 55 -
5.4.6	Docking Platform.....	- 55 -
5.5	Alarm Setting.....	- 56 -
5.5.1	Alarm In.....	- 56 -
5.5.2	Motion Detect .....	- 57 -
5.5.3	Linkage Setting.....	- 59 -
5.5.4	Alarm Linkage .....	- 59 -
5.6	Local Setting .....	- 60 -
6.	PTZ Control Basic Function.....	- 62 -

6.1 Preset Setting and Calling.....	- 62 -
6.1.1 Preset Setting .....	- 62 -
6.1.2 Calling for Preset Position .....	- 62 -
6.2 Special Function Setting and Calling.....	- 63 -
6.2.1 Left/Right Scan Setting.....	- 63 -
6.2.2 360° Scan .....	- 63 -
6.2.3 Tour Group Setting .....	- 63 -
6.2.4 Pattern Scan Setting .....	- 64 -
7. FAQ .....	- 66 -

# 1. Technical Data

## 1.1 Dome Camera Technical Data

Power Supply	DC15V±10% (4A)
Power Consumption	25W(Open high light IR)
Communication Baudrate	4800bps (Fix)
Manually Horizontal Rotate Speed	0.5°~120°/S, max 350°/S when rotate to preset position
Manually Vertical Rotate Speed	0.5°~60°/S, max 120°/S when rotate to preset position
Horizontal Rotate Range	360° no limit rotate
Vertical Rotate Range	0°~90°
Auto Flip Function	Auto-flip 180° when vertical 90°
Speed Auto-control as per the changing of zoom ratio	The pan/tilt can automatically adjust the running speed following the change of the zoom ratio
Left & Right Scan	Yes
Left & Right Scan Speed	Low,Medium,High
360° Scan	Low,Medium,High
Pattern Scan Number	4

Preset Position Number	128
Tour Group Number	4
Tour Group Preset Position Number	16 for each tour group
Guard Function	Yes
Wiper	Manually open or close
Alarm Interface	4 ways in, 1 way out(optional)
IR Lamp	High-power IR
IR Lamp Control	Sensor mode and camera mode
Brightness control for IR lamps	Auto/Manual, can open the low, medium, high model manually
Facial Recognition Distance	100m
Max Power Consumption for IR Lamp	13W
Working temperature	-25°C~60°C
Relative Humidity	≤95% no moisture condensation
Weight	6Kg (including the bracket)
Protection Grade	IP66

## 1.2 Internal Camera Technical Parameters

Image Sensor	1/2.8-type 'Exmor' CMOS
--------------	-------------------------

Valid Pixel	3.27 Million
Minimum Illuminance	0.095lux (ICR 开, F1.6, 50IRE)
close-up camera shooting distance	10mm(W)~1000mm(T) (default 300 mm)
Aperture value	F1.6(W)~F3.5(T)
Focus	Auto/Manual/Trigger
zooming rate	20 times Optical variable times, 12 times digital variable times
focal distance	f=4.7mm(Wide-angle end) ~94mm(long distance)
image angle	55.4°(Wide-angle end) ~2.9°(long distance)
electronic shutter	1/1 to 1/10, 000 s, 22 step
White Balance	Auto/Manual/Indoor/Outdoor
Gain Control	Auto/Manual
Weight	About260g
Size(W×H×D)	50x60x87.9mm
Working Temperature	-5°C to 60°C
Storage Temperature	-20°C to 60°C
Max Power Consumption	3.8W

Image Sensor	1/2.8"CMOS
Valid Pixel	327 万



Communication Interface	VISCA protocol (CMOS 5V)
Min Lightness	0.04lx (ICR 开, 1/30sec)
Working Distance	10mm(W) ~ 1000mm(T)
Synchronize Method	Internal synchronize
Scan Method	2: 1 progressive scanning
Aperture	Auto
Aperture Value	F1.6(W)~F3.5(T)
Focus	Auto/Manual
Zooming Rate	20 times Optical variable times, 12 times digital variable times
Focal distance	f=4.7mm(Wide-angle end) ~94mm(long distance)
image angle	55.4°(Wide-angle end) ~2.9°(long distance)
electronic shutter	Auto/Manual
White Balance	Auto/Manual
Gain Control	Auto/Manual
ICR Switch	Auto/Manual
Mirroring	Up Down/Left Right
Image Adjust	Definition/contrast/color enhancement/brightness
Weight	About 200g
size(W×H×D)	50x60x88mm
Working	- 5°C~+60°C

temperature	
Max power consumption	3.4W

### 1.3 Internet Technical Parameters

Processor	DavinciTMS320DM368
Switch in method	Ethernet
Video Compression Standard	H.264
Audio Compression Standard	AMR, G.711
Max Frame Rate	25 Frame/S
Video Resolution	1920*1080(1080P) , 720*576(D1) , 352*288(CIF) , 176*144(QCIF)
Stream	Dual stream. Main stream can choose 1080P/D1, sub stream can choose D1/CIF/QCIF
Video Compression Bit Rate	16Kbps~8Mbps
Audio Compression Bit rate	AMR:4.75Kbps~12.2Kbps; G.711:64Kbps

Image Delay	<200MS
Net Interface	RJ-45 10/100M Network adaptive
Internet Protocol	RTSP/HTTP/HTTPS//FTP/DHCP/MUDP/SMTP/CIFS/UPNP/PPPOE/NTP/DDNS
Front End Storage Device	USB storage device can support maximum 500G, TF card support maximum 16G(optional)
Talkback Function	1 way MIC In input, 1 way Line out output(optional)
Alarm Interface	4 way in, 1 way out(optional)
Motion Detect	Sensitivity 1~100% is adjustable, linkage alarm can be set

## **2. Characteristics**

### **2.1 Dome Camera Characteristics**

- ◆ The cover is constructed with aluminum alloy, which ensures compact structure, high shielding strength and excellent heat-dispersion effect. The lower part of the unit is designed as exposed, which effectively solve the heat-dispersion problem for the camera module and the IR lamps etc parts.
- ◆ Adopt wiper design for easy to clean the water or item from lens and gain clear image
- ◆ Adopt circus lifeline design to ensure the safety during installation
- ◆ Built in anti fog device to avoid fogging inside and ensure the image definition
- ◆ Latest LED Array technology is adopted for the IR lamp, LED Array has higher brightness, longer visible distance, more evenly distributed light field and much longer lifespan.
- ◆ Driven by a stepper electric motar, the unit runs smoothly, reacts quickly and locates positions accurately
- ◆ Adopt EEPROM data storage method, data will not be lost when out of electricity
- ◆ Adopt conductive slide design, which can rotate 360°, no supervision dead zone.
- ◆ Support PTZ auto flip function(vertical 180°auto flip and supervision)
- ◆ Support focus ratio control function(PTZ rotate speed can be adjusted base on lens zooming value)

### **2.2 Network Characteristics**


- 1、 Standard H.264 video compression format
- 2、 Support 1080P,D1,CIF,QCIF video format, can output main and sub stream at the same time

- 3、 Built-in Web Server, fully support browser to surveillance, configure and mange device, simple and convenience to operate.
- 4、 Dynamic bit rate control to ensure real time video transportation in internet
- 5、 Support multiple users to view video and can set log in authorization.
- 6、 Support two way speech talkback
- 7、 Support motion detect
- 8、 Support image snapping
- 9、 Support image parameters adjust
- 10、 Support linkage alarm
- 11、 Support local and front end record and playback


### 3. Device Installation and Internet Connection

#### 3.1 The outer shape and dimension of Dome Camera


Hanging bracket installation hole dimension(unit:mm)




Including hanging bracket unity machine appearance and dimension(unit:mm)



Hoisting bracket installation hole dimension(unit:mm)



Including hoisting bracket unity dimension(unit:mm)



**3.2 Wall-mounted Dome Camera Installation**

Step 1: get M5 die nut from seal pocket, screw off the knurled screw and take off installation head, then take off the integrated line(as Fig 1)




Fig 1

Step 2: through the integrated line across wall-mounted bracket, and fix the wall-mounted bracket to wall(as Fig 2)




Fig 2

Step 3: install the anti-falling steel wire rope to dome camera and connect with wall-mounted bracket, hold the camera in both hand by 45°, fix the rotate pendant on the camera to the rotate hook on bracket(as Fig 3)




Fig 3



Step 4: connect the integrated line on camera to the socket on the top of camera, hold the camera in both hand after confirmation, follow the arrow direction and rotate the camera to vertical angle, screw down the knurled screw by using die nut(as Fig 4)




Fig 4

### 3.3 Installation for Pendant-mount Camera

Step 1: get M5 die nut from seal pocket, screw off the knurled screw and take off installation head, then take off the integrated line(as Fig 1)




Fig 1

Step 2: through the integrated line across anti-falling boom bracket, and fix the anti-falling boom to wall(as Fig 2)




Fig 2

Step 3: install the anti-falling steel wire rope to dome camera and connect anti-falling boom bracket, hold the camera in both hand by 45°, fix the rotate pendant on the camera to the rotate hook on bracket(as Fig 3)




Fig 3

Step 4: connect the integrated line on camera to the socket on the top of camera, hold the camera in both hand after confirmation, follow the arrow direction and rotate the camera to vertical angle, screw down the knurled screw by using die nut(as Fig 4)












Fig 4

3.4 Sketch Map For Inside Camera



3.5 Main External Interface For High Speed Camera

Interface	Color	Function	Interface	Color	Function
	Black	15V power interface		Black	Video output(optional)
	Black	USB interface(optional)		Black	RJ45 Net interface
	Red	Audio input(optional)		White	Audio output(optional)

	Ground	Alarm input/output(optional) GND: Ground IN1: Alarm input 1 IN2: Alarm input 2 IN3: Alarm input 3 IN4: Alarm input 4 OUT11, OUT12: Alarm output interface			
-----------------------------------------------------------------------------------	--------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	--	--

Attention: USB and BNC interface can't exist in HD IR IP camera at the same time, only one can be chose.

### 3.6 Alarm Input/Output Connection And Installation

Alarm input/output connection and installation can refer to below figure. After open the alarm function and camera recognizes alarm signal,then can output alarm signal and linkage relevant motion.


Attention:

1. Alarm input should be switch type input signal, other type signal(as voltage signal) maybe destroy the camera. When alarm input occurs in several channels, then camera will give response to every channel.


2. As long as alarm signal being triggered,camera will execute alarm function first.

3. After start the alarm function, any input end without alarm probe should be insert 2.2k resistance, or camera system will consider alarm signal is triggered and open alarm function.


**sketch for Series Connection Alarm input (with Constant-closed detector):**



**sketch for Parallel Connection Alarm input (with Constant-open detector):**



**sketch for Alarm output connection:**



## **3.7 Network Connection Method**

### **3.7.1 Direct Connect Mode**


Connect the camera to PC by network directly.

### **3.7.2 Network Connect Mode**

Can connect the camera to internet, user can log in the device through client side software of browser.

There are two ways to connect to internet:

- Through PPPOE and DDNS
- Through router, as below figure



Network Connection Diagram

Attention: do not put the wire and network cable to places that will be easily touched by people, to avoid signal unstable caused by bad connection of lines and effect the quality of video.

### 3.8 Power On

1. Check the polarity of plug, socket and other connection, power on after confirmation.
2. Camera will do self-checking, rotate 360° horizontally and 90° vertically for checking the camera lens, the electronic and machine structure for camera in horizontal and vertical status, after that, the camera will execute reset program and rotate to original. When the camera stop completely, the self-checking is finish and ready for controlling.



## 4. Camera Function Setting

### 4.1 Camera Protocol, Bit Rate, Address Setting

The setting for HD IP IR camera protocol, baud rate and address is fix and can't be changed. After sefl-checking, the system information for camera is as below:

Protocol:	PELCO-D
BaudRate:	4800bps
Address:	1
DataBit:	8
StopBit:	1
ParityCheck:	No

### 4.2 Camera Function Setting Form

Tip: some special functions don't have coordinate command in 'PELCO-D' protocol, in order to control these functions, we have switched the function for some common use command. Normally will switch by 'change preset position/set preset position', this function will be introduced in 5.1.3, below list the command switch form:

Invoke Preset Point No.	Function for Preset Point	Invoke Preset Point No.	Function for Preset Point
130	Set left limit	195	Start the third tour group
131	Set right limit	196	The fourth tour group setting begin

132	Start left/right scan(low speed)	197	The fourth tour group setting over
133	Start left/right scan(medium speed)	198	Start the fourth tour group
134	Start left/right scan(high speed)	180	The first group setting for pattern scan begin
135	Start PTZ 360° scan(low speed)	184	The first group setting for pattern scan over
136	Start PTZ 360° scan(medium speed)	185	Start the frist group pattern scan
137	Start PTZ 360° scan(high speed)	181	The second group setting for pattern scan begin
138	Stop PTZ auto scan	184	The second group setting for pattern scan over
140	The frist tour group setting begin	186	Start the second group pattern scan
141	The frist tour group setting over	182	The third group setting for pattern scan begin
142	Start the first tour group	184	The third group setting for pattern scan over
190	The second tour group setting begin	187	Start the third group pattern scan

191	The second tour group setting over	183	The fourth group setting for pattern scan begin
192	Start the second tour group	184	The fourth group setting for pattern scan over
193	The third tour group setting begin	188	Start the fourth group pattern scan
194	The third tour group setting over	150	Restart of camera

## 5. IE Log In Interface

### 5.1 Login Home Page

#### 5.1.1 Device Log In

Firstly, set the IP address segment of PC the same as the Device's. For example, the device IP address is 192.168.1.217, gateway 192.168.1.1. PC IP address should be 192.168.1.XX, gateway 192.168.1.1.

Open the IE browser, input default IP address in address column, or visit through domain name if the domain name analytic function is in use, input domain name will display log in dialog box, as Fig 1-1. If user is not sure of the device address, can search it by using searching tool or client side software.




Fig5- 1-1 Log In Interface

Original Status:

Default Address	192.168.1.217		
User Name	admin	operator	user
Password	admin	operator	user

Attention: use default user name to login successfully, then the user will have authorization for all kinds of operations. It's suggested that user to modify password after first log in for security.

- Click 中文 or English can switch language
- For using this software for the first time will need to do below setting in IE.

For first use user, he needs to install OCX ActiveX, or can't view video. Click Download OCXfile for installation. After successfully downloading, click OCX icon  IPCameraOCXSetup.exe 大小: 1.04 MB - 完成 for installation, below page will be shown up:



Fig5- 1-2

Click 'Install' and below page will be shown up.




Fig5- 1-3

Click 'Finish' to complete the installation of OCX

Input user name and password to enter IE home page.

### 5.1.2 Home Page Instruction

After log in will enter the IE homepage, as Fig 1-2:




Fig5- 1-4 Home Page

## 5.1.3 Home Page Instruction

### 1、Tool Bar Instruction















Fig 5-1-5 Tool Bar

-  : Disconnect/Connect with device
-  : Snap the current image and save to local PC(default path C:\IPCamera, user can modify it by local setting)
-  : Save the current video to local PC
-  : Record playback
-  : User and controller talkback
-  : Volume on/off
-  : Select the area that need to zoom in
-  : Zoom in the selected area
-  : Display full screen of the current image
-  : Log out
-  : Display alarm status

Click 'Playback' button and a new window will be open as below figure.




Fig 5-1-6 Record Playback

Playback function includes search and play record:

- Search record: user can search record by record time and type. Select the begin and end time you want to search and choose record type, including local record and front end record, under each type there are alarm, schedule(PC doesn't have schedule record function), manual record. When the setting is finished, click 'Search', the record that suits the requirement will be listed.
- Play Record: select the record that you want to play, click 'Play' button or double click this record, record can be played on four screens on the left.

Double click one of the four screen can switch between signal screen and split screen.

Use the tool bar on the top, you can pause, stop, slower or



faster the record,you can also do snap, play by sequence, open/close volume.

## 2、Video Format Instruction




Fig 5-1-7 Video Image Format

HD IP Camera support dual stream, main stream supports 1080P and D1, sub stream supports D1, CIF, QCIF. In normal situation, 1080P and D1 suit for LAN, CIF suits for WAN, QCIF suits for mobile phone network. User can select stream according to actual use.

## 3、PTZ Control



Fig 5-1-8 PTZ Control

PTZ control includes focus+(focus-),zoom+(zoom-),wiper open(wiper close),up, down, left, right and auto loop, user can drap the

mouse to adjust PTZ rotate speed.

#### 4、Preset Position

Through setting of preset position, user can make the PTZ to certain position easily.

Click 'Preset' button as Fig 5-1-9.



The image shows a software interface window titled "Preset". Inside the window, there are three input fields: "Preset Title" with a text box, "Preset Num" with a text box, and "Preset Select" with a dropdown arrow. Below these fields are three buttons labeled "Add", "Delete", and "Call".

Fig 5-1-9 Preset Position Setting

Add preset position: input the preset title and num, click 'Add', the system will inform 'Preset add ok!'. (Different camera has different range for preset position, user can set ti according to actual situation)

Delete preset position: click 'Delete' after select the preset position you want to delete, system will inform 'Preset delete ok!'

Call preset position: select one of the preset position, click 'call', PTZ will switch to the position automatically, and the system will inform 'Preset call ok!' For more detail please '6. PTZ Basic Function Setting".

#### 5、Preset Guard

Fig 5-1-10 Preset Guard

Preset guard function: if user set a preset guard(a special preset position) and enable this function, when the device is in no operation status, it will execute guard position function after a period of time, PTZ will move to the guard position.

Set guard position: select 'Enable Guard', select a preset position as guard position, set the idle time, click 'Set' button and save the parameters is ok.

## 5.2 System Setting

### 5.2.1 Basic Information

Basic information will display current system information, user can execute software reboot, set default, auto reboot and so on. As Fig5-2-1.

The screenshot displays the IPCamera web interface. The top header is blue with the 'IPCamera' logo. The main content area is divided into sections for system information and settings. On the right, a sidebar lists navigation options under 'Return To The Video Page'.

**SysInfo**

DeviceName:	NVS-365-V01	Save
DeviceSN:	83921028	
KernelVersion:	Sat Nov 10 23:22:01 CST 2012	
ServerVersion:	T2.2.0918-20121122-V	
WebVersion:	V2.3.4-20120917	
OCXVersion:	4.0.7.12	

**Auto Reboot**

Valid Time: Sun 1:00 ☐ Enable Save

**Sys Update**

File Path:  浏览... Confirm

**SysOperation**

Set Default Reboot

**Return To The Video Page**

- ▼ **SysSetting**
  - BasicInfo
  - UserManage
  - SerialPort
  - DevRecord
  - NetRecord
  - TimeSetting
  - MultiDev
  - SysStatus
  - IRSensor
  - IRInfo
  - SysLog
  - AutoUpdate
- ▶ **AudioVideo**
- ▶ **NetSetting**
- ▶ **AlarmSetting**
- ▶ **LocalSetting**

Fig5- 2-1 Basic Information

**System Information:** display current device name, device SN, kernel version, server version, web version and OCX version.

**Auto Reboot:** user can set the time for auto reboot.

The method is, firstly click the 'Enable' check box and set the reboot time, can set to everyday or one certain day, save it after finish setting.

**System Update:** click the left-hand button, select the path of update document and click 'Confirm'.

User can get the latest version through update the software.

**Attention:** in the process of updating, please don't cut the electricity or do any other operation, or it may cause failure to update or destroy the system.

**System Operation:**

**Set Default:** return to default value

**Reboot:** reboot the device

## 5.2.2 User Manage

In user manage you can add, delete or modify users.

## 1.Device Authentication

When enable the device authentication, user should input the right name and password to log in the software; disable this function then user doesn't need to input password, only need to input the right user name to log in.

## 2.User Password Setting

User can create new user and set the group for new user.

Dev Authentication  
☒ Enable ☐ Disable (Whether authentication is needed at login page)

Username and Password Settings  
(The max user number is 8 in every group, username is unique, username and password up to 32 bytes, password at last 8 bytes, username only contain character or number, password should mix character and number.)

Username: admin Add  
Password: \*\*\*\*\* Delete  
Group: admin Modify

Username	Password	Group
admin	*****	admin
operator	*****	operator
user	*****	user

Return To The Video Page

**SysSetting**

- BasicInfo
- UserManage
- SerialPort
- DevRecord
- NetRecord
- TimeSetting
- MultiDev
- SysStatus
- IRSensor
- IRInfo
- SysLog
- AutoUpdate
- AudioVideo
- NetSetting
- AlarmSetting
- LocalSetting

Fig 5-2-2 User Management

Add: input new user name and password, select the user group, click 'Add' button, system will inform 'Add Success!' and the new user will be shown in the list below.

Delete: select the user need to delete, click 'Delete', system will inform 'Delete Success', at the same time this user will be deleted from the list.

Modify: Select the user need to modify, change the password, click 'Modify', system will inform 'Modify Success!'.

### 5.2.3 Serial Port

The setting for serial port is fixed and can't be changed.




Fig5- 2-3 Serial Port

## 5.2.4 Device Record

**Attention:** this function will be validated when the camera has internal TF card or connect with U disk.

### 1.Schedule Record Time Setting

User can set the front end record time through time setting.

Click the white box to select coordinate time, the color of the selected box will changed to orange.

Attention: click the day on the left will select 24 hours of that day. Click 'All' will select all, and all of the box will change to orange color.

Save the setting when it's finished.




Fig 5-2-4 Device Record

## 2. Record manage

User can set the disk strategy in case of the space of disk is not enough, it can be set to stop record or delete old file.

Set the size of record, the range is 1 to 15 minutes.

Set the length of alarm record when alarm occurs.

Set the record size, totally there are four kinds of size: 1080P, 720P, D1, CIF, QCIF.

## 3. Disk Status

Connect storage devices to device and the information of them will be shown, including partition, total capacity, used capacity, free capacity and used percentage.

When the setting for above parameters is finished, device will start recording if the free capacity is enough.

- Click 'StartRec', record status will display 'Manual Record', system begin to record, click 'StopRec' to stop recording.
- During the time of device record, system will do record automatically, record status will display 'Record Schedule'.

- During the time of recording, user can select 'Auto Flush', system will do auto flush for the status of storage device automatically based on the time you set.
- When the storage device is connected with device, there are two ways to download documents from storage device:  
HTTP Download: can use HTTP method to download document to local disk  
FTP Download: can use FTP method to download document to local disk
- Click 'Capture' can save the current image to storage device in the form of JPG.
- 'Initialize' button use for the SD card

### 5.2.5 Net Record

Net record function enable the storage device in network to be used in front end.

The screenshot shows the 'Network record Setting' page in the IPCamera web interface. The page has a blue header with the 'IPCamera' logo. The main content area is titled 'Network record Setting' and contains two sections: 'NFS Settings' and 'SAMBAs Settings'. Each section has a 'Record Switch' with radio buttons for 'ON' and 'OFF', a 'Network path' text box (with a red note '(at most 256 bytes)'), a 'Username' text box, and a 'Password' text box. A 'Save' button is at the bottom. On the right, there is a sidebar with a 'Return To The Video Page' link and a list of settings: SysSetting (expanded), BasicInfo, UserManage, SerialPort, DevRecord, NetRecord (highlighted in green), TimeSetting, MultiDev, SysStatus, IRSensor, IRInfo, SysLog, AutoUpdate, AudioVideo, NetSetting, AlarmSetting, and LocalSetting.

Fig5- 2-5 Net Record

### 1.NFS Setting

Record Switch: to open or close the NFS remote record function.



Network path: input address for remote NFS

Username: the user name to log in NFS

Password: password for the username

## 2.SAMBA Setting

Record Switch: to open or close SAMBA record function.

Network path: input address for SAMBA

Username: the user name to log in SAMBA

Password: password for the username

## 5.2.6 Time Setting

User can select time zone and adjust date and time.

The screenshot displays the IPCamera web interface. At the top, there is a blue header with the IPCamera logo. The main content area is divided into two sections: 'Time Settings' and 'NTP Settings'. The 'Time Settings' section includes a dropdown menu for 'Zone' (currently set to '(GMT+08:00)Beijing, Hongkong, Singapore, Taipei'), a 'Date' field (2012-11-23), a 'Time' field (10:00:18), and a 'Sync with PC' checkbox. The 'NTP Settings' section includes a 'Sync with NTP' checkbox and a 'Server' dropdown menu (currently set to 'clock.isc.org'). Both sections have 'Save' buttons. On the right side, there is a sidebar with a 'Return To The Video Page' link and a list of settings categories: SysSetting (expanded), AudioVideo, NetSetting, AlarmSetting, and LocalSetting. The 'SysSetting' category is expanded, showing sub-items: BasicInfo, UserManage, SerialPort, DevRecord, NetRecord, TimeSetting (highlighted in green), MultiDev, SysStatus, IRSensor, IRInfo, SysLog, and AutoUpdate.

Fig5- 2-6 Time Setting

Zone Setting: select local time zone and click ‘Save’.

Date Setting: can synchronize the date with local PC, click ‘Save’ to save the setting.

NTP Settings: click the check box ‘Sync with NTP’, select one of

the server and save, then system time will synchronize with the selected internet clock.

### 5.2.7 Multiple Device

IPCamera

Multidev Config

Device	Address	Port	User	Password	Description	Channel	Operation
1st device	192.168.36.25	554	admin	*****	The current device	1/1080P	
2nd device	192.168.36.26	554	admin	*****	720P	720P ▾	Add Delete
3rd device	192.168.36.27	554	admin	*****	720P	720P ▾	Add Delete
4th device	192.168.36.28	554	admin	*****	1080P	1080P ▾	Add Delete
5th device	192.168.36.29	554	admin	*****	1080P	1080P ▾	Add Delete
6th device						1080P ▾	Add Delete
7th device						1080P ▾	Add Delete
8th device						1080P ▾	Add Delete
9th device						1080P ▾	Add Delete

Return To The Video Page

▼ SysSetting

- BasicInfo
- UserManage
- SerialPort
- DevRecord
- NetRecord
- TimeSetting
- **Multidev**
- SysStatus
- IRSensor
- IRInfo
- SysLog
- AutoUpdate

▶ AudioVideo

▶ NetSetting

▶ AlarmSetting

▶ LocalSetting

Fig5- 2-7 Multiple Device

Here user can add multiple devices, after that, user can operate multiple devices in home page.

Setting method: input the IP address, port, username, password and related information in the column, select the right channel, click ‘Add’and return back to home page, then you can view and operate several devices by only log in one of them.

Attention: to view several devices will require higher configuration PC, to enable this function in low configuration PC may affect the quality, user can select the No. of devices based on the situation of your PC, system support maximum 9 devices to display at the same time.

### 5.2.8 System Status

System status display the system status currently.




Fig 5-2-8 System Status

Select the time interval for flush, or click ‘Auto flush’, it can flush the system status automatically.

Below is the information that system status will display:

- Sequence 1: display temperature information
- Sequence 2: display CPU use status
- Sequence 3: display clock CPU frequency
- Sequence 4: display RAM use status
- Sequence 5: display power on continuous time
- Sequence 6: display program operate continuous time
- Sequence 7: display system UPNP status
- Sequence 8: display ROUTE information
- Sequence 9: display DNS server information
- Sequence 10: display the IP address and resolution information of the video stream that connected with camera

### 5.2.9 IR Sensor

Click 'IR Sensor' will switch to below page.




Fig5- 2-9 IR Sensor

Here user can drag the mouse to set IR lux, the range is 1-100, when the environment brightness is lower than lux, IR lamp will be open.

### 5.2.10 IR Setting

Click 'IR Setting' to enter below page




Fig 5-2-10 IR Info

IR setting menu has IR lamp switch and IR lamp light model.

IR lamp switch mode: user can select 'Sensor Model' or 'Camera Model' to open IR lamp. When user select 'Sensor Model', the camera sensor will determine whether to open IR lamp. When user select 'Camera Model', the inside camera will determine whether to open IR lamp.

IR lamp brightness model: here user can select IR lamp brightness manual or auto model. When user select auto model, camera will choose different brightness based on inside camera times. User can also manually choose low, medium and high IR lamp.

### 5.2.11 Auto Update

Click 'Auto Update' button to enter below page.

Fig5- 2-11 Auto Update

In this page, click ‘open’ can begin to set the related parameters. Setting the right server URL, port, username, password and inquire time interval, system will do auto updated accordingly.

### 5.2.12 System Log

Click ‘SysLog’ to enter below page.

Time	Level	Event
Jan 1 00:00:12	debug	NVS 2.0 begin!
Jan 1 00:00:15	crit	A KillAllAppExceptServer kill from sysctrl/system_main.c[240]
Jan 1 00:00:16	notice	Thread begin=SysMsgSvr, pid=841!
Jan 1 00:00:16	notice	[getpid():830 pid:841]
Jan 1 00:00:16	notice	[getpid():830 pid:842] time call main loop...
Jan 1 00:00:16	notice	[getpid():830 pid:843] longtime call main loop...
Nov 23 09:53:10	notice	Thread begin=upnp client, pid=921!
Nov 23 09:53:10	notice	[getpid():830 pid:921 UpnpClientProcess loop...
Nov 23 09:53:10	notice	Thread begin=upnp server, pid=922!
Nov 23 09:53:10	notice	Thread begin=Ptz service, pid=920!
Nov 23 09:53:10	notice	Thread begin=AutoUpdate init, pid=923!
Nov 23 09:53:10	notice	[getpid():830 pid:922] UpnpServerProcess loop...
Nov 23 09:53:13	notice	[getpid():830 pid:939] hm service main loop...
Nov 23 09:53:13	notice	Thread begin=Thrtptd, pid=940!
Nov 23 09:53:13	notice	Thread begin=FtpdMagSvr, pid=941!
Nov 23 09:53:13	notice	Thread begin=Vsfptd, pid=942!
Nov 23 09:53:13	notice	Thread begin=fpd hearbeat, pid=943!
Nov 23 09:53:13	notice	Thread begin=alarm schedule, pid=944!
Nov 23 09:53:13	notice	Thread begin=combined action of alarm center, pid=946!
Nov 23 09:53:16	notice	Thread begin=Audio, pid=955!

Fig5- 2-12 System Log

User can view system log here.

### 5.2.13 Auto Update

When device needs real time update, it can use auto update function, as below figure:

Firstly select to 'open' the auto update function, parameters introduce as below:

ServerUrl: input auto update server address

ServerPort: input auto update server port

Username: input auto update username

Password: input password for the username

Repeat Time: input the quire time interval, device will update automatically when there is new update package

IPCamera

AutoUpdate

☒ OPEN ☐ CLOSE

ServerUrl: 192.168.2.119

ServerPort: 8080

UserName: devuser

Password: .....

RepeatTime: 5 (5~60)Min

Save

Return To The Video Page

- ▼ SysSetting
  - BasicInfo
  - UserManage
  - SerialPort
  - DevRecord
  - NetRecord
  - TimeSetting
  - MultiDev
  - SysStatus
  - IRSensor
  - IRInfo
  - SysLog
  - AutoUpdate
- ▶ AudioVideo
- ▶ NetSetting
- ▶ AlarmSetting
- ▶ LocalSetting

Fig5- 2-13 Auto Update

## 5.3 Audio Video

### 5.3.1 Video Channel

Select Audio Video and enter video channel page as Fig 5-3-1.

Video Channel Settings

Master Stream  
Master Stream Enable: ☒ Enable ☐ Disable  
Resolution: 1080P  
FastSet: Select...  
FrameRate: 25 (1~30)  
BPS: 8192 (128~8192)  
Interval: 40 (1~50)  
BPSPControl: CBR  
CodeModel: Rate first

Slave Stream  
Slave Stream Enable: ☒ Enable ☐ Disable  
Resolution: D1  
FastSet: Select...  
FrameRate: 25 (1~30)  
BPS: 2048 (64~4096)  
Interval: 40 (1~50)  
BPSPControl: CBR  
CodeModel: Rate first

Compress: H264  
Video input: 0

Playback Options  
Fluency: ☐ High ☒ Middle ☐ Low

Save

Return To The Video Page

- SysSetting
- ▼ AudioVideo
  - VideoChannel
  - VideoSet
  - VideoColor
  - VideoMask
  - AudioSet
  - ExtConfiguration
- NetSetting
- AlarmSetting
- LocalSetting

Fig5- 3-1 Video Channel

For different network status, user can select different video channel.

HD IT IP High Speed Dome Camera support dual stream, main stream support 1080P and D1 video format, sub stream support D1, CIF, QCIF video format, user can open or close stream according to actual use and set related parameters. Playback fluency can choose high, middle and low. Save the parameters after setting, then system will require you to log in again.

### 5.3.2 Video Set

Here is to set the contents show on the image, mainly include: device name, time and BPS.






Fig 5-3-2 Video Parameters

User can select show or hide the device name, time and BPS.

If user wants to show device name, he needs to input the name.

Click 'Save' after setting finish.

Attention: device name can't exceed 12 characters.

### 5.3.3 Video Mask

Through area mask, you can protect personal privacy from not display certain area in supervision video.

When setting video mask, firstly need to select the mask color, which is in the form of number, and then select the sequence in index, click 'Set' button, click 'Area' and drag the mouse to select mask area(mask area can't exceed 1/4 of the image). When the setting is finished, user can show, hide or delete this mask.




Fig5- 3-4



Fig 5-3-5 Video Mask Setting

### 5.3.4 Audio Settings

User can adjust the volume input and output based on actual situation, as Fig 3-4.




Fig 5-3-6 Audio Settings

Click ‘Save’ after the setting finish.

If user wants to return to default value, select ‘Default’ and save.

### 5.3.5 Extend Configuration

Encoding setting includes: code size(1080P, 720P,D1,UVGA,CIF,QCIF), Code profile (HIGH,MAIN,BASE) , code level (10,20,30,40,50) , user can set them according to actual use.

BNC function: devices have BNC function only need to open the function and save, then connect the BNC interface to output port, then the function is validated.




Fig 5-3-7 Extend Configuration

In ‘Extend Configuration’, user can select code size, code profile and code level. User can also enable or disable the BNC function. Click ‘Save’ after setting is finished.

## 5.4 Network Settings

### 5.4.1 Ethernet

Through Ethernet setting, user can set related parameters for Ethernet. As Fig 5-4-1.




Fig 5-4-1 Ethernet

User can set network parameter based on actual situation, including DNS address, IP address, Subnet mask, gateway and so on. ‘Save’ after the setting is finished.

Mac address is the physical address for device, it can’t be changed.

DHCP setting: can open this function and get network parameters automatically from local network, to enable this function needs the support of DHCP server, please confirm with network administrator.

o

## 5.4.2 PPPOE

When setting PPPOE auto dial, firstly need to enable the PPPOE switch, then select the network card, input username and password provided by internet supplier, save after the setting is finished.

PPPOE Settings

PPPOE Switch: ☒ Enable ☐ Disable

Card Select: ETH

Username: anonymous

Password: ••••••••

Save

Return To The Video Page

- ▶ SysSetting
- ▶ AudioVideo
- ▼ NetSetting
  - Ethernet
  - WiFi
  - PPPOE
  - DDNS
  - Port
  - 3G Status
  - NetCheck
  - Docking Platform
- ▶ AlarmSetting
- ▶ LocalSetting

Fig 5-4-2 PPPOE

## 5.4.3 DDNS Settings

DDNS can map the dynamic IP address to a fix domain name.

Before setting dynamic domain name analyze , you need open the switch.

Select DDNS service supplier, 3322.org or 9299.org, input DDNS

username and password and other parameters, save after finish setting.  
As Fig 5-4-3.




Fig 5-4-3 DDNS Setting

#### 5.4.4 Port

Select NetSetting and select Port to enter below page.




Fig5- 4-4 Port

WEB Port: the port use for log in device in IE

FTP Port: the port use for FTP upload and download

RTSP Port: real stream port, use for video stream transportation

Speak Port: the port use for speak talkback

Update Port: the port use for software update

UPNP Switch: Auto port mapping switch(need the support of router)

### 5.4.5 Network Check




Fig5- 4-5 Network check

### 5.4.6 Docking Platform

Different upgrade programs have different docking platform, here take industry docking platform for instance.

The screenshot displays the IPCamera web interface. At the top is a blue header with the 'IPCamera' logo. The main content area is divided into three sections:

- Server Setting:** Contains a section for 'Access Server' with an 'Enable' radio button selected and a 'Disable' option. Below this are input fields for 'Access Server Address' (containing '192.168.1.211'), 'Access Server Port' (containing '554'), and 'Heartbeat Period(S)' (containing '30' with a range '(1~3600)' in parentheses). A 'Save' button is at the bottom of this section.
- Link Status:** Displays real-time connection status for 'Access Link', 'Dispatch Link', 'Speak Link', and 'Speak Link Addr'. All status fields show 'connecting.....'. A 'Flush' button is at the bottom of this section.
- Right Sidebar:** Titled 'Return To The Video Page', it contains a list of settings: 'SysSetting', 'AudioVideo', 'NetSetting' (expanded), 'AlarmSetting', and 'LocalSetting'. Under 'NetSetting', options include 'Ethernet', 'WiFi', 'PPPOE', 'DDNS', 'Port', '3G Status', 'NetCheck', and 'Docking Platform' (highlighted in green).

Fig5- 4-6 Docking Platform

Enter the server page, as above Fig 4-6, select to enable or disable the accessing of server. Add the server address that coordinate with platform, port and heartbeat period and save. After saving the right parameter, server status will be displayed on the right, which can view real time connection status for each server.

## 5.5 Alarm Setting

### 5.5.1 Alarm In

Select 'Alarm In', enter 'Alarm Setting' page and enter page as Fig 5-5-1.






Fig 5-5-1 Alarm In

### Attention:

- Click white column in time table, it will change to orange color
- Click the day on the left, the whole day will change to orange color
- Click 'All' will select all, the whole time table will change to orange color.

## 5.5.2 Motion Detect

Select 'Alarm Setting' and enter 'Motion Detect', you will enter below page for motion detect setting.

Motion detect parameters: firstly click the check box to enable motion detect function, then set the sensitivity(1~100, the higher the sensitivity, the less motion is required to trigger recording). Click the radio button in front of 'Select', press Ctrl button and drag the mouse in the image to set motion detect area. Press the radio button in front of 'Display' and below page will be shown, as Fig 5-5-2.




Fig 5-2-2 Motion Detect

1. Motion detect time schedule: set the motion detect front end time schedule can linkage motion detect alarm during selecting time (including front end record, email sending, FTP uploading and so on)

**Attention:**

- Click white column in time table, it will change to orange color
- Click the day on the left, the whole day will change to orange color
- Click 'All' will select all, the whole time table will change to orange color.

2. Save the parameters after setting finish.

### 5.5.3 Linkage Setting

Select ‘Alarm Setting’ and select ‘LinkAttr’, as Fig 5-5-3.

LinkAttr

Alarm Center Parameter

Center Address: 192.168.1.66

Center Port: 8003 (1~65535)

Email Parameter

Server: smtp.163.com

Username: anonymous

Password: ••••••••

ToAddr: anonymous@163.com

AlarmOut Parameter

AO1 Cur Status: ☒ ON ☐ OFF

AO2 Cur Status: ☒ ON ☐ OFF

AO1 Alarm Status: ☐ ON ☒ OFF

AO2 Alarm Status: ☐ ON ☒ OFF

Holdtime(S): 10 (1~36000)

FTPClient Parameter

Server: ftp.163.com

Username: anonymous

Password: ••••••••

Path: /

Type: ☒ Picture ☐ Video

Return To The Video Page

- ▶ SysSetting
- ▶ AudioVideo
- ▶ NetSetting
- ▼ AlarmSetting
  - AlarmIn
  - MoveDetect
  - VideoLoss
  - Extend Alarm
  - LinkAttr
  - AlarmLinkage
- ▶ LocalSetting

Save

Fig 5-5-3 Linkage Setting

Alarm center parameters: set alarm center address and port, save after setting finish.

Email Parameters: set the email server, username and password and save, then system will send the alarm information to coordinate email.

FTP Client Parameter: firstly input the FTP server name, username and password, FTP path and upload type, save after setting finish.

### 5.5.4 Alarm Linkage

Select ‘Alarm Setting’ and enter ‘Alarm Linkage’ page, as Fig 5-5-4.

Fig 5-5-4 Alarm Linkage

Alarm input linkage: select input channel, alarm interval and linkage option such as alarm center, Email, playsound and so on.

Motion Detect: set motion detect alarm time interval, select linkage options, including alarm center, Email, record, FTPsend, play sound, capture and so on.

Simulate Alarm: this is for replacing probe and other devices to trigger alarm by pressing button.

## 5.6 Local Setting

Select 'Local Setting' to enter below page.

IPCamera

**Local Settings**

**Local Storage Setting**  
Manual Record Time: 1 Minute  
Manual/Snap Path: C:\IPCamera  
Don't change the default path [C:\IPCamera] for normal use

**Pre Record Setting**  
Pre Record Time: 5 (5~30)Second  
Pre Record Enable: ☐

**Local Record Setting**  
Alarm Record Time: 5 (1~2592000)s  
Alarm Linkage Record: ☐

Save

**Return To The Video Page**

- ▶ SysSetting
- ▶ AudioVideo
- ▶ NetSetting
- ▼ AlarmSetting
  - AlarmIn
  - MoveDetect
  - VideoLoss
  - Extend Alarm
  - LinkAttr
  - AlarmLinkage
- ▼ LocalSetting


Fig 5-6-1 Local Setting

Local Storage Setting: firstly set the manual record time and then storage path.

Pre Record Setting: open the pre record function for alarm record in IE.

Alarm Linkage Record: click 'Alarm Linkage Record' can do linkage record when have alarm. Set the record size and save is ok.

## 6.PTZ Control Basic Function



The image shows a software window titled "Preset". Inside the window, there are three input fields: "Preset Title" with a text box, "Preset Num" with a text box, and "Preset Select" with a dropdown arrow. Below these fields are three buttons: "Add", "Delete", and "Call".

Fig 6-1Preset Position Setting

### 6.1 Preset Setting and Calling

#### 6.1.1 Preset Setting

Camera can set 128 preset position. User can move the PTZ to surveillance place and zoom+ or zoom- to adjust the image size. Input a number to represent for this preset position, and press 'Add' button to save the setting. Then the camer will save this surveillance position and the setting parameters.

For instance: set No.1 preset position.

- Move the PTZ to surveillance place and adjust the size.
- Input 1 to 'Preset Num' and input preset title
- Press 'Add' button to save this preset position, then the information will be shown in 'Preset Select'.

#### 6.1.2 Calling for Preset Position

Input the preset No. in the text box after 'Preset Num', or click the drop down list from 'Preset Select' to choose the position you want,

then press 'Call' button, PTZ will move to coordinate position accurately based on the parameters set before(including PTZ horizontal, vertical angle and lens variable value).

For instance: call No.1 preset position

- Input 1 in the text box after 'Preset Num' or select one from 'Preset Select'
- Press 'Call' button
- Camera execute new order, PTZ move, lens adjust and finally locate in the accurate No.1 position

## **6.2 Special Function Setting and Calling**

User can achieve left/right scan, 360° scan, pattern scan and camera reboot through calling special preset position.

### **6.2.1 Left/Right Scan Setting**

Input 130 in the text box after 'Preset Num', press 'Call' button, the current position is the left limit point for left/right scan, input 131 and press 'Call' button, the current position is the right limit point for left/right scan. When finish setting of the left/right limit point, input 132, camera will begin to do low speed left/right scan, input 133 medium speed scan and 134 high speed scan.

### **6.2.2 360° Scan**

Input 135 in the text box after 'Preset Num', press 'Call' button, camera will begin to do low speed 360° scan, input 136 for medium speed 360° scan and 137 for high speed's.

### **6.2.3 Tour Group Setting**

#### **6.2.3.1 The First Tour Group Setting**

Input 140 in the text box after 'Preset Num', press 'Call' button, camera will begin the first tour group setting, select one preset position

from 'Play Select', and press 'Call', then this preset position will be added to tour group, for each tour group can add 16 preset positions, after the adding finished, input 141 and the adding will be over, input 142 to operate the first tour group.

#### **6.2.3.2 The Second Tour Group Setting**

Input 190 in the text box after 'Preset Num', press 'Call' button, camera will begin the second tour group setting, select one preset position from 'Play Select', and press 'Call', then this preset position will be added to tour group, for each tour group can add 16 preset positions, after the adding finished, input 191 and the adding will be over, input 192 to operate the second tour group.

#### **6.2.3.3 The Third Tour Group Setting**

Input 193 in the text box after 'Preset Num', press 'Call' button, camera will begin the third tour group setting, select one preset position from 'Play Select', and press 'Call', then this preset position will be added to tour group, for each tour group can add 16 preset positions, after the adding finished, input 194 and the adding will be over, input 195 to operate the second tour group.

#### **6.2.3.4 The fourth Tour Group Setting**

Input 196 in the text box after 'Preset Num', press 'Call' button, camera will begin the fourth tour group setting, select one preset position from 'Play Select', and press 'Call', then this preset position will be added to tour group, for each tour group can add 16 preset positions, after the adding finished, input 197 and the adding will be over, input 198 to operate the second tour group.

#### **6.2.4 Pattern Scan Setting**

Input 180 in the text box after 'Preset Num', press 'Call' button,



operate the camera(camera control, lens control) to execute the first pattern scan;track record;Input 181 in the text box after 'Preset Num', press 'Call' button, operate the camera(camera control, lens control) to execute the first pattern scan;track record;Input 182 in the text box after 'Preset Num', press 'Call' button, operate the camera(camera control, lens control) to execute the first pattern scan;track record; Input 183 in the text box after 'Preset Num', press 'Call' button, operate the camera(camera control, lens control) to execute the first pattern scan;track record; Input 184 in the text box after 'Preset Num', press 'Call' button to end the pattern pattern scan setting. Input 185,186,187,188 in the text box after 'Preset Num', press 'Call' button,camera will operate the first, second, third and fourth pattern scan.

## 7. FAQ

### 1. Can Not Visit Via Browser

Possible Reason (1): Internet is not connected

Solving Method: connect the PC to internet and check if it can normal work, get rid of cable and virus problem, till PCs can ping to each other.

Possible Reason (2): IP address is being occupied by other devices

Solving Method: connect the camera to PC and reset a new IP address

Possible Reason (3): camera and PC IP address not in the same segment

Solving Method: set them to the same segment

Possible Reason (4): Camera breakdown

Solving Method: return for repairing

### 2. Can Not Control Camera Via IE

Possible Reason (1): Ensure if the settings of address, protocol and other parameters in 'Serial Port' are coordinate with the camera dial-up.

Solving Method: check the camera protocol, bit rate and other parameters in 'Serial Port' and set them right.

Possible Reason (2): Camera breakdown

Solving Method: return for repairing