



User Manual

-Installation

-Operation

Omniksol-3k-TL

Omniksol-4k-TL

Omnik New Energy Co.,Ltd.

CATALOG

1. Notes on this manual	1
1.1 Scope of Validation	1
1.2 Symbols Used	1
1.3 Target Group	1
2. Preparation	3
2.1 Safety Instructions	3
2.2 Explanations of Symbols on Inverter	5
3. Product Information	6
3.1 Overview	6
3.2 Major Characteristics	7
3.3 Datasheet	8
4. Packing checklist	10
4.1 Assembly parts	10
4.2 Product Appearance	11
4.3 Product Identification	12
4.4 Further Information	12
5. Installation	13
5.1 Safety	13
5.2 Mounting Instructions	13
5.3 Safety Clearance	14
5.4 Mounting Procedure	15
5.5 Safety lock	16
6. Electrical Connection	18
6.1 Safety	18
6.2 Overview of Connection Area	18
6.3 AC Side Connection	19
6.4 DC Side Connection	20
6.5 DC Side Disconnection	23
6.6 Communication and Monitoring Device	23
7. Display	25
7.1 LCD Panel	25
7.2 LCD Display	26
7.3 Set Language	27

7.4 State Information 28

8. Recycling and Disposal 29

9. Troubleshooting 30

10. Abbreviation 31

11. Contact 32

1. NOTES ON THIS MANUAL

1.1 Scope of Validation

The main purpose of this User's Manual is to provide instructions and detailed procedures for installing, operating, maintaining, and troubleshooting the following two types of Omnik New Energy-Solar Inverters:

- Omniksol-3k-TL
- Omniksol-4k-TL

Please keep this user manual all time available in case of emergency.

1.2 Symbols Used



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazardous situation which, if not avoided, can result in death or serious injury or moderate injury.



CAUTION

CAUTION indicates a hazardous condition which, if not avoided, can result in minor or moderate injury.



NOTICE

NOTICE indicates a situation that can result in property damage, if not avoided.

1.3 Target Group

• Chapter 1, 2, 3, 4, 7, 8, 9, 10 and chapter 11 are intended for anyone who is intended to use Omnik Grid Tie Solar Inverter. Before any further action, the operators must first read all safety regulations and be aware of the potential danger to operate high-voltage devices. Operators must also have a complete understanding of this device's features and functions.



WARNING

Do not use this product unless it has been successfully installed by qualified personnel in accordance with the instructions in Chapter 5, "Installation".

• Chapter 5 and chapter 6 are only for qualified personnel who are intended to install or uninstall the Omnik Grid Tie Solar Inverter.



NOTICE

Hereby qualified personnel means he/she has the valid license from the local authority in:

- Installing electrical equipment and PV power systems (up to 1000 V).
- Applying all applicable installation codes.
- Analyzing and reducing the hazards involved in performing electrical work.
- Selecting and using Personal Protective Equipment (PPE).

2. PREPARATION

2.1 Safety Instructions



DANGER

DANGER due to electrical shock and high voltage

DO NOT touch the operating component of the inverter, it might result in burning or death.

TO prevent risk of electric shock during installation and maintenance, please make sure that all AC and DC terminals are plugged out.

DO NOT stay close to the instruments while there is severe weather conditions including storm, lighting etc.



WARNING

The installation, service, recycling and disposal of the inverters must be performed by qualified personnel only in compliance with national and local standards and regulations. Please contact your dealer to get the information of authorized repair facility for any maintenance or repairmen.

Any unauthorized actions including modification of product functionality of any form will affect the validation of warranty service; Omnik may deny the obligation of warranty service accordingly.



NOTICE

Public utility only

The PV inverter designed to feed AC power directly into the public utility power grid, do not connect AC output of the device to any private AC equipment.

**CAUTION**

The PV inverter will become hot during operation; please don't touch the heat sink or peripheral surface during or shortly after operation.

Risk of damage due to improper modifications.

Never modify or manipulate the inverter or other components of the system.

2.2 Explanations of Symbols on Inverter

Symbol	Description
	Dangerous electrical voltage This device is directly connected to public grid, thus all work to the inverter shall only be carried out by qualified personnel.
	DANGER to life due to high electrical voltage! There might be residual currents in inverter because of large capacitors. Wait 10 MINUTES before you remove the front lid.
	NOTICE, danger! This device directly connected with electricity generators and public grid.
	Danger of hot surface The components inside the inverter will release a log of heat during operation, DO NOT touch aluminum housing during operating.
	An error has occurred Please go to Part 10 "Trouble Shooting" to remedy the error.
	This device SHALL NOT be disposed of in residential waste Please go to Part 9 "Recycling and Disposal" for proper treatments.
	Without Transformer This inverter does not use transformer for the isolation function.
	German mark of conformity The inverter complies with the requirement of the German Grid Regulations.
	Certified Safety The inverter complies with the requirements of the Equipment and Product Safety Act in Europe.
	Standards Association of Australian The inverter complies with the requirement of the AS4777.
	CE Mark Equipment with the CE mark fulfils the basic requirements of the Guideline Governing Low-Voltage and Electromagnetic Compatibility.
	No unauthorized perforations or modifications Any unauthorized perforations or modifications are strictly forbidden, if any defect or damage (device/person) is occurred, Omnik shall not take any responsibility for it.

3. PRODUCT INFORMATION

3.1 Overview

- Industrial Layout



- Excellent Heat Elimination



- Effective Shield For DC/AC/Communication Connections



3.2 Major Characteristics

Omnik inverter has following characteristics which make Omnik inverter “High Efficiency, High Reliability, High Cost Effective Ratio”

- Wide DC input voltage and current ranges, enables more PV panels connected.
- Wide MPP voltage range ensure high yield under various weather conditions.
- High MPP tracking accuracy, ensure the minimum power losses during converting.
- Complete set of protection methods.

Also, following protection methods are integrated in Omnik inverter:

- Internal overvoltage
- DC insulation monitoring
- Ground fault protection
- Grid monitoring
- Ground fault current monitoring
- DC current monitoring
- Integrated DC switch (Optional)

3.3 Datasheet

Type	Omniksol-3k-TL		Omniksol-4k-TL
Input (DC)			
Max. PV-generator power	P _{PV} [W]	3400	4500
Max. DC voltage	V _{max(DC)} [V]		590
MPPT DC voltage range	V _{mppt} [V]		120 – 550
Turn off DC Voltage	V _{min(DC)} [V]		120
Max. DC current	I _{max(DC)} [A]		36
Nominal DC current	I _{N(DC)} [A]	28	33
Number of DC connection			2
DC-connection		Amphenol H4	
Number of MPP trackers			2
Turn on power	P _{min(DC)} [W]		10
Output (AC)			
Max. AC Power	P _{max(AC)} [V]	3300	4400
Nominal AC power	P _{N(AC)} [W]	3000	4000
Max. AC current	I _{max(AC)} [A]	14.4	19.0
Nominal AC current	I _{N(AC)} [A]	13	17.4
Power connection		Single phase	Single phase
Grid voltage range		According to VDE 0126-1-1, RD1663, ENEL2010,C10/11 G83/1 AS4777	
Grid frequency range		According to VDE 0126-1-1, RD1663, ENEL2010,C10/11, G83/1, AS4777	
Power factor		0.99 (>30% of Full Load)	
Harmonic distortion (THD) at nominal output		<2%	
AC Connector		Plug-in connector	
Power consumption			
Own consumption in operation	P _{own(AC)} [W]	45	50
Power consumption at night	P _{nigt(AC)} [W]		0
Power consumption at standby	P _{std(AC)} [W]		6
Efficiency			
Max. Efficiency (at 360VDC)		97.4%	97.6%
Euro efficiency (at 360VDC)		96.6%	97.0%
MPPT efficiency			99.9%
Safety and protection			
Internal overvoltage protection		Yes	
DC Insulation monitoring		Yes	
Earth fault protection		Yes	
Grid monitoring		According to VDE 0126-1-1, RD1663, ENEL2010,C10/11, G83/1, AS4777	
Earth fault current monitoring		According to VDE 0126-1-1, RD1663, ,ENEL2010,C10/11, G83/1, AS4777	
DC current monitoring		According to VDE 0126-1-1, RD1663, ENEL2010,C10/11, G83/1, AS4777	
Islanding protection		According to VDE 0126-1-1, RD1663, G83/1, AS4777	
Normative reference			
CE- compliant according to		EN 62109, EN 61000-6-1, EN 61000-6-3, EN 61000-6-2, EN 61000-6-4 EN61000-3-2, EN61000-3-3, EN61000-3-12, EN61000-3-11	
Dimensions and weight			
Dimensions (WxHxD)	[mm]	367x526x163	
Weight	[kg]	20	21
Environmental limits			
IP protection type		IP 65 according to IEC 60529	
Operating temperature range		-20°C to +60°C	
Relative humidity		0% to 98%, no condensation	
Maximum altitude (above sea level)	[m]	2000	
Noise level	[dBA]	< 40	

Cooling concept	Convection
Housing	metal housing for inside and outside installation
Mounting information	Wall bracket
LED display	3
LCD display	Backlight, 16 x 2 Character LCD
Data logger	
Data communication interfaces	RS485, Optional (Wi-Fi, GPRS, Ethernet)
Computer Communication	RS232 as Option
Standard warranty	5 years (optional 10 years)

4. PACKING CHECKLIST

4.1 Assembly parts

After you receive the Omnik inverter, please check if there is any damage on the carton, and then check the inside completeness for any visible external damage on the inverter or any accessories. Contact your dealer if anything is damaged or missing.



A



B



C



D




E

F



G




H

Object	Quantity	Description
A	1	Omnik inverter
B	2 pair	DC connector
C	1	AC connector
D	1	Ring tool to disconnect DC connector
E	4	Screw (ST6×50)
F	4	Expansion tube
G	1	Installation and operating instructions
H	1	DC Switch (Optional)


4.2 Product Appearance

• Front



Object	Description
A	Removable front shield
B	LED light(Green) – RUN
C	LED light(Red) – FAULT
D	LED light(Yellow) – COM
E	Function key for displays and choice of language
F	Monitoring LCD with backlighting


• Bottom



Object	Description
A	Plug connectors for DC input.
B	RS232/RS485 interface
C	Terminal for grid connection (AC output)

4.3 Product Identification

You can identify the inverter by the side name plate. Information such as serial number (SN.), type of the inverter, as well as inverter specifications are specified on the side name plate. The name plate is on the middle part of the right side of the inverter housing. And the following figure is the side name plate example as on Omniksol-3k-TL.



4.4 Further Information

If you have any further questions concerning the type of accessories or installation, please check our website www.omnik-solar.com or contact our service hotline.

5. INSTALLATION

5.1 Safety



DANGER

DANGER to life due to potential fire or electricity shock.

DO NOT install the inverter near any inflammable or explosive items.

This inverter will be directly connected with HIGH VOLTAGE power generation device, the installation must be performed by qualified personnel only in compliance with national and local standards and regulations.




NOTICE

NOTICE due to the inappropriate or the harmonized installation environment may jeopardize the life span of the inverter.

Installation directly expose under intensive sunshine is not recommended.

The installation site **MUST** have good ventilation condition.


5.2 Mounting Instructions



- Omnik inverter is designed for indoors and outdoors installation
- Please mount the inverter in the direction as illustrated above
- Install the inverter in the vertical direction is recommended, with a max.15 degrees backwards.
- For the convenience of checking the LCD display and possible maintenance activities, please install the inverter at eye level.
- Make sure the wall you selected is strong enough to handle the screws and bear the weight of the inverter
- Ensure the device is properly fixed to the wall
- It is not recommended that the inverter is exposed to the strong sunshine, because the excess heating might lead to power reduction
- The ambient temperature of installation site should be between -20 °C and +60 °C (between -4 °F and 140 °F)
- Make sure the ventilation of the installation spot, not sufficient ventilation may reduce the performance of the electronic components inside the inverter and shorten the life of the inverter

5.3 Safety Clearance


Observe the following minimum clearances to walls, other devices or objects to guarantee sufficient heat dissipation and enough space for pulling the electronic solar switch handle.




Direction	Minimum Clearance
Above	30 cm
Below	30 cm
Sides	10 cm

5.4 Mounting Procedure


1. Mark 4 positions of the drill holes on the wall according to the following figure.



2. First, according to the marks, drill 4 holes in the wall. Then, place four expansion tubes in the holes using a rubber hammer. Next, wring 4 screws into the expansion tubes.




3. First check the 4 holes in the backside of the inverter. Then, lift the inverter carefully, align the 4 holes in the inverter and the 4 screws in the wall, and finally attach the inverter to the screws slightly.




4. Please carefully check the accessories and original carton to make sure every necessary part is used and nothing is missing during installation.

5.5 Safety lock

To prevent possible theft activity, Omnik gives you an extra guard for your property. It is possible to lock the inverter to the rear panel with a padlock.



Recommended padlock dimension:




A.Shackle Diameter	5~7 mm
B.Vertical Clearance	8~15 mm
C.Horizontal Clearance	12~20 mm
Stainless, solid hanger and secured lock cylinder	



NOTICE

For further maintenance and possible repair, please keep the key of the padlock in a safe place.

After the inverter is hang up on the wall, install the lock bracket on the aluminium radiator at the Lower Right Corner of the inverter (as the picture showed below),make sure the round hole of the lock bracket aim at the hole of the inverter, after that lock up the device.



The lock bracket

6. ELECTRICAL CONNECTION

6.1 Safety



DANGER

DANGER to life due to potential fire or electricity shock.

With the inverter powered, comply with all prevailing national regulations on accidents prevention.


This inverter will be directly connected with HIGH VOLTAGE power generation device, the installation must be performed by qualified personnel only in compliance with national and local standards and regulations.



NOTICE

Electrical connections shall be carried out in accordance with the applicable regulations, such as conductor sections, fuses, PE connection.

6.2 Overview of Connection Area



Object	Description
A	Plug connectors for DC input.
B	RS232/RS485 interface
C	Terminal for grid connection (AC output)

6.3 AC Side Connection



DANGER

DANGER to life due to potential fire or electricity shock.


NEVER connect or disconnect the connectors under load.

1. Integrated RCD and RCM


The Omniksol inverter is equipped with integrated RCD (Residual Current Protective Device) and RCM (Residual Current Operated Monitor). The current sensor will detect the volume of the leakage current and compare it with the pre-set value, if the leakage current exceeds the permitted range, the RCD will disconnect the inverter from the AC load.

2. Assembly Instructions


1) Strip the cable with the length 0.276 inches (9/32") - (7mm) and please be careful NOT to nick conductors.




2) Screw off and separate each component of AC connector as follows.




3) Pass the cable through each component from left to the right as follows.



4) Use a screw driver and loose the three screws at the side of the straight plug. Then insert the **stripped N, L and PE cable** accordingly to the corresponding position and fully tighten the screws.



5) Aim the terminals on the straight plug to the holes of the grommet, and then compress them together.



6) Finally connect the straight plug to the AC terminal on inverter. **Pay attention to the polarity of the terminals to avoid wrong connecting.**

6.4 DC Side Connection



DANGER

DANGER to life due to potential fire or electricity shock.

NEVER connect or disconnect the connectors under load.



NOTICE

DC Switch(**Optional**) may be integrated or external to Inverter, and it can be used to connect or disconnect the DC source from Inverter.

For Omniksol-3k-TL and Omniksol-4k-TL, there are two MPP Trackers, and the DC characteristics of them are illustrated as the following table.

Inverter Type	MPP Tracker	Max. DC Power	Max. DC Voltage	Max. DC Current
Omniksol-3k-TL	2	3400W	590V	36A
Omniksol-4k-TL		4500W		36A

1. The DC connectors come pre-assembled and the caps are loose. The whole connector will include the male side and female side as showed below:




Female side connector (F)



Male side connector (M)

2. Assembly Instructions

a. Strip the cable with the length 0.276 inches (9/32") - (7mm) and please be careful NOT to nick conductors



b. Use specified strip tool in this step. Adjust the stripper stopper and put the cable in corresponding notch to strip the length of 7mm. Please see below figures.



c. Insert striped cable into contact barrel and insure all conductor strands are captured in the contact barrel and the conductors are visible in the contact barrel observation hole. Please see below figures.

Pin contact



Barrel observation hole, conductor should be visible

Socket contact



Barrel observation hole, conductor should be visible

d. Crimp contact barrel by using the hex crimping die. Please see below figures.

Crimped pin contact



Crimped socket contact



Cable requirements:

Cable Size	Cable pull – out force requirement
2.5 mm ²	Min. 310 N (70 Lbs)
4 mm ²	Min. 400 N (90 Lbs)
6 mm ²	Min. 450 N (100 Lbs)

e. Insert contact cable assembly into back of male and female connector. A “click” should be heard or felt when the contact cable assembly is seated correctly. Please see below figures.



Female side connector (F)



Male side connector (M)

f. Wrest the cap by using the torque of 2.6~2.9NM.



g. Plug the DC connectors to DC terminal on Omnik-sol

6.5 DC Side Disconnection


When the separation of DC connectors is necessary, please use the specified tool (Ring tool or wrench tool) to separate them. While using the ring tool or wrench tool, please make sure the wedge side of the fingers faces the female connector and push the tool down. Then separate the connector by hand. See below figures.



Separation by ring tool

6.6 Communication and Monitoring Device


There are 2 plugs in the bottom side of the Omnik inverter as the following figure:



These 2 plugs are used for multipoint communications, that is, up to 50 Omnik inverters can be connected one by one through these 2 plugs and the cables, the upper computer can communicate with these inverters via a single signal cable at the same time, and maximum length of the cable is 1000m. Through these plugs, the user can get the data from these inverters, and can also configure parameters of them.

7. DISPLAY

7.1 LCD Panel



Object	Description
A	LED light(Green) – RUN
B	LED light(Red) – FAULT
C	LED light(Yellow) – COM
D	Function key for displays and choice of language
E	Monitoring LCD with backlighting

The LCD panel is integrated in the front lid of the inverter, so it is easy for user to check and set the data. In addition, the user can press the function key to illuminate the LCD screen.



NOTICE

Omnik inverter is not an aligned measuring instrument for current, voltage or power consumption. A slight deviation of a few percent points is intrinsic to the system, the results from the inverter cannot be used for grid balance calculations. An aligned meter will be required to make calculations for the utility company.


7.2 LCD Display



NOTICE

Make sure the DC switch(**Optional**) is switched to “On” position, otherwise the inverter cannot work due to power shortage.

The display content consists of 2 lines. The bottom line (Line 2) always displays the output power ($Pac = xxxx\text{ W}$). The top line (Line 1) shows current state information by default, and by pressing function key it will display different operating information as the following flow chart and table.



Line 1	Description
State information	Current state information: all possible content shows in the following table, reference to 7.4 for further information
E-today	The energy generated today in kilo watt hours (kWh)
E-total	The energy generated since starting up the inverter (kWh)
Vpv	The present voltage of the solar generator
Ipv	The present current of the solar generator
Iac	The present grid current
Frequency	The grid frequency
Model	The type of the inverter
Ver	The Firmware version
Set Language	Several languages are provided for users, reference to 7.3 for further information
Vac	The grid voltage

7.3 Set Language

The Omnik inverter provides several languages for users to use. At the entry of “Set Language”, press the key for approx. 5 seconds, you can enter the language selection menu. Choose the language which you need with the function key, and keep this state without any operation. When it returns to the main menu automatically, the setting has been saved.

7.4 State Information

State	Display	State information
Wait	Waiting	Initialization & waiting
	Reconnect s	Reconnect
	Checking s	Checking
Normal	Normal	Normal state
Fault	Ground I Fault	GFCI failure oversized leakage current
	Fac Failure	Grid frequency failure
	Vac Failure	Grid voltage failure
	Utility Loss	No Utility&Island
	PV Over Voltage	Input voltage too high
	Over Temperature	Temperature abnormal
	Isolation Fault	Isolation failure
	Relay-Check Fail	Output relay failure
	DC INJ High	Output DC injection too high
	EEPROM R/W Fail	EEPROM problem
	SCI Failure	Serial communication interface failure
	AC HCT Failure	Output AC sensor abnormal
	GFCI Failure	GFCI testing device abnormal
Flash	F/W Updating	Update

About the further information for each fault, please reference to chapter “9. TROUBLESHOOTING”.

8. RECYCLING AND DISPOSAL

To comply with European Directive 2002/96/EC on waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Any device that you no longer required must be returned to your dealer or you must find an approved collection and recycling facility in your area.

Ignoring this EU Directive may have severe affects on the environment and your health.



WARNING



This device **SHALL NOT** be disposed of in residential waste.

9. TROUBLESHOOTING

	LCD display	Possible actions
Resumable Fault	Isolation Fault	1. Check the impedance between PV (+) & PV (-) and the inverter is earthed. The impedance must be greater than 2MΩ. 2. Check whether the AC-side has contacts with earth.
	Ground I Fault	1. The ground current is too high. 2. After cut off the AC side connection, unplug the inputs from the PV generator and check the peripheral AC system. 3. After the cause is cleared, re-plug the PV panel and AC connection, and check PV-Inverter status.
	Grid Fault	1. Wait for a moment, if the grid returns to normal, PV-Inverter automatically restarts.
	Fac Over Range	2. Make sure grid voltage and frequency meet the specifications.
	Vac Over Range	
	Utility Loss	1. Grid is not connected. 2. Check grid connection cables. 3. Check grid usability. 4. If grid is ok, and the problem persists, maybe the fuse in the inverter is open, please call service.
	Over Temperature	1. The internal temperature is higher than specified normal value. 2. Find a way to reduce the ambient temperature. 3. Or move the inverter to a cooler environment.
Permanent Fault	PV over Voltage	1. Check the open PV voltage, see if it is greater than or too close to 500VDC (for Omniksol-3k-TL or Omniksol-4k-TL). 2. If PV voltage is less than 590VDC, and the problem still occurs, please call local service.
	Consistent Fault	Disconnect PV (+) or PV (-) from the input, restart the inverter.
	Relay-Check Fail	1. Disconnect ALL PV (+) or PV (-). 2. Wait for a few seconds. 3. After the LCD switches off, reconnect and check again. 4. If the problems remain please call local service.
	DC INJ High	
	EEPROM R/W	
	Fail	
	SCI Failure	
	AC HCT Fault	
	GFCI Failure	

10. ABBREVIATION

LCD	Liquid Crystal Display
LED	Light Emitting Diode
MPPT	Maximum Power Point Tracking
PV	Photovoltaic
Vdc	Voltage at the DC side
Vac	Voltage at the AC side
Vmpp	Voltage at the Maximum Power Point
Impp	Amperage at Maximum Power Point
AC	Alternating Current (Form of electricity supplied by Utility Company)
DC	Direct Current (Form of electricity generated by PV modules)
VDE 0126-1-1	German standards for establishing suitability for Grid Connection of the Inverter.
DC Switch	Switch in the DC Circuit. Disconnects DC source from Inverter. May be integrated or external to Inverter.

11. CONTACT

Suzhou Headquarter

Xinghu Road No.218 bioBAY Park C2-101 215123 Suzhou China

Tel: +86 512 6295 6676

Fax: +86 512 6295 6682

Email: info@omnik-solar.com

www.omnik-solar.com

Omnik German Service Center

An der Pikardie 6

01277 Dresden

Deutschland

Tel: +49 (0)351 30986031

Fax: +49 (0)351 30930022

Email: service-de@omnik-solar.com

Service line

Tel: +86 512 6295 6676

Fax: +86 512 6295 6682

Email: service@omnik-solar.com