



**PW-5000**  
**One Reader Interface**  
**Installation Manual**  
**Part Number: PW5K1R1**



---

## **Table of Contents**

Warnings and Cautions .....	.iii
Disclaimer .....	.v
Product Liability; Mutual Indemnification .....	.v
Unpacking Procedure .....	.v
Shipping Instructions .....	.vi
Limited Warranty .....	.vi
Confidentiality .....	.vii
Reader Interface (PW5K1R1) .....	.1-1
Power, Reader and Door Hardware Wiring .....	.1-1
Communication to Controller .....	.1-3
Specifications .....	.1-5



## **Warnings and Cautions**

### **WARNING**



Before installation, **TURN OFF** the external circuit breaker which supplies power to the system.

Before connecting the device to the power supply, verify that the output voltage is within specifications of the power supply.

Do not apply power to the system until **after** the installation has been completed. Personal injury or death could occur, and the equipment could be damaged beyond repair, if this precaution is not observed!

### **WARNING**



#### **Fire Safety and Liability Notice**

Never connect card readers to any critical entry, exit door, barrier, elevator or gate without providing **an alternative exit** in accordance with all fire and life safety codes pertinent to the installation. These fire and safety codes vary from city to city and you must get approval from local fire officials whenever using an electronic product to control a door or other barrier. Use of egress buttons, for example, may be illegal in some cities. In most applications, single action exit without prior knowledge of what to do is a life safety requirement. Always make certain that any required approvals are obtained in writing. **DO NOT ACCEPT VERBAL APPROVALS, AS THEY ARE NOT VALID.**

Northern never recommends using the N-1000, N-800, N-500, PW-2000, EV-2000 or related products for use as a primary warning or monitoring system. Primary warning or monitoring systems should always meet local fire and safety code requirements. The installer must also test the system on a regular basis by instructing the end user in appropriate daily testing procedures. Failure to test a system regularly could make installer liable for damages to the end user if a problem occurs.

### **WARNING**



EARTH ground all enclosures, for proper installation.

### **WARNING**



Use suppressors on all door strikes. Use S-4 suppressors for installation. Northern Computers recommends only DC strikes.

**CAUTION**

IF ANY DAMAGE TO THE SHIPMENT IS NOTICED, A CLAIM MUST BE FILED WITH THE COMMERCIAL CARRIER RESPONSIBLE.

**CAUTION**

Electro-static discharge can damage CMOS integrated circuits and modules.

To prevent damage always follow these procedures:

Use static shield packaging and containers to transport all electronic components, including completed reader assemblies.

Handle all ESD sensitive components at an approved static controlled workstation. These workstations consist of a desk mat, floor mat and an ESD wrist strap. Workstations are available from various vendors.

**NOTICE**

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES WHEN WIRED USING METAL CONDUIT FOR THE CABLING EXTERNAL TO THE ENCLOSURE. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

**NOTICE**

This document and the data in it shall not be duplicated, used or disclosed to others for procurement or manufacture, except as authorized by and with the written permission of, Northern Computers, Inc. The information contained in this document or in the product itself is considered the exclusive property and trade secrets of Northern Computers, Inc. Copyright laws of the United States protect all information in this document or in the software product itself.

**NOTICE**

Any use of this product is subject to the terms and acceptance of the Northern Computers, Inc. Software Agreement. Please request a copy from Northern Computers, Inc., and review the agreement carefully.

## **Disclaimer**

### **Product Liability; Mutual Indemnification**

In the event that a Customer receives a claim that a Product or any component thereof has caused personal injury or damage to property of others, Customer shall immediately notify Northern in writing of all such claims. Northern shall defend or settle such claims and shall indemnify and hold Customer harmless for any costs or damages including reasonable attorneys' fees which Customer may be required to pay as a result of the defective Product or the negligence of Northern, its agents, or its employees.

Customer shall hold harmless and indemnify Northern from and against all claims, demands, losses and liability arising out of damage to property or injury to persons occasioned by or in connection with the acts or omissions of Customer and its agents and employees, and from and against all claims, demands, losses and liability for costs of fees, including reasonable attorneys' fees, in connection therewith.

## **Unpacking Procedure**

### **CAUTION**

If any damage to the shipment is noticed before unpacking, a claim must be filed with the commercial carrier.

All containers should be opened and unpacked carefully in order to prevent damage to the contents.

The following steps are used to unpack equipment in preparation for installation:

1. Open the container and remove the unit(s) and all packing material. Retain the container and all packing materials. They may be used again for reshipment of the equipment, if needed.
2. Inspect the contents for shortage. If items are missing items, contact the order entry department.
3. Visually check contents. If damage is discovered, perform the following:
  - If shipping caused damage to the unit, a claim must be filed with the commercial carrier.
  - If any other defect is apparent, call for a return authorization.

## **Shipping Instructions**

To ship equipment back to Northern Computers, Inc.:

1. Contact the customer service department before returning equipment.

When you call please have available:

- A description of the problem or reason you are returning the equipment.
  - Your original purchase order number, invoice number and if the unit is still under warranty.
  - A new purchase order number if the unit is not under warranty.
2. Obtain the Return Authorization Number (RMA) from the customer service department.
  3. Show the RMA number on all packages shipped. Packages, which are not marked with an RMA number will be refused at the factory and returned to you COD.
  4. Carefully pack the equipment for shipment. Use the original packing material whenever possible.

## **Limited Warranty**

All Products sold or licensed by Northern include a warranty registration card which must be completed and returned to Northern by or on behalf of the end user in order for Northern to provide warranty service, repair, credit or exchange. All warranty work shall be handled through Customer which shall notify Northern and apply for a Return Merchandise Authorization (RMA) number prior to returning any Product for service, repair, credit or exchange. Northern warrants that its Products shall be free from defects in materials and workmanship for a period of two years from date of shipment of the Product to Customer. The warranty on Terminals, Printers, Communications Products and Upgrade kits is 90 days from date of shipment. Satisfaction of this warranty shall be limited to repair or replacement of Products which are defective or defective under normal use. Northern's warranty shall not extend to any Product which, upon examination, is determined to be defective as a result of misuse, improper storage, incorrect installation, operation or maintenance, alteration, modification, accident or unusual deterioration of the Product due to physical environments in excess of the limits set forth in Product manuals.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THIS PROVISION. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY OR




FITNESS FOR ANY PARTICULAR PURPOSE. NO REPRESENTATION OR WARRANTY OF THE DISTRIBUTOR SHALL EXTEND THE LIABILITY OR RESPONSIBILITY OF THE MANUFACTURER BEYOND THE TERMS OF THIS PROVISION. IN NO EVENT SHALL NORTHERN BE LIABLE FOR ANY RE-PROCUREMENT COSTS, LOSS OF PROFITS, LOSS OF USE, INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES TO ANY PERSON RESULTING FROM THE USE OF NORTHERN'S PRODUCTS.

### **Confidentiality**


All software, drawings, diagrams, specifications, catalogs, literature, manuals and other materials furnished by Northern relating to the design, use and service of the Products shall remain confidential and shall constitute proprietary rights of Northern and Customer agrees to treat such information as confidential. Customer shall acquire no rights in the design of the Products or the related materials except to use such information solely for the purpose of and only during the time it sells the Products. Customer shall not copy the design of any of the Products or use or cause to be used any Product design or related materials for its own benefit or for the benefit of any other party. The covenants contained in this section shall remain effective throughout the term of this Agreement and thereafter unless specifically waived by Northern in writing.








The following circuit is recommended. Locate the protection circuit that is close to the load and one at the PW5K1R1 (within 12 inches [30cm]), as the effectiveness of the circuit will decrease if it is located far away.




### **Communication to Controller**

The Interface communicates to a controller via a half duplex multi-drop RS-485 interface. The total cable length is limited to 4,000 feet (1,200 meters). Shielded cable of 24AWG with characteristic impedance of 120 ohm and < 13pf/ft capacitance is specified for the RS-485 interface. The last devices on both end of the cable should have the termination installed (set jumper J4 on).



Represents that the shield must be grounded on one end.

Each Interface must be configured to have a unique address and correct baud rate. The address and baud rate are selected by installing the specified jumpers. Use 38400 as the standard Baud rate setting. See the following diagram.



\*WIN-PAK PRO uses the panel address 0 to equal the software setting of 32.

## **Specifications**

The Interface is for use in low voltage, class 2 circuits only.

### **Electrical**

Voltage	12 VDC $\pm$ 10%
Current	125mA max. (plus reader current 300 total max)
Relay Contacts	K1, 5A at 28 VDC; K2, 1A at 28 VDC
Monitor Inputs	2 supervised, End of Line resistors, 1k 1% ¼ watt standard
RS-485 Comm Cable	4,000' (1,219 m) max. 24 AWG, 2 twistedpairs shield with drain, 120 $\Omega$ impedance <13pf capacitance
LED Output	TTL compatible, high > 3V, low < 0.5V, 5mA source/sink max.
Buzzer Output	Open collector, 5 VDC open circuit max. 10mA sink max.
Reader Data Inputs	TTL compatible inputs
Reader Power	12 VDC, 175mA max.

### **Mechanical**

Dimensions	4.25" W x 2.75" L x 1.4" H (108 mm W x 70 mm L x 36 mm H)
Weight	4 oz. (120 g) nominal

### **Environment**

Temperature	-67° F to +185° F (-55° C to +85° C), storage 2° F to 50° F (0° C to 40° C), operating
Humidity	10% to 95% RHNC

