



3 axis controller User manual

© 2002 Twintec

Twintec controller user manual

3 axis controller user manual

© 2002 Twintec

All rights reserved. No parts of this work can be reproduced in any form without a written permission of the author. The products to who references are made in this manual can be trademark of the respective proprietary. The author assume no responsibility for errors or omissions, or for damage caused by the usage of the informations contained in this document and by the usage of the products to who it refer. In no case the author can be responsible of damage caused directly or indirectly by this document.

Printed: novembre 2002 at Gravina di Catania Italy

Published by:

Twintec

Address:

Via Monti Arsi, 13

95030 Gravina di Catania IT

Tel. 39 95 7253415

Author:

Michele Ribaudò

Web site:

<http://www.twintec.it>

e-mail:

info@twintec.it

Contents

Introduction	0
I Introduction	2
1 Controller manual	2
II Hardware	3
1 General description	3
2 Connections description	5
3 Electrical characteristics	7
4 Status indicators	7
5 Accessory	7
Controller connector	7
III Software	8
1 Command syntax	8
2 List of commands	8
Move	8
Move contour	8
Set the contour angle	9
Set the speed	9
Set the acceleration	9
Activate output	10
Wait an input	10
Wait a time	10
Execute home	10
Set the position	11
Configure	11
IV Operation principles	12
1 General Principles	12
2 Communication	13
3 Speed and acceleration	13
4 Vector's execution	15
Index	16

1 Introduction

1.1 Controller manual

This manual, destined to the controller users is divided in 4 sections to make more easy the arguments reading. We choose to not limit the manual to the simple technical description of the controller but to explain any argument, providing, where possible, examples and pictures than can give to the reader further informations for a correct use of the controller and a better understanding of it functionality.




Further informations can be found on our web site: <http://www.twintec.it>

Twintec di Ribaldo Michele
Via Monti Arsi, 13
95030 Gravina di Catania
ITALY
Tel. 39 95 7253415

2 Hardware


2.1 General description

3 axis controller



- Eurocard board 100X160 mm. connector DIN 96 poles.
- LED indicators for power, execution and error.
- Power supply 5V 200 mA.
- 3 AXIS interpolated.
- 2 serial port: Rs232 19200-38400 BPS. e RS 485 19200 a 38400.
- Communication protocol: RS232 Hardware Handshake via CTS-RTS..
- 8 user input CMOS 5V.
- 8 user output OPEN COLLECTOR max 100 mA.
- Inputs for HOME and LIMIT for all axis.
- STOP input.
- STOP with deceleration and acceleration at restart.
- CONTOURING with adjustable angle.
- Battery for data retention (6 month).
- Configuration buffer for startup.
- Input and output commands.
- Timing commands.

Drawing of the controller.



Led indicators description:

- PWR=POWER LED
- ERR=ERROR AND STOP LED
- STAT=STATUS LED

2.2 Connections description

In the following table the name of the signals.

VCC	5V supply.
GND	Ground.
PULSE0	Step output X
PULSE1	Step output Y
PULSE2	Step output Z
DIR0	Direction output X
DIR1	Direction output Y
DIR2	Direction output Z
UI0.. UI7	User inputs.
UO0..UO7	User outputs.
UO Com.	Common snubber for outputs
HOME0	
HOME1	Home input X.
HOME2	Home input Y.
LIM0	Home input Z.
LIM1	Limit Input X.
LIM2	Limit input Y.
	Limit input Z.
RXD	
TXD	Data input rs232
CTS	Data output rs232
RTS	Clear to send rs232
	Request to send 232
ANA1	
ANA2	Analogic input 0-5V
	Analogic input 0-5V
PULSE3	
DIR3	Step output (optional).
	Direction output (optional).

The following table show the drawing of the connector front view and the corresponding pin and signal.

	a32		b32		c32	
	a31		b31		c31	
	a30	GND	b30	GND	c30	GND
	a29		b29		c29	
	a28		b28	ANA 1	c28	ANA2
	a27		b27		c27	
	a26	LIM0	b26		c26	HOME0
	a25	STOP	b25	LIM 1	c25	
	a24	LIM2	b24	HOME1	c24	
	a23		b23		c23	HOME2
	a22	CTS	b22		c22	
	a21	TXD	b21	RTS	c21	UI0
	a20	RXD	b20	UI1	c20	UI6
	a19	UI7	b19	UI5	c19	UI3
	a18	UI2	b18		c18	UI4
	a17		b17	GND	c17	GND
	a16		b16	GND	c16	
	a15	Dir 0	b15	Dir 1	c15	Dir 2
	a14	Pulse0	b14	Pulse1	c14	Pulse2
	a13		b13		c13	GND
	a12	GND	b12	GND	c12	
	a11	GND	b11		c11	Pulse3
	a10		b10		c10	Dir3
	a9		b9		c9	
	a8		b8		c8	
	a7		b7		c7	
	a6	UO2	b6	UO1	c6	UO0
	a5	UO5	b5	UO4	c5	UO3
	a4	UO Com.	b4	UO7	c4	UO6
	a3	GND	b3	GND	c3	GND
	a2	VCC	b2	VCC	c2	VCC
	a1	VCC	b1	VCC	c1	VCC

Here the serial connector.

Connettore DB9 RS 232	Related signals
	2 RXD 3 TXD 4-----6 5 GND 7 CTS 8 RTS
	Data receive (PC) Data transmit (PC) Shortened (DTR DSR) Ground Clear to send (PC) Request to send (PC)

and the RS 485 connector

RS 485 connector	Related signals
	1 GROUND 2 BUS A 3 BUS B

2.3 Electrical characteristics

Power supply: 5V 200 mA max.

Input home and limits: Normally closed CMOS 5 V with pull-up da 10 KOhm.

User input: pull-up 10KOhm.

User output: Open collector max 100 mA.

Step and dir output: Open collector without pull-up.

Output IC: ULN2803;

Input IC: 74HC244;

2.4 Status indicators

The LED indicators are three:




1. GREEN LED: indicate the power is on.
2. RED LED: Have three states:
 - OFF: nessun errore.
 - FLASHING: The STOP is Pressed.
 - ON: A limit have benn reached.
3. YELLOW LED: have two states:
 - 1 sec. Flashing: The controller is in the stand-by state.
 - 1/2 sec. flashing: The controller is executing commands.

2.5 Accessory

2.5.1 Controller connector

This board allow the connection of the controller with detachable connectors. It comprise a 5V stabilized power so the input can be 9~15 V cc.. On the back there is a LED that indicate the power presence and is possible to add a DB9 connector whenever the one on the controller will result in an unfavorable position.



Power supply 9~15 V CC. 200 mA.

Nota: Not all the signals are disponible on that connector

Signals present:

UO common
UO 0..3
UI 0..3
PULSE 0,1,2
DIR 0,1,2
LIM 0,1,2
STOP
HOME 0,1,2
GND
VCC
ANA 1,2

3 Software

3.1 Command syntax

All commands are of two characters and a list of parameters delimited by a comma, the command terminator is the semi-colon ";".

MC100,100,100;

Spaced are discarded by the controller.

MC 100, 100, 100;

The interpreter is case insensitive;

mc 100,100,100;

Follow the description of the commands, the syntax, limits and error condition.

3.2 List of commands

3.2.1 Move

Syntax: ***MV X,Y,Z;***

Purpose: Move the axis at the specified position with acceleration and deceleration.

Parameters: X,Y and Z.

Example: MV 100, 100, 400;

Limits: 8388608÷ -8388608

Errors: Missing parrameter, parameter out of limit.

Note: The position are in step and are absolute.

3.2.2 Move contour

Syntax: ***MC X,Y,Z;***

Purpose: Move the axis at the specified position inside a path. If the angle between the vector and the previous one is greater than the angle of contour the controller will decelerate if in move and then accelerate to begin this position motion

([see the paragraph for the vector execution](#)).

Parameters: X,Y e Z.

Example: MC 100, 100, 400;

Limits: 8388608÷ -8388608

Errors: Missing parrameter, parameter out of limit.

Note: The position are in step and are absolute.

3.2.3 Set the contour angle

Syntax: **SI A;**

Purpose: Set the contour angle ([see the paragraph for the vector execution](#)).

Parameters: A. Contour angle in degree;

Example: SI 25;

Limits: 0-360;

Errors: Missing parrameter, parameter out of limit.

3.2.4 Set the speed

Syntax: **SV V;**

Purpose: Set the speed for the next vectors (see paragraph [Speed and acceleration](#)).

Parameters: V. Speed in cm/s.

Example: SV 2.5;

Limits: 1.2-20;

Errors: Missing parrameter, parameter out of limit.

3.2.5 Set the acceleration

Syntax: **SA A;**

Purpose: Set the acceleration in cm/s² (see paragraph [Speed and acceleration](#)).

Parameters: A. acceleration in cm/s².

Example: SA 5.5;

Limits: 1.2-40;

Errors: Missing parrameter, parameter out of limit.

3.2.6 Activate output

Syntax: EO bit,value;

Purpose: Set the user output at the specified value.

Parameters: bit: number 0..7, value 0-1.

Example: EO 7,1;

Limits: 0..7, 0-1;

Errors: Missing parrameter, parameter out of limit.

3.2.7 Wait an input

Syntax: WI bit,valore;

Purpose: Wait a specified value on a user input bit.

Parameters: bit: number 0..7, value 0-1.

Example: WI 7,1;

Limits: 0..7, 0-1;

Errors: Missing parrameter, parameter out of limit.

3.2.8 Wait a time

Syntax: EW tempo;

Purpose: Wait for the specified time in ms.

Parameters: time in ms.

Example: EW 1000; wait a second

Limits: 10-65536;

Errors: Missing parrameter, parameter out of limit.

3.2.9 Execute home

Syntax: EH x,y,z;

Purpose: Bring the axis at the home position seeking the specified switch. At the end of the command the internal position is 0,0,0.

Parameters: x,y,z. 0 mean no seek 1 mean seek the switch.

Example: EH 1,1,0; Seek the home switch for the x and y axis.

Limits: 0-1;

Errors: Missing parameter, parameter out of limit.

3.2.10 Set the position

Syntax: **SP x,y,z;**

Purpose: Set the logical position without making any move.

Parameters: x,y,z.

Example: SP 1000,1000,0;

Limits:

Errors: Missing parameter, parameter out of limit, command received in execution phase.

Note: This command have to be executed carefully, the command will be refused if the controller is executing vectors.

3.2.11 Configure

Syntax: **CF tipo, p1[, p2][, p2];**

These commands are for configuration that are retained even when the controller power is not present.

Configure HOME:

Syntax: **CF 1,x,y,z;**

Purpose: Set how the controller search the Home switch at the reset.

Parameters: x,y,z.

Default value: 0,0,0;

Example: CF1,0,0;

Limits: 0-1;

Note: This command have no immediate effect, but it configure the controller to seek or not the home switch at the reset. If we send the command CF 1,1,1,0; at the next reset the controller will seek the switch that are set to one.

Configure Axis resolution:

Syntax: **CF 2,x,y,z;**

Purpose: Set the axis resolution for the three axis in step/mm.

Parameters: x,y,z.

Default value: 40,40,40;

Example: CF2,40,40,80;

Limits: 1-400;

Note: this command have effect on the speed calculation.

Configure Home Speed:

Syntax: CF 3,f;

Purpose: Set the home frequency.

Parameters: f: frequency.

Valore predefinito: 1000;

Example: CF2500;


Limits: 100-10000;

4 Operation principles

This chapter describe the operation principle of a positioning system.

4.1 General Principles

Block diagram of a positioning system:



The controller is the head of a positioning system. It perform the following tasks:

- Generate the direction signals and step frequencies to the drivers to move the motors at the desired position.
- Activate the outputs.
- Wait a status at an input.
- Perform the timing between two command.
- Transmit informations about the position and the status.
- Acquire the Stop status.
- Acquire the Limits status.
- Seek the Home switch to put the axis in this position.

The actions above mentioned can be performed by communicating, through the serial PC line, with defined commands than will be executed by the controller in the sequence that are been transmitted. In the controller there is a receive buffer that allow the same to execute work of hours without interruptions. The communication handshake is managed by the CTS and RTS control signals.

4.2 Communication

The communication with the controller is established with RS232: the line parameters are:



Bit:8
Stop bit: 1
Parity: None
Baud rate: 19200 bps.

The cable to use is a simple direct MF DB9.
 The flow control signals are RTS and CTS. Note: in absence of those signals an overwriting of the buffer can occur with severe consequence for the correct execution.

The RS 485 is optional and is reserved for future or custom usages.


4.3 Speed and acceleration

The speed, in a system composed by three axis is done with the following formula: $V = \sqrt{V_x^2 + V_y^2 + V_z^2}$ here V is the speed and v_x, v_y, v_z are the component speeds. The controller calculate the component speeds for any axis to make the final desired speed that can be set with the SVv; command where v is the speed in cm/s


The acceleration of a system is the variation of the velocity with the time, this parameter is set in cm/s^2 in the controller.

The controller have two command for the setting of these parameters, read the

paragraphs [set the speed](#) e [set the acceleration](#) for a detailed explanation of these commands. When the controller have to move at a defined position it start to send pulse with an increasing frequency until it reach the final speed and continue with this speed until it reach the position calculated for the deceleration. The following diagram show how the curve of the velocity for a single vector assume a trapezoidal form. The vertical axis represent the speed and the orizontal the time.



If the length of the vector is too small to reach the final velocity the form of the curve is a triangle.



The correct setting of these two parameters (speed and acceleration) allow to reach optimal performances relating the speed and the positioning accuracy. It is necessary to consider the kind of work to execute before set these two parameters. The step loss can be a consequence of the incorrect setting of a speed or an acceleration. It is a good practice to refer with the characteristics of the motor to find the correct values.

4.4 Vector's execution


To explain how the controller perform the axis positioning it is necessary to introduce the concept of a **vector** and the **path**.

In the following diagram we can see a path composed of 4 vectors. To make that path we have to send to the controller 4 position command. We suppose that the controller start from the position 0.0.0 and all vectors are on the same level so the Z value is 0.

List of commands:

Position diagram

```
MC20,20,0;
MC40,30,0;
MC60,90,0;
MC80,20,0;
```



If the contouring angle is set to 23° (default value) the execution of that path is done with 3 accelerations and 3 decelerations. This because the angle between the first and the second vector is less than 23° while the angle between the second and the third vector and between the third and the fourth is greater than 23° .

The sequence will be the following:

1. accelerate from the 0,0,0 position until reach the final speed.
2. reach the position 20,20,0 and it continue in the direction of the 40,30,0 position
3. decelerate until it reach teh 40,30,0 position.
4. accelerate in the direction of the 60,90,0 position
5. decelerate until it reache the 60,90,0 position
6. accelerate in the direction of the 80,20,0 position
7. decelerate until it reach the final position 80,20,0

f we want to execute the move with an acceleration and a deceleration every vector independently of the angle we have to use the MV command instead of the MC one.

Index

- A -

acceleration 9
acceleration setting 9
angle 9
axis resolution 11

- C -

characteristics 7
communications 13
configuration 11
configure 11
connection 7
connection description 5
connections 5
connector 7
contour angle 9
controller signals 5

- E -

execute home 10

- G -

general description 3
general principles 12
green led 7

- H -

home 10

- I -

indicators 7
input 10
input wait 10
Introduction 2

- L -

led 7

- M -

Move 8
Move contour 8

- O -

output 10
output setting 10

- P -

position 11
position set 11
principle 12

- R -

red led 7

- S -

signals 5
speed 9
speed and acceleration 13
speed setting 9
syntax 8

- T -

timing 10
timing wait 10

- V -

vectors execution 15

- Y -

yellow led 7

NOTE