

DTVPA



User Manual Volume 1

Manufactured by



Italy



File Name: 03_DTVPA_ING_1.0.indd

Version: 1.1

Date: 29/01/2009

Revision History

Date	Version	Reason	Editor
30/10/2008	1.0	First Version	J. H. Berti
29/01/2009	1.1	DTVPA1K1UP1 integration	J. H. Berti

DTVPA - User Manual
Version 1.1

© Copyright 2008 - 2009

R.V.R. Elettronica SpA

Via del Fonditore 2/2c - 40138 - Bologna (Italia)

Telephone: +39 051 6010506

Fax: +39 051 6011104

Email: info@rvr.it

Web: www.rvr.it

All rights reserved

Printed and bound in Italy. No part of this manual may be reproduced, memorized or transmitted in any form or by any means, electronic or mechanic, including photocopying, recording or by any information storage and retrieval system, without written permission of the copyright owner.

Table of Contents

1. Preliminary Instructions	1
2. Warranty	1
3. First Aid	2
3.1 Treatment of electrical shocks	2
3.2 Treatment of electrical Burns	2
4. General Description	3
4.1 Make-up	3
5. Quick installation and operating reference	5
5.1 Preparation	5
5.2 Operation	8
5.3 Software	9
5.4 Protection System	14
6. External Description	17
6.1 PS Module Frontal Panel	17
6.2 PS module Rear Panel	18
6.3 Connector Description	19
6.4 RF Module Frontal Panel	22
6.5 RF module Rear Panel	23
7. Technical Specifications	25
8. Operating Theory	26
8.1 Power Supply Change	28
8.2 PS Part	31
8.3 RF Part	33

This page was intentionally left blank

IMPORTANT



The symbol of lightning inside a triangle placed on the product, evidences the operations for which is necessary gave it full attention to avoid risk of electric shocks.



The symbol of exclamation mark inside a triangle placed on the product, informs the user about the presence of instructions inside the manual that accompanies the equipment, important for the efficacy and the maintenance (repairs).

1. Preliminary Instructions

• General foreword

The equipment in object is to considering for uses, installation and maintenance from "trained" or "qualified" staff, they conscious of the risks connected to operate on electronic and electrical circuits electrical.

The "trained" definition means staff with technical knowledge about the use of the equipment and with responsibility regarding the own safety and the other not qualified staff safety place under his directed surveillance in case of works on the equipment.

The "qualified" definition means staff with instruction and experience about the use of the equipment and with responsibility regarding the own safety and the other not qualified staff safety place under his directed surveillance in case of works on the equipment.

⚡ WARNING: The machine can be equipped with an ON/OFF switch which could not remove completely voltages inside the machine. It is necessary to have disconnected the feeding cord, or to have switched off the control panel, before to execute technical operations, making sure himself that the safety connection to ground is connected.

The technical interventions that expect the equipment inspection with circuits under voltage must be carry out from trained and qualified staff in presence of a second trained person that it is ready to intervene removing voltage in case of need.

R.V.R. Elettronica SpA doesn't assume responsibility for injury or damage resulting from improper procedures or practices by untrained/unqualified personnel in the handling of this unit.

⚡ WARNING: The equipment is not water resistant and an infiltration could seriously compromise its correct operation. In order to prevent fires or electric shocks, do not expose the equipment to rain, infiltrations or humidity.

Please observe all local codes and fire protection standards during installation and use of this unit.

⚡ WARNING: The equipment has to its inside exposed parts to risk of electric shock, always disconnect power before opening covers or removing any part of this unit.

Fissures and holes are supplied for the ventilation in order to assure a reliable efficacy of the product that for protect itself from excessive heating, these fissures do not have to be obstructed or to be covered. The fissures doesn't be obstructed in no case. The product must not be incorporated in a rack, unless it is supplied with a suitable ventilation or that the manufacturer's instructions are been followed.

⚠ WARNING: This equipment can irradiate radio frequency energy and if it's not installed following the instructions contained in the manual and local regulations it could generate interferences in radio communications.



WIRING: This device has a connection to ground on the power cord and on the chassis. Check that they are correctly connected.

Operate with this device in a residential ambient can cause radio disturbs; in this case, it can be demanded to the user to take adequate measures.

Specifications and informations contained in this manual are furnished for information only, and are subject to change at any time without notice, and should not be construed as a commitment by **R.V.R. Elettronica SpA**.

The **R.V.R. Elettronica SpA** assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual, including the products and software described in it; and it reserves the right to modify the design and/or the technical specifications of the product and this manual without notice.

• **Warning regarding the use designated and the use limitations of the product.**

This product is an transmitter radio indicated for the audio broadcasting service in frequency modulation. It uses working frequencies that are not harmonized in the states of designated user.

The user of this product must obtain from the Authority for spectrum management in the state of designated user the appropriate authorization to use the radio spectrum, before putting in exercise this equipment.

The working frequency, the transmitter power, let alone other specifications of the transmission system are subject to limitation and defined in the authorization obtained.

2. Warranty

R.V.R. Electronics S.P.A. guarantees absence of manufacturing defect and the good operation for the products, within the provided terms and conditions.

Please read the terms carefully, because the purchase of the product or acceptance of order confirmation, constitutes acceptance of the terms and conditions.

For the last legal terms and conditions, please visit our web site (WWW.RVR.IT) wich may also be changed, removed or updated for any reason without prior notice.

Warranty will be void in cases of opened products, physical damage, misuse, modification, repair by unauthorised persons, carelessness and using the product for other purpose than its intended use.

In case of defect, proceed like described in the following:

1 Contact the dealer or distributor where you purchased the unit. Describe the problem and, so that a possible easy solution can be detected.

Dealers and Distributors are supplied with all the information about problems that may occur and usually they can repair the unit quicker than what the manufacturer could do. Very often installing errors are discovered by dealers.

2 If your dealer cannot help you, contact **R.V.R. Elettronica** and explain the problem. If it is decided to return the unit to the factory, **R.V.R. Elettronica** will mail you a regular authorization with all the necessary instructions to send back the goods;

3 When you receive the authorization, you can return the unit. Pack it carefully for the shipment, preferably using the original packing and seal the package perfectly. The customer always assumes the risks of loss (i.e.,

R.V.R. is never responsible for damage or loss), until the package reaches R.V.R. premises. For this reason, we suggest you to insure the goods for the whole value. Shipment must be effected C.I.F. (PREPAID) to the address specified by R.V.R.'s service manager on the authorization



DO NOT RETURN UNITS WITHOUT OUR AUTHORIZATION AS THEY WILL BE REFUSED

- 4 Be sure to enclose a written technical report where mention all the problems found and a copy of your original invoice establishing the starting date of the warranty.

Replacement and warranty parts may be ordered from the following address. Be sure to include the equipment model and serial number as well as part description and part number.



R.V.R. Elettronica SpA
Via del Fonditore, 2/2c
40138 BOLOGNA ITALY
Tel. +39 051 6010506

3. First Aid

The personnel employed in the installation, use and maintenance of the device, shall be familiar with theory and practice of first aid.

3.1 Treatment of electrical shocks

3.1.1 If the victim is not responsive

Follow the A-B-C's of basic life support.

- Place victim flat on his back on a hard surface.
- Open airway: lift up neck, push forehead back (Figure 1).




Figure 1

- clear out mouth if necessary and observe for breathing
- if not breathing, begin artificial breathing (Figure 2): tilt head, pinch nostrils, make airtight seal, four quick full breaths. Remember mouth to mouth resuscitation must be commenced as soon as possible.



Figure 2

- Check carotid pulse (Figure 3); if pulse is absent, begin artificial circulation (Figure 4) depressing sternum (Figure 5).




Figure 3



Figure 4




Figure 5

- In case of only one rescuer, 15 compressions alternated to two breaths.
- If there are two rescuers, the rhythm shall be of one breath each 5 compressions.
- Do not interrupt the rhythm of compressions when the second person is giving breath.
- Call for medical assistance as soon as possible.

3.1.2 If victim is responsive

- Keep them warm.
- Keep them as quiet as possible.
- Loosen their clothing (a reclining position is recommended).
- Call for medical help as soon as possible.

3.2 Treatment of electrical Burns

3.2.1 Extensive burned and broken skin

- Cover area with clean sheet or cloth.
- Do not break blisters, remove tissue, remove adhered particles of clothing, or apply any salve or ointment.
- Treat victim for shock as required.
- Arrange transportation to a hospital as quickly as possible.
- If arms or legs are affected keep them elevated.

If medical help will not be available within an hour and the victim is conscious and not vomiting, give him a weak solution of salt and soda: 1 level teaspoonful of salt and 1/2 level teaspoonful of baking soda to each quart of water (neither hot or cold).

Allow victim to sip slowly about 4 ounces (half a glass) over a period of 15 minutes.

Discontinue fluid if vomiting occurs.

DO NOT give alcohol.

3.2.2 Less severe burns

- Apply cool (not ice cold) compresses using the cleansed available cloth article.
- Do not break blisters, remove tissue, remove adhered particles of clothing, or apply salve or ointment.
- Apply clean dry dressing if necessary.
- Treat victim for shock as required.
- Arrange transportation to a hospital as quickly as possible.
- If arms or legs are affected keep them elevated.

4. General Description

The **DTVPA** is an amplifier for TV broadcasting. They are a fully solid-state apparatus of modern design that use MOSFET as active components in the amplifying modules. This chapter briefly describes the machine's main features.

4.1 Make-Up

The **DTVPA** amplifier is made up of two interconnected modules pre-arranged for assembly in a 19" rack.

The two modules are as follows:

- Control and power supply module (called **PS**)
- Amplifier module (called **RF**)




Figure 4-1: DTVPA modules

Subdividing it into two modules not only makes it easier to handle and assemble the amplifier but also permits to perform maintenance to the two parts separately.

The amplifier is controlled by a microprocessor-based system that includes a LCD which carries out the following functions:

- Measuring and displaying amplifier work parameters
- Activating and deactivating power delivery
- Protecting the amplifier as far as potentially harmful situations are concerned such as excess supplied power, SWR, excessive pilot power or temperature
- Detecting the warning thresholds set by the user (e.g. power delivered below a specific threshold), which are made available to the user via the telemetry connector
- Communicating with external devices

The amplifier's control software is based on a menu system through which the user may navigate using the following four buttons: **ESC**, , , and **ENTER**. A fifth button is provided for resetting any triggered alarms.

The PS module of this amplifier houses three rectifier/power supply switching units that normally work in parallel mode and that provide a fair degree of redundancy to the machine. Even if one of the power supply modules breaks down the amplifier will keep working at reduced power.

A schematic view of the operating theory of RF path is shown in the figure:




Figure 4-2: theory of operation

5. Quick installation and operating reference

The scope of this chapter is to summarize the procedures for installing the machine. If any point is not fully comprehensible, such as how to operate the machine the first time, it is advisable to read the entire manual very carefully.

In this description it is assumed that the amplifier is not supplied pre-installed in a rack inside a transmission system. In this case most of the operations outlined herein (for instance the wiring ones) are obviously not necessary.

5.1 Preparation

Unpack the amplifier and firstly check that it has not been damaged in any way during transport. Make sure that all the connectors and controls on the front and back panels are in good order.

Check the default setting of the type of power supply for this machine on the back of the **PS** module, which may be:

- single-phase 208 V, +15% -10%
- single-phase 230 V, +10% -15%
- three-phase 208 V, +15% -10%
- three-phase 230 V, +10% -15%
- three-phase 400 V, +10% -15%



Suggestion: Specify the type of power supply at order placement: the machine will be delivered to you configured according to your requirements.


Check, if need be, that the fuses are installed, in good working order and accessible on the back panel of the PS module. The required fuse values are as follows:

	@208/230V single phase	@208/230V three phase	@400V three phase
AUX OUT FUSE (chap. 6.2 - position [9])	(1x) F6,3T type 5x20	(1x) F6,3T type 5x20	(1x) F6,3T type 5x20
SERVICE FUSE (chap. 6.2 - position [10])	(1x) F6,3T type 5x20	(1x) F6,3T type 5x20	(1x) F6,3T type 5x20
MAINS FUSE (chap. 6.2 - position [1])	(3x) F25T type 10x38	(3x) F20T type 10x38	(3x) F16T type 10x38


Install the amplifier in a standard rack for 19" modules.
Assemble the modules by inserting them one on top of the other.

Make the connections between the **PS** module and the **RF** module using the cables supplied with the machine:

- Data connection by means of cable with DB37 connectors (PS-RF Interconnection)



- Ground connection between each module chassis



- Power supply connection by means of cable coming out of the **PS** module ending with the ILME CXM 4/2 type of socket (DC Output)



Figure 5-1 Example of installation in a rack

Connect the output of a suitable type of TV exciter (e.g. the DTVPE of R.V.R. Elettronica) to the RF input (**RF** module) using a cable fitted with N type connectors. The exciter should be set to minimum output power and OFF.

Connect the amplifier's INTERLOCK connector (on the back of the PS module) to the exciter's Interlock input, if available (it is available in all RVR Elettronica exciters) using a twin wire with BNC connectors.



Note: the amplifier's INTERLOCK connector is an output. The operating logic is as follows: the internal conductor floats when the amplifier works correctly, on the contrary power is delivered and the internal conductor is closed to ground to halt the exciter.

Connect the RF output to the antenna cable or to a dummy load capable of dissipating the power generated by the amplifier.

An ILME model CXF4/2 multipole socket is supplied with the amplifier to power the machine. The socket must be connected to the multipole cable that will be wired to the mains switchboard.



Danger: to avoid any risk of shock make ABSOLUTELY sure that the power supply cable is NOT powered when the multipole socket is connected to the cable itself.

Connect the multipole socket to the power supply cable as described below and refer to figure 5-2:

Three-phase power supply:

- G Ground
- 1 Neutral
- 2 R-Phase
- 3 S-Phase
- 4 T-Phase
- 11,12 Not connected




Figure 5-2: View of the mains multipole socket - terminals side (internal)

Single-phase power supply:

- G Ground
- 1 Not connected
- 2 Phase
- 3 Neutral
- 4 Not connected
- 11,12 Not connected



Danger: avoid the **risk of damaging the machine** by grounding it correctly. As such, connect the ground conductor of the power supply cable to the specific terminal in the multipole socket and check the efficiency of your own grounding system.

5.2 Operation

After having plugged in the power supply socket at the back of the machine, power on the amplifier via the switchboard. The ON LEDs on both modules will turn on and the forced cooling fans will start running. The LCD shows the first introductory screenful and then switches to a screenful that indicates the forward and reflected power values.

Turn on the exciter (at lowest power) and wait until it locks to the work frequency. Once locked, increase power gradually and check the amplifier's display. Increase the exciter's power until the amplifier's output attains the desired value, (keep in mind that due to the measurement digitalization effect it might not be possible to obtain a reading of exactly full-scale, but a lightly higher or lower value which is perfectly normal).

Now all of the machine's operating parameters may be checked via the software control system.

As a rule, the machine does not need to be manned to work. If any alarm conditions occur, they will be managed automatically by the protection system or notified to the user by means of LEDs on the panel and messages on the display.

5.3 Software

This chapter describes the ways in which the microprocessor controls the amplifier and how the user may interact with the software.

The figure in the follow shows the overall software user interface diagram.





Figure: Flow diagram of the software



Note: the user may issue commands to the equipment only when in LOCAL mode by means of the selector. Otherwise the user may only read the parameters and not change them.

When turned on, the LCD shows the introductory screenful with the equipment's software and hardware versions.



A few seconds later the main screenful is displayed indicating the forward and reflected power values:

```
Fwd Pwr 1.94 kW
Rfl Pwr  1.4  W
```

Press the ESC key to view the selection screenful from which to access all the menus:

```
Fnc Pwr P.A Set
Alm Mix Urs
```

To access one of the submenus select its name (which is underlined by a blinking cursor) using the RIGHT or LEFT keys and then press the ENTER key.

Take note that certain parameters, which are measured and shown to the user, might not be available in a few cases. This occurs when, for physical reasons, the measured vales are not significant for control software internal use.

When the value of a parameter is not available for the aforesaid reason, symbol “==” appears on the display in lieu of the value.

5.3.1 Operating Menu (Fnc)

```
On
Off
```

Turn the power amplifier ON or OFF via this menu.

When the amplifier is turned OFF, the internal conductor of the INTERLOCK connector is set to ground so as to force the connected exciter to a stand-by condition (this takes place only if the exciter features the interlock option, like those produced by RVR, and if the associated connector is connected to the amplifier).

When the amplifier is turned OFF the software program waits a few seconds for the machine to cool down and then the fans turn OFF.

5.3.2 Power Menu (Pwr)

This screen, made up of several lines that may be scrolled through using the UP and DOWN keys, displays all the measurements associated with the behaviour of the amplifier's power section:

- Forward Power (Fwd Pwr)
- Reflected Power (Rfl Pwr)
- SWR (Standing Wave Ratio)
- Input Power (Inp Pwr)
- Internal SWR (Int SWR)

Depending on the machine's configuration a few measurements might be disabled.

The figure below shows the complete aspect of this screen (only two lines can be seen at a time, use the UP and DOWN keys to scroll through it):

Fwd Pwr	2.94	KW
Rfl Pwr	1.4	W
SWR	Off	
Inp Pwr	21.2	W
Int SWR	Off	W

5.3.3 Power Amplifier Menu (P.A.)

This screen, consisting of several lines that may be scrolled through by using the UP and DOWN keys, displays all the measurements associated with the RF amplifier of the equipment:

- Voltage (VPA)
- Current (IPA)
- Efficiency
- Temperature
- Power Supply Voltage (Mains - percentage variation as compared to the nominal voltage)

The figure below shows the complete aspect of this screenful (only two lines can be seen at a time, use the UP and DOWN keys to scroll through it):

VPA	49.8	V
IPA	55.3	A
Eff.	68.3	%
Temp.	38.3	C
Mains	+1	%

5.3.4 Warning threshold setting menu

As mentioned in the introduction the amplifier offers three settable warning thresholds. Each one is compared with the level of one of the machine's operating parameters. The results of the comparison are available on the telemetry connector, on the contacts of the optional external telemetry card and may be read on the display as "O" (open, i.e. false result) or "C" (closed, i.e. real result).

Two of the settable thresholds (**Power Good**) refer to the emitted power level whereas the reflected power quantity (**Reflected Warning**) is checked for the third one.

Proceed as follows to change the values of the warning thresholds:

- Select the line to be changed (with the UP and DOWN keys)
- Press the ENTER key
- Change the threshold value (UP and DOWN keys)
- Press ENTER to confirm

The figure below shows a configuration example of this menu.

PwrGd1	>	80	%	0
PwrGd2	>	50	%	0
RflWar	>	40	%	0

In this example the alarm thresholds are as follows:

- PwrGd1 80%
- PwrGd2 50%
- RflWar 50%

5.3.5 Alarm Menu

This menu provides information about the status of the amplifier's built-in protection system.

It consists of a certain number of lines each of which contains the name of the variable controlled by the protection system and the type of intervention carried out by the system.

Said intervention may be as follows: **X - (Y)**, **Wait**, or **Dis.** (Disabled).

The aspect of this menu is as follows (only two lines can be seen at a time, use the UP and DOWN keys to scroll through it):

```
Fwd Pwr    0-(8)
Rfl Pwr    0-(8)
Inp Pwr    0-(8)
U.P.A.     Dis.
I.P.A.     0-(8)
Temp.      Wait
Int SWR    Dis.
Mains      Wait
SWR        Dis.
Eff.       Dis.
```

The task of this menu is essentially to help the technician in identifying the possible causes of any malfunction.

5.3.6 Miscellaneous Menu

In this menu the user may:

- set the address in the serial bus connection, type I²C
- set the main menu display mode

```
I2C Addr:   1
Display : Dig.
```

The network address I²C is very important when the amplifier is connected in an RVR transmission system that envisages the use of this protocol. Do not change it for any reason whatsoever.

The main menu may be displayed either in **Digital** mode (this is the standard mode) or **Analog** mode:



Rf 1 Pwr 1.4 ▴
■■

In the analog display mode a small triangle indicates the reflected power level set in the Alarm Threshold Setting Menu (RflWar), whereas the bar at the bottom shows the instant reflected power level.

This type of display might be useful when a device to be tuned is connected to the amplifier's output such as a cavity.

5.3.7 Version Menu

This screenful shows the hardware version (H.V.) and the software version (S.V.) of the equipment.



H.V. 1.01
S.V. 2.05

5.4 Protection System

The protection system implemented inside the amplifier is based on two types of intervention.

The first reaction is called "Foldback" and consists in decreasing the voltage in the power amplifier when the forward or reflected power exceeds the proportional limit voltage value. As such, the amplifier's gain is reduced and the overall result is an action that opposes the increase of the forward or reflected power. The yellow LED on the front panel indicates the tripping of the foldback circuit.



Note: in case the modulator has an adaptive precorrector, then it may be functioning in Foldback. Otherwise, for the laws in force, this feature is not permitted.

The second type of reaction consists in turning OFF the equipment's amplifying section when a specific variable exceeds a set value.

Depending on the type of event occurred, and after the amplifier has been turned OFF, it will be reactivated after a set length of time or only after the sharing, which caused the locking, has been cleared. In the alarm menu the first type of configuration is indicated by **X - (Y)**, whereas the second one is indicated by **Wait**. The third possibility is that the system does not trigger the protection conforming to a specific parameter: this is indicated by **Dis.** (Disabled).

While the amplifier is OFF temporarily owing to an alarm, the yellow WAIT LED lights up and the reason the protection was triggered is shown on the display.

When the protection system trips due to a “cyclic” type parameter, a counter begins counting up (the X value in the alarm menu). If the counter reaches the max admissible cycle value (Y), the amplifier turns OFF definitely and the red “FAULT” LED lights up on the front panel.

The user may press the ALARMS RESET key to interact with the protection system. The effect differs depending on the machine’s status when the key is pressed:

- If the equipment is off, waiting for the cycle time to be reached, or if it is definitively off in FAULT state, press the ALARMS RESET button to immediately turn the amplifier ON and reset the alarm counters.
- If the system is transmitting but alarms were triggered earlier causing certain counters not to be at “0”, pressing the key will have no effect unless it is pressed while inside the alarm menu. As such, the system will be sure that the user takes note of the alarms that were triggered before resetting them.

The system resets the alarm counters automatically after thirty minutes of operation, i.e. the user need not do anything, if the amplifier does not trigger any alarms or after the machine has been turned OFF and then back ON.

5.4.1 RF module auxiliary protection

The amplifier’s RF module contains a second microcontroller that manages local measurements and carries out auxiliary protection functions of the machine together with the main protection system. This microcontroller card indicates its interventions via the LEDs of the RF module.

A delivered power automatic back-off mechanism is envisaged for excess temperature, SWR or current absorbed by a MOSFET module. The yellow FOLDBACK LED indicates this case.

A FAULT signal is triggered (red LED) when a fault occurs that stops the power amplifier. This situation is signaled to the machine’s main microcontroller as well and triggers a lock situation (FAULT).

The LED FUSE BLOWN indicates that one of the fuses that protects the power supply of the MOSFET modules has blown. In this case the machine keeps running as usual (obviously without the contribution of the module) even if it is advisable to single out and clear the cause for the malfunction and replace the fuse as soon as possible to fully restore the machine’s working efficiency.



Note: The RESET button on PS module, resets the auxiliary protections of the RF module too.


5.4.2 Power Supply Units

Three power supply units, which work in parallel mode, power the machine. Should one of the power supply units malfunction, the machine automatically reduces the delivered power down to a value compatible with the current deliverable from the surviving power supply. This situation is indicated by the “P.S. ALARMS” LEDs on the front panel of the PS module.

6 External Description


This chapter describes the elements presents on the panels of the **DTVPA**.

6.1 PS Module Frontal Panel



- | | |
|------------------|---|
| [1] AIR FLOW | Grill for the ventilation flow passage |
| [2] ON | Green LED indicating the amplifier is switched on |
| [3] WAIT | Yellow LED indicating the amplifier is waiting for a condition that is blocking the power output to be removed |
| [4] FAULT | Red LED indicating that a fault that cannot be automatically reverted |
| [5] LOCAL | Yellow LED, indicating that the amplifier is in local control mode |
| [6] FOLDBACK | Yellow LED, indicating that the foldback function is active (automatic reduction of the distributed power). NOT USED IF THE MODULATOR HAS AN ADAPTIVE PRECORRECTOR. |
| [7] CONTRAST | Trimmer to regulate the contrast of the LCD display |
| [8] DISPLAY | LCD display |
| [9] ALARM RESET | Button used to manually reset the protection system |
| [10] P.S. ALARMS | Yellow LEDs, indicating the presence of a anomaly on one or more power supply boards |
| [11] LOC/REM | Switch to select the local or remote control modes |
| [12] ESC | Button used to exit from a menu |
| [13] LEFT/UP | Button used to navigate in the menu system and to modify the changeable parameters |
| [14] RIGHT/DOWN | Button used to navigate in the menu system and to modify the changeable parameters |
| [15] ENTER | Button used to accept a parameter's value or to enter into a menu |

6.2 PS module Rear Panel




- | | |
|---------------------------|---|
| [1] MAINS FUSE | Protection fuses of the power supplies 1,2 and 3 |
| [2] MAINS CONNECTOR | Plug for mains power supply |
| [3] AIR FLOW | Grill for the ventilation flow passage |
| [4] RS232 | DB9 connector to interface with external devices or factory programming |
| [5] I²C BUS | DB9 connector for I²C bus networking |
| [6] INTERCONNECTION PS-RF | DB37 connector for interfacement with RF part |
| [7] COM BUS | DB15 connector for interfacement with other equipment |
| [8] TELEMETRY | DB25 telemetry connector |
| [9] AUX OUT FUSE | Protection fuse of the auxiliary plug |
| [10] SERVICE FUSE | Protection fuse for the service section |
| [11] INTERLOCK | BNC connectors to inhibit an external device, as an exciter. In case of fault, the inner connector is shorted to ground |
| [12] DC OUTPUT | Presenza per l'alimentazione della parte RF |
| [13] AUX OUT AC LINE | Auxiliary VDE plug to supply external devices (typically an exciter) |

6.3 Connector Description

6.3.1 Telemetry Connector

Type: DB25 Female



1	Internal SWR	Disabled
2	RF power amplifier voltage	3,9V x 50V
3	GND	GND
4	Reflected Power	4.3V x 150W
5	Interlock	
6	Set 4	
7	GND	GND
8	"On" Command	
9	Set 1	
10	WAIT	
11	Reset alarm	
12	OFF	
13	Interlock	
14	Temperature	3.9V x 80°
15	RF power amplifier current	3.9V x 110A
16	Forward Power	4.3V x 2500W
17	FAULT	
18	Set 3	
19	Input power	4.3V x 10W
20	"OFF" Command	
21	GND	GND
22	Set 2	
23	LOC	
24	+Vcc	
25	ON	

6.3.2 RS 232


Type: DB9 female



1	NC
2	TX_D
3	RX_D
4	Internally connected with 6
5	GND
6	Internally connected with 4
7	Internally connected with 8
8	Internally connected with 7
9	NC

6.3.3 I²C Connector


Type: DB9 Female



1	NC	
2	SDA	Serial Data
3	SCL	Serial Clock
4	NC	
5	GND	GND
6	NC	
7	NC	
8	NC	
9	NC	

6.3.4 Com Bus


Type: DB15 male



1	GND
2	485+
3	485-
4	GND
5	ON OFF C
6	INP PWR
7	ST BY
8	IRQ
9	GND
10	PWR REG
11	GND
12	NC
13	NC
14	NC
15	NC


6.3.5 Interconnection PS-RF

Type: DB37 female




- | | |
|----|---|
| 1 | GND, Internally connected with 12/14/15/23/25/26/28/31/33 |
| 2 | V TOT |
| 3 | R PWR |
| 4 | TEMP |
| 5 | PS OFF |
| 6 | PS REG |
| 7 | PWR REG |
| 8 | ON OFF |
| 9 | IRQ |
| 10 | CLIX |
| 11 | RESET AL |
| 12 | GND, Internally connected with 1/14/15/23/25/26/28/31/33 |
| 13 | 485+ |
| 14 | GND, Internally connected with 1/12/15/23/25/26/28/31/33 |
| 15 | GND, Internally connected with 1/12/14/23/25/26/28/31/33 |
| 16 | NC |
| 17 | AC3, Internally connected with 35 |
| 18 | NC |
| 20 | I TOT |
| 19 | AC4, Internally connected with 37 |
| 21 | F PWR |
| 22 | INP PWR |
| 23 | GND, Internally connected with 1/12/14/15/25/26/28/31/33 |
| 24 | PS STATUS |
| 25 | GND, Internally connected with 1/12/14/15/23/26/28/31/33 |
| 26 | GND, Internally connected with 1/12/14/15/23/25/28/31/33 |
| 27 | ST BY |
| 28 | GND, Internally connected with 1/12/14/15/23/25/26/31/33 |
| 29 | FAULT |
| 30 | FUSE PS |
| 31 | GND, Internally connected with 1/12/14/15/23/25/26/28/33 |
| 32 | 485- |
| 33 | GND, Internally connected with 1/12/14/15/23/25/26/28/31 |
| 34 | NC |
| 35 | AC3, Internally connected with 17 |
| 36 | NC |
| 37 | AC4, Internally connected with 19 |

6.4 RF Module Frontal Panel



- | | |
|----------------|--|
| [1] AIR FLOW | Grill for the ventilation flow passage |
| [2] FAULT | Red LED that indicates a fault that cannot be automatically reverted |
| [3] FUSE BLOWN | Red LED that indicates the presence of one or more broken fuses |
| [4] RF PWR ADJ | Not used |
| [5] ON | Green LED indicating that the amplifier is switched on |
| [6] FOLDBACK | Yellow LED indicating that the foldback function is active (automatic reduction of the distributed power) |
| [7] RF TEST | BNC connector for RF monitor output. The output level is referred to the power output in 180-215 MHz range |

6.5 RF module Rear Panel



[1] INTERCONNECTION PS-RF

DB37 connector for interfacement with PS part

[2]

DB9 connector reserved for future uses

[3] RF IN

RF input connector ("N" type)

[4] RF IN TEST

Not used.

[5] PLUG

Plug for the supply of 50V_{DC} incoming from module PS

[6] AIR FLOW


Grill for the ventilation flow passage

[7] RF OUT

RF output connector (7/8" EIA flange)

6.5.1 Interconnection PS-RF

Type: DB37 female



- | | |
|----|---|
| 1 | GND, internally connected with 12/14/15/23/25/26/28/31/33 |
| 2 | V TOT |
| 3 | R PWR |
| 4 | TEMP |
| 5 | PS OFF |
| 6 | PS REG |
| 7 | PWR REG |
| 8 | ON OFF |
| 9 | IRQ |
| 10 | CLIX |
| 11 | RESET AL |
| 12 | GND, internally connected with 1/14/15/23/25/26/28/31/33 |
| 13 | 485+ |
| 14 | GND, internally connected with 1/12/15/23/25/26/28/31/33 |
| 15 | GND, internally connected with 1/12/14/23/25/26/28/31/33 |
| 16 | NC |
| 17 | AC3, internally connected with 35 |
| 18 | NC |
| 20 | I TOT |
| 19 | AC4, internally connected with 37 |
| 21 | F PWR |
| 22 | INP PWR |
| 23 | GND, internally connected with 1/12/14/15/25/26/28/31/33 |
| 24 | PS STATUS |
| 25 | GND, internally connected with 1/12/14/15/23/26/28/31/33 |
| 26 | GND, internally connected with 1/12/14/15/23/25/28/31/33 |
| 27 | ST BY |
| 28 | GND, internally connected with 1/12/14/15/23/25/26/31/33 |
| 29 | FAULT |
| 30 | FUSE PS |
| 31 | GND, internally connected with 1/12/14/15/23/25/26/28/33 |
| 32 | 485- |
| 33 | GND, internally connected with 1/12/14/15/23/25/26/28/31 |
| 34 | NC |
| 35 | AC3, internally connected with 17 |
| 36 | NC |
| 37 | AC4, internally connected with Internamente connesso con 19 |


7. Technical Specifications

			DTVPA800UV1		DTVPA1K1UP1		
Parameters	Conditions	U.M.	GENERALS			Notes	
Frequency range		MHz	180-210			70-88	
Rated output power		W	800 (potenza erogata in tecnologia di modulazione 8VSB)			1100 (potenza erogata in tecnologia di modulazione 8VSB)	
Input power for rated output		W	1,2			1,2	
Power supply type			monophase/biphase			monophase/biphase and threephase	
AC Supply Voltage	Mains input voltage range	VAC	230 +10%-15%(*) or 115/400 +10%-15% (**)			230 +10%-15%(*) or 115/400 +10%-15% (**)	
DC Supply Voltage	CPU backup Input Voltage	VDC					
AC Apparent Power Consumption		VA	About 3500			2720 (3ph with N @ 220V)	
Active Power Consumption		W	About 3600			2611 (3ph with N @ 220V)	
RF Fan active Power consumption		W	100			100	
RF module efficiency		%	24			24	
Overall efficiency		%					
Input device			5 pushbutton			5 pushbutton	
Display			Alphanumerical LCD - 2 x 16			Alphanumerical LCD - 2 x 16	
Overall Physical Dimensions	Front panel width	mm	483 (19")			483 (19")	
	Front panel height	HE	3+3			3+3	
	Overall depth	mm	695			695	
Ambient working temperature		°C	0 to + 50 (operational -10)			0 to + 40	
Spurious & harmonic suppression		dBc	In according to output filter			In according to output filter	
Meets or exceeds all FCC and COR rules							
RF INPUT							
RF Input	Connector		N type			N type	
	Impedance	Ohm	50			50	
Driver power for rated output		W	1,2			1,2	
Max input power before protection		W	50			50	
RF OUTPUTS							
RF Output	Connector		7/8"flange type			7/8"flange type	
	Impedance	Ohm	50			50	
RF Monitor	Connector		BNC			BNC	
	Impedance	Ohm	50			50	
	Output Level	dB	approx. -60			approx. -60	
Referred to the RF output							
AUXILIARY CONNECTIONS							
Interlock Output	Connector		BNC			BNC	
RS232 Serial Interface	Connector		DB9F			DB9F	
Com Bus	Connector		DB15M			DB15M	
PCbus	Connector		DB9F			DB9F	
Telemetry Interface	Connector		DB25F			DB25F	
RS485 Serial Interface	Connector						
Remote Interface	Connector						
AUX power supply	Connector		VDE F			VDE F	
for exciter mains supply							
POWER REQUIREMENTS							
AC Power Input	AC Supply Voltage	VAC	230 +10%-15%(*) or 115/400 +10%-15% (**)			230 +10%-15%(*) or 115/400 +10%-15% (**)	
	AC Apparent Power Consumption	VA	About 3500			2720 (3ph with N @ 220V)	
	Active Power Consumption	W	About 3600			2611 (3ph with N @ 220V)	
	Power Factor		0,98			0,96 (3ph with N @ 220V)	
DC Power Input	Connector		ILME CFX 4/2			ILME CFX 4/2	
	DC Supply Voltage	VDC					
	DC Current	mADC					
FUSES							
On Mains			3 External fuses F16T 10x38 (Threephases 400V) 3 External fuses F20T 10x38 (Threephases 230V) 3 External fuses F25T 10x38 (Monophase 230V)			3 External fuses F16T 10x38 (Threephases 400V) 3 External fuses F20T 10x38 (Threephases 230V) 3 External fuses F25T 10x38 (Monophase 230V)	
On services			1 External fuse F 6,3 T 5 x 20			1 External fuse F 6,3 T 5 x 20	
On AUX Power supply			1 External fuse F 6,3 T 5 x 20			1 External fuse F 6,3 T 5 x 20	
On P.A. Supply			8 Internal fuses F 16 LCT 10 x 38			8 Internal fuses F 16 LCT 10 x 38	
On fans Supply			1 Internal fuse F 10 T 5 x 20			1 Internal fuse F 12,5 T 5 x 20	
MECHANICAL DIMENSIONS							
Phisical Dimensions	Front panel width	mm	483			483	
	Front panel height	mm	2 x 132			2 x 132	
	Overall depth	mm	695			695	
	Chassis depth	mm	650			650	
Weigh		kg	about 55			about 55	
21 PS+34 RF							
OPTIONS							
Internal Driver		code	/LD			/LD	
TELEMETRY / TELECONTROL							
Telemetry connector inputs	Pulse		Command ON			Command ON	
	Pulse		Command OFF			Command OFF	
	Pulse		Alarm Reset			Alarm Reset	
	Analogical level		FWD power			4,3V x 1500W	
	Analogical level		REF power			4,3V x 150W	
	Analogical level		Internal SWR			Disabled	
	Analogical level		Input power			3,9V x 10W	
	Analogical level		VPA			3,9V x 50V	
	Analogical level		IPA			3,9V x 80A	
	Analogical level		Temperature			3,9V x 100°C	
	Open Collector		Status ON			Status ON	
	Open Collector		Status OFF			Status OFF	
	Open Collector		Power Good 1			Power Good 1	
	Open Collector		Power Good 2			Power Good 2	
	Telemetry connector outputs	Open Collector		SWR			SWR
Open Collector			Wait			Wait	
Open Collector			Fault			Fault	
Open Collector			Local			Local	
ON / OFF level			Interlock			Interlock	
TELEMETRY-TELECONTROL SW							
Telecon							
VARIOUS							
Cooling type			Forced with internal fans			Forced with internal fans	
Potenza dissipata in calore		W	1930				
Acoustic Noise		dBA	78			78	
Leq 3 min @ 1 m							
STANDARD COMPLIANCE							
Safety			EN60215:1989			EN60215:1989	
EMC			EN 301 489-11 V1, 2, 1			EN 301 489-11 V1, 2, 1	
Spectrum Optimization							

8. Operating theory


The figure shows the PS and the RF part of amplifier seen from above. The various cards are described in this chapter.

- Top View of PS section with PFC:



- 1) Interface Power Supply Board
- 2) Varistors Board
- 3) PFC Board
- 4) Power Supply Board
- 5) CPU Board + Protection Interface Board
- 6) LEDs Board

- Top view of RF section




- 1) Input Power Measure
- 1) Driver Board + Driver Bias Board
- 2) Amplifier Modules
- 3) Fuses Board
- 4) Bias Boards + CPU Board
- 5) LEDs Boards

8.1 Power Supply Change

To use the amplifier with different types of power supply you should connect the mains power supply socket as outlined in chapter 5. Also modify the connections inside as explained below.

8.1.1 Single-Phase Wiring




WARNING: the single-phase power supply may be used only with 208/230 Volts.

The single-phase wiring must have the following characteristics:

- PIN1 of the main connector is directly connected to neutral wire.
- PIN2 of the main connector is directly connected to phase wire and internally connected to PIN3.
- PIN3 of the main connector is internally connected via cable to the PIN4 and PIN2.
- PIN4 of the main connector is internally connected via cable to the PIN3.
- PIN5 of the main connector is directly connected to ground.

8.1.2 Three-Phase Wiring



The three-phase wiring must have the following characteristics:

- PIN1 of the main connector is directly connected to neutral wire.
- PIN2 of the main connector is directly connected to R-phase wire.
- PIN3 of the main connector is directly connected to S-phase wire.
- PIN4 of the main connector is directly connected to T-phase wire..
- PIN5 of the main connector is directly connected to ground.

8.1.3 Voltage Change



WARNING: the single-phase power supply may be used only with 208/230 Volts.

Proceed as follows to change voltage inside the machine:

- Make the JP3 connection, on the Rectifier card, between PIN 1 and 2 to select 230 Volts, or between PIN 2 and 3 for 115 Volts.





Figure 8-1: Connection for the selection of 115 or 208/230 Volts

- In order to select the 230 Volts on the connector inside the PS section near the transformer, make the connection between PIN 3 and 4 and PIN 6 and 7, or between PIN 2 and 3 and PIN 5 and 6 for 115 Volts.





Figure 8-2: Connection for the selection of 115V or 208/230V three fase with neutral wire

8.2 PS Part

8.2.1 Surge Protection

This card's main function is to avoid any damage to the internal cards by blocking the contact before current reaches the equipment in case overvoltages occur.

8.2.2 Power Supply

The three power supply modules are located in the middle part of the amplifier. The power supply units are mounted on a cooling fin to cool the amplifier by forced ventilation.

The amplifier houses a transformer the input voltage of which may be selected between 115 and 230 Volts.

The transformer is fitted with three secondary wires: A) 18-0-18 V, B) 0-17 V, C) 0-11.5 V that supply power to the cards inside the equipment.

8.2.3 PFC Unit or Rectifier

The PFC unit is a rectifier that modulates the current absorbed so that the wave

shape is the most possible sinusoidal, obtaining a factor of power of 99%.

The PFC can work with input supply voltages from 90 V to 250 V. A rectified voltage of 350 V is present on the output.

In place of PFC units, can be installed “traditional” rectifiers units (without power factor corrector). Its task is to rectify and stabilize the shape of the voltage produced by the power supply modules by fixing the voltage value to the value required by the internal circuitry.

This card also applies a resistive load when the amplifier is turned on and excludes said load after a short time to reduce current peaks in the transformer on turning it on (*SOFT-START*).

8.2.4 PS-RF Interface Board

This interface board is installed at the back of the amplifier for collecting the main signals of the machine and making them available on the connectors. This interface is connected to the three rectifiers, the CPU, the fans, the transformer from which it receives the signals and to which it issues commands.

This interface card is designed to make the PS part communicate with the RF part and making available the dedicated signals at the specific connector for each part.

8.2.5 LEDs Board

Three LEDs are present on this board for indicating the operating status of the three power supply modules.

The lighting up of a LED indicates a malfunction in the associated module.

8.2.6 CPU

This subsystem is made up of three cards: the CPU card, the display card and the analog card.

The CPU subsystem implements all the software functions (measurements, protection, control, data display, communications) outlined in the previous chapters.

This card carries the signals to the DB25 telemetry connector that is on the machine's back panel. The connector is fitted with 7 analog outputs, 8 open-collector digital outputs and 4 digital inputs. It also manages the DB9 signals associated with the RS232 connector, for interfacing with other equipment and for

the default programming functions, and the DB9 connector for communications in I²C standard.

8.3 RF Part

8.3.1 RF Power Amplifier

The RF power amplifying section consists in 8 power modules coupled by a Wilkinson splitter and combiner and implemented in strip-line technology and hybrid -3dB 90°.

The RF modules, the splitter and the combiner are housed inside the top part of the equipment.

The whole RF section is mounted on the fin that cools the equipment by means of forced ventilation.

Each RF module supplies 125 watts with 4 to 6 pilot power watts and is powered by the switching PSU.

The modules' operating parameters in standby are as follows:

VDC=50V Vgs=2,9-3,7V Idq=1,4A

The active device used in the amplifier modules is a SD2942 Mosfet.

8.3.2 Wilkinson Splitter and Combiner

Both the splitter and the combiner are made in strip-line technology and hybrid -3dB 90°.

The splitter is used for splitting power arriving from the exciter and supplying one part to each of the RF modules.

The combiner is then used to combine power output from each module to obtain the amplifier's total power.

The two cards ensure equal phases among the powers generated by the RF modules in two groups of "4+4". One power resistance is used for dissipating the offset power that might be present in case a module breaks down.

8.3.3 Bias Board

The task of this card is to check and to intervene the bias voltage of the Mosfets in the RF amplification section.

This card also supplies the following measurements: current and voltage of each module, total current and average voltage.

The bias card is also fitted with the temperature sensor which is monitored by the software.

8.3.4 Directional Coupler

The task of these two cards that seem identical is to supply the power measurement. They are installed on the input RF connector on the inside of the machine. One card supplies the amplifier's forward power whereas the other one supplies the reflected power.

8.3.5 Control Board

The control board acts as an auxiliary card for the PROTf card in the PS section should the latter fail to trip due to a malfunction. It implements all the functions associated with measurements, protection, control and communications and is even capable of detecting the individual voltages or currents inside the machine, in addition to the overall ones.

If pre-arranged, this Board can carry the signals to the DB9 connector located on the machine's back panel in RS485 standard.

8.3.6 LEDs Board

This card is fitted with 4 warning LEDs that indicate the machine's general operating status.

It also has a trimmer for adjusting power (AGC control). Use a small screwdriver to change the delivered power.

8.3.7 Driver Board

The driver board contains an RF amplifier with only one stage that, with a power of about 1-2W, can supply an output power of approximately 60W suitable to pilot **DTVPA**, with a total gain of approximately 28dB.

The active device utilized in the amplifier modules is a Mosfet (SD2942) and uses for the feeding the same voltage of 50VDC used from the eight RF amplifiers modules.

On the output stage of this board is present a directional coupler that measure the reflected and forward power; the latest comes acquired from the control software that represents it legible like input power.