



ELA 4170 user manual




* the latest user manual can be found online on the www.cimkezo.hu/en/ela-4170-manual



Content

ELA 4170 user manual	1
ELA 4170 2.1 Sending conveyor	4
2.1.1 Use of the sending conveyor	4
2.1.2 Guide rails adjustment	5
2.1.3 Pressing roll	5
ELA 4170 2.2 Guide rails	6
2.2.1 Rotators	6
2.2.2 Guide rails adjusting	7
2.2.3 Pack clamping plate	8
ELA 4170 2.3 Servo transfer modul	9
2.3.1 Sponge roll, brush setup	9
2.3.2 The positioning part should be adjusted to the left of the cigarette	10
2.3.3 Cross brush adjusting	11
2.3.4 Servo home position	12
2.3.5 Setting position sensor for step-conveyor	13
2.3.6 Produkt position sensor	13
ELA 4170 2.3.1 Servo transfer modul (serial Nr.006525)	14
ELA 4170 2.4 Collecting conveyor	16
2.4.1 Collecting conveyor	16
2.4.2 Sensor adjusting.	17
ELA 4170 2.5 Stickers applicator	18
2.5.1 Adjusting position of labeling applicator	19
2.5.2 Product sensor adjustment	20
ELA 4170 2.6 Operator panel	21
2.6.1 Touch screen operator panel handling	21
2.6.2 Main screen	21
2.6.3 Service menu	22
2.6.4 Parameters	23
2.6.5 Emergency button	24
2.6.6 Alarm log	25
ELA-4170 Spare parts list	26

ELA 4170 2.1 Sending conveyor



2.1.1 Use of the sending conveyor



This conveyor is for put the cigarettes into the system.

Two operators can work on this part at the same time.



After opening the original pack, the operator puts it on the conveyor. Push the packs to the limiter guide.

2.1.2 Guide rails adjustment



The guides could be adjusted to steer the packs.




The limiter guides with no knobs is the fix level. The other guide should be adjusted min 10mm wider than the cigarette pack length. Incorrect adjustment can cause jam!

2.1.3 Pressing roll



This sponge roll is for guarantee the equal distance between the packs. (The distance is required for the sensing) It prevents the manual pushing of pack. The vertical position can be adjusted with the wheel.

ELA 4170 2.2 Guide rails



2.2.1 Rotators



The rotators are used to rotate the packs to the right direction after the sending conveyor.

The first rotator are used by FRONT and the SIDE stickering.

By TOP stickering deactivate it. In this case activate the second rotator after stickering.

The second rotator should not adjust if the pack size

doesn't changes.

Adjust it only the direction shows teh red arrow.

2.2.2 Guide rails adjusting




Adjusting of the guider is very important, because it controls the stickering precision. Set is as close together as possible. Ensure the free movement of the pack between the guides. !!!



1. Loose the knobs or the screws
2. Move the guides to the right position.



2.2.3 Pack clamping plate



This plate is used for clamping the pack to the conveyor avoid the slip. It guarantees the stickering precision.

Adjusting option:

1. Pressing strength: Rotate the knob to adjust the pressing strength. Do not adjust it too strength, because it can stop the pack on the conveyor.



2. Length direction: Adjust the plate as close as possible to the dispensing beak.


3. Vertical direction: Set very low angle between the plate and the pack.

4. Cross direction: Set it the center of the cigarette.


5. Draft angle adjustment: Loose the screw nut and rotate the rod. After that fasten the screw nut.

ELA 4170 2.3 Servo transfer modul

2.3.1 Sponge roll, brush setup



The sponge roll and the braking brush should be adjusted into the right position. The roll presses the pack and holds it in the right position. It prevents the pack from continuing. The other pack will push it under the transfer unit.




The braking brush is for slowing down the pack and stopping it in the right position.

2.3.2 The positioning part should be adjusted to the length of the cigarette.



1. Loose the screws
 2. Move into the right position and fasten the screws.
- Do not adjust it too tight, because it can cause jam. Caution! If big distance is adjusted the pack can rotate and it can also cause jam.



2.3.3 Cross brush adjusting



This part used for slow down the high speed packs, and prevent the rotation. The precise adjusting is necessary, because the packs can rotate and jammed packs can stop the whole system.




5 pack groups with right adjustment.

2.3.4 Servo home position



The servo transfer belt should be set to the home position. Press the SERVO HOMING button in the parameters menu. The cleat will move to the main position.




2.3.5 Setting position sensor for step-conveyor





2.3.6 Produkt position sensor



ELA 4170 2.3.1 Servo transfer modul (serial Nr.006525)






ELA 4170 2.4 Collecting conveyor

2.4.1 Collecting conveyor



This conveyor prepare 5 packs groups for max 4 re-bounding operators. After received the fifth pack the conveyor makes one step. The operators can easily pull side the groups and put into the re-bounding machine.




2.4.2 Sensor adjusting.



This sensor sense the position of the ribs. The sensing distance is max 2mm, so the correct adjustment is very important. Caution! The collision can crash the sensor. The position of the ribs can be adjusted to move the sensor into the slot.

ELA 4170 2.5 Stickers applicator


*** HERMA H400**



2.5.1 Adjusting position of labeling applicator



Verical adjusment



Side position adjustment



Pivoting

2.5.2 Product sensor adjustment



For moving the sticker position use the sensor adjustment instead of adjusting the stickering head. In the stickering head should be adjusted the smallest strat delay as possible. The sensor should be opposite to the reflector. Caution! The IR beam must go through the hole on the guides.



For adjusting loose the srew and move the sensor to the right position.


ELA 4170 2.6 Operator panel

2.6.1 Touch creen operator panel handling




1. Shows the main functions
2. Start and stop the machine
3. Adjusting the parameters
4. Error/Alarm logging

2.6.2 Main screen



1. START – Start the system. (The stickering head should be separate switch on/off)
2. STOP – Stop the whole system
3. Conveyor1 – Sending Conveyor speed
4. Conveyor2 – Sticking conveyor speed



5. ALARM – Error log
6. SERVICE – Service menu – Parameter setting

2.6.3 Service menu



2.6.3.1 Buttons:

1. Conveyor3 step – Step one onto the collecting conveyor
2. Servo homing – Move the servo home position
3. Conveyor 12 start – Manual start of the conveyor 1 and 2.
4. Main – Back to the Main menu


2.6.3.2 Parameters

1. Conveyor 12 acc – Start acceleration of the 1,2 conveyor in (ms).
2. Conveyor 12 dec- Stop deceleration of the 1,2 conveyor in (ms).
3. Conveyor 3 speed – Stepping speed of the 3(collecting) conveyor (Hz)
4. Servo speed – Servo collector speed [Hz]
5. Servo home speed – Servo speed on manual homing function [Hz]
6. Conveyor 12 rate – Inactive!
7. Servo home step – Servo module position [pulse]
8. Servo full step – Servo moving distance [pulse]
9. Servo acc – Servo acceleration [ms]
10. Servo dec – servo deceleration [ms]


2.6.4 Parameters




After pressing the parameter value field, a numeric keyboard appears to input the value.



2.6.5 Emergency button




After activating one of Emergency button, the system stops and a popup window will appear on the screen.




The reset function works only after deactivating the Emergency button. After deactivating the Emergency Button, the system does not start automatically. Required to press the start button.


2.6.6 Alarm log



If the alarm log is empty the Alarm button is blue. In case of alarm the button will be red. Press the button to open the log window.













In the table shows the all alarm with time and state.













To empty the log press the RESET button.






ELA-4170 Spare parts list

	Description	Part nr.:
	Conveyor Belt (Short) 200x2235mm	
	Conveyor Belt (Long) 200x3835mm	
	Cleated conveyor belt 400x5235mm	
	Timing belt pulley T5 Z20-27	300100- 006525
	Bearing SKF 6002 ZZ	SKF6002ZZ- 006525

	<p>Stepper motor 4.0 Nm</p>	<p>STP4.0N- 006525</p>
	<p>Stepper motor 6,4 Nm</p>	<p>STP6.4N- 006525</p>
	<p>Timing belt T5 330x16mm</p>	<p>300100- 006525</p>
	<p>Timing belt pulley for Servo drive</p>	<p>6011- 006525</p>
	<p>Timing belt for servo T2.5</p>	<p>6012- 006525</p>

	<p>Cleated timing belt</p>	<p>6017-006525</p>
	<p>Timing belt pulley for Servo drive (motor side)</p>	
	<p>Mitsubishi SERVO Drive</p>	<p>Servo-006525</p>
	<p>MR-E- SERVO Controller</p>	<p>MR-E-006525</p>
	<p>MSD 80 5.6 Stepper driver</p>	<p>MSD80-5.6AI-006525</p>

	<p>MSD 80 5.6Ai Stepper driver</p>	<p>MSD80-5.6- 006525</p>
	<p>Schneider- Electric MODICON- M238 PLC</p>	<p>SCH-M238- 006525</p>
	<p>Schneider- Electric HMI STU665</p>	<p>SCH-HMI- 006525</p>
	<p>Shaft Encoder Res: 2000pulse</p>	<p>ENCR2000- 006525</p>
	<p>Label sensor (HERMA FS03)</p>	<p>680229- 006525</p>

	<p>Proximity switch Fotek</p>	<p>Sens-prox- 006525</p>
	<p>Schneider- Electric xum9apcnl2 Optical sensor</p>	<p>SCH- OPT_006525</p>
	<p>Sponge roll (For sending conveyor)</p>	<p>7101-4017- 006525</p>
	<p>Sponge roll (for the servo side)</p>	
	<p>Braking brush</p>	<p>6075- 006525</p>