



SERVICE MANUAL

**Room Airconditioner
Split Wall-Mounted Type**



**FSI Art-100HFD
FSI Art-180HFD**

NOTE:

Before servicing the unit, please read this at first.
Always contact with your service center if meet problem.

FI_SM_FSI Art_100_180HFD_090917

Content

1.	Precaution	1
2.	Function	3
3.	Dimension	5
4.	Specification	6
5.	Refrigerant cycle diagram	8
6.	Wiring diagram	9
7.	Installation details	11
7.1	Wrench torque sheet for installation	11
7.2	Connecting the cables	11
7.3	Pipe length and elevation	11
7.4	Air purging of the piping and indoor unit	12
7.5	Pumping down (Re-installation)	13
7.6	Re-air purging (Re-installation)	14
7.7	Balance refrigerant of the 2-way, 3-way valves	15
7.8	Evacuation	15
7.9	Gas charging	17
8.	Electronic function	18
8.1	Abbreviation	18
8.2	Display function	18
8.3	Protection	19
8.4	Fan only mode	19
8.5	Cooling mode	20
8.6	Dehumidifying mode	21
8.7	Heating mode	21
8.8	Auto mode	25
8.9	Force cooling function	25
8.10	Action of 4-way valve	26
8.11	To speed outdoor fan function	26
8.12	Timer mode	26
8.13	Sleep mode	26
8.14	Auto restart function	27
8.15	Ionizer	27
8.16	Self clean function	27
8.17	Follow me function	27
8.18	Outdoor unit heating cable function (option)	28

9	Troubleshooting	29
	9.1 Indoor Unit Error Display	30
	9.2 Diagnosis and Soéution	31
	9.3 Key parts checking	34
12	Exploded wiew	35

1. Precaution

1.1 Safety Precaution

■ **To prevent injury to the user or other people and property damage, the following instructions must be followed.**

■ **Incorrect operation due to ignoring instruction will cause harm or damage.**

■ **Before service unit, be sure to read this service manual at first.**

1.2 Warning

➤ Installation

■ **Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.**
There is risk of fire or electric shock.

■ **For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized service center.**

Do not disassemble or repair the product, there is risk of fire or electric shock.

■ **Always ground the product.**

There is risk of fire or electric shock.

■ **Install the panel and the cover of control box securely.**

There is risk of fire of electric shock.

■ **Always install a dedicated circuit and breaker.**
Improper wiring or installation may cause fore or electric shock.

■ **Use the correctly rated breaker of fuse.**

There is risk of fire or electric shock.

■ **Do not modify or extend the power cable.**

There is risk of fire or electric shock.

■ **Do not install, remove, or reinstall the unit by yourself (customer).**

There is risk of fire, electric shock, explosion, or injury.

■ **Be caution when unpacking and installing the product.**

Sharp edges could cause injury, be especially careful of the case edges and the fins on the condenser and evaporator.

■ **For installation, always contact the dealer or an Authorized service center.**

There is risk of fire, electric shock, explosion, or injury.

■ **Do not install the product on a defective installation stand.**

It may cause injury, accident, or damage to the

product.

■ **Be sure the installation area does not deteriorate with age.**

If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.

■ **Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.**

Moisture may condense and wet or damage furniture.

■ **Take care to ensure that power cable could not be pulled out or damaged during operation.**

There is risk of fire or electric shock.

■ **Do not place anything on the power cable.**

There is risk of fire or electric shock.

■ **Do not plug or unplug the power supply plug during operation.**

There is risk of fire or electric shock.

■ **Do not touch (operation) the product with wet hands.**

There is risk of fire or electric shock.

■ **Do not place a heater or other appliance near the power cable.**

There is risk of fire and electric shock.

■ **Do not allow water to run into electric parts.**

It may cause fire, failure of the product, or electric shock.

■ **Do not store or use flammable gas or combustible near the product.**

There is risk of fire or failure of product.

■ **Do not use the product in a tightly closed space for a long time.**

Oxygen deficiency could occur.

■ **When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.**

Do not use the telephone or turn switches on or off. There is risk of explosion or fire.

■ **If strange sounds, or small or smoke comes from product. Turn the breaker off or disconnect the power supply cable.**

There is risk of electric shock or fire.

■ **Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.**

There is risk of property damage, failure of product, or electric shock.

- **Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)**

There is risk of physical injury, electric shock, or product failure.

- **When the product is soaked (flooded or submerged), contact an Authorized service center.**

There is risk of fire or electric shock.

- **Be caution that water could not enter the product.**

There is risk of fire, electric shock, or product damage.

- **Ventilate the product from time to time when operating it together with a stove, etc.**

There is risk of fire or electric shock.

- **Turn the main power off when cleaning or maintaining the product.**

There is risk of electric shock.

- **When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.**

There is risk of product damage or failure, or unintended operation.

- **Take care to ensure that nobody could step on or fall onto the outdoor unit.**

This could result in personal injury and product damage.

➤ CAUTION

- **Always check for gas (refrigerant) leakage after installation or repair of product.**

Low refrigerant levels may cause failure of product.

- **Install the drain hose to ensure that water is drained away properly.**

A bad connection may cause water leakage.

- **Keep level even when installing the product.**

To avoid vibration or water leakage.

- **Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.**

It may cause a problem for your neighbors.

- **Use two or more people to lift and transport the product.**

Avoid personal injury.

- **Do not install the product where it will be exposed to sea wind (salt spray) directly.**

It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

➤ Operational

- **Do not expose the skin directly to cool air for long periods of time. (Do not sit in the draft).**

This could harm to your health.

- **Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigerant system.**

There is risk of damage or loss of property.

- **Do not block the inlet or outlet of air flow.**

It may cause product failure.

- **Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.**

There is risk of fire, electric shock, or damage to the plastic parts of the product.

- **Do not touch the metal parts of the product when removing the air filter. They are very sharp.**

There is risk of personal injury.

- **Do not step on or put anything on the product. (outdoor units)**

There is risk of personal injury and failure of product.

- **Always insert the filter securely. Clean the filter every two weeks or more often if necessary.**

A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

- **Do not insert hands or other object through air inlet or outlet while the product is operated.**

There are sharp and moving parts that could cause personal injury.

- **Do not drink the water drained from the product.**

It is not sanitary could cause serious health issues.

- **Use a firm stool or ladder when cleaning or maintaining the product.**

Be careful and avoid personal injury.

- **Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.**

There is risk of fire or explosion.


- **Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.**


They may burn or explode.

- **If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.**

The chemical in batteries could cause burns or other health hazards


2. Function





3. Dimension


3.1 Indoor Unit



Model	W	H	D
FSIArt-100HFD	900	285	160
FSIArt-180HFD	1022	295	185

3.2 Outdoor Unit

FSIArt-100HFD, FSIArt-180HFD




4. Specification

Model			FSIArt-100HFD	FSIArt-180HFD
Power supply		Ph-V-Hz	1,220-240V~,50Hz	1,220-240V~,50Hz
Cooling	Capacity	W	2800(900~3370)	5300(1800~6450)
	Input	W	730(280~1100)	1640(530~2300)
	Rated current	A	3.2(1.3~4.8)	7.2(2.4~9.8)
	EER	W/W	3,83	3.23
Heating	Capacity	W	3000(970~3660)	5300(1880~6740)
	Input	W	690(300~1150)	1460(480~2000)
	Rated current	A	3.1(1.4~5.0)	6.5(2.3~9.0)
	COP	w/w	4,34	3.63
Moisture Removal		L/h	0,8	1.5
Max. input consumption		W	1750	2950
Max. current		A	8,0	13.5
Starting current		A	5,0	10
Compressor	Model		DA108X1C-20FZ3	C-6RVN93H0N
	Type		Rotary	Rotary
	Brand		TOSHIBA	SANYO
	Capacity	W	10918	5830
	Input	W	855	1430
	Rated current(RLA)	A	5,3	7,46
	Locked rotor Amp(LRA)	A	8	10,7
	Thermal protector		CS-74	1NT11L-3979
	Capacitor	uF	No	No
	Refrigerant oil	ml	480	ESTER OIL VG74 750ml
Indoor fan motor	Model		RPG20D	RPG28D
	Brand		Welling	Welling
	Input	W	43	51
	Capacitor	uF	1,5	1,5
	Speed	r/min	1290/1250/1000/900/700	1280/1260/1080/900/750
Indoor coil	a.Number of rows		2	2
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37
	c.Fin spacing	mm	1,4	1,3
	d.Fin type (code)		Hydrophilic aluminium	Hydrophilic aluminium
	e.Tube outside dia.and type	mm	Φ7,innergroove tube	Φ7,innergroove tube
	f.Coil length x height x width	mm	676x336x26.74	804x336x26.74
	g.Number of circuits		2	4
Indoor air flow (Hi/Mi/Lo)		m3/h	600/500/400	870/730/520
Indoor noise level (Hi/Mi/Lo)		dB(A)	38/34/28	42/37/32

Indoor unit	Dimension (W*H*D)	mm	900×285×160	1022×295×185
	Packing (W*H*D)	mm	990×375×250	1105×385×275
	Net/Gross weight	Kg	9/11.5	12/15.5
Outdoor fan motor	Model		YDK24-6G	YDK50-6C
	Brand		Welling	Welling
	Input	W	59	111/96
	Capacitor	uF	2,5	2.5
	Speed	r/min	800/550	890/540
Outdoor coil	a.Number of rows		2	2
	b.Tube pitch(a)x row pitch(b)	mm	22x19	21×13.37
	c.Fin spacing	mm	1,4	1,4
	d.Fin type (code)		hydrophilic aluminium	Hydrophilic aluminium
	e.Tube outside dia.and type	mm	Φ7.94,innergroove tube	Φ7, innergroove tube
	f.Coil length x height x width	mm	656x550x38	655×546×26.74
	g.Number of circuits		2	2
Outdoor air flow		m3/h	2000	2200
Outdoor noise level		dB(A)	54	56
Outdoor unit	Dimension(W*H*D)	mm	760×590×285	760×590×285
	Packing (W*H*D)	mm	887×655×355	887×655×355
	Net/Gross weight	Kg	40.5/43	40/42.5
Refrigerant type R410A		g	1100	1100
Design pressure		MPa	4,2	4.2
Refrigerant piping	Liquid side/ Gas side	mm	Φ6.35/Φ9.53	Φ6.35/Φ12.7
	Max. refrigerant pipe length	m	20	25
	Max. difference in level	m	8	10
Thermostat type			Electronic control	Electronic control
Operation temp		°C	17 ~ 30	17 ~ 30
Ambient temp cooling/heating		°C	-15 ~ 50 / -15 ~ 34	-15 ~ 50 / -15 ~ 34

Notes:Specification are subject to change without prior notice for product improvement.


5. Refrigerant cycle diagram




6. Wiring diagram

6.1 Indoor Unit


FSIArt-100HFD



FSIArt-180HFD



FSIArt-100HFD



7. Installation details

7.1 Wrench torque sheet for installation

Outside diameter		Torque
mm	inch	Kgf.m
Φ6.35	1/4	1.8
Φ9.52	3/8	4.2
Φ12.7	1/2	5.5

7.2 Connecting the cables

The power cord of connect should be selected according to the following specifications sheet.



Unit	FSIArt-100HFD	FSIArt-180HFD
mm ²	3x1,5	3x2,5

Communication wire between the indoor and outdoor unit:

Unit	FSIArt-100HFD	FSIArt-180HFD
mm ²	4x1,5	4x2,5

7.3 Pipe length and the elevation

Model	Pipe size		Standard length (m)	Max. Elevation B (m)	Max. Length A (m)	Additional refrigerant (g/m)
	Gas	Liquid				
FSIArt-100HFD	3/8" (Φ9.52)	1/4" (Φ6.35)	5	8	20	30
FSIArt-180HFD	1/2" (Φ12.7)	1/4" (Φ6.35)	5	10	25	30



Caution:

Capacity is based on standard length and maximum allowance length is base of reliability.

Oil trap should be installed per 5-8 meters, (but not definitely needed).

7.4 Air purging of the piping and indoor unit


Required tools:

Hexagonal wrench; adjustable wrench; torque wrenches, wrench to hold the joints and gas leak detector.

Note:

The air in the indoor unit and in the piping must be purged. If air remains in the refrigeration piping, it will affect the compressor, reduce the cooling capacity, and could lead to a malfunction of unit.

Be sure, using a torque wrench to tighten the service port cap (after using the service port), so that it prevents the gas leakage from the refrigeration cycle.



Procedure

1. Recheck the piping connections.
2. Open the valve stem of the 2-way valve counterclockwise approximately 90°, wait 10 seconds, and then set it to closed position.

Be sure to use a hexagonal wrench to operate the valve stem.

3. Check for gas leakage.

Check the flare connection for gas leakage

4. Purge the air from the system.

Set the 2-way valve to the open position and remove the cap from the 3-way valve's service port.

Using the hexagonal wrench to press the valve core pin, discharge for three seconds and then wait for one minute.

5. Use torque wrench to tighten the service port cap to a torque of 1.8 kgf.m. (18N.m)

6. Set the 3-way valve to the opened position.

7. Mounted the valve stem nuts to the 2-way and 3-way valves.

8. Check for gas leakage.

At this time, especially check for gas leakage from the 2-way and 3-way stem nuts, and from the service port.


Caution:

If gas leakage is discovered in step (3) above, take the following measures.

If the leaks stop when the piping connections are tightened further, continue working from step (4).

If the gas leaks do not stop when the connections are retightened, repair the location of the leak, discharge all of the gas through the service port, and then recharge with the specified amount of gas from a gas cylinder.

7.5 Pumping down (Re-installation)



Procedure

1. Confirm that both the 2-way and 3-way valves are set to the opened position.

Remove the valve stem caps and confirm that the valve stems are in the opened position.

Be sure to use a hexagonal wrench to operate the valve stems.

2. Operate the unit for 10 to 15 minutes.

3. Stop operation and wait for 3 minutes, then connect the charge set to the service port of the 3-way valve.

Connect the charge hose with the push pin to the gas service port.

5. Air purging of the charge hose.

Open the low-pressure valve on the charge set slightly to purge air from the charge hose.

6. Set the 2-way valve to the close position.

7. Operate the air conditioner at the cooling cycle and stop it when the gauge indicates 0.1MPa.

8. Immediately set the 3-way valve to the closed position.


Do this quickly so that the gauge ends up indicating 0.3 to 0.5Mpa.

Disconnect the charge set, and amount the 2-way and 3-way valve's stem nuts and service port caps.

Use a torque wrench to tighten the service port cap to a torque of 1.8 kgf.m.

Be sure to check for gas leakage.

7.6 Re-air purging (Re-installation)



Procedure:

1. Confirm that both the 2-way and 3-way valves are set to the closed position.
2. Connect the charge set and a charging cylinder to the service port of the 3-way valve.

Leave the valve on the charging cylinder closed.

3. Air purging.

Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45° for 3 seconds then closing it for 1 minute; repeat 3 times.

After purging the air, use a torque wrench to tighten the flare nut to on the 2-way valve.

4. Check the gas leakage.

Check the flare connections for gas leakage.

5. Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant until the gauge indicates 0.3 to 0.5 Mpa.

6. Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position.


Be sure to use a hexagonal wrench to operate the valve stems.

7. Mount the valve stems nuts and the service port cap.

Be sure to use a torque wrench to tighten the service port cap to a torque 18N.m.

Be sure to check the gas leakage.

7.7 Balance refrigerant of the 2-way, 3-way valves



Procedure:

1. Confirm that both the 2-way and 3-way valves are set to the open position.
2. Connect the charge set to the 3-way valve's service port.

Leave the valve on the charge set closed.


Connect the charge hose with the push pin to the service port.

3. Open the valves (Low side) on the charge set and discharge the refrigerant until the gauge indicates 0.05 to 0.1Mpa.

If there is no air in the refrigeration cycle [the pressure when the air conditioner is not running is higher than 0.1Mpa, discharge the refrigerant until the gauge indicates 0.05 to 0.1 Mpa. If this is the case, it will not be necessary to apply an evacuation.

Discharge the refrigeration gradually; if it is discharged too suddenly, the refrigeration oil still be discharged.

7.8 Evacuation



Procedure:

1. Connect the vacuum pump to the charge set's centre hose.
2. Evacuation for approximately one hour.


Confirm that the gauge needle has moved toward -0.1 Mpa (-76 cmHg) [vacuum of 4 mmHg or less].

3. Close the valve (Low side) on the charge set, turn off the vacuum pump, and confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).

4. Disconnect the charge hose from the vacuum pump.

Vacuum pump oil, if the vacuum pump oil becomes dirty or depleted, replenish as needed.

7.9 Gas charging



Procedure:

1. Connect the charge hose to the charging cylinder.

Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder.

2. Purge the air from the charge hose.

Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

3. Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.

If the system cannot be charge with the specified amount of refrigerant, it can be charged with a little at a time (approximately 150g each time) while operating the air conditioner in the cooling cycle; however, one time is not sufficient, wait approximately 1 minute and then repeat the procedure.(pumping down-pin).

4. Immediately disconnect the charge hose from the 3-way valve's service port.

Stopping partway will allow the refrigerant to be discharged.

If the system has been charged with liquid refrigerant while operating the air conditioner, turn off the air conditioner before disconnecting the hose.

5. Mounted the valve stem caps and the service port

Use torque wrench to tighten the service port cap to a torque of 18N.m.

Be sure to check for gas leakage.

8. Electronic function

8.1 Abbreviation

T1: Indoor ambient temperature

T2: Pipe temperature of indoor heat exchanger







T3: Pipe temperature of outdoor heat exchanger

T4: Outdoor ambient temperature

8.2 Display function

8.2.1 Icon explanation on indoor display board.



	Lights up when the super ionizer function is energized.
	This indicator illuminates when TIMER is set ON/OFF.
	This indicator illuminates when the air conditioner starts defrosting automatically or when the warm air control feature is activated in heating mode.
	This indicator illuminates when the air conditioner is in AUTO operation.
	Usually it displays the setting temperature. It will display the room temperature when the air conditioner is in FAN only operation. It will display "SC" when self-clean function is activated. It will also display the malfunction code or protection code.
	This indicator appears only when the compressor is in operation and indicates the current operating frequency.

8.3 Protection

8.3.1 Three Minutes Delay at restart for compressor.

8.3.2 Temperature protection of compressor top.

If the temperature of compressor top is too high (higher than 115°C and the Over-load Protector is cut, the units stop.

When the Over-load Protector restore and close (lower than 100°C), the compressor will restart (In this case the compressor is restricted by Three Minutes Delay protection.)

8.3.3 Temperature protection of compressor exhaust.

If the exhaust temp. of compressor is higher than 115°C and lasts for 5 seconds, the compressor stops and does not resume until the exhaust temp. is lower than 90°C.

8.3.4 Inverter module Protection, Inverter module Protection itself has a protection function against current, voltage and temperature. If these protections happened, the corresponding code will display on indoor unit LED.

8.3.5 Sensor protection at open circuit and breaking disconnection

8.3.6 Fan Speed is out of control. When Indoor Fan Speed is too low (lower than 300RPM for 50 seconds), the unit stops and LED displays failure information and can't return to normal operation automatically.

8.3.7 Zero-crossing signal error warning.

If there is no zero-crossing signal in 4 minutes or the interval is wrong, the unit will enter error warning.

8.3.8 For all modes, when the units are turned on, the indoor fan can operate 10 seconds after the action of louver.

8.3.9 Compressor preheating function.

Preheating permitting condition:

If T_4 (outdoor ambient temperature) $< 3^\circ\text{C}$ and the machine connects to power supply newly or if $T_4 < 3^\circ\text{C}$ and compressor has stopped for over 3 hours, the compressor heating cable will work.

Preheating mode:

A weak current flow through the coil of compressor from the wiring terminal of compressor, then the compressor is heated without operation.

Preheating release condition:


If $T_4 > 5^\circ\text{C}$ or user turns on the machine and compressor runs, preheating function will stop.

8.4 Fan-Only Mode

8.4.1 Temperature setting function is disabled, and no setting temperature display.


8.4.2 In this mode, the action of louver is the same as in cooling mode.

8.4.3 The action of auto fan in fan-only mode is the same as auto fan in cooling mode with 24°C setting temperature.



8.5 Cooling Mode

8.5.1 The operation frequency of compressor after starting submits to following rule.



When the machine is running and ΔT (=room temp. – setting temp.) changes, the frequency of compressor will rise or descend a grade (7 minutes after starting).

After starting, if ΔT stays in a zone for 3 minutes, the frequency will change as follow:

Zone A : Current frequency rise a grade till the maximum grade F8.

Zone B: Keep the current frequency of compressor.


Zone C: Descend the current frequency of compressor until F1.

Zone D: Compressor stops after running as the minimum frequency F1 for 60 minutes or ΔT is less than -2°C .

8.5.2 Indoor heat exchanger anti-freezing function.

If T_2 is lower than 0°C , the compressor stops and resumes when $T_2 > 5^{\circ}\text{C}$.

8.5.3 Outdoor unit current control in cooling mode.



8.5.4 Rating capacity test function

- 1) Set the indoor unit with remote controller as: high fan, 17°C in cooling mode, then press “TURBO” button on controller 6 times or more within 10 seconds (make sure indoor unit receives these signals), the machine will turn into rating capacity test mode, the buzzer will make a “di” sound for 2 seconds continuously. Also, indoor fan will change to rating speed, the frequency of compressor will be fixed as rating value. Any condition of above is not satisfied, the machine cannot be turned into rating capacity test mode.
- 2) The machine will quit from the rating capacity test mode if running for 5 hours or changing fan speed or setting temperature.

8.5.5 Turbo function (press the "TURBO" button on remote controller)

Elevate current frequency to a higher grade.


Indoor fan turns to turbo speed.

After running for 30 minutes the machine will turn back to previous setting mode.

8.5.6 Indoor fan operation rule.

In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto.

Auto fan in cooling mode acts as follow:



8.5.7 Condenser high temperature protection function (in cooling and drying mode)

If $T_3 > 60^\circ\text{C}$ for 5 seconds, compressor will stop immediately, and the machine will not resume until $T_3 < 52^\circ\text{C}$.

8.6 Drying mode

8.6.1 Indoor fan speed is fixed at breeze grade and can't be changed. The horizontal angle is the same as in cooling mode.

8.6.2 Room overflow temperature protection

In drying mode, if room temperature is lower than 10°C , compressor will stop and not resume until room temperature climbs up to 12°C .


8.6.3 Evaporator anti-freezing protection, condenser high temperature protection and outdoor unit frequency limit are valid, and they are the same as that in cooling mode.

8.6.4 Horizontal louver action is the same as that in cooling mode.

8.7 Heating mode


8.7.1 Indoor fan action:

Anti-cold-wind function.




If the compressor stops caused by room temperature rising, indoor fan will be forced to run 127 seconds with breeze. During this period, anti-cold-wind is disabled. After this, anti-cold –wind function is available. If the machine runs in rating capacity test mode, indoor fan runs with rating speed, and anti-cold-wind is disabled.

8.7.2 Indoor fan speed can be set as high, medium, low or auto grade, but anti-cold-wind function is preferential. Auto fan action in heating mode.




8.7.3 The operation frequency of compressor after starting submits to following rule:



When the machine runs, if ΔTh stays in a zone for 3 minutes, action of frequency is as follow:

- Zone A: Elevate the current frequency one grade, and not stop until the maximum grade.
- Zone B: Keep the current frequency.
- Zone C: Descend the current frequency one grade.
- Zone D: Compressor stops after running with F1 for 60 minutes or when $\Delta Th > 6^{\circ}\text{C}$.

8.7.4 Outdoor unit current control in heating mode.



8.7.5 Indoor heat exchanger high temperature protection.

If $T_2 > 60^{\circ}\text{C}$, the compressor will stop and not resume until $T_2 < 48^{\circ}\text{C}$.

8.7.6 Defrosting mode.

Condition of defrosting.

Condition 1: If $T_4 > 0^{\circ}\text{C}$,

When the units are running, if the following two items are satisfied the units start defrosting:

The units runs with $T_3 < 3^{\circ}\text{C}$ for 40 minutes and T_3 keeps lower than -6°C for more than 3 minutes.

The units runs with $T_3 < 3^{\circ}\text{C}$ for 80 minutes and T_3 keeps lower than -4°C for more than 3 minutes.

Condition 2: If $T_4 < 0^{\circ}\text{C}$,

The program judges according to the condition 1, if the two items are satisfied, then judges if T_2 has descended for more than 5°C , if it has the machine starts defrosting, or continues to judge T_2 and will not defrost until T_2 drops more than 5°C .

Condition 3: No matter what value T_4 is, if the machine runs with $T_3 < 3^{\circ}\text{C}$ for more than 120 minutes and T_3 keeps

lower than -2°C for more than 3 minutes, the machine will defrost, no matter if T_2 drops for more than 5°C or not.

Condition of ending defrosting.


If any one of following items is satisfied, defrosting will finish and the machine will turn to normal heating mode.

T_3 rises to be higher than 12°C .

T_3 rises to be higher than 8°C and remains for 80 seconds.

The machine has run for 10 minutes in defrosting.

8.7.7 Defrosting action



8.7.8 Rating capacity test function.

Set the indoor unit with remote controller as: high fan, 30°C in heating mode, then press “TURBO” button on controller 6 times or more within 10 seconds (make sure indoor unit receives these signals), the machine will turn into rating capacity test mode, the buzzer will make a “di” sound for 2 seconds continuously. Also, indoor fan will change to rating speed, the frequency of compressor will be fixed as rating value. Any condition of above is not satisfied, the machine cannot be turned into rating capacity test mode.

The machine will quit from the rating capacity test mode if running for 5 hours or changing fan speed or setting temperature.

8.7.9 Turbo function in heating mode. (press the “TURBO” button on remote controller)

Elevate current frequency (excluding F8) to a higher grade. If indoor fan is in low speed or pause caused by defrosting or anti-cold-wind function, frequency of compressor will not be elevated one grade until these limit has been released.

Indoor fan changes to turbo speed and anti-cold-wind function is valid.

8.8 Auto mode function

8.8.1 This mode can be chosen with remote controller and the setting temperature can be changed between 17~30°C.

In auto mode, the machine will choose cooling, heating or fan-only mode according to ΔT ($\Delta T = T1 - Ts$).

$\Delta T = T1 - Ts$	Running mode
$\Delta T > 1^\circ\text{C}$	Cooling
$-1 \leq \Delta T \leq 1^\circ\text{C}$	Fan-only
$\Delta T < -1^\circ\text{C}$	Heating

8.8.2 Indoor fan will choose auto speed of relevant mode.

8.8.3 If the machine switches mode between heating and cooling, compressor will keep stopping for 15 minutes and then rechoose mode according to ΔT .

8.8.4 If the setting temperature is modified, the machine will rechoose running function.

8.9 Forced operation function

8.9.1 Forced cooling and auto function can be carried out through a touch button. In these two modes, the machine can be changed by remote controller to any other mode at any moment.

8.9.2 When the machine is off, pressing the touch button will carry the machine to forced auto mode, after this, if pressing the button once again within 5 seconds, the machine will turn into forced cooling mode. In forced auto, forced cooling or any other operation mode, pressing touch button will turn off the machine. In forced operation, remote control is available.

8.9.3 In forced operation mode, all general protections are available.

8.9.4 In forced cooling mode, after running for 30 minutes with compressor frequency F2 and breeze indoor fan speed, the machine will turn to normal auto mode in which setting temperature is 24°C.



8.9.5 The action of forced auto mode is the same as normal auto mode which temperature is 24°C.

8.10 Action of 4-way valve

In heating, fan-only, standby or turning off mode, 4-way valve is off, while in cooling, drying and forced cooling mode 4-way valve is on. If the machine changes operation mode from heating to cooling and drying and forced cooling mode, 4-way valve will be delayed off 2 minutes after compressor stop. If the machine changes operation mode from non-heating mode to heating mode, the 4-way valve will be turned off immediately.

8.11 Two speeds outdoor fan function

8.11.1 Outdoor fan action in heating mode(including heating in auto mode).



8.11.2 Outdoor fan action in cooling & drying mode(including cooling in auto & forced mode).

Please refer to the pic. above.

8.12 Timer function

8.12.1 Timing range is 24 hours, and the setting time is the relative time.

8.12.2 Timer on.

After turning off, the machine will turn on automatically when reaching the setting time.

8.12.3 Timer off.

After turning on, the machine will turn off automatically when reaching the setting time.

8.12.4 Timer on/off.

After turning off, the machine will turn on automatically when reaching the setting "on" time, and then turn off automatically when reaching the setting "off" time.

8.12.5 Timer off/on.

After turning on, the machine will turn off automatically when reaching the setting "off" time, and then turn on automatically when reaching the setting "on" time.

8.12.6 Timer function will be eliminated when the unit is turned off by remote controller.

8.13 Sleep function mode

8.13.1 Operation time in sleep mode is 7 hours. The unit will quit from this mode and be turned off in 7 hours.

8.13.2 In cooling, heating or auto mode sleep function is available.

8.13.3 Operation process in sleep mode is as follow:

After pressing SLEEP button on remoter controller, the machine will get into sleep mode.

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hour later the rising stops and indoor fan is fixed as low speed.

When heating, the setting temperature descends 1°C (be lower than 30°C) every one hour, 2 hour later the descending stops and indoor fan is fixed as low speed, and anti-cold-wind is available.

8.13.4 If user uses timer on function in sleep mode, sleep function will pause and not resume until reaches the setting on time.

8.13.5 When user uses timer off function in sleep mode(or sleep function in timer off mode), if the timing time is less than 7 hours, sleep function will be cancelled when reaching the setting time. If the timing time is more than 7 hours, the machine will not stop until reaches the setting off time in sleep mode.

8.14 Auto-Restart function

In case of a sudden power failure, the indoor main chip will restore the setting conditions before the power failure. The unit will resume the previous operation setting (including setting mode, temperature, fan speed, vertical swing) automatically after 3 minutes when power returns.

8.15 Super Ionizer function

Super ionizer function which is controlled through remote controller is available only when the unit is on.

After the Aircon being turned on, the Ionizer function is switched on when the unit receives CODE from remote controller at first time, and ionizer is switched off when the unit receives the CODE again. It's a circle.

After starting the Ionizer function, the ionizer can work only when the indoor fan motor is running. If the indoor fan motor is off, the ionizer also stops working, even though the Ionizer function is available. Ionizer function will not be off when the running mode is switched. Ionizer function will be off when the unit is turned off.

8.16 Self-clean function

1) Self-Clean function is available only at cooling (including auto-cooling and turbo) and drying mode, when the user presses down the button "Self-Clean" on remote controller, "SC" icon will be displayed on the indoor temperature display area. After running for 13 minutes in low fan mode, the unit will get into low heating mode (anti-cold wind function is not valid). When the unit keeps low heating mode for 1 min or evaporator high temp protection occurs, it will stop heating and get into low fan mode and keep running for another 2 minutes. Then the unit will quit from Self-Clean function and turn off.

2) When setting the Self-Clean function, the unit has been in Timer or Turbo function, the Timer or Turbo function will be cancelled and then execute Self-Clean function.

3) When the unit is running Self-Clean function, all other functions will be not available except swing/air direction/clean air/vent/LED display, and only receiving "Self-Clean" code again or "turn off" code, the unit will quit from the function.

4) When the unit is running Self-Clean function, all protection functions are valid.

8.17 Follow me function

If the indoor PCB receives the signal which results from pressing the FOLLOW ME button on remote controller, the buzzer will emit a sound and this indicates the follow me function is initiated. But when the indoor PCB receives signal which sent from remote controller every 3 minutes, the buzzer will not respond. When the unit is running with follow me function, the PCB will control the unit according to the temperature from follow me signal, and the temperature collection function of room temperature sensor will be shielded, but the error detective function of room temperature sensor will be still valid.

When the follow me function is available, the PCB will control the unit according to the room temperature (T1) from the remote controller and the setting temperature (TS), and the action of compressor is as following:

At cooling mode, if $T1 < TS$, compressor is off; If $T1 \geq TS$, compressor is on.

At heating mode, if $T1 > TS$, compressor is off; If $T1 \leq TS$, compressor is on.

The PCB will take action to the mode change information from remote controller signal, but it will not be affected by the setting temperature.

When the unit is running with follow me function, if the PCB doesn't receive any signal from remote controller for 7 minutes or pressing FOLLOW ME button again, the follow me function will be turned off automatically, and the temperature collection function of room temperature sensor will be available, the PCB will control the unit according to the room temperature detected from its own room temperature sensor and setting temperature.


8.18 Outdoor heating cable (Optional)

A heating cable can be fixed on outdoor chassis to help deicing and to avoid freezing. Another heating cable can be fixed around compressor to help starting the compressor. These heating cables are useful to improve the performance of the air conditioner especially when the outdoor ambient temperature is very low. The rated power voltage for the heating cables is 220V-240V. The action of the heating cables is controlled by the PCB. If outdoor temperature is lower than 5°C , the heating cable will begin to work. If outdoor temperature is higher than 15°C , the heating cable will stop working.

9. Troubleshooting

Safety


Because there are capacitors in PCB and relative circuit in outdoor unit, even shut down the power supply, electricity power are still kept in capacitors, do not forget to discharge the electricity power in capacitor.



Electrolytic Capacitors

(HIGH VOLTAGE! CAUTION!)

Bulb (25-40W)




9.1 Indoor Unit Error Display

Display	LED STATUS
E0	EEPROM parameter error
E1	Indoor / outdoor units communication protection
E2	Zero-crossing signal error
E3	Indoor fan speed out of control
E5	Open or short circuit of outdoor temperature sensors
E6	Open or short circuit of indoor temperature sensors
P0	Inverter module protection---IGBT over-strong current protection
P1	Over voltage or too low voltage protection
P2	Temperature protection of compressor top.
P4	Inverter compressor drive error


Note: E4 & P3: Reserved function

9.2 Diagnosis and Solution


9.2.1 E0 (EEPROM parameter error) error diagnosis and solution




9.2.2 E1 (indoor / outdoor units communication protection) error diagnosis and solution




9.2.3 E2(zero-crossing signal error) diagnosis and solution




9.2.4 E3(indoor fan speed out of control) diagnosis and solution




9.2.5 E5(Open or short circuit of outdoor ambient or condenser temperature sensor) diagnosis and solution.




9.2.6 E6(open or short circuit of indoor room or evaporator temperature sensor) diagnosis and solution.




9.2.7 P0(IGBT over-strong current protection) diagnosis and solution.




9.2.8 P1(over voltage or too low voltage protection) diagnosis and solution.



9.2.9 P2(temperature protection of compressor top) diagnosis and solution.



9.2.10 P4(inverter compressor drive error) diagnosis and solution.



9.3 Checking for temperature sensors

Room temp.(T1) sensor,
Indoor coil temp.(T2) sensor,
Outdoor coil temp.(T3) sensor,
Outdoor ambient temp.(T4) sensor,
Compressor exhaust temp.(Te) sensor.

Measure the resistance value of each winding by using the multi-meter.


Some frequently-used R-T data for T1,T2,T3 and T4 sensor:

Temperature (°C)	5	10	15	20	25	30	40	50	60
Resistance Value (KΩ)	26.9	20.7	16.1	12.6	10	8	5.2	3.5	2.4


Some frequently-used R-T data for Te sensor:

Temperature (°C)	5	15	25	35	60	70	80	90	100
Resistance Value (KΩ)	141.6	88	56.1	36.6	13.8	9.7	6.9	5	3.7

KΩ



FSI Art-100HFD indoor




No.	Part Name	Quantity	BOM Code
1	panel assembly	1	201132590304
1,1	panel	1	P0000350947
1,2	panel bolt	2	P0000350949
1,3	panel shackles	1	201232590012
2	Air cleaner	1	201130100212
	Air cleaner holder	1	201130100217
3	Left air filter	1	201132590297
4	Right air filter	1	201132590296
5	Screw cap	3	201132590303
6	Window cover for repairing	1	201132590298
7	Display board enclosure	1	203332390422
8	panel 's Mandril	1	201132590292
9	driven swing connector	2	201132590300
10	panel frame	1	201132590301
10,1	initiative swing connector	2	P0000354085
10,2	Louver motor	1	202400200054
	Louver motor cover	2	201132590289
10,3	panel frame	1	P0000354080

11	Air out frame assembly	1	201132590327
11,1	Vertical airflow louver	1	201132590295
11,2	Horizontal airflow grille	10	P0000349541
	Grille holder	2	P0000349544
11,3	Ion engender	1	202403000021
11,4	Air out frame	1	P0000350724
11,5	Horizontal louver bolt	1	201132590294
	Holder	2	201133190032
		1	201102010015
11,6	stepping motor	1	202400200006
	axis	1	201131390149
12	lash-up switch cover	1	201132590293
13	Drain Hose	1	201130000011
14	Evaporator	1	201532390081
15	Connecting pipe clamp	1	201232500001
16	Baffle of temperature induction	1	201130490002
17	Motor cover	1	201132590299
18	fan motor	1	202400300215
19	Bearing holder	1	202730100201
20	Cross flow fan	1	201100200120
21	Chassis	1	201132590305
22	Installation plate	1	201232390012
23	Electric control assy	1	203332390424
23,8	E-part box cover	1	201132390371
23,7	Wire Clip	1	201130100209
23,6	Chip	1	201300731546
	Main control board	1	201332390506
23,5	Electronic control box	1	201132390370
23,4	terminal	1	202301450119
23,3	transformer	1	202300900176
23,2	Indoor temp sensor	1	202433190000
23,1	Pipe Temp sensor	1	202301300080
23,9	Wire clamp	1	201135210303
24	Remote controller	1	203355090362
25	Holder,remote controller	1	201155060529
26	Copper nut	1	201600320000
27	Copper nut	1	201600320001
28	connector for watering	1	201101020011
29	seal	1	202720090001

No.	Part Name	Quantity	BOM code
1	Indoor temp sensor	1	202301300160
2	Rear net	1	2011374G0003
3	condenser coil assembly	1	201537390033
4	Pipe Temperature Sensor	1	202440500004
5	valve plate	1	201235120614
6	base pan assembly	1	201237590027
7	Big handle	1	201135000005
8	Water collector	1	201135270201
9	Right clapboard	1	201235270204
10	clip, capacitor	1	201200100002
11	Capacitor,Compressor	1	202401090055
12	partition plate assembly	1	201237590008
13	front panel	1	201237400029
14	Front net	1	201137590000
15	motor mounting bracket	1	201237500005
16	axial flow fan	1	201100300502
17	Left supporter	1	201237400028
18	Small handle	1	201150290006
19	top cover assembly	1	201235270249

20	motor	1	202400400477
21	Reactor	1	202301000820
22	Cover for inductance assembly	1	201235250802
23	Reactor	1	202301000819
24	electrical box assembly	1	203337390134
24,1	E-Parts box	1	201237300171
24,2	Radiator	1	202301900068
24,3	E-Parts box's cover	1	201237300162
24,4	Main control board	1	201337390055
24,5	Holder for E-parts	1	201137300162
25	board of terminal,assy	1	203337390043
25,1	Wire joint	1	202301450113
25,2	Washer for wire joint	1	201135000004
25,3	Wire clamp	1	201219900001
25,4	board of terminal	1	201237590009
26	liquid valve assembly	1	201637390335
26,1	Liquid valve	1	201600740523
27	Low Pressure Valve Ass'y	1	201632390037
27,1	4-Ways valve	1	201600670003
27,2	Gas pipe valve	1	201600720200
28	sound-proof materiall	1	202137300000
29	rotary compressor	1	201400620600
30	sound-proof material	1	202137390006
	Indoor temp sensor	1	202301300079
	Low ambient kit	1	201319900490


FSIArt-180HFD indoor



No.	Part Name	Quantity	BOM Code
1	Front panel	1	201132890178
2	Display board assy	1	201132890167
		1	201319900062
3	Air cleaner holder	1	201130100217
	Air cleaner	1	201130100212
4	Right air filter	1	201132890173
5	Left air filter	1	201132890174
6	Screw cap	3	201132890172
7	Window cover for repairing	1	201132890168
8	Panel frame assy	1	201132890170
9	Flap	1	201132890176
10	Air out frame assy	1	201132890193
11	Louver motor	1	202400200006
12	lash-up switch cover	1	201132890169
13	Drain hose	1	201130000011
14	Evaporator,assy	1	201532890029
15	Motor cover	1	201132890175
16	Motor	1	202400300415
17	Bearing holder	1	202730100201

18	Cross flow fan	1	201100200107
19	chassis	1	201132890180
20	Connecting pipe clamp	1	201232800001
21	Installation plate	1	201232790008
22	Electronic control box,indoor unit	1	203332890138
22,1	E-Parts box	1	201132890148
22,2	E-Parts box's cover	1	201132890147
22,3	Main control board	1	201332890093
22,4	Wire Clip	1	201135210303
22,5	Indoor temp sensor	1	202433190000
22,6	Evaporator temp sensor	1	202301300080
22,7	Wire joint, 5p	1	202301450119
22,8	Transformer	1	202300900176
23	Remote Controller	1	203355090362
24	Holder,remote controller	1	201155060529
25	Copper nut, TLM-A01	1	201600320000
26	Copper nut, TLM-C03	1	201600320002
27	connector for watering	1	201101020011
28	seal	1	202720090001

FSIART-180HFD outdoor



No.	Part Name	Quantity	BOM code
1	Indoor temp sensor	1	202301300057
2	Rear net	1	2011374G0003
3	condenser coil assembly	1	201537890023
4	Pipe Temperature Sensor	1	202440500004
5	valve plate	1	201235120614
6	base pan assembly	1	20123789G006
7	Big handle	1	201135000005
8	Water collector	1	201135270201
9	Right clapboard	1	201235270204
10	clip, capacitor	1	201200100002
11	Capacitor,Compressor	1	202401090055
12	partition plate assembly	1	20123789G003
13	front panel	1	201237890018
14	Front net	1	201137890001
15	motor mounting bracket	1	201237890037
16	axial flow fan	1	201100300514
17	Left supporter	1	201237400028
18	Small handle	1	201150290006
19	top cover assembly	1	201235270249

20	motor	1	202400410661
21	Reactor	1	202301000819
22	Cover for inductance assembly	1	20123789G002
23	Reactor	1	202301000834
24	electrical box assembly	1	203337890142
24,1	E-Parts box	1	201237300171
24,2	Radiator	1	202301900089
24,3	E-Parts box's cover	1	201237300162
24,4	Main control board	1	201337790009
24,5	Holder for E-parts	1	201137300162
25	board of terminal,assy	1	203337390043
25,1	Wire joint	1	202301450113
25,2	Washer for wire joint	1	201135000004
25,3	Wire clamp	1	201219900001
25,4	board of terminal	1	201237590009
26	liquid valve assembly	1	201637890228
26,1	Liquid valve	1	201600740523
27	4-Ways valve Ass'y	1	201637890243
27,1	4-Ways valve	1	201600690011
27,2	Gas pipe valve	1	201600720195
28	sound-proof materiall	1	202137300000
29	rotary compressor	1	201400710680
30	sound-proof material	1	202137590001
	Low ambient kit	1	201319900494
	Indoor temp sensor	1	202301300079