

HYOSUNG

Aquila 250 FI

Comet 250 / R FI

SERVICE MANUAL

FOREWORD

This manual contains an introductory description on HYOSUNG 『*Aquila 250 FI*』 & 『*Comet 250/R FI*』 and procedures for its inspection / service and overhaul of its main components.

It covers the differences from Carbure type and please refer to the service manual of 『*Aquila 250* (99000-95310)』, 『*Comet 250R* & *Comet 125R* (99000HR8310)』 and 『*Comet 250* & *Comet 125* (99000-94710)』 for others which are not covered in this manual.

Other information considered as generally known is not included.

Read GENERAL INFORMATION section to familiarize yourself with outline of the vehicle and MAINTENANCE and other sections to use as a guide for proper inspection and service.

This manual will help you know the vehicle better so that you can assure your customers of your optimum and quick service.

- ❖ This manual has been prepared on the basis of the latest specification at the time of publication.
If modification has been made since then, difference may exist between the content of this manual and the actual vehicle.
- ❖ Illustrations in this manual are used to show the basic principles of operation and work procedures.
They may not represent the actual vehicle exactly in detail.

WARNING

This manual is intended for those who have enough knowledge and skills for servicing HYOSUNG vehicles. Without such knowledge and skills, you should not attempt servicing by relying on this manual only.

Instead, please contact your nearby authorized HYOSUNG motorcycle dealer.

GROUP INDEX


GENERAL INFORMATION	1
FI SYSTEM DIAGNOSIS	4-1
FUEL SYSTEM AND THROTTLE BODY	4-2
ELECTRICAL SYSTEM	5
SERVICING INFORMATION	7



HOW TO USE THIS MANUAL

TO LOCATE WHAT YOU ARE LOOKING FOR :

1. The text of this manual is divided into sections.
2. As the title of these sections are listed on the previous page as GROUP INDEX, select the section where you are looking for.
3. Holding the manual as shown at the right will allow you to find the first page of the section easily.
4. On the first page of each section, its contents are listed. Find the item and page you need.



SYMBOL

Listed in the table below are the symbols indicating instructions and other information necessary for servicing and meaning associated with them respectively.

SYMBOL	DEFINITION	SYMBOL	DEFINITION
	Torque control required. Data beside it indicates specified torque.		Apply THREAD LOCK "1324".
	Apply oil. Use engine oil unless otherwise specified.		Apply or use brake fluid.
	Apply SUPER GREASE "A".		Measure in voltage range.
	Apply SUPER GREASE "C".		Measure in resistance range.
	Apply SILICONE GREASE.		Measure in current range.
	Apply MOLY PASTE.		Measure in continuity test range.
	Apply BOND "1215".		Use special tool.
	Use fork oil.		

ABBREVIATIONS USED IN THIS MANUAL

A

ABDC	: After Bottom Dead Center
AC	: Alternating Current
API	: American Petroleum Institute
ATDC	: After Top Dead Center

B

BBDC	: Before Bottom Dead Center
BDC	: Bottom Dead Center
BTDC	: Before Top Dead Center

D

DC	: Direct Current
DOHC	: Double Over Head Camshaft

E

ECU	: Engine Control Unit, FI Control Unit
ET Sensor	: Engine Temperature Sensor (ETS)

F

FI	: Fuel Injection, Fuel Injector
FP	: Fuel Pump
FPR	: Fuel Pressure Regulator

G

GP Switch	: Gear Position Switch
-----------	------------------------

I

IAP Sensor	: Intake Air Pressure Sensor (IAPS)
IAT Sensor	: Intake Air Temperature Sensor (IATS)
IG	: Ignition
ISC Solenoid	: Idle Speed Control Solenoid

L

LCD	: Liquid Crystal Display
LED	: Light Emitting Diode
LH	: Left Hand

M

Max	: Maximum
Min	: Minimum

O

O ₂ Sensor	: Oxygen Sensor (O ₂ S)
-----------------------	------------------------------------

R

RH	: Right Hand
----	--------------

S

SAE	: Society of Automotive Engineers
SAV Solenoid	: Secondary Air Valve Solenoid

T

TDC	: Top Dead Center
TO Sensor	: Tip Over Sensor (TOS)

WIRE COLOR

B	: Black	Gr	: Gray	Sb	: Light blue
L	: Blue	Lg	: Light green	W	: White
Br	: Brown	O	: Orange	Y	: Yellow
G	: Green	R	: Red		

BL	: Black with Blue tracer	BBr	: Black with Brown tracer
BG	: Black with Green tracer	BO	: Black with Orange tracer
BR	: Black with Red tracer	BW	: Black with White tracer
BY	: Black with Yellow tracer	LB	: Blue with Black tracer
LG	: Blue with Green tracer	LR	: Blue with Red tracer
LW	: Blue with White tracer	LY	: Blue with Yellow tracer
BrB	: Brown with Black tracer	BrW	: Brown with White tracer
GB	: Green with Black tracer	GR	: Green with Red tracer
GY	: Green with Yellow tracer	GrB	: Gray with Black tracer
GrR	: Gray with Red tracer	GrW	: Gray with White tracer
OB	: Orange with Black tracer	OL	: Orange with Blue tracer
OG	: Orange with Green tracer	OR	: Orange with Red tracer
OW	: Orange with White tracer	OY	: Orange with Yellow tracer
RB	: Red with Black tracer	RW	: Red with White tracer
WB	: White with Black tracer	WL	: White with Blue tracer
WR	: White with Red tracer	YB	: Yellow with Black tracer
YL	: Yellow with Blue tracer	YG	: Yellow with Green tracer
YR	: Yellow with Red tracer		

GENERAL INFORMATION

1

CONTENTS

SPECIFICATIONS (*Aquila 250 FI*, *Comet 250 FI* & *Comet 250 R FI*) 6 (1-8)

SPECIFICATIONS (*Aquila 250 FI*, *Comet 250 FI* & *Comet 250 R FI*)

⊙ DIMENSIONS AND MASS

ITEM	<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Overall length	2,270 mm (89.4 in)	2,080 mm (81.9 in)	2,060 mm (81.1 in)
Overall width	800 mm (31.5 in)	760 mm (29.9 in)	655 mm (25.8 in)
Overall height	1,090 mm (42.9 in)	1,120 mm (44.1 in)	1,125 mm (44.3 in)
Wheelbase	1,500 mm (59.1 in)	1,455 mm (57.3 in)	1,435 mm (56.5 in)
Ground clearance	155 mm (6.1 in)	180 mm (7.1 in)	130 mm (5.1 in)
Mass	170 kg (375 lbs)	←	185 kg (408 lbs)

⊙ ENGINE

ITEM	<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Type	Four-stroke, DOHC, air-cooled and oil-cooled	←	←
Number of cylinder	V-2 cylinder	←	←
Bore	57.0 mm (2.24 in)	←	←
Stroke	48.8 mm (1.92 in)	←	←
Piston displacement	249 cm ³ (15.2 in ³)	←	←
Fuel system	Fuel Injection	←	←
Starter system	Electric starter	←	←
Lubrication system	Wet sump	←	←

⊙ TRANSMISSION

ITEM	<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Clutch	Wet multi-plate type	←	←
Transmission	5-speed constant mesh	←	←
Gearshift pattern	1-down, 4-up	←	←
Final reduction	3.290	←	←
Gear ratio, 1st	2.460	←	←
2nd	1.560	←	←
3rd	1.190	←	←
4th	0.960	←	←
5th	0.840	←	←
Drive chain	520HO, 116 links	520HO, 112 links	←

◎ CHASSIS

ITEM	<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Front suspension	Telescopic type	←	←
Rear suspension	Swingarm type	←	←
Steering angle	40 ° (right & left)	33 ° (right & left)	27 ° (right & left)
Caster	33 °	25.5 °	←
Trail	135 mm (5.32 in)	85 mm (3.35 in)	90 mm (3.54 in)
Front brake	Disk brake	←	Double disk brake
Rear brake	Drum brake	Disk brake	←
Front tire size	110/90 - 16 59S	110/70 - 17 54H	←
Rear tire size	150/80 - 15M/C 70S	150/70 - 17 69H	←
Front fork stroke	120 mm (4.72 in)	←	←

◎ ELECTRICAL

ITEM		<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Ignition type		ECU	←	←
Ignition timing		13 ° B.T.D.C. at 2,000 rpm and 30 ° B.T.D.C. at 6,000 rpm	←	←
Spark plug		CR8E	←	←
Battery		12 V 12 Ah (MF)	←	←
Fuse		30 A & 15 A	←	←
Head lamp	HI	12 V - H4 : 60 W × 1	←	12 V - H1 : 55 W × 1
	LO	12 V - H4 : 55 W × 1	←	12 V - H3 : 55 W × 1
	Position	12 V - W5 W × 1	←	←
Turn signal lamp		12 V - RY10 W × 4	←	←
Brake / Tail lamp		12 V - P21/5 W × 1	←	←
License plate lamp		12 V - W5 W × 1	←	←
Illumination lamp		12 V - 1.7 W × 2	LED type	←
High beam indicator lamp		12 V - 1.7 W × 1	LED type	←
Turn signal indicator lamp(right & left)		12 V - 1.7 W × 2	LED type	←
Neutral indicator lamp		12 V - 1.7 W × 1	LED type	←
Fuel meter lamp		12 V - 1.7 W × 1	LED type (Level type)	←
"FI"(Fuel Injection) check lamp		LED type	←	←

◎ CAPACITIES

ITEM		<i>Aquila 250 FI</i>	<i>Comet 250 FI</i>	<i>Comet 250 R FI</i>
Fuel tank		14.0 l	17.0 l	←
Engine oil	Oil change	1,450 ml	←	←
	Oil and filter change	1,500 ml	←	←
	Engine overhaul	1,800 ml	←	←
Front fork oil capacity(One side)		250 cc	400 ± 2.5 cc	←

NOTE

The specifications are subject to change without notice.

FI SYSTEM DIAGNOSIS

CONTENTS

PRECAUTIONS IN SERVICING	10 (4-1-1)
FI SYSTEM TECHNICAL FEATURES	14 (4-1-5)
SELF-DIAGNOSIS FUNCTION (Comet 250/R FI)	20 (4-1-11)
SELF-DIAGNOSIS FUNCTION (Aquila 250 FI)	22 (4-1-13)
FI SYSTEM TROUBLESHOOTING	24 (4-1-15)
CUSTOMER COMPLAINT ANALYSIS	24 (4-1-15)
SELF-DIAGNOSTIC PROCEDURES (Comet 250/R FI)	26 (4-1-17)
SELF-DIAGNOSIS RESET PROCEDURE (Comet 250/R FI)	26 (4-1-17)
MALFUNCTION CODE AND DEFECTIVE CONDITION	27 (4-1-18)
"C15" ET SENSOR CIRCUIT MALFUNCTION	29 (4-1-20)
"C17" or "C18" IAP SENSOR CIRCUIT MALFUNCTION	31 (4-1-22)
"C21" IAT SENSOR CIRCUIT MALFUNCTION	33 (4-1-24)
"C22" OXYGEN SENSOR CIRCUIT MALFUNCTION	35 (4-1-26)
"C24" or "C25" IGNITION COIL MALFUNCTION	35 (4-1-26)
"C27" ISC SOLENOID RANGE ABNORMAL	36 (4-1-27)
"C32" or "C33" FUEL INJECTOR CIRCUIT MALFUNCTION	37 (4-1-28)
"C37" SAV SOLENOID MALFUNCTION	39 (4-1-30)
"C41" FUEL PUMP RELAY CIRCUIT MALFUNCTION	40 (4-1-31)
"C43" OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION	41 (4-1-32)
SENSORS	42 (4-1-33)

4-1





PRECAUTIONS IN SERVICING

When handling the component parts or servicing the FI system, observe the following points for the safety of the system.

⦿ ELECTRICAL PARTS

▣ CONNECTOR / COUPLER

- When connecting a connector, be sure to push it in until a click is felt.
- With a lock type coupler, be sure to release the lock when disconnecting, and push it in fully till the works when connecting it.
- When disconnecting the coupler, be sure to hold the coupler body and do not pull the lead wires.
- Inspect each terminal on the connector / coupler for looseness or bending.
- Inspect each terminal for corrosion and contamination.
The terminals must be clean and free of any foreign material which could impede proper terminal contact.
- Inspect each lead wire circuit for poor connection by shaking it by hand lightly. If any abnormal condition is found, repair or replace.
- When taking measurements at electrical connectors using a tester probe, be sure to insert the probe from the wire harness side (backside) of the connector / coupler.




- When connecting meter probe from the terminal side of the coupler (connection from harness side not being possible), use extra care not to force and cause the male terminal to bend or the female terminal to open.

Connect the probe as shown to avoid opening of female terminal.


Never push in the probe where male terminal is supposed to fit.

- Check the male connector for bend and female connector for excessive opening. Also check the coupler for locking (looseness), corrosion, dust, etc.




◎ FUSE

- When a fuse blows, always investigate the cause to correct it and then replace the fuse.
- Do not use a fuse of a different capacity.
- Do not use wire or any other substitute for the fuse.




◎ ECU / VARIOUS SENSORS

- Since each component is a high-precision part, great care should be taken not to apply any sharp impacts during removal and installation.




- Be careful not to touch the electrical terminals of the ECU.
The static electricity from your body may damage this part.




4-1-3 FI SYSTEM DIAGNOSIS


- When disconnecting and connecting the ECU, make sure to turn “OFF” the ignition switch, or electronic parts may get damaged.




- Battery connection in reverse polarity is strictly prohibited.
Such a wrong connection will damage the components of the FI system instantly when reverse power is applied.



- Removing any battery terminal of a running engine is strictly prohibited.
The moment such removal is made, damaging counter electromotive force will be applied to the ECU which may result in serious damage.



- Before measuring voltage at each terminal, check to make sure that battery voltage is 11 V or higher.
Terminal voltage check at low battery voltage will lead to erroneous diagnosis.



- Never connect an ohmmeter to the ECU with its coupler connected. If attempted, damage to ECU or sensors may result.
- Be sure to use a specified voltmeter / ohmmeter. Otherwise, accurate measurements may not be obtained and personal injury may result.

⦿ USING TESTERS

- Use well-charged batteries in the tester.
- Be sure to set the tester to the correct testing range.

▣ USING THE TESTER


- Incorrectly connecting the ⊕ and ⊖ probes may cause the inside of the tester to burnout.
- If the voltage and current are not known, make measurements using the highest range.
- After using the tester, turn the power off.

FI SYSTEM TECHNICAL FEATURES

◎ INJECTION TIME (INJECTION VOLUME)

The factors to determine the injection time include the basic fuel injection time, which is calculated on the basis of intake air pressure, engine speed and throttle opening angle, and various compensations.

These compensations are determined according to the signals from various sensors that detect the engine and driving conditions.



◎ COMPENSATION OF INJECTION TIME (VOLUME)


The following different signals are output from the respective sensors for compensation of the fuel injection time (volume).

SIGNAL	DESCRIPTION
ENGINE TEMPERATURE SENSOR SIGNAL	When engine temperature is low, injection time (volume) is increased.
INTAKE AIR TEMPERATURE SENSOR SIGNAL	When intake air temperature is low, injection time (volume) is increased.
BATTERY VOLTAGE SIGNAL	ECU operates on the battery voltage and at the same time, it monitors the voltage signal for compensation of the fuel injection time (volume). A longer injection time is needed to adjust injection volume in the case of low voltage.
ENGINE RPM SIGNAL	At high speed, the injection time (volume) is increased.
STARTING SIGNAL	When starting engine, additional fuel is injected during cranking engine.
ACCELERATION SIGNAL / DECELERATION SIGNAL	During acceleration, the fuel injection time (volume) is increased in accordance with the throttle opening speed and engine rpm. During deceleration, the fuel injection time (volume) is decreased.


◎ INJECTION STOP CONTROL

SIGNAL	DESCRIPTION
TIP OVER SENSOR SIGNAL (FUEL CUT-OFF)	When the motorcycle tips over, the tip over sensor sends a signal to the ECU. Then, this signal cuts OFF current supplied to the fuel pump, fuel injector and ignition coil.
OVER-REV. LIMITER SIGNAL	The fuel injectors stop operation when engine rpm reaches rev. limit rpm.

◎ FI SYSTEM PARTS LOCATION (*Aquila 250 FI*)




- | | |
|-----------------------|-----------------------|
| ① Speedometer | ⑤ GP switch |
| ② Ignition coil, NO.1 | ⑥ Fuel injector, NO.1 |
| ③ Ignition coil, NO.2 | ⑦ Fuel injector, NO.2 |
| ④ Pick-up coil | ⑧ ISC solenoid |




- ⑨ IAT sensor
- ⑩ TO sensor
- ⑪ Fuel pump relay
- ⑫ IAP sensor, NO.2

- ⑬ IAP sensor, NO.1
- ⑭ ET sensor
- ⑮ Oxygen sensor
- ⑯ SAV solenoid

◎ FI SYSTEM PARTS LOCATION (*Comet 250/R FI*)



- | | |
|-----------------------|-----------------------|
| ① Speedometer | ⑥ Pick-up coil |
| ② Fuel injector, NO.1 | ⑦ Ignition coil, NO.1 |
| ③ Fuel injector, NO.2 | ⑧ ISC solenoid |
| ④ IAT sensor | ⑨ Fuel pump relay |
| ⑤ GP switch | |



- ⑩ TO sensor
- ⑪ Ignition coil, NO.2
- ⑫ IAP sensor, NO.1
- ⑬ IAP sensor, NO.2

- ⑭ ET sensor
- ⑮ Oxygen sensor
- ⑯ SAV solenoid

SELF-DIAGNOSIS FUNCTION (*Comet 250/ R FI*)

The self-diagnosis function is incorporated in the ECU.

The function has two modes, "USER MODE" and "DEALER MODE".

The user can only be notified by the "FI" check lamp "FI" ①.

To check the function of the individual FI system devices, the dealer mode is prepared.


In this check, the special tool is necessary to read the code of the malfunction items.

⊙ USER MODE

The "FI" check lamp "FI" ① comes on for about three seconds whenever the ignition switch is set to "ON" position with the engine stopped as a test of the injection system operation. The check lamp must go off after three seconds.

If the check lamp comes on during normal engine operation, it means that the fuel injection system is not operating correctly.

When this is the case, inspect the fuel injection system to refer to "Dealer mode".



⦿ DEALER MODE




The defective function is memorized in the ECU.

Use the special tool's coupler to connect to the dealer mode coupler. (Refer to page 4-1-17)

The memorized malfunction code is displayed on LCD (DISPLAY) panel.

Malfunction means that the ECU does not receive signal from the devices. These affected devices are indicated in the code form.

 **Mode select switch : 09900-27000**



CAUTION

- ❖ Do not disconnect the ECU lead wire couplers, before checking the malfunction code, or the malfunction code memory is erased and the malfunction code can not be checked.
- ❖ Confirm the malfunction code after turn the ignition switch "ON" position or cranking the engine for few seconds.

MALFUNCTION	LCD (DISPLAY) INDICATION ①	INDICATION MODE ②
"NO"	Speedometer	"FI" check lamp goes off.
"YES"	C**code is indicated from small numeral to large one.	"FI" check lamp comes on continually.

SELF-DIAGNOSIS FUNCTION (*Aquila 250 FI*)

The self-diagnosis function is incorporated in the ECU.

The function has a mode, "USER MODE". The user and dealer can only be notified by the "FI" check lamp "FI" ①.

To check the function of the individual FI system devices, read blinks signal of the "FI" check lamp "FI" ①.

The "FI" check lamp "FI" ① comes on for about three seconds whenever the ignition switch is set to "ON" position with the engine stopped as a test of the injection system operation. The check lamp must go off after three seconds.


If the check lamp comes on during normal engine operation, it means that the fuel injection system is not operating correctly.









When this is the case, inspect the fuel injection system to refer to blinks signal of the "FI" check lamp "FI" ①.

The defective function is memorized in the ECU.

The memorized malfunction code is display with blinks signal of the "FI" check lamp "FI" ①.

Malfunction means that the ECU does not receive signal from the devices. These affected devices are displayed blinks signal of the "FI" check lamp "FI" ①.



<i>Comet 250 / R FI</i> CODE	<i>Aquila 250 FI</i> CODE	MALFUNCTION PART	REMARKS
C15		Engine temperature sensor (ETS)	
C17		Intake air pressure sensor (IAPS), NO.1	For NO.1 cylinder
C18		Intake air pressure sensor (IAPS), NO.2	For NO.2 cylinder
C21		Intake air temperature sensor (IATS)	
C22		Oxygen sensor (O ₂ S)	
C24		IG coil, NO.1	For NO.1 cylinder
C25		IG coil, NO.2	For NO.2 cylinder
C27		Idle speed control solenoid (ISC solenoid)	
C32		Fuel injector, NO.1	For NO.1 cylinder
C33		Fuel injector, NO.2	For NO.2 cylinder
C37		Secondary air valve solenoid (SAV solenoid)	
C41		Fuel pump relay	
C43		Oxygen sensor heater (O ₂ S heater)	


■ *Comet 250 / R FI*

In the LCD (DISPLAY) panel①, the malfunction code is indicated from small code to large code.


■ *Aquila 250 FI*

In the "FI" check lamp "Ⓢ"②, the malfunction code is displayed from small blinks signal to large blinks signal.

Comet 250 / R FI



Aquila 250 FI



FI SYSTEM TROUBLESHOOTING

CUSTOMER COMPLAINT ANALYSIS

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form will facilitate collecting information to the point required for proper analysis and diagnosis.

■ EXAMPLE : CUSTOMER PROBLEM INSPECTION FORM

User name :	Model :	VIN :	
Date of issue :	Date Reg.	Date of problem :	Mileage :

"FI" Check lamp	☐ Always ON ☐ Sometimes ON ☐ Always OFF ☐ Good condition
Malfunction display / code (LCD) or Blinks signal ("FI" check lamp)	☐ No code ☐ Malfunction code ()

PROBLEM SYMPTOMS

☐ Difficult Starting ☐ No cranking ☐ No initial combustion ☐ No combustion ☐ Poor starting at (☐ cold ☐ warm ☐ always) ☐ Other _____	☐ Poor Driveability ☐ Hesitation on acceleration ☐ Back fire / ☐ After fire ☐ Lack of power ☐ Surging ☐ Abnormal knocking ☐ Engine rpm jumps briefly ☐ Other _____
☐ Poor Idling ☐ Poor fast Idle ☐ Abnormal idling speed (☐ High ☐ Low) (rpm) ☐ Unstable ☐ Hunting (rpm. to rpm) ☐ Other _____	☐ Engine Stall when ☐ Immediately after start ☐ Throttle valve is opened ☐ Throttle valve is closed ☐ Load is applied ☐ Other _____
☐ OTHERS :	

MOTORCYCLE / ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS	
Environmental condition	
Weather	☐ Fair ☐ Cloudy ☐ Rain ☐ Snow ☐ Always ☐ Other
Temperature	☐ Hot ☐ Warm ☐ Cool ☐ Cold (°F / °C) ☐ Always
Frequency	☐ Always ☐ Sometimes (times / day, month) ☐ Only once
	☐ Under certain condition
Road	☐ Urban ☐ Suburb ☐ Highway ☐ Mountainous (☐ Uphill ☐ Downhill)
	☐ Tarmacadam ☐ Gravel ☐ Other
Motorcycle condition	
Engine condition	☐ Cold ☐ Warming up phase ☐ Warmed up ☐ Always ☐ Other at starting
	☐ Immediately after start ☐ Racing without load ☐ Engine speed (rpm)
Motorcycle condition	During driving : ☐ Constant speed ☐ Accelerating ☐ Decelerating
	☐ Right hand corner ☐ Left hand corner ☐ At stop
	☐ Motorcycle speed when problem occurs (km/h, Mile/h)
	☐ Other _____

NOTE

The above form is a standard sample. It should be modified according to conditions characteristic of each market.

SELF-DIAGNOSTIC PROCEDURES

(*Comet 250/ R FI*)

Don't disconnect couplers from ECU, battery cable from battery, ECU ground wire harness from engine or main fuse before confirming malfunction code (self-diagnostic trouble code) stored in memory. Such disconnection will erase memorized information in ECU memory.

Malfunction code stored in ECU memory can be checked by the special tool.

To check malfunction code, read SELF-DIAGNOSIS FUNCTION "DEALER MODE" (Refer to page 4-1-12, 14) carefully to have good understanding as to what functions are available and how to use it.



Be sure to read "PRECAUTIONS for Electrical Circuit Service" (Refer to page 4-1-1) before inspection and observe what is written there.

- Remove the front and rear seat.
- Connect the special tool to the dealer mode coupler at the wiring harness, and the ignition switch is set to "ON" position.
- Turn the special tool's switch "ON" position and check the malfunction code to determine the malfunction part.

 **Mode select switch : 09900-27000**


NOTE

The dealer mode coupler is located under the rear seat.



SELF-DIAGNOSIS RESET PROCEDURE (*Comet 250/ R FI*)

- After repairing the trouble, turn the ignition switch "OFF" position and turn "ON" position again.
- If speedometer (LCD INDICATION ①) is indicates, the malfunction codes are cleared.
- Disconnect the special tool from the dealer mode coupler.



MALFUNCTION CODE AND DEFECTIVE CONDITION

MALFUNCTION CODE	DETECTED ITEM	DETECTED FAILURE CONDITION
		CHECK FOR
C15	Engine temperature sensor (ETS)	The sensor voltage should be the following. $0.1 \text{ V} \leq \text{sensor voltage} < 4.6 \text{ V}$ Without the above range for 4 sec. and more, C15 is indicated.
		Engine temperature sensor, lead wire / coupler connection.
C17 / C18	Intake air pressure sensor (IAPS), NO.1 / NO.2	The sensor should produce following voltage. $0.1 \text{ V} \leq \text{sensor voltage} \leq 4.8 \text{ V}$ Without the above range for 4 sec. and more, C17 or C18 is indicated.
		Intake air pressure sensor, lead wire / coupler connection.
C21	Intake air temperature sensor (IATS)	The sensor voltage should be the following. $0.1 \text{ V} \leq \text{sensor voltage} < 4.6 \text{ V}$ Without the above range for 4 sec. and more, C21 is indicated.
		Intake air temperature sensor, lead wire / coupler connection.
C22	Oxygen sensor (O ₂ S)	The oxygen sensor signal is input in ECU since then more than 120 sec. after the engine run. When this is the case, ECU not receive the signal, C22 is indicated.
		Oxygen sensor, lead wire / coupler connection.

4-1-19 FI SYSTEM DIAGNOSIS


MALFUNCTION CODE	DETECTED ITEM	DETECTED FAILURE CONDITION
		CHECK FOR
C24 / C25	Ignition coil (IG coil), NO.1 / NO.2	When the IC of the ECU electric current gets 6 A and more, C24 or C25 is indicated.
		Ignition coil, wiring / coupler connection, power supply from the battery.
C27	Idle speed control solenoid (ISC solenoid)	The idle speed control solenoid step should be the following. O step $\leq$ solenoid step $\leq$ 100 step Without the above range, C27 is indicated.
		Idle speed control solenoid, lead wire / coupler connection.
C32 / C33	Fuel injector, NO.1 / NO.2	The fuel injector not comes in voltage from the battery, C32 or C33 is indicated.
		Injector, wiring / coupler connection, power supply to the injector.
C37	Secondary air valve solenoid (SAV solenoid)	When the secondary air valve solenoid voltage is not input in ECU, C37 is indicated.
		Secondary air valve solenoid, lead wire / coupler connection.
C41	Fuel pump relay	No voltage is applied to the both injectors 3 for 3 sec. after the contact of fuel pump relay is turned "ON" position. Or voltage is applied to the both injectors, when the contact of fuel pump is "OFF" position.
		Fuel pump relay, connecting lead wire, power source to fuel pump relay, fuel injector.
C43	Oxygen sensor heater (O ₂ S heater)	The oxygen sensor heater signal is not input in ECU.
		Oxygen sensor heater, lead wire / coupler connection.

“C15” ET SENSOR CIRCUIT MALFUNCTION

<i>Comet 250/</i> FI CODE	<i>Aquila 250</i> FI CODE
C15	
DETECTED CONDITION	POSSIBLE CAUSE
Output voltage is out of the specified range. 0.1 V $\leq$ Sensor voltage < 4.6 V	● ET sensor circuit open or short. ● ET sensor malfunction. ● ECU malfunction.

■ INSPECTION**◆ Step 1**

- 1) Turn the ignition switch “OFF” position.
- 2) Check the ET sensor coupler for loose or poor contacts.
If OK, then measure the ET sensor voltage at the wire side coupler.
- 3) Disconnect the coupler and turn the ignition switch “ON” position.



- 4) Measure the voltage between G wire terminal and ground.
- 5) If OK, then measure the voltage between G wire terminal and BW wire terminal.

ET sensor voltage	4.5 ~ 5.5 V (⊕ G — ⊖ Ground) (⊕ G — ⊖ BW)
--------------------------	---

Tester knob indication : Voltage (---)

Is the voltage OK?


YES	Go to Step 2.
NO	● Loose or poor contacts on the ECU coupler. ● Open or short circuit in the G wire or BW wire.

4-1-21 FI SYSTEM DIAGNOSIS

◆ Step 2

- 1) Turn the ignition switch "OFF" position.
- 2) Measure the ET sensor resistance.


ET sensor resistance	
Engine Temp.	Resistance (To ECU)
0 °C (32 °F)	Approx. 28.788 kΩ
20 °C (68 °F)	Approx. 12.209 kΩ
40 °C (104 °F)	Approx. 5.671 kΩ
60 °C (140 °F)	Approx. 2.845 kΩ
80 °C (176 °F)	Approx. 1.525 kΩ




 **Tester knob indication : Resistance (kΩ)**

Is the resistance OK?

YES	● G or BW wire open or shorted to ground, or poor⑧ or⑤ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the ET sensor with a new one.



“C17” or “C18” IAP SENSOR CIRCUIT MALFUNCTION

<i>Comet 250/</i> FI CODE	<i>Aquila 250 FI</i> CODE
C17	
C18	


DETECTED CONDITION	POSSIBLE CAUSE
IAP sensor voltage is out of the specified range. $0.1\text{ V} \leq \text{Sensor voltage} \leq 4.8\text{ V}$ NOTE : <i>Note that atmospheric pressure varies depending on weather conditions as well as altitude.</i> <i>Take that into consideration when inspecting voltage.</i>	● Clogged vacuum passage between throttle body and IAP sensors. ● Air being drawn from vacuum passage between throttle body and IAP sensors. ● IAP sensor circuit open or shorted to ground. ● IAP sensor malfunction. ● ECU malfunction.

■ INSPECTION**◆ Step 1**

- 1) Remove the fuel tank.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the IAP sensor NO.1 coupler ① and NO.2 coupler ② for loose or poor contacts.
If OK, then measure the IAP sensor input voltage.



- 4) Disconnect the IAP sensor couplers NO.1 ① and NO.2 ②.
- 5) Turn the ignition switch “ON” position.
- 6) Measure the voltage at the OB wire and ground.
If OK, then measure the voltage at the OB wire and BW wire.

**IAP sensor input voltage**

4.5 ~ 5.5 V
 (⊕ OB — ⊖ Ground)
 (⊕ OB — ⊖ BW)

 **Tester knob indication : Voltage (---)**

Is the voltage OK?


YES	Go to Step 2.
NO	● Loose or poor contacts on the ECU coupler. ● Open or short circuit in the OB wire or BW wire.

4-1-23 FI SYSTEM DIAGNOSIS

◆ Step 2

- 1) Connect the IAP sensor couplers NO.1 ① and NO.2 ②.
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Start the engine at idle speed.
- 4) Measure the IAP sensor output voltage at the wire side coupler (between BL(NO.1) or BY(NO.2) and BW wires).


IAP sensor output voltage	Approx. 4.0 ~ 4.2 V when ignition switch "ON" ([NO.1] ⊕ BL — ⊖ BW) ([NO.2] ⊕ BY — ⊖ BW)
----------------------------------	--



Tester knob indication : Voltage (—)

Is the voltage OK?

YES	● OB, BL(NO.1), BY(NO.2) or BW wire open or shorted to ground, or poor ⑰, ⑳ (NO.1), ⑮ (NO.2) or ⑤ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	If check result is not satisfactory, replace IAP sensor with a new one.




Output voltage (Input voltage 5 V, ambient temp. 25 °C, 77 °F)				
ALTITUDE (Reference)		ATMOSPHERIC PRESSURE		OUTPUT VOLTAGE
(ft)	(m)	(mmHg)	kPa	(V)
0	0	760	100	Approx. 4.0 ~ 4.3
2 000	610	707	94	
2 001	611	707	94	Approx. 3.6 ~ 4.0
5 000	1 524	634	85	
5 001	1 525	634	85	Approx. 3.3 ~ 3.6
8 000	2 438	567	76	
8 001	2 439	567	76	Approx. 3.0 ~ 3.3
10 000	3 048	526	70	

“C21” IAT SENSOR CIRCUIT MALFUNCTION

<i>Comet 250</i> FI CODE	<i>Aquila 250</i> FI CODE
C21	
DETECTED CONDITION	POSSIBLE CAUSE
Output voltage is out of the specified range. $0.1\text{ V} \leq \text{Sensor voltage} < 4.6\text{ V}$	● IAT sensor circuit open or short. ● IAT sensor malfunction. ● ECU malfunction.

▣ INSPECTION**◆ Step 1**

- 1) Remove the fuel tank.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the IAT sensor coupler for loose or poor contacts.
If OK, then measure the IAT sensor voltage at the wire side coupler.
- 4) Disconnect the coupler and turn the ignition switch “ON” position.




- 5) Measure the voltage between Lg wire terminal and ground.
- 6) If OK, then measure the voltage between Lg wire terminal and BW wire terminal.

IAT sensor voltage	$4.5 \sim 5.5\text{ V}$ $(\oplus \text{ Lg} - \ominus \text{ Ground})$ $(\oplus \text{ Lg} - \ominus \text{ BW})$
---------------------------	---

Tester knob indication : Voltage (---)

Is the voltage OK?

YES	Go to Step 2.
NO	● Loose or poor contacts on the ECU coupler. ● Open or short circuit in the Lg wire or BW wire.



4-1-25 FI SYSTEM DIAGNOSIS

◆ Step 2



- 1) Turn the ignition switch "OFF" position.
- 2) Measure the IAT sensor resistance.

IAT sensor resistance	
Intake Air Temp.	Resistance
-10 °C (14 °F)	Approx. 53.30 KΩ
0 °C (32 °F)	Approx. 31.52 KΩ
20 °C (68 °F)	Approx. 12.33 KΩ
40 °C (104 °F)	Approx. 5.19 KΩ
60 °C (140 °F)	Approx. 2.42 KΩ

 **Tester knob indication : Resistance (KΩ)**

Is the resistance OK?

YES	● Lg or BW wire open or shorted to ground, or poor ②② or ⑤ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the IAT sensor with a new one.





“C22” OXYGEN SENSOR CIRCUIT MALFUNCTION

<i>Comet 250/</i> FI CODE	<i>Aquila 250</i> FI CODE
C22	
DETECTED CONDITION	POSSIBLE CAUSE
Oxygen sensor signal is not input in ECU since then more than 120 sec. after the engine run.	● Oxygen sensor, Oxygen sensor heater circuit open or short. ● Oxygen sensor, Oxygen sensor heater malfunction. ● ECU malfunction.


▣ INSPECTION

- 1) Remove the front seat and frame cover.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the Oxygen sensor coupler ① for loose or poor contacts.



Is OK?

YES	● BR or BW wire open or shorted to ground, or poor ③ or ⑤ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the Oxygen sensor.

**“C24” or “C25” IGNITION COIL MALFUNCTION**

Refer to the IGNITION COIL for details. (Refer to page 5-3)


<i>Comet 250/</i> FI CODE	<i>Aquila 250</i> FI CODE
C24	
C25	

“C27” ISC SOLENOID RANGE ABNORMAL


<i>Comet 250/ R</i> FI CODE	<i>Aquila 250</i> FI CODE
C27	
DETECTED CONDITION	POSSIBLE CAUSE
ISC solenoid's step is out of the specified range. 0 step ≤ Solenoid step ≤ 100 step	● ISC solenoid malfunction. ● ISC solenoid's step is out of the specific range. ● ECU malfunction.

■ INSPECTION

- 1) Remove the front seat.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the ISC solenoid coupler for loose or poor contacts.
- 4) Turn the ignition switch “ON” position to check the ISC solenoid operation.






[When Ignition switch “OFF”]



[When Ignition switch “ON”]

Is OK?

YES	● Gr, GR, Y or W wire loose or poor contacts on the ISC solenoid coupler, or poor ③④, ③②, ③③ or ②⑤ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the ISC solenoid with a new one.

Aquila 250 FI*Comet 250/ R FI*

“C32” or “C33” FUEL INJECTOR CIRCUIT MALFUNCTION

<i>Comet 250</i> FI CODE	<i>Aquila 250</i> FI CODE
C32	
C33	

DETECTED CONDITION	POSSIBLE CAUSE
Fuel injector not comes in voltage from battery.	● Injector circuit open or short. ● Injector malfunction. ● ECU malfunction.



■ INSPECTION**◆ Step 1**

- 1) Remove the fuel tank and frame cover.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the injector couplers NO.1 ① and NO.2 ② for loose or poor contacts.
If OK, then measure the injector resistance.

※ ① : Fuel injector NO.1
② : Fuel injector NO.2

- 4) Disconnect the injector couplers NO.1 ① and NO.2 ② and measure the resistance between terminals.

Injector resistance 11.5 ~ 13.5 Ω at 20 °C (68°F)




- 5) If OK, then check the continuity between injector terminals and ground.

Injector continuity ∞ Ω (Infinity)

 **Tester knob indication : Resistance (Ω)**

Is the resistance OK?

YES	Go to Step 2
NO	Replace the Injector with a new one.



4-1-29 FI SYSTEM DIAGNOSIS

◆ Step 2

- 1) Turn the ignition switch "ON" position.
- 2) Measure the injector voltage between YG(NO.1), YR(NO.2) wire and ground.

Injector voltage

Battery voltage
 ([NO.1] ⊕ YG ⊖ Ground)
 ([NO.2] ⊕ YR ⊖ Ground)


 Tester knob indication : Voltage (---)

NOTE


Injector voltage can be detected only 3 seconds after ignition switch is turned "ON" position.

Is the voltage OK?

YES	● YG(NO.1) or YR(NO.2) wire open or shorted to ground, or poor ⑱ (NO.1) or ⑩ (NO.2) connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	● Inspect the fuel pump or fuel pump relay. (Refer to page 4-2-6)




- ※ ① : Fuel injector coupler NO.1
 ② : Fuel injector coupler NO.2



ECU Coupler

“C37” SAV SOLENOID MALFUNCTION

<i>Comet 250</i> FI CODE	<i>Aquila 250</i> FI CODE
C37	
DETECTED CONDITION	POSSIBLE CAUSE
SAV solenoid voltage is not input in ECU.	● SAV solenoid circuit open or short. ● SAV solenoid malfunction. ● ECU malfunction.


INSPECTION

- 1) Remove the front seat.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the SAV solenoid coupler for loose or poor contacts.
- 4) Connect the SAV solenoid coupler.
- 5) Turn the ignition switch “ON” position.
- 6) Measure the voltage at the wire side coupler between GL wire and ground.

SAV solenoid voltage


Battery voltage
(⊕ GL – ⊖ Ground)

 **Tester knob indication : Voltage (---)**



Is the voltage OK?

YES	● GL wire open or shorted to ground, or ②⑥ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the SAV solenoid with a new one.



“C41” FUEL PUMP RELAY CIRCUIT MALFUNCTION

<i>Comet 250/R</i> FI CODE	<i>Aquila 250 FI</i> CODE
C41	
DETECTED CONDITION	POSSIBLE CAUSE
No voltage is applied to the both injectors for 3 sec. after the contact of fuel pump relay is turned “ON” position. Or voltage is applied to the both injectors, when the contact of fuel pump is “OFF” position.	● Fuel pump relay circuit open or short. ● Fuel pump relay malfunction. ● ECU malfunction.


▣ INSPECTION

◆ Step 1


- 1) Remove the frame cover.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the fuel pump relay coupler for loose or poor contacts.
If OK, then check the insulation and continuity.
Refer to page 4-2-6 for details.

- Ⓐ : Head lamp relay
Ⓑ : Fuel pump relay
Ⓒ : Main relay
Ⓓ : Turn signal relay

Aquila 250 FI




Comet 250/R FI



Is the Fuel pump relay OK?

YES	● GW wire open or shorted to ground, or poor② connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection. ● Inspect the fuel injectors. (Refer to page 4-1-28)
NO	Replace the fuel pump relay with a new one.



“C43” OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION

<i>Comet 250</i> FI CODE	<i>Aquila 250</i> FI CODE
C43	
DETECTED CONDITION	POSSIBLE CAUSE
Oxygen sensor heater signal is not input in ECU.	● Oxygen sensor, Oxygen sensor heater circuit open or short. ● Oxygen sensor, Oxygen sensor heater malfunction. ● ECU malfunction.


INSPECTION

- 1) Remove the frame cover.
- 2) Turn the ignition switch “OFF” position.
- 3) Check the Oxygen sensor heater coupler for loose or poor contacts.
If OK, then measure the Oxygen sensor heater voltage.
- 4) Disconnect the coupler and then the ignition switch “ON” position.
- 5) Measure the voltage between OB wire terminal and B (or ground) wire terminal.

Oxygen sensor heater voltage


Battery voltage
(⊕ OB – ⊖ B)
(⊕ OB – ⊖ Ground)

Tester knob indication : Voltage (---)



Is the voltage OK?

YES	● OB or B wire open or shorted to ground, or poor ⑰ or ⑳ connection. ● If wire and connection are OK, intermittent trouble or faulty ECU. ● Recheck each terminal and wire harness for open circuit and poor connection.
NO	Replace the Oxygen sensor.





SENSORS

⊙ IAP SENSOR INSPECTION

The intake air pressure (IAP) sensors NO.1 ① and NO.2 ② are installed at the upside of each intake pipe. (Refer to page 4-1-22)

⊙ IAP SENSOR REMOVAL AND INSTALLATION

- Remove the fuel tank.
- Remove the IAP sensor from the intake pipe.
- Install the IAP sensor in the reverse order of removal.




⊙ ET SENSOR INSPECTION

The engine temperature (ET) sensor ③ is installed at the engine case. (Refer to page 4-1-20)

⊙ ET SENSOR REMOVAL AND INSTALLATION

- Remove the ET sensor.
- Install the ET sensor in the reverse order of removal.

 ET sensor : 18 N · m (1.8 kgf · m)




⊙ IAT SENSOR INSPECTION

The intake air temperature (IAT) sensor ① is installed at the air cleaner case.

(Refer to page 4-1-24)

⊙ IAT SENSOR REMOVAL AND INSTALLATION

- Remove the fuel tank.
- Remove the IAT sensor from the air cleaner case.
- Install the IAT sensor in the reverse order of removal.



⊙ TO SENSOR INSPECTION, REMOVAL AND INSTALLATION

The tip over (TO) sensor ② is located in the frame.

- Remove the seat.
- Remove the TO sensor from the frame.
- Install the TO sensor in the reverse order of removal.



FUEL SYSTEM AND THROTTLE BODY


CONTENTS

FUEL SYSTEM	46 (4-2-1)
REMOVAL AND DISASSEMBLY (Comet 250/R FI)	47 (4-2-2)
REASSEMBLY AND INSTALLATION (Comet 250/R FI)	48 (4-2-3)
REMOVAL AND DISASSEMBLY (Aquila 250 FI)	49 (4-2-4)
REASSEMBLY AND INSTALLATION (Aquila 250 FI)	50 (4-2-5)
FUEL PRESSURE INSPECTION	51 (4-2-6)
FUEL PUMP RELAY INSPECTION	51 (4-2-6)
FUEL MESH FILTER INSPECTION AND CLEANING (Comet 250/R FI)	52 (4-2-7)
FUEL GAUGE INSPECTION	52 (4-2-7)
THROTTLE BODY	53 (4-2-8)
REMOVAL	54 (4-2-9)
CLEANING	55 (4-2-10)
INSPECTION	55 (4-2-10)
INSTALLATION	56 (4-2-11)

4-2

FUEL SYSTEM


Comet 250 / R FI



REMOVAL AND DISASSEMBLY (*Comet 250/R FI*)

- Remove the front seat.
- Remove the fuel tank mounting bolt and take off the hooks.

- Disconnect the fuel gauge coupler① .




- Remove the fuel pump coupler② .
- Remove the fuel injector hose③ and return hoses ④ .



CAUTION

After disconnecting the fuel injector hose③ , insert a blind plug into the end to stop fuel leakage.



4-2-3 FUEL SYSTEM AND THROTTLE BODY

- Remove the fuel tank rearward.

CAUTION


As gasoline leakage may occur in this operation, keep away from fire and sparks.

- Remove the fuel pump assembly ① by removing its mounting bolts diagonally.

WARNING

- ❖ Gasoline is highly flammable and explosive.
- ❖ Keep heat, spark and flame away.

- Remove the fuel gauge ② .



REASSEMBLY AND INSTALLATION

(Comet 250/R FI)


Reassembly and installation the fuel tank in the reverse order of removal and disassembly.

- When installing the fuel pump assembly, first tighten all the fuel pump assembly mounting bolts lightly in diagonal stages, and then tighten them in the above tightening order.

NOTE

Apply a small quantity of the **THREAD LOCK "1324"** to the thread portion of the fuel pump mounting bolt.


 **THREAD LOCK "1324"**



REMOVAL AND DISASSEMBLY

(*Aquila 250 FI*)


- Remove the front seat.
- Remove the fuel tank mounting bolts and take off the hooks.



- Disconnect the fuel gauge coupler①.




- Remove the fuel pump coupler②.



- Remove the fuel injector hose③ and return hose④.

**CAUTION**

After disconnecting the fuel injector hose③, insert a blind plug into the end to stop fuel leakage.



4-2-5 FUEL SYSTEM AND THROTTLE BODY

- Remove the fuel tank rearward.



CAUTION

As gasoline leakage may occur in this operation, keep away from fire and sparks.

- Remove the fuel pump assembly ① by removing its mounting bolts.




WARNING


- ❖ Gasoline is highly flammable and explosive.
- ❖ Keep heat, spark and flame away.

- Remove the FPR ② by removing its mounting bolt.

※ FPR : Fuel Pressure Regulator



- Remove the fuel gauge ③.



REASSEMBLY AND INSTALLATION

(*Aquila 250 FI*)

Reassembly and installation the fuel tank, fuel pump assembly and FPR in the reverse order of removal and disassembly.

FUEL PRESSURE INSPECTION

- Remove the front seat.
- Place a rag under the fuel injector hose.
- Disconnect the fuel injector hose from the fuel delivery pipe.
- Install the special tool between the fuel tank and fuel delivery pipe.

TOOL Fuel pump pressure gauge
: 09915-54510

Turn the ignition switch "ON" position and check the fuel pressure.

Fuel pressure

Approx. 3.4 ~ 3.7 kgf/cm²
(333 ~ 363 kPa, 48.4 ~ 52.6 psi)

If the fuel pressure is lower than the specification, inspect the following items :

- * Fuel hose leakage
- * Clogged fuel filter
- * Pressure regulator
- * Fuel pump

If the fuel pressure is higher than the specification, inspect the following items :

- * Fuel pump check valve
- * Pressure regulator



⚠ WARNING

- Before removing the special tool, turn the ignition switch to "OFF" position and release the fuel pressure slowly.
- Gasoline is highly flammable and explosive. Keep heat, sparks and flame away.

FUEL PUMP RELAY INSPECTION

Fuel pump relay is located the left side of the frame.


- Remove the frame cover.
- Remove the fuel pump relay①.



4-2-7 FUEL SYSTEM AND THROTTLE BODY

First, check the insulation between ① and ② terminals with pocket tester. Then apply 12 volts to ③ and ④ terminals, ⊕ to ③ and ⊖ to ④, and check the continuity between ① and ②.

If there is no continuity, replace it with a new one.




FUEL MESH FILTER INSPECTION AND CLEANING

(*Comet 250/ R FI*)

- If the fuel mesh filter is clogged with sediment or rust, fuel will not flow smoothly and loss in engine power may result.
- Blow the fuel mesh filter with compressed air.

NOTE

If the fuel mesh filter is clogged with many sediment or rust, replace the fuel filter cartridge with a new one.




FUEL GAUGE INSPECTION


- Measure resistance between the terminals when float is at the position instead below.

Fuel float position	Resistance between terminals
F	Approx. 90 ~ 105 Ω
1/2	Approx. 38 Ω
E	Approx. 4 ~ 10 Ω

- If the resistance measured is out of the specification, replace the gauge with a new one.
- Fuel level meter inspection.



THROTTLE BODY




REMOVAL

- Remove the fuel tank.
- Remove the air cleaner box.
- Disconnect the fuel hose.
- Remove the all coupler to related the throttle body.



- Loosen the throttle body clamp screws.



- Disconnect the throttle cables from their drum.
- Dismount the throttle body assembly.



CAUTION

- ❖ Be careful not to damage the throttle cable bracket when dismounting or remounting the throttle body assembly.
- ❖ After disconnecting the throttle cables, do not snap the throttle valve from full open to full close. It may cause damage to the throttle valve and throttle body.



CLEANING


- Clean all passageways with a spray-type throttle body cleaner and blow dry with compressed air.

WARNING

Some throttle body cleaning chemicals, especially dip-type soaking solutions, are very corrosive and must be handled carefully. Always follow the chemical manufacturer's instructions on proper use, handling and storage.

CAUTION

Do not use wire to clean passageways. Wire can damage passageways. If the components cannot be cleaned with a spray cleaner it may be necessary to use a dip-type cleaning solution and allow them to soak. Always follow the chemical manufacturer's instructions for proper use and cleaning of the throttle body components. Do not apply throttle body cleaning chemicals to the rubber and plastic materials.




INSPECTION

- Check following items for any damage or clogging.
 - * O-ring
 - * Secondary throttle valve
 - * Throttle shaft bushing and seal
 - * Injector cushion seal
 - * Throttle valve
 - * Vacuum hose

Check fuel injector filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in the fuel lines and fuel tank.

CAUTION

Never operate the idle screws ① (NO.1) and ② (NO.2) to avoid variations of the carburetion setting.




INSTALLATION

Installation is in the reverse order of removal.

Pay attention to the following points :

- Connect the throttle cable to the throttle cable drum.
- Adjust the throttle cable play with the cable adjusters.




ELECTRICAL SYSTEM


CONTENTS

<i>LOCATION OF ELECTRICAL COMPONENTS</i>	<i>58 (5-1)</i>
<i>IGNITION SYSTEM</i>	<i>60 (5-3)</i>
<i>CHARGING SYSTEM</i>	<i>61 (5-7)</i>


LOCATION OF ELECTRICAL COMPONENTS





① Ignition coil NO.1
② Ignition coil NO.2




③ Main relay
④ Fuel pump relay
⑤ Head lamp relay




⑥ Main fuse (30A)
⑦ ECU
⑧ Head lamp fuse (15A)
⑨ Battery




⑩ IAT sensor



⑪ TO sensor





⑫ Magneto
⑬ Pick-up coil
⑭ GP switch





⑮ ISC solenoid




⑯ IAP sensor NO.1
⑰ ET sensor
⑱ IAP sensor NO.2




⑲ SAV solenoid



⑳ Oxygen sensor




㉑ Fuel injector NO.2



㉒ Fuel injector NO.1

IGNITION SYSTEM



⊙ INSPECTION



▣ IGNITION COIL RESISTANCE INSPECTION

● Disconnect the ignition coil read wire.
Measure the ignition coil resistance in bolt the primary and secondary windings. If the resistance is not within the standard range, replace the ignition coil with a new one.

IGNITION COIL / PLUG CAP RESISTANCE

Primary	3.5 ~ 5.5 Ω (⊕ Terminal – ⊖ Terminal)
Secondary	20 ~ 31 K Ω (Plug cap – ⊕ Terminal)

Tester knob indication : Resistance (K Ω)



▣ MAGNETO

Using the pocket tester, measure the resistance between the lead wires in the following table.
If the resistance is not within the specified value, replace the magneto coil, with a new one.

Magneto coil resistance	Standard
Pick-up coil	G - L Approx. 85 ~ 105 Ω
Charging coil	Y - Y Approx. 0.2 ~ 1.0 Ω

 **Tester knob indication : Resistance (Ω)**

CAUTION

When mounting the stator on the magneto cover, apply a small quantity of THREAD LOCK "1324" to the threaded parts of screws.

 **THREAD LOCK "1324"**

WIRE COLOR

L : Blue
G : Green
Y : Yellow
BY : Black with Yellow tracer
OB : Orange with Black tracer
Br : Brown
BW : Black with White tracer
WL : White with Blue tracer
YG : Yellow with Green tracer

▣ MAGNETO NO-LOAD PERFORMANCE

Disconnect the three lead wires from the magneto terminal.



Start the engine and keep it running at 5,000 rpm.

Using the pocket tester, measure the AC voltage between the three lead wires.


If the voltage is under the specified value, replace the magneto with a new one.

NO-load performance of magneto	Standard
	Over 60 V (at 5,000 rpm)

 **Tester knob indication : Voltage (---)**



CHARGING SYSTEM



⦿ INSPECTION

▣ CHARGING OUTPUT CHECK

Start the engine and keep it running at 5,000 rpm. Using the pocket tester, measure the DC voltage between the battery terminal $\oplus$ and $\ominus$. If the voltage is not within the specified value, check the magneto no-load performance and regulator / rectifier.




CAUTION

When making this test, be sure that the battery is full-charged condition.

Standard charge 13.5~15.0 V (at 5,000 rpm)

 Tester knob indication : Voltage (---)





REGULATOR / RECTIFIER

- Disconnect the regulator / rectifier couplers.
 - Using the pocket tester, measure the resistance between the terminals in the following table.
- If the resistance checked is incorrect, replace the regulator / rectifier.

Unit : MΩ

⊕ Tester probe						
⊖ Tester probe	①	②	③	④	⑤	
	①	3~4	3~4	1~2	1~2	
	②	3~4	3~4	1~2	1~2	
	③	3~4	3~4	1~2	1~2	
	④	1~2	1~2	1~2	32kΩ	
	⑤	1~2	1~2	1~2	32kΩ	

 Tester knob indication : Resistance (MΩ)



SERVICING INFORMATION

CONTENTS

TROUBLESHOOTING	66 (7-1-1)
SPECIAL TOOLS	75 (7-8)
TIGHTENING TORQUE	76 (7-11)
SERVICE DATA	77 (7-19-1)
WIRING DIAGRAM (<i>Aquila</i> 250 FI)	80 (7-31-1)
WIRING DIAGRAM (<i>Comet</i> 250 FI)	82 (7-31-3)
WIRING DIAGRAM (<i>Comet</i> 250 <i>R</i> FI)	84 (7-31-5)

TROUBLESHOOTING

◎ MALFUNCTION CODE AND DEFECTIVE CONDITION

MALFUNCTION CODE	DETECTED ITEM	DETECTED FAILURE CONDITION
		CHECK FOR
C15	Engine temperature sensor (ETS)	The sensor voltage should be the following. $0.1\text{ V} \leq \text{sensor voltage} < 4.6\text{ V}$ Without the above range for 4 sec. and more, C15 is indicated.
		Engine temperature sensor, lead wire / coupler connection.
C17 / C18	Intake air pressure sensor (IAPS), NO.1 / NO.2	The sensor should produce following voltage. $0.1\text{ V} \leq \text{sensor voltage} \leq 4.8\text{ V}$ Without the above range for 4 sec. and more, C17 or C18 is indicated.
		Intake air pressure sensor, lead wire / coupler connection.
C21	Intake air temperature sensor (IATS)	The sensor voltage should be the following. $0.1\text{ V} \leq \text{sensor voltage} < 4.6\text{ V}$ Without the above range for 4 sec. and more, C21 is indicated.
		Intake air temperature sensor, lead wire / coupler connection.
C22	Oxygen sensor (O ₂ S)	The oxygen sensor signal is input in ECU since then more than 120 sec. after the engine run. When this is the case, ECU not receive the signal, C22 is indicated.
		Oxygen sensor, lead wire / coupler connection.

MALFUNCTION CODE	DETECTED ITEM	DETECTED FAILURE CONDITION
		CHECK FOR
C24 / C25	Ignition coil (IG coil), NO.1 / NO.2	When the IC of the ECU electric current gets 6 A and more, C24 or C25 is indicated.
		Ignition coil, wiring / coupler connection, power supply from the battery.
C27	Idle speed control solenoid (ISC solenoid)	The idle speed control solenoid step should be the following. O step $\leq$ solenoid step $\leq$ 100 step Without the above range, C27 is indicated.
		Idle speed control solenoid, lead wire / coupler connection.
C32 / C33	Fuel injector, NO.1 / NO.2	The fuel injector not comes in voltage from the battery, C32 or C33 is indicated.
		Injector, wiring / coupler connection, power supply to the injector.
C37	Secondary air valve solenoid (SAV solenoid)	When the secondary air valve solenoid voltage is not input in ECU, C37 is indicated.
		Secondary air valve solenoid, lead wire / coupler connection.
C41	Fuel pump relay	No voltage is applied to the both injectors 3 for 3 sec. after the contact of fuel pump relay is turned "ON" position. Or voltage is applied to the both injectors, when the contact of fuel pump is "OFF" position.
		Fuel pump relay, connecting lead wire, power source to fuel pump relay, fuel injector.
C43	Oxygen sensor heater (O ₂ S heater)	The oxygen sensor heater signal is not input in ECU.
		Oxygen sensor heater, lead wire / coupler connection.

ENGINE

Complaint	Symptom and possible causes	Remedy
Engine will not start or is hard to start.	Compression too low 1. Tappet clearance out of adjustment. 2. Worn valve guides or poor seating of valves. 3. Mistimed valves. 4. Excessively worn piston rings. 5. Worn-down cylinder bore. 6. Starter motor cranks too slowly. 7. Poor seating of spark plugs.	Adjust. Repair or replace. Adjust. Replace. Replace. See electrical section. Retighten.
	Plug not sparking 1. Fouled spark plugs. 2. Wet spark plugs. 3. Defective ignition coils. 4. Open or short in high-tension cord. 5. Defective pick-up coil. 6. Defective ECU. 7. Open-circuited wiring connections.	Clean. Clean and dry. Replace. Replace. Replace. Replace. Repair or replace.
	No fuel reaching the intake manifold 1. Clogged fuel filter or fuel hose. 2. Defective fuel pump. 3. Defective fuel pressure regulator. 4. Defective fuel injector. 5. Defective fuel pump relay. 6. Defective ECU. 7. Open-circuited wiring connections.	Clean or replace. Replace. Replace. Replace. Replace. Replace. Check and repair.
	Incorrect fuel / air mixture 1. Defective fuel pump. 2. Defective fuel pressure regulator. 3. Defective pick-up coil. 4. Defective IAP sensor. 5. Defective ECU. 6. Defective ET sensor. 7. Defective IAT sensor.	Replace. Replace. Replace. Replace. Replace. Replace. Replace.

Complaint	Symptom and possible causes	Remedy
Engine idles poorly.	1. Tappet clearance out of adjustment. 2. Poor seating of valves. 3. Defective valve guides. 4. Worn down camshafts. 5. Too wide spark plug gaps. 6. Defective ignition coils. 7. Defective pick-up coil. 8. Defective ECU. 9. Defective fuel pump. 10. Imbalanced throttle valve or SAV solenoid. 11. Damaged or cracked vacuum hose.	Adjust. Replace or repair. Replace. Replace. Adjust or replace. Replace. Replace. Replace. Replace. Adjust. Replace.
Engine stalls often	Incorrect fuel / air mixture 1. Defective IAP sensor or circuit. 2. Clogged fuel filter. 3. Defective fuel pump. 4. Defective fuel pressure regulator. 5. Defective ET sensor. 6. Defective IAT sensor. 7. Damaged or cracked vacuum hose. Fuel injector improperly operating 1. Defective fuel injectors. 2. No injection signal from ECU. 3. Open or short circuited wiring connection. 4. Defective battery or low battery voltage. Control circuit or sensor improperly operating 1. Defective ECU. 2. Defective fuel pressure regulator. 3. Defective IAT sensor. 4. Defective pick-up coil. 5. Defective ET sensor. 6. Defective fuel pump relay. Engine internal parts improperly operating 1. Fouled spark plugs. 2. Defective pick-up coil or ECU. 3. Clogged fuel hose. 4. Tappet clearance out of adjustment.	Repair or replace. Clean or replace. Replace. Replace. Replace. Replace. Replace. Replace. Repair or replace. Repair or replace. Replace or recharge. Replace. Replace. Replace. Replace. Replace. Replace. Clean. Replace. Clean. Adjust.

Complaint	Symptom and possible causes	Remedy
Noisy engine.	Excessive valve chatter 1. Too large tappet clearance. 2. Weakened or broken valve springs. 3. Worn tappet or cam surface. 4. Worn and burnt camshaft journal.	Adjust. Replace. Replace. Replace.
	Noise seems to come from piston 1. Worn down pistons or cylinders. 2. Combustion chambers fouled with carbon. 3. Worn piston pins or piston pin bore. 4. Worn piston rings or ring grooves.	Replace. Clean. Replace. Replace.
	Noise seems to come from cam chain 1. Stretched chain. 2. Worn sprockets. 3. Tension adjuster not working.	Replace. Replace. Repair or replace.
	Noise seems to come from clutch 1. Worn splines of countershaft or hub. 2. Worn teeth of clutch plates. 3. Distorted clutch plates, driven and drive. 4. Worn clutch release bearing. 5. Weakened clutch dampers.	Replace. Replace. Replace. Replace. Replace the primary driven gear.
	Noise seems to come from crankshaft 1. Rattling bearings due to wear. 2. Worn and burnt big-end bearings. 3. Worn and burnt journal bearings.	Replace. Replace. Replace.
	Noise seems to come from transmission 1. Worn or rubbing gears. 2. Worn splines. 3. Worn bearings. 4. Worn or rubbing primary gears.	Replace. Replace. Replace. Replace.

Complaint	Symptom and possible causes	Remedy
Engine runs poorly in high speed range.	Defective engine internal / electrical parts 1. Weakened valve springs. 2. Worn camshafts. 3. Valve timing out of adjustment. 4. Too narrow spark plug gaps. 5. Ignition not advanced sufficiently due to poorly working timing advance circuit. 6. Defective ignition coils. 7. Defective pick-up coil. 8. Defective ECU. 9. Clogged fuel hose, resulting in inadequate fuel supply to injector. 10. Defective fuel pump. 11. Defective SAV solenoid. 12. Clogged air cleaner element.	Replace. Replace. Adjust. Adjust. Replace ECU. Replace. Replace. Replace. Clean and prime. Replace. Replace. Clean.
	Defective air flow system 1. Clogged air cleaner element. 2. Defective throttle valve. 3. Sucking air from throttle body joint. 4. Defective ECU.	 Clean or replace. Adjust or replace. Repair or replace. Replace.
	Defective control circuit or sensor 1. Low fuel pressure. 2. Defective IAT sensor. 3. Defective pick-up coil. 4. Defective IAP sensor. 5. Defective ECU. 6. Defective SAV solenoid.	 Repair or replace. Replace. Replace. Replace. Replace. Replace.


Complaint	Symptom and possible causes	Remedy
Engine lacks power.	Defective engine internal / electrical parts 1. Loss of tappet clearance. 2. Weakened valve springs. 3. Valve timing out of adjustment. 4. Worn piston rings or cylinders. 5. Poor seating of valves. 6. Fouled spark plugs. 7. Incorrect spark plugs. 8. Clogged injectors. 9. Clogged air cleaner element. 10. Sucking air from throttle valve or vacuum hose. 11. Too much engine oil. 12. Defective fuel pump or ECU. 13. Defective pick-up coil and ignition coils. Defective control circuit or sensor 1. Low fuel pressure. 2. Defective IAT sensor. 3. Defective pick-up coil. 4. Defective IAP sensor. 5. Defective ECU. 7. Defective SAV solenoid. 8. Defective GP switch.	Adjust. Replace. Adjust. Replace. Repair. Clean or replace. Adjust or replace. Clean. Clean. Retighten or replace. Drain out excess oil. Replace. Replace. Repair or replace. Replace. Replace. Replace. Replace. Replace. Replace.
Engine overheats.	Defective engine internal parts 1. Heavy carbon deposit on piston crowns. 2. Not enough oil in the engine. 3. Defective oil pump or clogged oil circuit. 4. Sucking air from intake pipes. 5. Use incorrect engine oil. 6. Defective oil cooler. Lean fuel / air mixture 1. Short-circuited IAP sensor / lead wire. 2. Short-circuited IAT sensor / lead wire. 3. Sucking air from intake pipe joint. 4. Defective fuel injectors. 5. Defective ET sensor. The other factors 1. Ignition timing too advanced due to defective timing advance system (ET sensor, pick-up coil, GP switch and ECU). 2. Drive chain is too tight.	Clean. Add oil. Replace or clean. Retighten or replace. Change. Clean or replace. Repair or replace. Repair or replace. Repair or replace. Replace. Replace. Replace. Adjust.

Complaint	Symptom and possible causes	Remedy
Dirty or heavy exhaust smoke.	1. Too much engine oil in the engine. 2. Worn piston rings or cylinders. 3. Worn valve guides. 4. Cylinder wall scored or scuffed. 5. Worn valves stems. 6. Defective stem seals. 7. Worn side rails.	Check with inspection window, drain out excess oil. Replace. Replace. Replace. Replace. Replace. Replace.
Slipping clutch.	1. Weakened clutch springs. 2. Worn or distorted pressure plates. 3. Distorted clutch plates or pressure plates.	Replace. Replace. Replace.
Dragging clutch.	1. Some clutch springs weakened while others are not. 2. Distorted pressure plates or clutch plates.	Replace. Replace.
Transmission will not shift.	1. Broken gearshift cam. 2. Distorted gearshift forks. 3. Worn gearshift pawl.	Replace. Replace. Replace.
Transmission will not shift back.	1. Broken return spring on shift shaft. 2. Rubbing or sticky shift shaft. 3. Distorted or worn gearshift forks.	Replace. Repair or replace. Replace.
Transmission jumps out of gear.	1. Worn shifting gears on driveshaft or countershaft. 2. Distorted or worn gearshift forks. 3. Weakened stopper spring on gearshift stopper.	Replace. Replace. Replace.

⊙ ELECTRICAL

Complaint	Symptom and possible causes	Remedy
No sparking or poor sparking.	1. Defective ignition coils or spark plug caps. 2. Defective spark plugs. 3. Defective pick-up coil. 4. Defective ECU. 5. Defective TO sensor. 6. Open-circuited wiring connections.	Replace. Replace. Replace. Replace. Replace. Check and repair.
Spark plug soon become fouled with carbon.	1. Mixture too rich. 2. Idling speed set too high. 3. Incorrect gasoline. 4. Dirty element in air cleaner. 5. Spark plugs too cold.	Inspect FI system. Adjust fast idle or throttle stop screw. Change. Clean or replace. Replace by hot type plug.
Spark plug become fouled too soon.	1. Worn piston rings. 2. Pistons or cylinders worn. 3. Excessive clearance of valve stems in valve guides. 4. Worn stem oil seal.	Replace. Replace. Replace. Replace.
Spark plug electrodes overheat or burn.	1. Spark plugs too hot. 2. The engine overheats. 3. Spark plugs loose. 4. Mixture too lean.	Replace by cold type plug. Tune up. Retighten. Adjust carburetor.
Magneto charge, but charging rate is below the specification.	1. Lead wires tend to get shorted or open-circuited or loosely connected at terminals. 2. Grounded or open-circuited stator coils of magneto. 3. Defective regulator / rectifier. 4. Defective cell plates in the battery.	Repair or retighten. Replace. Replace. Replace the battery.
Magneto overcharges.	1. Internal short - circuit in the battery. 2. Resistor element in the regulator / rectifier damaged or defective. 3. Regulator / rectifier poorly grounded.	Replace the battery. Replace. Clean and tighten ground connection.
Magneto does not charge.	1. Open - or short - circuited lead wire, or loose lead connections. 2. Short - circuited, grounded or open stator coil. 3. Short - circuited or punctured regulator / rectifier.	Repair or replace or retighten. Replace. Replace.
Unstable charging.	1. Lead wire insulation frayed due to vibration resulting in intermittent shorting. 2. Magneto internally shorted. 3. Defective regulator / rectifier.	Repair or replace. Replace. Replace.
Starter switch is not effective.	1. Battery run down. 2. Defective switch contacts. 3. Brushes not seating properly on commutator in starter motor. 4. Defective starter relay / ignition interlock switch. 5. Defective main fuse.	Recharge or replace. Replace. Repair or replace. Replace. Replace.

SPECIAL TOOLS

Special tools	Part Number · Part Name · Description
	09900-27000 Mode select switch
	Inspect FI system sensor. (Only for "Comet 250/2 FI")
	09915-54510 Fuel pump pressure gauge
	Measure fuel pressure of fuel pump.

TIGHTENING TORQUE

⊙ FI SYSTEM PARTS

ITEM	N · m	kgf · m
Engine temperature sensor (ET sensor)	18	1.8
Fuel injector bolt	6 ~ 8	0.6 ~ 0.8

SERVICE DATA

⦿ FI SENSORS

ITEM	SPECIFICATION		NOTE
IAP sensor input voltage	4.5 ~ 5.5 V		
IAP sensor output voltage	Approx. 4.0 ~ 4.2 V when ignition switch "ON"		
IAT sensor voltage	4.5 ~ 5.5 V		
IAT sensor resistance	Refer to page 34 (4-1-25)		
TO sensor voltage	4.5 ~ 5.5 V at normal condition (To sensor switch - "ON" at leaned more than 60°)		
SAV solenoid voltage	Battery voltage		
Oxygen sensor heater voltage	Battery voltage		
ET sensor voltage	4.5 ~ 5.5 V		
ET sensor resistance (To ECU)	0°C (32°F)	Approx. 28.788 KΩ	
	20°C (68°F)	Approx. 12.209 KΩ	
	40°C (104°F)	Approx. 5.671 KΩ	
	60°C (140°F)	Approx. 2.845 KΩ	
	80°C (176°F)	Approx. 1.525 KΩ	

⊙ THROTTLE BODY

ITEM	SPECIFICATION	NOTE
I.D. No.	GT250	
Bore size	∅ 28	
Idle rpm	1,400 ~ 1,600 rpm	
Throttle cable play	0.5 ~ 1.0 mm (0.02 ~ 0.04 in)	

⊙ FUEL INJECTOR + FUEL PUMP


ITEM	SPECIFICATION	NOTE
Fuel injector resistance	11.5 ~ 13.5 Ω at 20°C (68°F)	
Fuel injector voltage	Battery voltage	
Fuel pressure	Approx. 3.4 ~ 3.7 kgf/cm ² (333 ~ 363 kPa, 48.4 ~ 52.6 psi)	

⊙ ELECTRICAL

Unit : mm (in)


ITEM	STANDARD		NOTE
Ignition timing	BTDC 13° / 2,000rpm ~ 30° / 6,000rpm		
Spark plug	Type	CR8E	
	Gap	0.7 ~ 0.8 (0.028 ~ 0.032)	
	Hot type	CR7E	
	Standard type	CR8E	
	Cold type	CR9E	
Spark performance	Over 8 mm (0.32 in)		
Ignition coil primary peak voltage	150 V and more		
Ignition coil resistance	Primary	3.5 ~ 5.5 Ω	
	Secondary	20 ~ 31 KΩ	
Magneto coil resistance	Pick-up coil	Approx. 85 ~ 105 Ω	G-L
	Charging coil	Approx. 0.2 ~ 1.0 Ω	Y-Y
Magneto no-load voltage	Over 60 V / 5,000 rpm		
Battery standard charging voltage	13.5 ~ 15.0 V / 5,000 rpm		
Battery	Type	STX14-BS	
	Capacity	12V 12Ah	
	Standard electrolyte S.G.	1.320 at 20°C (68°F)	
Fuse size	Main	30A	
	Head lamp	15A	


WIRING DIAGRAM (*Aquila 250 FI*)






WIRING DIAGRAM (*Comet 250 FI*)









MEMO

MEMO

Prepared by



1st Ed. OCT. 2008.

Manual No. 99000-95610

Printed in Korea

S&T Motors Co., Ltd.