

# Ice Star ISPort

## User Guide Part 2

**- Device Configuration**

**Versio 11**

ISDOK:

**DPM2\_EN\_V11**


## Directory

Device info: Device settings.....	3
Program and update: Updating hardware.....	8
I/O Configuration: I/O Configuration, ICM Calibration.....	9
Temperature controllers: Controller defaults.....	15
Calibration: Calibrating ISC/ISD.....	17
Process instructions: Heating plan.....	19
Completed processes: Completed processes and recovering.....	20
System events: System events.....	20
Printing: Printing.....	20


## Device Info

Device Info

This tab contains a variety of settings assembled to different devices.



By pressing "Download/Save" buttons, can settings be returned from PCs memory to the devices memory or save to PCs memory from the devices memory



## Return the settings

Open the "Load settings" dialog by clicking on "Download" button. Choose from the list wanted format (settings).

### I/O-settings

Devices IO-configuration and calibration.

### Calibration


Calibration chart and calibration certificates info

### Led panel

Led panels settings.


### Options 1

Device info, temperature controllers settings, PWE settings, recording, overheat limit and PIN code




## Save settings

Open the dialog with the "Save" button. Give a fitting name to the settings and press "OK". All device settings are saved to the same file, so it is important to at least announce what kind of device in question. Settings are saved in the DEFAULT.TB1 file.



Open the "General settings for the device" dialog by pressing "Settings" button



**[1] Device ID (Used on this PC)**

When programs and documents refer to this device, this ID code is used. If the ID field is empty it is automatically filled with the ID saved in the device.

**[2] Device ID (in the device's memory)**

This ID is used if device ID if empty.

**3 ID**

Device ID number. The number is used when more than one device (ISC) are connected to the same data channel (RS-485). The number must be between 1-15 and all the devices connected to the same channel, must have a different number. Since the devices in the same channel (eg, a furnace) send data to each other, the ID number works as a transmission queue number. There can be up to fifteen devices in the same channel (ISC). The ID number is not used in the communication between the devices and the PC, so devices that are not connected to each other via the channel, may use the same ID number.


**4 the PIN code**

A code can be set to protect the device from unwanted users. Each time the device is connected to the ISPort program, its PIN code is checked. If the right PIN code has not been saved on the PC, it will be asked for from the user at the beginning of connecting. When the code is correct, it is saved to the PC's memory, and not asked for at the next times of connecting. If the PIN code field is left empty, the code is not in use, and the device can be connected to with all ISPort programs.

**[5] Zigbee settings**

- Zigbee modem installed: Always chosen when Zigbee is in use. This choice must be there to use Zigbee connection
- ZB modem used to transfer messages to other modules: Always chosen when Zigbee is used
- Process status sent by ZB modem: Chosen when more then one controller is connected to same process with Zigbee

Edit the BT settings by pressing "Bluetooth" button



Device ID: ISPort automatically reads the devices ID  
 Set Pin code if in use  
 Serial nr: ISPort automatically reads the devices serial number  
 Port (Com xx) to be used: Set the (seding) COM port number that the PC has given from the PCs Bluetooth settings

## ISC Module settings

Edit device module settings by pressing "ISC" button.



### [1] Fast operation mode

In fast processes the step execution time needs to be short, so that fast timings are possible. Therefore, the device can be set to high-speed operation mode, wherein the step time is one second instead of the normal 13 s. In the high-speed operation mode data transfer between the devices is not used, so all controllers used in the same process must be located in the same device (ISC), a maximum of six controllers for heating. Expansion I/O modules (ISD) can be used normally.

### [2] Slow PID-controller


Suitable for furnace

### [3] Output Power monitor active

Output current detection active. If more than 1A current is detected when there should not be any current (0% output power), then output 9006 is activated.

### [4] The overheating limit value


The maximum operating temperature for the device can be set. If any of the controllers exceed this limit, then after a short delay the output 9006 is activated. The output can be used as an alarm trigger or for example for disconnecting power from heaters. This heat limit should be used only in error situations.



### [5] Serial numbers of connected I/O-units (ISD)

ISD expansion units connected to the ISC controller, must be defined. One or more ISD expansion unit can be connected to the ISC unit using the I/O channel (CAN). The serial number list is saved to the device's memory by the "Use" button.

Edit GSM settings by pressing on "GSM" button



### [1] GSM

Choose "GSM modem in use". Set the phone number in form "+..."

### [2] Device

Choose from which error situations a SMS will be send.

### [3] Process

Choose from which process situations a SMS will be send. An alarm will be given once per phase, if the process moves on to the next phase and the error is not fixed, same SMS will be send again.

### [4] Controller

Choose from which controller situations a SMS will be send. Alarm is given when error happens.


### [5] SMS are sending periodically

Choose how often and when a textmessage is sent

### [6] Send test SMS

Test the GSM modem, the text message will be sent within one minut after "Use" button is pressed.

Use and edit simulation by pressing on "Simulation" button



When using the I/O simulation, temperature measurements to controllers are disconnected, and replaced by calculated temperatures. The controller calculates the temperature using the output power and the simulation parameters.

***The simulation should not be turned on if the outputs are connected to the real heating systems.***

Simulation is activated by checking the box "IO simulation in use" and pressing the "Use" button. When the device is turned on, or it is reset, the simulation is not active by default. If you wish to reset the temperatures used by the simulation, the simulation is turned off and then back on again.

**The parameters affecting the calculation:**

#### Insulation thickness (1-250)

Affects heat dissipation. 70% of the heat dissipates through the resistor and the rest through the object. The amount of energy bind to the resistor cannot be changed.

#### Heat transfer (1-250)

Affects the transfer of heat from the resistor to the object, and since most of the heat dissipates through the resistor, the cooling of the object. Heat transfer improves as the value increases.

#### The controllers' load (1-100)

Each controller can be given a separately simulated load, which, together with the heat transfer determines the dynamics of the controller. The larger the mass and the slower the heat transfer the longer the adjustment range needs to be.


***The temperature of the resistors and the energy attached to them can be seen by specifying the additional virtual measurement points in the I/O configuration and using these in the project. The simulated resistor temperature IO numbers are 9601-9606.***

28	Virtual	8551	1	9601	Simulated heater 1
29	Virtual	8552	2	9602	Simulated heater 2
30	Virtual	8553	3	9603	Simulated heater 3
31	Virtual	8554	4	9604	Simulated heater 4
32	Virtual	8555	5	9605	Simulated heater 5
33	Virtual	8556	6	9606	Simulated heater 6

Edit the display settings by pressing "Display" button




*Every device with display, (ISQ, ISNxx), has different display settings*



ISQ

**Controller, processes can be altered directly from the keypad**




ISN2

**Shows all process average values at once. Process can be controlled from the panel**

- Buttons locked: Can not use buttons on the ISQs panel
- Fahrenheit: Temperatures as fahrenheit, normally celsius
- Display period and brightness: Adjust led and screen brightness and period
- Shown parameters: Choose what parameters are shown in ISQ display


- Adjust same settings as ISQs displaysettings
- Also:
  - Devices: Set ID nr for which controllers are showed. Empty (0), shows automatically all devices connected to the same CAN bus
  - Controllers/Processes: Choose all
  - Parameters: Choose which parameters that will be visible

**ISN2 must have own ID nr if process want to be controlled from the keypad (Settings --> Set ID nr 1-15) the ID nr must be different from any else ID nr that is in use**



ISN1A

**Shows one controllers all values (Power, error etc.)**



ISN1B

**Shows at a time all controllers values (Power, error etc.)**

- Adjust same settings as ISN2
- Controllers: Choose which controllers values are shown
- Parameters: Choose which parameters are shown

- Adjust same settings as ISN2
- Controllers: Shows automatically all controllers
- Parameters: Choose which parameters are shown



## Program and update

Program and update


The ISx devices' programs are located in the CPU flash memory. If necessary, the programs can be updated and new programmatic features can be introduced. The software consists of the operating system, and the program modules operating under this. This design allows the software to be updated in parts, and if necessary new modules can be added.

At the list are program modules currently loaded and running. If a later version of the module is saved to the UPD directory, the column of the list will display a "New Version" message.

The program modules can be updated in two ways, manually or automatically.

### **When you update, always connect with fixed line (USB, RS232) to PC**

#### Automatic update




16	EF	Module	14:1	1	FF	1.12	1.13	25.12.12	Ledpanel interface
17	F0	Module	11:1	1	FF	1.22		19.03.13	6C Pid Controller

When updating a module, always connect device with cable (USB, RS232) to PC. Make sure no processes are in progress when you update.

- 1 If operating system (IsRTos) is new, must it be updated first.
  - Doubleclick on operating systems row, press start download.
  - Reset device
  - Power off and back on
  - Device reads the newest operating system to memory
- 2 Next all other modules can be updated

Start the update with "Update all" button. All marked modules are update on at the time, when modules are updated, ISPort automatically resets the device.

#### Manual update



ISQ Interface EN		Module	
Current Version		Downloadable version	
1.13		1.16	
04.03.15		16/11	
16/11		3	



**Version Nr.**



**Module ID**

The program modules can be updated manually. If you do not want to update the selected module, or if you want to remove a program module, or reload same version again, updating can be done manually.

- 1 The module to be processed is selected from the list
- 2 Open the update dialogue with the "Load/Remove" button

The module is removed by the "Remove" button, in the case that a new module is not downloaded to replace the removed one. This must be done with caution, because all modules have a specific task.


- 3 If a newer version of the module can be found in the UPD directory, this will be chosen by default into the "Download version" - section.

If desired, the pre-selected version can be changed, or if the same module is reloaded, the download of the selected module done by the "Select" button. It is essential that the ID number (type) of the module to be downloaded, is same as the module to be updated.

- 4 The download is started by the "Start downloading" button.
- 5 After the deletion or download, the dialogue is closed by the "Close" button.
- 6 Go back to step 1 and carry out the same procedure for all modules to be processed.
- 7 Finally, the system is started by the "Reset" button or by moving away from the "Program" tab.



# I/O Configuration





The largest I/O-point count for ISx devices is 42. The first three points have been taken into the system's use, and the rest are free for the user. The I/O points are connected in order to the installed I/O adapters, that will finally define the type and quantity of the I/O points. All of the I/O points used in the system have their own ID number, that define how the I/O-point is used in the system. The values used by the system and their ID numbers are specified in the range of 1 - 9299. Free ID numbers for the user are between 9300 -9599.

If the I/O-point defined by the user, is located in the I/O expansion unit (ISD), then it must be added to the ISC's I/O-list virtually. For this all the rest of the (empty) I/O points are available for use.

No.	I/O Type	Modul-ID (used)	Description (I/O Name)	I/O-Point location	Variable ID	Variable Name	Value	Status
1	Analog Lores		Käyttöjännite	0: 1	9301	Operation power	26.229 mV	
2	Analog Lores		Lämpötila	0: 2	9302	Device temperature (Power supply)	45.8°C	
3	Analog Lores		TC Cold End	0: 3	9303	Connector temperature (Cold end)	46.6°C	
4	Analog HRes			1: 1	4355	Controller 1 Temperature (Measured)	52.9°C	
5	Analog HRes		[R1 Tc]	1: 2	4387	Controller 2 Temperature (Measured)	60.2°C	
6	Analog HRes		[R5 Tc]	1: 3	9337	Cold End measurement 1		Manual
7	Analog HRes		[R6 Tc]	2: 1	4419	Controller 3 Temperature (Measured)	51.3°C	
8	Analog HRes		[R2 Tc]	2: 2	4451	Controller 4 Temperature (Measured)	63.1°C	
9	Analog HRes	0	[R4 Tc]	2: 3	9338	Cold End measurement 2		Manual
10	Analog HRes			3: 1	4483	Controller 5 Temperature (Measured)		
11	Analog HRes			3: 2	4515	Controller 6 Temperature (Measured)		Manual
12	Analog HRes	0		3: 3	9339	Cold End measurement 3		Manual
13	Digital Out			4: 1	8483	Controller 1 Output Power %	4 %	
14	Digital Out			4: 2	8485	Controller 2 Output Power %	4 %	
15	Digital Out			4: 3	8517	Controller 3 Output Power %	5 %	
16	Digital Out			4: 4	8549	Controller 4 Output Power %	5 %	
17	Digital Out	0	Poverin lampolla	4: 5	8195	Process 1 Measured temperature AVG		
18	Digital Out			4: 6	0			
19	Digital Out			5: 1	8581	Controller 5 Output Power %	5 %	
20	Digital Out			5: 2	8613	Controller 6 Output Power %	6 %	
21	Digital Out			5: 3	9000	Process running (Output)	Running	
22	Digital Out			5: 4	9001	Device fault (Output)	No Fault	
23	Digital Out	0		5: 5	0			
24	Digital Out	0		5: 6	0			
25	Virtual			1	9315	Extra Temp 1		
26	Virtual			2	9316	Extra Temp 2		
27	Virtual			3	9317	Extra Temp 3		
28	Virtual	8551		4	9318	Extra Temp 4		
29	Virtual	8552		5	9319	Extra Temp 5		
30	Virtual	8553		6	9320	Extra Temp 6		
31	Virtual	0		7	0			
32	Virtual	8555		8	9601	Simulated heater 1	36.0°C	
33	Virtual	8556		9	9602	Simulated heater 2	36.7°C	
34	Virtual			10	9603	Simulated heater 3	38.4°C	
35	Virtual			11	9604	Simulated heater 4	39.0°C	
36	Virtual			12	9605	Simulated heater 5	40.1°C	
37	Virtual			13	9606	Simulated heater 6	41.3°C	
38	Virtual	0		14	0			
39	Virtual	0		15	0			
40	Virtual	0		16	0			
41	Virtual	0		17	0			
42	Virtual	0		18	0			

### Number of channels must be defined to ISD and ISC

Choose number of channels by pressing "Constants"



Both of the duty ratio start-up frequencies can be changed in the dialogue as follows

- Fast Pwm 1-7 (Fastest - Slowest)
- Slow Pwm 1-250 (Fastest - Slowest)
- Multiplex in use: Mark when multiplex is in use, ex. QDP assembly
- Number of channels: Choose 3, if six channel controller. Choose 6 if twelve channel controller.

**What the columns refer to**  
No. : I/O point number.

**I/O type:** The type determined by the I/O adapter.

**Module ID (in which unit used, is defined in the settings tab)**

If several ISC and ISD units are connected to the same I/O-bus (can), then it must be defined in which module I/O-data is to be used. For example, the controller's temperature (actual value) ID, is the same for all modules.

- Empty value Value is not transferred to other units
- \* Value is transferred to all connected units
- 1-15 Value transferred to the unit in accordance with the ID number

### I/O point description

This description is used in this PC to clarify the type and location of the point. If multiple devices are connected to the PC at the same time, it is also a good idea to describe in the description which device the point is located in. It eases the process of selecting points for a project.

### I/O point location SS:NN

- SS The adapter, and the I/O connector number ISD: 1-4 ISC 1-5
- NN The number of the point in the adapter. Depending on the type of adapter 3-6

### The variable ID

The ID number of the variable connected to this I/O point. All variables must be defined in advance, before they can be connected to an I/O point. The defining is done by the ISPortIO.txt file. If the I/O point is an input-type it updates the value of a variable, while the output is controlled by the variable value. The same variable can be linked to only one I/O-input. The same variable may however be used for more than one outputs.

**Variable name:** The description of the point in the definition file

**Value:** The current value

**Status:** The current action

## Configuring an I/O-point and connecting to a variable.

Configuration dialogue opens by double-clicking the the I/O-line.

### The fields in the configuration dialogue

#### [1] The description point on this PC.

Settings can be defined for the point for use on this PC. The description is saved to the PC's memory

#### [2] The variable of the point

The variable connected to the I/O point. The variable can be connected to one input at a time, in the outputs the same variable may be used more frequently. The dialogue for selecting the variable is opened by the "Select" button.

#### [3] Scaling

Different scaling is available, depending on the type of the I/O point and variable.

#### [4] Settings

Additional settings depending on the type of the I/O

#### [5] Manual

Manual operation for the point


### [1] Point description

The additional point settings are saved to the PC, so they do not move when the controller is used on another PC. It is a good idea to also use the devices serial number in the point ID, this way it is easier to distinguish the points from each other when there is more than one device connected to the PC at the same time. In the absence of the ID the point is marked with the serial number in brackets. When the points are selected for a project colors are selected for them in the order in which they have been defined in the PC's settings. If you want to always use the same color for the same point, the selection is marked and a suitable color chosen.

The points can be grouped in the certificate using a group ID number. Differently from the point ID, the group ID can be given to a point also later when it has already connected to a project.

### [2] The variable of the point

The I/O point must always be connected to a pre-defined variable. The variables are either fixed system variables, or variables defined by the user. The system variables have pre-defined ID numbers and types. The ID numbers 1-9299 are reserved for the system and the numbers 9300 - 9599, are available for defining by the user. Most of the variables can be connected to both the inputs and outputs, but to an input or input-like system variable only once. How the I/O point and the variable coordinate the values between themselves, depends on the type of the I/O point and the variable.



**Variable selection**

The variable selection dialogue is opened, and the variable is selected from the list. All user's variables must be defined in advance in the ISPortIO.txt file. The variables are divided into groups to make the selection easier. If you want to detach a variable from the I/O point (delete) do not choose a new variable, only exit with the OK button.


As an example an analog 16 bit resolution input is used as temperature measurement of the controller No.1.

Open the configuration dialogue by double-clicking the desired input. In the picture the first point of the first adapter. The H-type adapter has three points. The controller's temperature sensor can only be connected to a H-type adapter.




Open the configuration dialogue, and then "Variable selection" -dialogue by clicking the "Select ..." button.



Select the "Controller" group



Select controller No. 1



Select "Temperature" and close the dialogue by the "Ok" button



**ModID**

In the ISC configuration the field is left empty (is in use in the device where the I/O point is located). In the ISD configuration the \*-character is inserted into the field. (in use in any ISC device connected to the Can-channel)

Select matching, in the picture type K.

**Pull-up set (a continuous 0.5 uA current for testing the sensor)**

If the sensor is broken (loose), the temperature rises over the range, and sensor fault is detected.

**Pull-up not set**

The pull-up may interfere with other devices using the same sensor, where the pull-up is switched on. If a broken sensor do not have the pull-up set, then the temperature reading is undefined (will show whatever value).

**Compensation**

The cold-junction compensation used with thermocouples. Select the desired variable from the "User group" list.

**Close the dialogue using the "Close" button**

**Example: The configuration of the controller's No. 1 power output.**

Open the configuration dialogue by double-clicking on the line which is used as a power output. In the picture the first output of the I/O adapter No. 4.

13	Digital Out	4: 1	8453	Controller 1 Output Power %	4 %
14	Digital Out	4: 2	8485	Controller 2 Output Power %	5 %
15	Digital Out	4: 3	8517	Controller 3 Output Power %	4 %

Select "Output power %" as the variable

**ModID**

Leave empty (the output can be located in the ISC or the ISD unit)

**Scaling**

How to change the value of an analog variable to the output electric mode depends on the type of output being used.

**1 High-speed PWM**
**2 Slow PWM**

An analog variable such as power, is scaled analogously to a duty ratio between "Scale max" - "Scale min". If for example the "Scale max" setting is 80%, then the 100% controller output power gives a duty ratio of 80%. And with the same logic the "Scale min" is the duty ratio obtained by the controller output power of 0%.

**3 On/Off**

The variable is compared with the limit value (NOT). When the value of the variable is less than the limit (NOT) then the output is switched off, otherwise it is on. If the "Over limit value" is defined and the value exceeds this, the output is also turned off.

**The high-speed duty ratio is available only for the first four I/O points of the adapters installed to the devices' I/O positions three and four. When using the slow PWM mode, then the switching is automatically synchronized with the H-adapters' measuring sequence. The slow PWM mode must be used with contactors in order to avoid interfering with temperature measurement. All slow PWM mode outputs, also in different units, will be in synchronized with each other.**

**After changing the editable fields (text, number) the "Apply" button must be pressed**

**The dialogue is closed and the values taken into use by the "Close" button**

**Settings**
**"Reverse" marked:**

Duty ratio: -100% - 0 Output is scaled to the negative values ( ie negative ouput power is cooling power)  
On/Off: Output is inverted (Reverse)

**Current control**

Takes the output current monitoring and warning into use.

**Output power**

The load connected to the output (kW). This value is used to calculate the output power and the energy used by this output. If the controller has several outputs, the outputs powers are summed.

The configuration is saved to the device memory by the "Upload" button. The modified configurations of the thermocouples will take effect after saving. Cold-end measurements take a short period to stabilize to their correct values.




If you want to recover the previous configuration in the middle of making changes, this can be done by the "Reload" button. After saving the previous configuration can no longer be recovered. After the reset the list is updated when the tab is visited again.



# ICM11 Current measurement calibration

Measure the current with current measurement device, then wait 1min without current


Open I/O-configuration



Doubleclick on "Controller 1 output current measurement unit" row

3	Analog LoRes	0	0: 3	9303	Connector temperature (Cold end)	26.9°C
4	Analog LoRes	1: 1		4356	Controller 1 Output current measurement...	0 A
5	Analog LoRes	1: 2		4388	Controller 2 Output current measurement...	0 A
6	Analog LoRes	1: 3		4420	Controller 3 Output current measurement...	0 A
7	Analog LoRes	1: 4		4452	Controller 4 Output current measurement...	0 A
8	Analog LoRes	1: 5		4484	Controller 5 Output current measurement...	0 A
9	Analog LoRes	1: 6		4516	Controller 6 Output current measurement...	0 A

Point configuration window opens.



[1] Use for Matching "Current measurement A"


[2] Set Gain value 150 and Offset value 0

[3] Adjust Offset until final current value is 0-1 A. Press "Use (read)" when you adjust the value

[4] Press "Use and close"

Doubleclick "Controller 1 output power %" row


19	Digital Out	5: 1		8453	Controller 1 Output Power %	0 %
20	Digital Out	5: 2		8485	Controller 2 Output Power %	0 %
21	Digital Out	5: 3		8517	Controller 3 Output Power %	0 %
22	Digital Out	5: 4		8549	Controller 4 Output Power %	0 %
23	Digital Out	5: 5		8581	Controller 5 Output Power %	0 %
24	Digital Out	5: 6		8613	Controller 6 Output Power %	0 %



[5] Connect output power to manual, ex. 24%

Then return back to Points configuration window






[6] Adjust Gain until final value is same as measured earlier with measurement device

[7] Set high current limit to 100 A, this is the device high current alarm limit. Low current limit is 0 A

After this repeat same to channels 2-6



NOTE!

When all channels are calibrated, press "Upload" in I/O-configuration tab



# Temperature controllers

Temperature controllers

The settings of the temperature controllers are usually changed when the controller is in use (connected to a project). Then the controller settings dialogue can be opened by double-clicking the controller at the "Connected devices" list. The controller's ID is read into the project data when the controller is selected to the project, so ID must be set before connecting.

No.	Type	Code	Process	Status
1	PID	A1	R100	
2	PID	A2		
3	PID	A3		
4	PID	A4		
5	PID	A5		
6	PID	A6		

### Controller list

The "Settings" dialogue is opened by double-clicking the controller line. In the picture for the controller one (1) has been set a fixed color, and controller five (5) is in use in the project Q52.

## Controller defaults



*The settings are device-specific, that is, the devices in the same process use their own settings. However, the parameter set defined in the process settings (Control tab) is the same for all devices.*

*Settings are saved to the device's memory with the "Ok" button, the new settings will take effect immediately. The parameters (parameter set) are taken to use, when a set other than zero (0) is selected from the slider in the "Additional process settings" dialogue.*

**[1] Saving**

The controller's measured output power and the rate of change, may be saved to the device's memory. Diagrams can be printed from the saved values. Saving is performed at regular intervals. If the power and change diagrams are not needed, it is recommended to turn off saving in order to save flash memory. The On/Off setting can also be controlled from other dialogues, but the saving interval is only determined here.

**Save power**

**Save rate of change**

Fixed saving interval

**[2] The controller parameters**

The controller's PID parameters consist of five different values. Since the values usually depend on each other, it makes sense to adjust them together. The "Additional process settings" dialogue has a slider with which all the parameters can be chosen at the same time. The slider's each position from 1-10 selects a pre-defined set of parameters. All the controllers (in the same device) connected to the process use the same parameter set. When using the parameter set zero (0) the controller's parameters are not set, but controller specific parameters are used. When something else than the set zero is chosen with the slider, the corresponding set of parameters is moved from the "controller parameters" table to all the controllers connected to the project. The explanations of the parameters can be found in a separate instruction.

**[3] The factory settings**

All of the dialogue settings can be returned to the default values

**[4] The sensor error settings**

The operation of a controller in the situation of sensor error, depends if there are other temperature sensors in use in the same process. If other sensors are not connected, the controller's power control will automatically be set to zero, and the progress of the process will be left to wait for the proper temperature. The output power can be manually controlled. If the process has a usable power reading (other controllers are working), it is sensible to use this instead of the manual power setting. The output power of the process is a average of all controllers connected to the process. Also the controller can use the process temperature as the measured temperature.

**Use the process power**

In the absence of temperature measurement, the process output power % is primarily used as controller's output power.

**Use the process temperature**

If the process output power does not exist, or if it is not wanted to be used, the process temperature is used. Using the temperature requires that other controllers or measurement points is connected to the process.

**Sensor error acknowledgement**

A faulty sensor can be taken out of use, in which case the sensor is not taken into use even if it seems to be ok. The sensor is acknowledged as error-free by taking the I/O points "Manual" setting off.

**If the temperature falls by more than 50%**

There can be a short-circuit on the thermocouple or compensating cable, in which case the temperature is measured at place of short-circuit. When the temperature is over 50 degrees, and then falls to one-half, during one measurement period (3s), it is assumed to be defective. The situation will, however, only last for two measurement periods, so the error lock and acknowledgement can be used.

# Calibration


Calibration

ISx devices are calibrated programmatically in such a way that the Offset and Gain of every point is calibrated separately. Only the points connected to H-type adapters (16b) are calibrated. Calibration and the possible additional information for the calibration certificate are saved to the device's EEPROM memory.

## Preparation before calibration using the I/O configuration


Before calibration the configuration of the I/O point is checked

### 1 The calibration table is chosen for the point (E\_Type ... PT100)



### 2 Ensure the correct settings (Pull-up)

The pull-up current (0.5 uA) monitoring the thermocouple, causes an error to the temperature reading if the sensor resistance is high. If the sensor wire, or its compensating cable is long, then this installation should also be used during calibrating if possible. Efforts have been made to compensate pull-up error programmatically, but due to the tolerances of the components, the temperature reading will change when the pull-up is turned on or off.



### 4 Selecting the temperature measuring point for the cold-junction compensation

When using thermocouples, the sensor's cold-junction must be measured and compensated. The I/O point used for compensation must be chosen for each adapter. All 1-3 points of the H-adapter use the same compensation point, so all thermocouples connected to the same adapter, must be of the same type.



### 5 Checking the value of the cold-junction

If points, which are not calibrated are used for compensation, it must be ensured that the temperature reading is approximately correct. If necessary the point's offset can be adjusted. With NTC-type measurement, the temperature reading drops when the offset increases.

If the offset is changed, and the new value is set by the "Apply" button, then the temperature reading can be checked from the "Final value" field.



### 6 Save the configuration to the device

It takes a while before temperature readings are correct.



## Carrying out the calibration




### Releasing lock

Calibration is password-protected to prevent accidental alteration. The password is entered into the "Lock" dialogues password box. The password is set on the PC settings "Passwords" tab. The calibration password can only be set by the administrator. If no password is set, then a simple "Ok" is enough to unlock.

### Selecting the points to be calibrated

The type to be calibrated is selected from the list. Also, the calibrator is set to source same type. All the same type of I/O points can now be selected for the actual calibration.



### Calibration table columns

Although the calibration is performed at only two points, space has been reserved in the checking table for eight check values. Usually the point is calibrated with the value zero and with the highest value to be used. When using thermocouples zero is a sensible value because the thermocouple voltage is then also zero, wherein the gain effect is minor.

The actual value of the measurement, the column value, is given by clicking on the column [1], and then typing in the field [2] the column value.

You can move to the next column also by using the TAB button



### Activating the points to be calibrated

If the calibrator is connected to the incoming connections with a splitter, several points can be calibrated at the same time.

Points to be calibrated are activated by clicking on the number field. The green triangle indicates an activated point.

No.	IO...	Fitting	Error
4	1:1	TYPE_K	+0.0
5	1:2	TYPE_K	+0.0
6	1:3	Pt100 / 1mA	+0.0

### Zero point calibration (offset)

Offset is the correction which is added to the value received from the A/D converter. Its purpose is to correct the errors of the amplifier, converter, and protection components.

- 1 Select the column, usually the smallest value, by clicking on the column header.
- 2 Set the calibrator to enter the same value. For each selected point the error is displayed on the corresponding row.
- 3 If measured error is too high, then correction dialogue is opened by double-clicking on the line (I/O point).
- 4 The offset is changed either manually from the "Offset" slider or by clicking the "Offset correction" button.
- 5 When the error is zero, the dialogue can be closed
- 6 The same operation is done for all activated activated points (Section 3)

### The gain calibration

Gain calibration (scaling)

- 1 Select the column, usually the biggest value
- 2 Set the calibrator to source the corresponding value.
- 3 If measured error is too high, open the correction dialogue by double-clicking on the line.
- 4 The gain is changed either manually from the "Gain" slider, or by clicking the "Gain correction" button.
- 5 When the error is zero, the dialogue can be closed
- 6 The same operation is done for all activated activated points (Section 3)

### Filling in the checking table

- 1 Select the temperature and column where the error is checked by clicking on the column header.
- 2 Set the same temperature into the calibrator.
- 3 When all the measuring points have error values, move to the next column
- 4 Finally deactivate points.

**Change the calibrator value after you have moved to the next column**

## Process Instructions (heating plan)

Process Instructions

Before starting the process, the software uploads the heating plan to the controller's memory. There is space reserved in the controller for 24 heating plans. The same plan can be used up to 250 times. The current reference (heating) can be stopped and removed from the device memory.

No.	File ID	Running	Pause	The process no	Parts
1	Q2151				7
2	201				7
3	200				7
4	212				7
5	196				7
6	189				7
7	198				7
8	193				7
9	197				7
10	203				7
11	191				7
12	211				7
13	2118				7
14	R100	X		1	7

### No.

The plan number (memory location). The plan is automatically uploaded to the first empty location, or if there are no empty locations, to the place with the oldest plan. If the user wants to upload the plan to a specific memory location, then the location number is to be defined in the process settings. The specified location is used if the user would like to start the plan for example with the I/O button.

### RNro

Reference ID and file name

### In progress

A reference in use cannot be removed. The process must first be stopped

### Pause

### Process

The process execution number. The controller is capable of performing six simultaneous processes. When started, the process will automatically be given the next empty process number, or the defined number is used if free. The process number must be known if the process is referred to, for example via I/O.

### Parts

The inspection number. 7 = Ok

**The process can be stopped with the "Stop" button. This stop method should only be used when the process can not be found on the controlling PC. Then the process has been started on another computer, or the process has been removed from the PC.**

**The plan can be removed from the device memory. Normally there is no reason to remove unnecessary references, as they are automatically erased when new references are loaded into the memory.**

No.	File ID	Running	Pause	The process no	Parts
1	Q2151				7
2	201				7
3	200				7
4	212				7
5	196				7
6	189				7
7	198				7
8	193				7
9	197				7
10	203				7
11	191				7
12	211				7
13	2118				7
14	R100	X		1	7

No.	File ID	Running	Pause	The process no	Parts
1	Q2151				7
2	201				7
3	200				7
4	212				7
5	196				7

## Completed processes

Completed Processes

The events and temperatures are saved in the controller's flash memory, from where they are transferred to the PC, either during heating or afterwards. The last 250 processes is available on the memory's Table of Contents. If heatings are long, then it is possible that although the process information appears in the table of contents, the actual data in the flash memory has been overwritten.

No	RegNo	Drive No	Start time	Event	Measurement	Status
1	TESTQ188	1	23.02.2015 15:42	17	18	---
2	TESTQ188	2	23.02.2015 15:43	19	20	---
3	TESTQ188	1	23.02.2015 15:53	21	22	---
4	TESTQ189	1	24.02.2015 14:16	23	24	---
5	TESTQ189	1	24.02.2015 15:04	25	27	---

### [1] Update

Update the list

### [2] Delete

Deletes memory from controller, so info on these tabs also emptys:  
System events, Process plans and Completed processes

#### No.

Memory location 1-250. Ring buffer

#### RegNo

Completed process ID (file name)

#### Process No.

Record number, if the same heating plan used more than ones.

#### Start time

The process start time

#### Event

Event starting point in the flash memory

#### Measurement

Measurement starting point in the flash memory

#### Status

Not in use

## Recovering process data from memory

Recorded processes can be recovered, that is, be re-read from the controller's memory. Recovering can be used when the project has been removed from the PC, or the process is located on another computer.

*The recovering dialogue is opened by double-clicking the line of the process to be recovered*

*The recovery is complete when the "Begin recovery" button is available again.*

*The dialogue can be closed once the recovery has begun.*

*The possible project added is at the end of the project list.*

*Recovering process data from memory is not possible if earlier "Delete" button is used and memory is empty*



## System events

System events

The most recent events. Only for monitoring

## Printing

Print

The calibration certificate templates are located in the "\Layout" directory. The template file must be in the form ISD\_xxxx.TXT.