


Operating Instructions

VEGAWELL 52

4 ... 20 mA



Process pressure/
Hydrostatic



Contents

1	About this document	
1.1	Function	4
1.2	Target group	4
1.3	Symbolism used	4
2	For your safety	
2.1	Authorised personnel	5
2.2	Appropriate use	5
2.3	Warning about misuse	5
2.4	General safety instructions	5
2.5	Safety approval markings and safety tips	6
2.6	CE conformity	6
2.7	Safety instructions for Ex areas	6
2.8	Environmental instructions	6
3	Product description	
3.1	Configuration	7
3.2	Principle of operation	9
3.3	Operation	9
3.4	Packaging, transport and storage	9
4	Mounting	
4.1	General instructions	11
4.2	Mounting steps with straining clamp	13
4.3	Mounting steps with screwed connection	14
4.4	Mounting steps with threaded connection or housing	15
5	Connecting to power supply	
5.1	Preparing the connection	17
5.2	Connection procedure	19
5.3	Wiring plan	20
5.4	Switch on phase	21
6	Maintenance and fault rectification	
6.1	Maintain	22
6.2	Remove interferences	22
6.3	Shortening the suspension cable	23
6.4	Shortening the suspension cable	23
6.5	Instrument repair	25
7	Dismounting	
7.1	Dismounting steps	27
7.2	Disposal	27
8	Supplement	
8.1	Technical data	28
8.2	Dimensions	34

Supplementary documentation



Information:

Supplementary documents appropriate to the ordered version come with the delivery. You can find them listed in chapter "*Product description*".

Instructions manuals for accessories and replacement parts



Tip:

To ensure reliable setup and operation of your VEGAWELL 52, we offer accessories and replacement parts. The associated documents are:

- 32798 - VEGABOX 02

1 About this document

1.1 Function

This operating instructions manual provides all the information you need for mounting, connection and setup as well as important instructions for maintenance and fault rectification. Please read this information before putting the instrument into operation and keep this manual accessible in the immediate vicinity of the device.

1.2 Target group

This operating instructions manual is directed to trained qualified personnel. The contents of this manual should be made available to these personnel and put into practice by them.

1.3 Symbolism used



Information, tip, note

This symbol indicates helpful additional information.



Caution: If this warning is ignored, faults or malfunctions can result.

Warning: If this warning is ignored, injury to persons and/or serious damage to the instrument can result.

Danger: If this warning is ignored, serious injury to persons and/or destruction of the instrument can result.



Ex applications

This symbol indicates special instructions for Ex applications.



List

The dot set in front indicates a list with no implied sequence.



Action

This arrow indicates a single action.



Sequence

Numbers set in front indicate successive steps in a procedure.

2 For your safety

2.1 Authorised personnel

All operations described in this operating instructions manual must be carried out only by trained specialist personnel authorised by the plant operator.

During work on and with the device the required personal protective equipment must always be worn.

2.2 Appropriate use

VEGAWELL 52 is a suspension pressure transmitter for level and gauge measurement.

You can find detailed information on the application range in chapter "*Product description*".

Operational reliability is ensured only if the instrument is properly used according to the specifications in the operating instructions manual as well as possible supplementary instructions.

For safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden.

2.3 Warning about misuse

Inappropriate or incorrect use of the instrument can give rise to application-specific hazards, e.g. vessel overfill or damage to system components through incorrect mounting or adjustment.

2.4 General safety instructions

This is a high-tech instrument requiring the strict observance of standard regulations and guidelines. The user must take note of the safety instructions in this operating instructions manual, the country-specific installation standards as well as all prevailing safety regulations and accident prevention rules.

The instrument must only be operated in a technically flawless and reliable condition. The operator is responsible for trouble-free operation of the instrument.

During the entire duration of use, the user is obliged to determine the compliance of the required occupational safety measures with the current valid rules and regulations and also take note of new regulations.

2.5 Safety approval markings and safety tips

The safety approval markings and safety tips on the device must be observed.

2.6 CE conformity

The protection goals of the EMC Directive 2004/108/EC (EMC) and the Low Voltage Directive 2006/95/EC (LVD) are fulfilled.

Conformity has been judged according to the following standards:

EMC: EN 61326: 2006

(electrical instruments for control technology and laboratory use - EMC requirements)

- Emission: Class B
- Susceptibility: Industrial areas

LVD: EN 61010-1: 2001

(safety regulations for electrical measurement, control and laboratory instruments - part 1: General requirements)

2.7 Safety instructions for Ex areas

Please note the Ex-specific safety information for installation and operation in Ex areas. These safety instructions are part of the operating instructions manual and come with the Ex-approved instruments.

2.8 Environmental instructions

Protection of the environment is one of our most important duties. That is why we have introduced an environment management system with the goal of continuously improving company environmental protection. The environment management system is certified according to DIN EN ISO 14001.

Please help us fulfil this obligation by observing the environmental instructions in this manual:

- Chapter "*Packaging, transport and storage*"
- Chapter "*Disposal*"

3 Product description

3.1 Configuration

Scope of delivery

The scope of delivery encompasses:

- VEGAWELL 52 pressure transmitter with suspension cable
- optionally available with straining clamp, screwed connection or housing with cable locking
- Documentation
 - this operating instructions manual
 - test certificate
 - Ex-specific "*Safety instructions*" (with Ex-versions)
 - if necessary, further certificates

Components

VEGAWELL 52 with suspension cable consists of the following components:

- Transmitter
- Suspension cable
- Optionally fixing element or housing with threaded fitting

The components are available in different versions.




Fig. 1: Example of a VEGAWELL 52 with transmitter 22 mm and unassembled threaded fitting

- 1 Transmitter
- 2 Suspension cable
- 3 Screw connection

Type label

The type label contains the most important data for identification and use of the instrument:

- Article number
- Serial number
- Technical data
- Article numbers documentation

The serial number allows you to access the delivery data of the instrument via www.vega.com, "VEGA Tools" and "serial number search". You can also find the serial number on the type label on the suspension cable or on the housing.

3.2 Principle of operation

Application area	VEGAWELL 52 is used for level and gauge measurement in wells, basins and atmospherically open vessels particularly in the water/waste water industry as well as in the shipbuilding industry. ¹⁾
Functional principle	The actual sensor element is the CERTEC® measuring cell with rugged ceramic diaphragm. The hydrostatic pressure causes a capacitance change in the measuring cell via the ceramic diaphragm. This change is converted into an appropriate output signal.
Power supply	Two-wire electronics 4 ... 20 mA for power supply and measured value transmission on the same cable. The supply voltage range can differ depending on the instrument version. The data for power supply are specified in chapter " <i>Technical data</i> ".

3.3 Operation

VEGAWELL 52 with 4 ... 20 mA electronics has no adjustment option.

3.4 Packaging, transport and storage

Packaging	Your instrument was protected by packaging during transport. Its capacity to handle normal loads during transport is assured by a test according to DIN EN 24180. The packaging of standard instruments consists of environment-friendly, recyclable cardboard. For special versions, PE foam or PE foil is also used. Dispose of the packaging material via specialised recycling companies.
Transport	Transport must be carried out under consideration of the notes on the transport packaging. Nonobservance of these instructions can cause damage to the device.
Transport inspection	The delivery must be checked for completeness and possible transit damage immediately at receipt. Ascertained transit damage or concealed defects must be appropriately dealt with.
Storage	Up to the time of installation, the packages must be left closed and stored according to the orientation and storage markings on the outside. Unless otherwise indicated, the packages must be stored only under the following conditions: <ul style="list-style-type: none">● Not in the open

¹⁾ For use in closed vessels under vacuum, the instrument is available with absolute pressure measuring ranges.

Storage and transport temperature

- Dry and dust free
- Not exposed to corrosive media
- Protected against solar radiation
- Avoiding mechanical shock and vibration

- Storage and transport temperature see chapter "*Supplement - Technical data - Ambient conditions*"
- Relative humidity 20 ... 85 %

4 Mounting

4.1 General instructions

Suitability for process conditions

Make sure that all parts of the instrument in contact with the measured product, especially the sensor element, process seal and process fitting, are suitable for the existing process conditions such as process pressure, process temperature as well as the chemical properties of the medium.

You can find the specifications in chapter "*Technical data*" in the or on the type label.

Mounting position

Note the following points when selecting the installation location.

- Sideways movements of the transmitter can cause measurement errors
- Therefore, mount VEGAWELL 52 in a calm area or in a suitable protective tube



Information:

We recommend the measuring instrument holder from the VEGA line of accessory (article no. BARMONT.D) to fasten VEGAWELL 52.

Pressure compensation

- The connection cable has a capillary for atmospheric pressure compensation
- Therefore lead the cable end into a dry space or directly into a suitable terminal housing.



Information:

For this purpose, VEGA recommends VEGABOX 02. It contains terminals and a filter element for pressure compensation. A suitable protective cover is available for outdoor mounting.

Mounting example




Fig. 2: Mounting example: VEGAWELL 52 in a pump shaft with breather housing VEGABOX 02

4.2 Mounting steps with straining clamp




Fig. 3: Straining clamp

- 1 Suspension cable
- 2 Suspension opening
- 3 Clamping jaws

Mount VEGAWELL 52 with straining clamp as follows:

- 1 Hang the straining clamp on a suitable wall hook
- 2 Lower VEGAWELL 52 to the requested height
- 3 Slide the clamping jaws upward and push the suspension cable between them
- 4 Hold the suspension cable, push the clamping jaws downward and fix them with a light blow

Removal is carried out in reverse order.

4.3 Mounting steps with screwed connection




Fig. 4: Screw connection

- 1 Suspension cable
- 2 Seal screw
- 3 Cone bushing
- 4 Seal cone
- 5 Screw connection
- 6 Seal

Mount VEGAWELL 52 with screwed connection as follows:

- 1 Weld the welded socket into the vessel top
- 2 Lower VEGAWELL 52 to the requested height by means on the welded socket G1½ A or 1½ NPT on the vessel side
- 3 Insert the suspension cable from below into the open screwed connection
- 4 Slide the seal cone and the cone sleeve over the suspension cable, fasten manually with the seal screw
- 5 Screw the screwed connection into the socket, fasten with SW 30 and then fasten seal screw with SW 19

How to correct the height:

- 1 Loosen seal screw with SW 19
- 2 Slide seal cone and cone sleeve to the requested position on the cable
- 3 Fasten the seal screw

Removal is carried out in reverse order.

4.4 Mounting steps with threaded connection or housing



Fig. 5: Plastic housing

- 1 Housing
- 2 Seal
- 3 Thread

Mount into the vessel

Mount VEGAWELL 52 as follows:

- 1 Weld the welded socket G1½ A or 1½ NPT to the vessel top
 - 2 Shift transmitter through the mounting boss
 - 3 Turn the thread with seal into the socket and tighten with SW 46²⁾
- Removal is carried out in reverse order.

Mounting into the basin

Mount VEGAWELL 52 as follows:

- 1 Fasten the mounting bracket at the suitable height on the basin wall



Information:

We recommend articles from the line of VEGA accessories:

- Mounting angle of stainless steel
- Counter nut of PP

²⁾ Seal the 1½ NPT thread with teflon, hemp or a similar resistant material.

- 2 Lead the transmitter through the opening of the mounting bracket and the counter nut
- 3 Fasten the counter nut to the thread with SW 46

5 Connecting to power supply

5.1 Preparing the connection

Note safety instructions

Always keep in mind the following safety instructions:

- Connect only in the complete absence of line voltage
- If overvoltage surges are expected, overvoltage arresters should be installed



Tip:

We recommend the following VEGA overvoltage arresters:

- B63-48 (use in plastic housing of VEGAWELL 52)
- ÜSB 62-36G.X (use in a separate housing)

Take note of safety instructions for Ex applications



In hazardous areas you should take note of the appropriate regulations, conformity and type approval certificates of the sensors and power supply units.

Select power supply

Power supply and current signal are carried on the same two-wire cable. The voltage supply range can differ depending on the instrument version.

The data for power supply are specified in chapter "*Technical data*".

Provide a reliable separation between the supply circuit and the mains circuits according to DIN VDE 0106 part 101.

VEGA power supply units VEGATRENN 149AEx, VEGASTAB 690, VEGADIS 371 as well as all VEGAMETs meet this requirement. When using one of these instruments, protection class III is ensured for VEGAWELL 52.

Keep in mind the following additional influences on the operating voltage:

- Output voltage of the power supply unit can be lower under nominal load (with a sensor current of 20.5 mA or 22 mA in case of fault message)
- Influence of additional instruments in the circuit (see load values in chapter "*Technical data*")

Selecting connection cable

The instrument is connected with standard two-wire cable without screen. If electromagnetic interference is expected which is above the test values of EN 61326 for industrial areas, screened cable should be used.

Use cable with round cross-section. A cable outer diameter of 5 ... 9 mm (0.2 ... 0.35 in) ensures the seal effect of the cable gland. If you are using cable with a different diameter or cross-section, exchange the seal or use a suitable cable gland.




Fig. 6: Connect VEGAWELL 52 to power supply

- 1 Direct connection
- 2 Connection via VEGABOX 02
- 3 Connection via housing

Cable screening and grounding

If screened cable is necessary, connect the cable screen on both ends to ground potential. In the plastic housing, in VEGABOX 02 or in VEGADIS 12, the screen must be connected directly to the internal ground terminal. The ground terminal outside on the housing must be connected to the potential equalisation.

If potential equalisation currents are expected, the connection on the processing side must be made via a ceramic capacitor (e. g. 1 nF, 1500 V). The low frequency potential equalisation currents are thus suppressed, but the protective effect against high frequency interference signals remains.

Select connection cable for Ex applications



Take note of the corresponding installation regulations for Ex applications.

5.2 Connection procedure

Direct connection

Proceed as follows:

- 1 Wire the connection cable up to the connection compartment. The bending radius must be at least 25 mm.³⁾
- 2 Connect the wire ends to the screw terminals according to the wiring plan

Connection via VEGABOX 02

Proceed as follows:

- 1 Snap VEGABOX 02 onto the carrier rail or screw it to the mounting plate
- 2 Loosen the cover screws and remove the cover
- 3 Push the cable into VEGABOX 02 through the cable entry
- 4 Loosen the screws with a screwdriver
- 5 Insert the wire ends into the open terminals according to the wiring plan
- 6 Tighten the screws with a screwdriver
- 7 Check the hold of the wires in the terminals by lightly pulling on them
- 8 Tighten the compression nut of the cable entry. The seal ring must completely encircle the cable
- 9 Connect the supply cable according to steps 3 to 8
- 10 Screw the housing cover on

The electrical connection is finished.

³⁾ The connection cable is already preconfecteded. After shortening the cable, fasten the type plate with support again to the cable.

5.3 Wiring plan

Direct connection




Fig. 7: Wire assignment, suspension cable

- 1 Blue (-): to power supply or to the processing system
- 2 Brown (+): to power supply or to the processing system
- 3 Shielding
- 4 Breather capillaries with filter element

Connection via VEGABOX 02




Fig. 8: Terminal assignment VEGABOX 02

- 1 To power supply or the processing system
- 2 Shielding⁴⁾

⁴⁾ Connect screen to ground terminal. Connect ground terminal on the outside of the housing as prescribed. The two terminals are galvanically connected.


Connection via housing

Fig. 9: Terminal assignment of the housing

1 To power supply or the processing system

5.4 Switch on phase

After connecting VEGAWELL 52 to power supply or after a voltage recurrence, the instrument carries out a self-check:

- Internal check of the electronics
- 4 ... 20 mA output jumps to the failure signal

The instrument delivers after this run-up period a current of 4 ... 20 mA to the cable. The value corresponds to the actual level as well as to settings already carried out, e.g. the factory setting.

6 Maintenance and fault rectification

6.1 Maintain

Maintenance

When used in the correct way, no special maintenance is required in normal operation.

In some applications, product buildup on the sensor diaphragm can influence the measuring result. Depending on the sensor and application, take precautions to ensure that heavy buildup, and especially a hardening thereof, is avoided.

Cleaning

If necessary, clean the transmitter. Make sure that the materials are resistant against the cleanig, see resistance list under "Services" on "www.vega.com". The application variety of VEGAWELL 52 requires special cleaning instructions for each application. Please ask the VEGA agency serving you.

6.2 Remove interferences

Reaction when malfunctions occur

The operator of the system is responsible for taken suitable measures to remove interferences.

Causes of malfunction

A maximum of reliability is ensured. Nevertheless, faults can occur during operation. These may be caused by the following, e.g.:

- Sensor
- Process
- Power supply
- Signal processing

Fault rectification

The first measure to be taken is to check the output signal. In many cases, the causes can be determined this way and the faults rectified.

24 hour service hotline

However, should these measures not be successful, call the VEGA service hotline in urgent cases under the phone no. **+49 1805 858550**.

The hotline is available to you 7 days a week round-the-clock. Since we offer this service world-wide, the support is only available in the English language. The service is free of charge, only the standard telephone costs will be charged.

Checking the 4 ... 20 mA signal

Connect a handheld multimeter in the suitable measuring range according to the wiring plan.

- ?
- 4 ... 20 mA signal not stable
- no atmospheric pressure compensation
 - Check the capillaries and cut them clean
 - Check pressure compensation in VEGABOX 02, if necessary clean filter element

- ? 4 ... 20 mA signal missing
- Wrong connection to power supply
 - Check connection according to chapter "*Connection steps*" and if necessary, correct according to chapter "*Wiring plan*"
 - No power supply
 - Check cables for breaks; repair if necessary
 - Operating voltage too low or load resistance too high
 - Check, adapt if necessary



In Ex applications, the regulations for the wiring of intrinsically safe circuits must be observed.

Reaction after fault rectification

Depending on the failure reason and measures taken, the steps described in chapter "*Set up*" must be carried out again, if necessary.

6.3 Shortening the suspension cable

Shorten the suspension cable individually. Proceed as follows:

- 1 Remove the filter adapter from the transparent capillary line
- 2 Cut the suspension cable with an edge cutter to the requested length



Caution:

Do not squeeze the capillary cable, this will influence the pressure compensation. If necessary, rework with a sharp knife.

- 3 Remove approx. 10 cm of the cable mantle, strip off approx. 1 cm of the wire ends

Insert the filter adapter

The work steps are finished.

6.4 Shortening the suspension cable

The suspension cable can be shortened individually. For the version with plastic or stainless steel housing proceed as follows:

- 1 Unscrew the housing cover
- 2 Loosen the screw terminals and remove the wire ends of the suspension cable out of the screw terminals
- 3 Hold the hexagon on the screwed socket with SW 46 and loosen with seal screw SW 22



Caution:

Seal screw is secured with Loctide pink, note breakaway torque!



Fig. 10: Step 4

- 1 SW 46
- 2 SW 22

- 4 Pull the suspension cable out of the screwed socket, remove the pressure screw, cone sleeve and seal cone from the cable
- 5 Remove the filter adapter from the transparent capillary line




Fig. 11: Configuration of the cable seal

- 1 Connection cable (up to 6 pieces depending on the version)
- 2 Cable screen
- 3 Breather capillaries with filter element
- 4 Seal cone
- 5 Suspension cable
- 6 Cone bushing
- 7 Seal screw

- 6 Cut the suspension cable with an edge cutter to the requested length
- 7 Remove approx. 10 cm of the cable mantle, strip off approx. 1 cm of the wire ends, insert the filter adapter
- 8 Shift the seal screw, cone sleeve and seal cone to the suspension cable and insert the cable into the screwed socket, insert the wire ends through the cable entry into the mounting plate

The work steps are finished.

6.5 Instrument repair

If a repair is necessary, please proceed as follows:

You can download a return form (23 KB) from our Internet homepage www.vega.com under: "Downloads - Forms and certificates - Repair form".

By doing this you help us carry out the repair quickly and without having to call back for needed information.

- Print and fill out one form per instrument
- Clean the instrument and pack it damage-proof

- Attach the completed form and, if need be, also a safety data sheet outside on the packaging
- Please ask the agency serving you for the address of your return shipment. You can find the respective agency on our website www.vega.com under: "*Company - VEGA worldwide*"

7 Dismounting

7.1 Dismounting steps

**Warning:**

Before dismounting, be aware of dangerous process conditions such as e.g. pressure in the vessel, high temperatures, corrosive or toxic products etc.

Take note of chapters "*Mounting*" and "*Connecting to power supply*" and carry out the listed steps in reverse order.

7.2 Disposal

The instrument consists of materials which can be recycled by specialised recycling companies. We use recyclable materials and have designed the electronics to be easily separable.

WEEE directive 2002/96/EG

This instrument is not subject to the WEEE directive 2002/96/EG and the respective national laws. Pass the instrument directly on to a specialised recycling company and do not use the municipal collecting points. These may be used only for privately used products according to the WEEE directive.

Correct disposal avoids negative effects to persons and environment and ensures recycling of useful raw materials.

Materials: see chapter "*Technical data*"

If you have no possibility to dispose of the old instrument professionally, please contact us concerning return and disposal.

8 Supplement

8.1 Technical data

General data

Measured value	Level
Measuring principle	Ceramic-capacitive, dry measuring cell
Communication interface	None

Materials and weights

Materials, wetted parts	
– Transmitter	316L, 316L with PE coating, 1.4462 (Duplex), 1.4462 with PE coating, PVDF, Titanium
– Protective cap	PA, PE
– Diaphragm	sapphire ceramic® (99.9 % oxide ceramic)
– Joining material diaphragm/Basic element measuring cell	Glass solder
– Measuring cell seal	FKM (VP2/A) - FDA and KTW approved, FFKM (Perlast G75S), EPDM (A+P 75.5/KW75F)
– Suspension cable	PE (FDA and KTW-approved), FEP, PUR
– Cable gland on the transmitter	316L
– Cable seal with PE, PUR cable	FKM
– Cable seal with FEP cable	FEP
– Process fitting	316L
– Straining clamp	1.4301
– Unassembled screw connection	316L, PVDF
– Threaded connection on the housing	316L
Materials, non-wetted parts	
– Housing	plastic PBT (Polyester), 316L
– type label support on cable	PE hard
– transport protection net	PE
Weight approx.	
– Basic weight	0.8 kg (1.764 lbs)
– Suspension cable	0.1 kg/m (0.07 lbs/ft)
– Straining clamp	0.2 kg (0.441 lbs)
– Screw connection	0.4 kg (0.882 lbs)
– Plastic housing	0.8 kg (1.764 lbs)
– Stainless steel housing	1.6 kg (3.528 lbs)

Input variable

percentage value	-10 ... +110 % of the nominal measuring range
------------------	---

pressure value -20 ... +120 % of the nominal measuring range

Recommended max. turn down 10 : 1 (no limitation)

Nominal measuring ranges and overload capability in bar/kPa

Nominal range	Overload, max. pressure	Overload, min. pressure
Gauge pressure		
0 ... 0.1 bar/0 ... 10 kPa	15 bar/1500 kPa	-0.2 bar/-20 kPa
0 ... 0.2 bar/0 ... 20 kPa	20 bar/2000 kPa	-0.4 bar/-40 kPa
0 ... 0.4 bar/0 ... 40 kPa	30 bar/3000 kPa	-0.8 bar/-80 kPa
0 ... 1 bar/0 ... 100 kPa	35 bar/3500 kPa	-1 bar/-100 kPa
0 ... 2.5 bar/0 ... 250 kPa	50 bar/5000 kPa	-1 bar/-100 kPa
0 ... 5 bar/0 ... 500 kPa	65 bar/6500 kPa	-1 bar/-100 kPa
0 ... 10 bar/0 ... 1000 kPa	90 bar/9000 kPa	-1 bar/-100 kPa
0 ... 25 bar/0 ... 2500 kPa	130 bar/13000 kPa	-1 bar/-100 kPa
Absolute pressure		
0 ... 1 bar/0 ... 100 kPa	35 bar/3500 kPa	0 bar abs.
0 ... 2.5 bar/0 ... 250 kPa	50 bar/5000 kPa	0 bar abs.
0 ... 5 bar/0 ... 500 kPa	65 bar/6500 kPa	0 bar abs.
0 ... 10 bar/0 ... 1000 kPa	90 bar/9000 kPa	0 bar abs.
0 ... 25 bar/0 ... 2500 kPa	130 bar/13000 kPa	0 bar abs.

Nominal measuring ranges and overload capability in psig

Nominal range	Overload, max. pressure	Overload, min. pressure
Gauge pressure		
0 ... 1.5 psig	200 psig	-3 psig
0 ... 3 psig	290 psig	-6 psig
0 ... 6 psig	430 psig	-12 psig
0 ... 15 psig	500 psig	-15 psig
0 ... 35 psig	700 psig	-15 psig
0 ... 70 psig	950 psig	-15 psig
0 ... 150 psig	1300 psig	-15 psig
0 ... 350 psig	1900 psig	-15 psig
0 ... 900 psig	2900 psig	-15 psig
Absolute pressure		
0 ... 15 psi	500 psi	0 psi
0 ... 35 psi	700 psi	0 psi
0 ... 70 psi	900 psi	0 psi
0 ... 150 psi	1300 psi	0 psi
0 ... 350 psi	1900 psi	0 psi

Output variable

Output signal	4 ... 20 mA
Signal resolution	2 μ A
Failure signal	<3,6 mA
Max. output current	22 mA
Run-up time approx.	2 s
Step response time	\leq 100 ms (ti: 0 s, 0 ... 63 %)
Fulfilled NAMUR recommendations	NE 43

Reference conditions and actuating variables (similar to DIN EN 60770-1)

Reference conditions according to DIN EN 61298-1

– Temperature	+15 ... +25 °C (+59 ... +77 °F)
– Relative humidity	45 ... 75 %
– Air pressure	860 ... 1060 mbar/86 ... 106 kPa (12.5 ... 15.4 psig)

Determination of characteristics Limit point adjustment according to IEC 61298-2

Characteristics linear

Reference installation position upright, diaphragm points downward

Influence of the installation position < 0.2 mbar/20 Pa (0.003 psig)

Deviation determined according to the limit point method according to IEC 60770⁵⁾

Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

Deviation with version < 0.2 %

– Turn down 1 : 1 up to 5 : 1	< 0.25 %
– Turn down up to 10 : 1	< 0.05 % x TD

Deviation with version < 0.1 %

– Turn down 1 : 1 up to 5 : 1	< 0.1 %
– Turn down up to 10 : 1	< 0.02 % x TD

Influence of the product or ambient temperature

Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

Average temperature coefficient of the zero signal

In the compensated temperature range of 0 ... +80 °C (+32 ... +176 °F), reference temperature 20 °C (68 °F).

Average temperature coefficient of the zero signal

– Turn down 1 : 1	< 0.15 %/10 K
– Turn down up to 5 : 1	< 0.2 %/10 K
– Turn down up to 10 : 1	< 0.25 %/10 K

⁵⁾ Incl. non-linearity, hysteresis and non-repeatability.

Outside the compensated temperature range:

Average temperature coefficient of the zero signal

- Turn down 1 : 1 typ. < 0.15 %/10 K

Long-term stability (similar to DIN 16086, DINV 19259-1 and IEC 60770-1)

Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

- Long-term drift of the zero signal < (0.1 % x TD)/year

Total deviation (similar to DIN 16086)

The total deviation F_t , also called practical deviation, is the sum of the basic accuracy F_p and long-term stability:

$$F_t = F_p + F_s$$

$$F_{perf} = \sqrt{(F_T)^2 + (F_{KI})^2}$$

With

- F_t : F_{total} , total deviation
- F_p : F_{perf} , basic accuracy
- F_s : F_{stab} , long-term drift
- F_T : Temperature coefficient (influence of medium or ambient temperature)
- F_{KI} : Deviation

Ambient conditions

Ambient temperature

- Connection cable PE -40 ... +60 °C (-40 ... +140 °F)
- Connection cable PUR, FEP -40 ... +80 °C (-40 ... +176 °F)

Storage and transport temperature -40 ... +80 °C (-40 ... +176 °F)

Process conditions

Max. process pressure, transmitter⁶⁾

- Measuring range 0.1 bar (1.45 psig) 15 bar (218 psig)
- Measuring range 0.2 bar (2.9 psig) 20 bar (290 psig)
- Measuring range ≤ 0.4 bar (5.8 psig) 25 bar (363 psig)

Pressure stage, process fitting

- Unassembled screw connection 316L: PN 3, PVDF: unpressurized
- Thread on the housing PN 3

Product temperature, depending on the version

⁶⁾ Limited by the overpressure resistance of the measuring cell.

Suspension cable	Transmitter	Product temperature
PE	All	-20 ... +60 °C (-4 ... +140 °F)
PUR	All	-20 ... +80 °C (-4 ... +176 °F)
PUR	PE coating	-20 ... +60 °C (-4 ... +140 °F)
FEP	All	-20 ... +80 °C (-4 ... +176 °F)
FEP	PE coating	-20 ... +60 °C (-4 ... +140 °F)

Vibration resistance mechanical vibrations with 4 g and 5 ... 100 Hz⁷⁾

Electromechanical data

Suspension cable

- Configuration six wires, one suspension cable, one breather capillary, screen braiding, foil, mantle
- Wire cross-section 0.5 mm²
- Wire resistance ≤ 0.036 Ω/m
- Tensile strength ≥ 1200 N (270 pound force)
- Max. length 1000 m (3280 ft)
- Min. bending radius 25 mm (with 25 °C/77 °F)
- Diameter approx. 8 mm (0.315 in)
- colour (non-Ex/Ex) - PE black/blue
- colour (non-Ex/Ex) - PUR, FEP blue/blue

Cable entry housing 1 x cable gland M20 x 1.5 (cable: ø 5 ... 9 mm), 1 x blind stopper M20 x 1.5

Screw terminals for cable cross-section up to 1.5 mm² (AWG 16)

Power supply

Operating voltage 8 ... 36 V DC

Permissible residual ripple

- < 100 Hz $U_{ss} < 1 \text{ V}$
- 100 Hz ... 10 kHz $U_{ss} < 10 \text{ mV}$

Load see diagram

⁷⁾ Tested according to the regulations of German Lloyd, GL directive 2.




Fig. 12: Voltage diagram

- 1 Voltage limit
- 2 Operating voltage

Integrated overvoltage protection

Nominal leakage current (8/20 μ s)	5 kA
Min. response time	< 25 ns

Electrical protective measures

Protection	
– Transmitter	IP 68 (30 bar)
– Housing	IP 66/IP 67
Overvoltage category	III
Protection class	III

Approvals

Depending on the version, instruments with approvals can have different technical data.

For these instruments, the corresponding approval documents have to be taken into account. These are part of the delivery or can be downloaded under www.vega.com via "VEGA Tools" and "serial number search" as well as via "Downloads" and "Approvals".

8.2 Dimensions

VEGAWELL 52 - suspension cable 1




Fig. 13: VEGAWELL 52 - suspension cable

- 1 Transmitter Duplex, with straining clamp
- 2 Transmitter Duplex for deep wells, with unassembled screw connection G1 1/2 A (1 1/2 NPT) and closing cap
- 3 Transmitter Duplex, with PE coating
- 4 Transmitter with screwed connection of PVDF
- 5 Transmitter Titanium/Titanium with glass leadthrough, with thread G1 A (1 NPT) and plastic housing

VEGAWELL 52 - suspension cable 2




Fig. 14: VEGAWELL 52 - suspension cable

- 1 Transmitter 316L, with straining clamp
- 2 Transmitter Titanium, with unassembled screw connection G1 A (1 NPT)

8.3 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see <http://www.vega.com>.

Only in U.S.A.: Further information see patent label at the sensor housing.

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte.

Nähere Informationen unter <http://www.vega.com>.

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle. Pour plus d'informations, on pourra se référer au site <http://www.vega.com>.

VEGA líneas de productos están protegidas por los derechos en el campo de la propiedad industrial. Para mayor información revise la pagina web <http://www.vega.com>.

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность. Дальнейшую информацию смотрите на сайте <http://www.vega.com>.

VEGA系列产品在全球享有知识产权保护。
进一步信息请参见网站<<http://www.vega.com>>。

8.4 Trademark

All brands used as well as trade and company names are property of their lawful proprietor/originator.



Printing date:

VEGA Grieshaber KG
Am Hohenstein 113
77761 Schiltach
Germany
Phone +49 7836 50-0
Fax +49 7836 50-201
E-mail: info@de.vega.com
www.vega.com



All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.

© VEGA Grieshaber KG, Schiltach/Germany 2009