

# User Manual

# Conceptpower™

# Gemini-Line

Modular (n+1)-redundant  
3phase UPS System  
10-30kVA



# CONTENTS

<b>1</b>	<b>SAFETY</b> .....	<b>4</b>
<b>2</b>	<b>DESCRIPTION</b> .....	<b>5</b>
2.1	RELIABILITY AND QUALITY STANDARDS.....	5
2.2	CONCEPTPOWER MODELS.....	5
2.3	SINGLE/PARALLEL-MODULES AND SINGLE/MULTI-CABINET CONFIGURATIONS .....	5
2.4	WARRANTY .....	6
2.5	EXTENDED WARRANTY .....	6
<b>3</b>	<b>INSTALLATION</b> .....	<b>7</b>
3.1	INTRODUCTION.....	7
3.1.1	Receipt of the UPS .....	7
3.1.2	Nameplate.....	7
3.2	UNPACKING .....	7
3.3	BATTERIES .....	7
3.4	STORAGE.....	8
3.4.1	UPS.....	8
3.4.2	Battery.....	8
3.5	POSITIONING.....	8
3.6	CABLING.....	9
3.6.1	Connection Diagram .....	9
3.6.2	Preparation for the Input Cabling.....	9
3.6.3	Earthing.....	9
3.6.4	Connection of the Mains Supply .....	9
3.6.5	Single Input Feed.....	10
3.6.6	Dual Input Feed .....	10
3.6.7	Preparation for the Output Cabling .....	11
3.6.8	Connection of the Load.....	11
3.6.9	Output Cabling.....	11
3.7	INTERNAL BATTERY MODULES.....	14
3.8	EXTERNAL BATTERY CABINET AND BATTERY CONNECTION .....	14
3.8.1	External Battery Configuration.....	14
3.8.2	Connection of External Battery Cabinet and UPS Conceptpower™ Gemini-Line.....	15
3.9	INTERFACING .....	16
3.9.1	SMART PORT (Serial RS 232).....	16
3.9.2	DRY PORT (volt-free contacts).....	17
<b>4</b>	<b>OPERATION</b> .....	<b>18</b>
4.1	COMMISSIONING .....	18
4.2	CONTROL PANEL.....	18
4.2.1	Power Management Display (PMD) .....	18
4.2.2	LED Indicators .....	19
4.2.3	Keys .....	19
4.2.4	ON/OFF Start-up and Shutdown Buttons .....	19
4.2.5	Definition of a Single/Parallel-Module System (DIP Switch SW1-1).....	20
4.2.6	Definition of a Single/ Multi-Cabinet Chain (DIP Switch SW2-9).....	20
4.3	DESCRIPTION OF THE LCD .....	21
4.3.1	Status Screens.....	21
4.3.2	Main Menu Screen.....	21
4.3.3	Event Log Screen .....	21
4.3.4	Measurements Screen.....	22
4.3.5	Commands Screen .....	22
4.3.6	UPS Data .....	22
4.3.7	Set-Up User .....	23
4.3.8	Set-Up Service.....	23
4.4	OPERATING MODES .....	24
4.4.1	Mode "ON LINE" (INVERTER MODE) .....	24

4.4.2	Mode"OFF-LINE"(ECO- or BYPASS MODE)	24
4.4.3	"MAINTENANCE BYPASS" - Mode	25
4.4.4	Parallel Isolator (IA2)	25
4.5	START-UP PROCEDURE	26
4.6	SHUTDOWN PROCEDURE	28
4.7	LOAD TRANSFER: FROM INVERTER OPERATION TO MAINTENANCE BYPASS	29
4.8	LOAD TRANSFER: FROM MAINTENANCE BYPASS TO INVERTER OPERATIONS	30
<b>5</b>	<b>REPLACEMENT OF UPS-MODULE</b>	<b>31</b>
5.1	REPLACEMENT OF UPS-MODULE IN SINGLE-MODULE SYSTEMS	31
5.1.1	How to Extract a UPS-Module in SINGLE MODULE Systems	31
5.1.2	How to Fit Back a UPS-Module in SINGLE-MODULE-Systems	32
5.2	REPLACEMENT OF UPS-MODULE IN REDUNDANT MULTI-MODULE SYSTEM	34
5.2.1	How to Extract a Module in Redundant Multi-Module System	34
5.2.2	How to insert a module in a Redundant Multi Module System	35
5.3	REPLACEMENT OF A MODULE IN CAPACITY MULTI-MODULE SYSTEM	36
5.3.1	How to Extract a Module in a Capacity Multi-Module System	36
5.3.2	How to Fit Back a Module in a Capacity Multi-Module System	37
<b>6</b>	<b>MULTI-CABINET CONFIGURATION</b>	<b>39</b>
6.1	CONCEPT OF MULTI-CABINET CONFIGURATION	39
6.2	INSTALLATION INSTRUCTIONS	40
6.2.1	Introduction	40
6.2.2	Paralleling of UPS-Cabinets	40
6.2.2.1	Connection of Parallel Communication Cables (BUS-lines)	40
6.2.2.2	Parallel Adapter and DIP-Switch SW2-2	41
6.2.3	DIP-Switch SW1-1 and SW2-9 Settings	41
6.2.4	ON/OFF – Main Buttons	42
6.2.5	Parallel Isolator (IA2)	42
6.2.6	Maintenance Bypass (IA1)	42
6.2.6.1	Redundant Parallel Configuration	42
6.2.6.2	Capacity Parallel Configuration	42
6.2.7	ECO-MODE (BYPASS MODE) in Parallel Systems	43
6.3	COMMISSIONING OF MULTI-CABINET CONFIGURATION	43
6.3.1	Start-up of a Multi-Cabinet Configuration	43
6.3.2	Shutdown of Multi-Cabinet Configuration	43
6.3.3	Replacement of a Faulty UPS-Module in a Multi-Cabinet Configuration	43
<b>7</b>	<b>MAINTENANCE</b>	<b>44</b>
7.1	INTRODUCTION	44
7.2	USER RESPONSIBILITIES	44
7.3	ROUTINE MAINTENANCE	44
7.4	BATTERY TEST	44
<b>8</b>	<b>TROUBLESHOOTING</b>	<b>45</b>
8.1	ALARMS	45
8.2	MENU, COMMANDS, EVENT LOG, MEASUREMENTS,	45
8.3	FAULT IDENTIFICATION AND RECTIFICATION	45
<b>9</b>	<b>OPTIONS</b>	<b>46</b>
9.1	INTRODUCTION	46
9.2	REMOTE EMERGENCY FACILITIES	46
9.3	REMOTE SIGNALLING PANEL (RSP)	47
9.3.1	How to Connect the Remote Signalling Panel (RSP)	48
9.4	GENERATOR ON FACILITIES	48
9.5	WAVEMON SHUTDOWN AND MANAGEMENT SOFTWARE	49
9.5.1	Why is UPS Management important?	49
9.5.2	Wavemon Shutdown and Monitoring Software	49
9.6	SNMP CARD/ADAPTER FOR NETWORK MANAGEMENT /REMOTE MONITORING	51
<b>10</b>	<b>TECHNICAL SPECIFICATIONS</b>	<b>52</b>

# 1 Safety



**BEFORE ATTEMPTING TO INSTALL OR START UP THIS UPS THE USER MUST ENSURE THAT THE SAFETY INSTRUCTIONS IN THIS MANUAL ARE CAREFULLY READ AND OBSERVED BY TECHNICALLY COMPETENT PERSONNEL. KEEP THIS MANUAL WITH THE UPS FOR FUTURE REFERENCE. THIS UPS MUST NOT BE STARTED UP OR PUT INTO USE WITHOUT HAVING BEEN COMMISSIONED BY A FULLY TRAINED AND AUTHORISED PERSON.**



**ALL SERVICING MUST BE PERFORMED ONLY BY QUALIFIED PERSONNEL. DO NOT ATTEMPT TO SERVICE THE UPS YOURSELF. BY OPENING OR REMOVING THE UPS-COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!**

**IN CASE OF ANY KIND OF DOUBT REGARDING THIS UPS, CONTACT:**

**■ NEWAVE SA, SWITZERLAND**

**Tel. +41 91 850 29 29**

**Fax. +41 91 840 12 54**

**e-mail: [info@newave.ch](mailto:info@newave.ch)**

**[www.newave.ch](http://www.newave.ch)**

**NEWAVE SA WILL ASSUME NEITHER RESPONSIBILITY NOR LIABILITY DUE TO INCORRECT OPERATION OR MANIPULATION OF THE UPS.**



**HIGH LEAKAGE CURRENT!**

**MAKE SURE THAT THE EARTHING IS CARRIED OUT CORRECTLY BEFORE YOU CONNECT THE MAINS POWER SUPPLY!**



**THE CONCEPTPOWER 10 – 30 kVA IS CLASS A - UPS-PRODUCT (ACCORDING TO EN 50091/Part-2).**

**IN A DOMESTIC ENVIRONMENT IT MAY CAUSE RADIO INTERFERENCE. IN SUCH AN ENVIRONMENT THE USER MAY BE REQUIRED TO UNDERTAKE ADDITIONAL MEASURES.**

**NEWAVE S.A. HAS TAKEN EVERY PRECAUTION TO PRODUCE AN ACCURATE, COMPLETE AND EASY TO UNDERSTAND MANUAL AND WILL THEREFORE ASSUME NO RESPONSIBILITY NOR LIABILITY FOR DIRECT, INDIRECT OR ACCIDENTAL PERSONAL OR MATERIAL DAMAGE DUE TO ANY MISINTERPRETATION OR UNDESIRED MISTAKES IN THIS MANUAL.**

**THIS MANUAL MAY NOT BE COPIED NOR REPRODUCED PRIOR TO WRITTEN PERMISSION OF NEWAVE SA.**



**USER MUST HANG A WARNING LABEL ON ALL PRIMARY UPS POWER ISOLATORS. ELECTRICAL MAINTENANCE PERSONNEL SHOULD BE AWARE OF DANGEROUS VOLTAGES. THE WARNING LABEL SHOULD CARRY THE FOLLOWING WORDING: "ISOLATE UPS BEFORE WORKING ON THIS CIRCUIT"**

## 2 Description

### 2.1 RELIABILITY AND QUALITY STANDARDS.

Congratulation on your purchase of the **Conceptpower™**.

The **Conceptpower™** will provide your critical equipment with a steady and reliable power supply for many years.

NEWAVE SA is situated in Switzerland and is specialized in the design and manufacture of Uninterruptible Power Supplies.

The unique and modular UPS **Conceptpower™** belongs to the newest generation of midrange 3phase UPS-Systems. High reliability, low operating cost and excellent electrical performance are only some of the highlights of this innovative UPS solution.

The criteria and methods implemented at NEWAVE SA for the design and manufacture correspond to the most stringent quality standards.

The Swiss Association for Quality and Management System (SQS) certified that, according to the model of the International Standard ISO 9001/EN 29001, the whole Newave SA company complies successfully. (Registration No.: 14879-01, date issued: 12 April 1999.)

### 2.2 CONCEPTPOWER MODELS

The **Conceptpower™** UPS-Series consists of three Lines:

**Classic-Line:** The Classic-Line 10-40kVA cabinet consists of only one UPS-Module and a standard battery.

**Gemini-Line:** The Gemini-Line 10-30kVA cabinet consists of two UPS-Module and a standard battery.

**Upgrade-Line:** The Upgrade-Line 10-40kVA cabinet consists of three UPS-Module

### 2.3 SINGLE/PARALLEL-MODULES AND SINGLE/MULTI-CABINET CONFIGURATIONS

The **Conceptpower™** has unique paralleling features. We distinguish:

#### **Single/Parallel-Modules**

Single-Module: If a configuration consists of one single Module it is defined as a Single-Module Configuration (Classic-, Gemini- or Upgrade-Line with a single Module).

Parallel-Module: A Parallel-Module is a Module that is operating in a parallel with other equivalent Modules.

#### **Single/Multi-Cabinet Configurations**

Single-Cabinet Configuration: A single-cabinet configuration means that there are no cabinets operating in a chain.

Multi-Cabinet Configurations: It is possible to parallel **Conceptpower™** (Classic-, Gemini- or Upgrade-Line) Cabinets into a Multi-Cabinet Configuration in order to increase the number of paralleled Modules.

## 2.4 WARRANTY

The **Conceptpower™** is supplied with a limited warranty that the UPS and its component parts are free from defects in materials for a period of 12 months from the date of original commissioning or 15 months from the date of original delivery, whichever is the sooner. Transportation cost is not included in the warranty and has to be paid by the end-user.

Do not return anything without written authorisation from NEWAVE or your closest service centre. NEWAVE or the closest service centre will then give you further instructions how to proceed.

Any product must be returned with transportation charges prepaid and must be accompanied by a description of the failure. Products without description will not be handled.

This warranty is invalidated if the UPS is put into use without having been commissioned by a fully trained and by NEWAVE authorised person.

This warranty does not apply to any damage or losses caused by misuse, abuse, negligence, neglect, unauthorised repair or modification, incorrect installation, inappropriate environment, accident, act of God or inappropriate application.

If the UPS fails to conform to the above within the warranty period then NEWAVE SA or an authorized service centre will, at its sole option, repair or replace the UPS or parts of it. All repaired or replaced parts will remain the property of NEWAVE or of the authorized service centre.

NEWAVE is not liable for any costs, such as loss of profits or revenue, loss of equipment, loss of data or software, cost of substitutes, claims by third parties or otherwise.

As general policy, NEWAVE does not recommend the use of any of its products in life support applications where failure or malfunction of the NEWAVE product can be reasonably expected to cause failure of the life support device or to significantly affect us safety or effectiveness. NEWAVE does not recommend the use of any of its products in direct patient care. NEWAVE will not knowingly sell its products for use in such applications unless it receives in writing assurances satisfactory to NEWAVE that the risks of injury or damage have been minimized, the customer assumes all such risks and the liability of NEWAVE is adequately protected under the circumstances.



---

*The UPS may contain batteries that must be re-charged for a minimum of 24 hours every 6 months to prevent deep discharging. Batteries that have been, for whatever reason, deep discharged are not covered by the warranty.*

## 2.5 EXTENDED WARRANTY

The standard warranty may be enhanced by protecting the UPS with an Extended Warranty Agreement (maintenance contract).

For more details please contact the nearest representative.

# 3 Installation

## 3.1 INTRODUCTION

This chapter contains all the necessary information for the correct unpacking, positioning, cabling and installation of the UPS **Conceptpower™**.



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED PERSONNEL.**

**NEWAVE will take no responsibility for any personal or material damage caused by incorrect cabling or operations or activities, which are not carried out as per the instructions contained in this manual.**

### 3.1.1 Receipt of the UPS

Upon receiving the UPS, carefully examine the packing container and the UPS for any sign of physical damage. In case of rupture or suspect inform immediately:

- a) The carrier and
- b) NEWAVE SA.

Ensure that the received UPS corresponds to the material indicated in the delivery note.

The packing container of the **Conceptpower™** protects it from mechanical and environmental damage. To increase its protection the UPS is wrapped with a plastic sheet.

### 3.1.2 Nameplate

The technical specifications of the **Conceptpower™** are provided on the nameplate, which is situated at the front of the UPS. Check if it corresponds to the purchased material mentioned in the delivery note.

## 3.2 UNPACKING

When unpacking the UPS observe the "FRAGILE" and "ARROW" on the packing container.

Perform the following steps to unpack the UPS:

- Cut wrappers and remove packing container by pulling it upwards;
- Remove the plastic cover from the UPS;
- Remove pallet from the UPS;
- Retain the packaging materials for future shipment of the UPS;
- Examine the UPS for any sign of damage. Notify your carrier or supplier immediately if damage is apparent.
- Open the UPS-door and make sure that all the UPS-Modules are appropriately fitted in their UPS-Compartment and if the UPS system is provided without a UPS-module make sure that the empty UPS-compartment is correctly covered with the UPS-compartment protection cover.

## 3.3 BATTERIES

The standard batteries of the **Conceptpower™** are sealed, maintenance-free batteries, mounted in an external battery cabinet and will typically be connected when the UPS is commissioned.

The battery life depends very much on the ambient temperature. A temperature range between +18° and +23°C will achieve the optimum battery life.

If the UPS is delivered without batteries, NEWAVE is not responsible for any damage or malfunctioning caused to the UPS by incorrect wiring.

### 3.4 STORAGE

#### 3.4.1 UPS

If you plan to store the UPS prior to use, keep the UPS unpacked in a dry, clean and cool storage room with an ambient temperature between (+5 °C to +40°C) and humidity of less than 90%.

If the packing container is removed protect the UPS from dust.

#### 3.4.2 Battery

The battery life depends very much on the ambient temperature.

It is therefore important not to store the battery longer than 6 months at 20°C, 3 months at 30°C and 2 months at 35°C storage temperature without a battery recharge.

For longer-term storage make sure that the battery is fully recharged every 6 months.

SEALED BATTERIES MUST NEVER BE STORED IN A DISCHARGED OR PARTIALLY DISCHARGED STATE.

EXTREME TEMPERATURE, UNDER- AND OVERCHARGE AND OVERDISCHARGE WILL DESTROY BATTERIES!

Before and after storing, charge the battery.

Always store the batteries in a dry, clean, cool environment in their original packaging.

If the packing container is removed protect the batteries from dust and humidity.

### 3.5 POSITIONING

The **Conceptpower™** is a compact and light UPS and can easily be moved to the final position.

All parts of the **Conceptpower™** are accessible from the front and rear making it a service-friendly and maintenance-friendly UPS.

The UPS should be located where:

- Humidity and temperature are within prescribed limits;
- Fire protection standards are respected;
- Cabling can be performed easily;
- Available front accessibility for service or periodic maintenance;
- Requested air cooling flow should be granted;
- The air conditioning system should have sufficient capacity;
- Dust or corrosive/explosive gases must be absent;
- The place is vibration free;
- Minimum 10cm rear space is recommended for proper cooling (see Figure 3.1 and 3.2);
- Only front access is necessary for service and maintenance.




Figure 3.1: UPS space recommendation




Figure 3.2: UPS + Battery cabinet space recommendation



## 3.6 CABLING

### 3.6.1 Connection Diagram

To ensure correct operation of the UPS and its ancillary equipment it is necessary to provide the mains cables with appropriate fuse protection.

To connect the **Conceptpower™** to the mains power supply see Figures 3.3, 3.4 and 3.5.



**ALL THE OPERATIONS IN THIS MANUAL MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.  
DO NOT OPERATE IN CASE OF PRESENCE OF WATER OR MOISTURE.  
BY OPENING OR REMOVING THE UPS-COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!**

### 3.6.2 Preparation for the Input Cabling

Before you start connecting the UPS, ensure that:

- MAINS VOLTAGE (INPUT VOLTS) AND FREQUENCY (FREQUENCY) CORRESPOND TO THE VALUES INDICATED ON THE NAMEPLATE OF THE UPS.
- EARTHING IS PERFORMED IN ACCORDANCE WITH THE PRESCRIBED IEC STANDARDS OR WITH LOCAL REGULATIONS;
- UPS IS CONNECTED TO THE MAINS THROUGH A LV-DISTRIBUTION BOARD WITH A SEPARATE MAINS LINE (PROTECTED WITH A CIRCUIT BREAKER OR FUSE) FOR THE UPS.

Provide input fuses and cables according to Figure 3.4 or in accordance with the prescribed IEC Standards or with the local regulations.

The input of the UPS must be fitted with circuit breakers or other kind of protection. The circuit breakers will be connected between the mains supply and the UPS and will provide additional protection to the UPS in the event of overloads and short circuits.

### 3.6.3 Earthing



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED TRAINED INTERNAL PERSONNEL.**

To ensure protection of personnel during the installation of UPS make sure that the connections are performed under the following conditions:

- No mains voltage is present;
- Loads are shut down and disconnected;
- UPS **Conceptpower™** is shut down and voltage-free.

Connect the earthing wire coming from the LV-Distribution Board to the terminal "PE".

Under the connection terminal of the UPS there is a cable-fixing rail to ensure that the cables have been fastened properly.

### 3.6.4 Connection of the Mains Supply

After the UPS has been unpacked and brought to its final position the authorized technician may start with the cabling.



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

To ensure protection of the personnel during the installation of the UPS make sure that the connections are performed under the following conditions:

- No mains voltage is present;
- All loads are shut down and disconnected;
- UPS **Conceptpower™** is shut down and voltage-free.

Remove the terminal cover of the UPS

Before connecting the input power cables make sure that:

- UPS-Module is fitted in its correct position;
- Maintenance Bypass IA1 is open in position OFF;
- Parallel Isolators IA2 are in position OFF

Connect the input power cable coming from the LV-Distribution Board to the terminals of the UPS showed in the following pages, keeping the phase rotation in clock-wise sense.



**NOTE: Neutral input wire must always be connected!**

**NOTE:** The UPS **Conceptpower™** is provided with facilities for both single feed (one common input cable for rectifier and bypass) and dual feed (separate input cable for rectifier and bypass).

The standard UPS Conceptpower™ is always supplied with facilities for a single feed.

If dual feed is required please contact your nearest Service Centre.

### 3.6.5 Single Input Feed

To achieve correct Input Cabling see Drawing in Figure 3.5.

For single input feed connect the mains input cable to UPS Terminal Block according to the following table:

MAINS INPUT CABLE	UPS TERMINAL
Phase L1	1L1
Phase L2	1L2
Phase L3	1L3
NEUTRAL	1N
EARTH	PE

For minimum recommended Input Cable Sections and Fuse Ratings for the conceptpower Gemini-Line see table in Figure 3.4.

Under the connection terminal of the UPS there is a cable-fixing rail to ensure that the cables have been fastened properly.

### 3.6.6 Dual Input Feed

To achieve correct input cabling see Terminal Block in Figure 3.5.

**NOTE:** The UPS is supplied (as standard version) with facilities for a single cable feed (for rectifier and bypass).

If dual feed is required, please contact your nearest service centre.

For dual input feed connect the mains input cables to UPS Terminal according to following tables:

MAINS INPUT CABLE	UPS TERMINAL	BYPASS INPUT CABLE	UPS TERMINAL
Phase L1	1L1	Phase L1	2L1
Phase L2	1L2	Phase L2	2L2
Phase L3	1L3	Phase L3	2L3
NEUTRAL	1N	NEUTRAL	2N
EARTH	PE	EARTH	PE

For minimum recommended Input Cable Sections and Fuse Ratings for the **Conceptpower™ Gemini-Line** see table in Figure 3.4.

Under the connection terminal of the UPS there is a cable-fixing rail to ensure that the cables have been fastened properly.

### 3.6.7 Preparation for the Output Cabling

Before you start connecting the loads, ensure that the sum of the indicated UPS-module rated powers (OUTPUT POWER) on the nameplates (on the front side of the UPS-modules) is equal to or larger than the total load requirements.

The output of the UPS must be fitted with circuit breakers or other kind of protection. These circuit breakers will be connected between the loads and the UPS and will provide additional protection to the UPS in the event of overloads and short circuits.

These circuit breakers will enable the protection of each load separately.

The size of the circuit breakers depends on the load rating of the load sockets.

The circuit breakers must comply with the prescribed IEC Standards. It is recommended to provide a separate output distribution board for the load.

The following values should be indicated on the output distribution board:

- Maximum total load rating;
- Maximum load rating of the load sockets.
- If a common distribution board is used (sockets for Mains and UPS voltage), ensure that on each socket there is an indication of the applied voltage (“Mains” or “UPS”).

Output power cable ratings should be in accordance with the recommended cable sections and fuses ratings or in accordance with the prescribed IEC Standards or with the local regulations.

Under the connection terminal of the UPS there is a cable-fixing rail to ensure that the cables have been fastened properly.

Ensure that the earthing is performed in accordance with the prescribed IEC Standards or with the local regulations.

### 3.6.8 Connection of the Load



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL**

To ensure protection of the personnel during the installation of the UPS make sure that the connections are performed under the following conditions:

- No mains voltage is present;
- All loads are shut down and disconnected;
- UPS Conceptpower™ is shut down and voltage-free.

Before connecting the output power cables make sure that:

- UPS-Module is fitted in its correct position;
- Maintenance bypass is in position OFF;
- Parallel Isolators IA2 is in position OFF

Remove the terminal cover of the UPS.

Connect the output power cable coming from the LV-Distribution Board to the terminals of the UPS as shown in drawing of Figure 3.5.

### 3.6.9 Output Cabling

To achieve correct Output Cabling see Terminal Block in Figure 3.5.

For output cabling connect output cable to UPS Terminal according to following Output to UPS terminal block correlation.

OUTPUT CABLE	UPS TERMINAL
Phase L1	3L1
Phase L2	3L2
Phase L3	3L3
NEUTRAL	3N
EARTH	PE

Under the connection terminal of the UPS there is a cable-fixing rail to ensure that the cables have been fastened properly.

## Block Diagram Gemini




Figure 3.3: Block Diagram Conceptpower™ Gemini

### Recommended Cable Sections and Fuse Ratings

#### STANDARD VERSION (SINGLE INPUT FEED)

Power (kVA)	Fuse A (Agl/CB)	Cable A (IEC 60950-1:2001)	Cable D (IEC 60950-1:2001)	Fuse E +/N/-	Cable E +/N/-
10	3x40	5x6	5x6	3x32A	3x4
10+10	3x40	5x6	5x6	3x63A	3x10*
15	3x63	5x10	5x10	3x63A	3x10
15+15	3x63	5x10	5x10	3x100A*	3x25*
20	3x80	5x16	5x16	3x63A	3x10
20+20	3x80	5x16	5x16	3x125A*	3x35*
30	3x100	5x25	5x25	3x80A	3x16
30+30	3x100	5x25	5x25	3x125A*	3x35*

#### VERSION ON REQUEST (DOUBLE INPUT FEED)

Power (kVA)	Fuse B (Agl/CB)	Cable B (IEC 60950-1:2001)	Fuse C (Agl/CB)	Cable C (IEC 60950-1:2001)	Cable D (IEC 60950-1:2001)	Fuse E +/N/-	Cable E +/N/-
10	3x40	5x6	3x40	4x6	5x6	3x32A	3x4
10+10	3x40	5x6	3x40	4x6	5x6	3x63A*	3x10*
15	3x63	5x10	3x63	4x10	5x10	3x63A	3x10
15+15	3x63	5x10	3x63	4x10	5x10	3x100A*	3x25*
20	3x80	5x16	3x80	4x16	5x16	3x63A	3x10
20+20	3x80	5x16	3x80	4x16	5x16	3x125A*	3x35*
30	3x100	5x25	3x100	4x25	5x25	3x80A	3x16
30+30	3x100	5x25	3x100	4x25	5x25	3x125A*	3x35*

\*only valid for common battery use




Figure 3.5: In/Out Terminal Block, Front View Conceptpower™ – Gemini Line

### 3.7 INTERNAL BATTERY MODULES


In **Conceptpower™ Gemini** there is space for up to 120 x 7Ah internal batteries.

In the drawing below different Battery and System configurations are shown. The batteries may be used as separate batches for each System or they can be used as common batteries for both Systems.

**NOTE:** For UPS-Systems 10kVA, 15kVA and 20kVA it is allowed to use 30-50 (only even numbers) of 12V-battery blocks. For UPS-System 30kVA use only 40-50 (only even numbers) of 12V-battery blocks.

**NOTE:** Set-up the correct number of battery blocks on Control Panel (Menu: Service-Set-Up).3

\*) For 2 x 30 kVA configuration, it is possible to utilize the internal battery (3x40) x 7Ah in common for both Moduls




### 3.8 EXTERNAL BATTERY CABINET AND BATTERY CONNECTION

#### 3.8.1 External Battery Configuration

An external matching battery frame CBAT-30GU is also available for 7Ah, 7.2Ah, 9Ah, 11Ah, 24Ah and 28Ah battery blocks. Up to 90 x 24Ah battery blocks may be fitted in this cabinet. See Figure 3.6.

**NOTE:** For UPS-Modules 10kVA, 15kVA and 20kVA it is allowed to use 30-50 (only even numbers) of 12V-battery blocks. For UPS-Module 30kVA use only 40-50 (only even numbers) of 12V-battery blocks.

**NOTE:** Set-up the correct number of battery blocks on Control Panel (Menu: Service-Set-Up).



**Figure 3.6** In the left drawing (2x30)x24Ah battery blocks are fitted. The lower batch of 30x24Ah belong to UPS 1 and the upper batch of 30x 24Ah belong to UPS 2. On the right drawing (2x40)x24Ah battery blocks are fitted and each UPS-Module is provided with 40x24Ah.

Depending on the request the batteries may be connected separately for each Module or it is possible to parallel them together into one common battery for all three UPS-modules

### 3.8.2 Connection of External Battery Cabinet and UPS Conceptpower™ Gemini-Line




**ALL THE OPERATIONS IN THIS MANUAL MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

**DO NOT OPERATE IN CASE OF PRESENCE OF WATER OR MOISTURE.**

**BY OPENING OR REMOVING THE UPS-COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!**

It is normally recommended for redundant Multi-Module systems to provide each UPS-Module with its own separate battery. In this way the redundancy is extended also to the batteries. In the Figure 3.7 the drawing shows how to connect the batteries in the external battery cabinet CBAT-30GU and the UPS Conceptpower™ Gemini Line.



To ensure protection of the personnel during the installation of the UPS make sure that the connections are performed under the following conditions:

- No mains voltage is present in the UPS
- All the loads are disconnected

To verify the complete shut down of the **Conceptpower™** perform following steps:

- 1) Make sure that the fuses feeding the UPS in the input Distribution Board are all open and no power is fed to the UPS.
- 2) Make sure the "MAINTENANCE BYPASS"(IA1) is open (position "OFF")
- 3) Make sure that F4 and the battery fuses in the external battery cabinet are open.
- 4) Connect Earth (**PE**) between the UPS and external battery cabinet.
- 5) Connect the corresponding **+** , **N** , **-** terminals between UPS and external battery cabinet according to drawing in Figure 3.7.

### 3.9 INTERFACING

The **Conceptpower™** is provided with two ports:

- SMART PORT (Serial RS 232);
- DRY PORT (voltage-free contacts);

#### 3.9.1 SMART PORT (Serial RS 232)

The SMART PORT JD1 is an intelligent RS 232 serial port that allows the UPS to be connected to a computer. The connector is a standard D-Type, 9-pin, female.

When installed the optional SMART PORT, the software WAVEMON allows the computer to monitor the mains voltage and the UPS status continuously.

In the event of any changes the computer terminal will display a message. (For details see our Monitoring Package: **WAVEMON**)\*.

The Fig. 3.8 and 3.9 shows how to connect a PC to the UPS.

- Fig. 3.8 in case the PC has a 9 pin serial port
- Fig. 3.9 in case the PC has a 25 pin serial port




Figure 3.8 Connector Cable - PC Serial Port with 9-Pin Connection




Figure 3.9 Connector Cable – PC Serial Port with 25-pin Connection





















### 3.9.2 DRY PORT (volt-free contacts)

Description:

The DRY PORT JD2 (DB-25P/F) may be used for:

- Connection of remote emergency stop facilities (see paragraph 9.2);
- Connection of Remote Status Panel (see paragraph 9.3);
- Provision of signals for the automatic and orderly shutdown of servers
- or IBM AS400, etc.

Definition of PINs on DRY PORT JD2 (25 PIN):

Pin	Contact	Signal	Function
1	NO 	ALARM	Mains failure
2	NC 		MAINS_OK
3	C 		Common
4	NO 	Message	Load on inverter
5	NC 		LOAD_ON_INV
6	C 		Common
7	NO 	ALARM	Battery low
8	NC 		BATT_LOW
9	C 		Common
10	NO 	Message	Load on Mains (BYPASS mode)
11	NC 		LOAD_ON_MAINS
12	C 		Common
13	NO 	ALARM	Common Alarm
14	NC 		COMMON_ALARM
15	C 		Common
16		NC	Not Connected
19			
20			Customer in  +12V
21		GND	Customer in GND
22		PS_12	GND
23		PS_12	+ 12V (I <sub>max</sub> = 100 mA)
24			Not Connected
25			Not Connected

All volt free contacts are rated 60 VAC max. and 500 mA max.

Figure 3.10 DRY PORT (JD2) Connections

# 4 Operation

## 4.1 COMMISSIONING

The Conceptpower™ UPS is a high quality electronic machine that must be commissioned by a fully trained and authorized NEWAVE field service engineer before being put into use.

The commissioning of the UPS involves the connection of the UPS and battery, the checking of the electrical installation and operating environment of the UPS, the controlled start-up and testing of the UPS and customer training.



***Any Conceptpower™ UPS system not commissioned by a NEWAVE field service engineer or authorized service centre must be considered an electrical hazard and NEWAVE accepts no responsibility for its safe operation or the safety of any personnel. Additionally, the manufacturer's warranty is immediately invalidated if the UPS is put into use before it has been correctly commissioned.***

## 4.2 CONTROL PANEL

The user-friendly control panel is composed of three parts:

- POWER MANAGEMENT LCD DISPLAY (PMD);
- LED INDICATORS;
- KEYS.




Figure 4.1 Control Panel.

### 4.2.1 Power Management Display (PMD)

The 2 x 20 character LCD simplifies the communication with the UPS and provides the necessary monitoring information about the UPS.

The menu driven LCD enables the access to the:

- EVENT REGISTER;
- Monitor the input and output U, I, f, P,
- Battery runtime;
- To perform commands like start-up and shut-down of UPS and
- Load transfer from INVERTER to BYPASS and vice-versa;
- DIAGNOSIS (SERVICE MODE);
- Adjustments and testing.

## 4.2.2 LED Indicators

The mimic diagram serves to indicate the general status of the UPS. The LED-indicators show the power flow status and in the event of mains failure or load transfer from inverter to bypass and vice-versa. The corresponding LED-indicators will change colours from green (normal) to red (warning).

The LED's LINE 1 (rectifier) and LINE 2 (bypass) indicate the availability of the mains power supply.

The LED's INVERTER and BYPASS if green indicate which of the two is supplying power to the critical load. When the battery is supplying the load due to mains failure the LED-indicator BATTERY is flashing.

The LED-indicator ALARM is a visual indication of any internal or external alarm condition. At the same time an audible alarm will be activated.

INDICATOR	INDICATOR STATUS	MEANING
ALARM	OFF	No alarm condition
	RED	Alarm condition
LINE 1	GREEN	Mains rectifier available
	RED	Mains rectifier not available
LINE 2	GREEN	Mains bypass available
	RED	Mains bypass not OK or not available
	OFF	UPS is turned off
BY-PASS	GREEN	Load on bypass (Bypass-or Eco-Mode)
	OFF	Bypass not operating (switched-off)
INV	GREEN	Load on inverter
	RED	Inverter fault or load not transferable to inverter
	OFF	Inverter not operating (switched-off)
BATTERY	GREEN	Battery OK
	RED	Battery fault or battery is discharged
	Flashing GREEN	Battery in discharge or battery fuse open

## 4.2.3 Keys

The keys allow the user to operate the UPS to perform settings and adjustments, to start-up and shutdown the UPS, to monitor on the LCD display the voltages, currents, frequencies and other values.

KEYS	FUNCTION
ON/OFF ON/OFF	Serve to switch-on (press both keys simultaneously), or shutdown the UPS (press both keys simultaneously)
UP (↑)	Move upwards through the menu
DOWN (↓)	Move downwards through the menu.
RESET	Cancel the audible alarm. If the alarm condition was only transient the LED-indicator ALARM would also extinguish otherwise it will remain on (red).
ENTER	Confirms a chosen menu item.

## 4.2.4 ON/OFF Start-up and Shutdown Buttons

By pressing simultaneously both ON/OFF Buttons on the Control Panel the UPS may be switched on or shutdown. This is to prevent accidental start-up or shutdown of the UPS. The two main ON/OFF buttons are also used as a security LOAD-OFF-switch, making it possible to quickly disconnect the load from the UPS in emergency situations when a competent technician working on the UPS is in danger or if the UPS has some kind of anomaly.



**TO SHUT DOWN A UPS-MODULE YOU MUST PRESS BOTH ON/OFF-BUTTONS SIMULTANEOUSLY ON CONTROL PANEL!**



**ACTIVATION OF THE ON/OFF BUTTONS WHEN THE UPS IS NOT IN MAINTENANCE BYPASS MODE CAN INTERRUPT THE POWER SUPPLY TO THE LOAD.**

#### 4.2.5 Definition of a Single/Parallel-Module System (DIP Switch SW1-1)

By means of the DIP Switch SW1-1, which is located on the front of a Module, it is possible to determine whether the Module is a:

- Single UPS (Switch Position **LOW**). On the right hand corner of the LCD you can read **S** (for **Single**)
- Parallel UPS (Switch Position **HIGH**). On the right hand corner of the LCD of the respective UPS-Modules you can read **P01** (Master), **P02** (slave) and **P03** (Slave)

#### 4.2.6 Definition of a Single/ Multi-Cabinet Chain (DIP Switch SW2-9)

By means of the DIP Switch SW2-9, which is located on the front of a Cabinet, it is possible to determine the “position” of the Cabinets in Multi-Cabinet Chain:

- “**First**” in the Multi-Cabinet Chain
- “**Middle**” in the Multi-Cabinet Chain (there may be more than one)
- “**Last**” in the Multi-Cabinet Chain.

**NOTE:** If a Cabinet is a **Single Cabinet** then it is seen as the “**First**” and “**Last**” in an imaginary Chain. So the positions of the DIP Switch SW2-9 must be set as shown below:

SW2-9	Single Cabinet	First Cabinet	Middle Cabinet	Last Cabinet
1	ON	ON	OFF	ON
2	ON	ON	OFF	ON
3	ON	ON	OFF	ON
4	ON	ON	OFF	ON
5	ON	ON	OFF	ON
6	ON	ON	OFF	ON
7	ON	ON	OFF	ON
8	ON	ON	OFF	OFF
9	ON	OFF	OFF	ON

## 4.3 DESCRIPTION OF THE LCD

### 4.3.1 Status Screens

DESCRIPTION	LCD-DISPLAY
1 Load is protected by UPS power (load is supplied by inverter(Normal Operation))	<b>LOAD PROTECTED</b> P01
2 Load is not protected by UPS power it is supplied by mains power (load on bypass)	<b>LOAD NOT PROTECTED</b> P01
3 Load supply completely interrupted. UPS has been switched off by "ON/OFF" buttons	<b>LOAD OFF SUPPLY FAILURE</b> P01
4 The UPS/module is not supplying load anymore. The output switch is open	<b>LOAD DISCONNECTED PARALLEL SWITCH OPEN</b> P01

**NOTE:** On the right hand side of the LCD there is a 3 digit indicator defining the Module "Position" in the Multi-Module system.

S stands for Single Module. The system consists only of one Module.

P01 stands for Parallel Cabinet in a Multi-Module system and 01 stands for the first Cabinet (MASTER) in the Multi-Module system.

P02 stands for Parallel Cabinet in a Multi-Cabinet system and 02 stands for the second Cabinet (SLAVE) in the Multi-Cabinet system.

P03 stands for Parallel-Cabinet in a Multi- Cabinet system and 03 stands for the third Cabinet (SLAVE) in the Multi- Cabinet system.

The definition of the Cabinet "Position" is achieved in the Menu Service Set-Up.

### 4.3.2 Main Menu Screen

DESCRIPTION	LCD-DISPLAY
1 Logging Control. A log of the last 64 events is stored in the Power Management Display.	→ <b>EVENT LOG</b> MEASUREMENTS
2 In Menu Measurements: monitor voltages, power,frequencies, currents, autonomy etc.	→ <b>MEASUREMENTS</b> COMMANDS
3 The Command Menu enables to perform the commands "Load to inveter", Load to bypass, battery test.	→ <b>COMMANDS</b> UPS DATA
4 The UPS Data are the UPS personalized information "serial number"	→ <b>SET-UP DATA</b> SET-UP USER
5 Various settings can be performed by the user: Date/Time, automatic battery test, etc.	→ <b>SET-UP USER</b> SET-UP SERVICE
6 Various adjustments can be performed by the service staff	→ <b>SET-UP SERVICE</b> NO MORE MENU

### 4.3.3 Event Log Screen

DESCRIPTION	LCD-DISPLAY
1 Logging Control; a log of the last 64 events is stored in the Power Management Display.	<b>01</b> 05-10-00 14-38-59 <b>LOAD TO INV.</b>
2 Every stored event is identified with a sequential number and time stamp.	<b>02</b> 05-10-00 14-38-56 <b>LOAD TO BYP.</b>
3 All events and alarms are indicated with their date and time of appearance.	<b>03</b> 05-10-00 14-37-14 <b>LOAD OFF</b>

#### 4.3.4 Measurements Screen

DESCRIPTION	LCD-DISPLAY
1 Battery Runtime	<b>BATT. RUN TIME (MIN)</b> 00h 00m
2 UPS-Output Frequency	<b>OUTPUT FREQUENCY (HZ)</b> 50.00
3 Bypass Frequency.	<b>BYPASS FREQUENCY (HZ)</b> 50.00
4 Battery Voltage	<b>BATTERY VOLTAGE (V)</b> + 0.0 - 0.0
5 Battery Charger Current	<b>BATT. CHARGE CUR. (A)</b> + 0.0 - 0.0
6 Discharge Current.	<b>DISCHARGE CURRENT (A)</b> 00.00
7 Rectifier Voltage of all three phases	<b>RECTIFIER VOLTAGE (V)</b> 230 230 230
8 Bypass Voltage of all three phases	<b>BYPASS VOLTAGE (V)</b> 230 230 230
9 Output Voltage of all three phases	<b>OUTPUT VOLTAGE (V)</b> 230 230 230
10 Output Current of all three phases	<b>OUTPUT CURRENT (A)</b> 00.00 00.00 00.00
11 Active Output Power of all three phases	<b>ACTIVE POWER (KW)</b> 00.00 00.00 00.00
12 Reactive Output Power of all three phases	<b>REACTIVE POWER (kVAr)</b> 00.00 00.00 00.00
13 Apparent Output Power of all three phases	<b>APPARENT POWER (KVA)</b> 00.00 00.00 00.00
14 Output Power of all three phases	<b>OUTPUT POWER (%)</b> 00.00 00.00 00.00
15 Battery capacity	<b>BATT. CAPACITY (%)</b> 00.00

#### 4.3.5 Commands Screen

DESCRIPTION	LCD-DISPLAY
1 Transfer Load to inverter	→ <b>LOAD TO INVERTER</b> LOAD TO BYPASS
2 Transfer Load to bypass.	→ <b>LOAD TO BYPASS</b> PERFORM BATT.TEST
3 Battery Test	→ <b>PERFORM BATT.TEST</b> NO MORE COMMANDS

#### 4.3.6 UPS Data

DESCRIPTION	LCD-DISPLAY
1 These general UPS Data are installed at the manufacturing plant	<b>UPS SERIAL NUMBER</b> NW-nnnnn
2 Manufacturing date	<b>DATE OF MANUFACTURE</b> 15-01-2003
3 EPROM Version	<b>EPROM VERSION</b> V-000
4 Actual Date and Time	<b>DATE</b> <b>TIME</b> dd-mm-yyyy                hh:mm:ss

### 4.3.7 Set-Up User

#### DESCRIPTION

- 1 Set-up Language  
(not active yet)
- 2 Set-up Date and Time
- 3 Set-up battery test
- 4 Set-up operation with Gen-Set

#### LCD-DISPLAY

→ SET LANGUAGE SET DATE AND TIME
ENGLISH FRANCAIS POLISH
→ SET-UP DATE/TIME SET-UP BATT. TEST
DD-MM-YY HH-MM-SS
→ SET BATTERY TEST SET GENERATOR OP.
DAY OF MONTH (1-31)
HOUR OF DAY (1-24)
REPETITIVE (Y/N) YES/NO
→ SET GENERATOR OP. NO MORE SETTINGS
BATT.CHARGE LOCK YES/NO
BYPASS LOCK YES/NO

### 4.3.8 Set-Up Service

#### DESCRIPTION

- 1 This Menu is reserved for authorized service engineers. It is not to be used by End-Users
- 2 Type in password

#### LCD-DISPLAY

→ SET-UP SERVICE PASSWORD
→ PASSWORD.

Password is necessary to enter.


**NOTE:** Apart from the adjustment of voltages, frequencies, currents, power and autonomies in the SET-UP Service it is also possible to set and check the following parameters:

- UPS Rated Power
- Module configuration S, P01, P02,...
- Single (standard) or Dual Input feed
- f-converter, 50/60Hz and 60/50Hz
- Sync window (2-4%)

## 4.4 OPERATING MODES

### 4.4.1 Mode "ON LINE" (INVERTER MODE)

The ON-LINE-Mode is the UPS-Operating Mode in which the load is supplied through the RECTIFIER and INVERTER.



LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	OFF
INVERTER	Green
BATTERY	Green

Using the control panel (see figure 4.1), the UPS can easily be transferred to the ON-LINE-Mode. The ON-LINE-Mode provides the highest degree of protection, especially in the event of a mains disturbance or failure.


This operating mode is always recommended if the critical loads (computer systems) will not tolerate any interruption of the supply (not even the shortest).

In the unlikely event of an inverter fault or overload condition the UPS will transfer the load automatically and without interruption to the static bypass-mains supply (transfer time = 0).

### 4.4.2 Mode "OFF-LINE" (ECO- or BYPASS MODE)

In the "OFF-Line Mode", the load is supplied from the mains through the static bypass.

Using the control panel (see figure 4.1), the UPS may be easily transferred to "Bypass Mode".



LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Green

When the UPS is operating in "Bypass Mode", the efficiency of the system is higher. In the event of a mains failure the load will automatically be transferred from mains to inverter within 5 msec (this is valid for single and parallel systems). The battery charger remains active in the "Bypass-Mode".

The "Bypass-Mode", is recommended only if the loads can tolerate interruptions of 3-5 ms (transfer time from Bypass Mode to ON-LINE Mode).




**In order to provide the load with maximum protection NEWAVE always recommends that the load be supplied by the inverter (ON-LINE-Mode).**



### 4.4.3 "MAINTENANCE BYPASS" - Mode

The Maintenance Bypass Mode is performed by means of the IA1 BYPASS SWITCH on the front of the UPS:

POSITION OF SWITCH	EFFECT
ON	Bypass-Switch Closed (Load supplied directly from mains) LCD-indication: "MANUAL BYP IS CLOSED" LED Indicators will indicate as shown in table below.
OFF	Bypass-Switch Open – Normal operating condition (Load supplied by inverter) LCD-indication "MANUAL BYP IS OPEN" LED Indicators will indicate as shown in table below.



LED Indicator	ON	OFF
LINE 1	Green	Green
LINE 2	Green	Green
BYPASS	Green	OFF
INVERTER	RED	Green
BATTERY	Green	Green



**Before transferring the load to Maintenance Bypass (IA1) always make sure all the UPS-modules are in the "Bypass-Mode" or "ECO-Mode".**



*IF THE UPS IS OPERATING IN THE MAINTENANCE BYPASS MODE THROUGH THE BYPASS SWITCH THE LOAD WILL NOT BE PROTECTED IN THE EVENT OF A MAINS FAILURE. IT IS THEREFORE STRONGLY RECOMMENDED TO SWITCH OVER TO THE ON-LINE MODE (INV. ON) OR BYPASS MODE (OFF-LINE MODE) AS SOON AS POSSIBLE.*

### 4.4.4 Parallel Isolator (IA2)

Every UPS-unit (module) is provided with an output parallel isolator (IA2) which, when opened isolates the corresponding unit (module) from the PARALLEL BUS and from the LOAD. Once IA2 is open there is no power coming from its inverter.

In redundant parallel configurations it is used to isolate a unit from the parallel system without the need of transferring the load to bypass.

POSITION	EFFECT
ON	Normal Operation (Load supplied by UPS)
OFF	UPS-Module isolated from Parallel Bus for maintenance or module replacement (UPS-Module not supplying load)

## 4.5 START-UP PROCEDURE



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

### Situation of UPS-System before switching it on:

1. Make sure the fuses for the supply of UPS-System in the Input Distribution Board on site are open.
2. Make sure all the input and output cabling has been performed correctly and check the input phase rotation.
3. Verify that all Parallel Isolator Switches IA2-1 and IA2-2 are open (Position OFF).
4. Verify that the Maintenance Switch IA1 is open and in Position OFF.
5. Make sure all the battery fuses F4 and F5 and those in external battery cabinets are open.
6. Bypass fuses F2 on all UPS-modules are inserted.
7. Check the DIP Switch SW1-1 position, of all Modules. If the cabinet has only one Module and it is operating as a Single UPS (Switch in Position LOW). If it is a Parallel UPS (Switch in Position HIGH).
8. Check the Position of the DIP Switches SW2-9. This is a **Single- Cabinet** Configuration, and the DIP Switches SW2-9 must be set according to positions shown in Table of Paragraph 4.2.6

### **Start up procedure of Gemini Line:**

1. Insert fuses for the supply of UPS-System in the Input Distribution
  - The LED-indicators LINE 1 and battery on UPS-Module is lit – green
  - On LCD-Display “LOAD OFF, SUPPLY FAILURE” will appear.
2. UPS-Module 1:  
Press both “ON/OFF” Main Buttons to switch on UPS.  
LCD panel must display: “LOAD DISCONNECTED PARALLEL SWITCH OPEN” and the LED-indicator will appear as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Flashing Green

3. Check Command: LOAD TO INVERTER  
LED indicator will appear as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	OFF
INVERTER	Green
BATTERY	Flashing Green

4. Scroll through the menu measurement and check their correctness
5. Module 2: Repeat same procedure as for Module 1:Steps **2)-4)**.
6. Check battery polarity and voltage.
7. If the battery polarity and voltage is correct insert F4 and F5 and external battery fuses (breakers).

8. Testing of Parallel Functions  
(The load fuses in output Distribution Board are still open i.e. the loads are disconnected!).  
All two UPS-Modules are on INVETER MODE
9. Press simultaneously both ON/OFF Buttons on both modules to turn them OFF. On LCD "LOAD DISCONNECTED, SUPPLY FAILURE" will appear.
10. Close Parallel Isolator IA2-1 (position ON) of Module 1, on LCD: "PARALLEL SW CLOSED" will appear.  
Close Parallel Isolator IA2-2 (position ON) of Module 2, on LCD: "PARALLEL SW CLOSED" will appear.
11. Press simultaneously both ON/OFF Buttons on both modules to turn them ON. On output Terminal Block there is now UPS power and on all two LCD's: "LOAD PROTECTED" will appear.
12. Load transfer to Maintenance Bypass  
Go to Menu COMMANDS and choose command "LOAD TO BYPASS" and transfer the load to mains on control panel of any one of the three UPS-modules.  
Close Maintenance Bypass Switch IA1 (position ON)  
On LCD: "MANUAL BYP IS CLOSED" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

13. Connect Load to the UPS Output  
Insert fuses in output Distribution Board  
Verify on control Panel that the load is on bypass
14. Open Maintenance Bypass Switch IA1  
On LCD: "MANUAL BYP IS OPEN" will appear followed by "LOAD NOT PROTECTED"
15. Check on LCD the Output Powers, Voltages Currents and Frequencies.
16. Load transfer to Inverter  
Go to Menu COMMANDS and choose command "LOAD TO INVERTER" and transfer the load to inverter on control panel of any one of the two UPS-modules.  
On all three LCD's: "LOAD PROTECTED" will appear followed by
17. Check the output Voltages and Currents once again.

**THE LOAD IS NOW PROTECTED BY THE UPS CONCEPTPOWER**

## 4.6 SHUTDOWN PROCEDURE



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

The Conceptpower™ UPS may be shutdown completely if the load does not need input power for an extended period of time.

It may be switched to Maintenance Bypass Mode for service or maintenance purposes, or transferred to the OFF-LINE Mode if the load does not need the highest degree of protection.

The load may be disconnected by means of the two ON/OFF (LOAD-OFF) buttons for security reasons.

### **Complete Shutdown procedure of Gemini-Line:**



**The UPS may be shut down completely if the loads do not need any power supply. Therefore the following steps are to be performed only after the load has been disconnected and does not need any power supply.**

**PRESSING ON ALL MODULES BOTH ON/OFF BUTTONS SIMULTANEOUSLY DURING NORMAL OPERATION WILL SWITCH OFF THE UPS OUTPUT AND NO LONGER SUPPLY POWER TO THE LOAD.**

1. Verify that the loads are shutdown and that there is no need for power supply to the load.
2. If the loads are all disconnected, press simultaneously both ON/OFF-Buttons on UPS-Control Panel on all two Control Panels.  
On the LCD: "LOAD OFF, SUPPLY FAILURE" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Green

3. Open all two Parallel Isolator Switches IA2-1 and IA2-2.
4. Open battery fuses F4 and F5 or those in external battery cabinets or racks.
5. Open the mains fuses/breaker in the building distribution panel.

**AFTER SWITCHING OFF A UPS UNIT MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED AND WAIT AT LEAST 10 MINUTES**

**THE UPS CONCEPTPOWER IS NOW VOLTAGE FREE.**

## 4.7 LOAD TRANSFER: FROM INVERTER OPERATION TO MAINTENANCE BYPASS

If it is necessary to perform service or maintenance on the UPS it is possible to transfer the UPS to MAINTENANCE BYPASS.



**BEFORE YOU SWITCH THE MAINTENANCE BYPASS TO POSITION «ON», MAKE SURE THAT THE LOAD HAS BEEN TRANSFERRED TO MAINS SUPPLY (OFF-LINE MODE)**



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

### Situation of UPS-System before starting the Transfer Procedure to Maintenance Bypass:

The load is protected by **Conceptpower™** UPS running in normal operation. (The UPS-Module is operating on inverter).

- Using LDC panel, select the COMMANDS menu and choose command "LOAD TO BYPASS" and transfer the load to mains on control panel of any one of the two UPS-modules  
On LCD panel "LOAD NOT PROTECTED" will appear.

- Close Maintenance Bypass Switch IA1 (position ON).  
On LCD: "MANUAL BYP IS CLOSED" will appear and the mimic panel will show:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

- Press simultaneously the two ON/OFF buttons on the UPS-control panel (PMD) on all two control panels.  
On the LCD's message "LOAD OFF, SUPPLY FAILURE" will appear and the mimic panel will show:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing Green

- Open Parallel Isolators IA2-1 and IA2-2.
- Open battery fuses F4 and F5 or those in the external battery cabinets or racks.

**THE LOAD IS NOW SUPPLIED BY MAINS AND IS NOT PROTECTED**

## 4.8 LOAD TRANSFER: FROM MAINTENANCE BYPASS TO INVERTER OPERATIONS

This procedure describes the sequence of operations to be done in order to restart the UPS and restore ON-LINE mode (Load on Inverter).



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

### **Situation of UPS-System before starting the Transfer Procedure to ON-LINE mode:**

The load is supplied directly by Input Mains power and the UPS is OFF.

1. Close battery fuses F4 and F5 or those in the external battery cabinets or racks.
2. On the LCD's: "LOAD OFF, SUPPLY FAILURE" will appear and the mimic panel will show:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing/Green

3. Close Parallel Isolators IA2-1 and IA2-2 and check message "PARALLEL SW CLOSED" on LCD of each module.
4. Press simultaneously the two ON/OFF buttons on the UPS-control panel (PMD) on all three control panels.  
Unit will start-up and after about 60 seconds the mimic panel will show:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

5. Make sure that the bypass LED is green, then open the Maintenance Bypass Switch IA1 (position OFF).
6. Using LDC panel, select the COMMANDS menu and choose command "LOAD TO INVERTER". This will transfer the LOAD to Inverter on the complete system (all units). On LCD panel "LOAD PROTECTED" will appear.

**THE LOAD IS NOW SUPPLIED BY INVERTER POWER AND IS PROTECTED**

# 5 Replacement of UPS-Module

## 5.1 REPLACEMENT OF UPS-MODULE IN SINGLE-MODULE SYSTEMS



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

*BEFORE REMOVING A UPS-MODULE MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED FOR AT LEAST 2 MINUTES.*

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO

### 5.1.1 How to Extract a UPS-Module in SINGLE MODULE Systems

If your **Conceptpower™ Gemini-Line** consists of only one single UPS-Module then perform following steps to extract the module:

1. Reset the Alarm on faulty Module. The audible noise will stop.  
If the Alarm condition persists (the LED-Indicator ALARM will remain red) it means that there is a fault in the UPS-Module.
2. If the load is supplied by the mains in Bypass-Mode (Eco-Mode) the Maintenance Bypass (IA1) may be closed by turning it to position "ON".  
**NOTE:** If the load is on inverter, transfer load to bypass by means of the command "LOAD TO BYPASS" in submenu COMMANDS. On LCD: "LOAD NOT PROTECTED" will appear.
3. Close Maintenance Bypass Switch IA1 (position ON)  
On LCD: "MANUAL BYP IS CLOSED" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

#### **The load is now directly supplied by mains and is not protected**

4. Open the Parallel Isolator Switch IA2 (switch to position "OFF") of the faulty UPS-Module. The UPS-Module is now disconnected from output;
5. Press both ON/OFF Buttons on UPS-Module simultaneously;
6. Open corresponding battery fuses
7. Disconnect cables from connectors JD1, JD2, JD7, JD4 and SNMP network cable.
8. Unscrew the four screws on the front side of the module that are fixing it to the UPS-frame;
9. Pull Module only partly horizontally by means of the 2 black handles until the rear connectors are disconnected.



**ATTENTION:** BEFORE DRAWING THE UPS-MODULE COMPLETELY OUT, WAIT 2 MINUTES UNTIL THE INTERNAL DC-CAPACITORS ARE DISCHARGED.

10. Draw UPS-Module by pulling it out horizontally:  
**NOTE:** Two persons are needed to pull out the module from the UPS-Frame. The weight of a 30 kVA-module is 55kg (the weight of 10 kVA-module is 52kg)
11. Insert new UPS-Module or cover the opening (UPS-Module Compartment) with appropriate protection cover immediately and fix with four screws.



WHILE THE UPS IS OPERATING IN THE MAINTENANCE BYPASS-MODE THE LOAD IS NOT PROTECTED AND IN THE EVENT OF A MAINS FAILURE THE LOAD SUPPLY WILL BE INTERRUPTED AND THE LOAD WILL CRASH.

### 5.1.2 How to Fit Back a UPS-Module in SINGLE-MODULE-Systems



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO.

If your **Conceptpower™ Gemini-Line** consists of only one single UPS-Module then perform following steps to fit back the new module:

1. Remove UPS-Module compartment protection cover by unscrewing four screws on the front.
2. Slide two thirds of UPS-Module into dedicated UPS-compartment (make sure not to plug the UPS-Module into the rear connector).  
 Connect Control Panel cable to connector JD7.  
 Push UPS-module to its final position and push strongly to assure good contact on the rear plugs.  
**NOTE:** Two persons are needed to carry and push the module to its final position in UPS-frame. The weight of 30 kVA-Module is 55kg (the weight of 10 kVA-module is 52kg)
3. Tighten the four screws on the front of module;
4. Reconnect cables on connectors JD1, JD2, JD4 and SNMP network cable.
5. Check if the LED LINE1 and battery is green. If yes, mains voltage is OK;  
 On the LCD: "LOAD OFF, SUPPLY FAILURE" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing Green

6. Make sure the bypass fuses F2 are inserted (front of Module);
7. Close internal and external battery fuses/breaker(if available);
8. Press simultaneously both "ON/OFF" Buttons to start-up UPS.  
 LCD panel must display: "LOAD DISCONNECTED PARALLEL SWITCH OPEN" and the LED-indicator will appear as shown below:



LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	OFF
INVERTER	Green
BATTERY	Green

9. Transfer load to mains and inverter for testing using submenu COMMANDS;
10. Transfer Load to Bypass-Mode by means of COMMAND "LOAD TO BYPASS"
11. Verify the status (Load on Bypass, Eco-Mode) by checking the LED-indicators as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Green

12. Close Parallel Isolator (IA2);
13. Open Maintenance Bypass (IA1) by turning it to position "OFF". The load is now supplied by the static bypass.
14. Transfer load to Inverter-Mode by means of COMMAND "LOAD TO INVERTER". On LCD: "LOAD PROTECTED" will appear.

**THE LOAD IS NOW PROTECTED BY THE UPS CONCEPTPOWER**

## 5.2 REPLACEMENT OF UPS-MODULE IN REDUNDANT MULTI-MODULE SYSTEM



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

BEFORE REMOVING A UPS-MODULE MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED FOR AT LEAST 2 MINUTES.

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO.

### 5.2.1 How to Extract a Module in Redundant Multi-Module System

If in a redundant parallel system a UPS-module is faulty, the load will continue to be protected by the operating modules On-Line-Mode (Inverter-Mode) and the faulty Module may be replaced without having to transfer the load to bypass!

To extract the faulty module from the UPS-Frame in a Redundant Multi- Module Configuration proceed as follows:

1. Identify the faulty Module with the Alarm condition and RESET the Alarm. The audible noise will stop. If the Alarm conditions persists (the LED-Indicator ALARM is red) there is a fault in the UPS-Module.
2. Verify that load is supplied by inverter of the other modules running by checking the LCD indication LOAD PROTECTED. Verify load measures on the operating modules.
3. Turn the faulty module OFF by pressing simultaneously both "ON/OFF" buttons. On the LCD: "LOAD OFF, SUPPLY FAILURE" should appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing Green

4. Open the corresponding Parallel Isolator Switch IA2. LCD panel must show: PARALLEL SW OPEN.
5. Remove the 4 fixation screws and slide out the UPS-Module (10cm) paying particular attention to the cable connected to JD4. This operation will disconnect module by the power connection located on the back of the cabin.
6. With the module OFF, disconnect any connected cable as JD7, JD1 and JD2, and any network cable from the SNMP adapter.
7. Pull the module out.

**ATTENTION: BEFORE DRAWING THE UPS-MODULE COMPLETELY OUT, WAIT 2 MINUTES UNTIL THE INTERNAL DC-CAPACITORS ARE DISCHARGED.**

**NOTE:** Two persons are needed to carry and push the module to its final position in UPS-frame. The weight of 30 kVA-Module is 55kg (the weight of 10 kVA-module is 52kg).

8. Screw the protection cover on the empty area left empty by the module with the 4 fixation screws.

### 5.2.2 How to insert a module in a Redundant Multi Module System

In a Redundant Parallel system one module can be re-introduced on its original location without affecting normal system operation. Load will be protected by the other modules running ON-LINE.

Module must be previously set according to system personalization. Please make sure with your nearest service centre for correct settings.

1. Remove the protection cover by unscrewing the 4 fixation screws on the front.
2. Lift the module to its destination position. See previous note concerning weights.
3. Slide two thirds of UPS module into dedicated compartment (make sure not to plug the UPS-Module into the rear connector). Connect Control Panel cable to connector JD7. Push UPS-module to its final position and push strongly to assure good contact on the rear plugs. Tighten the four screws on the front of module;
4. Reconnect cables on connectors JD1, JD2, JD4 and SNMP network cable;
5. Check if LED LINE1 and battery is green. If yes, mains voltage is OK; On the LCD: "LOAD OFF, SUPPLY FAILURE" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing Green

6. Make sure the bypass fuse F2 is inserted (front of Module);
7. Close battery fuses/breaker of the new Module
8. Press both "ON/OFF" Buttons simultaneously to start-up UPS.
9. Wait 60 seconds, LCD panel must display: "LOAD DISCONNECTED PARALLEL SWITCH OPEN" and the LED-indicator will appear as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Flashing/Green

10. Transfer load to Inverter-Mode by means of COMMAND "LOAD TO INVERTER" of the control panel. LED-indicator will appear as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	OFF
INVERTER	Green
BATTERY	Green

11. Stop the module by pressing simultaneously both "ON/OFF" buttons.
12. Close the Parallel Isolator Switch IA2 corresponding to the module. LCD panel must show the message PARALLEL SW CLOSED.
13. Press simultaneously both "ON/OFF" buttons. Module will restart automatically connecting load to inverter and run in parallel with other ON LINE modules. LCD panel must show LOAD PROTECTED indication.

**THE LOAD IS NOW PROTECTED BY THE UPS CONCEPTPOWER**

## 5.3 REPLACEMENT OF A MODULE IN CAPACITY MULTI-MODULE SYSTEM



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

*BEFORE REMOVING A UPS-MODULE MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED FOR AT LEAST 2 MINUTES.*

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO.

### 5.3.1 How to Extract a Module in a Capacity Multi-Module System

If in capacity parallel system a UPS-Module experiences a fault and there is not enough capacity left to protect the load by the remaining operating UPS-Modules, the load will automatically be transferred to bypass (Bypass-Mode or Eco-Mode) and will continue to be supplied by the mains power supply.

To extract the faulty module from the UPS-Frame in a Capacity Multi-Module System proceed as follows:

1. Identify the faulty Module with the Alarm condition and RESET the Alarm. The audible noise will stop. If the Alarm conditions persists (the LED-Indicator ALARM is red) there is a fault in the UPS-Module.
2. Verify that the load is on Bypass and is supplied by the mains power (Bypass-Mode or Eco-Mode) on all three UPS-Modules; in the majority of the events the LED-indicators on Control Panel of the Faulty Module will show:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

3. Whereas the LED-indicators on the Control Panels of the other two Operating Modules will show

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Green

4. Close Maintenance Bypass Switch IA1 (position ON)

5. On LCD: “MANUAL BYP IS CLOSED” will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	RED
BATTERY	Green

**The load is now directly supplied by mains and is not protected**

6. Open the Parallel Isolator Switch IA2 (switch to position “OFF”) of UPS-module to be replaced. The UPS-module is now disconnected from the output;
7. Press both ON/OFF Buttons on UPS-Module simultaneously;
8. Open corresponding battery fuses;
9. Remove the 4 fixation screws and slide out the UPS-Module (10cm) paying particular attention to the cable connected to JD4. This operation will disconnect module by the power connection located on the back of the cabin.
10. Disconnect cables from connectors JD1, JD2, JD7, JD4 and SNMP network cable;



**ATTENTION: BEFORE DRAWING THE UPS-MODULE COMPLETELY OUT, WAIT 2 MINUTES UNTIL THE INTERNAL DC-CAPACITORS ARE DISCHARGED.**

11. Draw UPS-Module by pulling it out horizontally:  
**NOTE:** Two persons are needed to pull out the module from the UPS-Frame. The weight of a 30 kVA-module is 55kg (10 kVA-module 52kg).
12. Insert new UPS-Module or cover the opening (UPS-Module Compartment) with appropriate protection cover immediately and fix with four screws.



**WHILE THE UPS IS OPERATING IN THE MAINTENANCE BYPASS-MODE THE LOAD IS NOT PROTECTED AND IN THE EVENT OF A MAINS FAILURE THE LOAD SUPPLY WILL BE INTERRUPTED AND THE LOAD WILL CRASH.**

**5.3.2 How to Fit Back a Module in a Capacity Multi-Module System**

To replace a Faulty Module in a **Capacity Multi-Module System** perform following steps:

1. Remove UPS-Module compartment protection cover by unscrewing four screws on the front.
2. Slide two thirds of UPS-Module into dedicated UPS-compartment (make sure not to plug the UPS-Module into the rear connector).  
 Connect Control Panel cable to connector JD7.  
 Push UPS-module to its final position and push strongly to assure good contact on the rear plugs.  
**NOTE:** Two persons are needed to carry and push the module to its final position in UPS-frame. The weight of 30 kVA-Module is 55kg (the weight of 10 kVA-module is 52kg)
3. Tighten the four screws on the front of module;
4. Reconnect cables on connectors JD1, JD2, JD4 and SNMP network cable;

5. Check if LED LINE1 and battery are green.  
On the LCD: "LOAD OFF, SUPPLY FAILURE" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	OFF
BYPASS	OFF
INVERTER	OFF
BATTERY	Flashing Green

6. Make sure the bypass fuse F2 is inserted (front of Module);
7. Close corresponding external battery fuses/breaker for the new Module;
8. Press both "ON/OFF" Buttons simultaneously to start-up UPS.  
LCD panel must display: "LOAD DISCONNECTED PARALLEL SWITCH OPEN" and the LED-indicator will appear as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Green

9. Transfer load to mains and inverter for testing using submenu COMMANDS
10. Transfer Load to Bypass-Mode by means of COMMAND "LOAD TO BYPASS"
11. Verify the status LOAD ON BYPASS

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	Green
INVERTER	OFF
BATTERY	Green

12. Verify that the remaining UPS-Modules are also on Bypass;
13. If all two UPS-Modules are on Bypass, Close Parallel Isolator Switch IA2 of New Module (position ON); on LCD should appear "PARALLEL SW IS CLOSED".
14. Open Maintenance Bypass (IA1) by turning it to position "OFF". The load is now supplied by the static bypass of all three Modules. Check LED-indicators on control panels.
15. Transfer load to Inverter-Mode by means of COMMAND "LOAD TO INVERTER" on any one of three control panels. On LCD: "LOAD PROTECTED" will appear and the LED-indicator will indicate as shown below:

LED Indicator	Colour
LINE 1	Green
LINE 2	Green
BYPASS	OFF
INVERTER	Green
BATTERY	Green

**THE LOAD IS NOW PROTECTED BY THE UPS CONCEPTPOWER**

# 6 Multi-Cabinet Configuration

## 6.1 CONCEPT OF MULTI-CABINET CONFIGURATION

The Gemini-Line UPS-Cabinets may be paralleled for power capacity Classic or for redundancy indefinitely. Every standard **Conceptpower™** UPS is provided with the parallel option and therefore no time-consuming upgrading is necessary on site.




Fig. 6.1. UPS **Conceptpower™** Gemini-Line Multi-Cabinet Chain.

The Multi-Cabinet Chain is based on a decentralised bypass architecture i.e. every UPS is provided with its own static bypass. In a parallel system there is always one Master Module and the other Modules are slaves. If at any time the master is faulty the next UPS (former slave) will immediately take over the master function and the former master will switch off.

Every UPS unit in a parallel configuration is provided with a proper output parallel Isolator (IA2) which, when opened isolates the corresponding unit from the parallel system. Once the parallel isolator (IA2) of a unit is open that unit (module) is isolated from the rest of the parallel system and therefore does not provide power to the output.

For example if you perform the command “LOAD TO BYPASS” on any unit, all the units will transfer the load simultaneously to mains and if you perform the command “LOAD TO INVERTER” on any unit all the UPS’s will simultaneously transfer the load to the inverters.

The **Conceptpower™** is paralleled for redundancy (highest availability) or for power parallel systems.

**IMPORTANT:** The BYPASS MODE (ECO-MODE) function of a parallel systems is the same as in single units of **Conceptpower™**. If in a parallel UPS system the load is transferred to the BYPASS (load on mains) and if the mains fails, the UPS’s will all be automatically transferred to inverter within 5msec.



**In order to provide the load with maximum protection NEWAVE always recommends that the load be supplied by the inverter (ON-LINE-Mode).**

## 6.2 INSTALLATION INSTRUCTIONS

### 6.2.1 Introduction




---

#### **ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

*BEFORE REMOVING A UPS-MODULE MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED FOR AT LEAST 2 MINUTES.*

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER.

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO.

---



#### **DO NOT ATTEMPT TO COMMISSION A PARALLEL CABINETS SYSTEM WITHOUT CAREFULLY READING THIS USER MANUAL (SEE ALSO CHAPTERS 3 AND 4**

NOTE: IN ORDER TO ACHIEVE EQUAL LOAD SHARING BETWEEN THE UPS-CABINETS, THE INPUT CABLE LENGTHS FROM THE INPUT DISTRIBUTION BOARD TO THE UPS AND FROM THE OUTPUT CABLE TO THE OUTPUT DISTRIBUTION BOARD SHOULD BE THE SAME RESPECTIVELY.

WHEN CABLING THE UPS'S BEWARE TO CONNECT INPUT AND OUTPUT WIRES TO THE CORRESPONDING TERMINALS, RESPECTING THE SAME PHASE SEQUENCE ON ALL UPS CABINETS. EXAMPLE: PHASE1 UPS1 = PHASE1 UPS2 = ..... = PHASE1 UPS n




---

#### **WHEN CABLING THE UPS's MAKE SURE THAT THE UPS's ARE COMPLETELY VOLTAGE FREE. CHECK THAT THE MAINTENANCE BYPASSES (IA1) AND ALL PARALLEL ISOLATOR (IA2) ARE OPEN ("OFF") ON ALL CABINETS.**

### 6.2.2 Paralleling of UPS-Cabinets

#### 6.2.2.1 Connection of Parallel Communication Cables (BUS-lines)

For the correct performance of different parallel functions and operations the parallel units communicate continuously between each other. This is achieved by means of the so-called communication BUS-Lines.

After terminating the input and output cabling of each single UPS, it is necessary to connect the units together to form the parallel system. For this purpose a communication BUS line is connected sequentially between the units. Connect communication BUS lines according to Figure 6.2.

---

#### **NOTE: CONNECT THE BUS CABLES ONLY WITH SWITCHED OFF UPS AND OPENED PARALLEL ISOLATORS IA2. RESPECT THE FOLLOWING CONNECTION SEQUENCES.**

1. Fit the Parallel Adapter over the Connector JD8 on all UPS-cabinets
2. Set DIP Switch SW2-2 on each Parallel Adapter depending on the UPS Cabinet in the parallel cabinet configuration (see page 45)
3. Connect PORT JD6 on Parallel Adapter of UPS-Cabinet 1 and PORT JD5 of Parallel Adapter of UPS-Cabinet 2 with the corresponding BUS-Cable;
4. Connect PORT JD6 on Parallel Adapter of UPS-Cabinet 2 and PORT JD5 of UPS-Cabinet 3 with the corresponding BUS-Cable
5. Continue in the same manner for the remaining UPS-Cabinets.







Figure 6.2. Connection of the Bus Lines when paralleling UPS-Cabinets by means of Parallel Adapters.

### 6.2.2.2 Parallel Adapter and DIP-Switch SW2-2

If the UPS-CABINETS are paralleled the Parallel Adapter will be placed on the Connector JD8 on the distribution panel and the communications cables between the cabinets will be connected through the connectors JD5 and JD6, as we are doing now.

NOTE: set the Switch SW2-2 correctly according to the corresponding cabinet configuration.



### 6.2.3 DIP-Switch SW1-1 and SW2-9 Settings

Before starting up the parallel system it is necessary to set the DIP Switches SW1-1 and SW2-9 to their correct positions.

#### DIP Switch SW1-1

The DIP Switch SW1-1 is located on every UPS-Module and serves to define if the UPS-Module is a single or parallel Module.

SW1-1 has two positions:

**HIGH = Parallel** (the Module is in a parallel system)

**LOW = Single** (the Module is a single UPS)

In the case of parallel cabinet configurations the SW1-1 on all Modules is always in position HIGH = Parallel.

SW1-1	Module Type
HIGH	Parallel Module
LOW	Single Module

#### DIP Switch SW2-9

The DIP Switch SW2-9 is located on every Cabinet (Gemini-Line) and not on Modules. With this switch it is possible to determine the “**position of an Gemini-Line-Cabinet**” in a Multi-Cabinet Chain. Define each Gemini-Line-Cabinet in a Multi-Cabinet Chain as:

1. The “**First**”,
2. The “**Middle**” (there may be more than one) and
3. The “**Last**”

Cabinet in the Multi-Cabinet Chain by setting the DIP Switch SW2-9 on each cabinet according to the Table below:

SW1-9	Single Cabinet	First Cabinet	Middle Cabinet	Last Cabinet
1	ON	ON	OFF	ON
2	ON	ON	OFF	ON
3	ON	ON	OFF	ON
4	ON	ON	OFF	ON
5	ON	ON	OFF	ON
6	ON	ON	OFF	ON
7	ON	ON	OFF	ON
8	ON	ON	OFF	OFF
9	ON	OFF	OFF	ON

After having set the SW1-1 on all UPS-Modules and SW2-9 on all the Gemini-Line-Cabinets correctly the UPS's may be commissioned

#### 6.2.4 ON/OFF – Main Buttons

The ON/OFF-Buttons serve to shutdown the UPS-system for service or maintenance or for emergency reasons.



**IF BOTH ON/OFF-BUTTONS ARE PRESSED ON THE UPS-Module IN A MULTI-Module SYSTEM ONLY THAT PARTICULAR UPS-Module WILL SHUTDOWN. TO SHUTDOWN THE COMPLETE SYSTEM PRESS BOTH ON/OFF-BUTTONS ON EVERY UPS-MODULE OF A MULTI-MODULE SYSTEM.**

#### 6.2.5 Parallel Isolator (IA2)

Every UPS-unit is provided with a parallel isolator IA2. The parallel isolator is an important element of the UPS-unit, that allows the isolation of a unit from the parallel system without the need to transfer the load to bypass.



**IA2 OPEN: THE CORRESPONDING UPS-MODULE IS ISOLATED FROM THE OUTPUT. THERE IS NO COMMUNICATION BETWEEN THE ISOLATED UNIT AND THE REST OF THE PARALLEL SYSTEM. THE ISOLATED UPS-MODULE MAY BE REPLACED WITHOUT COMPROMISING THE REST OF THE SYSTEM.**

**IA2 CLOSED: THE CORRESPONDING UPS IS BEING ADDED TO THE REST OF THE PARALLEL SYSTEM.**

**IMPORTANT: BEFORE CLOSING THE IA2 OF A UPS-MODULE BE SURE THAT THE STATUS OF THAT UPS-MODULE IS THE SAME AS OF THE REST OF THE OPERATING UPS-MODULE WITH CLOSED IA2. EXAMPLE: IF ALL UPS's WITH CLOSED IA2 ARE ON INVERTER, MAKE SURE THAT THE UNIT ON WHICH ISOLATOR IA2 IS BEING CLOSED IS ALSO ON INVERTER.**

#### 6.2.6 Maintenance Bypass (IA1)

There are two types of Parallel System Configurations: redundant and capacity parallel systems (see Chapter 5).

##### 6.2.6.1 Redundant Parallel Configuration

In a redundant parallel system a UPS-module may easily be isolated from the parallel system by opening the respective isolator (IA2). It is now possible to operate or shut down this unit without influencing the rest of the parallel system. The rest of the parallel system will continue to protect the load. The isolated UPS-Module may be replaced without the need of transferring the load to bypass by means of the Maintenance Bypass (IA1).

##### 6.2.6.2 Capacity Parallel Configuration

In the event of a fault in one of the UPS-Modules in a capacity parallel system the load will automatically be transferred to static bypass (mains). In order to replace the faulty module the load must be transferred to mains by means of Maintenance Bypass (IA1).

### 6.2.7 ECO-MODE (BYPASS MODE) in Parallel Systems

The Eco-Mode function in a Parallel System is the same as in Single Systems. If in a **Conceptpower™** Parallel System the load is supplied by the mains(load on mains) and in the event of mains failure, **all UPS's will automatically transfer the load back to the inverters with 5msec.**



*In order to provide the load with maximum protection NEWAVE always recommends that the load be supplied by the inverter (ON-LINE-Mode).*

## 6.3 COMMISSIONING OF MULTI-CABINET CONFIGURATION



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL TRAINED PERSONNEL.**

BY OPENING OR REMOVING THE UPS-MODULES AND MODULE COVERS YOU RUN RISK OF EXPOSURE TO DANGEROUS VOLTAGES!

BEFORE REMOVING A UPS-MODULE MAKE SURE THE INTERNAL DC-CAPACITORS HAVE BEEN DISCHARGED FOR AT LEAST 2 MINUTES.

DO NOT EVER LEAVE THE UPS-MODULE COMPARTMENT WITHOUT AN APPROPRIATE PROTECTION COVER.

NEWAVE WILL NOT TAKE RESPONSIBILITY OR BE LIABLE FOR PERSONNEL INJURIES OR MATERIAL DAMAGES CAUSED BY IMPROPER MANIPULATION OF THE UPS, OR BY INCORRECT CABLING. THE PROPER INSTALLATION AND USAGE INSTRUCTIONS OF THE UPS ARE DESCRIBED WITHIN THIS MANUAL AND MUST BE STRICTLY ADHERED TO.

### 6.3.1 Start-up of a Multi-Cabinet Configuration

Before starting up a Multi-Cabinet Configuration verify that:

1. All the input and output cabling has been performed correctly according to Chapter 3 of this User Manual;
2. The parallel communication cables have been connected correctly according to Paragraph 6.2.2 of Chapter 6;
3. All the DIP Switches for the Modules and Gemini-Line Cabinets been set correctly according to Paragraph 6.2.3 of Chapter 6;
4. All the external battery cabinets/racks have been connected correctly;

The start-up of a Multi-Cabinet Configuration may be performed in analogy to the start-up procedures for a single Gemini-Line Cabinet described in Paragraph 4.5 of Chapter 4.

### 6.3.2 Shutdown of Multi-Cabinet Configuration

Before shutting-down of a Multi-Cabinet Configuration make sure that the loads do need power protection and that they are disconnected.



**The UPS may be shut down completely if the loads do not need any power supply. Therefore the steps in this Paragraph are to be performed only after the load has been disconnected and does not need any power supply.**

To perform a complete shutdown of a Multi-Cabinet Configuration proceed in analogy to the shutdown procedures described in Paragraph 4.6 of Chapter 4.

### 6.3.3 Replacement of a Faulty UPS-Module in a Multi-Cabinet Configuration

If in a Multi-Cabinet Configuration a UPS-Module fails proceed in replacing the UPS-Module in analogy with the replacement procedures described in Chapter 5 of this User Manual.

# 7 Maintenance

## 7.1 INTRODUCTION



**ALL THE OPERATIONS IN THIS SECTION MUST BE PERFORMED BY AUTHORISED ELECTRICIANS OR BY QUALIFIED INTERNAL PERSONNEL.**

To ensure an optimum operation of the **Conceptpower™** and a continuous and efficient protection of the connected load it is recommended to check the batteries every 6 months, depending on the ambience temperature.

## 7.2 USER RESPONSIBILITIES

There are no user serviceable parts contained within the UPS so the maintenance responsibilities of the user are minimal. To maximise the useful working life and reliability of the UPS and its batteries, the environment in which the UPS operates should be kept cool, dry, dust and vibration free. The batteries should be hold fully charged.

## 7.3 ROUTINE MAINTENANCE

The UPS is designed to receive regular preventative maintenance inspections. These preventative maintenance inspections are essential to ensure that both the useful working life and the reliability of the UPS are maximised. When the UPS is commissioned, the commissioning field service engineer will attach a service record book to the front of the UPS and this will be used to record the full service history of the UPS.

Preventative maintenance inspections involve working inside the UPS, which contains hazardous AC and DC voltages. Only NEWAVE trained or agreed service personnel and authorised field service engineers are fully aware of all of the hazardous areas within the UPS.

During a preventative maintenance inspection the field service engineer will carry out the following checks:

- Site/environment conditions;
- Integrity of electrical installation;
- Cooling airflow;
- Rectifier operation and calibration;
- Inverter operation and calibration;
- Static switch operation;
- Battery status;
- Load characteristics;
- Integrity of alarm and monitoring systems;
- Operation of all installed options;

## 7.4 BATTERY TEST

The battery test takes approx. 3 minutes and should be performed only if:

- there are no alarm conditions;
- the battery is fully charged;
- mains is present.

The battery testing can be carried out independently of the operation mode (OFF-LINE or ON-LINE) and whether or not the load is connected.

The battery test procedure can be performed from the UPS front panel. See "Operation" Chapter 4.

# 8 Troubleshooting

## 8.1 ALARMS

In the event of an alarm condition the red LED-Indicator "Alarm" and the audible alarm will turn on.

In this case proceed as follows:

1. Silence the audible alarm by pressing the button "Reset".
2. Identify the cause of the alarm condition by means of the EVENT LOG in the MAIN menu.
3. In case of doubts please contact the nearest Service centre.
4. Fault identification and rectification information is given on the following pages.

## 8.2 MENU, COMMANDS, EVENT LOG, MEASUREMENTS,

In Chapter 4 there is a detailed description of the Menu, Commands, Event Log and Measurements that can be operated and displayed on the LCD. The List of Alarms and Messages are shown in the Annex.

## 8.3 FAULT IDENTIFICATION AND RECTIFICATION

The major alarm conditions that will be encountered are:

Alarm Condition	Meaning	Suggested Solution
UPS FAULT	There is a fault in the UPS and therefore normal operation cannot be guaranteed	Call the authorised service centre for assistance
MAINS BYP/RECT FAULT	Mains power supply is outside prescribed tolerance	The input power to UPS is too low or missing. If site power appears to be OK, check the input circuit breakers etc. supplying the UPS
OUTPUT SHORT	There is a short circuit at the output of UPS (on load side)	Check all output connections and repair as required.
OVERLOAD	Load exceeds the UPS rated power	Identify which piece of equipment is causing the overload and remove it from the UPS. Do not connect laser printers, photocopiers, electric heaters, kettles etc. to the UPS
OVERTEMPERATURE	UPS temperature has exceeded the allowed value	Check the ambient temperature of the UPS is less than 30° C. If the ambient temperature is normal call the authorised service centre for assistance.
BATTERY CHARGER OFF	The attached battery and the battery charger set-up do not correspond or battery charger fault	Call the authorised service centre for assistance.
INVERTER FAULT	Inverter is faulty.	Call the authorised service centre for assistance.
SYNCHRON FAULT	The inverter and mains are not synchronised.	The frequency of the input voltage to the UPS is outside operational limits and the UPS static bypass has been temporarily disabled.
BATTERY IN DISCHARGE	Battery is near end of autonomy	Shutdown load connected to UPS before the UPS switches itself off to protect its batteries
MANUAL BYP IS CLOSED	Maintenance Bypass closed. Load supplied by mains	This alarm is only displayed if the UPS is on Maintenance Bypass

# 9 Options

## 9.1 INTRODUCTION

The UPS **Conceptpower™** is provided with the following accessories:

- REMOTE EMERGENCY STOP FACILITIES;
- REMOTE SIGNALLING PANEL (RSP);
- GENERATOR ON FACILITIES;
- SOFTWARE FOR AUTOMATIC SHUTDOWN AND MONITORING;
- SNMP INTERFACES FOR NETWORK MANAGEMENT AND REMOTE MONITORING.

## 9.2 REMOTE EMERGENCY FACILITIES

The emergency stop facility **must** use a normally closed contact, which opens to operate the emergency stop sequence.

The emergency stop port X1 is located at the front of the UPS **Conceptpower™** module. See Figure 3.5 for location drawing.

In order to allow removal, maintenance or testing of any remote emergency stop facility without disturbing the normal operation of the UPS, it is recommended that a terminal block, with linking facilities, be installed between the UPS and the stop button.

1. Use a screened cable with 1 pair (section of wires 0.6 mm<sup>2</sup>) and maximum length of 100 m.
2. Connect the cable as shown in Fig. 9.1





Fig 9.1 Drawing of the wiring for the EMERGENCY-OFF-SWITCH.

### 9.3 REMOTE SIGNALLING PANEL (RSP)

The optional Remote Status Panel (RSP) may be used to display UPS status information up to a distance of 100m.




No.	INDICATOR	INDICATOR STATUS	MEANING
1	LINE	GREEN	Mains available
		RED	Mains not available
2	BATTERY	GREEN	Battery OK
		YELLOW	Battery near the end of capacity
		OFF	No UPS supply or UPS on bypass
3	INVERTER	GREEN	Load supplied by inverter
		OFF	Inverter supply not available
4	LOAD	GREEN	Load is supplied
		RED FLASHING	Load is not supplied
5	ALARM RESET	Push button	Silence the audible alarm
6	ALARM	RED	Alarm condition; check other LEDS for indication of mains and/or UPS status.
		OFF	UPS is in normal operation condition
7	BYPASS	RED	Load is supplied by mains
		OFF	Load is supplied by inverter

Figure. 9.2: LED Indicators on Remote Signalling Panel (RSP)

### 9.3.1 How to Connect the Remote Signalling Panel (RSP)

- Provide a 0,7.5 mm<sup>2</sup>, shielded cable (max 100 meters);
- Do not connect shielding;
- Connect a D-type, 25pin, Male connector to one end of cable;
- The other end of cable connect to the 6pin, Terminal Block inside the RSP-Box as shown in Figure 9.3
- Connect 25 pin D-type connector to the UPS Dry Port.



Connects Fig. 9.3: Connection of Remote Signalling Panel (RSP)

Details of all Dry Port connections are shown in Figure 3.10.

## 9.4 GENERATOR ON FACILITIES

The generator ON facility must use a normally open contact that closes to indicate that a generator is running and supplying input power to UPS.

When used, this facility disables the UPS static bypass and prevents the UPS from transferring the load onto the generator power supply.




Figure 9.4: Generator ON Connection



## 9.5 WAVEMON SHUTDOWN AND MANAGEMENT SOFTWARE

### 9.5.1 Why is UPS Management important?

By combining a UPS with network management products, such as an SNMP protocol, System-administrators are guaranteed their data and their system will constantly be protected from corruption or data loss even in the event of an extended power failure or when batteries reach a critical low state. In the event of a power disturbance system administrators can also monitor their network from a central location, allowing an early detection of problems. In fact utility power is unreliable at times, ensuring that all network systems have constant power can be a difficult task. The situation becomes even more complex if systems are managed across a Local Area Network (LAN) or Wide Area Network (WAN) around the world.

When a power failure occurs action can be taken to protect the system and its valuable data. If no action is initiated by the operator, this event can seriously damage the system. The UPS software will react automatically in such a case and shutdown the operating system. NEWAVE has found it important to have a complete solution for its UPS and is able to offer a wide range of monitoring/remote controls for assuring the maximum protection degree to the NEWAVE customers.

### 9.5.2 Wavemon Shutdown and Monitoring Software

**Wavemon** is an external monitoring and shutdown software which was designed to operate with all NEWAVE UPS products, both with the DRY PORT (Relays) JD2 and SMART PORT (RS232) JD1.

The software packet consists of a CD ROM for most diffused operating systems (Windows, Unix, OS/2, DEC VMS, Novell, Apple), a standard connection and a user manual.

The 25 pin port with voltage-free contacts may also be used for automatic shutdown in connection with **wavemon**. It is necessary to provide a special cable to connect the 25 pin port of the UPS and the serial port of the server.




Figure 9.5. Monitoring image.

The main characteristics of **wavemon** software are:

- Automatic unattended master/slave shutdown in heterogeneous networks
- On-screen autonomy time / battery time countdown
- On-screen server log off and shutdown procedure
- Extensive logging of all UPS activity and power quality data, with timestamp
- Scheduled UPS economy mode, service mode, other systems status
- Graphical user interface for Windows compatible platforms
- Automatic unattended local shutdown
- Special software modules to close and save open MS-Office documents.
- Compatible for all optional modules like UPSDIALER, SNMP adapters, Temperature sensors, etc.

The UPS-Management Software is a client-/server-application for networks and local workstations. Basically **Wavemon** consists of two parts: the server-module of the UPS-Management Software is **UPSMAN**, which communicates via RS-232 cable with the UPS. Working as

a background process the UPSMAN collects messages, received from the UPS. The UPSMAN interprets received messages and makes them available to the client-module **UPSMON** and to any SNMP-based management station.

When UPSMAN detects voltage variations or a power failure it can execute various so called system „event routines“, which for example may shutdown the server or send warning to connected users. These system event routines which are a part of the UPS-Management Software can be adjusted to your demands.

The UPS management software includes with every serial number the licence for using the UPS service on one server with one UPS and an unlimited numbers of connected WINDOWS workstations. When operating with two or more servers a licence for every additional server is required. It doesn't matter if the UPS service runs at that location or if the server is halted by a UPS service via remote command. The same regulations are applicable to the use of remote send/receive modules RCCMD and multiserver shutdown under NT, UNIX and other operating systems. The service programs are generally delivered as a single-licence. To use a single CD ROM to shutdown multiple servers you have to purchase additional CD license keys.

Parallel/redundant UPS systems are also manageable by the software.

The main principle is: let introduce a shutdown of a Server only when strictly necessary. A correct Parallel Handling has therefore to manage a parallel system as a whole and always considering redundancy. Following statements apply:

- Every alarm on any unit is immediately notified, but ...
- ... a reaction to a severe fault is introduced only when the minimum number of UPS –Modules necessary to supply the load exhibits an alarming situation.
- The real Battery autonomy time of the (whole) parallel system is computed continuously.
- Maintenance on a redundant unit may be executed without annoyance to the management system (supervisor).

In order to be managed, a NEWAVE UPS can be integrated into a network in two ways:

1. By means of the server which is being powered by the UPS and is integrated in the network. In most of the cases the server is used as sub-agent and you only need the Wavemon software without any SNMP Adapter. You need a standard serial connection between the RS232 SMART port of the UPS and the RS232 port of the computer/server.
2. In some situations it is preferable to interface the network via an SNMP adapter. By this way up to 50 computers can be shut down in a RCCMD environment. RCCMD (Remote Console Command) is an additional software module, which can be triggered by the SNMP device to executes a command (typically a shutdown command) on a remote system.

## 9.6 SNMP CARD/ADAPTER FOR NETWORK MANAGEMENT /REMOTE MONITORING

The **Simple Network Management Protocol (SNMP)** is a worldwide-standardized communication-protocol. It is used to monitor any device in the network via simple control language. The UPS-Management Software also provides its data in this SNMP format with its internal software agent. The operating system you are using must support the SNMP protocol. We offer our software with SNMP functionality for Novell, OS/2, all Windows running on INTEL and ALPHA, DEC VMS, Apple.

Two types of SNMP interfaces with identical functionality are available: an external SNMP-Adapter (Box) and an internal SNMP-Card. Both can manage a parallel system (N modules) and return either global values - which are consistent for the whole parallel system - or specific values from the single modules.




Figure 9.6 SNMP Adapter

The adapter may be configured via Telnet, HTTP (Web-Browser) or serial connection (Terminal). For normal operation at least one network connection (Ethernet) is required.

The SNMP adapter can be used, utilising the RCCMD send function, for an automatic network wide shut down or just for informing connected users. The shut down procedure can be initiated on a low residual battery autonomy time (downtime) or by a countdown timer which is started at the beginning of the alarm. A shut down is therefore possible without extra input from the operator, and is fully software controlled.

The small (125x70 mm) External SNMP adapter comes with following interfaces:



1. RJ-45 connector for 10/100 Base-T (autoswitchable)
2. Serial Port for configuration (COM2) or optional ModBus interface.
3. Error/Link LED for UPS status
4. Aux Port
5. DIP Switch
6. Serial Port to the UPS (COM1)
7. DC Supply (9 VDC or 9-36 VDC supply, depending on model);

Figure 9.7 External SNMP Adapter



The Internal SNMP-Card can be inserted into an appropriate extension slot of the UPS **Conceptpower™**. This adapter communicates via the serial port of the UPS and makes a direct multiple server shut down possible without additional SNMP management software.

Figure 9.8 Internal SNMP Adapter

For detailed information please see Software Manual provided with the WAVEMON CD ROM.

**RCCMD - Remote Console Command module** for a multi-server shutdown. This stand-alone software module is designed to receive and execute a command issued by a remote device. Thanks to RCCMD it is possible to execute a shutdown in an heterogeneous multiplatform network. The new release RCCMD2 is an application available for all Operating Systems, analogous to Wavemon. Our SNMP Interfaces are compatible to RCCMD

# 10 Technical Specifications