

# User Manual

## IP120



### IP Phone

### Version 1.1

<b>1</b>	<b>PRODUCT OVERVIEW .....</b>	<b>4</b>
<b>2.</b>	<b>POST MODE .....</b>	<b>5</b>
<b>3</b>	<b>APP MODE .....</b>	<b>6</b>
4	CONFIGURE IP PHONE BY WEB : .....	6
<b>4.1</b>	<b>CONFIGURATION WITH WEB .....</b>	<b>6</b>
4.2	USER VALIDATION .....	7
4.3	CONFIGURATION DETAILS .....	8
4.3.1	CURRENT STATE.....	8
4.3.2	NETWORK CONFIGURATION .....	9
4.3.2.1	Wide area network ( WAN ) .....	9
4.3.2.2	Local area network (LAN) .....	11
4.3.3	VOIP CONFIGURATION.....	12
4.3.4	ADVANCE CONFIGURATION .....	15
4.3.3.2	NAT configuration.....	17
4.3.3.3	Net Service configuration.....	19
4.3.3.4	Firewall configuration .....	20
4.3.3.5	QOS configuration .....	22
4.3.3.6	SIP advanced configuration.....	24
4.3.3.7	Dial mode configuration.....	26
4.3.3.8	Value added service configuration.....	28
4.3.3.9	MMI filter configuration .....	30
4.3.4	NUMBER BINDING CONFIGURATION .....	33
4.4	SAVE AND CLEAR CONFIGURATION .....	37
4.5.	UPGRADE ON-LINE .....	39
4.5.1.	Upload WEB page.....	39
4.5.2	FTP download .....	39
4.5.4.2	Telephone book configuration.....	43
4.5.4.3	Syslog configuration .....	43
4.5.4.3	Time configuration .....	44
4.5.4.4	System restart .....	45
<b>5.</b>	<b>COMMAND LINE .....</b>	<b>45</b>
5.1.1	MAIN FRAME OF THE COMMAND LINE.....	45
5.1.2	CONFIGURATION UNDER CONFIG NODE .....	46
5.1.2.1	Accesslist Firewall Configuration .....	46
5.1.2.2	DHCP-Server DHCP service configuration .....	47
5.1.2.3	Dial-Rule configuration.....	47
5.1.2.4	Interface-Fastethernet-Lan Local area network(LAN) parameter configuration.....	47
5.1.2.5	Interface-Fastethernet-Wan wide area network parameter configuration.....	48
5.1.2.6	MMI FILTER (man-machine interface filter) .....	48
1.1.	3.3.8 NAT parameter configuration .....	48

5.1.2.7 Network service configuration .....	49
5.1.2.8. Phone book outgoing call number binding configuration .....	49
5.1.2.9 Port configuration.....	50
5.1.2.10 PPPOE configuration .....	52
5.1.2.11 QOS configuration .....	52
5.1.2.12 SIP configuration.....	53
5.1.2.13 UDP TUNNEL configuration.....	54
5.1.2.14 User management configuration.....	54
5.2 OTHER CONFIGURATIONS OUTSIDE THE CONFIG NODE .....	54
5.2.1 Account charging module configuration .....	54
5.2.2 Time configuration .....	54
5.2.3. SYSTEM UPGRADING COMMAND.....	55
5.2.4 Other command.....	55

# 1 Product Overview



## 1.1. IP Phone Overview

IP is short for Internet Protocol. IP phone carries voice package by IP protocol grouped data package. IP phone can be used by Internet, enterprise LAN, MAN who adopts IP protocols. The main feature of IP phone is to carry voice message on data traffic network. It possesses such features as low cost, sound quality and so on.

IP120 IP Phone attaches a LCD for user to do configuration by its keyboard. It supports prepaid card issued by ITSP, e-Talk card and all IP phone cards while provides sound voice quality which can be compatible to PSTN.

## 1.2. Key Features and compatibility.

- Support two models: Bridge and Router(NAT&NAPT)
- Network Protocols: TCP/UDP/IP、ICMP、HTTP、DHCP Client ( WAN Interface ), DHCP Server ( LAN Interface ), DNS Client、DNS Relay、SNTP、PPPoE、FTP、TFTP
- Sip protocols
- Voice Codecs: G.711 ( A-law/U-law ), G.723.1、G.729A/B、G.726 , and G.722
- Redundancy SIP server (or Gate Keeper): Can auto swap address between two servers address
- NAT transversal: Support STUN client, AVS and Citron etc . Can modify SIP register port, HTTP server port、Telnet server port and RTP port
- Support two SIP server synchronously : Can register two different SIP server, and can make a call by either proxy
- Support standard voice features such as numeric Caller ID Display, Call Waiting, Hold,

Transfer, Do-Not-disturb, Forward, in-band and out-of-band DTMF, Hotline (off hook autodial), auto answer, ban outgoing

- Full duplex hands-free speakerphone, redial, call log, volume control, voice record with indicator
- Support standard encryption and authentication (DIGEST using MD5, MD5-sess)
- Support Silence Suppression, VAD (Voice Activity Detection), CNG (Comfort Noise Generation), Line Echo Cancellation (G.168), and AGC (Automatic Gain Control)
- Provide easy configuration thru manual operation (phone keypad, Web interface and Telenet) or automated centralized configuration file via TFTP or HTTP.
- Support firmware upgrade via TFTP/FTP and HTTP
- Support syslog, can send event of phone to syslog server.


## 2. POST mode

If user can't log in due to some mistake in configuration or the device can't be started due to some parameters, POST mode will be helpful for initial configuration.

Processes to log in POST mode:

1. Restart Gateway (Connect phone with Fxs port. Phone display will count down after 3 sec. If '#' is pressed down within 5 sec., POST mode will be got in, or, the system will be lead to APP. ) (If user press down keyboard by mistake within 5 sec. to get in POST mode, press down "Subnet Mask" can log out POST mode to lead to APP.)

Log in POST mode by telnet 192.168.10.1 as following picture show;



```
ca Telnet 192.168.10.1
      Uoip   Phone   System
      Post   Version:2.0(16m)
      Date:Aug 7 2006 09:36:16

1 ---- Show Mac Address
2 ---- FTP Update Image
3 ---- Clear Configuration
4 ---- Exit and Reboot
```

2, POST mode has been logged in when got above picture and can do initial configuration. Choose 1 can look over MAC address; choose 2 can enter FTP upgrade mode; choose 3 to clear configurations and back to default configurations.


### 3 APP mode

After APP is enabled successfully, sometimes in order to meet different demands , we should check the current configuration of the phone and modify some configurations according to our own needs. The phone provides three ways for checking and modifying configuration :

- a. Command line
- b. WEB page
- c. Phone keyboard

After APP is enabled, the one near the power supply is WAN port , another is LAN port.

### 4 Configure IP phone by WEB :




#### 4.1 Configuration with WEB

The IP Phone Web Configuration Menu can be accessed by the following URI:

<http://Phone-IP-Address>. The default LAN IP address is “**192.168.10.1**” and WAN IP address is “**192.168.1.179**”. If the web login port of the phone is configured as non-80 standard port , then

user need to input `http://xxx.xxx.xxx.xxx : xxxx/` , otherwise the web will show that no server has

been found),it will be shown as follows:




## 4.2 user validation

### 4.2 User validation.

Login should be effected before configuration.

Account for guest: user name and pin are both guest. This user can overview the system.

Admin account: user name and pin are both admin. This user is for administrators only and can configure system.



## 4.3 Configuration details


### 4.3.1 Current state

On this page user can gather information of each commonly-used parameter of the phone, it is shown as the following figure : the network section shows the current WAN, LAN configurations of the phone : including gaining way of WAN IP and IP ( static state, DHCP, PPPoE) , MAC address , WAN IP address of the phone , LAN IP address of the phone , opening state of LAN DHCP server.

The VoIP section shows the current default signaling protocol in use , and server parameter in use of each protocol : including GateKeeper IP of H323 ,H323ID , whether enables register , whether has registered on GK ; Register server IP of SIP , proxy server IP , whether enables register , whether has registered on register server , whether enables outbound proxy , whether enables STUN server ;

The Phone Number section shows corresponding phone number of each protocol ;

The version number and date of issue have been shown at the end of the page ;



## 4.3.2 Network configuration

### 4.3.2.1 Wide area network ( WAN )

User can view the current network IP linking mode of the system on this page.

User will be authorized to set the network IP , Gateway and DNS if the system adopts the static linking mode.

If the system selects DHCP service in the network which is using DHCP service, IP address will be gained dynamically.

If the system selects PPPOE service in the network which is using the PPPOE service, then the IP address will be gained by the set PPPOE ISP internet and password of the account.

**Note :if IP address has been modified, the web page will no longer respond owing to the modification , so new IP address should be input in the address field now.**

### WAN Configuration

Active IP	Current Netmask	MAC Address	Current Gateway
192.168.1.97	255.255.255.0	00:01:02:03:04:06	192.168.1.68

Static   
  DHCP   
  PPPOE

Static	IP Address	192.168.1.97	Netmask	255.255.255.0
	Gateway	192.168.1.68	DNS Domain	voip.com
	Primary DNS	192.168.1.68	Alter DNS	192.1.1.1

PPPOE	Server	ANY	User	user123	Password	●●●●●●
-------	--------	-----	------	---------	----------	--------

**Configuration Explanation :**

Active IP	Current Netmask	MAC Address	Current Gateway
192.168.10.77	255.255.255.0	00:01:02:12:34:57	192.168.10.86

Current phone IP , subnet mask , mac address and current phone IP ;

Static   
  DHCP   
  PPPOE

, Select acquisition way of IP for WAN ;

This is single option ; Configure static IP parameter for WAN :

Static	IP Address	192.168.10.77	Netmask	255.255.255.0
	Gateway	192.168.10.86	DNS Domain	voip.com
	Primary DNS	192.168.10.86	Alter DNS	192.1.1.1

IP Address	192.168.10.77
------------	---------------

Configure static IP address ;

Netmask	255.255.255.0
---------	---------------

Configure subnet mask ;

Gateway	192.168.10.86
---------	---------------

Configure IP address of the the phone ;

DNS Domain	voip.com
------------	----------

Configure "dns domain" suffix ; if user input

"domain" and it can't be resolved , then the phone will add and resolve the "domain" after user has

input ;

Primary DNS	<input type="text" value="192.168.10.86"/>	Main DNS server IP address ;
Alter DNS	<input type="text" value="192.1.1.1"/>	The second DNS server IP address ;

Configure PPPoE :

PPPOE Server	<input type="text" value="ANY"/>	User	<input type="text" value="user123"/>	Password	<input type="password" value="....."/>
Server	<input type="text" value="ANY"/>	Service name , if PPPoE ISP has no special requirement for this			


name , generally is the default ;

User	<input type="text" value="user123"/>	PPPoE account ;
Password	<input type="password" value="....."/>	PPPoE password ;

Configure the parameter and then click "apply" to go into effect ;

### 4.3.2.2 Local area network (LAN)

User can make local area network (LAN) configuration on this page, when bridging mode is selected, the local area network (LAN) configuration will no longer go into effect.



The screenshot shows a blue-tinted window titled "LAN Configuration". At the top, there is a checkbox labeled "Bridge Mode" which is currently unchecked. Below this, there are two input fields: "IP" with the value "192.168.10.11" and "Netmask" with the value "255.255.255.0". At the bottom, there are two checkboxes: "DHCP Service" and "NAT", both of which are checked.

Configuration Explanation :

<input type="checkbox"/> Bridge Mode	Use bridge mode( transparent mode ) :bridge mode will make the phone no longer set IP address for LAN physical port , LAN and WAN will join in the
--------------------------------------	--

same network ;

IP 192.168.1.68 Configure LAN static IP ;

Netmask 255.255.255.0 Configure LAN subnet mask ;

DHCP Service Enable LAN port DHCP server ; after user modify LAN IP , the phone will automatically modify the adjustment and save the configuration according to IP and subnet mask team DHCP Lease Table ,user need to restart the phone to make DHCP server configuration go into effect ;

NAT Enable NAT ;

### VOIP configuration

Sip parameters can be configured by this interface.

SIP [Registered] Configuration			
Register Server Addr	210.51.235.200	Proxy Server Addr	210.51.235.200
Register Server Port	5060	Proxy Server Port	5060
Register Username	60576181	Proxy Username	60576181
Register Password	●●●●●●	Proxy Password	●●●●●●
Phone Number	60576181	Local SIP Port	5060
Detect Interval Time	60 seconds	Register Expire Time	33 seconds
DTMF Mode	DTMF_RFC2833	RFC Protocol Edition	RFC3261
<input checked="" type="checkbox"/> Enable Register		<input type="checkbox"/> Auto Detct Server	
<input checked="" type="checkbox"/> Enable Pub Outbound Proxy		<input type="checkbox"/> Server Auto Swap	
<input checked="" type="checkbox"/> SIP(Default Protocol)			

Configuration Explanation :

## SIP[Registered] Configuration

show SIP register state ; if register

successfully, there will show Registered in the square bracket , otherwise show Unregistered ;

Register Server Addr

Configure SIP register server IP

address ;

Register Server Port

Configure SIP register server signal

port ;

Register Username

Configure SIP register account

( usually it is the same with the port number that configured , some special SIP servers will have

different port configurations,then the port configuration needs to be configured to be numbers ,

here the configuration account can be arbitrary character string ) ;

Register Password

Configure password of SIP register

account ;

Proxy Server Addr

Configure proxy server IP address

( usually SIP will provide user with service of proxy server and register server which have the

same configuration , so the configuration of proxy server is usually the same with that of register

server , but if the configurations of them are different(such as different IP addresses), then each

server's configuration should be modified separately ) ;

Proxy Server Port

Configure SIP proxy server signal

port ;

Proxy Username

Configure proxy server account ;

Proxy Password

Configure proxy server password ;

Local SIP Port 5060 Configure local signal port , the default is 5060( this port will go into effect immediately, the SIP call will use the modified port for communication after modification )

Register Expire Time 300 seconds Configure expire time of SIP server register , the default is 600 seconds. If the expire time that server requires is more or less than that configured by the phone , the phone can automatically modify it to the recommended time limit and register ;

Detect Interval Time 60 seconds Configure detection interval time of the server , if the phone enables SIP detection server function , the phone will detect once for whether the server has response every other detection interval time ;

Enable Register Configure enable/disable register ;

Enable Pub Outbound Proxy Configure to enable public outbound proxy. If proxy server has been enabled , the phone will consider the user as using outbound proxy automatically. If the configuration has been disabled , the phone can still be registered to the server , but can't make SIP call ; configuration of registered call by the phone will not have impacts on SIP point-to-point call ;

SIP(Default Protocol) Configure SIP of the phone as default protocol ;

RFC Protocol Edition RFC3261 Enable the phone to use protocol edition. When the phone need to communicate with phones which is using SIP1.0 such as CISCO5300 and so on, then it should be configured into RFC2543 to communicate normally. the default is to enable

DTMF Mode DTMF\_SIP\_INFO  
 Enable Register DTMF\_RELAY  
 Enable Pub Outbound DTMF RFC2833  
DTMF sending mode

RFC3261 ; three kinds : the above are basic configurations of SIP.

Note : if you want to register and call through server , you must configure corresponding numbers ( which are usually SIP accounts ) to local port , otherwise the phone will reject for sending out register message when it considers that there is no number.

Auto Detect Server

Configure automatic detection server of the phone ;

Server Auto Swap


Configure main and backup auto-swap server ; if the phone enables main and backup server function , the automatic detection and auto-swap functions should both be chosen ;

**After the aforesaid network and VoIP configurations have been configured on the phone and internetwork communication has been implemented , the user can make VoIP calls by the calling register and proxy.**

**SOME ISP INTERNET MAY INHIBIT THE PHONE TO REGISTER AND CANCEL THE REGISTER IN SUCCESSION, SO USER HAD BETTER NOT APPLY OR REGISTER AND CANCEL SOON IN SUCCESSION AND SUBMIT REGISTRATION REPEATEDLY. SERVER MAY STOP RESPONSE OF DIALOGUE MACHINE, THEN THE PHONE RECEIVES NO CERTIFICATION OF REGISTER/CANCEL LOGIN REQUEST AND REGISTRATION STATE WILL SHOW AS INCORRECT!**

#### **4.3.3.1 DHCP server configuration.**

User can configure DHCP service on this page , user can define dynamic IP distribution scope and other configurations.



Configuration Explanation :

DNS Relay Configure DNS Relay mode ; this mode enables user's LAN-linked equipments to use LAN port IP of the phone as DNS server address. The default is Enable ;click apply to make it go into effect after it has been selected ;

Name	Start IP	End IP	Lease Time	Netmask	Gateway	DNS
lan2005	192.168.10.2	192.168.10.50	1440	255.255.255.0	192.168.10.1	192.168.10.1

The display of DHCP lease table configuration , of which the unit of the lease time is minute ;

Lease Table Name	lan_202	Lease Time	1440	Add
Start IP	192.168.1.1	End IP	192.168.1.31	
Netmask	255.255.255.0	Gateway	192.168.1.99	
DNS	192.168.1.99			
Lease Table Name	lan2005			Delete

Add and delete of the lease table :

Lease Table Name  Additive lease table names ;

Lease Time	<input type="text" value="1440"/>	Time limit of additive lease table IP ;
Start IP	<input type="text" value="192.168.1.1"/>	Start address of additive lease table IP ;
End IP	<input type="text" value="192.168.1.31"/>	End address of additive lease table IP ;
Netmask	<input type="text" value="255.255.255.0"/>	Subnet mask of additive lease table ;
Gateway	<input type="text" value="192.168.1.99"/>	Default phone IP of additive lease table IP ;
DNS	<input type="text" value="192.168.1.99"/>	Default DNS server IP of additive lease table IP ;


Click ADD to add DHCP lease table ;

Lease Table Name	<input type="text" value="lan2005"/>	Select lease table names that you want to delete from the drop-down menu , click Delete to delete your options from DHCP Lease Table.
------------------	--------------------------------------	---

✘If user modify dhcp lease table , the configuration should be saved and will go into effect after restarting.

### 4.3.3.2 NAT configuration

User can configure NAT image on this page. Each kind of image can have 10 configurations at most.



Configuration Explanation :

- H323 ALG Configure enable/disable of H323 ALG , the default is Disable ;
- FTP ALG Configure enable/disable of FTP ALG , the default is Enable ;
- PPTP ALG Configure enable/disable of FTP ALG , the default is Enable ;
- IPsec ALG Configure enable/disable of FTP ALG , the default is Enable ;

Click Apply to go into effect after selecting.

Inside IP	Inside TCP Port	Outside TCP Port
192.168.1.201	1719	1917

Inside IP	Inside UDP Port	Outside UDP Port
192.168.1.201	5060	5000

Configure the display of TCP and UDP inner-net image table of NAT ;

Transfer Type  Configure image protocol types of NAT , TCP or UDP ;

Inside IP  Configure LAN equipment IP address of NAT image ;

Inside Port  Configure the NAT image LAN equipment port ;

Outside Port  Configure the NAT image WAN port of the phone ;

After configuration, click Add to add to the image table, click Delete to delete from the image table.

### 4.3.3.3 Net Service configuration

User can set up Telnet, HTTP, RTP port on this page and view DHCP table.

**Net Service**

HTTP Port	<input type="text" value="80"/>	Telnet Port	<input type="text" value="23"/>
RTP Initial Port	<input type="text" value="10000"/>	RTP Port Quantity	<input type="text" value="200"/>

If modify HTTP or Telnet port,you'd better set it more than 1024,then save and restart.

DHCP Lease table

Leased IP Address	Client hardware Address
-------------------	-------------------------

Configuration Explanation :

HTTP Port  Configure web browse port , the default is 80 port , if you want to enhance system safety , you'd better change it into non-80 standard port ;

Telnet Port  Configure telnet port , the default is 23 port ;

RTP Initial Port  Enable RTP initial port configuration. It is dynamic allocation ;

RTP Port Quantity  Configure the maximum quantity of RTP port. The default is 200 ;

Leased IP Address  Client hardware Address

Leased IP-MAC correspondence table of DHCP ;

※The configuration on this page needs to be saved after modified and will go into effect after restarting.


※If the Telnet, HTTP port will be modified, the port is better to be set as greater than 1024,because the 1024 port system will save ports.

※Set the HTTP port as 0 , then the http service will be disabled.

#### 4.3.3.4 Firewall configuration

User can set whether enable the input and output firewall on this page , and configure the IO(input-output) rule of firewall ,utilize these configurations to guard against some malicious IP to access this phone or restrict visiting some resource of the outside-net , so that the security will be enhanced.

Accesslist is a simple execution module such as Cisco accesslist ( firewall ) .This function supports two rules : input and output rule. Each rule will be provides with one serial number.Each rule is allowed to 10 configurations at most.



Configuration instance :

Debug configuration of icmp data packet sent from lan attached device to wan network segment device. wan ip of the phone is 192.168.10.77 , lan ip is 192.168.1.68.

<input type="checkbox"/> in_access enable	<input checked="" type="checkbox"/> out_access enable
Input/Output <input type="text" value="Output"/>	Deny/Permit <input type="text" value="Deny"/>
Protocol Type <input type="text" value="ICMP"/>	Port Range <input type="text" value="more than"/> <input type="text" value="0"/>
Src Addr <input type="text" value="192.168.10.77"/>	Des Addr <input type="text" value="192.168.10.86"/>
Src Mask <input type="text" value="255.255.255.255"/>	Des Mask <input type="text" value="255.255.255.255"/>

Configuration Explanation :

- out\_access enable , To enable the output rule application ;
- Input/Output  To select the current additive rule as input or output rule ;
- Deny/Permit  To select the current rule configuration as deny or permit ;
- Src Addr  It is source address, which can be specific IP address or network address ;

Src Mask 255.255.255.255

It is source address mask , which stands for specific host computer when it is configured as 255.255.255.255 , and it stands for network ID when the it has been set as subnet mask 255.255.255.0 ;

Des Mask 255.255.255.255

It is destination address mask , which stands for specific host computer when it is configured as 255.255.255.255 , and it stands for network ID when it has been set as subnet mask 255.255.255.0 ;in this way ,when this configuration has been added ,there will be an additive item in output rule table , shown as the following figure.


Index	Deny/Permit	Protocol	Src Addr	Src Mask	Des Addr	Des Mask	Range	Port
0	deny	ICMP	192.168.10.77	255.255.255.255	192.168.10.86	255.255.255.255	more than	0

And then select "out\_access table" and click the "apply" button.

When the lan port attached device ping 192.168.10.86 through wan port , it can't receive echo of 192.168.10.86 because of the deny of the rule, but other IP of ping 192.168.10.0 network segment can still receive echo of destination host normally.

#### 4.3.3.5 QOS configuration

The phone is accomplished to base on the qos 802.1p and used for marking and ranking the priority of internetwork communication in data link/MAC sublayer. 802.1p communication is to be classified and transmitted to destination.



QOS Enable The selected Qos Enable represents application of Qos service.

QOS Table Include The selected Qos Table Include means that the network segment addresses in the set Qos table are required to provide Qos service addresses ,those outside the table are not required to provide qos ; cancelling the checked qos table include is to say all the addresses outside the table are required to provide Qos service.

Click Submit to go into effect after selecting.

Description of qos table items : the setup of IP can be network address or specific IP address. User can set destination address through the setup of IP and mask. When the setting is 255.255.255.255 , then it stands for appointed specific IP.


Deletion of qos table : input items that you want to delete in ip / netmask configuration table and then select delete.

### 4.3.3.6 SIP advanced configuration

Set SIP STUN , private and backup server, user password and so on.

SIP STUN is a kind of server that used to realize the SIP's enablement of NAT , when the STUN server IP of the phone has been configured( generally the default is 3478 )and Enable SIP Stun has been selected, conventional SIP server can be used to realize the phone's penetration of NAT. Public backup server can implement the proxy of the dialogue machine through auto-swap function when no response to public server. When the phone detect response of public server , it will auto-swap to public server. Public backup server is redundancy backup of public server, it should have the same account with public server.

The phone's supports to two different kinds of SIP server concurrently can be implemented on private server. In this way user can register and use two different kinds of services concurrently.



Configure explanation of private server :

**Public [Unregistered] Private [Unregistered]** To show the phone whether has been registered on public server or private server ;

STUN Server Addr  Configure IP address of SIP STUN server ;

STUN Server Port  Configure port of SIP STUN ;

STUN can support SIP terminal's penetration to NAT in the inner-net. In this way , as long as there is conventional SIP proxy and a STUN server placed in the public net, it will do; but STUN only supports three NAT modes : FULL CONE, restricted, port restricted ;

Public Alter Register	<input type="text" value="10.1.1.11"/>	Public Alter Proxy	<input type="text" value="0.0.0.0"/>
Register Port	<input type="text" value="5060"/>	Proxy Port	<input type="text" value="5060"/>
Register Username	<input type="text" value="1234"/>	Proxy Username	<input type="text" value="1234"/>
Register Password	<input type="password" value="••••"/>	Proxy Password	<input type="password" value="••••"/>

Public backup server configuration ; the specific configuration parameter has the same meaning with public server. It should be noted that the username and password should be the same with the public main server ;

Private Register	<input type="text" value="210.25.132.124"/>	Private Proxy	<input type="text" value="210.25.132.124"/>
Register Port	<input type="text" value="5060"/>	Proxy Port	<input type="text" value="5060"/>
Register Username	<input type="text"/>	Proxy Username	<input type="text"/>
Register Password	<input type="password"/>	Proxy Password	<input type="password"/>

Private server configuration. specific configuration parameter has the same meaning with public server ;

STUN Effect Time  minute Interval time for STUN's detection on

NAT type , the unit is minute ;

Enable SIP Stun Configure enable/disable SIP STUN ;

Enable Private Server Register Configure permit/deny private server register ;

Enable Private Outbound Proxy Configure enable/disable private outbound proxy ;

If user has accounts of a certain SIP server and each account has different password , then user should add each account and its corresponding password to the account& password table.

SIP Account	Password
1000	1000

Configure display of account & password list ;

Click Add to add account and password, it is shown as the following figure:

Configure additive accounts

Configure additive passwords

Click submit to submit the configuration, click return to cancel the configuration and return ;

delete. Select drop-down menu to select accounts that want to

modify, click load to load the configuration and then click modify to modify :

Accounts to be modified , read-only ;

Passwords to be modified ;

Click submit to submit, click return to cancel the modification and then return ;

### 4.3.3.7 Dial mode configuration

Dial modes supported by this system :

End with # key : user add an # to end the calling number.


End with fixed length : the system intercepts numbers that user input by the fixed length.

End with H323 RAS : the system checks each number that user input at net gate through H323

protocol.

End with timeout setup : the system sends out number received after time out.

End with user-defined rule : the user-defined length and prefix of the numbers.



Configuration Explanation :

- End with "#"  
Configure the phone to end with # key ;
- FixedLength 0  
Configure the phone to end with fixed length ;for example, when user set a"8",then when user have dialed 8 figures,the phone will make the call of this number of 8 figures automatically.
- User-defined Rule  
Configure to end with user-defined rule ; add configurations to the following user-defined list ;
- Time out 5 (3--30)  
Configure timeout length of dialing , the unit is second. The default is 5 seconds , that is, after the user has dialed a number and haven't dialed in 5 seconds ,the phone will consider that the user has finished dialing and then send out the

number it has received as the called number ;

H. 323 Stack auto parse Configure to be H323 protocol automatic resolving ;

The following is list of user-defined rules :

Prefix Number	Length
010	11
020	11

Display of user-defined digit reception rule list ;

Prefix Number	Length	
<input type="text" value="0139"/>	<input type="text" value="12"/>	<input type="button" value="Add"/>
Prefix to be deleted	<input type="text" value="010"/> ▼	<input type="button" value="Delete"/>

Configure add/delete of user-defined rule list. Configure the dialed number prefix in prefix number , configure number length in length , then click add to submit ;

#### 4.3.3.8 Value added service configuration

On this page, user can set value added services such as hot-line , call forwarding , call transfer (CT) , call-waiting service , three way call , blacklist , out-limit list and so on.

Call Service	
Hotline	<input type="text"/>
Call Forward	<input checked="" type="radio"/> Off <input type="radio"/> Busy <input type="radio"/> No Answer <input type="radio"/> Always
	Faraway Protocol:H323 Number <input type="text"/> IP <input type="text"/> Port <input type="text" value="1720"/>
	Faraway Protocol:SIP Number <input type="text"/> IP <input type="text"/> Port <input type="text" value="5060"/>
<input type="checkbox"/> No Disturb	<input type="checkbox"/> Ban Outgoing
<input checked="" type="checkbox"/> Enable Call Transfer	<input checked="" type="checkbox"/> Enable Call Waiting
<input checked="" type="checkbox"/> Enable Three Way Call	<input checked="" type="checkbox"/> Accept Any Call
<input type="checkbox"/> Auto Answer	

Configuration Explanation :

Hotline	<input type="text"/>
---------	----------------------

Configure hot-line number of the port. With this number of the port , this hot-line number will be dialed automatically as soon as off-hook and user can's dial any other number ;

Call Forward	<input checked="" type="radio"/> Off <input type="radio"/> Busy <input type="radio"/> Always
--------------	--

Call forwarding. The default is Disable ;  
 when busy is selected , if the number dialed is engaged after the phone has received a call, then it will automatically transfer to the configured number according to the following configuration ;  
 when always is selected , then the phone will directly transfer all the numbers that dial to this port to the configured numbers ;

Faraway Protocol:H323	Number <input type="text"/>	IP <input type="text" value="0.0.0.0"/>	Port <input type="text" value="1720"/>
Faraway Protocol:SIP	Number <input type="text"/>	IP <input type="text" value="0.0.0.0"/>	Port <input type="text" value="5060"/>

number IP configuration of call transfer (CT) ;

<input type="checkbox"/> Enable Call Waiting
--

Configure enable/disable call waiting service ;After it is enabled,

user can hold calls of the other party by hooking, with hooking again, the hold call can go on.

Enable Call Transfer

Configure enable/disable call transfer (CT) ; after it is enabled,

user accept calls, with hooking and dial directly , the phone will transfer the calls according to the

above configurations of the port number IP images ;

Enable Three Way Call

Configure enable/disable three way call ; user can call the other

part as the call origination , after talking , make hooking to hold this part and then press \* key to

hear the dialing tone ,after call completion to the third party, hooking again to recover the talk with

the second part, then the three way call concurrently ;

After the aforesaid configuration has been done, click apply to make them go into effect.

Black List			
<input type="text"/>	<input type="button" value="Add"/>	<input type="button" value="v"/>	<input type="button" value="Delete"/>


Configure add/delete blacklist. If user don't want to answer a certain number, please add this number to the list, and then this number will be unable to get through the phone.

Limit List			
<input type="text"/>	<input type="button" value="Add"/>	<input type="button" value="v"/>	<input type="button" value="Delete"/>

Configure out-limit list ; for example, if user don't want the phone to dial a certain number, please add the number to this table, and the user will be unable to get through this number.

#### 4.3.3.9 MMI filter configuration

On this page, user can set MMI to permit only a certain network segment IP accessing the phone.



Configuration Explanation :

MMI Filter Configure enable/disable MMI access filter ; click apply button to go into effect ;

Start IP	End IP
192.168.10.1	192.168.10.254

Display of MMI permitted IP network segment ;

Start IP	<input type="text"/>	End IP	<input type="text"/>	<input type="button" value="Add"/>
Start IP to be deleted	192.168.10.1	<input type="button" value="Delete"/>		

Add and delete MMI visit-permitted IP network segment ; configure start IP address in start IP and configure end IP address in End IP , submit the configuration to go into effect. User can set a big network segment or set several network segments to add, when user make deletion, select the start IP of network segment that will be deleted and then click delete to go into effect go into effect ;

✘It should be noted that if the phone device you are accessing is at the same network segment with the phone , don't configure the mmi filter network segment outside of the network segment of the phone you have, otherwise it can't logging in web in the phone network segment.

#### 4.3.3.10 DSP configuration

On this page, user can set speech coding , IO volume control, cue tone standard, caller ID standard and so on.

DSP Configuration			
Coding Rule	<input type="text" value="g723-r63"/> <input type="button" value="v"/>	Handdown Time	<input type="text" value="200"/> ms
Input Volume	<input type="text" value="5"/> (1-5)	Output Volume	<input type="text" value="5"/> (1-9)
Handfree Volume	<input type="text" value="5"/> (1-9)		

Configuration Explanation :

Output Volume  (1-9) Configure output volume ;

Input Volume  (1-5) Configure input volume ;

Handfree Volume  (1-9) Configure handfree volume

Handdown Time  ms Configure handdown time , that is, if the hooking time is shorter than this time, then the gateway will not consider the user has handdown ;

#### 4.3.3.11 VPN network configuration

**VPN Tunnel**

VPN IP		0.0.0.0	
VPN Server Addr	0.0.0.0	VPN Server Port	80
Server Group ID	VPN	Server Area Code	12345
<input type="checkbox"/> Enable VPN Tunnel		Out GK Addr	

---

Tunnel List			
	<input type="button" value="Add"/>	▼	<input type="button" value="Delete"/>

#### 4.3.4 Number binding configuration

Number IP table configuration :

Function of number IP table is one way to implement the phone's calling online, and the calling of the phone will be more flexible by configuring the number IP table. For example, user know the other party's number and IP and want to make direct call to the party by point-to-point mode :

the other party's number is 1234 , make a configuration of 1234 directly ,then the phone will send the called number1234 to the corresponding IP address ; Or set numbers with prefix matching pattern , for example, user want to make a call to a number in a certain region ( 010 ) , user can configure the corresponding number IP as 010T—— protocol—— IP , after that, whenever user dial numbers with 010 prefix ( such as 010 - 62201234),the call will be made by this rule.

Bases on this configuration , we can also make the phone use different accounts and run speed calling without swap.

When making deletion or modification, select the number first and click load, then click Modify and complete the operation.

### Dial-Peer

Number	Destination	Port	Alias	Suffix	Del length
--------	-------------	------	-------	--------	------------

---

Phone Number   
 Destination (optional)   
 Port (optional)   
 Alias (optional)   
 Suffix (optional)   
 Delete Length (optional)

Configuration Explanation :

Number	Call Mode	Destination	Port	Alias	Suffix	Del length
0T	lifeline	0.0.0.0	0	no alias	no suffix	0
9T	sip	0.0.0.0	0	no alias	no suffix	0
1T	h323	0.0.0.0	1720	no alias	no suffix	0
8T	sip	255.255.255.255	5060	del	no suffix	1

Display of calling number IP image list ;

Click Add , the following figure will be shown at the lower part of the page, of which :

Phone Number

It is to add outgoing call number, there are two kinds

of outgoing call number setup : One is exactitude matching ,after this configuration has been done, when the number is totally the same with the user's calling number, the phone will make the call with this number's IP address image or configuration; Another is prefix matching ( be equivalent to PSTN's district number prefix function ) ,if the previous N bits of this number are the same with that of the user's calling number(the prefix number length) , then the phone will use this number's IP address image or configuration to make the call. When configuring the prefix matching, letter

"T" should be added behind the prefix number to be distinguished from the exactitude matching; the longest length is 30 bits.

**Call Mode** sip  Configure the calling mode : H323 and SIP ;

**Destination** 192.168.10.11 Configure destination address , if it is point-to-point call , then input the opposite terminal's IP address, it can also be set as domain name and resolved the specific IP address by DNS server of the phone. If no configuration has been made, then the IP will be considered as 0.0.0.0. This is an optional configuration item ;

**Port(optional)**  Configure the other party's protocol signal port, this is optional configuration item : when nothing is input,then the default of h323 protocol is 1720 , the default of sip protocol is 5060 ; lifeline required no configuration of this item, shown as 0 ;

**Alias(optional)**  Configure alias , this is optional configuration item : it is the number to be used when the other party's number has prefix ; when no configuration has been made, shown as no alias ;

**Suffix(optional)**  Configure suffix , this is optional configuration item : it is the additive dial-out number behind the number; when no configuration has been made, shown as no suffix ;

**Delete Length (optional)**  Configure the replacing length, replace the number that user input according to this length ; this is optional configuration item ;

Of which the alias can be divided into four types , it should be combined with replacing length to make the setup :

Add : xxx , add xxx before number. in this way it can help user save the dialing length ;

All :xxx ,the number is all replaced by xxx ;speed dialing can be implemented ,for example, user configure the dialing number as 1, with the configuration "all" , the actual calling number will be

replaced;

Del , delete n bit in the front part of the number,n can be decided by the replacing length ; this configuration can decide the protocol for appointed number ;

Rep : xxx , n bit in the front part of the number will be replaced. n is decided by the replacing length. For example, user want to dial PSTN ( 010 - 62281493 ) by VoIP's voice over service , while actually the called number should be 8610 - 62281493 , then we can configure called number as 010T,then rep :8610 ,and then set the replacing leangth as 3. So that when user make a call with 010 prefix,the number will be replaced as 8610 plus the number and then sent out. It is a convenient thinking mode for user to make a call;

Delete selective number IP image ;

If user want to modify a certain current number image , first select in the drop-down menu and then load the image parameter of the said number, click modify to make modification ; of which :

this is the modified number. read-only ;

To modify call mode ;

To modify destination address ; this is optional configuration item ;

To modify destination phone port ; this is optional configuration item ;

To modify alias ; this is optional configuration item ;

To modify suffix ; this is optional configuration item ;

To modify replacing length ( if rep and del of alias

have been configured )



Click submit to go into effect ; click return to cancel configuration and return.

The basic application of the number IP table has been introduced , now let me introduce how to configure IP table of number to implement configuration of using multi-accounts concurrently :

For example, now user has a H323 account and two SIP accounts, then under the default condition, user can only make calls by the default protocol. Configure the number IP table to select the call protocol , then user don't need to select default protocol before making calls everytime.

The configuration process will not be repeated, now I will mainly introduce what kind of number IP image can implement this function.

By configuration , image table as follows will be gained:

Number	Call Mode	Destination	Port	Alias	Suffix	Del length
9T	sip	0. 0. 0. 0	5060	del	no suffix	1
8T	sip	255. 255. 255. 255	5060	del	no suffix	1
7T	h323	0. 0. 0. 0	1720	del	no suffix	1

Image of 9T means when user configure public SIP server and register , then user just need to add a"9"before the calling number whenever making a call by public SIP ;

Image of 8T means when user configure private private server and register , then user just need to add a"8"before the calling number whenever making a call by private SIP ;

Image of 7T means when user configure h323 server and register , then user just need to add a"7"before the calling number whenever making a call by H323 GK ;

## 4.4 Save and Clear configuration

### 4.4.1 Save configuration

User can save the current configuration on this page.



#### 4.4.2 Clear configuration.

The system configuration can be set as factory default configuration on clear config page and the phone will restart automatically



#### 4.4.3 Configuration looking over

- [Current State](#)
- [Network](#)
- [VOIP](#)
- [Advance](#)
- [DHCP Server](#)
- [NAT](#)
- [Net Service](#)
- [Firewall](#)
- [QOS](#)
- [SIP](#)
- [Digital Map](#)
- [Call Service](#)
- [MMI Filter](#)
- [DSP](#)
- [VPN](#)
- [Dial-peer](#)
- [Config Manage](#)
- [Show Config](#)
- [Save Config](#)
- [Clear Config](#)
- [Update](#)
- [System Manage](#)

```
<>Version:1.000 ITEM:23 Static Ip :192.168.1.179 Static NetMask :255.255.255.0 Static
GateWay :192.168.1.1 Default Protocol :2 Default Lifeline :0 SIP use Lifeline :0 Digital
MapVersion :1 ConfFile Version :1 Primary DNS :202.96.134.133 Alter DNS :202.96.128.68 DHCP Mode :0
Domain Name : Host Name :VOIP Pppoe Mode :0 HTL Start Port :10000 HTL Port Number :200 SNTP Time
Zone :55 SNTP Server :207.46.130.100 Enable SNTP :1 Enable Daylight :0 SNTP Time Out :60 Enable Gk
And Proxy:1 Encrypt Key : ITEM:4 Lan Ip :192.168.10.1 Lan NetMask :255.255.255.0 Bridge Mode :0
Router Priority :1 ITEM:9 Dial End With # :1 Dial Fixed Length :0 Use Dial Timeout :5 H323 Ras
Location :0 Fixed Length :11 Poll Sequence :0 Accept Any Call :1 Phone Prefix : Local Area Code :
Total Number :1*5 Item1 Number :8703273 Item1 Count :1 Item1 Protocol :2 Item1 Type :1 Item1 Alias :
Port1 Max PhoneNum :10 P1 Num1 Index :0 P1 Num2 Index :-1 P1 Num3 Index :-1 P1 Num4 Index :-1 P1 Num5
Index :-1 P1 Num6 Index :-1 P1 Num7 Index :-1 P1 Num8 Index :-1 P1 Num9 Index :-1 P1 Num10 Index :-1
Port1 Config Item :18 No Disturb :0 No Dial Out :0 No Empty Calling :0 Enable CallerId :1 Forward
Service :0 H323 Forward Num : H323 Forward Addr : H323 Forward Port :1720 SIP Forward Num : SIP
Forward Addr : SIP Forward Port :5060 Enable CallWaiting :1 Enable CallTransfer:1 Enable Call3Way :1
Enable AutoAnswer :0 No Answer Time :20 Hotline Number : Fxo Hotline Number : P1 BlackList Num :0 P1
LimitList Num :0 DialPeer Number :0*9 Digital Map Number :0*2 ITEM:5 Signal Standard :1 Handdown
Time :200 G729 Payload Length:1 VAD :0 Ring Type :0 Port1 Config Item :8 Output Volume :7 Input
Volume :3 HandFree Volume :8 RingTone Volume :4 Codec :1 Voice Record :0 Record Playing :1 User
Defined Voice :0 ITEM:48 Register Address :sip99.kiwitalk.com Register Port :5060 Register
User :8703273 Register Password :52315 Register Expire :60 Proxy Address :sip99.kiwitalk.com Proxy
Port :5060 Proxy User :8703273 Proxy Pass :52315 AlterReg Address : AlterReg Port :5060 AlterReg
User : AlterReg Pass : AlterReg Expire :0 AlterProxy Address : AlterProxy Port :5060 AlterProxy
User : AlterProxy Pass : PrivateReg Address : PrivateReg Port :5060 PrivateReg User : PrivateReg
Pass : PrivateReg Expire :60 PrivateProxy Addr : PrivateProxy Port :5060 PrivateProxy User :
PrivateProxy Pass : Local Sip Port :5060 Local Domain :sip99.kiwitalk.com Private Domain : Enable
Regisger :1 Dtmf Mode :0 Enable Stun :0 Enable Private :0 Stun Address : Stun Port :3478 Stun Effect
Time :50 Rfc Version :1 Enable PublicProxy :1 Enable PrivateProxy:0 Public User-Agent :EP310 v1.0
Private User-Agent :EP310 v1.0 Public Server Type :0 Private Server Type:0 Enable ServerDetect:1
Server Detecet Time:60 Server Auto Swap :0 Busy if gw no reg :0 SIP User Password :0*3 ITEM:3 Pppoe
User user123 Pppoe Password password Pppoe Service ANY ITEM:18 Telnet Port :23 Web Port :80 Account 1
Name :admin Account 1 Pass :admin Account 1 Level :10 Account 2 Name :guest Account 2 Pass :guest
Account 2 Level :5 Account 3 Name : Account 3 Pass : Account 3 Level :0 Account 4 Name : Account 4
```

## 4.5. Upgrade on-line

### 4.5.1. Upload WEB page

On this page, user can select the upgrade documents(**firmware or config file**) on hard disk of the computer directly to run the system upgrade. After the upgrade has been completed , restart the phone and it will be usable at once.



### 4.5.2 FTP download

On this page, user can upgrade system and configure files by FTP or TFTP mode.

Configuration Explanation :

**Server**  Configure upload or download FTP/ TFTP server

IP address ;

**Username**  Configure username of the upload or download FTP server. If user select TFTP mode, username and password are not required to be configured ;

**Password**  Configure upload or download of FTP server password ;

**File name**  Configure upload or download system upgrade document or system layout file name. It should be noted that system file take .dlf as suffix , configuration files take .cfg as suffix ;

**Porotocol**  Select server type ;

**Image Update**  Click image update button , the phone will upgrade system file ;

**Config Upload**  Click config upload button , the phone will upload its configuration files to

FTP/TFTP server and save with names of user-defined configuration files ;




Click config download button , the phone will download configuration

files of FTP/TFTP server to the phone and the configuration will go into effect after restarting ;

### 4.5.3. System management.

On this page , user can add and delete users according to own needs and can modify user's authorities there have been.



Configuration Explanation :

User Name	User Level
admin	Root
guest	General

display of phone user account list ;



To add phone account ; it will be shown at lower part of page as the following figure ,

of which :

User name	<input type="text"/>
User level	Root <input type="button" value="v"/>
Password	<input type="text"/>
Confirm	<input type="text"/>

### Add new accounts ;


As account level ; root possesses authorities to modify configuration , general possesses read-only authority ;

as corresponding password of the additive account ;

As second confirmation of password,to ensure correct setup of password ;

Click submit to go into effect ; click return to cancel configuration and return.

 Select users that you want to delete in the drop-down menu , click Delete.

 To modify the chosen accounts , need to select account first , click

load again and then click modify , it will be shown at lower part of page as the following figure, of

which :

User name	admin	The modified username ;
User level	Root	
Password	•••••	Modify user authorities ;
Confirm	•••••	
	<input type="button" value="Return"/> <input type="button" value="Submit"/>	Modify user password ;

Make confirmation of the modified user password ;

Submit or cancel the modification ;

Owing to the phone's default account 'accounts of the administrator level-admin and the ordinary level - guest are all weak account and weak password,the username and password will be easily to be guessed on public network, so the user had better modify the administrator and ordinary user.

Enter with manager level when making modification , create a administrator account and a

#### 4.5.4.2 Telephone book configuration

User can save and configure telephone book

**Phone Book**

---

Index	Name	Number	Address
-------	------	--------	---------

---


Name

Number

Address

#### 4.5.4.3 Syslog configuration

On this page, user can enable or close Syslog function , and configure Syslog server address and port.



Configuration Explanation :


Enable Syslog Configure enable/disable Syslog. Click apply to go into effect after selecting.

Server IP 0.0.0.0 Configure Syslog server IP address ;

Server Port 514 Configure Syslog server port ; click apply and the configuration will go into effect.

#### 4.5.4.3 Time configuration

User can make a setup to acquire time from network.



#### 4.5.4.4 System restart

After certain configurations are made on user's dialogue machine, it needs to be restarted and then go into effect. Enter this page and click reboot, the phone will automatically restart. Please remember to see whether the phone configuration has already saved before restarting , otherwise the configuration after restarting will still be the original one.

## 5. Command line

### 5.1.1 Main frame of the command line

Structure under the root node as follows :

```

IP120 #
--- account
--- config
--- debug
--- download
--- password
--- setdefault
--- show
--- telnet

```

--- time  
--- trancert  
--- update  
--- upload

Major parameters setup of command line are all under the config node , structure of config

node as follows :

```
IP120<config> #  
--- accesslist  
--- dhcpserver  
--- dial-rule  
--- h323  
--- interface  
--- mmifilter  
--- nat  
--- netservice  
--- pbook  
--- port  
--- pppoe  
--- qos  
--- sip  
--- udptunnel  
--- user
```

## 5.1.2 Configuration under Config node

### 5.1.2.1 Accesslist Firewall Configuration

Path : IP120<config-accesslist>#

**Add firewall rules**                    ---entry -I/O xxx -P/D xxx -proto xxx -srcaddr x.x.x.x  
  --srcmask x.x.x.x--desaddr x.x.x.x --desmask x.x.x.x  
  --portrange xxx --portnum xxx

For example: IP120<config-accesslist>#entry -I/O input -P/D deny -proto udp -straddr  
  202.112.10.1 --srcmask 255.255.255.0 --desaddr  
  210.25.132.1 --desmask 255.255.255.0 --portrange neq  
  --portnum 5060

**Delete firewall rules**                ---no entry -I/O xxx -index xxx

For example: IP120<config-accesslist>#no entry -I/O input -index 1

**Check firewall setup**                ---show

**[Disable] enable in-access filters**    ---[no]in-access

**[Disable] enable out-access Filter**    ---[no]out-access

### 5.1.2.2 DHCP-Server DHCP service configuration

Path : IP120<config-dhcp>#

**Add DHCP rules**                    ---entry -name xxx -startip x.x.x.x -endip x.x.x.x -netmask  
  x.x.x.x -gateway x.x.x.x -dnsserver x.x.x.x \_time xxx

For example: IP120<config-dhcp>#entry -name lan2004 -startip 192.168.1.2 -endip  
  192.168.1.254 -netmask 255.255.255.0 -gateway  
  192.168.1.1 -dnsserver 192.168.10.18

**Delete DHCP rules**                ---no entry -name xxx

For example: IP120<config-dhcp>#no entry -name lan2004

**Check DHCP setup**                 ---show

**[Disable] enable DNS-relay**       ---[no] dns-relay

### 5.1.2.3 Dial-Rule configuration

Path : IP120<config-dialrule>#

**Set the fixed length to end**       ---fixlen xxx

**No fixed length to end**            ---no fixlen

**Set to send numbers after time out**       ---timeout-send xxx

**No timeout-send**                   ---no timeout-send

**[Disable] use of h323 RAS location**       ---[no] h323-location

**Add user-defined dial rule**        ---entry -prefix xxx -length xxx

For example:IP120<config-dialrule>#entry -prefix 010 -length 11

**Delete user-defined dial rule**        ---no entry -prfix xxx

For example:IP120<config-dialrule>#no entry -prefix 010

**Show current dial-rule config**        ---show

### 5.1.2.4 Interface-Fastethernet-Lan Local area network(LAN) parameter configuration

Path : IP120<config-interface-fastethernet-lan>#

**[Disable] bridging mode**            ---[no]bridgemode

**[Disable] enable DHCP service**        ---[no]dhcp-server

**Show DHCP current rules:**            ---dhcpshow

**Show IP address of LAN:**            ---ipshow

**Show NAT information:**               ---natshow

**Change IP address of LAN**            --ip -addr x.x.x.x -mask x.x.x.x

For example: IP120<config-interface-fastethernet-lan>#ip -addr 192.168.1.10 -mask  
255.255.255.0

※When the phone is transfers data by NAT, don't use natshow command to view , otherwise it will result in system's temporary zero response.

※Enable bridge mode ,LAN configuration will be disabled, user is unable to access network by NAT of the phone.

### 5.1.2.5 Interface-Fastethernet-Wan wide area network parameter configuration

Path : IP120<config - interface - fastethernet - wan>#

[Disable] enable dhcp client-side service ---[no]dhcp  
[Disable] enable pppoe ---[no]pppoe  
[Disable] enable QOS ---[no]qos  
IP configuration of the phone ---gateway x.x.x.x  
Clear IP configuration of the phone ---no gateway  
IP address configuration ---ip -address x.x.x.x -mask x.x.x.x  
For example:IP120<config-interface-fastethernet-wan>#ip -addr 202.112.241.100 \_mask 255.255.255.0

Note : after changing the IP, telnet new IP again because IP has been changed.

Show wide area network configuration: ---show

### 5.1.2.6 MMI FILTER (man-machine interface filter)

Path : IP120<config-mmifilter>#

Add filter rule ---entry -start x.x.x.x -end x.x.x.x  
For example:IP120<config-mmifilter>#entry -start 202.112.20.1 -end 202.112.20.255  
Delete filter rule ---no entry -start x.x.x.x  
For example:IP120<config-mmifilter>#no entry -start 202.112.20.1  
Check filter rule ---show  
[Disable] enable man-machine interface filter parameter configuration ---[no]start-filter

### 3.3.8 NAT

Path : IP120<config - nat>#

[Disable] enable ftp alg ---[no]ftpalg  
[Disable] enable ipsec alg ---[no]ipsecalg  
[Disable] enable pptp alg ---[no]pptpalg  
Add TCP rule ---tcp-entry -ip x.x.x.x -lanport xxx -wanport xxx  
For example:IP120<config-nat>#tcp-entry -ip 192.168.1.5 -lanport 1720 -wanport 1000  
Delete TCP rule ---no entry -ip x.x.x.x -lanport xxx -wanport xxx  
For example:IP120<config-nat>#no tcp-entry -ip 192.168.1.5 -lanport 5060 -wanport 1000  
Add UDP rule ---udp-entry -ip x.x.x.x -lanport xxx -wanport xxx  
Delete UDP rule ---no udp-entry -ip x.x.x.x -lanport xxx -wanport xxx  
Check NAT configuration ---show



to dial 34)

**Add number IP binding rule and replace part of the numbers in the front of the number**

---entry -number xxx -ip x.x.x.x -protocol xxx \_rep xxx  
\_length xxx

For example:IP120<config-pbook>#entry -number 1234 -ip 202.112.20.100 -protocol sip \_rep  
567 \_length 2(in this way when user dial 100,it will be  
equivalent to dial 56734)

**Delete number binding rule** ---no entry -number xxx

**Check current number binding rule** ---show

**Current default VOIP protocol configuration** ---default-protocol xxx

**5.1.2.9 Port configuration**

If entering "port" under the "config" node , then the configuration will go into effect for all  
ports , if entering " port X" , then the configuration will only into effect for X port ( X represents a  
certain port number ) , but some functions will not go into effect for all ports , so user must enter"  
port X" when configuring, otherwise it is shown as" Error : Missing parameter ".

Path : IP120<config - port># or IP120<config - X>#

**Set accept relay mode** ---accept-relay xxx

**Set caller ID mode** ---callerid xxx

**No caller ID** ---no callerid

**Call forwarding configuration** ---callforward -conditon xxx -number  
xxx -ip xxx -port xxx -protocol xxx

For example:IP120<config-port 0>#callforward -condition busy -number 100 -ip 202.112.10.100  
-port 5060 -protocol sip

**Disable call forwarding** ---no callforward

**[Disable] enable call transfer (CT)** ---[no]calltransfer

Note :after  call transfer function is enabled ,user make hooking operation to implement transfer  
after starting the phone call.

**[Disable] enable call waiting** ---[no]callwaiting

**DSP priority encoding mode configuration** ---codec xxx

**Set DTMF port volume** ---dtmfvolume xxx

**set fastcalled number** --- fastcalled xxx

**No fast called number (FXO)** ---no fastcalled

**Show fast called number (FXO)** ---fastcalled

**Set fast calling number(FXS)** --- fastcalling xxx

**No fast calling number (FXS)** ---no fastcalling

**Show fast calling number ( FXS )** ---fastcalling

**[Disable] enable FAX ECM** ---[no]faxecm

**Fax mode configuration** --- faxmode xxx



destination-prefix -number xxx+T

For example:IP120<config-port >#private no destination-prefix 1000T

**Add [delete] the matching numbers of the public server FXS** ---public

[no]destination-pattern - number xxx \_protocol

**Add outgoing call number to the public server FXO** --- public destination-prefix -

number xxx+T \_protocol

**Add the outgoing call number to the public server FXO and set suffix**

--- public destination-prefix -number xxx+T \_suffix  
xxx

**Add the outgoing call number to the public server FXO and set prefix**

--- public destination-prefix -number xxx+T -prefix  
xxx

**Delete the matching outgoing call number of public server** --- public no

destination-prefix -number xxx+T

**[Disable] enable outgoing call** ---[no]shutdown out

**[Disable] enable outgoing call** ---[no]shutdown in

**[Disable] enable outgoing call and outgoing call** ---[no]shutdown

**[Disable] enable three way call** ---[no]threetalk

Note : after the three-way-call function is enabled , user make hooking operation and then press \*

key to implement this function. For example, user A call user B , after the phone call starts, A

makes hooking operation to hold B, and then presses \* key to receive dialing tone , and then call

user C , after starting the phone call with C, A makes hooking operation again and recover the call

with B,in this way, A, B and C can begin the three-way-call.

**Set Tone Type** ---tontype xxx

**Check port configuration** ---show

### 5.1.2.10 PPPOE configuration

Path : IP120<config - pppoe>#

**PPPOE username, password configuration** ---auth -user xxx -password xxx

For example:IP120<config-pppoe>#auth -user aaa -password 123456

**[Disable] PPPOE service** ---[no]service xxx

**Show PPPOE parameters configuration** ---show

### 5.1.2.11 QOS configuration

Path : IP120<config - qos>#

**[Delete] add network address of 802.1p configuration list** --- [no]entry -addr x.x.x.x -mask x.x.x.x

For example:IP120<config-qos>#entry -addr 202.112.10.1 -mask 255.255.255.0

**[Exclude] include QOS list** ---[no]include

**Show all 802.1p priority guarantee configuration** ---show

Note : after the "qos" is enabled acquiescently, the system will add qos acquiescently to all sending-out "rtp" packages , when user configure "qos table" and "include" , the system only sends voice packets with "qos" to the "ip" included in the table, and those of "no include" will be sent to the "ip" which is not included in the " qos table".

### 5.1.2.12 SIP configuration

Path : IP120<config - sip>#

**[Disable] enable register to SIP** ---[no] register

**[Disable] enable automatic detection server** ---[no] detect-server

**Set DTMF mode** ---dtmf-mode xxx

**Set detection interval time** ---interval-time xxx

**Set RFC edition** ---rfc-version xxx

**Disable [enable] auto-swap server** [no]swap-server

**Set passwords to phone numbers of the ports** ---number-password -number xxx  
-password xxx

**SIP signal port configuration** --- signalport xxx

**SIP Proxy parameters configuration** ---server proxy -ip x.x.x.x \_port xxx  
\_user xxx \_password xxx

For example:IP120<config-sip-server># proxy ip 210.25.23.22 \_port 5060 \_user aaa \_password 123456

**SIP Register server parameters configuration** ---server register -ip x.x.x.x  
\_port xxx -user xxx \_password xxx

**Alternate-proxy-server setup** ---alter-server proxy -ip x.x.x.x \_port xxx \_user  
xxx \_password xxx

**Alternate-register-server setup** ---alter-server register -ip x.x.x.x \_port xxx  
\_user xxx \_password xxx

**[Disable] enable stun server** ---stun [no]enable

**Set stun server detection interval time** ---stun interval-time xxx

**Set the stun server address and port** ---stun -ip x.x.x.x -port xxx

**Show all current relevant SIP parameters configuration** ---show

Note : private server and public server have the same configuration , changing the configuration under "server" into private-register and private-proxy will do.



<b>[Disable] enable sntp</b>	---sntp [no] start
<b>Set the address of sntp server</b>	---sntp server x.x.x.x
<b>Set the effective time of sntp</b>	---sntp timeout xxx
<b>Set the sntp time zone</b>	---sntp zone xxx
<b>View sntp information</b>	---sntp show
<b>View current time</b>	---print

### 5.2.3. System upgrading command

Path : IP120#

**Upgrade application program by FTP**                    ---update ftp -user xxx -password xxx -ip  
x.x.x.x -file xxx

For example: IP120# update ftp -user abc -password 123 -ip 202.112.20.15 -file abc.dlf

**Upgrade application program by TFTP**                    ---update tftp -ip x.x.x.x -file xxx

**Upload configuration files by FTP**                    ---upload ftp -user xxx -password xxx -ip  
x.x.x.x

-file xxx

**Upload configuration files by TFTP**                    ---upload tftp -ip x.x.x.x -file xxx

**Download configuration files by FTP**                    ---download ftp -user xxx -password xxx  
-ip x.x.x.x -file xxx

**Download configuration files by TFTP**                    ---download tftp -ip x.x.x.x -file xxx

### 5.2.4 Other command

Path : IP120#

**Set all module debug level**                    ---debug all xxx

**Set app module debug level**                    ---debug app xxx

**Set cdr module debug level**                    ---debug cdr xxx

**Set sip module debug level**                    ---debug sip xxx

**Set h323 module debug level**                    ---debug h323 xxx

**Set tel module debug level**                    ---debug tel xxx

**Set dsp module debug level**                    ---debug dsp xxx

**Close all modulars debug**                    ---debug no all

**Close app modulars debug**                    ---debug no app

**Close cdr modulars debug level**                    ---debug no cdr

**Close sip modulars debug level**                    ---debug no sip

**Close h323 modulars debuglevel**                    ---debug no h323

**Close tel modulars debug level**                    ---debug no tel

**Close dsp modulars debug level**                    ---debug no dsp

**Recover the factory default setting**                    ---setdefault

**Recover all modules to the factory default setting**                    ---setdefault all

**Show a certain module information**                    ---show xxx

**Active user update password**                    --- password

<b>Telnet rlogin</b>	---	telnet x.x.x.x	
<b>Telnet by specific port</b>	---	telnet x.x.x.x -port xxx	
<b>Logout command for Telnet user</b>	---	logout	
<b>Switch to Chinese help</b>	---	chinese	
<b>Switch to English help</b>	---	english	
<b>Save configuration</b>	---	write	
<b>Restart</b>	---	reload	
<b>View help</b>	---	help	
<b>Exit current node</b>	---	exit	
<b>Clear screen</b>	---	clear	
<b>PING remote terminal host computer</b>	---	ping x.x.x.x	
<b>Broadcast to all CLI users</b>	---	broadcast xxx	
<b>show system history record</b>	---	history	
<b>Terminal parameter settings</b>	---	stty row xxx or stty columns xxx	
<b>Send message to appointed users</b>	---	sendmsg	
<b>Show current login users</b>	---	who	
<b>Trace command</b>	---	tracert x.x.x.x	
<b>Add alias</b>	---	alias xxx xxx	
<b>Execute a document</b>	---	exec xxx	
<b>Echo input</b>	---	echo xxx	

- ※ After recovery of default configuration , restart system directly without saving the configuration.
- ※ Technicians or administrator can know in more detail about information of the system by "debug" message. Debug message is divided into 0-7 level , technicians can open messages of different levels as required.