




myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for MIELE G 880 DISHWASHER. You'll find the answers to all your questions on the MIELE G 880 DISHWASHER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MIELE G 880 DISHWASHER
User guide MIELE G 880 DISHWASHER
Operating instructions MIELE G 880 DISHWASHER
Instructions for use MIELE G 880 DISHWASHER
Instruction manual MIELE G 880 DISHWASHER

Miele

Operating instructions



for the G880
dishwasher

To prevent accidents and reduce
the risk of damaging the machine,
read the Operating Manual
before installing or using
the machine.



M.-Nr. 04 873 731



[Your user manual](#)
[MIELE G 880 DISHWASHER](#)

Manual abstract:

Four height adjustable levelling legs 9. Combination filter 6 10. Salt reservoir 11. Dual compartment detergent dispenser 12. Rinse aid reservoir (with dosage selector) 13. Data plate Note: Lower basket is not shown. Guide to the appliance Control panel 14. On/Off button 15. Door release 16. Child safety lock 17.

"Top Solo" button 18. "Check" indicator lamps 19. Program sequence display 20. Program and temperature selector knob 7 **IMPORTANT SAFETY INSTRUCTIONS** Repairs should only be performed **WARNING** by qualified personnel. Disconnect When using your dishwasher, follow all basic safety precautions.

This appliance conforms to all uniform safety codes and regulations. To avoid injury and machine damage, read the operating instructions carefully before using the dishwasher. This dishwasher is designed for household use only. The manufacturer cannot be held responsible for damage or injury caused by improper use or for uses other than those for which the appliance is intended. the appliance from the power supply before servicing (pull out the plug or turn off the circuit breaker).

If not purchased specifically as a "Freestanding" model, only install the dishwasher under a continuous countertop which is secured to the cabinetry. The dishwasher must be electrically grounded. Install the dishwasher as per the included Installation instructions. Use only powder detergents and liquid rinse aids recommended for dishwashers. Never use gels or liquid detergents. Do not use commercial or industrial grade detergents, as these may cause adverse chemical reactions and damage the machine. Use only detergents made for residential dishwashers. Do not use your dishwasher unless all enclosure panels are properly in place. Do not allow children to play in or on the dishwasher. Keep all detergents and rinse aids out of the reach of children.

Dishwasher detergents contain Sodium Silicate and Sodium Carbonate. In case of eye contact, immediately flush with water. Call a physician or poison control. Do not tamper with the controls. 8 **IMPORTANT SAFETY INSTRUCTIONS** When loading items to be washed: Load pointed items so that they are not likely to damage the door seal. Load knives with the cutting edge down to reduce the risk of injuries. Do not wash plastic items unless they are labeled "dishwasher safe" or the equivalent. For items not labeled, check the manufacturer's recommendations. Do not abuse, sit, or stand on the door or dishracks of the dishwasher. Remove the front door and cut off the power cord of the dishwasher before removing it from service or discarding it.

This will help protect children from injury or accidentally locking themselves in. Under certain conditions, hydrogen gas may be produced in a hot water system that has not been used for two weeks or more. **HYDROGEN GAS IS EXPLOSIVE**. If the hot water system has not been used for such a period, turn on all hot water faucets and let the water flow from each for several minutes before using the dishwasher. This will release any accumulated hydrogen gas. Do not smoke or use an open flame during this time. Do not drink the water from the wash cabinet. For dishwashers with visible heating element Do not touch the heating element during or immediately after use. **SAVE THESE INSTRUCTIONS 9 INSTRUCTIONS IMPORTANTES SUR LA SÉCURITÉ** **AVERTISSEMENT** Au moment d'utiliser votre lave-vaisselle, veuillez observer toutes les mesures de sécurité de base. Cet appareil électroménager est conforme à tous les règlements et codes sur la sécurité.

Pour éviter de vous blesser et d'endommager l'appareil, veuillez lire soigneusement les instructions sur l'utilisation. N'utilisez le lave-vaisselle que pour laver la vaisselle. Le fabricant ne peut être tenu responsable des dommages ou blessures causés par une utilisation inadéquate ou par des utilisations autres que celles auxquelles l'appareil est destiné. Les réparations doivent être effectuées uniquement par une personne compétente. Débrancher l'appareil de la prise de courant avant d'en faire l'entretien (enlever la fiche de la prise ou fermer le disjoncteur). Installer uniquement le lave-vaisselle sous un comptoir continu qui est fixé à des meubles adjacents. Vous devez mettre le lave-vaisselle à la terre. Installer le lave-vaisselle en observant les instructions pour l'installation ci-jointes..



[Your user manual](#)
[MIELE G 880 DISHWASHER](#)