

## 50W RMS/100W Max. Powerhorn

### Mounting

Remove the powerhorn's mounting base and use as a template.

1. Loosen the wing nut and slide off the base.
2. Attach the base to the mounting location and fix with three screws (appropriate to surface) and nuts (screws and nuts not supplied).
3. Place the powerhorn back onto its base.
4. Adjust the powerhorn to the desired angle, then secure the speaker in place with the wing nut.

### Caution:

- Set the powerhorn speaker slightly downward to prevent water collecting inside.
- Mount the powerhorn away from heat sources.

### Connecting

Your powerhorn is designed for connection to an amplifier with an impedance of 8 ohm.

1. Connect the powerhorn's black wire to the amplifier's negative (-) speaker terminal.
2. Connect the powerhorn's white wire to the amplifier's positive (+) speaker terminal.

Thank you for purchasing your 50W RMS/100W Max. Powerhorn from RadioShack. Please read this user's guide before installing, setting up, and using your new powerhorn.

### What's Included

Powerhorn

User's Guide

### Specifications

Impedance (Nominal).....	8 Ohms
Frequency Response .....	350 ~ 9,000 Hz
Output .....	110 dB
Power Handling .....	50 Watts (RMS)
Maximum Power Handling .....	100 Watts
Dispersion .....	90° x 20° (2000 Hz)
Dimensions (H×W×D) .....	11 × 6½ × 8½ in
.....	(28 × 17 × 22 cm)
Net Weight.....	3.1 lbs (1.4 kg)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

### Limited Warranty

This product is warranted by **RadioShack** against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from **RadioShack** company-owned stores and authorized **RadioShack** franchisees and dealers. EXCEPT AS PROVIDED HEREIN, **RadioShack** MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, **RadioShack** SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF **RadioShack** HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. In the event of a product defect during the warranty period, take the product and the **RadioShack** sales receipt as proof of purchase date to any **RadioShack** store. **RadioShack** will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of **RadioShack**. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a **RadioShack** Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**RadioShack** Customer Relations  
300 RadioShack Circle, Fort Worth, TX 76102

12/99

[www.radioshack.com](http://www.radioshack.com)



Protect the environment by recycling used electronics. Go to [www.ecyclingcentral.com](http://www.ecyclingcentral.com) to find a recycle location near you.

