

# HP StorageWorks XP24000/XP20000 External Storage Software User Guide

## Abstract

This guide describes how to connect and map external storage to HP StorageWorks XP24000/XP20000 storage systems. Topics include instructions for setting ports and paths, mapping volumes, maintaining connections, using spreadsheets to map external volumes, and mapping remote command devices. The intended audience is a storage system administrator or authorized service provider with independent knowledge of HP StorageWorks XP storage systems and HP StorageWorks Remote Web Console.



© Copyright 2007, 2011 Hewlett-Packard Development Company, L.P.

Confidential computer software. Valid license from HP required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

### Acknowledgments

Microsoft, Windows, and Windows XP are U.S. registered trademarks of Microsoft Corporation.

Hitachi and Universal Replicator are registered trademarks of Hitachi, Ltd.

ShadowImage and TrueCopy are registered trademarks of Hitachi, Ltd. and Hitachi Data Systems Corporation.

### Export Requirements

You may not export or re-export this document or any copy or adaptation in violation of export laws or regulations.

Without limiting the foregoing, this document may not be exported, re-exported, transferred or downloaded to or within (or to a national resident of) countries under U.S. economic embargo, including Cuba, Iran, North Korea, Sudan, and Syria. This list is subject to change.

This document may not be exported, re-exported, transferred, or downloaded to persons or entities listed on the U.S. Department of Commerce Denied Persons List, Entity List of proliferation concern or on any U.S. Treasury Department Designated Nationals exclusion list, or to parties directly or indirectly involved in the development or production of nuclear, chemical, biological weapons, or in missile technology programs as specified in the U.S. Export Administration Regulations (15 CFR 744).

### Revision History

Edition	Date	Description
First	June 2007	This edition applies to microcode version 60-01-31-00/00 or later.
Second	September 2007	This edition applies to microcode version 60-01-68-00/00 or later.
Third	November 2007	This edition applies to microcode version 60-02-04-00/00 or later.
Fourth	January 2008	This edition applies to microcode version 60-02-25-00/00 or later.
Fifth	April 2008	This edition applies to microcode version 60-02-48-00/00 or later.
Sixth	June 2008	This edition applies to microcode version 60-03-04-00/00 or later.
Seventh	September 2008	This edition applies to microcode version 60-03-24-00/00 or later.
Eighth	December 2008	This edition applies to microcode version 60-04-04-00/00 or later.
Ninth	February 2009	This edition applies to microcode version 60-04-13-00/00 or later.
Tenth	June 2009	This edition applies to microcode version 60-05-00-00/00 or later.
Eleventh	August 2009	This edition applies to microcode version 60-05-00-00/00 or later.
Twelfth	December 2009	This edition applies to microcode version 60-06-05-00/00 or later.
Thirteenth	June 2010	This edition applies to microcode version 60-07-00-00/00 or later.
Fourteenth	October 2010	This edition applies to microcode version 60-07-50-00/00 or later.
Fifteenth	May 2011	This edition applies to microcode version 60-08-01-00/00 or later.

---

# Contents

1 Overview of HP StorageWorks XP External Storage Software.....	9
XP External Storage.....	9
Unifying Copy Operations between Different Storage Systems.....	9
Unifying Connections from a Host to Different Storage Systems.....	10
2 About XP External Storage Operations.....	12
Connecting External Storage Systems.....	12
XP External Storage Components.....	13
Storage Systems and Cross-subsystem Paths.....	14
Volumes and Mapping Paths.....	14
XP External Storage Operations.....	15
Configuring XP External Storage.....	16
Choosing the External Port.....	16
Choosing and Mapping External Volumes.....	16
Registering a Volume to an External Volume Group (ExG).....	17
Configuring External Volume Attributes.....	17
Cross-subsystem Paths.....	18
Path Mode.....	19
Examples of Alternate Paths.....	19
Examples of Switching I/O Execution Paths to Alternate Paths.....	21
Connecting Mainframe Volumes.....	25
Connecting Open Systems Volumes.....	26
Choosing Mapping Policy.....	26
Difference between Automatic Mapping and Manual Mapping.....	26
Port Discovery and Volume Discovery.....	26
Using a Mapped External Volume from a Connected Host.....	27
Storing New Data in the Mapped External Volume.....	27
Using Existing Data in the Mapped External Volume.....	28
Interoperability with other Products and Functions.....	29
LUN Manager and Configuration File Loader.....	29
LUN Expansion (LUSE).....	29
Virtual LVI/LUN (VLL).....	30
Cache Residency Manager.....	30
Performance Monitor and XP Auto LUN.....	30
XP Continuous Access and Hitachi TrueCopy™ for Mainframe.....	30
HP StorageWorks XP Continuous Access Journal Software and Hitachi Universal Replicator™ for Mainframe.....	30
HP StorageWorks XP Business Copy Software and Hitachi ShadowImage™ for Mainframe.....	30
HP StorageWorks XP Snapshot Software.....	31
HP StorageWorks XP Thin Provisioning Software.....	31
SNMP Agent.....	31
Examples of Using External Volumes with Other Products.....	31
XP Auto LUN Operations.....	31
XP Continuous Access Operations.....	32
XP Continuous Access Journal Operations.....	33
XP Business Copy Operations.....	35
XP Snapshot Operations.....	36

<b>3 Preparing for XP External Storage Operations.....</b>	<b>37</b>
System Requirements.....	37
Storage Systems Supported as External Storage Systems.....	37
XP External Storage Requirements.....	37
Guidelines for XP External Storage Operations.....	38
Mapping Guidelines.....	38
Recommended Applications According to HDD Type.....	39
Capacity Guidelines.....	40
Guidelines for Mainframe Volumes.....	41
Volume Attribute Guidelines.....	41
Creating LUSE Volume Guidelines.....	42
Maintenance Guidelines for an External Storage System.....	43
Performance and Status Guidelines.....	43
RAID Level Considerations.....	43
AMS 2000 Series Guidelines.....	43
Installing and Uninstalling XP External Storage.....	44
Installing XP External Storage.....	44
Uninstalling XP External Storage.....	44
Starting XP External Storage.....	45
<b>4 Using the XP External Storage GUI.....</b>	<b>46</b>
Volume Operation Window.....	46
Volume Operation Tree.....	49
Volume Operation List (When Subsystem or Product Name is Clicked).....	50
Volume Operation List (When Path Group is Clicked).....	51
Preview Dialog Box.....	54
Path Operation Window.....	55
Path Operation Tree.....	58
Path Operation List (When Subsystem is Clicked).....	58
Path Operation List (When Product Name is Clicked).....	60
Path Operation List (When Port or WWN is Clicked).....	60
Port Operation Window.....	61
Port Operation Tree.....	63
Port Information List.....	63
<b>5 Performing XP External Storage Operations.....</b>	<b>65</b>
Overview of Setting Operations.....	65
Setting Port of External Storage System.....	66
Setting Port Attribute for Local Storage System.....	67
Mapping an External Volume Automatically.....	67
Mapping an External Volume Manually.....	68
Add Volume Dialog Box.....	70
Set External Volume Parameter Dialog Box.....	72
LDEV Mapping (Auto) Dialog Box.....	73
LDEV Mapping (Manual) Dialog Box.....	74
SSID Dialog Box.....	75
Example: How to Map LDEVs Automatically.....	77
Example: How to Map LDEVs Manually.....	77
Setting the Cross-subsystem Paths.....	78
Configure Cross-subsystem Paths Dialog Box.....	79
Configuring the Cross-subsystem Path.....	81
Changing the Configured Cross-subsystem Path Priority.....	82
Canceling the Cross-subsystem Path Configuration.....	83

Changing the Cross-subsystem Path.....	83
Replacing All Cross-subsystem Paths with Newly Added Cross-subsystem Paths.....	83
Checking the External Volume Details.....	85
LDEV Information Dialog Box.....	85
Mapping Path Information Dialog Box.....	86
Turning On or Off the Storage System.....	88
Commands for Turning On or Off Only the External Storage System.....	88
Turning On or Off Only the External Storage System.....	89
Turning On or Off Only the Local Storage System.....	89
Turning On or Off Both Storage Systems.....	90
Disconnecting External Storage System or Disconnecting External Volume.....	91
Disconnecting All External Volumes (Disconnect Subsystem).....	92
Disconnecting an Individual External Volume (Disconnect Volume Operation).....	92
Checking Connection Status and Resuming External Volume Operation.....	93
Resuming All External Volumes (Check Paths & Restore Volume).....	93
Resuming an Individual External Volume (Check Paths & Restore Volume Operation).....	94
Stopping the Use of Paths to the External Volume (Disconnect Paths).....	94
Restoring the Paths to the External Volume (Check Paths).....	95
Changing the Cache Mode Setting of the External Volume.....	95
Changing the Inflow Control Setting of the External Volume.....	96
Changing the Port Setting of the External Storage System.....	97
Change WWN Parameter Dialog Box.....	97
Performing Maintenance for External Subsystem.....	98
Editing Mapping Policy.....	98
Edit Policy Dialog Box.....	98
Deleting the External Volume Mapping (Delete Volume Command).....	99

## 6 Using Spreadsheets for XP External Storage Operations..... 101

Introduction.....	101
Before Using Spreadsheets.....	102
Available Types and Operation Tags.....	102
Saving Storage System Information.....	103
SSID Tag.....	103
ExternalGroup Tag.....	104
MappedVolume Tag.....	104
Mapping External Volumes.....	106
AddVolumeSetting Tag.....	106
How to Specify the LDEV Capacity.....	110
AddVolumeSetting2 Tag.....	111
Disconnecting an Individual External Volume (DisconnectVolume Tag).....	114
Resuming an Individual External Volume (CheckPath-RestoreVolume Tag).....	114
Deleting the External Volume Mapping (DeleteVolume Tag).....	115
Changing Path Group.....	115
DividePathGroup Tag.....	115
UnitePathGroup Tag.....	116
Example of a Spreadsheet.....	117

## 7 Remote Command Devices..... 119

Overview of Remote Command Devices.....	119
Guidelines for Remote Command Devices.....	120
Mapping a Command Device as a Remote Command Device.....	122
Using XP Continuous Access or XP Continuous Access Journal with Remote Command Device.....	122
Procedure to Use Initiator/External MIX Mode.....	124

Restrictions on Initiator/External MIX Mode.....	125
<b>8 Troubleshooting.....</b>	<b>126</b>
Troubleshooting for XP External Storage.....	126
Troubleshooting the Mapping Path.....	127
Troubleshooting Volume Discovery.....	130
Calling HP Technical Support.....	131
<b>9 Support and Other Resources.....</b>	<b>132</b>
Related Documentation.....	132
Conventions for Storage Capacity Values.....	132
HP Technical Support.....	132
Subscription Service.....	133
HP Websites.....	133
Documentation Feedback.....	133
<b>A Connecting External Storage Systems.....</b>	<b>134</b>
AMS/WMS Storage System.....	134
System Parameters.....	134
Relationship between the Serial Number and the AMS/WMS Model.....	135
Relationship between the WWN of the Port and Controller (AMS/WMS).....	135
Path Status and Examples of the Recovery Procedure (AMS/WMS).....	136
P9500 Disk Array.....	137
Path status and examples of recovery procedure.....	137
Notes on Using the Power Savings Option (AMS/WMS).....	138
Thunder 9500V Storage System.....	138
System Parameters.....	138
Relationship between the Serial Number and Thunder 9500V Model.....	140
Relationship between the WWN of the Port and Controller.....	140
Path Status and Examples of the Recovery Procedure.....	140
USP V/VM Storage System.....	141
Path Status and Examples of the Recovery Procedure.....	141
TagmaStore USP/NSC Storage System.....	142
Setting the Host Mode Option for a Volume Larger Than 2 TB (USP/NSC).....	142
Path Status and Examples of the Recovery Procedure.....	142
Lightning 9900V Storage System.....	143
Path Status and Examples of the Recovery Procedure.....	143
Lightning 9900 Storage System.....	144
Path Status and Examples of the Recovery Procedure.....	144
SVS200 Storage System.....	145
Path Status and Examples of the Recovery Procedure.....	145
HP StorageWorks EVA Storage System.....	146
System Parameters.....	146
Identifying Logical Volumes (Using Characteristic2).....	146
Behavior of the Alternate Path.....	147
Sun StorEdge 6120/6320.....	147
Sun StorageTek Flexline 380.....	147
Sun StorageTek 2540.....	148
Sun StorageTek V2X2.....	148
EMC CLARiiON CX Series.....	148
Notes on Connecting an EMC CLARiiON CX Series.....	148
System Option mode.....	149
EMC Symmetrix Series.....	149

IBM DS3000/DS4000/DS5000 Series.....	150
System Parameter for Connecting IBM SVC Series.....	150
Notes on Connecting IBM XIV Series.....	150
Fujitsu FibreCAT CX Series.....	151
System Option mode.....	151
System Parameter for Connecting Fujitsu FibreCAT CX Series.....	151
Notes on Connecting Fujitsu FibreCAT CX Series.....	151
SGI IS4600 Series.....	151
Non-HP Storage Systems.....	151
<b>B Required Volume Capacity for Each Emulation Type.....</b>	<b>152</b>
Determining Required External Volume Capacity.....	152
Capacity List for Each Emulation Type.....	153
<b>C Adjusting the Volume Capacities for Pairs.....</b>	<b>156</b>
<b>D The ExPath Tool.....</b>	<b>158</b>
Overview of the ExPath Tool.....	158
Preparing for Using the ExPath Tool.....	158
Installing the ExPath Tool.....	159
Uninstalling the ExPath Tool.....	159
Upgrading the ExPath Tool.....	159
Using the ExPath Tool.....	159
Creating an Authentication File.....	160
Syntax.....	160
Parameters.....	160
Examples.....	160
Editing the Java Security Policy.....	160
Creating a Command File.....	160
Running the ExPath Tool.....	161
Syntax.....	161
Parameters.....	161
Example.....	161
Termination Code.....	161
Command Reference.....	162
svpip Command.....	162
Syntax.....	162
Description.....	162
Parameters.....	162
Example.....	162
login Command.....	163
Syntax.....	163
Description.....	163
Parameters.....	163
Example.....	163
disconnect Command.....	163
Syntax.....	163
Description.....	163
Parameters.....	163
Example.....	163
checkpath Command.....	164
Syntax.....	164
Description.....	164

Parameters.....	164
Example.....	164
checkstatus Command.....	164
Syntax.....	164
Description.....	164
Parameters.....	164
Example.....	164
Termination Code.....	165

Glossary.....	167
---------------	-----

Index.....	169
------------	-----



---

# 1 Overview of HP StorageWorks XP External Storage Software

This chapter provides an overview of XP External Storage.

- [“XP External Storage” \(page 9\)](#)
- [“Unifying Copy Operations between Different Storage Systems” \(page 9\)](#)
- [“Unifying Connections from a Host to Different Storage Systems” \(page 10\)](#)

Unless otherwise specified, the term *storage system* in this document refers to the following disk arrays:

- HP StorageWorks XP24000 Disk Array
- HP StorageWorks XP20000 Disk Array

The GUI illustrations in this guide were created using a Windows computer with the Internet Explorer browser. Actual windows may differ depending on the operating system and browser used. GUI contents also vary with licensed program products, storage system models, and firmware versions.

## XP External Storage

XP External Storage provides the virtualization of a multi-tiered storage area network comprised of heterogeneous storage systems. It enables the operation of multiple storage systems connected to an HP XP storage system as if they were all one storage system and provides common management tools and software. The shared storage capacity comprised of external storage volumes can be used with storage system-based software for data migration and replication, as well as any host-based application. Combined with HP StorageWorks XP Auto LUN Software, XP External Storage provides a data lifecycle management solution across multiple tiers of storage.

The key features and benefits of XP External Storage include:

- Virtualizes external storage attached to the XP storage system
- Enables deployment of multi-tiered storage
- Integrates heterogeneous systems
- Creates extended storage capacity independent of physical location
- Creates new opportunities based on enhanced capability of existing business continuity software and management tools to manage external storage devices

## Unifying Copy Operations between Different Storage Systems


When you copy data between different storage systems, the copy operations are usually different depending on the storage system that you use.

If you install XP External Storage, you can perform the following copy operations in the same way as when you copy data between volumes in the XP storage system.



- To copy data between a volume in the XP storage system and a volume in an external storage system.
- To copy data between a volume in an external storage system and a volume in another external storage system.

**Figure 1 Unifying Copy Operations between Different Storage Systems**

Without XP External Storage, different copy operations are required.



XP External Storage allows you to perform all copy operations in the same way.




## Unifying Connections from a Host to Different Storage Systems

When a system has multiple storage systems, a host usually needs to connect all storage systems. When a system administrator configures the connections from a host to volumes, they need to follow the different instructions depending on the storage systems.


If you install XP External Storage, a system administrator only needs to configure the connection from a host to the XP storage system. After the configuration is completed, a host can manipulate volumes in the external storage system in the same way as volumes in the XP storage system.

**Figure 2 Unifying Connections from a Host to Different Storage Systems**

Without XP External Storage, a host needs to connect all storage systems.



XP External Storage allows you to unify the connections from a host to different storage systems.



---

## 2 About XP External Storage Operations

This chapter explains the functions and the applications of XP External Storage.

- [“Connecting External Storage Systems” \(page 12\)](#)
- [“XP External Storage Components” \(page 13\)](#)
- [“XP External Storage Operations” \(page 15\)](#)
- [“Configuring XP External Storage” \(page 16\)](#)
- [“Choosing Mapping Policy” \(page 26\)](#)
- [“Using a Mapped External Volume from a Connected Host” \(page 27\)](#)
- [“Interoperability with other Products and Functions” \(page 29\)](#)
- [“Examples of Using External Volumes with Other Products” \(page 31\)](#)


### Connecting External Storage Systems

XP External Storage enables you to use HP XP storage systems and other vendors' storage systems (such as IBM or EMC) as connectable external storage systems. Hosts will recognize these volumes as internal volumes of the original XP storage system. From this section onward, the original storage system is called *local storage system* and a connected storage system is called the *external storage system*.

External volume mapping is required for manipulating external volumes from a local storage system. Mapping means assigning management numbers to the external volumes. These management numbers are required for manipulating external volumes from a local storage system. By assigning management numbers to the external volumes, the system administrator will be able to manipulate not only internal volumes of a local storage system but also external volumes using Remote Web Console. The management numbers consist of *external volume group number - sequential number* (for example, E2-1, E50-3).

[Figure 3 \(page 13\)](#) shows the concept of a local storage system and an external storage system that are connected by XP External Storage. In the figure, the external storage system is connected to the external port of the local storage system via a switch using the Fibre Channel interface. The external port is a kind of port attribute that is used for XP External Storage. The external volumes are mapped as internal volumes.

**Figure 3 Concept of XP External Storage**



By mapping an external volume as an internal volume using XP External Storage as shown in [Figure 3 \(page 13\)](#), it becomes possible to operate the external volume using Remote Web Console as if it is a volume in the local storage system.


## XP External Storage Components

Systems using XP External Storage usually contain the following components:

- Local storage system
- External storage system
- Remote Web Console computer
- XP External Storage
- External volume
- Internal volume, which is a virtual representation of an external volume
- LDEVs (Logical Devices) in an external volume
- Cross-subsystem path
- Mapping path

[Figure 4 \(page 14\)](#) illustrates the relations of the XP External Storage components.

**Figure 4 XP External Storage Components**



This section describes the details on the storage systems, cross-subsystem paths, volumes and mapping paths as shown in [Figure 4 \(page 14\)](#).

## Storage Systems and Cross-subsystem Paths

Before using XP External Storage, connect the Fibre Channel port of the local storage system to the external storage system port with the fiber cable. The route between the ports that are connected with the cable, is called the cross-subsystem path.

The Fibre Channel port of the local storage system is set to connect to a host by default. The Fibre Channel port can be connected to an external storage system if you change the attribute of the Fibre Channel port to make it an external port. The external storage system port can be a target port, that is, a port that would be connected to a host if the storage system were not being used as external storage.

Two or more external storage systems can be connected to one external port. You can add an external storage system to a port that is being used by another external storage system.

To manipulate XP External Storage, you need to install XP External Storage using the license key. Use your Remote Web Console computer to access the local storage system via SVP (web server) and perform the XP External Storage operations.

## Volumes and Mapping Paths

Volumes in the external storage system (see C in [Figure 4 \(page 14\)](#)) are called external volumes. Mapping is necessary to manipulate an external volume from the local storage system. The system administrator maps an external volume as an internal volume (see B in [Figure 4 \(page 14\)](#)) in the

local storage system. After the mapping, you can manipulate the external volume from the local storage system in the same way as manipulating an internal volume.

When external volumes in external storage systems are mapped as internal volumes in your storage systems, the external volumes can be accessed and copied by hosts connecting to your storage systems, but not by hosts connecting to the external storage systems.

This document sometimes uses the term *external volume* or *mapped external volume* to mention an internal volume where an external volume is mapped (see B in [Figure 4 \(page 14\)](#)), because this internal volume is a virtual representation of an external volume.

When you perform mapping, a path is automatically created between an internal volume and an external volume. This path is called a mapping path, which connects one volume with another volume. A cross-subsystem path is a part of a mapping path.

To use the external volumes that you mapped as an internal volume (see B in [Figure 4 \(page 14\)](#)) - from the host or other program products, the system administrator needs to create LDEVs in the external volume (see A in [Figure 4 \(page 14\)](#)). To create LDEVs, use XP External Storage at the time of mapping, or use the Virtual LVI/LUN (VLL) function on the internal volume where an external volume is mapped after mapping. The LDEVs created by these methods are called *LDEVs in the external volume* in this document. These LDEVs are usually called *external volumes* in other documents.

An external volume corresponds to a VLL VDEV (Virtual Device). An LDEV in the external volume corresponds to a VLL LDEV. Therefore, you can use the VLL function to create custom-sized volumes in an external volume after mapping, in the same way as creating custom-sized volumes in the normal internal volumes. For details on VDEVs and LDEVs, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

## XP External Storage Operations

Use XP External Storage to execute the following operations.

- Preparing to use external volumes  
You can map external volumes, set port attributes, and set cross-subsystem paths. For details, see [“Configuring XP External Storage” \(page 16\)](#) and [“Overview of Setting Operations” \(page 65\)](#).
- Preparing to manipulate the power supply of the storage systems  
You must follow specific procedures to manipulate the power supply of the storage systems when external volumes are used. To turn on or off the power supply of the external storage system after starting to use the external volumes, you need to execute the commands of XP External Storage. For details, see [“Turning On or Off the Storage System” \(page 88\)](#).
- Setting up and removing the cross-subsystem paths  
When you set up or remove the path (cable) connecting the storage systems, you need to use XP External Storage to make settings on the path. For details on removal, see [“Disconnecting External Storage System or Disconnecting External Volume” \(page 91\)](#) and [“Checking Connection Status and Resuming External Volume Operation” \(page 93\)](#). For details on setup, see [“Configuring the Cross-subsystem Path” \(page 81\)](#).
- Referring to the status of external volumes  
You can see the status and the configuration of external volumes. For details, see [“Checking the External Volume Details” \(page 85\)](#).
- Stopping the use of external volumes  
You can cancel mapping of external volumes. For details, see [“Deleting the External Volume Mapping \(Delete Volume Command\)” \(page 99\)](#).

- Using spreadsheets to map external volumes  
XP External Storage supports Configuration File Loader spreadsheets. These spreadsheets allow you to configure the mapping of multiple external volumes at the same time, which is efficient when mapping large numbers of volumes. For details, see [“Using Spreadsheets for XP External Storage Operations”](#) (page 101).
- Setting the remote command device  
By using the remote command device, you can manipulate volumes in the external storage system from RAID Manager on host computers. For details, see [“Remote Command Devices”](#) (page 119).

## Configuring XP External Storage

Before configuring the XP External Storage settings, answer the following:

- Which ports can be connected to external storage systems? (see [“Choosing the External Port”](#) (page 16))
- Which external storage system and volumes should be mapped as the internal volumes? (see [“Choosing and Mapping External Volumes”](#) (page 16))
- How will you configure external volume groups? (see [“Registering a Volume to an External Volume Group \(ExG\)”](#) (page 17))
- What external volume attributes will be configured? (see [“Configuring External Volume Attributes”](#) (page 17)).
- How will you configure cross-subsystem paths? (see [“Cross-subsystem Paths”](#) (page 18))
- How will you make volumes usable from the local storage system? (see [“Connecting Mainframe Volumes”](#) (page 25) and [“Connecting Open Systems Volumes”](#) (page 26))

Each item is explained in the following sections.

### Choosing the External Port

The port used for XP External Storage must be set as the external port. When the external storage system is connected to the external port of the local storage system, you can view the information on the external storage system from the Remote Web Console computer. The external storage system cannot be connected to ports other than the external port.

In order to set the port attribute to external, any LU paths set to the port must be released. The attribute of the port where LU paths are already set cannot be changed to external. Therefore, you must identify ports whose attributes can be changed to external before starting the XP External Storage operations.

The ports whose attributes are set for remote copy software (for example, RCU target, initiator) or other features cannot be used as external ports for XP External Storage. In addition, change the port attribute to external if the port attribute is set to other than external.

For instructions on configuring port attributes, see [“Setting Port Attribute for Local Storage System”](#) (page 67).

### Choosing and Mapping External Volumes

When connecting an external storage system to an external port, volumes in the external storage system (external volumes) become available for mapping as volumes in the local storage system



(internal volumes). Identify the volumes in each external storage system that should be mapped as internal volumes.

- You cannot access the data that is stored in an external volume beyond the maximum available capacity.  
For example, if an external volume of 100 GB was mapped as an internal volume of 70 GB, then 30 GB of the external volume would not be accessible from the local storage system side.
- You cannot map an external volume whose capacity is smaller than the minimum available capacity.  
For example, you cannot map an external volume of 10 GB as an internal volume requiring at least 30 GB.

The maximum or minimum available capacity of an external volume depends on the emulation type that is set when the volume is mapped. See [“Required Volume Capacity for Each Emulation Type” \(page 152\)](#) for the capacity of the external volume for each emulation type. For the maximum number of external volumes that can be mapped, see [“XP External Storage Requirements” \(page 37\)](#).

## Registering a Volume to an External Volume Group (ExG)

When you map an external volume as an internal volume, you need to register the external volume to an external volume group.

External volumes, which are set by XP External Storage, can be classified into groups by usage. Any group of this type is called an external volume group (ExG). For instance, you can register multiple volumes in one external storage system to one external volume group. Or you can register the volumes in one external volume group and manage them in block, even though the data you want to manage in a lump is stored in volumes in the different external storage systems.

You need to assign numbers to external volume groups. See [“XP External Storage Requirements” \(page 37\)](#) for details on a maximum number of external volume groups, or a maximum number of volumes to be registered in one external volume group.

## Configuring External Volume Attributes

When you map an external volume as an internal volume, you set the attributes of the external volume. External volume attributes can be set using the mapping policy or the Set External Volume Parameter dialog box of XP External Storage. For details on the mapping policy, see [“Choosing Mapping Policy” \(page 26\)](#). For details on the Set External Volume Parameter dialog box, see [“Set External Volume Parameter Dialog Box” \(page 72\)](#).

The attributes of the external volume are as follows:

- **Emulation type**  
Select an emulation type for the mapped external volume from the list.  
The emulation type OPEN-V must be selected if, after the mapping, you are planning to use the existing data in the external volume from the local storage system. For example, to migrate the existing data in the external volume to the local storage system volume, set the OPEN-V emulation type when the external volume is mapped.  
If you select the emulation type other than OPEN-V, the volume requires a specific area to be provided for management data. Once this area is provided, volume capacity after the mapping becomes less than the actual external volume capacity for the area (volume). For details on volume capacity, see [“Capacity Guidelines” \(page 40\)](#).
- **Cache Mode (Enable or Disable)**  
Cache mode specifies whether the write data from the host to the external storage system is propagated synchronously (Disable) or asynchronously (Enable). By default, cache mode is

set to Disable. All I/O to and from the local storage system (either Enable or Disable) always uses cache mode. Write operations are always backed up in duplex cache.

- If you select **Enable**, after receiving the data into the local storage system cache memory, the local storage system signals the host that an I/O operation has completed and then asynchronously destages the data to the external storage system.
- When emulating OPEN volumes and selecting **Disable**, the local storage system signals the host that an I/O operation has completed only after the local storage system has synchronously written the data to the external storage system. When emulating mainframe volumes, when you select Disable, after receiving the data into the local storage system cache memory, the local storage system signals the host that an I/O operation has completed and then asynchronously destages the data to the external storage system.

If you perform the Cache Residency Manager operation on an external volume with Cache Mode set to Disable, the bind mode of Cache Residency Manager cannot be specified. For Cache Residency Manager operations, see the *HP StorageWorks XP24000/XP20000 Cache Residency Manager User Guide*.

When you set the cache mode, note the following:

- Data that is not written by the host (for example, data written by HP StorageWorks XP Continuous Access Software) is asynchronously destaged to the external storage system regardless of the Cache Mode setting.
- If you set the emulation type for a mainframe system (such as 3390-x), data that is written by a host using a command such as Format Write is asynchronously destaged to the external storage system regardless of the Cache Mode setting. Data that is written by a host using a command such as Update Write is destaged to the external storage system as configured in the Cache Mode setting.

- **Inflow Control (Enable or Disable)**

Inflow control specifies whether the writing operation to the cache memory is stopped (Enable) or continued (Disable) when the writing operation to the external volume is impossible. By default, inflow control is set to Disable.

- If you select **Enable**, the writing operation to cache is stopped and the I/O from the host is not accepted when the writing operation to the external volume is impossible.
- If you select **Disable**, the I/O from the host during the retry operation is written to the cache memory even after the writing operation to the external volume is impossible. Once the writing operation to the external volume becomes normal, all the data in the cache memory is written to the external volume (all the data is destaged).

- **CLPR**

When the cache memory is partitioned using *HP StorageWorks XP Disk/Cache Partition Software*, configure a cache logical partition (CLPR) to access the mapped volume. It is strongly recommended that you place External Storage array groups in a CLPR other than CLPRO. See the *HP StorageWorks XP24000/XP20000 Disk/Cache Partition User Guide* for detailed information on CLPR.

## Cross-subsystem Paths

A cross-subsystem path is a route from a local storage system port to an external storage system port. To prepare for possible failures of the cable, the switch, or the channel processor, HP recommends that you create redundant cross-subsystem paths. This redundancy allows you to continue performing the I/O operations to the external volumes when you maintain the cable. You can set up to eight paths.

If two or more external volumes use the same redundant cross-subsystem paths, these external volumes can be a group. This group is called a path group. In the redundant cross-subsystem paths, the cross-subsystem path that has the highest priority is called the primary path. The cross-subsystem paths other than the primary path are called alternate paths.

- Setting of the path groups

A path group is automatically set when you map the external volume or when you change a path group by using spreadsheets. You cannot set a new path group by itself. For more information about changing a path group by using spreadsheets, see [“Changing Path Group” \(page 115\)](#).

- Setting of cross-subsystem paths

Use fiber cables to establish multiple paths between the external storage system and the local storage system. At this time, connect to the external storage system from a different cluster port of the local storage system.

If multiple paths are established between the two storage systems, the starting points of the paths (that is, external ports of the local storage system) and the ending points (that is, WWNs showing the ports of the external storage system) will be displayed in a dialog box when you map an external volume. In this dialog box, you can set cross-subsystem paths by selecting the starting points and the ending points of the paths according to the actual cable connections. For details on how to set cross-subsystem paths, see [“Configure Cross-subsystem Paths Dialog Box” \(page 79\)](#).

- Setting of redundant cross-subsystem paths

You can set redundant cross-subsystem paths (add alternate paths) when you set the cross-subsystem paths. You can also add an alternate path or change the priority after completing the mapping of the external volume (see [“Setting the Cross-subsystem Paths” \(page 78\)](#)).

## Path Mode

Path mode is either Single mode or Multi mode, depending on the connected external storage system.

- In the *Single mode*, only the path with the highest priority (primary path) is used to execute the I/O to the external volume. When an error occurs in the primary path, the path with the second highest priority is used.
- In the *Multi mode*, all of the set paths are used at the same time. The multiple paths are used to execute the I/Os to the external volume thus distributing the work load (round-robin processing).

For example, when a volume in the external storage system with the path mode of the Single mode is mapped as an internal volume using XP External Storage, the host I/O operations to the external volume are enabled using the primary path set in the mapping operation. The path is automatically switched to the alternate path when the primary path set in mapping operation cannot be used due to, for instance, maintenance operation in the storage system, or a failure in the channel processor. Because the path is switched to the alternate path, the I/O operation to the external volume continues even though an error occurred in the original path.

When the primary path cannot be used for three minutes continuously, the path is switched to the alternate path.

## Examples of Alternate Paths

[Figure 5 \(page 20\)](#) illustrates an example of setting an alternate path. External storage system ports, WWN A and WWN B, are connected to CL1-A and CL2-A respectively, which are set to the external ports in the local storage system. You need to specify the port of a different cluster in

the local storage system for the alternate path. Therefore, CL1 port and CL2 port are specified as shown in the figure.

**Figure 5 Example of Alternate Path Setting**






Figure 6 (page 20) illustrates an example of setting an alternate path when a switch is used. Two ports are specified in the local storage system, and connected to the ports in the external storage system through the switch. In this case, two ports of different clusters are specified in the local storage system. Therefore, the setting of the alternate path is enabled.

**Figure 6 Example of Available Alternate Path Setting**



In Figure 7 (page 21), two paths are also set between the internal volume and the external volume. However, one port is specified in the local storage system, and two ports are specified in the external storage systems over the switch. This configuration is not recommended because two ports of different clusters need to be set in the local storage system for alternate path settings in XP External Storage.

**Figure 7 Example of Unavailable Alternate Path Setting**



### Examples of Switching I/O Execution Paths to Alternate Paths

This section describes examples of the performance when the I/O execution path is switched to the alternate path for each path mode as follows:

- When the path mode is Multi mode
- When the path mode is Single mode
- When the path mode is Single mode and there is at least one alternate path in the Standby status


For the description about the path status, see [“Mapping Path Information Dialog Box” \(page 86\)](#).

- When the path mode is Multi mode

[Figure 8 \(page 22\)](#) shows an example of when the path mode is Multi mode. When an error occurs in one path, I/Os are executed using the paths other than the error path.

As you restore the error path, the use of the restored path is automatically resumed.

**Figure 8 When the Path Mode is Multi Mode**




- When the path mode is Single mode

Figure 9 (page 23) shows an example of when the path mode is Single mode. When an error occurs in the path that is being used for I/Os, the I/O execution path is switched to the path with the second highest priority.

As you restore the path with the priority higher than the currently used path, the I/O execution path is automatically switched to the restored path that has the highest priority.

**Figure 9 When the Path Mode is Single Mode**




- When the path mode is Single mode and there is at least one alternate path in the Standby status

Figure 10 (page 24) shows an example of when the path mode is Single mode, and there are alternate paths in Normal status and Standby status. Figure 11 (page 25) shows another example of when the path mode is Single mode. For Figure 11 (page 25), there are alternate paths in Standby status only.

When an error occurs in the path that is being used for I/Os, the I/O execution path is switched to the path with the second highest priority in Normal status (see Figure 10 (page 24)). If there is no path in Normal status other than the path that is being used for I/Os, the status of the path in Standby status is automatically changed to Normal, and the I/O execution path is switched to that path (see Figure 11 (page 25)).


As you restore the path with the highest priority, note that only when the external storage system is an EVA storage system, the I/O execution path is switched back to the restored highest priority path. In this case, the status of the path for which the status was changed to Normal when the error occurred changes back to Standby.

**Figure 10 Single Mode with Alternate Paths in Normal and Standby**





**Figure 11 Single Mode with Alternate Paths in Standby Only**



## Connecting Mainframe Volumes

Mainframe volumes that pre-exist on an external storage system and are accessed by ESCON or FICON channels cannot connect directly to the storage system as an external volume. The storage system does not recognize these volumes because of Fibre Channel.

To use external volumes as mainframe volumes, there are two ways:

- Zero-format external volumes on the external storage system side, map the external volumes to the internal volumes using XP External Storage on the local storage system side, and then perform the **Write to Control Blocks** operation using the VLL function on the local storage system side.
- Map the external volumes to the internal volumes using XP External Storage on the local storage system side, and then format the mapped external volumes using the VLL function on the local storage system side.

If you set the emulation type for the mainframe system (such as 3390) as you map the external volume, the status of the mapped volume becomes Blockade after the mapping operation. After the system administrator performs the **Write to Control Blocks** operation or formats the mapped external volumes using the VLL function on the local storage system side, the mainframe host can then access the new mainframe volume through the local storage system's ESCON or FICON channels.

If you format the mapped volume of the external storage system from the external storage system side, the existing data before formatting cannot be assured. When you use the mapped external volume from the mainframe operating system, format the mapped volume from the local storage system side.

For the volume formatting and **Write to Control Blocks** operation procedures, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

## Connecting Open Systems Volumes

Open systems volumes in external storage system connect to and are recognized by the storage system as open systems volumes, without requiring reformatting. Reformatting is not required because the connection between the storage system and the external storage system is Fibre Channel. If you need to initialize the data area for the volume, format the volume using the VLL function. For the volume formatting operation procedure, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

OPEN-V emulation is recommended because, in most cases, OPEN-V emulation provides the most efficient use of storage and the best performance. Also, emulation types other than OPEN-V may not retain existing data after being mapped.

## Choosing Mapping Policy

Mapping policy is a list of settings of the necessary information for mapping the external volume. By setting the mapping policy in advance, the setting at the time of mapping will be easier.

The default mapping policy is prepared in advance. You can change the values of the default mapping policy.

## Difference between Automatic Mapping and Manual Mapping

When you map the external volume, you need to configure:

- Cross-subsystem paths
- External volume parameters
- LDEV number to LDEVs in the external volume
- SSID (storage system ID)

When you perform automatic mapping, users configure only cross-subsystem paths and all the other settings are automatically made by XP External Storage according to the mapping policy. When you perform manual mapping, users configure all the settings.

Automatic mapping maps all the external volumes found by volume discovery to internal volumes. Automatic mapping requires fewer settings but you are not allowed to set different parameters for each external volume or to specify an LDEV number for each LDEV. You can set the parameters such as emulation type to the mapping policy in advance.

---

**NOTE:** In automatic mapping, external volumes are mapped in the order of the local storage system recognizing. Therefore, the LDEV number is also specified in this order. Moreover, when you copy external volumes with the program product for copying, the copy operation is performed in the order of the LDEV number if you specify two or more external volumes for the initial copy or resynchronization. Therefore, when you copy external volumes that are mapped automatically with the program product for copying, the copy operation might focus on a specific RAID group and cause insufficient performance. To prevent the copy operation from focusing on a specific RAID group, HP recommends that the external volumes be mapped manually so that the copy operation is distributed to two or more RAID groups.

---

## Port Discovery and Volume Discovery

Port discovery and volume discovery are methods used to find external volumes, and are executed when you map external volumes or when you add cross-subsystem paths.

- Port discovery searches for and gets information about target ports of the connected external storage system from an external port of the local storage system. The latest information about

the external storage system can be displayed in a dialog box of XP External Storage when you execute port discovery.

You can set in advance the mapping policy on whether to execute port discovery automatically or manually. If port discovery is executed automatically, WWNs connected to all the external ports of the local storage system will be searched for. If port discovery is executed manually, you can select a specific external port and limit the scope to search WWNs. If you can specify which external port to search for, you can reduce the operation time by executing the port discovery manually.

- Volume discovery searches for and gets information about external volumes from the target ports of the external storage system. Volume discovery is automatically executed after the port discovery process.

When a port in an external storage system is connected to an XP storage system and has a management LU (for example, Universal Xport LU), an extra operation is required. A management LU is an LU that receives commands issued by a particular application. The management LU controls or manages that application. The management LU stores control information from that application and, therefore, the management LU cannot be used as an external volume. A command device is not a management LU.

Before performing port discovery or volume discovery, perform one of the following operations on the external storage system.

- Delete the management LU from the port connected to the XP storage system.
- Make sure that at least one LU is used for data storage and has a smaller LUN ID than the LUN of the management LU. Also make sure that the data storage LU is set to the port connected to the XP storage system.
- Use the security function and configure the access attribute of the management LU to prohibit read and write operations.

If none of the operations is performed, an external storage system that has a management LU might not be recognized by the local storage system.

## Using a Mapped External Volume from a Connected Host

There are two ways of using the mapped external volume from a host that is connected the local storage system.

- [“Storing New Data in the Mapped External Volume” \(page 27\)](#)
- [“Using Existing Data in the Mapped External Volume” \(page 28\)](#)

## Storing New Data in the Mapped External Volume

To store new data in a mapped external volume from a host that is connected to the local storage system:

1. Map the volume in the external storage system as an internal volume of the local storage system using XP External Storage.

Select the emulation type of the mapped volume as you required. If you select the emulation type for the open system (such as OPEN-V), go to step 2. If you select the emulation type for the mainframe system (such as 3390-3), go to step 3.

For information on mapping operations, see [“Mapping an External Volume Automatically” \(page 67\)](#).

2. If you set the emulation type for the open system when you map the volume, the status of the mapped volume automatically becomes Normal. If you need to initialize the data area of the mapped volume, format the volume using the VLL function. For the volume formatting procedure,

see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.


3. If you set the emulation type for the mainframe system when you map the volume, the status of the mapped volume becomes Blockade. Format the volume using the VLL function.

For zero-formatted external volumes, when you select that volume to map, you can use the VLL function to perform the **Write to Control Blocks** operation to restore the volume. For instructions on how to format volumes and the **Write to Control Blocks** operation, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.

4. To perform the host I/O operations, set the LU path from the Target port to the mapped volume. After the LU path is set, the host I/O operation to the mapped volume becomes available.

**Figure 12 Storing the New Data in the Mapped External Volume**



## Using Existing Data in the Mapped External Volume

To use the existing data in the mapped external volume from the host that is connected to the local storage system:

1. Store the data from the host that is connected to the external storage system to the volume in the external storage system.
2. Map the volume containing data in the external storage system as an internal volume of the local storage system using XP External Storage.


When you map the external volume, set the attributes of the mapped volume to **Emulation type = OPEN-V** to read the existing data in the mapped external volume from the local storage system side.

3. Set the LU path from the **Target** port to the mapped volume to perform the host I/O operation. After the LU path is set, the host I/O operation to the mapped volume can be initiated.

Make sure that you do not access the external volume, which has been mapped as an internal volume, from the host that is connected to the external storage system. Also make sure that you do not access the mapped external volume using the function (for example, copy function) of the external storage system. Once you have mapped an external volume as an internal volume, you can access the mapped external volume only from the local storage system side.

From the host, you can access the external storage system volumes that have not been mapped as internal volumes. There is no restriction. [Figure 13 \(page 29\)](#) illustrates using existing data in a mapped external volume.

**Figure 13 Using the Existing Data in the Mapped External Volume**



## Interoperability with other Products and Functions

You can use XP disk array program products to use and manage the external volumes you have set using XP External Storage. For the operations and notes on each program product, see the respective user's guides.

### LUN Manager and Configuration File Loader

If you set the emulation type for the open system as you map an external volume, you need to set the LU path for the mapped volume using LUN Manager.

Consider the following for the Configuration File Loader function:

- You can set the LU path definition for the external volume (add, delete, or change LU paths).
- You can set the command device for the external volume (add or delete the setting).
- The setting of the channel adapter (CHA) mode, host group, and WWN for the external port is not supported. When an external volume is mapped through that external port, the setting operation of the topology is not available, either.

### LUN Expansion (LUSE)

Consider the following for LUN Expansion (LUSE):

- The internal volume in the local storage system and the external volume cannot be combined to form a LUSE volume.
- Do not combine LDEVs of multiple external volumes to create a LUSE volume. Only the LDEVs in the same external volume can be used to configure the LUSE volumes.
- All external volumes in a LUSE volume must be in the same **Cache Mode**.

## Virtual LVI/LUN (VLL)

Consider the following for Virtual LVI/LUN (VLL):

- If you set the emulation type for the mainframe system as you map the external volume, you need to format the mapped volume or perform the **Write to Control Blocks** operation using the VLL function before you use the external volume.

For the volume formatting operation and **Write to Control Blocks** operation procedures, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

- If you create LDEVs in an external volume using the VLL function, the cache mode of the created LDEVs becomes the same as that of the source external volume.

## Cache Residency Manager

Consider the following for Cache Residency Manager:

- The bind mode of the Cache Residency Manager operation cannot be specified for the external volume if the **Cache Mode** is set to **Disable**.
- If you use the mapped external volume for the Cache Residency Manager operation and set the bind mode, a cache of twice as much capacity as the user data is required for the Cache Residency Manager operation.

## Performance Monitor and XP Auto LUN

Consider the following for Performance Monitor and XP Auto LUN:

- Performance Monitor can be used to display the monitoring information about the external volumes.
- Mapped volumes can be used for XP Auto LUN. For instructions on adjusting volume capacity, see [“Adjusting the Volume Capacities for Pairs” \(page 156\)](#).

For the configuration example of XP Auto LUN, see [“XP Auto LUN Operations” \(page 31\)](#).

## XP Continuous Access and Hitachi TrueCopy™ for Mainframe

Mapped volumes can be used for XP Continuous Access and for TrueCopy for Mainframe. For a configuration example of XP Continuous Access, see [“XP Continuous Access Operations” \(page 32\)](#).

## HP StorageWorks XP Continuous Access Journal Software and Hitachi Universal Replicator™ for Mainframe

Mapped volumes can be used for XP Continuous Access Journal and Universal Replicator for Mainframe. For a configuration example of XP Continuous Access Journal, see [“XP Continuous Access Journal Operations” \(page 33\)](#).

## HP StorageWorks XP Business Copy Software and Hitachi ShadowImage™ for Mainframe

Mapped volumes can be used for XP Business Copy and ShadowImage for Mainframe. For a configuration example of XP Business Copy, see [“XP Business Copy Operations” \(page 35\)](#).

## HP StorageWorks XP Snapshot Software

Mapped volumes can be used for XP Snapshot. Consider the following for XP Snapshot:

- Both internal and external volumes cannot be mixed in one pool.
- All external volumes in the same pool must be in the same **Cache Mode**.

## HP StorageWorks XP Thin Provisioning Software

Mapped volumes can be used for XP Thin Provisioning. Consider the following for XP Thin Provisioning:

- Both internal and external volumes cannot be mixed in one pool.
- All external volumes in the same pool must be in the same **Cache Mode**.

## SNMP Agent

Consider the following for SNMP Agent:

- The information on the mapped external volume is displayed.
- The information on the external port is displayed.

## Examples of Using External Volumes with Other Products

For the following XP disk array program products, examples of using external volumes are described in the following subsections:

- “XP Auto LUN Operations” (page 31)
- “XP Continuous Access Operations” (page 32)
- “XP Continuous Access Journal Operations” (page 33)
- “XP Business Copy Operations” (page 35)
- “XP Snapshot Operations” (page 36)

### XP Auto LUN Operations

Figure 14 (page 32) shows the use of an external volume for the XP Auto LUN operation. The mapped external volume is set as the source volume and the local internal volume is set as the target volume. Existing data in the external volume is migrated manually to the local storage system internal volume using XP Auto LUN. For detailed information on XP Auto LUN operations, see the *HP StorageWorks XP24000/XP20000 Auto LUN Software User Guide*.

The procedure for the operation is as follows:

1. Use XP External Storage to map a volume in the external storage system as an internal volume of the local storage system.

For Figure 14 (page 32), set the attributes of the mapped volume as follows:


Emulation type: OPEN-V

To migrate the existing data in the mapped external volume to the local storage system volume using XP Auto LUN, set the emulation type to **OPEN-V** as you map the volume. The emulation type must be **OPEN-V** to read out the existing data in the external volume from the local storage system side.

To copy the existing data in the mapped external volume using the copy program products of Remote Web Console such as XP Continuous Access and XP Business Copy, the emulation type of the mapped external volume also has to be **OPEN-V**.

2. Prepare the local internal volume that has the same capacity as the mapped external volume. Adjust the capacity of the internal volume as it is required using the VLL function.  
For the VLL function, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.  
The emulation type of the prepared internal volume must be **OPEN-V**.
3. Set the mapped external volume as the source volume and local storage system internal volume as the target volume.
4. Migrate the existing data in the mapped external volume to the local storage system internal volume manually using XP Auto LUN.

**Figure 14 Example of the XP Auto LUN Operations**



## XP Continuous Access Operations

Figure 15 (page 33) shows the use of an external volume for the XP Continuous Access operation. The mapped external volume is set as the S-VOL of the XP Continuous Access pair, and the volume in the local storage system that is connected as the multipoint control unit (MCU) is set as the P-VOL of the XP Continuous Access pair. For details on XP Continuous Access, see the *HP StorageWorks XP24000/XP20000 Continuous Access Software User Guide*.

The procedure for the operation is as follows:

1. Use XP External Storage to map a volume in the external storage system as an internal volume of the local storage system, which is used as remote control unit (RCU) for the XP Continuous Access operation.  
You can select the emulation type of the mapped volume as you required. If you select the emulation type for the open system (such as OPEN-V), go to step 2. If you select the emulation type for the mainframe system (such as 3390-3), go to step 3.  
For details on the mapping operation, see [“Mapping an External Volume Automatically” \(page 67\)](#).
2. If you set the emulation type for the open system when you map the volume, the status of the mapped volume automatically becomes Normal. However, the volume formatting processing



is not executed automatically. If you need to format the mapped volume, format the volume using the VLL function.

For the volume formatting operation procedure, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.


3. If you set the emulation type for the mainframe system when you map the volume, the status of the mapped volume becomes Blockade. Format the volume using the VLL function. Or if you have mapped the volume for which the data area has already been zero-formatted on the external storage system side, perform the **Write to Control Blocks** operation using the VLL function to restore the volume.

For the volume formatting operation and **Write to Control Blocks** operation procedures, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.

4. Set the P-VOL and S-VOL of the XP Continuous Access pair, as shown in [Figure 15 \(page 33\)](#).

**Figure 15 Example of the XP Continuous Access Operations**



## XP Continuous Access Journal Operations

[Figure 16 \(page 34\)](#) shows the use of an external volume for the XP Continuous Access Journal operation. The mapped external volume is set as the S-VOL of the XP Continuous Access Journal pair, and the volume in the local storage system that is connected as the MCU is set as the P-VOL of the XP Continuous Access Journal pair. For details on XP Continuous Access Journal, see the *HP StorageWorks XP24000/XP20000 Continuous Access Journal Software User Guide*.

The procedure for the operation is as follows:

1. Use XP External Storage to map the volume in the external storage system as an internal volume of the local storage system, which is used as RCU for the XP Continuous Access Journal operation.

You can select the emulation type of the mapped volume as you required. If you select the emulation type for the open system (such as OPEN-V), go to step 2. If you select the emulation type for the mainframe system (such as 3390-3), go to step 3.

For details on the mapping operation, see [“Mapping an External Volume Automatically” \(page 67\)](#).

2. If you set the emulation type for the open system when you map the volume, the status of the mapped volume automatically becomes Normal. However, the volume formatting processing is not executed automatically. If you need to format the mapped volume, format the volume using the VLL function.

For the volume formatting operation procedure, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.


3. If you set the emulation type for the mainframe system when you map the volume, the status of the mapped volume becomes Blockade. Format the volume using the VLL function. Or if you have mapped the volume for which the data area has already been zero-formatted on the external storage system side, perform the **Write to Control Blocks** operation using the VLL function to restore the volume.

For the volume formatting operation and **Write to Control Blocks** operation procedures, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.

4. Set the P-VOL and S-VOL of the XP Continuous Access Journal pair, as shown in [Figure 16 \(page 34\)](#).

**Figure 16 Example of the XP Continuous Access Journal Operations**



## XP Business Copy Operations

Figure 17 (page 35) shows the use of an external volume for the XP Business Copy operation. The mapped external volume is set as the S-VOL of the XP Business Copy pair, and the local storage system internal volume is set as the P-VOL of the XP Business Copy pair. For details on XP Business Copy, see the *HP StorageWorks XP24000/XP20000 Business Copy Software User Guide*.

The procedure for the operation is as follows:

1. Use XP External Storage to map a volume in the external storage system as an internal volume of the local storage system.

You can select the emulation type of the mapped volume as you required. If you select the emulation type for the open system (such as OPEN-V), go to step 2. If you select the emulation type for the mainframe system (such as 3390-3), go to step 3.

For details on the mapping operation, see [“Mapping an External Volume Automatically” \(page 67\)](#).

2. If you set the emulation type for the open system when you map the volume, the status of the mapped volume automatically becomes Normal. However, the volume formatting processing is not executed automatically. If you need to format the mapped volume, format the volume using the VLL function.

For the volume formatting operation procedure, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.


3. If you set the emulation type for the mainframe system when you map the volume, the status of the mapped volume becomes Blockade. Format the volume using the VLL function. Or if you have mapped the volume for which the data area has already been zero-formatted on the external storage system side, perform the **Write to Control Blocks** operation using the VLL function to restore the volume.

For the volume formatting operation and **Write to Control Blocks** operation procedures, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

Go to step 4.

4. Set the P-VOL and S-VOL of the XP Business Copy pair, as shown in [Figure 17 \(page 35\)](#).

**Figure 17 Example of the XP Business Copy Operations**



## XP Snapshot Operations

Figure 18 (page 36) shows the use of an external volume for the XP Snapshot operation. The mapped external volume is set as a pool-VOL of the XP Snapshot pair. For details on XP Snapshot, see the *HP StorageWorks XP24000/XP20000 Snapshot User Guide*.

The procedure for the operation is as follows:


1. Use XP External Storage to map a volume in the external storage system as an internal volume of the local storage system.

**CAUTION:** Set the emulation type of the volume to OPEN-V when you map the volume, because the volume with the OPEN-V emulation type can only be set as a pool-VOL of XP Snapshot.

For details on the mapping operation, see [“Mapping an External Volume Automatically” \(page 67\)](#).

2. The status of the mapped volume automatically becomes Normal. However, the volume formatting processing is not executed automatically. If you need to format the mapped volume, format the volume using the VLL function. For the volume formatting operation procedure, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.
3. Create a pool and add the mapped external volume to that pool as a pool-VOL.
4. Set the P-VOL and S-VOL of the XP Snapshot pair with specifying the pool you have created at step 3.

**Figure 18 Example of the XP Snapshot Operations**



---

## 3 Preparing for XP External Storage Operations

This chapter describes the requirements and preparations for XP External Storage operations.

- [“System Requirements” \(page 37\)](#)
- [“Guidelines for XP External Storage Operations” \(page 38\)](#)
- [“Installing and Uninstalling XP External Storage” \(page 44\)](#)
- [“Starting XP External Storage” \(page 45\)](#)

### System Requirements

The system requirements for XP External Storage are:

- HP XP storage system (First storage system)  
All the necessary hardware and microcode required for XP External Storage operations must be installed and enabled. In this user's guide, the first storage system is called local storage system.
- Storage system other than the first storage system  
A second storage system must be available and operate as an external storage system. The kinds of storage systems that can be used as an external storage system include HP StorageWorks EVA storage systems, HP StorageWorks MSA storage systems, and other similar storage systems. For detailed information on the storage systems that can be used as the external storage system, see [“Storage Systems Supported as External Storage Systems” \(page 37\)](#).
- Remote Web Console computer (user-supplied computer)  
See the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide* for instructions on installing and using the Remote Web Console computer.

---

**NOTE:** You must operate the Remote Web Console computer in **Modify** mode to perform XP External Storage operations. Users in **View** mode can only view XP External Storage information.

---
- License key for XP External Storage program product  
You need a license key to install XP External Storage.

### Storage Systems Supported as External Storage Systems

For the storage systems that are currently supported as external storage, contact HP.

### XP External Storage Requirements

[Table 1 \(page 38\)](#) describes the XP External Storage requirements.

**Table 1 XP External Storage Requirements**

Item	Requirement
Maximum number of ports in the connected external storage system (WWN is used as a port identification number)	1,024 per port
Maximum number of external volumes that can be connected	<p>63,232 volumes can be connected.</p> <p>4,096 volumes can be connected per port.</p> <p>If you use XP Snapshot or XP Thin Provisioning, the number of external volumes that can be connected is as follows:</p> <p>Number of external volumes + Number of virtual volumes <math>\leq</math> 63,232</p>
Maximum number of mapping paths can be set for one external volume	8
Maximum capacity of an external volume	<p>4 TB per external volume</p> <p>If you specify an external volume that is more than 4 TB you can access the data stored in the field up to 4 TB. You cannot access the data that is stored in the field over 4 TB.</p>
Minimum capacity of an external volume	<p>77,760 blocks (about 38 MB) per external volume.</p> <p>However, when the emulation type of the volume is OPEN-V, the minimum capacity becomes 96,000 blocks (about 47 MB) per external volume</p>
Maximum number of external volume groups	16,384
Maximum number of external volumes that can be registered in one external volume group	4,096

## Guidelines for XP External Storage Operations

This section provides guidelines for the XP External Storage operations.

### Mapping Guidelines

- Before mapping external volumes, make sure that external volumes are not reserved by a host. External volumes that are reserved by a host cannot be mapped as internal volumes.  
If external volumes are reserved by a host, cancel the reserve settings and then map the external volumes.
- Once external volumes are mapped, do not reserve the external volumes for a host.  
If external volumes are reserved by a host, internal volumes to which the external volumes are mapped will be blocked.

- Make sure that an external volume is accessed only from the local storage system side once the external volume is mapped.
  - Make sure that the external volume, which has been mapped as an internal volume, is not accessed from the host that is connected to the external storage system.
  - Make sure that the external volume, which has been mapped as an internal volume, is not manipulated by the copy function or other function of the external storage system.
  - If you need to access the mapped external volumes from the external storage system, perform the operation explained in [“Disconnecting External Storage System or Disconnecting External Volume”](#) (page 91).

Hosts can access the external storage system volumes that have not been mapped as the internal volumes. There is no restriction.

- Do not map a volume from an external storage system if it has already been mapped as internal storage in another storage system.
- When an external storage system that has an ownership is connected to a storage system, configure the cross-subsystem path to the primary controller in the external storage system as primary path.

Ownership is an exclusive right to control volumes. A controller that has an ownership is called a primary controller. If a cross-subsystem path to a controller without ownership is configured as primary path, the ownership will be transferred and it may affect the performance.

## Recommended Applications According to HDD Type

[Table 2 \(page 39\)](#) and [Table 3 \(page 40\)](#) show the recommended level of the application of mapped external volume according to the hard disk drive (HDD) type of the external volume.

**Table 2 When the Emulation Type of the External Volume is for OPEN**

Application	HDD Type	
	FC/SSD <sup>1, 2</sup>	SATA <sup>3</sup>
Database Online Transaction Processing (OLTP)	Yes	Not Recommended
File Operation from Host (Both of Read and Write)	Yes	Not Recommended
File Operation from Host (Mainly Read)	Yes	Yes
Backup	Yes	Recommended
Archive	Yes	Recommended

1 FC = Fibre channel

2 SSD = Solid State Drive


3 SATA = Serial Advanced Technology Attachment

**Table 3 When the Emulation Type of the External Volume is for Mainframe**

Application	HDD Type	
	FC/SSD	SATA
Database Online Transaction Processing (OLTP)	Not Recommended	Not Recommended
System Volumes (Journal, Check points)	Not Recommended	Not Recommended
Operation from TPF	Not Supported	Not Supported
File Operation from Host (Both of Read and Write)	Yes	Not Recommended
File Operation from Host (Mainly Read)	Yes	Yes
Backup	Yes	Recommended
Archive	Yes	Recommended

## Capacity Guidelines

- When a volume, which has the capacity of 4 TB or less, in the external storage system (external volume) is mapped with the setting of OPEN-V emulation type, the volume is defined as the internal volume that has the same capacity as the mapped external volume.

**Figure 19 Example of External Volume of 4 TB or Less**

- You cannot access the data that is stored in the field over the maximum capacity of the external volume.

The maximum volume capacity differs depending on the emulation type that you specify at the external volume mapping. See [“Required Volume Capacity for Each Emulation Type” \(page 152\)](#) for more details.

- When an external volume is mapped as internal volumes with the setting of the emulation type other than OPEN-V, the number of volumes and the volume capacity of the mapped external volumes depend on the capacity of the original external volume and the basic capacity of each emulation type. When an external volume is mapped with the setting of emulation type other than OPEN-V, the data management information area is required to be provided in the mapped volume. This means that the capacity that can be used after the mapping becomes




smaller than the actual external volume capacity. The available capacity decreases as much capacity as the data management information area.


Figure 20 (page 41) shows an example of when the original capacity of the external volume is bigger than the basic capacity of the emulation type. The emulation type is OPEN-3.

Figure 21 (page 41) shows an example of when the original capacity of the external volume is smaller than the basic capacity of the emulation type.

**Figure 20 When the External Volume Capacity is Bigger than the Basic Capacity of Specified Emulation Type (Example of the OPEN-3 emulation type)**



**Figure 21 When the External Volume Capacity is Smaller than the Basic Capacity of Specified Emulation Type**



## Guidelines for Mainframe Volumes

- If you plan to use the mapped external volume from the mainframe operating system (for example, the volume is mapped with the setting of 3390-x mainframe emulation type), you need to select the external volume that consists of one LDEV or you need to adjust the capacity of the external volume to be mapped beforehand. If multiple LDEVs exist in one external volume and if a lot of I/Os are made to these LDEVs, the read, write commands may time out. When the commands may time out, the SIM (21D2xx) is reported.
- When you use the mapped external volume from the mainframe operating system, set the MIH (Missing Interrupt Handler) timer to 45 seconds (which is the recommended value).

## Volume Attribute Guidelines

- The external volume attributes for all the LDEVs created in an external volume become the same. The attributes are taken over, when the LDEVs are reconfigured using the VLL function.
- The **Cache Mode** becomes the same for all the LDEVs in one external volume.

- The attributes that are set for the external volume originally on the external storage system side (such as the port security, the LUN security, the Volume Retention Manager attributes, and so on) are not kept, when the external volume is mapped as an internal volume. If the original attributes are required to be set, set the attributes on the mapped external volume from the local storage system side.
- For the external volume, for which the **Cache Mode** is set to **Disable**, the bind mode for the Cache Residency Manager operation is not available.
- If you use the mapped external volume for the Cache Residency Manager operation and set the bind mode, the cache of twice as much capacity as the user data is required for the Cache Residency Manager operation.

## Creating LUSE Volume Guidelines

- Do not combine LDEVs of multiple external storage systems to create a LUSE volume. The LDEVs in the same external storage system can only be used to set the LUSE volumes.  
When you combine LDEVs of multiple external storage systems to create a LUSE volume, the following problems will occur:
  - If a LUSE volume consists of multiple external storage systems and one external storage system volume has lower performance than the other storage system volumes, the lower performance of the volume affects the performance of the LUSE volume.
  - When an external storage system volume that is part of a LUSE volume is blocked, data reliability of the LUSE volume will deteriorate because the LUSE volume has both accessible area and inaccessible area from a host.
  - When you disconnect an external volume or resume the use of an external volume, you need to perform the operation at the same time on all the external volumes that are components of the LUSE volume.
- The mapped volumes that have different cache mode settings cannot be used to create one LUSE volume.

## Maintenance Guidelines for an External Storage System

- Before you change settings of the external storage system, you must delete the external volume mapping. After you change settings of the external storage system, you must remap the external volume. If you do not remap the volume, the external volume cannot be used in the local storage system.

The examples of external storage system settings requiring the re-mapping of external volume are as follows:

- Changing WWNs of target ports that connect to the local storage system
- Changing the serial number of the external storage system
- Changing LUNs of volumes of the external storage system
- Reducing the volume capacity of the external storage system so that the volume capacity is smaller than when volume mapping was performed

Besides, re-mapping is required for XP External Storage after you change external storage system settings that require modification on the host side when hosts are connected directly to a external storage system.

Before you delete the external volume mapping, make sure that the volume has no LU paths, and that the volume is not a component of any pairs (such as XP Continuous Access pairs). For detailed information on deleting the external volume mapping, see [“Deleting the External Volume Mapping \(Delete Volume Command\)” \(page 99\)](#). For detailed information on mapping external volume, see [“Mapping an External Volume Automatically” \(page 67\)](#).

## Performance and Status Guidelines

- The performance and status of the external storage system affect the Read and Write performance of the mapped external volume. If there is a heavy load on the external storage system, the processing speed of the Read and Write operation becomes slow. In this case, the I/Os from the mainframe host may MIH error.
- When you use an external volume from the host, note the Path Blockade Watch time for the external volume. If the Path Blockade Watch time is longer than the timeout period of the host command, the commands from the host time out when the power supply is off or when an error occurs on the external storage system. If the host I/O is a significant concern, make sure that the Path Blockade Watch time of the external volume is the same as or shorter than the timeout period of the host command.

## RAID Level Considerations

In the internal processing, the RAID level of the external volume is handled as RAID-1 across the board. The bar (–) is displayed on the Remote Web Console windows. The RAID level of external volumes is reported as RAID-1 when information about external storage system is reported to the higher-level device (OS).

## AMS 2000 Series Guidelines

- When you use an AMS 2000 series storage system as an external storage system, unnecessary loads to the external storage system should be avoided.

When an AMS 2000 series storage system is used as an external storage system, the path mode between storage systems is Multi mode. Therefore, if there are many external paths and mapping volumes, the load to the external storage system becomes high and some commands from the host to the XP24000 disk array or some commands from the XP24000 disk array to the external storage system might time out.

To keep the load proper, HP recommends the following:

- Define volumes of each AMS 2000 series storage system to set the external path number to two. In that case, set the paths to the ports of each controller of the AMS 2000 series storage system.
- Set the queue of commands that are issued at the same time from one AMS 2000 series storage system to 500 or less. The formula to calculate the number of the queue commands per AMS 2000 series storage system is shown as follows:  
$$(\text{number of queues}) \times (\text{number of paths of external volumes}) \times (\text{number of external volumes that issue commands at the same time}) < 500$$
  
For more information about setting the queue of commands, see [“Change WWN Parameter Dialog Box” \(page 97\)](#).
- When you use external volumes of the AMS 2000 series storage system with the program product for copying, the copy operation needs to be distributed to two or more RAID groups. There is an upper bound to the number of pairs that can be used for an initial copy or resynchronization. Therefore, the copy operation might focus on a specific RAID group according to the order of the copy operation when the copy operation is performed to two or more external volumes. The drive of the AMS 2000 series storage system might become a bottleneck, which causes insufficient performance, when the copy operation focuses on a specific RAID group.

## Installing and Uninstalling XP External Storage

This section explains how to install and uninstall XP External Storage.

### Installing XP External Storage

You need to install XP External Storage using the license key to perform the XP External Storage operations on the Remote Web Console computer.

To install the XP External Storage license key:

1. Start the Remote Web Console for the desired storage system.
2. Enable the XP External Storage options on the Remote Web Console computer and on each storage system.

For detailed instructions, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

### Uninstalling XP External Storage

To uninstall XP External Storage, you must remove all the pairs and then delete the external volume mapping.

To uninstall XP External Storage:

1. Start Remote Web Console, and open the Remote Web Console main window.  
For instructions, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.
2. Delete external volume mapping (see [“Deleting the External Volume Mapping \(Delete Volume Command\)” \(page 99\)](#)).
3. Disable the XP External Storage option on the Remote Web Console computer and on each storage system.

For detailed information about the uninstallation procedure, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

## Starting XP External Storage

This section explains how to start XP External Storage.

To start XP External Storage and display the window:

1. Start Remote Web Console, and open the Remote Web Console main window.  
For instructions, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.
2. Click **Go** and then **External Storage** on the menu bar of the Remote Web Console main window.  
Names of the windows which you need for XP External Storage operations are displayed in the submenu.
3. Click the name of the window you want to display.  
XP External Storage starts up, and the window you selected, opens.  
For details about the displayed windows, see [“Using the XP External Storage GUI” \(page 46\)](#).
4. Switch to **Modify** mode if necessary.  
For instructions, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

---

## 4 Using the XP External Storage GUI


This chapter explains the XP External Storage windows: Volume Operation, Path Operation, and Port Operation. When you click the tab of the window name, the window is switched to the corresponding window.

- [“Volume Operation Window” \(page 46\)](#)
- [“Path Operation Window” \(page 55\)](#)
- [“Port Operation Window” \(page 61\)](#)

### Volume Operation Window

Use the Volume Operation window to perform operations, such as mapping external volumes and setting cross-subsystem paths. To open the Volume Operation window, click **Go**, **External Storage**, and then **Volume Operation** on the menu bar of the Remote Web Console main window.

**Figure 22 Volume Operation Window**



Item	Description
Tree	The left pane of the window contains a tree and a list for changing the tree display. The information shown in the list on the right changes according to the items selected in the tree. For details, see <a href="#">Table 4 (page 48)</a> .
Status	<p>Provides the external volume status in the <b>Ext. VOL Status</b> column in the Volume Operation list. The <b>Ext. VOL Status</b> column does not show the status when you open the Volume Operation window, because displaying the external volume status takes longer than displaying other items in the window.</p> <ul style="list-style-type: none"> <li>• <b>Status: Disable:</b> The status is not displayed. Click <b>Status: Disable</b> to display the status. The button name changes to <b>Status: Enable</b>.</li> <li>• <b>Status: Enable:</b> The status is displayed.</li> </ul> <p>To update the all items in the window including the <b>Ext. VOL Status</b> column, make sure the button name is <b>Status: Enable</b>, then click <b>File</b> and <b>Refresh</b> on the menu bar of the Remote Web Console main window.</p>
List	Information on the local storage system and external storage system appears corresponding to the items selected in the tree. Sort the list by clicking the column headings.
Operation	The name of the performed setting operation. Click <b>Preview</b> to check the details.
Preview	Opens the Preview dialog box where you can confirm the contents set in the list of the Volume Operation window. The contents displayed in the Preview dialog box have not yet been applied to the local storage system.

Item	Description
<b>Apply</b>	<p>Applies the settings in the Preview dialog box to the local storage system.</p> <p>When the settings are applied successfully, they are removed from the Preview dialog box and the settings in blue italics in the Volume Operation window appear normally.</p> <p>When the settings are not applied, the error messages appear and the settings in blue italics remain in the Volume Operation window. To see the error detail, click <b>Preview</b> to open the Preview dialog box.</p>
<b>Cancel</b>	Cancels all the settings in the Preview dialog box.

Table 4 (page 48) shows how the items clicked in the tree control the information displayed in the list on the right:

**Table 4 Volume Operation Tree and List**

Items selected in the list	Items displayed in the tree (Clicked items are underlined)	Contents displayed in the list	Reference
Fibre	<b><u>Subsystem</u></b> + Product name + Path group	Information about the external storage system. The same contents are displayed when you click the product name in the tree.	"Volume Operation List (When Subsystem or Product Name is Clicked)" (page 50)
	<b><u>Subsystem</u></b> + <u>Product name</u> + Path group	Information about the external storage system. The same contents are displayed when you click the <b>Subsystem</b> in the tree.	
	<b><u>Subsystem</u></b> + Product name + <u>Path group</u>	The list of external volumes and cross-subsystem paths which are set in the selected path group.	"Volume Operation List (When Path Group is Clicked)" (page 51)



## Volume Operation Tree

The Volume Operation tree, on the left side of the Volume Operation window, contains the following:

Item	Description
List	Changes the items displayed in the Volume Operation tree. You can select <b>Fibre</b> as a PCB type.
Tree	<p>The following items appear in tree format. The information displayed in the list on the right changes corresponding to the items clicked in this tree.</p> <ul style="list-style-type: none"> <li>• <b>Subsystem</b>: The root node of the Volume Operation tree that is always displayed.</li> <li>• Product name of the external volume: The product name of the external storage system whose volumes are mapped by XP External Storage appears under <b>Subsystem</b>. The display format is <i>Vendor name: Product name (Serial number)</i>.</li> <li>• Path group: The path group set in the external storage system appears under the product name of the external storage system. When multiple path groups are set, the registration numbers are added after the Path Group (For example, Path Group 2).</li> </ul>
Pop-up menu	Right-click the item in the Volume Operation tree to perform the operations from the pop-up menu. For details, see <a href="#">Table 5 (page 49)</a> .

**Table 5 Pop-up Menu for the Volume Operation Tree**



Items displayed in the tree (Clicked items are underlined)	Pop-up Menu	Reference	Description
<b>Subsystem</b> + Product name + Path group	Add Volume (Auto) Add Volume (Manual)	<a href="#">“Mapping an External Volume Automatically” (page 67)</a> <a href="#">“Mapping an External Volume Manually” (page 68)</a>	Displays the Configure Cross-subsystem Paths dialog box or the Add Volume (Manual) dialog box. These dialog boxes allow you to set a new path group, and add external volumes to the new path group.
	Edit Policy	<a href="#">“Editing Mapping Policy” (page 98)</a>	Displays the Edit Policy dialog box. This dialog box allows you to edit the mapping policy.

**Table 5 Pop-up Menu for the Volume Operation Tree** *(continued)*

Items displayed in the tree (Clicked items are underlined)	Pop-up Menu	Reference	Description
<b>Subsystem</b> + <u>Product name</u> + Path group	Disconnect Subsystem Check Paths & Restore Volume	"Disconnecting External Storage System or Disconnecting External Volume" (page 91) "Checking Connection Status and Resuming External Volume Operation" (page 93)	Disconnects or reconnects the external volumes in the selected external storage system.
<b>Subsystem</b> + Product name + <u>Path group</u>	Add Volume (Auto) Add Volume (Manual)	"Mapping an External Volume Automatically" (page 67) "Mapping an External Volume Manually" (page 68)	Executed the volume discovery. All external volumes found by the volume discovery process appear in the following windows. <ul style="list-style-type: none"> <li>For the <b>Add Volume (Auto)</b> command: Volume Operation window</li> <li>For the <b>Add Volume (Manual)</b> command: Add Volume dialog box</li> </ul>

## Volume Operation List (When Subsystem or Product Name is Clicked)

When you click **Subsystem** or a product name in the Volume Operation tree, the external storage system information appears in the list.

External Subsystem			
Vendor	Product Name	Serial Number	Ext. VOL Status
 HP	XP24	50001FE150005710	-
 HP	MSA	500805F3000D80B0	-






Item	Description
<b>Vendor</b>	Name of the vendor.
<b>Product Name</b>	Name of the storage system.
<b>Serial Number</b>	Serial number of the storage system.
<b>Ext. VOL Status</b>	Status of the operation executed to the external volume or status of the connection of the mapping path. The displayed items are shown in <a href="#">Table 6 (page 51)</a> . To check status of each LDEV in the external volume, you need to view the VLL window.
Information Area	Information according to the contents of <b>External Subsystem</b> on the Volume Operation window appears in the information area, as follows: <ul style="list-style-type: none"> <li><b>Total Number of Ext. Subsystems:</b> The number of external storage systems that have the mapped external volumes.</li> <li><b>Total Number of Ext. Volumes:</b> The number of the mapped external volumes and the number of the external volumes that can be mapped.</li> </ul>

**Table 6 Status of the External Volume in Ext. VOL Status**

Displayed Item	Description
<b>Normal</b>	The path is normal.
-	The status of the mapping path is not retrieved yet. Click <b>Status</b> in the Volume Operation window to change the name of the button to <b>Status: Enable</b> , and display the status of the mapping path.
<b>Unknown</b>	The status of the mapping path is unknown.
<b>Blockade</b>	The mapping path is blocked.
<b>Warning</b>	There are mapping paths whose status is not normal. Check the status of the mapping paths in the Mapping Path Information dialog box.
<b>Checking</b>	The checking of the mapping path status is in progress.
<b>Cache Destage</b>	The writing of data in cache memory to the volume is in progress.
<b>Disconnect</b>	Connecting to the external storage system or the external volume is intentionally stopped using the <b>Disconnect Subsystem</b> command or the <b>Disconnect Volume</b> command.

## Volume Operation List (When Path Group is Clicked)

When you click a path group in the Volume Operation tree, the external storage system information and the cross-subsystem path information appears in the list.

External Volumes				
ExG	LDEV	Characteristic1	Device	C
 E1 - 1	-	0000	OPEN-V	
 E1 - 2	-	0001	OPEN-V	
 E1 - 4	-	0003	OPEN-V	
<div><div></div><div></div></div>				
Cross-subsystem Paths				
Priority	Port	WWN		
 1	CL1-A	0111111000000000		
 2	CL3-A	0111111000000001		

The External Volumes list provides the following information:

Item	Description
<b>ExG</b>	External volume group number and sequential number assigned to each volume in the external volume group. This appears in the format of <i>external volume group number - sequential number of volume in the group</i> . The sequential numbers of volumes in the group are automatically assigned by XP External Storage when the external volumes are mapped.
<b>LDEV</b>	LDKC:CU:LDEV number that is assigned to the external volume. When multiple LDEVs are created in the external volume, the top LDEV number appears, and [...] appears at the end of the number.
<b>Characteristic1</b>	Identification number of the external volume.
<b>Device</b>	Name of the storage system that is reported to the host by the external volume. The displayed items differs depending on the vendor of the storage system.
<b>Capacity (blocks)</b>	Capacity, in blocks, of the external volume.
<b>Cache Mode</b>	Indicates whether the write data from the host to the external storage system is propagated synchronously ( <b>Disable</b> ) or asynchronously ( <b>Enable</b> ). Data that is not written by the host (for example, data written by XP Business Copy) is asynchronously destaged to the external storage system regardless of the <b>Cache Mode</b> setting.
<b>Inflow Control</b>	Indicates whether the writing operation to the cache memory is stopped ( <b>Enable</b> ) or continued ( <b>Disable</b> ) when the writing operation to the external volume is impossible.
<b>Path Mode</b>	Indicates how the cross-subsystem paths work. The modes of the cross-subsystem path are as follows: <ul style="list-style-type: none"> <li>• <b>Single</b>: Only the cross-subsystem path with the highest priority (primary path) is used to execute the I/O to the external volume. When an error occurred in the primary path, the path with the second highest priority is used.</li> <li>• <b>Multi</b>: All of the cross-subsystem paths are used at the same time. The multiple paths are used to execute the I/Os to the external volume distributing the work load.</li> <li>• <b>APLB</b>: All of the cross-subsystem paths are used at the same time. The multiple paths are used to execute the I/Os to the external volume distributing the work load. However, the paths are not used when the paths are connected to ports in the Passive status.</li> </ul>
<b>Ext. VOL Info</b>	Information about the external volume. An asterisk (*) appears when the external volume is a SATA drive of the following storage systems. Usage of SATA drives differs depending on storage systems, and therefore SATA drives should be used accordingly. <ul style="list-style-type: none"> <li>• USP V/USP VM storage system</li> <li>• AMS/WMS storage system</li> <li>• SMS storage system</li> <li>• Thunder 9500V series storage system</li> </ul> A dollar sign (\$) appears when the external volume is an SSD drive of the USP V/USP VM storage system. Usage of SSD drives differs depending on storage systems, and therefore SSD drives should be used accordingly.

Item	Description
<b>Ext. VOL Status</b>	Status of the operation executed to the external volume or status of the connection of the mapping path. For the displayed status descriptions, see <a href="#">Table 6 (page 51)</a> . To check status of each LDEV in the external volume, view the VLL window.
<b>Progress</b>	Appears when the <b>Status</b> is <b>Cache Destage</b> . The progress status of destaging processing is displayed in 1% to 99%.
<b>Characteristic2</b>	Extended identification number of the external volume. This information is used for identifying volumes in the EVA storage system.  For details about <b>Characteristic2</b> , see <a href="#">"Connecting External Storage Systems" (page 134)</a> .
Pop-up menu	Right-click a row in the External Volumes list (at the top of the window) to perform the following operations: <ul style="list-style-type: none"> <li>• Mapping Path Information: Opens the Mapping Path Information dialog box. This dialog box allows you to see the list of the mapping paths set to the selected external volume. See <a href="#">"Checking the External Volume Details" (page 85)</a>.</li> <li>• LDEV Information: Opens the LDEV Information dialog box. This dialog box allows you to see the emulation type and the capacity of the selected external volume. See <a href="#">"Checking the External Volume Details" (page 85)</a>.</li> <li>• Delete Volume: Cancels the mapping of the selected external volume. See <a href="#">"Deleting the External Volume Mapping (Delete Volume Command)" (page 99)</a>.</li> <li>• Disconnect Volume: Disconnects the selected external volume. See <a href="#">"Disconnecting an Individual External Volume (Disconnect Volume Operation)" (page 92)</a>.</li> <li>• Check Paths &amp; Restore Volume: Reconnects the selected external volume. See <a href="#">"Checking Connection Status and Resuming External Volume Operation" (page 93)</a>.</li> <li>• Change Cache Mode: Changes the cache mode set to the selected external volume. See <a href="#">"Changing the Cache Mode Setting of the External Volume" (page 95)</a>.</li> <li>• Inflow Control: Allows you to select whether to stop writing to the cache memory when it is impossible to write to the selected external volume. See <a href="#">"Changing the Inflow Control Setting of the External Volume" (page 96)</a>.</li> </ul>

The Cross-system Paths list provides the following information:

**Table 7 Cross-subsystem Paths List Details**

Item	Description
<b>Priority</b>	Priority of the cross-subsystem paths, where <b>1</b> indicates the cross-subsystem path with the highest priority.
<b>Port</b>	The port number in the local storage system connecting to the external storage system.

**Table 7 Cross-subsystem Paths List Details** *(continued)*

Item	Description
<b>WWN</b>	Identification number of the port in the external storage system.
Pop-up menu	Right-click a row in the <b>Cross-subsystem Paths</b> list (at the bottom of the window) to perform the following operation: <ul style="list-style-type: none"><li>• <b>Configure Cross-Subsystem Paths</b>: Opens the Configure Cross-subsystem Paths dialog box. This dialog box allows you to add and delete cross-subsystem paths, and also change the priority of the selected cross-subsystem path. See <a href="#">“Configure Cross-subsystem Paths Dialog Box”</a> (page 79).</li></ul>


## Preview Dialog Box

Use the Preview dialog box to check or cancel the settings that will be applied to the local storage system. To display the Preview dialog box, click **Preview** in the Volume Operation window, the Path Operation window, or the Port Operation window. This document uses the phrase *XP External Storage windows* for these three windows.

The contents displayed in the Preview dialog box are displayed in blue and italics in the list of the XP External Storage windows. The contents displayed in the Preview dialog box have not yet been applied to the local storage system. When you click **Apply** on the XP External Storage windows, the settings in the Preview dialog box are applied to the local storage system. When the settings are applied, the contents of the Preview dialog box disappear, and the list of the XP External Storage windows appears normally. When you click **Cancel** on the XP External Storage windows, all the settings in the Preview dialog box are canceled.

When the settings in the Preview dialog box are not applied to the local storage system even if you click **Apply** on the XP External Storage windows, an error message appears and the erroneous settings are displayed in blue and italics in the XP External Storage windows. To see the error detail, click **Preview** to open the Preview dialog box.


The identical error codes may be displayed for all the errors listed in the Preview dialog box depending on the type of errors occurred. In this case, check the status of settings and identify the error source.



Item	Description
Preview Area	A list of the items that are set in the list of the XP External Storage windows. The items appearing in the preset area differ depending on the items set in the list of the XP External Storage windows. The items in the preset area appear in blue italics in the list of the XP External Storage windows.
Information Area	The operation information on the settings displayed in the Preview dialog box appears. The following information is available: <ul style="list-style-type: none"> <li>• <b>Operation:</b> name of the setting operation.</li> <li>• <b>Total Number of Objects in Preview:</b> the number of settings displayed in the Preview dialog box.</li> </ul>
Close	Closes the Preview dialog box and returns to the XP External Storage windows.
Pop-up menu	Right-click a row in the Preview dialog box to perform the following operations: <ul style="list-style-type: none"> <li>• <b>Error Message:</b> Displays the error message of the selected setting.</li> <li>• <b>Delete:</b> Cancels the settings selected in the Preview dialog box.</li> </ul>

## Path Operation Window

Use the Path Operation window to stop or resume using cross-subsystem paths. To display the Path Operation window, click **Go**, **External Storage**, and then **Path Operation** on the menu bar of the Remote Web Console main window.



Item	Description
Tree	The left pane of the window contains a tree and a list for changing the tree display. The information displayed in the list on the right changes corresponding to the items selected in the tree. For details, see <a href="#">Table 8 (page 57)</a> .
Status	<p>Provides the cross-subsystem path status in the <b>Status</b> column in the Path Operation list. The Status column does not show the status when you open the Path Operation window, because displaying the cross-subsystem path status takes longer than displaying other items in the window.</p> <ul style="list-style-type: none"> <li>• <b>Status: Disable:</b> The status is not displayed. Click <b>Status: Disable</b> to display the status. The button name changes to <b>Status: Enable</b>.</li> <li>• <b>Status: Enable:</b> The status is displayed.</li> </ul> <p>To update the all items in the window including the <b>Status</b> column, make sure the button name is <b>Status: Enable</b>, then click <b>File</b> and <b>Refresh</b> on the menu bar of the Remote Web Console main window.</p>
List	Information on the local storage system and external storage system appears corresponding to the items selected in the tree. Sort the list by clicking the column heading.
Operation	The name of the performed setting operation. Click <b>Preview</b> to check the details.
Preview	Opens the Preview dialog box where you can confirm the contents set in the list of the Path Operation window. The contents displayed in the Preview dialog box have not yet been applied to the local storage system.



Item	Description
<b>Apply</b>	<p>Applies the settings in the Preview dialog box to the local storage system.</p> <p>When the settings are applied successfully, they are removed from the Preview dialog box and the settings in blue italics in the Path Operation window appear normally.</p> <p>When the settings are not applied, the error messages are displayed and the settings in blue italics remain in the Port Operation window. To see the error detail, click <b>Preview</b> to open the Preview dialog box.</p>
<b>Cancel</b>	Cancels all the settings in the Preview dialog box.



Table 8 (page 57) shows how the items clicked in the tree control the information appearing in the list on the right:

**Table 8 Path Operation Tree and List**

Items selected in the list	Items displayed in the tree (Clicked items are underlined)	Contents displayed in the list	Reference
Fibre - Local Subsystem	<u>Subsystem</u> + Port number	External ports of the local storage system.	"Path Operation List (When Subsystem is Clicked)" (page 58)
	<u>Subsystem</u> + <u>Port number</u>	<p>Cross-subsystem paths that are set to the selected external ports of the local storage system.</p> <p>The same contents are displayed when you click the WWN in the tree.</p>	"Path Operation List (When Port or WWN is Clicked)" (page 60)
Fibre - External Subsystem	<u>Product name</u> + WWN	WWNs of the external storage system.	"Path Operation List (When Product Name is Clicked)" (page 60)
	Product name + <u>WWN</u>	<p>Cross-subsystem paths which are set to the selected WWN of the external storage system.</p> <p>The same contents are displayed when you click the port number in the tree.</p>	"Path Operation List (When Port or WWN is Clicked)" (page 60)











## Path Operation Tree



The Path Operation tree, on the left side of the Path Operation window, contains the following:

Item	Description
List	<p>Changes the items displayed in the Path Operation tree. You can select which side to display the information on cross-subsystem paths from.</p> <p><b>Fibre - Local Subsystem:</b> Displays ports in the local storage system.</p> <p><b>Fibre - External Subsystem:</b> Displays ports (WWNs) in the external storage system.</p>
Tree	<p>The following items appear in tree format. The information displayed in the list on the right changes corresponding to the items clicked in this tree.</p> <p>When you select <b>Fibre - Local Subsystem</b> from the list, the following items appear in the tree:</p> <ul style="list-style-type: none"><li>• <b>Subsystem:</b> The root node of the Path Operation tree that is always displayed.</li><li>• Port number: The port number of the local storage system, for which the port attribute is set to External, appears under <b>Subsystem</b>. One of the following icons appears:<ul style="list-style-type: none"><li>: Ports in the Standard mode.</li><li>: Ports in the Initiator/External MIX mode.</li></ul></li></ul> <p>When you select <b>Fibre - External Subsystem</b> from the list, the following items appear in the tree:</p> <ul style="list-style-type: none"><li>• Product name of the external volume: The product name of the external storage system that is connected by XP External Storage appears as a root node. The display format is <i>Vendor name: Product name (Serial number)</i>.</li><li>• WWN: The WWNs of the external storage system appear under the product name of the external storage system.</li></ul>

## Path Operation List (When Subsystem is Clicked)

When you click **Subsystem** in the Path Operation tree, the external port information that is set to the local storage system appears in the list on the right.

Port				
Port	PLI_TOV	FLI_TOV	Margin	Status
 CL1-A	5	10	0	-
 CL3-A	5	10	0	-
 CL5-A	5	10	0	-
 CL7-A	5	10	0	-
 CL1-B	5	10	0	-
 CL5-B	5	10	0	-
 CL2-A	5	10	0	-
 CL6-A	5	10	0	-
 CL2-B	5	10	0	-
 CL6-B	5	10	0	-

Item	Description
<b>Port</b>	<p>The external port of the local storage system. One of the following icons appears:</p> <p>: Ports in the Standard mode.</p> <p>: Ports in the Initiator/External MIX mode.</p>
<b>PLI_TOV</b>	The wait time (in seconds) of PLOGI to the external storage system when the switch is not connected. This value is automatically set by XP External Storage. You cannot change the value.
<b>FLI_TOV</b>	The wait time (in seconds) from the switch to FLOGI when the switch is connected. This value is automatically set by XP External Storage. You cannot change the value.
<b>Margin</b>	The additional wait time (in seconds) to <b>FLI_TOV</b> (FLOGI wait time) or <b>PLI_TOV</b> (PLOGI wait time). This value is automatically set by XP External Storage. You cannot change the value. As a result, the sum of <b>FLI_TOV</b> time and the margin time, or the sum of <b>PLI_TOV</b> time and the margin time is set as a total wait time.
<b>Status</b>	Status of the cross-subsystem path. <a href="#">Table 9 (page 59)</a> shows the displayed statuses.
Pop-up menu	<p>Right-click a row in the list to perform the operations:</p> <ul style="list-style-type: none"> <li>• <b>Disconnect Paths:</b> Allows you to stop the use of the cross-subsystem paths that are connected to the selected external port of the local storage system. See <a href="#">“Stopping the Use of Paths to the External Volume (Disconnect Paths)” (page 94)</a>.</li> <li>• <b>Check Paths:</b> Allows you to resume using the cross-subsystem paths that are connected to the selected external port of the local storage system. See <a href="#">“Restoring the Paths to the External Volume (Check Paths)” (page 95)</a>.</li> </ul>

**Table 9 Status of the Cross-subsystem Path Displayed in the Status**

Displayed Item	Description
<b>Normal</b>	The cross-subsystem path is normal.
-	The status of the cross-subsystem path is not retrieved yet. Click <b>Status</b> in the Path Operation window to change the name of the button to <b>Status: Enable</b> , and display the status of the cross-subsystem path.
<b>Unknown</b>	The status of the cross-subsystem path is unknown.
<b>Blockade</b>	The cross-subsystem path is blocked.

**Table 9 Status of the Cross-subsystem Path Displayed in the Status** *(continued)*

Displayed Item	Description
<b>Disconnect</b>	Connecting to the external storage system or the external volume is intentionally stopped using the <b>Disconnect Subsystem</b> command or the <b>Disconnect Volume</b> command.
<b>Warning</b>	There are cross-subsystem paths whose status is not normal. Check the status of the cross-subsystem paths.
<b>Checking</b>	The processing of checking the cross-subsystem path status is in progress.

## Path Operation List (When Product Name is Clicked)

When you click a product name in the Path Operation tree, the WWN indicating the port in the external storage system appears in the list on the right.

WWN				
WWN	QDepth	I/O TOV	Path Watch	
0111111000000000	8	15	10	▶
0111111000000001	8	15	10	

Item	Description
<b>WWN</b>	WWN indicating the port in the external storage system. WWN appears after the connection setting is completed.
<b>QDepth</b>	The number of Read/Write commands which can be issued (queued) to the external volume at a time.
<b>I/O TOV</b>	Value specified as the time over of the I/O to the external volume.
<b>Path Watch</b>	The time from when the connection of all the cross-subsystem paths to the external volume have been down to when the external volume is blocked.
<b>Status</b>	Status of the cross-subsystem path. <a href="#">Table 9 (page 59)</a> shows the displayed statuses.
Pop-up menu	<p>Right-click a row in the list to perform the operations:</p> <ul style="list-style-type: none"> <li>• <b>Disconnect Paths:</b> Allows you to stop the use of the cross-subsystem paths that are connected to the selected external port of the local storage system. See <a href="#">“Stopping the Use of Paths to the External Volume (Disconnect Paths)”</a> (page 94).</li> <li>• <b>Check Paths:</b> Allows you to resume using the cross-subsystem paths that are connected to the selected external port of the local storage system. See <a href="#">“Restoring the Paths to the External Volume (Check Paths)”</a> (page 95).</li> <li>• <b>Change WWN Parameter:</b> Opens the Change WWN Parameter dialog box where you can change the parameters on the port of the external storage system. See <a href="#">“Changing the Port Setting of the External Storage System”</a> (page 97).</li> </ul>

## Path Operation List (When Port or WWN is Clicked)


When you click a port or WWN in the Path Operation tree, a cross-subsystem path appears in the list on the right.

Cross-subsystem Paths			
Port	WWN	Vendor	I
CL4-A	50001FE15000571C	HP	XP24

Item	Description
<b>Port</b>	External port in the local storage system.
<b>WWN</b>	WWN indicating the target port in the external storage system.
<b>Vendor</b>	Vendor name of the external storage system.
<b>Product Name</b>	Product name of the external storage system.
<b>Serial Number</b>	Serial number of the external storage system.
<b>Status</b>	Status of the cross-subsystem path. <a href="#">Table 9 (page 59)</a> shows the displayed statuses.

## Port Operation Window

Use the Port Operation window to check the settings of ports and set the port attributes. To display the Port Operation window, click **Go, External Storage**, and then **Port Operation** on the menu bar of the Remote Web Console main window.



Item	Description
Tree	The left pane of the window contains a tree and a list for changing the tree display. The information displayed in the list on the right changes corresponding to the items selected in the tree.
List	Information on the port appears corresponding to the items selected in the tree. Sort the list by clicking the column headings.
Operation	The name of the performed setting operation. Click <b>Preview</b> to check the details.
Preview	Opens the Preview dialog box where you can confirm the contents set in the list of the Port Operation window. The contents displayed in the Preview dialog box have not yet been applied to the local storage system. For details on the Preview dialog box, see <a href="#">“Preview Dialog Box”</a> (page 54).
Apply	Applies the settings in the Preview dialog box to the local storage system.  When the settings are applied successfully, they are removed from the Preview dialog box and the settings in blue italics in the Port Operation window appear normally.  When the settings are not applied, the error messages appear and the settings in blue italics remain in the Port Operation window. To see the error detail, click <b>Preview</b> to open the Preview dialog box.
Cancel	Cancels all the settings in the Preview dialog box.




## Port Operation Tree

The Port Operation tree, on the left side of the Port Operation window, contains the following:

Item	Description
List	Changes the items displayed in the Port Operation tree. You can select <b>Fibre</b> as a PCB type.
Tree	<p>The ports in the local storage system appear in the tree. The information displayed in the list on the right changes corresponding to the items clicked in this tree. For instance, when you click <b>External</b> in the tree, only the ports that port attributes are set to external are displayed in the Port Operation list.</p> <ul style="list-style-type: none"><li>• <b>Subsystem</b>: Nothing appears in the list when you select <b>Subsystem</b>. <b>Subsystem</b> is selected, when you display the Port Operation window.</li><li>• <b>External</b>: When you click <b>External</b>, the ports set to the external port are displayed in the list. The external port is the port attribute used for XP External Storage. The external port does not have the High Speed mode.</li><li>• <b>Target</b>: When you click <b>Target</b>, the ports set as the target port are displayed in the list.</li><li>• <b>Initiator</b>: When you click Initiator, the ports set as the initiator port (used for XP Continuous Access, TrueCopy for Mainframe, XP Continuous Access Journal, Universal Replicator for Mainframe, and so on) are displayed in the list.</li><li>• <b>RCU Target</b>: When you click <b>RCU Target</b>, the ports set as the RCU target port (used for XP Continuous Access, TrueCopy for Mainframe, XP Continuous Access Journal, Universal Replicator for Mainframe, and so on) are displayed in the list.</li><li>• <b>Initiator/External</b>: When you click <b>Initiator/External</b>, the ports for which the Initiator/External MIX mode is set are displayed in the list.</li></ul>

## Port Information List

When you click the items in the Port Operation tree, the following information about the port in the local storage system appears in the list on the right.

Item	Description
Port	<p>Port number. One of the following icons appears on the left of each port:</p> <ul style="list-style-type: none"><li>• : Ports in the Standard mode.</li><li>• : Ports in the High Speed mode.</li><li>• : Ports in the Initiator/External MIX mode.</li></ul>
Attribute	<p>Port attribute. The external ports are used for connecting to the external storage system. When you want to set the remote command device, you can use the port for which the Initiator/External MIX mode has been set.</p>

Item	Description
PCB Mode	<p>The PCB mode of the port.</p> <ul style="list-style-type: none"> <li>• <b>Standard</b></li> <li>• <b>High Speed</b></li> <li>• <b>MIX</b> (for Initiator/External MIX mode)</li> </ul> <p>The external ports do not have the High Speed mode. For detailed information on the PCB mode, see the <i>HP StorageWorks XP24000/XP20000 LUN Manager User Guide</i>.</p>
Information Area	<p>The total number of ports in the Port Operation list (<b>Total Number of Ports</b>).</p>
Pop-up menu	<p>Right-click a row in the <b>Port Information</b> list to perform the following operations.</p> <ul style="list-style-type: none"> <li>• Change to External: Allows you to change the selected port attribute to external. See <a href="#">“Setting Port Attribute for Local Storage System”</a> (page 67).</li> <li>• Change to Target: Allows you to change the selected port attribute to target. See <a href="#">“Setting Port Attribute for Local Storage System”</a> (page 67).</li> </ul>



---

## 5 Performing XP External Storage Operations


This chapter describes setting the external volume using XP External Storage.

- [“Overview of Setting Operations” \(page 65\)](#)
- [“Setting Port of External Storage System” \(page 66\)](#)
- [“Setting Port Attribute for Local Storage System” \(page 67\)](#)
- [“Mapping an External Volume Automatically” \(page 67\)](#)
- [“Mapping an External Volume Manually” \(page 68\)](#)
- [“Setting the Cross-subsystem Paths” \(page 78\)](#)
- [“Checking the External Volume Details” \(page 85\)](#)
- [“Turning On or Off the Storage System” \(page 88\)](#)
- [“Disconnecting External Storage System or Disconnecting External Volume” \(page 91\)](#)
- [“Checking Connection Status and Resuming External Volume Operation” \(page 93\)](#)
- [“Stopping the Use of Paths to the External Volume \(Disconnect Paths\)” \(page 94\)](#)
- [“Restoring the Paths to the External Volume \(Check Paths\)” \(page 95\)](#)
- [“Changing the Cache Mode Setting of the External Volume” \(page 95\)](#)
- [“Changing the Inflow Control Setting of the External Volume” \(page 96\)](#)
- [“Changing the Port Setting of the External Storage System” \(page 97\)](#)
- [“Editing Mapping Policy” \(page 98\)](#)
- [“Deleting the External Volume Mapping \(Delete Volume Command\)” \(page 99\)](#)

### Overview of Setting Operations

The following flow chart illustrates XP External Storage setting operations, which make external volumes usable from a host.

**Figure 23 Operations of Making External Volumes Usable from a Host**



The outlined procedure for making the external volumes usable from a host is as follows:

1. Prepare a volume in the external storage system.
2. Set the port and system parameters for the external storage system.  
For the procedure, see the documents for your external storage system.  
Also see [“Setting Port of External Storage System”](#) (page 66) and [“Connecting External Storage Systems”](#) (page 134).
3. Start Remote Web Console and set the attribute of the port connecting the external storage system to External in the Port Operation window of XP External Storage (see [“Setting Port Attribute for Local Storage System”](#) (page 67)).
4. Map the external volume to the internal volume.  
You can map external volumes automatically or manually in the Volume Operation window. For the difference between automatic mapping and manual mapping, see [“Difference between Automatic Mapping and Manual Mapping”](#) (page 26).
5. Perform the following operation according to the emulation type that you set for mapping.
  - If you select the emulation type of mainframe, you need to format the volume or perform the **Write to Control Blocks** operation using Virtual LVI/LUN (VLL). For the procedure to format the volume and perform the **Write to Control Blocks** operation, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.
  - If you select the emulation type of open-system, you need to define LU paths to a host using LUN Manager. For the defining LU paths procedure, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.

## Setting Port of External Storage System

This section describes the procedure for setting the port of the external storage system. For detailed information, see the documentation for the external storage system you use.

To set the port of the external storage system:

1. Set the topology information according to the configuration of the connection.
2. According to the configuration, set the data transfer speed.
3. Set the system parameters.  
See [“Connecting External Storage Systems” \(page 134\)](#) to set the system parameters for the external storage systems.
4. Define the LUN to the port that is set.

## Setting Port Attribute for Local Storage System

The port attribute used for XP External Storage must be set to the external port.

If the storage system is partitioned by using XP Disk/Cache Partition, the ports that can be set as external ports are only the ports allocated to SLPR 0.

To set the port attribute to the external port:

1. Start Remote Web Console, and open the Port Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Right-click the port that you want to set to external port in the Port Operation list.  
To set multiple ports to external ports at a time, select and right-click all the ports you want to set.
4. Click **Change to External** in the pop-up menu.  
In the **Port Operation** list, the attribute of the selected port is changed to **External**, and the row of the selected port is displayed in blue italics.
5. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
6. Click **Apply** in the Port Operation window.  
The settings are applied to the local storage system and the Port Operation window is displayed normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.
7. Set the topology information according to the configuration of the connection.  
When the switch is connected, set the **Fabric** to **Enable**. When the switch is not connected, set the **Fabric** to **Disable** and set **FC-AL**. Set the **Connection** according to the configuration of the actual connection. For detailed information on setting the topology information, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.
8. Set the data transfer speed according to the configuration.

For the data transfer speed, select the Auto Negotiation setting.

When connecting an AMS/WMS storage system, use LUN Manager to set the data transfer speed of the external port to a fixed value other than the **Auto**. Also, set the data transfer speed of the target port of the AMS/WMS storage system to the fixed value according to the data transfer speed of the external port.

## Mapping an External Volume Automatically

After setting the attribute of the port used for XP External Storage to the external port, you can map the external volume as an internal volume.

Before you map the external volume, check whether any application (for example, RAID Manager) is using the command device. If there is, stop the application.

External volumes can be mapped either automatically or manually. This section explains automatic mapping. For the difference between automatic mapping and manual mapping, see [“Difference between Automatic Mapping and Manual Mapping”](#) (page 26).

- △ **CAUTION:** Do not specify 01 for the LDKC number when you map a volume of which the emulation type is 3380 series except for 3380-3, 3380-3A, 3380-3B, 3380-3C. Before you apply the mapping configuration, make sure the LDKC number that is automatically assigned is 00.

To map the external volume automatically:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Right-click one of the following in the Volume Operation tree:
  - **Subsystem:** Allows you to create a new path group, and add external volumes to the new path group.
  - **Path group:** Allows you to add external volumes to the existing path group.
4. Click **Add Volume (Auto)** in the pop-up menu, and then click the desired mapping policy in the submenu.
  - When you click the **Subsystem** in the Volume Operation tree, the Configure Cross-subsystem Paths dialog box opens. Go to step 5.
  - When you click the path group in the Volume Operation tree, the volume discovery is executed and all the external volumes found by the volume discovery are displayed in blue italics in the Volume Operation window. Go to step 7.
5. Configure cross-subsystem paths in the Configure Cross-subsystem Paths dialog box (see [“Configuring the Cross-subsystem Path”](#) (page 81)).  
Configure at least two cross-subsystem paths and change the priority if necessary.
6. Click **OK** to close the Configure Cross-subsystem Paths dialog box and return to the Volume Operation window.  
The volume discovery is executed, and all the external volumes found by the volume discovery are mapped. The settings appear in blue italics.
7. Verify the settings in the Preview dialog box (see [“Preview Dialog Box”](#) (page 54)).
8. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Mapping an External Volume Manually

After setting the attribute of the port used for XP External Storage to the external port, you can map the external volume as an internal volume.

Before you map the external volume, check whether any application (for example, RAID Manager) is using the command device. If there is, stop the application.

- △ **CAUTION:** Do not specify 01 for the LDKC number when you map a volume of which the emulation type is 3380 series except for 3380-3, 3380-3A, 3380-3B, 3380-3C.

To map the external volume manually:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.

3. Right-click one of the following in the Volume Operation tree:
  - **Subsystem**: Allows you to create a new path group, and add external volumes to the new path group
  - **Path group**: Allows you to add external volumes to the existing path group.
4. Click **Add Volume (Manual)** in the pop-up menu, and then click the desired mapping policy in the submenu.
  - When you click the **Subsystem** in the Volume Operation tree, the Configure Cross-subsystem Paths dialog box opens. Go to step 5.
  - When you click the path group in the Volume Operation tree, the volume discovery is executed and the Add Volume dialog box opens. Go to step 7.
5. Configure cross-subsystem paths in the Configure Cross-subsystem Paths dialog box (see [“Configuring the Cross-subsystem Path” \(page 81\)](#)).  
Configure at least two cross-subsystem paths and change the priority if necessary.
6. Click **OK** to close the Configure Cross-subsystem Paths dialog box.  
The volume discovery is executed and all the external volumes found by the volume discovery appear in the Add Volume dialog box.  
The Add Volume dialog box shows a list of all the external volumes that can be mapped to the local storage system. To map these volumes, set the external volume parameter or the LDEV number as explained in the following steps.
7. In the Add Volume dialog box (see [“Add Volume Dialog Box” \(page 70\)](#)), right-click the external volume that you want to map.  
You can select multiple external volumes to make the same settings to them at a time. When you map LDEVs, you can select the multiple external volumes which have the same emulation type.
8. Click each command in the pop-up menu and make the settings in the resulting dialog box. Execute the operations in the following order (a and then b).
  - a. The **Set External Volume Parameter** command (see [“Set External Volume Parameter Dialog Box” \(page 72\)](#)): Allows you to configure the external volume parameters. After you configure parameters, click **OK** to close the displayed dialog box.
  - b. Configure the LDKC:CU:LDEV number to the LDEVs in the external volume. After you configure the number, click **OK** to close the displayed dialog box.  
The **LDEV Mapping (Auto)** command (see [“LDEV Mapping \(Auto\) Dialog Box” \(page 73\)](#)): Allows you to specify the LDEV number to the first LDEV in the external volume. The rest of LDEVs are automatically allocated to the subsequent LDEV number. For the example of operation, see [“Example: How to Map LDEVs Automatically” \(page 77\)](#).  
The **LDEV Mapping (Manual)** command (see [“LDEV Mapping \(Manual\) Dialog Box” \(page 74\)](#)): Allows you to specify the LDEV number to all the LDEVs in the external volume. For the example of operation, see [“Example: How to Map LDEVs Manually” \(page 77\)](#).  
Both commands allow you to specify the interval between LDEV numbers.

When you close the dialog box, the Add Volume dialog box opens.

9. In the Add Volume dialog box, make the settings to all the volumes you want to map (repeat step 7 and step 8).  
Delete the external volume that you do not want to map in the Add Volume dialog box. To delete the external volume, right-click the external volume and click **Delete** in the pop-up menu.

10. Click **OK** to close the Add Volume dialog box.
  - When the SSID setting is required, the SSID dialog box opens (see “SSID Dialog Box” (page 75)). Go to step 11.
  - When the SSID setting is not required, the Volume Operation window opens. Go to step 15.
11. In the SSID dialog box, right-click an LDEV for which SSID is not specified, and then click **SSID** in the pop-up menu.  
The Set SSID dialog box opens.
12. In the Set SSID dialog box, select a value from the SSID list and click **OK**.  
The selected value appears in the SSID dialog box.
13. In the SSID dialog box, make the settings to all the LDEVs that you need to set SSID to (repeat step 11 and step 12).
14. Click **OK** to close the SSID dialog box and return to the Volume Operation window.  
The settings appear in blue italics.
15. Verify the settings in the Preview dialog box.
16. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.


## Add Volume Dialog Box

Use the Add Volume dialog box to view the external volume parameter or LDEV number that is configured to the LDEVs in the external volume. The Add Volume dialog box automatically opens when you click the **Add Volume (Manual)** command in the Volume Operation window.

The Add Volume dialog box shows the list of the external volumes that can be mapped to the local storage system. To map the external volume, you need to configure the external volume parameter and the LDEV number. The parameter that you have not configured is shown with a hyphen (-) .

To configure the parameter, click the external volume with the parameter that you have not configured, and open the other dialog boxes from the Add Volume dialog box. Delete the external volume if the Add Volume dialog box contains the external volume that you do not want to map.

**Figure 24 Add Volume Dialog Box**



The Add Volume dialog box consists of:

- **List** (for more information, see [“Volume Operation List \(When Path Group is Clicked\)”](#) (page 51))
  - **Characteristic1:** Identification number of the external volume.
  - **ExG:** External volume group number and its sequential number.
  - **Emulation Type:** Emulation type of the external volume.
  - **LDEV:** LDKC:CU:LDEV number assigned to the external volume.
  - **Number of LDEVs:** Number of LDEVs that are actually created in the external volume.
  - **SLPR/CLPR:** SLPR and CLPR used to access the external volume. Appears when the cache memory is partitioned using XP Disk/Cache Partition.
  - **Cache Mode:** Indicates whether the write data from the host to the external storage system is propagated synchronously (**Disable**) or asynchronously (**Enable**).
  - **Inflow Control:** Indicates whether the writing operation to the cache memory is stopped (**Enable**) or continued (**Disable**) when the writing operation to the external volume is impossible.
  - **Path Mode:** Indicates how the cross-subsystem paths work.
  - **Device:** Product name reported to the host by the external volume.
  - **Ext. VOL Info:** Information about the external volume.
  - **Capacity (blocks):** Capacity of the external volume in blocks.
  - **Characteristic2:** Extended identification number of the external volume.
- **OK** button  
Saves the settings and closes the dialog box.
- **Cancel** button  
Cancels the settings and closes the dialog box.
- **Pop-up Menu**  
Right-click a row in the Add Volume dialog box to perform the following operations.

**Table 10 Pop-up Menu in the Add Volume dialog box**

Pop-up menu	Description
Set External Volume Parameter	Opens the Set External Volume Parameter dialog box where you can set the parameters. See <a href="#">“Set External Volume Parameter Dialog Box”</a> (page 72).
LDEV Mapping (Auto)	Opens the LDEV Mapping (Auto) dialog box where you can specify the LDEV number to the first LDEV in the external volume. See <a href="#">“LDEV Mapping (Auto) Dialog Box”</a> (page 73).
LDEV Mapping (Manual)	Opens the LDEV Mapping (Manual) dialog box where you can specify the LDEV number to all the LDEVs in the external volume. See <a href="#">“LDEV Mapping (Manual) Dialog Box”</a> (page 74).
Delete	Allows you to delete the external volume from the Add Volume dialog box.



## Set External Volume Parameter Dialog Box

Use the Set External Volume Parameter dialog box to set the external volume parameter. The Set External Volume Parameter dialog box opens when you right-click the external volume in the Add Volume dialog box and click the **Set External Volume Parameter** in the pop-up menu.

**Figure 25 Set External Volume Parameter Dialog Box**

<b>Set External Volume Parameter</b>	
ExG (1 - 16384)	E
Emulation Type	OPEN-V <input type="checkbox"/> Except OPEN-V
Number of LDEVs	2048
Cache Mode	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Inflow Control	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
CLPR	0 SLPR0
OK Cancel	

The Set External Volume Parameter dialog box consists of:

- **ExG (1-16384)**  
Group number of the connected external volume. Specify the number using decimal numbers from 1 to 16384. The **E** displayed outside of the text box is the capital letter of the external volume group.
- **Emulation Type**  
Select the emulation type of the mapped external volume from the list.  
Before you map the external volume as an open system volume, first decide the emulation type for the mapped volume, OPEN-V or other than OPEN-V. To map the external volume as an open system volume with the emulation type other than OPEN-V, select the **Except OPEN-V** check box.
  - When you clear the **Except OPEN-V** check box, OPEN-V and available mainframe emulation types appear in the list.
  - When you select the **Except OPEN-V** check box, the emulation types for the open system other than OPEN-V also appear in the list.
- **Number of LDEVs**  
Select the maximum number of LDEVs that can be created in the external volume when you map the external volume. This number is different corresponding to the capacity supported by the emulation type specified in the **Emulation Type**. The number of LDEVs which are actually created in the external volume appears in the **Number of LDEVs** column in the Add Volume dialog box after you set this parameter in the Set External Volume Parameter dialog box.
- **Cache mode**  
Cache mode specifies if the write data from the host is propagated synchronously (**Disable**) or asynchronously (**Enable**) to the external storage system.  
Data that is not written by the host (for example, data written by XP Business Copy) is asynchronously destaged to the external storage system regardless of the **Cache Mode** setting.  
If you set **Disable**, the bind mode of Cache Residency Manager cannot be set.



- **Inflow Control**

Inflow Control specifies if the writing operation to the cache memory is stopped (**Enable**) or continued (**Disable**) when the writing operation to the external volume is impossible.

- **CLPR**

When the cache memory is partitioned using XP Disk/Cache Partition, select CLPR used for accessing to the mapped external volume from the list. The number of SLPR that selected CLPR belongs is shown at the right of the list. However, when the emulation type for the mainframe is selected in **Emulation Type**, you can select only the CLPR that belongs to SLPR number 0.

- **OK** button

Saves the settings and closes the dialog box.

- **Cancel** button

Cancels the settings and closes the dialog box.

## LDEV Mapping (Auto) Dialog Box

Use the LDEV Mapping (Auto) dialog box to specify the LDEV number only to the first LDEV in the external volume. If you specify the LDEV number to the first LDEV, the subsequent LDEV numbers are automatically assigned for the rest of LDEVs.

**Figure 26 LDEV Mapping (Auto) Dialog Box**

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00																
10																
20																
30																
40																
50																
60																
70																
80																
90																
A0																
B0																
C0																
D0																
E0																
F0																

The LDEV Mapping (Auto) dialog box consists of:

- **SLPR Limited**  
To restrict the CU in the **CU** list to the CU which belongs to the SLPR, select the **Limited**. To display all the CU in the **CU** list without any restriction, select the **Unlimited**. By default, the **Limited** is selected.
- **LDKC list**  
Select the LDKC number of the local storage system to which you want to map the external volume.
- **CU list**  
Select the CU number of the local storage system to which you want to map the external volume. When you select **Limited** in the **SLPR Limited**, the selection range is limited to CU which belongs to the SLPR.
- **Interval list**  
Select the interval of the LDKC:CU:LDEV number for mapping each volume. The LDEV number is set to each LDEV with the interval that you specified in this list.
- **LDEV Map**  
LDEV map allows you to allocate the LDEV number to each LDEV by clicking cells in a table. Each cell in the LDEV map represents an internal volume. In the LDEV map, the horizontal scale indicates tens place digit of the LDEV number, and the vertical scale indicates ones place digit of the LDEV number. Select a cell for the internal volume on the LDEV map, the selected cell turns to blue, and the LDEV number which the cell indicates is defined to the LDEV. The defined internal volume is grayed out, and undefined internal volumes to be mapped appear in white.
- **OK button**  
Saves the settings and closes the dialog box.
- **Cancel button**  
Cancels the settings and closes the dialog box.

## LDEV Mapping (Manual) Dialog Box

Use the LDEV Mapping (Manual) dialog box to specify the LDEV number for all the LDEVs in the external volume.

Figure 27 LDEV Mapping (Manual) Dialog Box

The LDEV Mapping (Manual) dialog box consists of:

- **List**
  - **ExG**  
The external volume group number of the connected external volume specified in the Set External Volume Parameter dialog box.
  - **LDKC:CU:LDEV**  
Use the **LDKC:CU:LDEV** with the LDEV map for assigning the LDEV number. You can either map an LDEV number to each LDEV one by one, or map a number to multiple LDEVs at once.  
  
The **LDKC:CU:LDEV** shows the LDKC numbers, CU numbers, and LDEV numbers of the external volumes mapped as internal volumes. A hyphen (-) indicates that the external volumes are not mapped as internal volumes.  
  
To assign an LDEV number to an LDEV, select one or more external volumes whose LDEV number is a hyphen (-) in the LDKC:CU:LDEV, and select one cell in the LDEV map.  
  
When you select two or more external volumes in the **LDKC:CU:LDEV**, the other cells are automatically added to match the number of external volumes that you previously selected in the **LDKC:CU:LDEV**. When **Interval** is set, mapping is performed in intervals of that number.

Other items are same as the LDEV Mapping (Auto) dialog box.

## SSID Dialog Box

Use the SSID dialog box to set the SSID to the LDEVs in the external volume. The storage system assigns a SSID that identifies each group of LDEV number. If the LDEVs that you created do not have SSID, you need to assign one using the SSID dialog box. The SSID dialog box opens during the mapping operation when the SSID setting is required.


**Figure 28 SSID Dialog Box**



The SSID dialog box consists of:

- **SLPR list**  
When the storage system is partitioned using XP Disk/Cache Partition, use the **SLPR** list.  
If you select the **SLPR Limited** check box and select the SLPR number in the **SLPR** list, only the SSIDs that can be used for the selected SLPR can be set in the Set SSID dialog box. If you do not select the **SLPR Limited** check box, you can set the SSID from all the unused SSIDs regardless of the selected SLPR number.
- **List**
  - **LDEV Boundary:**  
The range of LDEVs in the selected external volume.
  - **SSID:**  
The SSIDs allocated to each LDEV. If SSID is not set, a hyphen (-) appears.
- **OK button**  
Saves the settings and closes the dialog box.
- **Cancel button**  
Cancels the settings and closes the dialog box.
- **Pop-up Menu**  
Right-click a row in the **SSID** column to execute the **Set SSID** command in the pop-up menu. Use the **Set SSID** command to set the SSID to the selected LDEV. When you click the **Set SSID**, the following dialog box opens.

**Figure 29 Set SSID Dialog Box**



**SSID (0004–FFFE):** Select the SSID from the SSID list. You can select the value for an SSID from 0x0004 to 0xFFFE.

- If you have selected the **SLPR Limited** check box on the **SSID** dialog box, only the SSIDs that can be used in SLPR selected on the SSID dialog box appear in the list.
- If you have not selected the **SLPR Limited** check box on the **SSID** dialog box, all of the unused SSIDs appear in the list regardless of the selected SLPR.

## Example: How to Map LDEVs Automatically

For instance, you map two external volumes that have the same emulation type, and create two LDEVs in each external volume.

To assign the number which starts 00:01:01 with 255 intervals to total four LDEVs that you created:

1. Select the two external volumes and right-click them in the Add Volume dialog box, and then click the **LDEV Mapping (Auto)** in the pop-up menu.

The LDEV Mapping (Auto) dialog box opens.

2. Configure the starting LDEV number and interval as follows:

- LDKC: 00
- CU: 01
- Interval: 255
- LDEV map: Select the cell in the row **1** and column **00**.

3. Click **OK**.

LDEV numbers are automatically assigned as follows:

- The first LDEV: 00:01:01
- The second LDEV: 00:02:01
- The third LDEV: 00:03:01
- The fourth LDEV: 00:04:01

However, the Add Volume dialog box shows only the LDEV number assigned for the first LDEV of each external volume. In this case, **00:01:01...** and **00:03:01...** appear in the Add Volume dialog box.

## Example: How to Map LDEVs Manually

This example shows how to map two external volumes that have the same emulation type, and create two LDEVs in each external volume.

To assign the desired number to total four LDEVs that you created:

1. Select the two external volumes and right-click them in the Add Volume dialog box, and then click the **LDEV Mapping (Manual)** in the pop-up menu.

The LDEV Mapping (Manual) dialog box opens.

2. Click the LDEV to which you want to assign an LDEV number in the **LDKC:CU:LDEV** column on the left of the LDEV Mapping (Manual) dialog box.
3. Select the desired LDKC number and the desired CU number to the specified LDEV from the list on the right of the LDEV Mapping (Manual) dialog box.
4. Click the cell of the desired LDEV number in the LDEV map on the right of the LDEV Mapping (Manual) dialog box (see [Figure 30 \(page 78\)](#)).

The selected cell turns blue and the assigned LDEV number appears in the **LDKC:CU:LDEV** column.

5. Make the settings to all the LDEVs in the **LDKC:CU:LDEV** column (repeat step 2 through step 4).
6. Click **OK**.  
The specified numbers are assigned to the LDEVs. However, the Add Volume dialog box shows only the LDEV number assigned for the first LDEV of each external volume.

**Figure 30 Example of LDEV Mapping (Manual) Dialog Box**

ExG	LDKC:CU:LDEV
E3 - 1	00:01:01
E3 - 1	-
E5 - 1	-

SLPR Limited: ☒ Limited ☐ Unlimited

LDKC: 00

CU: 01

Interval: 0

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00																
10																
20																
30																
40																
50																
60																
70																
80																
90																
A0																
B0																
C0																
D0																
E0																
F0																

OK Cancel

You can also assign contiguous LDEV numbers to LDEVs using this dialog box. To assign contiguous LDEV numbers to LDEVs, select multiple LDEVs at step 2, and specify the starting LDEV number at step 3 and 4. You can set **Interval** if necessary.

## Setting the Cross-subsystem Paths

You need to configure the cross-subsystem path from the internal volume to the external volume before using the external volume mapped as an internal volume. For details on the cross-subsystem path, see [“Cross-subsystem Paths” \(page 18\)](#).

You can configure the cross-subsystem path when you map the external volume as the internal volume. You can also add or change the cross-subsystem paths after the mapping operation is

completed. To configure the cross-subsystem paths, use the Configure Cross-subsystem Paths dialog box.

- △ **CAUTION:** You cannot delete all the current cross-subsystem paths to substitute newly added cross-subsystem paths for them in one operation. To replace all the current cross-subsystem paths with newly added cross-subsystem paths, you need to perform more than two operations and leave at least one current cross-subsystem path setting when you perform the first operation.


## Configure Cross-subsystem Paths Dialog Box

Use the Configure Cross-subsystem Paths dialog box to configure cross-subsystem paths. This dialog box opens automatically when you add a volume to a new path group using the **Add Volume (Auto)** command or the **Add Volume (Manual)** command. You can also open this dialog box by clicking the **Configure Cross-subsystem Paths** command in the Volume Operation window.

You can change the priority, add and delete the cross-subsystem path in the Configure Cross-subsystem Paths dialog box.

The Volume Operation window displays only the external storage system for which you have configured the mapping. However, the Configure Cross-subsystem Paths dialog box shows all the external storage systems connected to the local storage system even without the mapping configuration. To update the dialog box, click **Port Discovery** in the upper right of the dialog box.

**Figure 31 Configure Cross-subsystem Paths Dialog Box**



The Configure Cross-subsystem Paths dialog box consists of:

- **Available Paths** (Upper part of the dialog box)

The following three panes appear from the left.

The left pane shows the external storage systems connected to the local storage system.

- **Vendor:** Vendor name.
- **Product Name:** Product name.
- **Serial Number:** Serial number of the product.

The middle pane shows external ports of the local storage system that connects to the external storage system that you selected in the left pane.

- **Port:** external port of the local storage system. One of the following icons appears:



: Ports in the Standard mode.



: Ports in the Initiator/External MIX mode.


The right pane shows the WWN of the external storage system for which the port attribute is set to Target. The WWN connecting to the port selected in the middle pane is displayed out of the WWN of the external storage system selected in the left pane.

- **WWN:** Identification number of the port in the external storage system.

- **Port Discovery** button (Upper right of the dialog box)

Allows you to update information in the **Available Paths** or display the information on all the external storage systems connected to the local storage system even without the mapping configuration. When you click **Port Discovery**, the port discovery dialog box opens.

**Figure 32 Port Discovery Dialog Box**



The Port Discovery dialog box shows the list of the external ports in the local storage system. When you click the external port in the list, WWNs of the external storage system connected to the clicked external port are searched for, and the **Available Paths** in the Configure Cross-subsystem Paths dialog box is updated.

---

**NOTE:** Depending on the status of external subsystem port, the WWN of the external subsystem that is connected to the selected external port may not be displayed. If this happens, change the settings of the external subsystem port and then remove and reinsert the cable. After you have changed the settings, click **Port Discovery**.

---

- **Selected Paths** (Lower part of the dialog box)

The cross-subsystem paths appear that you have added in the **Available Paths**.

- **Priority:** Priority of the cross-subsystem paths connecting to the external volume. **1** indicates the path with the highest priority.
- **Port:** Port of the local storage system that the port attribute is set to External.
- **WWN:** WWN of the external storage system that the port attribute is set to Target.

- **OK** button

Saves the settings and closes the dialog box.



- **Cancel** button  
Cancels the settings and closes the dialog box.
- **Pop-up Menu**  
Right-click a row in the Configure Cross-subsystem Paths dialog box to perform the following operations.

**Table 11 Pop-up Menu in the Configure Cross-subsystem Paths dialog box**

Right-clicked area	Pop-up menu	Description
<b>WWN</b> in the <b>Available Paths</b>	Add	Allows you to add cross-subsystem paths. See <a href="#">“Configuring the Cross-subsystem Path”</a> (page 81).
<b>Selected Paths</b>	Delete	Allows you to delete the selected cross-subsystem path. See <a href="#">“Canceling the Cross-subsystem Path Configuration”</a> (page 83).
	Raise Priority	Allows you to raise the priority of the selected cross-subsystem path. See <a href="#">“Changing the Configured Cross-subsystem Path Priority”</a> (page 82).
	Lower Priority	Allows you to lower the priority of the selected cross-subsystem path. See <a href="#">“Changing the Configured Cross-subsystem Path Priority”</a> (page 82).

## Configuring the Cross-subsystem Path

You can configure the cross-subsystem path using the Configure Cross-subsystem Paths dialog box. This section explains the procedure to add a cross-subsystem path to an existing path group. To create a new path group and configure cross-subsystem paths, you need to operate the mapping operation. For the procedure, see [“Mapping an External Volume Automatically”](#) (page 67).

To add the cross-subsystem path to an existing path group:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group that you want to add a cross-subsystem path in the Volume Operation tree.
4. Right-click the cross-subsystem path in **Cross-subsystem Paths** in the Volume Operation list.
5. Click **Configure Cross-subsystem Paths** in the pop-up menu.


The Configure Cross-subsystem Paths dialog box opens (see [“Configure Cross-subsystem Paths Dialog Box”](#) (page 79)).

6. In the **Available Paths**, select the following three items (see [Figure 33](#) (page 82)).
  - **External storage system**: Select the external storage system.
  - **Port**: Select the external port of the local storage system, which is the starting point of the cross-subsystem path.
  - **WWN**: Select the WWN of the external storage system, which is the ending point of the cross-subsystem path.

If the external storage system or the WWN that you want to choose is not displayed in the dialog box, you can update the information by clicking **Port Discovery**, selecting the port that connects to the WWN, and then clicking **OK**.

7. Right-click the WWN in the **WWN**, and then click **Add** in the pop-up menu.  
The cross-subsystem path is added to the **Selected Paths** with the selected information. Configure more than two cross-subsystem paths for one path group. Change the priority or delete unnecessary cross-subsystem paths if necessary.
8. Click **OK** to close the Configure Cross-subsystem Paths dialog box and return to the Volume Operation window.  
The settings appear in blue italics.
9. Verify the settings in the Preview dialog box (see “Preview Dialog Box” (page 54)).
10. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

**Figure 33 Pop-up Menu of Configure Cross-subsystem Paths Dialog Box**



## Changing the Configured Cross-subsystem Path Priority

To change the cross-subsystem path priority, use the **Raise Priority** command and the **Lower Priority** command displayed in the Configure Cross-subsystem Paths dialog box.

The following is an example of procedure to make the cross-subsystem path to the currently used path by raising the priority of the cross-subsystem path:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group to which the cross-subsystem path belongs in the Volume Operation tree.
4. Right-click the cross-subsystem path in **Cross-subsystem Paths** in the Volume Operation list.
5. Click **Configure Cross-subsystem Paths** in the pop-up menu.  
The Configure Cross-subsystem Paths dialog box opens.
6. Right-click the cross-subsystem path that you want to change the priority of in the **Selected Paths** in the Configure Cross-subsystem Paths dialog box.
7. Click **Raise Priority** in the pop-up menu  
The row of the selected path switches with the one row above.

8. Repeat the operation of the **Raise Priority** command until the row of the selected path appears in the head of the **Selected Paths** list and its **Priority** column changes to 1.  
When the **Priority** column changes to 1, it means the cross-subsystem path is set as the usually used one (primary path).
9. Click **OK** to close the Configure Cross-subsystem Paths dialog box and return to the Volume Operation window.  
The settings appear in blue italics.
10. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
11. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Canceling the Cross-subsystem Path Configuration

You can cancel the configuration of the cross-subsystem path using the Configure Cross-subsystem Paths dialog box.

To cancel the cross-subsystem path configuration:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group to which the cross-subsystem path belongs in the Volume Operation tree.
4. Right-click the cross-subsystem path in **Cross-subsystem Paths** in the Volume Operation list.
5. Click **Configure Cross-subsystem Paths** in the pop-up menu.
6. In the Configure Cross-subsystem Paths dialog box, right-click the cross-subsystem path that you want to cancel the configuration in the **Selected Paths** in the Configure Cross-subsystem Paths dialog box.
7. Click **Delete** in the pop-up menu.  
The configuration of the selected cross-subsystem path is canceled, and the cross-subsystem path is deleted from the **Cross-subsystem Paths**.
8. Click **OK** to close the Configure Cross-subsystem Paths dialog box and return to the Volume Operation window.  
The settings appear in blue italics.
9. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
10. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Changing the Cross-subsystem Path


To change the cross-subsystem path, cancel the current cross-subsystem path, and configure another cross-subsystem path as a new cross-subsystem path. To cancel the current cross-subsystem path, see [“Canceling the Cross-subsystem Path Configuration” \(page 83\)](#). To configure an cross-subsystem path, see [“Configuring the Cross-subsystem Path” \(page 81\)](#).

## Replacing All Cross-subsystem Paths with Newly Added Cross-subsystem Paths

This section explains how to change all the current cross-subsystem paths to newly added cross-subsystem paths with an example.

Figure 34 (page 84) shows the overview of the operation and the status of the cross-subsystem paths. When you delete the current cross-subsystem paths (A and B) and add new cross-subsystem paths (C and D), you cannot delete both the current cross-subsystem paths (A and B) in one operation because at least one current path that functions normally has to be configured. In this case, you need to delete the cross-subsystem path A and add the cross-subsystem path C, and then apply the setting. After that, you need to delete the cross-subsystem path B and add the cross-subsystem path D.

**Figure 34 Overview of Operation to Replace All the Current Cross-subsystem Paths with Newly-added Cross-subsystem Paths**



To replace all the current cross-subsystem paths (A and B) with newly added cross-subsystem paths (C and D):

1. Execute the **Disconnect Paths** command on the cross-subsystem path A.
2. Disconnect the cable that the cross-subsystem path A uses, and connect the cable that the cross-subsystem path C uses.
3. Cancel the configuration of the cross-subsystem path A, and add the cross-subsystem path C.
4. Click **Apply** to apply the settings of the cross-subsystem paths A and C.
5. Make sure the status of the cross-subsystem path C is Normal.

At this point, the cross-subsystem paths B and C are configured as normal paths.

Take the following steps to delete the cross-subsystem path B and add the cross-subsystem path D.

6. Execute the **Disconnect Paths** command on the cross-subsystem path B.

7. Disconnect the cable that the cross-subsystem path B uses, and connect the cable that the cross-subsystem path D uses.
8. Cancel the configuration of the cross-subsystem path B, and add the cross-subsystem path D.
9. Click **Apply** to apply the settings of the cross-subsystem paths B and D.
10. Make sure the status of the cross-subsystem path D is Normal.

## Checking the External Volume Details

You can check the details on the mapped external volume using the LDEV Information dialog box, and the details on the mapping path using the Mapping Path Information dialog box.


To check the external volume details:

1. Start Remote Web Console, and open the Volume Operation window.
2. Click the path group in the Volume Operation tree.
3. Right-click the external volume that you want to check in the Volume Operation list.
4. Select one of the following commands in the pop-up menu.
  - **LDEV information:** Displays the LDEV Information dialog box (see “LDEV Information Dialog Box” (page 85)).
  - **Mapping Path Information:** Displays the Mapping Path Information dialog box (see “Mapping Path Information Dialog Box” (page 86)).
5. Verify the details in the displayed dialog box.
6. Click **Close** to close the displayed dialog box and return to the Volume Operation window.

## LDEV Information Dialog Box

The LDEV Information dialog box shows the information on the LDEVs created in the external volumes. Each row displays one LDEV information.

**Figure 35 LDEV Information Dialog Box**



LDKC:CU:LDEV	Emulation Type	Capacity
00:00:20	OPEN-3	2347MB(4806720blocks)
00:00:21	OPEN-3	2347MB(4806720blocks)
00:00:22	OPEN-3	2347MB(4806720blocks)
00:00:23	OPEN-3	2347MB(4806720blocks)
00:00:24	OPEN-3	2347MB(4806720blocks)
00:00:25	OPEN-3	2347MB(4806720blocks)
00:00:26	OPEN-3	2347MB(4806720blocks)
00:00:27	OPEN-3	2347MB(4806720blocks)
00:00:28	OPEN-3	2347MB(4806720blocks)
00:00:29	OPEN-3	2347MB(4806720blocks)

**Close**

The LDEV Information dialog box consists of:

- **List**
  - **LDKC:CU:LDEV:** The LDKC:CU:LDEV number of the LDEVs created in the external volume.
  - **Emulation Type:** The emulation type of the external volume set when it was mapped.
  - **Capacity:** Capacity of the external volume. When the emulation type of the mapped external volume is for the open system, the capacity is shown in Blocks. When the


emulation type of the mapped external volume is for the mainframe system, the capacity is shown in Cylinder.

- **Close** button  
Closes the LDEV Information dialog box.

## Mapping Path Information Dialog Box

The Mapping Path Information dialog box shows the information on the mapping paths that connect the internal volume and the external volume.

**Figure 36 Mapping Path Information Dialog Box**



The Mapping Path Information dialog box consists of:

- **List**
  - **Priority:** Priority of the mapping path. **1** indicates the mapping path with the highest priority.
  - **Port:** The port number in the local storage system connecting to the external storage system.
  - **WWN:** Identification number of the port in the external storage system.
  - **LUN:** LU number set to the external volume.
  - **Status:** Status of the mapping path. [Table 12 \(page 86\)](#) lists and describes the status terms that are displayed on the Mapping Path Information dialog box. For required actions for each path status, see [“Mapping Path Statuses and Required Actions” \(page 127\)](#).
- **Close** button  
Closes the Mapping Path Information dialog box.
- **Pop-up menu**  
The Mapping Path Information dialog box does not have a pop-up menu that can be displayed.

**Table 12 Status of the Mapping Paths in the Mapping Path Information Dialog Box**

Displayed Item	Description
Normal	The mapping path is normal.
-	The status of the mapping path is not retrieved yet. Click <b>Status:Disable</b> and change the button name to <b>Status: Enable</b> in the Volume Operation window to display the status of the mapping path.
Unknown	The status of the mapping path is unknown.
Blockade	The mapping path is blocked.

**Table 12 Status of the Mapping Paths in the Mapping Path Information Dialog Box**  
(continued)

Displayed Item	Description
<b>External device setting changed</b>	The setting of the external storage system has been changed. For example, the path definition was deleted, or the external storage system itself was replaced by another device.
<b>LDEV size reduced</b>	The setting of the volume capacity of the external storage system has been changed (the volume capacity was reduced).
<b>Not ready</b>	The reply from the external storage system was NOT READY.
<b>Illegal request</b>	The reply from the external storage system was ILLEGAL REQUEST.
<b>Command aborted</b>	The reply from the external storage system was ABORTED COMMAND.
<b>Busy</b>	The external storage system is busy.
<b>LDEV reserved</b>	The external storage system is reserved.
<b>Response error</b>	The external storage system is blocked due to an abnormal reply.
<b>Initiator port</b>	The port attribute of the external storage system has been changed to the initiator port.
<b>Unknown port</b>	The port attribute of the external storage system is unknown.
<b>Cannot detect port</b>	The path has been removed or the port of the external storage system cannot be found.
<b>Internal error</b>	The program error occurred or there is a logical contradiction.
<b>Timeout</b>	Processing was retried because an abnormal reply was returned, however, the processing has timed out.
<b>Passive</b>	The port of the external storage system is not active. The port status is normal but the port is not used for I/O.
<b>Standby</b>	The port of the external storage system is standing by. The port status is normal but cannot receive I/O.
<b>Target error</b>	Port failures, such as controller blockade, are detected on the external storage system side.
<b>Checking</b>	The process of checking the mapping path status is in progress.
<b>Disconnect</b>	Connection to the external storage system or the external volume is intentionally stopped using the <b>Disconnect Subsystem</b> command or the <b>Disconnect Volume</b> command.
<b>Unavailable</b>	The reply from the external storage system was Unavailable. The external storage system demands to change the connected port. Once the status becomes Unavailable, the primary path is changed to the alternate path that is in the Standby status. When the primary path changes, the status of the path becomes Normal.
<b>Backoff</b>	The reply from the external storage system was Backoff. The status of the path is waiting for recovery because a temporary error has occurred in the volume of the external storage system. Even if the status of the primary path becomes this status, the primary path is not changed to the alternate path immediately. After the error recovery, the status becomes Normal. If the status cannot be recovered from the error, the path status is changed to the other status.
<b>Device check error</b>	An external volume is mapped, but you cannot access the volume in the external storage system.
<b>Medium error</b>	The volume in the external storage system becomes inaccessible.



## Turning On or Off the Storage System

This section describes how to turn on or off the local storage system and the external storage system after the XP External Storage operation has been started.

This section includes the following procedures, and uses XP Business Copy as an example:

- “Commands for Turning On or Off Only the External Storage System” (page 88)
- “Turning On or Off Only the External Storage System” (page 89)
- “Turning On or Off Only the Local Storage System” (page 89)
- “Turning On or Off Both Storage Systems” (page 90)

When you turn on or off the power supply of only the external storage system, you need to execute the XP External Storage commands. For details on these commands, see “[Commands for Turning On or Off Only the External Storage System](#)” (page 88).

---

### ⚠ CAUTION:

- When you want to turn off both the local storage system and the external storage system, you first need turn off the local storage system, and then turn off the external storage system.
  - When you want to turn on both the local storage system and the external storage system, you first need to turn on the external storage system, and then turn on the local storage system.
- 

## Commands for Turning On or Off Only the External Storage System

When you turn on or off the power supply of only the external storage system while the power supply of the local storage system remains on, you need to execute the following XP External Storage commands:

- **Disconnect Subsystem** command

The **Disconnect Subsystem** command should be executed when the external storage system is maintained or stopped on purpose. When the **Disconnect Subsystem** command is executed, the acceptance of the host I/O to the external volume that is mapped as the internal volume is stopped. Then all the data that should belong to the external volume is written to the external volume from the cache memory of the local storage system (all the data is destaged).

For the procedure to execute the **Disconnect Subsystem** command, see “[Disconnecting External Storage System or Disconnecting External Volume](#)” (page 91).

When you want to perform the same processing of the **Disconnect Subsystem** command on individual volume, you can use the **Disconnect Volume** command. To delete the external volume mapping individually, you first need to execute the **Disconnect Volume** command and then the **Delete Volume** command. For the procedure to delete the external volume mapping, see “[Deleting the External Volume Mapping \(Delete Volume Command\)](#)” (page 99).

- **Check Paths & Restore Volume** command

The **Check Paths & Restore Volume** command checks if the defined information about the mapped external volume and the actual external volume status match. If the external volume can be used as the mapped volume as the result of the check, the external volume is set to accept the I/Os, and you can continue using the external volume as a mapped volume.

The **Check Paths & Restore Volume** command can be used to restore the external volume, which is set to reject the host I/O by the **Disconnect Subsystem** command or the **Disconnect Volume** command, as the mapped volume. The **Check Paths & Restore Volume** command can be executed for both the whole storage system and for the individual volume.

If an error occurs in the path, first remove the error in the path to make the path restorable, and then execute the **Check Paths & Restore Volume** command.



When the **Check Paths & Restore Volume** command is executed and the external volume is ready to be restored as the mapped volume, the external volume is set to accept the I/Os and you can resume using the external volume as a mapped volume. However, if the external volume is not ready to be restored, the external volume status remains blocked.

## Turning On or Off Only the External Storage System

To turn off the power supply of the external storage system (to turn off on purpose):

1. Stop the read or write I/O to the external volume that is mapped as a local storage system internal volume and is contained in the external storage system that you want to turn off.
2. Execute the **Disconnect Subsystem** command for the external storage system that you want to turn off.

The additional I/O to the external volume is stopped and all the data in the local cache memory is written in the external volume (all the data is destaged).

For the procedure to execute the **Disconnect Subsystem** command, see [“Disconnecting External Storage System or Disconnecting External Volume” \(page 91\)](#).

3. Perform other operations that are required before turning off the local storage system.
4. Turn off the power supply of the external storage system.



### CAUTION:

- After you have executed the **Disconnect Subsystem** command, but you need to use the mapped external volume again, execute the **Check Paths & Restore Volume** command.
- To turn on the power supply of the external storage system to restart from the turned off status:
  1. Turn on the external storage system that contains the external volume, which is mapped as an internal volume.
  2. Execute the **Check Paths & Restore Volume** command of the XP External Storage.

For the procedure to execute the **Check Paths & Restore Volume** command, see [“Checking Connection Status and Resuming External Volume Operation” \(page 93\)](#).
- When the external storage system is turned off after the **Disconnect Subsystem** command is executed, you cannot access the mapped external volume from the local storage system as you just turn the external storage system on. It is necessary to execute the **Check Paths & Restore Volume** command to resume using the mapped external volume. The **Check Paths & Restore Volume** command checks the defined information and the actual status of the external volume mapped as an internal volume. If the external volume is ready to be used as a mapped volume, the volume is set to accept the I/Os and you can resume using the volume as a mapped volume.

## Turning On or Off Only the Local Storage System

To turn off the power supply of the local storage system (to turn off on purpose):

1. Stop the read or write I/O to the external volume that is mapped as a local storage system internal volume.
2. Perform other operations that are required before turning off the local storage system.
3. Turn off the power supply of the local storage system.

All the data for the external volume in the local cache memory is written in the external volume (all the data is destaged).

To turn on the power supply of the local storage system to restart from the turned off status:

1. Turn on the external storage system that contains the external volume, which is mapped as an internal volume.
  2. Turn on the power supply of the local storage system.
- 

△ **CAUTION:**

- When the local storage system is turned off after the **Disconnect Subsystem** command is executed, you cannot access the mapped external volume from the local storage system as you just turn the local storage system on. It is necessary to execute the **Check Paths & Restore Volume** command to resume using the mapped external volume. The **Check Paths & Restore Volume** command checks whether there is a match between the defined information and the actual status of the external volume mapped as an internal volume. If the external volume is ready to be used as a mapped volume, the volume is set to accept the I/Os and you can resume using the volume as a mapped volume.
  - When the **Disconnect Subsystem** or **Disconnect Volume** command is executed and all the data in the cache memory is written to the external volume, **Disconnect** appears for **Ext. VOL Status** in the Volume Operation window.
- 

## Turning On or Off Both Storage Systems

This section explains how to turn on or off the power supply of the local and external storage systems, and uses XP Business Copy as an example.

To turn off the power supply of both storage systems:

1. Stop the read or write I/O to the local storage system.  
All read and write I/Os with Fibre Channel connections should be stopped.
  2. Split all XP Business Copy pairs (pairsplit operation).  
For details on the pairsplit operation, see the *HP StorageWorks XP24000/XP20000 Business Copy Software User Guide*.
  3. Turn off the power supply of the local storage system.
- 

- △ **CAUTION:** Make sure that the power supply of the local storage system is completely off and then go on to the next step.
- 

4. Turn off the power supply of the external storage system.
- 

- △ **CAUTION:** Make sure that the power supply of the external storage system is completely off.
- 

To turn on the power supply of both storage systems:

1. Turn on the power supply of the external storage system.
- 
- ⚠ **CAUTION:** Make sure that the power supply of the external storage system is completely on and then go on to the next step.
- 
2. Turn on the power supply of the local storage system.
- 
- ⚠ **CAUTION:** Make sure that the power supply of the local storage system is completely on and then go on to the next step.
- 
3. Resynchronize all XP Business Copy pairs (pairresync operations).  
For details on the pairresync operation, see the *HP StorageWorks XP24000/XP20000 Business Copy Software User Guide*.
  4. Start the read or write I/O to the local storage system.  
All read and write I/Os with Fibre Channel connections should be started.

## Disconnecting External Storage System or Disconnecting External Volume

The **Disconnect Subsystem** command and the **Disconnect Volume** command allow you to disconnect the external volume. You need to disconnect the external volumes, for example, before you turn the power supply off of the local storage system or the external storage system for maintenance, or before you delete the external volume mapping. In addition, before you access the mapped external volumes from the external storage system, disconnect the external volumes. After you finish using the external volumes from the external storage system and need to access the external volumes from the local storage system, resume using the external volumes by following the procedure in “[Checking Connection Status and Resuming External Volume Operation](#)” (page 93).

As you execute the **Disconnect Subsystem** command or the **Disconnect Volume** command, the mapped external volume stops accepting host I/O, and all the data in the cache memory is written into the external volume (all the data is destaged).

The settings of the mapping are preserved, even though the external volume is disconnected using the **Disconnect Subsystem** command or the **Disconnect Volume** command. Therefore, you can resume using the external volume as a mapped volume with the former settings, even though once you have disconnected the external volume.

[Table 13 \(page 91\)](#) describes operations that are required before disconnecting external volumes.

**Table 13 Operations Required before Disconnecting External Volumes**


If the External Volume is Used in this way	This Operation is Required
I/Os to the external volume from the open system host are in progress.	Stop the host I/Os to the volume and unmount from the host.  The host I/Os to the specified volume are forcibly stopped if you disconnect an external volume when I/Os from the open system host are in progress.
The external volume is online from the mainframe host.	Stop the host I/Os to the volume and perform the Vary Offline operation.
The external volume includes the LDEVs that are set as the pair of the copy program products. <sup>1</sup>	Delete the pairs.  However, you can disconnect external volumes without deleting pairs when the XP Business Copy pair status is <b>PSUE</b> or the ShadowImage for Mainframe pair status is <b>Suspend</b> .
The external volume includes the LDEVs that are registered to a pool for XP Snapshot as pool volumes.	Change the status of the XP Snapshot pair to PAIR.

**Table 13 Operations Required before Disconnecting External Volumes** *(continued)*

If the External Volume is Used in this way	This Operation is Required
The external volume includes the LDEVs that are registered to a pool for XP Thin Provisioning as pool volumes.	Perform the following operations on all the XP Thin Provisioning volumes (V-VOLs) that are associated with a pool to which the external volume is registered. <ul style="list-style-type: none"> <li>• Stop the use of the XP Thin Provisioning volumes.</li> <li>• Block the XP Thin Provisioning volumes by using the VLL function for blocking volumes.</li> </ul>
The external volume includes the LDEVs for which the migration processing of XP Auto LUN is in progress.	Delete the migration plans.

1 The copy program products include XP Business Copy, ShadowImage for Mainframe, XP Continuous Access Journal, Universal Replicator for Mainframe, XP Continuous Access, TrueCopy for Mainframe, and XP Snapshot.

**CAUTION:** The cautions on the **Disconnect Subsystem** command and the **Disconnect Volume** command are as follows:

- After you have executed the **Disconnect Subsystem** command or the **Disconnect Volume** command, click the **Refresh** command (  ) on the Remote Web Console main window to update the information, and check the current progress status.
- When the **Disconnect Subsystem** command or the **Disconnect Volume** command is executed, the displayed information for **Ext. VOL Status** in the **Volume Operation** window becomes **Cache Destage**. Even if there is no data left in the cache memory, the displayed status remains as **Cache Destage**, until the processing of the **Disconnect Subsystem** command or the **Disconnect Volume** command has completed.
- When the **Disconnect Subsystem** command or the **Disconnect Volume** command is executed and all the data in the cache memory is written to the external volume, the displayed information for **Ext. VOL Status** in the Volume Operation window becomes **Disconnect**.

## Disconnecting All External Volumes (Disconnect Subsystem)

To disconnect all the external volumes in the external storage system at once:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Right-click the product name that you want to disconnect in the Volume Operation tree.
4. Click **Disconnect Subsystem** in the pop-up menu.

The settings appear in blue italics.

5. Verify the settings in the Preview dialog box.
6. Click **Apply** in the Volume Operation window.

The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

**CAUTION:** To access the external storage system after you have executed the **Disconnect Subsystem** command, you need to execute the **Check Paths & Restore Volume** command.

## Disconnecting an Individual External Volume (Disconnect Volume Operation)

To disconnect an individual external volume:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.

3. Click the product name in the Volume Operation tree.
4. Right-click the external volume that you want to change in the Volume Operation list.
5. Click **Disconnect Volume** in the pop-up menu.

The settings appear in blue italics.

6. Verify the settings in the Preview dialog box.
7. Click **Apply** in the Volume Operation window.

The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

---

**⚠ CAUTION:** To access the external storage system after you have executed the **Disconnect Volume** command, execute the **Check Paths & Restore Volume** command.

---

You can also disconnect an individual external volume by using a spreadsheet. For more information about disconnecting an individual external volume by using a spreadsheet, see [“Disconnecting an Individual External Volume \(DisconnectVolume Tag\)”](#) (page 114).

## Checking Connection Status and Resuming External Volume Operation

You can resume external volume operation by executing the **Check Paths & Restore Volume** command in the following cases:

- The **Check Paths & Restore Volume** command is required to be executed to resume using the disconnected external volume using the **Disconnect Subsystem** command or the **Disconnect Volume** command.
- When the errors occur in all the cross-subsystem paths, the local storage system makes the status of external volume to **Blockade**. In this case, execute the **Check Paths & Restore Volume** command.

If the status of the external volume cannot be restored even though the **Check Paths & Restore Volume** command is executed, restore the path to the external storage system as described in [“Troubleshooting for XP External Storage”](#) (page 126). Then execute the **Check Paths & Restore Volume** command to make the external volume in the Blockade status usable.

- When the **Check Paths & Restore Volume** command is executed for the disconnected external volume for which the mapping settings are preserved, the defined mapping setting and the current status of the external volume are compared and checked if the settings match the actual status. The path status and all other mapping configuration definitions are checked. If the external volume can be resumed as a mapped volume as a result of the checking processing, the volume status is set to be available for the I/O operation.

When the **Check Paths & Restore Volume** command is executed and the external volume is ready to be restored as the mapped volume, the external volume is set to accept the I/Os and you can resume using the external volume as a mapped volume. However, if the external volume is not ready to be resumed, the status of the disconnected volume remains as Blockade.

---

**⚠ CAUTION:** After you have executed the **Check Paths & Restore Volume** command, check the current progress status. To refresh the displayed information, make sure the button name on the upper right of the Remote Web Console main window is **Status: Enable**, and click **File** and **Refresh** on the menu bar of the Remote Web Console main window.

---

## Resuming All External Volumes (Check Paths & Restore Volume)

To resume all the external volumes in the external storage system at once:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Right-click the product name that you want to resume connection in the Volume Operation tree.
4. Click **Check Paths & Restore Volume** in the pop-up menu.  
The settings appear in blue italics.
5. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
6. Click **Apply** in the Volume Operation window.  
The **Ext. VOL Status** in the Volume Operation window changes to **Checking**. When the checking processing of mapping path status is completed, and the external storage system can be resumed, the **Ext. VOL Status** changes to **Normal**. If the external storage system cannot be resumed, the **Ext. VOL Status** changes to **Blockade**.

## Resuming an Individual External Volume (Check Paths & Restore Volume Operation)

To resume an individual external volume:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group in the Volume Operation tree.
4. Right-click the external volume that you want to resume connection in the Volume Operation list.
5. Click **Check Paths & Restore Volume** in the pop-up menu.  
The settings appear in blue italics.
6. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
7. Click **Apply** in the Volume Operation window.  
The **Ext. VOL Status** in the Volume Operation window changes to **Checking**. When the checking processing of mapping path status is completed, and the external volume can be resumed, the **Ext. VOL Status** changes to **Normal**. If the external volume cannot be resumed, the **Ext. VOL Status** changes to **Blockade**.

You can also resume an individual external volume operation by using a spreadsheet. For more information about resuming an individual external volume by using a spreadsheet, see [“Resuming an Individual External Volume \(CheckPath-RestoreVolume Tag\)” \(page 114\)](#).

## Stopping the Use of Paths to the External Volume (Disconnect Paths)

Use the **Disconnect Paths** command to prepare for stopping the use of the cross-subsystem path. For example, when you want to maintain one of the cross-subsystem paths, you can stop the specified cross-subsystem path while the local storage system is still connected to the external volume. To resume the use of the cross-subsystem path that is stopped by the **Disconnect Paths** command, use the **Check Paths** command.

The **Disconnect Paths** command is not for the actual disconnection of the cross-subsystem path to the external volume. You need to confirm that some normal cross-subsystem paths to the external volume is set, other than the cross-subsystem path for which you plan to execute the **Disconnect Paths** command.

To stop the use of the paths to the external volume:

1. Start Remote Web Console, and open the Path Operation window.
2. Make sure that Remote Web Console is in Modify mode.

3. Select one of the following from the list above the Path Operation tree.
  - **Fibre - Local Subsystem**: Displays the ports in the local storage system. Select **Fibre - Local Subsystem** to stop the use of all the cross-subsystem paths connected to the specified port in the local storage system.
  - **Fibre - External Subsystem**: Displays the WWNs in the external storage system. Select **Fibre - External Subsystem** to stop the use of all the cross-subsystem paths connected to the specified WWNs (ports) in the external storage system.
4. Click **Subsystem** or the product name in the Path Operation tree.
5. Right-click the port or WWN that you want to stop the use of in the Path Operation list.
6. Click **Disconnect Paths** in the pop-up menu.  
The settings appear in blue italics.
7. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
8. Click **Apply** in the Path Operation window.  
The settings are applied to the local storage system and the Path Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Restoring the Paths to the External Volume (Check Paths)

Use the **Check Paths** command to resume using the cross-subsystem path which was stopped by using the **Disconnect Paths** command. Make sure that the path is in a status that can be restored.

To restore the path to the external volume:

1. Start Remote Web Console, and open the Path Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Select one of the following from the list above the Path Operation tree.
  - **Fibre - Local Subsystem**: Displays the ports in the local storage system. Select **Fibre - Local Subsystem** to restore all the cross-subsystem paths connected to the specified port in the local storage system.
  - **Fibre - External Subsystem**: Displays the WWNs in the external storage system. Select **Fibre - External Subsystem** to restore all the cross-subsystem paths connected to the specified WWNs (ports) in the external storage system.
4. Click **Subsystem** or the product name in the Path Operation tree.
5. Right-click the port or WWN that you want to restore in the Path Operation list.
6. Click **Check Paths** in the pop-up menu.  
The settings appear in blue italics.
7. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
8. Click **Apply** in the Path Operation window.  
The settings are applied to the local storage system and the Path Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Changing the Cache Mode Setting of the External Volume

You can change the cache mode of the external volume in the Volume Operation window. To change the cache mode of the external volume, right-click the external volume, click **Change Cache Mode** in the pop-up menu, and then click **Enable** or **Disable**.

Data that is not written by the host (for example, data written by XP Business Copy) is asynchronously destaged to the external storage system regardless of the **Cache Mode** setting.



Check the following before changing the cache mode of the external volume.

- Whether the volume is not set as a volume that constitutes a part of a LUSE volume.  
When it is set as a volume that constitutes a part of a LUSE volume, the cache mode setting should be the same among all volumes that constitute a LUSE volume.
- Whether the bind mode of Cache Residency Manager is not set.  
When the bind mode is set, you cannot change the cache mode from **Enable** to **Disable**. To change the cache mode to **Disable**, cancel the setting for Cache Residency Manager or change the cache residency mode to the priority mode.
- Whether the volume is not registered to a pool.  
When a volume is registered to a pool as a pool volume, the cache mode setting should be the same among all the pool volumes in the pool.
- Whether the volume is not a remote command device.  
When the volume is a remote command device, you cannot change the cache mode from **Disable** to **Enable**.

To change the cache mode of the external volume:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group in the Volume Operation tree.
4. Right-click the external volume that you want to change in the Volume Operation list.
5. Click **Change Cache Mode** in the pop-up menu and click **Enable** or **Disable** in the submenu.  
The settings appear in blue italics.
6. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
7. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Changing the Inflow Control Setting of the External Volume

You can change the inflow control setting of the external volume in the Volume Operation window. To change the inflow control setting of the external volume, right-click the external volume, click **Inflow Control** in the pop-up menu, and then click **Enable** or **Disable**.

To change the inflow control setting of the external volume:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group in the Volume Operation tree.
4. Right-click the external volume that you want to change in the Volume Operation list.
5. Click **Inflow Control** in the pop-up menu and click **Enable** or **Disable** in the submenu.  
The settings appear in blue italics.
6. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
7. Click **Apply** in the Volume Operation window.  
The settings are applied to the local storage system and the Volume Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.



## Changing the Port Setting of the External Storage System

You can change the setting of the port of the external storage system in the Path Operation window. For changing the setting of the port, use the Change WWN Parameter dialog box.

### ⚠ CAUTION:

- If the default setting has no problem, use the default setting as it is.
- For the volume used in usual I/O, set I/O TOV within 15 seconds.
- For changing the setting, match the value to the recommended value of the external storage system.

To change the port setting of the external storage system:

1. Start Remote Web Console, and open the Path Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Select **Fibre - External Subsystem** from the list above the Path Operation tree.
4. Click the product name in the Path Operation tree.
5. Right-click the WWN that you want to change the setting in the Path Operation list.
6. Click **Change WWN Parameter** in the pop-up menu.

The Change WWN Parameter dialog box opens (see [Figure 37 \(page 97\)](#)).

7. Change the set parameter of the selected port on the Change WWN Parameter dialog box.
8. Click **OK** to close the Change WWN Parameter dialog box and return to the Path Operation window.


The selected items appear in blue italics.

9. Verify the settings in the Preview dialog box.
10. Click **Apply** in the Path Operation window.

The settings are applied to the local storage system and the Path Operation window appears normally. When an error occurs, an error message appears. Verify the details in the Preview dialog box.

## Change WWN Parameter Dialog Box

**Figure 37 Change WWN Parameter Dialog Box**



Change WWN Parameter	
QDepth (2 - 128)	8 -> <input type="text"/>
I/O TOV (5 - 240)	15 -> <input type="text"/> [sec.]
Path Blockade Watch (5 - 180)	10 -> <input type="text"/> [sec.]
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

The Change WWN Parameter dialog box consists of:

- **QDepth (2-128):** The number of Read/Write commands which can be issued (queued) to the external volume at a time. The value that can be set ranges from 2 to 128. The default value is 8.
- **I/O TOV (5-240):** Value specified as the time over of the I/O to the external volume. The value that can be set ranges from 5 to 240 (in seconds). The default value is 15.
- **Path Blockade Watch (5-180):** The time from when the connection of all the paths to the external volume have been down to when the external volume is blocked. The commands from the host

are accepted until the time set for this parameter has passed. After the time set for this parameter has passed, the path status becomes Blockade. The value that can be set ranges from 5 to 180 (seconds). The default value is 10.

## Performing Maintenance for External Subsystem

If a **Not Ready** message occurs in the external storage system when performing maintenance, or during the reboot of the controller of the external storage system by the firmware update, the external storage system might be blocked. This blockade of the external storage system can be prevented by setting a system option 725. To set the system option mode 725, contact your HP service representative.

## Editing Mapping Policy

You choose mapping policy when you map an external volume as an internal volume using the Add Volume commands. This section explains how to edit the default mapping policy. For details on mapping policy, see [“Choosing Mapping Policy” \(page 26\)](#).

To edit the mapping policy:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Right-click **Subsystem** in the Volume Operation tree.
4. Click **Edit Policy** in the pop-up menu.

The Edit Policy dialog box opens.

5. Click **Default Policy** in the **Pattern**.
6. Edit the settings in the **Policy**.
7. Click **Close** to close the Edit Policy dialog box.

The mapping policy changes and then the Volume Operation window opens.

## Edit Policy Dialog Box

Use the Edit Policy dialog box to edit the mapping policy.

**Figure 38 Edit Policy Dialog Box**

Pattern	Policy
(Default Policy)	Emulation Type: OPEN-V <input type="checkbox"/> Except OPEN-V
	CLPR: 0
	SLPR: 0
	Cache Mode: <input checked="" type="radio"/> Enable <input type="radio"/> Disable
	Inflow Control: <input type="radio"/> Enable <input checked="" type="radio"/> Disable
	Number of LDEVs: 2048
	Auto Discovery of Ports: <input type="radio"/> Enable <input checked="" type="radio"/> Disable

Close

The Edit Policy dialog box consists of:

- **Pattern:** Mapping policies. **Default Policy** is prepared.
- **Policy:** The content of the selected mapping policy is displayed.
  - **Emulation Type:** The emulation type of the external volume. To select an emulation type other than OPEN-V, select the **Except OPEN-V** check box and select the emulation type from the list.
  - **CLPR:** CLPR used for accessing to the mapped volume when the cache memory is partitioned using XP Disk/Cache Partition.
  - **SLPR:** SLPR that the selected CLPR belongs to. When the emulation type for the mainframe is selected in **Emulation Type**, you can only select CLPR that belongs to SLPR number 0.
  - **Cache mode:** Indicates if the write I/O from the host is propagated synchronously (**Disable**) or asynchronously (**Enable**) to the external storage system.
  - **Inflow Control:** Indicates the writing operation to the cache memory is stopped (**Enable**) or continued (**Disable**) when the writing operation to the external volume is impossible.
  - **Number of LDEVs:** Maximum number of LDEVs to be created in the external volume.
  - **Auto Discovery of Ports:** Indicates whether to search for the WWN connected to all the external ports (**Enable**) or to search for the WWN connected to only the external port which you specify (**Disable**). If you set **Enable**, port discovery is automatically executed before the Configure Cross-subsystem Paths dialog box opens.
- **Close** button  
Close the Edit Policy dialog box.

## Deleting the External Volume Mapping (Delete Volume Command)

You can start the operation of deleting the external volume mapping from the Volume Operation window. To delete the mapping of the external volume, click the **Delete Volume** command in the pop-up menu displayed in the Volume Operation window. Though you can delete the setting of mapping for an internal volume and an external volume using the **Delete Volume** command, you cannot delete data in the external volume. You cannot delete data in the internal volume either.

You can also delete the external volume mapping by using a spreadsheet. For more information about deleting the external volume mapping by using a spreadsheet, see [“Deleting the External Volume Mapping \(DeleteVolume Tag\)” \(page 115\)](#).

Check the following before deleting the external volume mapping.

- Whether the execution of any application (for example, RAID Manager) that is using the command device is in progress or not.  
If the execution of any application that is using the command device is in progress, stop the application.
- Whether the **Disconnect Subsystem** command or the **Disconnect Volume** command is executed.  
All the data in the cache memory must be written into the mapped external volume using the **Disconnect Subsystem** command or the **Disconnect Volume** command. For detailed information on the **Disconnect Subsystem** command and the **Disconnect Volume** command, see [“Disconnecting External Storage System or Disconnecting External Volume” \(page 91\)](#).
- Whether the volume is set as a volume that configures a LUSE volume.  
When it is set as a volume that configures a LUSE volume, you cannot delete the external volume mapping.

- Whether an LU path is set.  
When an LU path is set to the mapped volume, you cannot delete the external volume mapping.
- Whether the volume is set to configure the XP Continuous Access pair, XP Continuous Access Journal pair, XP Business Copy pair, or XP Snapshot pair.  
When the volume is set to configure the XP Continuous Access pair, XP Continuous Access Journal pair, XP Business Copy pair, or XP Snapshot pair, you cannot delete the external volume mapping.
- Whether the volume is set as a reserved volume for XP Business Copy or XP Auto LUN.  
When the volume is set as the reserved volume for XP Business Copy or XP Auto LUN, you cannot delete the external volume mapping.
- Whether the volume is set as a pool-VOL.  
When the volume is set as a pool-VOL, you cannot delete the external volume mapping.

To delete the external volume mapping:

1. Start Remote Web Console, and open the Volume Operation window.
2. Make sure that Remote Web Console is in Modify mode.
3. Click the path group in the Volume Operation tree.
4. Right-click the external volume that you want to delete in the Volume Operation list.
5. Click **Delete Volume** in the pop-up menu.  
The settings appear in blue italics.
6. Verify the settings in the Preview dialog box (see [“Preview Dialog Box” \(page 54\)](#)).
7. Click **Apply** in the Volume Operation window.
8. When a message appears asking if you have performed the Disconnect operation, click **Yes** if you have already performed the **Disconnect Subsystem** command or the **Disconnect Volume** command. Click **No** if you have not performed the **Disconnect Subsystem** command or the **Disconnect Volume** command yet.
  - If you click **Yes**, the setting is applied to the local storage system, and the external volume where the mapping is deleted is removed from the Volume Operation list.
  - If you click **No**, a message appears asking if you want to execute the Delete Volume operation without writing the data in the cache memory into the external volume.  
Click **OK** to execute the Delete Volume operation without writing the data in the cache memory into the external volume. Click **Cancel** to cancel the operation.
    - When you click **OK**, the setting is applied to the local storage system, and the external volume where the mapping is deleted is removed from the Volume Operation list.
    - When you click **OK**, the Delete Volume operation is performed, however, the data in the cache memory that is not written to the volume is not guaranteed.

When an error occurs, an error message appears. Verify the details in the Preview dialog box.

The operation may not be performed if some parts of the local storage system are blocked. In this case, restore the blocked parts of the local storage system first, and then retry the operation.

## 6 Using Spreadsheets for XP External Storage Operations

This chapter contains the following sections describing how to use spreadsheets, instead of the Remote Web Console GUI, for XP External Storage operations.


- “Introduction” (page 101)
- “Before Using Spreadsheets” (page 102)
- “Available Types and Operation Tags” (page 102)
- “Saving Storage System Information” (page 103)
- “Mapping External Volumes” (page 106)
- “Example of a Spreadsheet” (page 117)

### Introduction

To map external volumes, you may want to use spreadsheets instead of the Remote Web Console GUI. For example, when you want to map many external volumes at a time, using spreadsheets shortens the operation time compared to when using the GUI. You can import spreadsheets directly to the storage system using CFL Extension.

Figure 39 (page 101) describes the work flow when you use spreadsheets.

**Figure 39 Work Flow for Using Spreadsheets**



This chapter describes how to write to spreadsheets as shown in Figure 39 (page 101). For detailed information about the other operations, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

## Before Using Spreadsheets

Remote Web Console is required to use spreadsheets. In addition, you must use CFL Extension (not the Configuration File Loader window) when you perform operations on spreadsheets.

Spreadsheets must be written in the following format. Multiple operation tags and parameters can be written in a spreadsheet.

```
#!Version Version number, Program product, Type, ;  
[Operation tag]  
Parameter
```

Italic text indicates variables that should be changed according to program products or operations. [Table 14 \(page 102\)](#) shows how to write these elements.

**Table 14 Contents of a Spreadsheet**

Element	Content
<i>Version number</i>	See “Available Types and Operation Tags” (page 102).
<i>Program product</i>	CLI_External Storage
<i>Type</i>	See “Available Types and Operation Tags” (page 102).
<i>Operation tag</i>	
<i>Parameter</i>	See “Saving Storage System Information” (page 103) and the subsequent sections.

## Available Types and Operation Tags

Available operation tags differ depending on the types. The version number that you write in the spreadsheet declaration depends on the operation tags. [Table 15 \(page 103\)](#) shows the relationship among types, operation tags, and version numbers supported by XP External Storage.

**Table 15 Relationship Among the Types, Operation Tags, and Version Number**

Type	Operation Tag	Version Number	Template
Get	SSID ExternalGroup MappedVolume	05_02_01	ExternalStorage_ Get_def.spd
VolumeOperationFibre	AddVolumeSetting	05_02_01	ExternalStorage_ AddVolumeSetting_ def_.spd
	AddVolumeSetting2	05_03_01	ExternalStorage_ AddVolumeSetting2_ def_.spd
	DisconnectVolume	05_06_00	ExternalStorage_ DisconnectVolume_ def_.spd
	CheckPath-RestoreVolume	05_06_00	ExternalStorage_ CheckPath-RestoreVolume_ def_.spd
	DeleteVolume	05_06_00	ExternalStorage_ DeleteVolume_def_.spd
	DividePathGroup	05_05_00	ExternalStorage_ DividePathGroup_ def_.spd
	UnitePathGroup	05_05_00	ExternalStorage_ UnitePathGroup_ def_.spd

The operation tags can be used only for XP External Storage. In addition, other operation tags that are common for all program products can also be used in a spreadsheet. For details on common operation tags, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*. For detailed information about the parameters for each operation tag, see the following sections. You can quickly write a spreadsheet if you make a copy of the provided templates and then modify the copy. For information about the location of the templates, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

## Saving Storage System Information

You can save the storage system information in files by specifying a spreadsheet when you execute the `CFLGET` command using the CFL Extension.

The storage system information will be saved in different files for each operation tag. The file named *Input-file-name\_Result.spd* lists all the operation tags and the names of the files.

### SSID Tag

When you write the SSID tag in a spreadsheet and execute the `CFLGET` command, the SSID information will be saved in the files.

Specify the GET\_ALL parameter for the SSID tag. By specifying this parameter, the information about all the SSIDs that the local storage system has will be saved in files.

```
[SSID]
GET_ALL, ;
```

Table 16 (page 104) shows the information that will be saved in a file when the SSID tag is written in a spreadsheet.

**Table 16 Information Saved when the SSID Tag is Written**

Column in Spreadsheet	Item	Content
A	LDKC:CU:LDEV-LDEV	The range of LDEV numbers to which the SSID is assigned
B	SSID	SSID

When the SSID tag is written, the information about internal volumes as well as external volumes will be saved.

## ExternalGroup Tag

When you write the ExternalGroup tag in a spreadsheet and execute the CFLGET command, the information about external volume groups will be saved in the files.

Specify the GET\_ALL parameter for the ExternalGroup tag. By specifying this parameter, the information about all the external volume groups configured to the local storage system will be saved in the files.

```
[ExternalGroup]
GET_ALL, ;
```

Table 17 (page 104) shows the information that will be saved in a file when the ExternalGroup tag is written in a spreadsheet.

**Table 17 Information Saved when the ExternalGroup Tag is Written**

Column in Spreadsheet	Item	Content
A	ExG	External volume group number and its sequential number

## MappedVolume Tag

When you write the MappedVolume tag in a spreadsheet and execute the CFLGET command, the information about external volumes in the local storage system will be saved in the files.

Specify the GET\_ALL parameter for the MappedVolume tag. By specifying this parameter, the information about all the external volumes in the local storage system will be saved in the files.

```
[MappedVolume]
GET_ALL, ;
```

Table 18 (page 105) shows the information that will be saved in a file when the MappedVolume tag is written in a spreadsheet.



**Table 18 Information Saved when the MappedVolume Tag is Written**

Layer	Column in Spreadsheet	Item	Content
<b>First Layer</b>			Information about the external storage system
	A	Vendor	Name of the vendor
	B	Product	Name of the storage system
	C	SerialNumber	Serial number of the storage system
<b>Second Layer</b>			Information about the external volume
	A	+	Identifier
	B	PathGroup	Path group number
	C	ExG	External volume group number and its sequential number
	D	Characteristic1	Identification number of the external volume
	E	Device	Name of the storage system that is reported to the host by the external volume
	F	Attribute	<ul style="list-style-type: none"> <li>• Normal: This volume is an external volume.</li> <li>• R-CMD: This volume is a remote command device.</li> </ul>
	G	CacheMode	<ul style="list-style-type: none"> <li>• Enable: Cache mode is set to Enable.</li> <li>• Disable: Cache mode is set to Disable.</li> </ul>
	H	InflowControl	<ul style="list-style-type: none"> <li>• Enable: Inflow control is set to Enable.</li> <li>• Disable: Inflow control is set to Disable.</li> </ul>
	I	PathMode	<ul style="list-style-type: none"> <li>• Single: The cross-subsystem paths work in the Single mode.</li> <li>• Multi: The cross-subsystem paths work in the Multi mode.</li> <li>• APLB: The cross-subsystem paths work in the APLB mode.</li> </ul>
	J	Capacity	Capacity of the external volume. This capacity is expressed in blocks.
	K	Characteristic2	Extended identification number of the external volume
<b>Third Layer</b>			Information about the cross-subsystem paths
	A	+	Identifier
	B	+	
	C	Port	Port number of the local storage system
	D	WWN	WWN of the external storage system
	E	LUN	LU number of the external volume

The information about the external volumes that is defined to the local storage system will be stored in files per path group. It takes approximately 30 seconds to store the data into files when there are 64 path groups.

## Mapping External Volumes

Tags to map external volumes are:

- The AddVolumeSetting tag: Creates multiple LDEVs in an external volume by specifying the capacity
- The AddVolumeSetting2 tag: Creates one LDEV in an external volume without specifying the capacity

The version number that you write in a spreadsheet declaration differs depending on the tag you use. Write the appropriate version number for the tag you use (for details, see [“Available Types and Operation Tags” \(page 102\)](#)).

You can map external volumes to the local storage system by specifying a spreadsheet that includes one of these tags when you execute the `CFLSET` command using the CFL Extension.

Write parameters required for mapping external volumes in these tags. Parameters must be written in a hierarchical structure by using the + identifier. [Table 19 \(page 106\)](#) shows the structure and identifier of the parameters that can be set for these tags.

**Table 19 Structure and Identifier of Parameters (AddVolumeSetting Tag and AddVolumeSetting2 Tag)**

Layer	Identifier	Content	Description
First layer	None	Information about external volumes and the primary path	This layer is required.
Second layer	+,	Information about alternate paths	Specifies one row for each alternate path. Up to seven rows can be specified. HP recommends that you specify at least one alternate path.
Third layer	+,+,	Information about LDEVs	Specifies one row for each LDEV. Up to 2,048 rows can be specified. If you do not specify the third layer, no LDEVs will be created.

### AddVolumeSetting Tag

Use the AddVolumeSetting tag to create multiple LDEVs in an external volume by specifying the LDEV capacity. The AddVolumeSetting tag allows you to specify the LDEV capacity in blocks so you can use this tag to create an LDEV with the predetermined capacity (an LDEV for creating a pair, for example).

[Table 20 \(page 107\)](#) shows the parameters that can be set for the AddVolumeSetting tag.

**Table 20 AddVolumeSetting Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
<b>First layer</b>			Information about external volumes and the primary path		
	A	PathGroup	Path group number	0 to 63231	5 decimal digits or fewer
	B	Port	Port number of the primary path	1A to GR	2 digits or fewer
	C	WWN	WWN of the primary path	0000000000000000 to FFFFFFFFFFFFFFFF	16 hexadecimal digits
	D	LUN	LU number set to the external volume	0000 to 0FFF	4 hexadecimal digits or fewer
	E	ExG	External volume group number and its sequential number. The format should be <i>EGrp-VPG</i> (for example, E16384-4096).	<i>Grp</i> : 1 to 16384 <i>VPG</i> : 1 to 4096	<i>Grp</i> : 5 decimal digits or fewer <i>VPG</i> : 4 decimal digits or fewer
	F	Attribute	<ul style="list-style-type: none"> <li>Normal: Maps an external volume</li> <li>R-CMD: Maps a command device</li> </ul>	<ul style="list-style-type: none"> <li>Normal</li> <li>R-CMD</li> </ul>	N/A
	G	CLPR	CLPR that is used to access the external volume	0 to 31	2 decimal digits or fewer
	H	Emulation	Emulation type of the external volume. Write the same characters as the emulation type shown in “LDEV Capacity Information for Each Emulation Type” (page 154).	N/A	16 characters or fewer in ASCII format
	I	CacheMode	<ul style="list-style-type: none"> <li>Enable: Sets cache mode to Enable.</li> <li>Disable: Sets cache mode to Disable.</li> </ul>	<ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul>	N/A
	J	InflowControl	<ul style="list-style-type: none"> <li>Enable: Sets inflow control to Enable.</li> <li>Disable: Sets inflow control to Disable.</li> </ul>	<ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul>	N/A

**Table 20 AddVolumeSetting Tag Parameters** *(continued)*

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
<b>Second layer</b>			Information about alternate paths. Specify the paths in the order of descending priorities.		
	A	+	Identifier	N/A	N/A
	B	Port	Port number of the alternate path	1A to GR	2 digits or fewer
	C	WWN	WWN of the alternate path	0000000000000000 to FFFFFFFFFFFFFFFF	16 hexadecimal digits
<b>Third layer</b>			Information about LDEVs to be created in an external volume		

**Table 20 AddVolumeSetting Tag Parameters** *(continued)*

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
	A	+	Identifier	N/A	N/A
	B	+			
	C	LDKC	LDKC number	00 to 01	2 hexadecimal digits or fewer
	D	CU	CU number	00 to FE	2 hexadecimal digits or fewer
	E	LDEV	LDEV number. Specify an LDEV number that is not assigned to any volume. An unassigned LDEV number cannot be specified if other LDEVs in the same area grouped by 32 LDEV numbers are already assigned to a different emulation group. For details on emulation groups, see the <i>HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide</i> .  To see whether the LDEV number can be assigned to a volume or not, view the LDEV dialog box of the Reports Display dialog box. You can also save the content of the LDEV dialog box in a file, and view the file. For details on the LDEV dialog box, see the <i>HP StorageWorks XP24000/XP20000 Remote Web Console User Guide</i> .	00 to FF	2 hexadecimal digits or fewer
	F	Capacity		1 to 8589934592	10 decimal digits or fewer

**Table 20 AddVolumeSetting Tag Parameters** (continued)

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
			Capacity of the LDEV in blocks. For details, see <a href="#">“How to Specify the LDEV Capacity”</a> (page 110).		
	G	SSID	SSID assigned to the range of the LDEV numbers. Specify the SSID written in the file that you saved by using the SSID tag. When you create an LDEV that does not have an SSID, specify an SSID that is not written in this file. For details on an SSID, see the <i>HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide</i> .	0004 to FFFE	4 hexadecimal digits or fewer


### How to Specify the LDEV Capacity

When you specify the LDEV capacity for the AddVolumeSetting tag in a spreadsheet, follow the instruction in this section depending on the emulation type.

- When the emulation type is OPEN-V:
  - Specify the value in the range of 96000 and 8589934592.
  - An LDEV is created from where a slot starts. Therefore, if you specify the LDEV capacity indivisible by the slot size (512 blocks), an adjustment area will be created between where an LDEV ends and where the next LDEV starts. This adjustment area cannot be used as an LDEV.  
You can calculate the adjustment area using the following equation:  
Adjustment area capacity =  $\lceil \text{LDEV capacity} \div 512 \rceil \times 512 - \text{LDEV capacity}$   
The value enclosed in two upward arrows ( $\lceil \rceil$ ) must be rounded up to the nearest whole number.
  - Make sure that the capacity of the external volume is greater than or equal to the capacity that is the sum of the total capacity of all the LDEVs in the external volume and the total capacity of the adjustment areas.

[Figure 40 \(page 111\)](#) gives an example of creating four LDEVs of 100,000 blocks each. In this case, the required capacity of the external volume is 401,056 blocks.

**Figure 40 When Creating Multiple LDEVs in an External Volume**



- When the emulation type is other than OPEN-V:  
For details on the base LDEV capacity, the base data area capacity, and the control information area capacity, see [“Required Volume Capacity for Each Emulation Type”](#) (page 152).
  - If the capacity of the external volume is equal to or larger than the base LDEV capacity, specify the base data area capacity. Also, make sure that the capacity of the external volume is greater than or equal to the total capacity of the base LDEV capacity for all the LDEVs.
  - If the capacity of the external volume is smaller than the base LDEV capacity, create one LDEV the capacity of the external volume. Also, specify the value that is calculated by using the following equation:  
$$\text{LDEV capacity} = \left\lfloor \frac{(\text{External volume capacity} - \text{Control information area capacity})}{\text{Cylinder capacity}} \right\rfloor \times \text{Cylinder capacity}$$

The value enclosed in two downward arrows (  $\downarrow$  ) must be rounded down to the nearest whole number.

Use the following numbers for the cylinder capacity:

    - For 3380 mainframe volumes: 1,440 blocks
    - For 3390 mainframe volumes: 1,740 blocks
    - For open volumes other than OPEN-V: 1,440 blocks

## AddVolumeSetting2 Tag

Use the AddVolumeSetting2 tag to create one LDEV in an external volume without specifying the LDEV capacity. The created LDEV has the same capacity as the external volume. You can also use this tag when you use existing data in the external volume after mapping.

The LDEV is created with the following settings:

- LDEV capacity: the same capacity as the external volume
- Emulation type: OPEN-V
- Cache mode: Disable
- Inflow control: Disable

[Table 21](#) (page 112) shows the parameters that can be set for the AddVolumeSetting2 tag.

**Table 21 AddVolumeSetting2 Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
<b>First layer</b>			Information about external volumes and the primary path		
	A	PathGroup	Path group number	0 to 63231	5 decimal digits or fewer
	B	Port	Port number of the primary path	1A to GR	2 digits or fewer
	C	WWN	WWN of the primary path	00000000 00000000 to FFFFFFFF FFFFFFFF	16 hexadecimal digits
	D	LUN	LU number set to the external volume	0000 to 0FFF	4 hexadecimal digits or fewer
	E	ExG	External volume group number and its sequential number. The format should be <i>EGrp-VPG</i> (for example, E16384-4096).	<i>Grp</i> : 1 to 16384 <i>VPG</i> : 1 to 4096	<i>Grp</i> : 5 decimal digits or fewer <i>VPG</i> : 4 decimal digits or fewer
	F	Attribute	<ul style="list-style-type: none"> <li>Normal: Maps an external volume</li> <li>R-CMD: Maps a command device</li> </ul>	<ul style="list-style-type: none"> <li>Normal</li> <li>R-CMD</li> </ul>	N/A
	G	CLPR	CLPR that is used to access the external volume	0 to 31	2 decimal digits or fewer
<b>Second layer</b>			Information about alternate paths. Specify the paths in the order of descending priorities.		
	A	+	Identifier	N/A	N/A
	B	Port	Port number of the alternate path	1A to GR	2 digits or fewer
	C	WWN	WWN of the alternate path	00000000 00000000 to FFFFFFFF FFFFFFFF	16 hexadecimal digits
<b>Third layer</b>			Information about LDEVs to be created in an external volume		



**Table 21 AddVolumeSetting2 Tag Parameters** *(continued)*

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
	A	+	Identifier	N/A	N/A
	B	+			
	C	LDKC	LDKC number	00 to 01	2 hexadecimal digits or fewer
	D	CU	CU number	00 to FE	2 hexadecimal digits or fewer
	E	LDEV	<p>LDEV number. Specify an LDEV number that is not assigned to any volume. However, an unassigned LDEV number cannot be specified if other LDEVs in the same area grouped by 32 LDEV numbers are already assigned to a different emulation group. For details on emulation groups, see the <i>HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide</i>.</p> <p>To see whether the LDEV number can be assigned to a volume or not, view the LDEV dialog box of the Reports Display dialog box. You can also save the content of the LDEV dialog box in a file, and view the file. For details on the LDEV dialog box, see the <i>HP StorageWorks XP24000/XP20000 Remote Web Console User Guide</i>.</p>	00 to FF	2 hexadecimal digits or fewer
	F	SSID		0004 to FFFE	4 hexadecimal digits or fewer

**Table 21 AddVolumeSetting2 Tag Parameters** *(continued)*

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
			SSID assigned to the range of the LDEV numbers. Specify the SSID written in the file that you saved by using the SSID tag. When you create an LDEV that does not have an SSID, specify an SSID that is not written in this file. For details on an SSID, see the <i>HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide</i> .		

## Disconnecting an Individual External Volume (DisconnectVolume Tag)

Use the DisconnectVolume tag to disconnect an individual external volume. [Table 22 \(page 114\)](#) shows the parameters that can be set for the DisconnectVolume tag.

**Table 22 DisconnectVolume Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
The first layer	A	ExG	External volume group number and its sequential number. The format should be <i>EGrp-VPG</i> (for example, E16384-4096).	<i>Grp</i> : 1 to 16384 <i>VPG</i> : 1 to 4096	<i>Grp</i> : 5 decimal digits or fewer <i>VPG</i> : 4 decimal digits or fewer

## Resuming an Individual External Volume (CheckPath-RestoreVolume Tag)

Use the CheckPath-RestoreVolume tag to resume an individual external volume operation. [Table 23 \(page 115\)](#) shows the parameters that can be set for the CheckPath-RestoreVolume tag.

**Table 23 CheckPath-RestoreVolume Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
The first layer	A	ExG	External volume group number and its sequential number. The format should be <i>EGrp-VPG</i> (for example, E16384-4096).	<i>Grp</i> : 1 to 16384 <i>VPG</i> : 1 to 4096	<i>Grp</i> : 5 decimal digits or fewer <i>VPG</i> : 4 decimal digits or fewer

## Deleting the External Volume Mapping (DeleteVolume Tag)

Use the DeleteVolume tag to delete the external volume mapping. [Table 24 \(page 115\)](#) shows the parameters that can be set for the DeleteVolume tag.

**Table 24 DeleteVolume Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
The first layer	A	ExG	External volume group number and its sequential number. The format should be <i>EGrp-VPG</i> (for example, E16384-4096).	<i>Grp</i> : 1 to 16384 <i>VPG</i> : 1 to 4096	<i>Grp</i> : 5 decimal digits or fewer <i>VPG</i> : 4 decimal digits or fewer

## Changing Path Group

The DividePathGroup tag is used to move an external volume from an existing path group to a new path group.

The UnitePathGroup tag is used to move all external volumes from one path group to another path group.

### DividePathGroup Tag

Use the DividePathGroup tag to move an external volume from an existing path group to a *new* path group. If no external volume remains in the source path group after the move, the group is automatically deleted.

The DevicePathGroup tag allows you to move an external volume only to a new path group. To move an external volume to an existing path group, first use DevicePathGroup to move the volume to a new path group, and then use the UnitePathGroup tag to move the volume from the new path group to an existing path group. For more information about UnitePathGroup tag, see [“UnitePathGroup Tag” \(page 116\)](#).

Write parameters are required to change the path group. Parameters must be written using the + identifier. [Table 25 \(page 116\)](#) shows the structure and identifier of the parameters that can be set for this tag.

**Table 25 Structure and Identifier of Parameters (DividePathGroup Tag)**

Layer	Identifier	Content	Description
The first layer	None	Information about the path group that you want to change.	This layer is required.
The second layer	+,	Information about the new path group.	This layer is required.
The third layer	+,+,	Information about external volumes that you want to move.	Specifies one row for each alternate external volume.  External volumes in the same path group can be moved by specifying two or more external volumes.

Table 26 (page 116) shows the parameters that can be set for the DividePathGroup tag.

**Table 26 DividePathGroup Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
The first layer			Information about the path group that you want to change.		
	A	PathGroup	Path group number.	0 to 63231	5 decimal digits or fewer
The second layer			Information about the new path group.		
	A	+	Identifier.	N/A	N/A
	B	NewPath Group	New path group number.	0 to 63231	5 decimal digits or fewer
The third layer			Information about external volumes that you want to move.		
	A	+	Identifier	N/A	N/A
	B	+			
	C	ExG	External volume group number and its sequential number. The format should be EGrp-VPG (for example, E16384-4096).	Grp: 1 to 16384 VPG: 1 to 4096	Grp: 5 decimal digits or fewer VPG: 4 decimal digits or fewer

## UnitePathGroup Tag

The UnitePathGroup tag is used to move all external volumes from one path group to another path group. The source path group will be automatically deleted because there will be no external volume in the path group after the volumes are moved.

Write parameters are required to change the path group for this tag. Parameters must be written using the + identifier. Table 27 (page 117) shows the structure and identifier of the parameters.

**Table 27 Structure and Identifier of Parameters (UnitePathGroup Tag)**

Layer	Identifier	Content	Description
The first layer	None	Information about the path group to which you want to move an external volume.	This layer is required.
The second layer	+,	Information about the path group that you want to change.	Specifies one row for each alternate path group. External volumes in two or more path groups can be moved to one path group by specifying two or more path groups.

Table 28 (page 117) shows the parameters that can be set for the UnitePathGroup tag.

**Table 28 UnitePathGroup Tag Parameters**

Layer	Column in Spreadsheet	Parameter	Setting	Range of Values	Number of Characters
The first layer			Information about the path group to which you want to move an external volume.		
	A	PathGroup	Path group number.	0 to 63231	5 decimal digits or fewer
The second layer			Information about the path group that you want to change.		
	A	+	Identifier.	N/A	N/A
	B	TargetPathGroup	Path group number.	0 to 63231	5 decimal digits or less

## Example of a Spreadsheet

This section shows an example of a spreadsheet that can be used for mapping an external volume in the following configuration:

- An external volume is configured as follows:
  - Map the volume to which 0001 is configured as a LUN that can be discovered through the primary path.
  - Use 1 for a path group number.
  - Configure E16384-4095 for an external volume group (ExG).
- Two cross-subsystem paths are configured as follows:
  - The primary path  
Port number on the local storage system: 1A  
WWN on the external storage system: 60060E8004F81370
  - The alternate path  
Port number on the local storage system: 1B  
WWN on the external storage system: 60060E8004F81371
- Attributes of an external volume are configured as follows:
  - Emulation type: OPEN-V
  - Cache mode: Enable

- Inflow control: Disable
- CLPR: 00
- LDEVs are configured as follows:
  - Number of LDEVs: 3
  - LDEV number: 00:00:00, 00:01:00, 00:02:00
  - LDEV capacity: 96,000 blocks

*Example:*

```
#!Version 50_02_01, CLI_ExternalStorage, VolumeOperationFibre,;

[SerialNumber]
65536,;

[AddVolumeSetting]
1,1A,60060E8004F81370,0001,E16384-4095,Normal,00,OPEN-V,Enable,Disable,;
+,1B,60060E8004F81371,;
+,+,00,00,00,96000,0004,;
+,+,00,01,00,96000,0005,;
+,+,00,02,00,96000,0006,;
```

## 7 Remote Command Devices

This chapter describes how to use remote command devices as command devices.

- “Overview of Remote Command Devices” (page 119)
- “Guidelines for Remote Command Devices” (page 120)
- “Mapping a Command Device as a Remote Command Device” (page 122)
- “Using XP Continuous Access or XP Continuous Access Journal with Remote Command Device” (page 122)

### Overview of Remote Command Devices


A remote command device is a device in the local storage system to which a command device in the external storage system is mapped.

As you send the RAID Manager commands to the remote command device, you can enter these RAID Manager commands to the command device of the external storage system to operate the RAID Manager in the external storage system.

Figure 41 (page 119) shows an example. The OPEN host that is connected to the local storage system sends the RAID Manager commands of XP Business Copy or XP Continuous Access to the remote command device, and this means that the commands are entered to the command device in the external storage system to operate the XP Business Copy pair or the XP Continuous Access pair in the external storage system.

For detailed information about RAID Manager and the command device, see the *HP StorageWorks XP RAID Manager User Guide*.

**Figure 41 Outline of Remote Command Device**



## Guidelines for Remote Command Devices

Notices on remote command device are as follows:

- You can map a command device as a remote command device when one of the following storage systems is connected as an external subsystem.
  - Universal Storage Platform V
  - Universal Storage Platform VM
  - TagmaStore Universal Storage Platform
  - TagmaStore Network Storage Controller
  - Adaptable Modular Storage
  - Workgroup Modular Storage
  - Lightning 9900V series
  - Thunder 9500V series
  - SANRISE Universal Storage Platform
  - SANRISE Network Storage Controller
  - SANRISE9900V series
  - SANRISE9500V series
  - H24000
  - H20000
  - SANRISE H12000
  - SANRISE H10000
  - SANRISE H1024/H128
  - HP StorageWorks XP24000 Disk Array
  - HP StorageWorks XP20000 Disk Array
  - HP StorageWorks XP12000 Disk Array
  - HP StorageWorks XP10000 Disk Array
  - HP StorageWorks XP1024/XP128 Disk Array
- You do not need the license for XP External Storage to map a command device as a remote command device.
- The remote command devices appear in the **Device** column on the Volume Operation window (see [Table 29 \(page 121\)](#)):



**Table 29 Displayed Information in Device Column for Remote Command Device**

Storage System	Displayed Information in Device Column
Universal Storage Platform V Universal Storage Platform VM TagmaStore Universal Storage Platform TagmaStore Network Storage Controller Lightning 9900V series SANRISE Universal Storage Platform SANRISE Network Storage Controller SANRISE9900V series H24000 H20000 SANRISE H12000 SANRISE H10000 SANRISE H1024/H128 HP StorageWorks XP24000 Disk Array HP StorageWorks XP20000 Disk Array HP StorageWorks XP12000 Disk Array HP StorageWorks XP10000 Disk Array HP StorageWorks XP1024/XP128 Disk Array	Format: <i>Emulation Type</i> + -CM For example, OPEN-V-CM, OPEN-3-CM
Adaptable Modular Storage Workgroup Modular Storage Thunder 9500V series SANRISE9500V series	DF600F-CM

- If you access the remote command device from an OPEN host, the device information that is reported by the remote command device is about the command device, which is mapped as a remote command device, of the external storage system.

The device information about the command device that is reported to the host by the remote command device includes the following:

- Serial number
- Vendor
- Device name

The device name that is reported to the host is same as the one displayed in the **Device** column of the Volume Operation window. For the device name that is reported to the host, see [Table 29 \(page 121\)](#).

- Even if the status of the remote command device is normal, an error may occur when the operations or commands are performed on the remote command device.  
If an error occurs even though the status of the remote command device is normal, check the status of the command device of the external storage system, not the remote command device.
- [Table 30 \(page 122\)](#) shows restrictions for mapping a command device as a remote command device.

**Table 30 Restrictions on Remote Command Device**

Item	Restriction
Emulation type	OPEN-V
Number of LDEVs in an external volume	1
Cache mode	Disable
Minimum capacity	96,000 Blocks (about 47 MB)
Maximum capacity	4 TB

- The remote command device cannot be identified by the port discovery or volume discovery of XP External Storage.
- When an external storage system (A) has a remote command device (B) [that is, when a command device in another external storage system (C) is mapped to this external storage system (A)], make sure that the remote command device (B) does not have the smallest LUN ID on the port in the external storage system (A).
- You cannot execute I/Os to the remote command device.
- You cannot set the command device disable on the remote command device.
- You cannot set the command device security on the remote command device.
- Do not set the command device security on the external storage system side for the command device that is mapped as a remote command device.
- You cannot create a LUSE volume using a remote command device.
- You cannot create CVs using the VLL function in the remote command device.
- Cache Residency Manager is not available on the remote command device.

## Mapping a Command Device as a Remote Command Device

The command devices that can be mapped as remote command devices appear in the **Device** column of the Volume Operation window as shown in [Table 29 \(page 121\)](#).

To map a command device, select a command device that can be mapped and follow the procedure in [“Mapping an External Volume Automatically” \(page 67\)](#).

## Using XP Continuous Access or XP Continuous Access Journal with Remote Command Device

When you want to use XP Continuous Access or XP Continuous Access Journal with a remote command device, you need two different kinds of ports, which are an initiator port for XP Continuous Access or XP Continuous Access Journal and an external port for the remote command device. However, if you set the Initiator/External MIX mode, you will be able to use a port as both initiator port for XP Continuous Access or XP Continuous Access Journal and external port only for the remote command device.

Before you set the Initiator/External MIX mode, you need to prepare initiator ports and external ports in one port block of the Standard mode. You can set the Initiator/External MIX mode on the port block that consists of the initiator ports and external ports.

[Figure 42 \(page 123\)](#) shows the difference between the Standard mode and Initiator/External MIX mode. When the Standard mode is set to the ports, you have to connect the cables for both initiator port and external port. However, if you set the Initiator/External MIX mode, you just need to connect one cable, and you can use XP Continuous Access or XP Continuous Access Journal and remote command device.

For detailed information on the port block and setting the Initiator/External MIX mode, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.

**Figure 42 Difference between Standard Mode and Initiator/External MIX Mode**





Figure 43 (page 124) shows an example of using XP Continuous Access or XP Continuous Access Journal with remote command device. The System 1 functions as MCU of XP Continuous Access or XP Continuous Access Journal, and at the same time it functions as the local storage system of the remote command device. The System 2 functions as RCU of XP Continuous Access or XP Continuous Access Journal, and at the same time it functions as the external storage system of the remote command device. In this case, the setting of XP Continuous Access pair or XP Continuous Access Journal pair and setting of the remote command device are both made using the port of the Initiator/External MIX mode. As this example shows, you only need to connect one cable to one of the ports that are set to the Initiator/External MIX mode, which means that you do not need to connect cables to each port of different port attributes.

**Figure 43 Example of Using XP Continuous Access or XP Continuous Access Journal with Remote Command Device**



## Procedure to Use Initiator/External MIX Mode

This section describes the procedure to use the Initiator/External MIX mode and the procedure to stop using the Initiator/External MIX mode.

To use the Initiator/External MIX mode:

1. Prepare the initiator ports of the Standard mode and external ports of the Standard mode in one port block.  
For the procedure to set the port attribute to initiator, see the *HP StorageWorks XP24000/XP20000 Continuous Access Software User's Guide* or the *HP StorageWorks XP24000/XP20000 Continuous Access Journal Software User Guide*.
2. Set the Initiator/External MIX mode to the port block consisting of the initiator ports of the Standard mode and external ports of the Standard mode.  
For the procedure to set the Initiator/External MIX mode, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.
3. Connect the cable to the port, and connect a storage system to be used as an MCU and local storage system and a storage system to be used as an RCU and external storage system.

4. Map the command device as the remote command device.  
Only the command device can be recognized when the discovery operation is performed using the external port of the Initiator/External MIX mode.
5. Start the operation of XP Continuous Access or XP Continuous Access Journal and operation of the remote command device using the port of the Initiator/External MIX mode.

To stop using the Initiator/External MIX mode:

1. Stop the copy processing and operation of XP Continuous Access and XP Continuous Access Journal.
2. Stop accessing the remote command device.
3. Delete the mapping of the remote command device.
4. Change the setting of the port block from the Initiator/External MIX mode to the Standard mode.

For the procedure to change the setting of the port block, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.

## Restrictions on Initiator/External MIX Mode

The restrictions on the Initiator/External MIX mode are as follows:

- The restrictions on the High Speed mode are also restrictions on the Initiator/External MIX mode. For the restrictions on the High Speed mode, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.
- The point-to-point connection is not available.
- You cannot set the Initiator/External MIX mode on the external ports of the Standard mode that have already been used to map the external volumes. You cannot set the Standard mode on the port of the Initiator/External MIX mode that has already been used to map the remote command device. You need to delete the mapping of the external volume and then change the setting of the port mode.
- Using a port of the Initiator/External MIX mode, the command device of the external storage system can only be recognized by the discovery operation and mapped. Other volumes can be neither recognized by the discovery operation nor mapped using the port of the Initiator/External MIX mode.

## 8 Troubleshooting

This chapter provides troubleshooting information for XP External Storage.

- “Troubleshooting for XP External Storage” (page 126)
- “Calling HP Technical Support” (page 131)

### Troubleshooting for XP External Storage



If you have a problem with the Remote Web Console computer or Remote Web Console software, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide* for troubleshooting information.

Table 31 (page 126) provides general troubleshooting instructions for the XP External Storage operations. If you need to call the HP technical support, see “Calling HP Technical Support” (page 131) for instructions.

**Table 31 General Troubleshooting for XP External Storage**

Error	Corrective Action
The Remote Web Console computer cannot access the external volume.	<p>Remove the error and retry the operation.</p> <p>The reason for the error could be as follows:</p> <ul style="list-style-type: none"><li>• The switch is off.</li><li>• An error occurred in the switch.</li><li>• The cables are not properly connected.</li><li>• Configuration in the external storage system is altered, and the specified external volume has already been deleted.</li><li>• An error on the external volume in the external storage system has occurred.</li><li>• The path has been changed in the external storage system.</li><li>• The port attribute of the local storage system has been changed.</li><li>• The topology information has not been properly set.</li></ul>
The external volume cannot be mapped as an internal volume of the local storage system.	<p>Remove the error and retry the operation.</p> <p>The reason for the error could be as follows:</p> <ul style="list-style-type: none"><li>• The number of mapped volumes exceeds the maximum number (63,232) available for the local storage system.</li><li>• There are not enough LDKC:CU:LDEV numbers available for external volume mapping.</li></ul>
The path to the external volume is blocked.	<ol style="list-style-type: none"><li>1. The factors listed in the first row of Table 31 (page 126) (Error: The Remote Web Console computer cannot access the external volume) could also be the reason for this error. Check the factors of the first row, remove the error, and retry the operation. When the error still remains, try step 2.</li><li>2. Try the following procedures. If the following procedures do not work and the path is not restored, call HP technical support.<ul style="list-style-type: none"><li>• Confirm that the cable between the local storage system and the external storage system is connected properly.</li><li>• When the cable between the local storage system and the external storage system is connected properly, disconnect it once and connect it appropriately again. After 30 seconds, check the path status from Remote Web Console.</li></ul></li></ol>
The path status that requires the reaction appears in the Mapping Path Information dialog box (see “Mapping Path Information Dialog Box” (page 86).	<p>See “Troubleshooting the Mapping Path” (page 127) and perform the required action.</p>

**Table 31 General Troubleshooting for XP External Storage** *(continued)*

Error	Corrective Action
The volume in the external storage system cannot be found even after the port discovery or the volume discovery was performed.	Perform the required action and retry the operation. See “ <a href="#">Troubleshooting Volume Discovery</a> ” (page 130) for the causes of the error.
The external volume is blocked.	Remove the error and retry the operation. The reason for the error could be as follows: <ul style="list-style-type: none"> <li>• All the set paths are blocked (paths are not connected).</li> <li>• The attribute of external volume is not set to Read/Write attribute.</li> <li>• The external volume is blocked by error.</li> </ul>
The <b>Check Paths &amp; Restore Volume</b> command is executed and you have waited more than 10 minutes, but the status of the device does not change from <b>Checking</b> .	Click the <b>Refresh</b>  command on the Remote Web Console main window while the <b>Status: Enable</b> button is shown. If the device status remains as <b>Checking</b> even though you have updated the information, execute the <b>Check Paths &amp; Restore Volume</b> command again. If the same problem persists despite retrying, call HP technical support.
The <b>Disconnect Subsystem</b> command or the <b>Disconnect Volume</b> command is executed, but the progress status information is not updated.	Click the <b>Refresh</b>  command on the Remote Web Console main window while the <b>Status: Enable</b> button is shown. If the progress information about the <b>Cache Destage</b> status is not updated even though you have updated the information, call HP technical support. The time required for the writing processing of data from the cache to the external volume (destaging processing) depends on the volume capacity (more time is required for the larger volume than the smaller one). The processing speed is about 20 MB/s. However, the processing speed depends on the performance and the status of the external storage system.
The message of INTERVENTION REQUIRED is issued to the mainframe host as the device status.	The device status is currently changing. Wait for a while, and then check the device status again. When the transition of the device status has completed normally, the device can be used immediately. If the device is blocked as a result of the device status transition, see the error description “The external volume is blocked.” in <a href="#">Table 31 (page 126)</a> for the corrective action.
The message of DEVICE ERROR is issued to the mainframe host as the device status.	See the error description “The external volume is blocked.” in <a href="#">Table 31 (page 126)</a> for the corrective action.

## Troubleshooting the Mapping Path

[Table 32 \(page 127\)](#) shows the description on the path statuses that are displayed in the **Status** column in the Mapping Path Information dialog box and the reactions for them. See “[Connecting External Storage Systems](#)” (page 134) for notes on connecting each storage system as an external storage system and for settings of connection and examples of recovery procedure, and then take corrective actions.

**Table 32 Mapping Path Statuses and Required Actions**

Status	Description	Action
<b>Unknown</b>	The status of the path is unknown.	The status of the path cannot be identified. Call HP technical support.
<b>Blockade</b>	The external port is blocked.	The external port is blocked because of the microcode replacement or package replacement or other factor. Check the status of the local storage system. If you cannot restore the path, call HP technical support.

**Table 32 Mapping Path Statuses and Required Actions** *(continued)*

Status	Description	Action
<b>External device setting changed</b>	The setting of the external storage system has been changed. For example, the path definition was deleted, or the external storage system itself was replaced by another device.	The port of the external storage system is recognized. See the documents for your external storage system, and check if the operation that changes the setting information about the mapped device has not been performed.
<b>LDEV size reduced</b>	The setting of the volume capacity of the external storage system has been changed (the volume capacity was reduced).	Check the volume capacity of the volume of the external storage system. Execute the Delete Volume operation, and then retry the Add Volume operation.
<b>Not ready</b>	The reply of the external storage system was NOTREADY. The drive of the external storage system is spinning up, or the device of the external storage system is being formatted.	The path cannot be used to access the external storage system. Check the status of the external storage system. If you cannot restore the path, call HP technical support.
<b>Illegal request</b>	The reply of the external storage system was ILLEGALREQUEST. The command cannot be executed to the device of the external storage system. The data protection may be set on the device of the external storage system.	The port of the external storage system is recognized. Check the setting of the external storage system. If you cannot restore the path, call HP technical support.
<b>Command aborted</b>	The reply of the external storage system was ABORTEDCOMMAND. An error may have occurred on the external storage system side.	The port of the external storage system is recognized. Check the setting of the external storage system and the condition of the connection (for example, cables, switches) to the external storage system. If you cannot restore the path, call HP technical support.
<b>Busy</b>	The external storage system is in the BUSY status.	The port of the external storage system is recognized. Check the setting of the external storage system and the load on the external storage system (for example, check if the configuration gives too much load on the external storage system or not). If you cannot restore the path, call HP technical support.
<b>LDEV reserved</b>	The external storage system is in the Reserve status. You are not allowed to access the device of the external storage system from the local storage system.	Remove the Reserve status on the device of the external storage system.
<b>Response error</b>	The external storage system is in the blocked status caused by the abnormal reply (Response). You may not be able to access the device of the external storage system. Or data protection may be set on the device of the external storage system.	The port of the external storage system is recognized. Check the setting and status of the external storage system. If you cannot restore the path, call HP technical support.
<b>Initiator port</b>	The port attribute of the external storage system has been changed to the initiator port.	Set the port attribute of the external storage system to the target port. If you cannot restore the path, call HP technical support.



**Table 32 Mapping Path Statuses and Required Actions** *(continued)*

Status	Description	Action
<b>Unknown port</b>	The port attribute of the external storage system is unknown.	The port of the external storage system is recognized. Check the condition of the connection (for example, cables, switches) to the external storage system. If you cannot restore the path, call HP technical support.
<b>Cannot detect port</b>	<p>The path has been removed or the port of the external storage system cannot be found. There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fiber cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• Because the security is set on the port, the device of the external storage system cannot be recognized from the local storage system.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul>	Check the condition of the connection to the external storage system. If you cannot restore the path, call HP technical support.
<b>Internal error</b>	The program error occurred. Or there is a logical contradiction.	Call HP technical support.
<b>Timeout</b>	The processing was retried because the abnormal reply (Response) was returned, however, the processing has been stopped by timeout.	The port of the external storage system is recognized. Check the condition of the connection (for example, cables, switches) to the external storage system. If you cannot restore the path, call HP technical support.
<b>Target error</b>	An error such as the blockade of the controller has been found in the port of the external storage system.	Check the status of the ports of the external storage system. If you cannot restore the path, call HP technical support.
<b>Unavailable</b>	The reply of the external storage system was Unavailable. The external storage system demands to change the connected port. When the status becomes Unavailable, the primary path changes to the alternate path that is in the Standby status. When the primary path has been changed, the status of the path becomes Normal.	If the path is not changed over properly, check the status of the external storage system. If you cannot restore the path, call HP technical support.
<b>Backoff</b>	The reply of the external storage system was Backoff. The status of the path is waiting for recovery because a temporary error has occurred in the volume of the external storage system. Even if the status of the primary path becomes this status, the primary path is not changed to the alternate path immediately. After the error recovery, the status becomes Normal.	If the status cannot be recovered from the error, the path status changes to another status. React to the new path status after the status is changed. If you cannot restore the path, call HP technical support.

**Table 32 Mapping Path Statuses and Required Actions** *(continued)*

Status	Description	Action
<b>Device check error</b>	An external volume is mapped, but you cannot access the volume in the external storage system.	Check the status of the volume in the external storage system and recover the volume if it is not normal. Format the volume if it is not formatted.
<b>Medium error</b>	The volume in the external storage system becomes inaccessible.	Check the status of the volume in the external storage system and recover the volume if it is not normal. Format the volume if it is not formatted.

## Troubleshooting Volume Discovery

Table 33 (page 130) shows the causes of port discovery failure or volume discovery failure, and actions required to troubleshoot the failure.

**Table 33 Causes of Volume Discovery Failure and Required Actions**

Cause	Action
Remote Web Console is not in the Modify mode.	Change to the Modify mode and retry the operation.
Port of the local storage system and port of the external storage system are not connected.	Connect the external port of the local storage system and the port of the external storage system.
Cable for the switch is not connected appropriately. Or the port of the switch is blocked.	Connect the cable to the correct port of the switch. Or change the port status of the switch into the normal status.
Zoning for the switch is not set appropriately.	Make sure the zone configuration is correct so that the external port of the local storage system can communicate with the port of the external storage system.
External storage system is not connected to the port set to External of the local storage system.	Connect the external storage system to the External port of the local storage system. Or change the connected port to External.
External volume cannot be used because the used external port is in the Internal/External MIX mode. This problem occurs when the external volume is not a command device.	Perform one of the following: <ul style="list-style-type: none"> <li>Use the external port in the Standard mode.</li> <li>Change the Internal/External MIX mode of the external port to the Standard mode.</li> </ul>
External volume returned RESERVATION CONFLICT.	Release the reserved state of the external volume.
Port security is set on the external storage system.	Cancel the port security setting or change the security of the external storage system so that the local storage system can access the port of the external storage system.
No LU is configured on the port of the external storage system.	Configure an LU on the port of the external storage system.
Capacity of the external volume is less than the supported capacity of XP External Storage.	Perform one of the following: <ul style="list-style-type: none"> <li>Increase the capacity of the external volume so that the capacity of the external volume is equal to or larger than the capacity supported by XP External Storage.</li> <li>Use a security function or delete the LU setting from the port of the connected external storage system so that the local storage system cannot recognize the volume with insufficient capacity.</li> </ul>

**Table 33 Causes of Volume Discovery Failure and Required Actions** *(continued)*

<b>Cause</b>	<b>Action</b>
External volume is configured as a management LU.	<p>If a management LU is configured on the port of the external storage system, perform one of the following:</p> <ul style="list-style-type: none"> <li>• Make sure that at least one LU is used for data storage and has a smaller LUN than the LUN of the management LU. Also make sure that the data storage LU is set to the port connected to the local storage system.</li> <li>• Delete the management LU from the port connected to the local storage system. operations.</li> <li>• Use a security function and configure the access attribute of the management LU to prohibit read and write</li> </ul>
Remote command devices of the external storage system are cascaded.	<p>Perform one of the following:</p> <ul style="list-style-type: none"> <li>• Change the configuration so that the remote command devices are not cascaded.</li> <li>• Use a security function or delete the LU setting from the port of the connected external storage system so that the local storage system cannot recognize the remote command devices.</li> </ul>
External storage system information that is retrieved by the port discovery is not found in the profile information.	<p>Perform one of the following:</p> <ul style="list-style-type: none"> <li>• Connect an external storage system supported by XP External Storage.</li> <li>• Call HP technical support to ask if the external storage system is supported by XP External Storage. If the external storage system is supported, you can connect the external storage system by either installing the microcode version that supports the external storage system or the profile information for the external storage system.</li> </ul>
Login to the external storage system failed.	<p>Perform one of the following:</p> <ul style="list-style-type: none"> <li>• Make sure that the port of the external storage system is in the normal status.</li> <li>• Register WWN to the external storage system to allow login from the local storage system.</li> </ul>
External volume is not in the normal status. Or a failure or an error occurred in retrieving the information from the external storage system.	<p>Make sure that the external storage system or the external volume is in the normal status.</p>

If none corresponds to the actual factor, disconnect the cable between the local storage system and the external storage system once and connect it appropriately again. After 30 seconds, retry the operation.

## Calling HP Technical Support

If you need to call HP technical support, be sure to provide as much information about the problem as possible. Include the circumstances surrounding the error or failure, the Remote Web Console configuration information saved in the floppy disks by the **FD Dump Tool**, the exact content of any messages displayed on the Remote Web Console, and the severity levels and reference codes displayed on the **Status** tab of the Remote Web Console main window.

---

## 9 Support and Other Resources

### Related Documentation

- *HP StorageWorks XP24000/XP20000 Disk Array Owner Guide*
- *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*
- *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*

You can find these documents on the HP Manuals website:

<http://www.hp.com/support/manuals>

In the Storage section, click **Storage Software** and then select a product.

### Conventions for Storage Capacity Values

HP XP storage systems use the following values to calculate physical storage capacity values (hard disk drives):

- 1 KB (kilobyte) = 1,000 bytes
- 1 MB (megabyte) = 1,000<sup>2</sup> bytes
- 1 GB (gigabyte) = 1,000<sup>3</sup> bytes
- 1 TB (terabyte) = 1,000<sup>4</sup> bytes
- 1 PB (petabyte) = 1,000<sup>5</sup> bytes

HP XP storage systems use the following values to calculate logical storage capacity values (logical devices):

- 1 KB (kilobyte) = 1,024 (2<sup>10</sup>) bytes
- 1 MB (megabyte) = 1,024 KB or 1,024<sup>2</sup> bytes
- 1 GB (gigabyte) = 1,024 MB or 1,024<sup>3</sup> bytes
- 1 TB (terabyte) = 1,024 GB or 1,024<sup>4</sup> bytes
- 1 PB (petabyte) = 1,024 TB or 1,024<sup>5</sup> bytes
- 1 block = 512 bytes

### HP Technical Support

For worldwide technical support information, see the HP support website:

<http://www.hp.com/support>

Before contacting HP, collect the following information:

- Product model names and numbers
- Technical support registration number (if applicable)
- Product serial numbers
- Error messages
- Operating system type and revision level
- Detailed questions

## Subscription Service

HP recommends that you register your product at the Subscriber's Choice for Business website:

<http://www.hp.com/go/e-updates>

After registering, you will receive email notification of product enhancements, new driver versions, firmware updates, and other product resources.

## HP Websites

For additional information, see the following HP websites:

- <http://www.hp.com>
- <http://www.hp.com/go/storage>
- <http://www.hp.com/support/manuals>
- <http://www.hp.com/storage/spock>

## Documentation Feedback

HP welcomes your feedback.

To make comments and suggestions about product documentation, send a message to [storagedocsFeedback@hp.com](mailto:storagedocsFeedback@hp.com). All submissions become the property of HP.

# A Connecting External Storage Systems

This appendix provides configuration information for connecting various external storage systems to the HP XP24000/XP20000 storage systems.

## AMS/WMS Storage System

### System Parameters

Table 34 (page 134) explains whether to specify system parameters when making settings on ports on the AMS and WMS storage systems. You can either specify or omit any other parameters.

When connecting an AMS or WMS storage system, use Remote Web Console Modular or Remote Web Console Modular 2 to set the data transfer speed of the external port to a fixed value other than **Auto**. Also, set the data transfer speed of the target port of the AMS or WMS storage system to a fixed value according to the data transfer speed of the external port.

**Table 34 System Parameters (AMS/WMS)**

Window Names	Parameters	Parameter Settings
Boot Options	Start Attribute	
	Single Mode	Specify this parameter when the TagmaStore AMS storage system or TagmaStore WMS storage system is in the one controller configuration.
	Dual Active Mode	Specify this parameter when the TagmaStore AMS storage system or TagmaStore WMS storage system is in the two controller configuration.
	Delay Planned Shutdown	You can either specify or omit specifying this parameter.
	Drive blocking mode	You can either specify or omit specifying this parameter.
	Vendor ID	Keep the default parameter and do not change.
	Product ID	Keep the default parameter and do not change.
	ROM Microcode Version	You can either specify or omit specifying this parameter.
	RAM Microcode Version	You can either specify or omit specifying this parameter.
System Parameter	Option	You can either specify or omit specifying this parameter.
	Operation if the processor failure occurs	Specify this parameter to Reset of occurred.
	WEB Title	You can either specify or omit specifying this parameter.
	Write and verify mode	Set this parameter to ON for AMS 1000, AMS 500, AMS 200, and WMS 100. Set this parameter to OFF for AMS 2500, AMS 2300 and AMS 2100.
Port Options	Port Option	You can either specify or omit specifying this parameter.

**Table 34 System Parameters (AMS/WMS) (continued)**

Window Names	Parameters	Parameter Settings
Host Connection Mode	Host Connection Mode 1	Set this parameter to Standard Mode.
	Host Connection Mode 2	Do not specify any parameters. <b>NOTE:</b> As for AMS 1000, AMS 500, AMS 200, and WMS 100, do not specify HISUP OFF mode, either.

## Relationship between the Serial Number and the AMS/WMS Model

When the external storage system is the AMS or WMS storage system, you can identify the storage system model from the serial number displayed in the **Serial Number** column in the Volume Operation window.

Table 35 (page 135) describes the relationship between the serial number displayed in the **Serial Number** column and the storage system model.

**Table 35 Relationship between the Serial Number and the AMS/WMS Model**

Storage System	Displayed Serial Number	Model
AMS	87XXXXXX	AMS 2500
	85XXXXXX	AMS 2300
	83XXXXXX	AMS 2100
	77XXXXXX	AMS 1000
	75XXXXXX	AMS 500
	73XXXXXX	AMS 200
WMS	71XXXXXX	WMS 100

**NOTE:** In serial numbers, X is an arbitrary number or character.

## Relationship between the WWN of the Port and Controller (AMS/WMS)

When the external storage system is the AMS or WMS storage system, you can identify the controller (controller 0 or controller 1) from the WWN of the port.

Table 36 (page 135) describes the relationship between WWN of port and controller.

**Table 36 Relationship between the WWN of the Port and Controller (AMS/WMS)**

Model	Controller	WWN of the Port
AMS 200 WMS 100	Controller 0	XXXXXXXXXXXXXXXX0
	Controller 1	XXXXXXXXXXXXXXXX1
AMS 2100 AMS 500	Controller 0	XXXXXXXXXXXXXXXX0 XXXXXXXXXXXXXXXX1
	Controller 1	XXXXXXXXXXXXXXXX2 XXXXXXXXXXXXXXXX3

**Table 36 Relationship between the WWN of the Port and Controller (AMS/WMS) (continued)**

Model	Controller	WWN of the Port
AMS 2300 AMS 1000	Controller 0	XXXXXXXXXXXXXXXXX0
		XXXXXXXXXXXXXXXXX1
		XXXXXXXXXXXXXXXXX2
		XXXXXXXXXXXXXXXXX3
	Controller 1	XXXXXXXXXXXXXXXXX4
		XXXXXXXXXXXXXXXXX5
		XXXXXXXXXXXXXXXXX6
		XXXXXXXXXXXXXXXXX7
AMS 2500	Controller 0	XXXXXXXXXXXXXXXXX0
		XXXXXXXXXXXXXXXXX1
		XXXXXXXXXXXXXXXXX2
		XXXXXXXXXXXXXXXXX3
		XXXXXXXXXXXXXXXXX4
		XXXXXXXXXXXXXXXXX5
		XXXXXXXXXXXXXXXXX6
		XXXXXXXXXXXXXXXXX7
	Controller 1	XXXXXXXXXXXXXXXXX8
		XXXXXXXXXXXXXXXXX9
		XXXXXXXXXXXXXXXXXA
		XXXXXXXXXXXXXXXXXB
		XXXXXXXXXXXXXXXXXC
		XXXXXXXXXXXXXXXXXD
		XXXXXXXXXXXXXXXXXE
		XXXXXXXXXXXXXXXXXF

**NOTE:** In WWNs, X is an arbitrary number or character. The ports in the same apparatus have the identical value

## Path Status and Examples of the Recovery Procedure (AMS/WMS)

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 37 \(page 137\)](#) to recover the path status. For other errors not described in this section, see “[Troubleshooting for XP External Storage](#)” (page 126). If you cannot restore the path, call HP technical support.



**Table 37 Path Status and Examples of the Recovery Procedure (AMS/WMS)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"><li>• The fiber cable is not physically connected in the proper way.</li><li>• The setting of the topology does not match between the external port and the target port.</li><li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li></ul> <p>Verify the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>If host group security is enabled, disable host group security using LUN Manager.</p>

## P9500 Disk Array

When connecting a VSP storage system as the external storage system, you need to set the port to the host group for the Windows hosts (host mode 0C: Windows, host mode 2C: Windows Extension).

Also, the port attribute must be the target port or the RCU target port.

## Path status and examples of recovery procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see the following table to recover the path status. If you cannot restore the path, contact HP.

**Table 38 Path status and examples of recovery procedure (P9500 Disk Array)**

Path Status	Examples of Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use Universal Volume Manager to perform the Delete Volume operation and perform the Add Volume operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of ShadowImage, TrueCopy, Universal Replicator or some other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fibre cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul> <p>Make sure that the fibre cable is connected properly, and then set the fibre channel port properly using LUN Manager.</p> <p>The LUN security may have been enabled by LUN Manager. Check if the LUN security is enabled or not. If the LUN security is enabled, disable the LUN security.</p>

## Notes on Using the Power Savings Option (AMS/WMS)

When the AMS 2500, AMS 2300 or AMS 2100 storage system is connected as an external storage system and the Power Savings option is enabled on the external storage system, do not access external volumes from a host if the external volumes are spinning down. If an external volume is accessed from a host when the external volume is spinning down, the status of the external volume changes to Blockade.

If the status of the external volume changes to Blockade, the external volume will be automatically restored in several hours. You can also manually restore the external volumes by using the **Check Paths & Restore Volume** command.

## Thunder 9500V Storage System

### System Parameters

Table 39 (page 139) explains whether to specify system parameters when making settings on ports on the Thunder 9500V storage system.

**Table 39 System Parameters (Thunder 9500V)**

Window Names	Parameters	Parameter Settings
System Startup Settings	Start Attribute	
	Single Mode	Specify this parameter when the Thunder 9500V storage system is in the one controller configuration.
	Dual Active Mode	Specify this parameter when the Thunder 9500V storage system is in the two controller configuration. <b>NOTE:</b> Be sure to specify that Data Share Mode will be used.
	Hot Stand-By Mode	Do not specify this parameter.
Common 1	Delay Planned Shutdown	You can either specify this parameter or omit specifying this parameter.
OPTION 1	SCSI Fibre Channel Common Options	You can either specify this parameter or omit specifying this parameter.
OPTION 2	SCSI Fibre Channel Common Options	You can either specify this parameter or omit specifying this parameter.
Data Striping	Operation if the processor failure occurs	Specify this parameter to Reset of occurred.
Inquiry Setting	Command Queuing Mode	Specify this parameter ON.
	Vendor ID	Keep the default parameter and do not change.
	Product ID	Keep the default parameter and do not change.
	ROM Microcode Version	You can either specify this parameter or omit specifying this parameter.
	RAM Microcode Version	You can either specify this parameter or omit specifying this parameter.
	WEB Title	You can either specify this parameter or omit specifying this parameter.
Port Type	Reset/LIP Mode	
	Reset/LIP Mode (Signal)	You can either specify this parameter or omit specifying this parameter.
	Reset/LIP Mode (Process)	You can either specify this parameter or omit specifying this parameter.
	LIP Reset Mode	You can either specify this parameter or omit specifying this parameter.
Controller Option	RS232C Error Information Outflow Mode	You can either specify this parameter or omit specifying this parameter.
	Write and verify mode	Set this parameter to ON.
Host Connection Mode	Host Connection Mode 1	Set this parameter to Standard Mode.
	Host Connection Mode 2	Specify HISUP Mode. <b>NOTE:</b> Do not specify any other parameters.

When you use the Thunder 9500V storage system as an external storage system, the following versions are recommended. If you use a 9500V storage system whose version is earlier than the following versions, the information about the SATA drive may not be displayed correctly.

- For Thunder 9530V, Thunder 9520V, Thunder 9570V: version 0658 or later.
- For Thunder 9580V, Thunder 9585V: version 1658 or later.

## Relationship between the Serial Number and Thunder 9500V Model

When the external storage system is Thunder 9500V storage system, you can identify the storage system model from the serial number displayed in the **Serial Number** column in the Volume Operation window.

Table 40 (page 140) describes the relationship between the serial number displayed in the **Serial Number** column and the storage system model.

**Table 40 Relationship between the Serial Number and Thunder 9500V Model**

Displayed Serial Number	Model
D600XXXX	9570V, 9520V
D60JXXXX	9530V
D60HXXXX	9580V, 9585V
<b>NOTE:</b> In serial numbers, X is an arbitrary number or character.	

## Relationship between the WWN of the Port and Controller

When the external storage system is Thunder 9500V storage system, you can identify the controller (controller 0 or controller 1) from the WWN of the port.

Table 41 (page 140) describes the relationship between WWN of port and controller.

**Table 41 Relationship between the WWN of the Port and Controller (Thunder 9500V)**

Model	Controller	WWN of the Port
9570V 9530V 9520V	Controller 0	XXXXXXXXXXXXXXXX0
		XXXXXXXXXXXXXXXX1
	Controller 1	XXXXXXXXXXXXXXXX2
		XXXXXXXXXXXXXXXX3
9580V 9585V	Controller 0	XXXXXXXXXXXXXXXX0
		XXXXXXXXXXXXXXXX1
		XXXXXXXXXXXXXXXX2
		XXXXXXXXXXXXXXXX3
	Controller 1	XXXXXXXXXXXXXXXX4
		XXXXXXXXXXXXXXXX5
		XXXXXXXXXXXXXXXX6
		XXXXXXXXXXXXXXXX7
<b>NOTE:</b> In WWNs, X is an arbitrary number or character. The ports in the same apparatus have the identical value.		

## Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see Table 42 (page 141)

to recover the path status. For other errors not described in this section, see [“Troubleshooting for XP External Storage” \(page 126\)](#). If you cannot restore the path, call HP technical support.

**Table 42 Path Status and Examples of the Recovery Procedure (Thunder 9500V)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fiber cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The host group security may have been enabled by LUN Manager. Check if the host group security is enabled or not. If the host group security is enabled, disable the host group security.</p>

## USP V/VM Storage System

When connecting a USP V/VM storage system as the external storage system, you need to set the port to the host group for the Windows hosts (host mode 0C: Windows, host mode 2C: Windows Extension).

Also, the port attribute must be the target port or the RCU target port.

### Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 43 \(page 142\)](#) to recover the path status. For other errors not described in this section, see [“Troubleshooting for XP External Storage” \(page 126\)](#). If you cannot restore the path, call HP technical support.

**Table 43 Path Status and Examples of the Recovery Procedure (USP V/VM)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete Volume operation and perform the Add Volume operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, XP Continuous Access Journal, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fiber cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The LUN security may have been enabled by LUN Manager. Check if the LUN security is enabled or not. If the LUN security is enabled, disable the LUN security.</p>

## TagmaStore USP/NSC Storage System

When connecting a TagmaStore USP or NSC storage system as the external storage system, you need to set the port to the host group for the Windows hosts (host mode 0C: Windows, host mode 2C: Windows Extension).

Also, the port attribute must be the target port or the RCU target port.

## Setting the Host Mode Option for a Volume Larger Than 2 TB (USP/NSC)

If a volume that has the capacity of more than 2 TB is mapped as an external volume, host mode option No. 24 must be enabled. If No. 24 is disabled, a volume that has the capacity of more than 2 TB cannot be mapped as an external volume. For instructions on the host mode option, see the *HP StorageWorks XP24000/XP20000 LUN Manager User Guide*.

## Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 44 \(page 143\)](#) to recover the path status. For other errors not described in this section, see “[Troubleshooting for XP External Storage](#)” (page 126). If you cannot restore the path, call HP technical support.

**Table 44 Path Status and Examples of the Recovery Procedure (USP V/VM)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, XP Continuous Access Journal, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"><li>• The fiber cable is not physically connected in the proper way.</li><li>• The setting of the topology does not match between the external port and the target port.</li><li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li></ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The LUN security may have been enabled by LUN Manager. Check if the LUN security is enabled or not. If the LUN security is enabled, disable the LUN security.</p>

## Lightning 9900V Storage System

When connecting a Lightning 9900V storage system as the external storage system, you need to set the port to the host group for the Windows hosts (host mode 0C: Windows, host mode 2C: Windows Extension).

Also, the port attribute must be the target port or the RCU target port.

## Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 45 \(page 144\)](#) to recover the path status. For other errors not described in this section, see [“Troubleshooting for XP External Storage” \(page 126\)](#). If you cannot restore the path, call HP technical support (see [“Calling HP Technical Support” \(page 131\)](#)).

**Table 45 Path Status and Examples of the Recovery Procedure (Lightning 9900V)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by Data Retention Utility. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"><li>• The fiber cable is not physically connected in the proper way.</li><li>• The setting of the topology does not match between the external port and the target port.</li><li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li></ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The LUN security may have been set by LUN Manager. Check if the LUN security is set or not. If the LUN security is set, remove the setting of the LUN security.</p>

## Lightning 9900 Storage System

When connecting a Lightning 9900 storage system as the external storage system, you need to set the host mode of the port to PC Server (OC).

Also, the port attribute must be the target port or the RCU target port.

## Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 46 \(page 145\)](#) to recover the path status. For other errors not described in this section, see [“Troubleshooting for XP External Storage” \(page 126\)](#). If you cannot restore the path, call HP technical support (see [“Calling HP Technical Support” \(page 131\)](#)).



**Table 46 Path Status and Examples of the Recovery Procedure (Lightning 9900)**

Path Status	Examples of the Recovery Procedure
External device setting changed	Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.
Illegal request or Response error	The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fiber cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The LUN security may have been set by LUN Manager. Check if the LUN security is set or not. If the LUN security is set, remove the setting of the LUN security.</p>

## SVS200 Storage System

When connecting an SVS200 storage system as the external storage system, you need to set the port to the host group for the Windows hosts (host mode 0C: Windows, host mode 2C: Windows Extension).

Also, the port attribute must be the target port or the RCU target port.

If you are using the microcode that does not support the SVS200 storage system, the SVS200 storage system is recognized as the XP12000 storage system. If you need the connected external storage system to be recognized as the SVS200 storage system, use the microcode of the version that supports the SVS200 storage system (which is the microcode version 50-07-0X-XX/XX or higher). If you have used an earlier microcode version that does not support the SVS200 storage system to map the volumes of the SVS storage system, delete the mapping setting and then change the microcode version to the one that supports the SVS200 storage system.

## Path Status and Examples of the Recovery Procedure

This section describes errors that require recovery operation on the external storage system side when the path status is not normal. When the path status is not normal, see [Table 47 \(page 146\)](#) to recover the path status. For other errors not described in this section, see [“Troubleshooting for XP External Storage” \(page 126\)](#). If you cannot restore the path, call HP technical support (see [“Calling HP Technical Support” \(page 131\)](#)).

**Table 47 Path Status and Examples of the Recovery Procedure (SVS200)**

Path Status	Examples of the Recovery Procedure
External device setting changed	<p>Settings of the LU paths may have been changed by LUN Manager. Check the settings of the LU paths. If the settings of the LU paths have been changed, change the settings back to the ones when the volume is mapped. Or use XP External Storage to perform the Delete LU operation and perform the Add LU operation again.</p> <p>The access attribute of the volume may have been changed by HP StorageWorks XP LUN Security Extension. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Illegal request or Response error	<p>The volume may have been set as a pair volume for data copy. Check if the volume is set as a pair volume of XP Business Copy, XP Continuous Access, XP Continuous Access Journal, or other copy program. If the volume is set as a pair volume, the volume may be protected because of the pair status. When the volume is protected, change the pair status or delete the pair.</p> <p>The access attribute of the volume may have been changed by XP LUN Security Extension. Check the access attribute of the volume. If the volume is protected by the access attribute, release the protection.</p>
Cannot detect port	<p>There is a problem with the connection to the external storage system. The possible causes are:</p> <ul style="list-style-type: none"> <li>• The fiber cable is not physically connected in the proper way.</li> <li>• The setting of the topology does not match between the external port and the target port.</li> <li>• If the external storage system is connected through switches, the settings for the switches may not be appropriate.</li> </ul> <p>Make sure that the fiber cable is connected properly, and then set the Fibre Channel port properly using LUN Manager.</p> <p>The LUN security may have been enabled by LUN Manager. Check if the LUN security is enabled or not. If the LUN security is enabled, disable the LUN security.</p>

## HP StorageWorks EVA Storage System

### System Parameters

When connecting an EVA storage system as an external storage system, set the system parameters of the EVA storage system according to [Table 48 \(page 146\)](#). For the system parameters that are not in [Table 48 \(page 146\)](#), see the documentation for the EVA storage system and set the parameters appropriately for the connecting configuration.

**Table 48 System Parameters for Connecting an EVA Storage System**

Parameter		Parameter Setting
Add a Host	Host OS	Windows


### Identifying Logical Volumes (Using Characteristic2)

When the connected external storage system is an EVA storage system, LUNs appear as **Characteristic1** in the XP External Storage windows.

If you search for the logical volumes specifying the WWN indicating EVA Port A in the configuration, as shown in [Figure 44 \(page 147\)](#), the logical volumes named LUN 1 and LUN 2 are found for each of HostGroup-1 and HostGroup-2. In this case, two different logical volumes that have the same name, such as LUN 1 and LUN 2, are found as the logical volumes that can be connected from EVA Port A, but you cannot tell which LUN 1 and LUN 2 belong to HostGroup-1 or HostGroup-2 only by **Characteristic1**.

In the configuration in [Figure 44 \(page 147\)](#), you can identify the logical volumes referring to **Characteristic2** in the XP External Storage windows. The first 32 characters of **Characteristic2** indicate the World Wide LUN Name that can be found on the EVA storage system side. You can identify the logical volume of the EVA storage system by this World Wide LUN Name.

**Figure 44 Configuration Example for which Logical Volumes Cannot be Identified only by Characteristic**



## Behavior of the Alternate Path

When an EVA storage system is connected, the behavior of the alternate path differs depending on the microcode version of the EVA storage system.

If the subsystem system type is EVA3000/5000, the behavior of the alternate path differs between the EVA storage system of the microcode version 4.000 or later and the EVA storage systems of the earlier microcode versions.

To replace the microcode of the EVA storage system, check whether the behavior of the alternate path changes as a result of changing the microcode version. If the behavior of the alternate path changes, perform the Delete Volume operation of XP External Storage to release the setting of mapping the EVA storage system volume before you actually replace the microcode.

See the EVA storage system manuals for how the behavior of the alternate path changes.

## Sun StorEdge 6120/6320

When connecting a Sun StorEdge 6120/6320 as an external storage system, set the system parameters of the Sun StorEdge 6120/6320 according to [Table 49 \(page 147\)](#). For the system parameters that are not in [Table 49 \(page 147\)](#), see the documentation for the Sun StorEdge 6120/6320 and set the parameters appropriately for the connecting configuration.

**Table 49 System Parameter (Connecting Sun StorEdge 6120/6320)**

Parameter	Parameter Setting
port host	SUN

## Sun StorageTek FlexLine 380

When you connect a Sun StorageTek FlexLine 380 as an external storage system, set the system parameters of the Sun StorageTek FlexLine 380 according to [Table 50 \(page 148\)](#). For the system parameters that are not in [Table 50 \(page 148\)](#), see the documentation for the Sun StorageTek FlexLine 380 and set the parameters appropriately for the connecting configuration.

**Table 50 System Parameter (Sun StorageTek FlexLine 380)**

Parameter	Parameter Setting
host type	Windows Non-clustered (DMP Support)

## Sun StorageTek 2540

When connecting a Sun StorageTek 2540 as an external storage system, set the system parameters of the Sun StorageTek 2540 according to [Table 51 \(page 148\)](#). For the system parameters that are not in [Table 51 \(page 148\)](#), see the documentation for the Sun StorageTek 2540 and set the parameters appropriately for the connecting configuration.

**Table 51 System Parameter (Sun StorageTek 2540)**

Parameter	Parameter Setting
host type	Windows 2K non Clustered DMP

## Sun StorageTek V2X2

When connecting a Sun StorageTek V2X2 as an external storage system, make sure that only one cross-subsystem path is configured when you map external volumes. Do not add any alternate paths after you finish mapping external volumes.

## EMC CLARiiON CX Series

When you connect an EMC CLARiiON CX series as an external storage system, set the system parameters of the EMC CLARiiON CX series according to the settings in [Table 52 \(page 148\)](#). For system parameters that are not in [Table 52 \(page 148\)](#), see the EMC CLARiiON CX series documentation and set the parameters appropriately to connect your configuration.

**Table 52 System Parameters (EMC CLARiiON CX series)**

Parameter	Parameter Setting
Initiator Type	CLARiiON Open
Failover Mode	2

## Notes on Connecting an EMC CLARiiON CX Series

Volumes created with Individual Disk Units (JBOD disks) of EMC CLARiiON CX series are not supported.

The following restrictions are for the use of the RAID-6 volume for the EMC CLARiiON CX series. Moreover, when you downgrade a version of a storage system that does not support the RAID-6 volume from a version of a storage system that supports the RAID-6 volume, the configuration of the EMC CLARiiON CX series should be changed.

**Table 53 Restrictions for Connecting an EMC CLARiiON CX Series**

Version	Restrictions
60-04-04-00/00 and higher, and lower than 60-06-00-00/00	<p>The RAID-6 volume for the EMC CLARiiON CX series can be used by installing the profile for supporting the RAID-6 volume for the EMC CLARiiON CX series.</p> <p>However, the RAID-6 volume and the other RAID volume cannot be defined in the same port. Either the RAID-6 mapping volume or the other RAID type mapping volume might be blockaded when those volumes are added in the same port.</p> <p>The RAID-6 volume and the other RAID volume that are defined in separate ports are displayed as different devices.</p>
60-06-00-00/00 and higher	<p>The RAID-6 volume and the other RAID volume can be defined and mapped in the same port.</p> <p>The volume that is mapped by a storage system lower than 60-06-00-00/00 can be continuously used. However, the volumes that have been displayed as different devices are displayed as one device.</p> <p><b>NOTE:</b> The RAID-6 mapping volume is blockaded without exception when you downgrade a storage system to a version lower than 60-06-00-00/00. Therefore, delete the RAID-6 volume when you downgrade a storage system. After the downgrade, the restrictions described in the column for 60-04-04-00/00 and higher, and lower than 60-06-00-00/00 in this table are applied. Change the definition to the other port when the RAID-6 volume and the other RAID volume are defined in the same port.</p>

## System Option mode

When you connect an EMC CLARiiON CX series as an external storage system, set system option mode 725 of the local storage system. If system option mode 725 is not set, the external storage system might be blocked when performing maintenance, including rebooting the controller of the external storage system by the firmware update and so on. For instructions about setting system option mode 725, contact HP

## EMC Symmetrix Series

If you have or plan to have EMC logical devices with addresses over FFF provisioned to a storage system, to display these addresses correctly in the **Characteristic1** field in the External Volumes list on the Volume Operation window, you must do the following:

### Procedure 1

1. Check the EMC Symmetrix SCSI flags listed on the EMC Command Center Display for the EMC adapters that are connected to or will be connected to the storage system external ports. Ensure that the SC3 flag is enabled and the SPC2 flag is disabled.
2. Set SOM 745 to ON. An HP-authorized support person is required to do this service action from the SVP.
3. In the Path Operation tree on the Path Operation window (see [“Path Operation Window” \(page 55\)](#)), perform the CheckPaths operation for paths that are already mapped. An alternate method is to wait at least 1 hour, and then the device health check is automatically performed.
4. After processing, click **Refresh** to update the **Characteristic1** field. The volumes with EMC logical device addresses over FFF will display correctly.

If CheckPaths is performed while a ShadowImage for Mainframe pair and an HP StorageWorks XP for FlashCopy Mirroring Software pair are defined in the specified volume, the CheckPaths operation is rejected with a 605 2518 message. If a ShadowImage for Mainframe pair and a FlashCopy Mirroring pair are defined in the specified volume, do not perform CheckPaths, but wait for the device health check to automatically update the **Characteristic1** field.

When you connect an EMC Symmetrix series as an external storage system, set the system parameters of the EMC Symmetrix series according to the settings in [Table 54 \(page 150\)](#). For the system parameters that are not in [Table 54 \(page 150\)](#), refer to the documentation of the EMC Symmetrix series and set the parameters appropriately to connect your configuration.

**Table 54 System Parameters for Connecting EMC Symmetrix Series**

Parameter	Parameter Setting
SC3 flag	Enable
SPC2 flag	Disable

## IBM DS3000/DS4000/DS5000 Series

When connecting an IBM DS3000/DS4000/DS5000 series as an external storage system, set the system parameters of the IBM DS3000/DS4000/DS5000 series according to [Table 55 \(page 150\)](#). For the system parameters that are not in [Table 55 \(page 150\)](#), see the documentation for the IBM DS4000/DS5000 series and set the parameters appropriately for the connecting configuration.

**Table 55 System Parameter (IBM DS3000/DS4000/DS5000 Series)**

Parameter	Parameter Setting
host type	When alternate paths are connected to different clusters on the DS3000/DS4000/DS5000 series side: Linux

## System Parameter for Connecting IBM SVC Series

When connecting an IBM SVC series as an external storage system, set the system parameters of the IBM SVC series according to the following table. For the system parameters that are not in the following table, refer to the documentation of the IBM SVC series and set the parameters appropriately for the connecting configuration.

**Table 56 System Parameter (IBM SVC Series)**

Parameter	Parameter Setting
host type	Generic

## Notes on Connecting IBM XIV Series

When connecting an IBM XIV series as an external storage system, note that the type of display of the system and device serial number differs between IBM XIV series and USP V/VM.

**Table 57 Serial number display (IBM XIV Series)**

Display in USP V/VM		Display in IBM XIV	
Item	Type	Item	Type
The first 2 digits of Serial Number	Decimal value	The first 2 digits of (System) Serial number	Decimal value
The last 5 digits of Serial Number	Hexadecimal value	The last 5 digits of (System) Serial number	Decimal value
Characteristic 1	Hexadecimal value	Device serial number	Decimal value

## Fujitsu FibreCAT CX Series

### System Option mode

When you connect a Fujitsu FibreCAT CX series as an external storage system, set system option mode 725 of the local storage system. If system option mode 725 is not set, the external storage system might be blocked when performing maintenance, including rebooting the controller of the external storage system by the firmware update and so on. For instructions about setting system option mode 725, contact

### System Parameter for Connecting Fujitsu FibreCAT CX Series

When you connect a Fujitsu FibreCAT CX series as an external storage system, set the system parameters of the Fujitsu FibreCAT CX series according to the following table. For the system parameters that are not in the following table, refer to the documentation of the Fujitsu FibreCAT CX series and set the parameters appropriately for the connecting configuration.

**Table 58 System Parameters for Connecting Fujitsu FibreCAT CX Series**

Parameter	Parameter Setting
Initiator Type	CLARiiON Open
Failover Mode	2

### Notes on Connecting Fujitsu FibreCAT CX Series

Volumes created with the RAID0 level or Individual Disk Units (JBOD disks) of Fujitsu FibreCAT CX series are not supported.

### SGI IS4600 Series

When connecting an SGI IS4600 series as an external storage system, set the system parameters of the SGI IS4600 series according to the following table. For system parameters that are not in the following table, refer to the documentation of the SGI IS4600 series and set the parameters appropriately for the connecting configuration.

**Table 59 SGI IS4600 Series**

Parameter	Parameter Setting
host type	When alternate paths are connected to different clusters on the SGI IS4600 series side: Linux

### Non-HP Storage Systems

Generally, when connecting a non-HP storage system as the external storage system, the non-HP storage system port must be configured as a target attached to a Windows host. The third-party vendor should be contacted as necessary for the technical details to accomplish this.

## B Required Volume Capacity for Each Emulation Type

When you map an external volume as an internal volume, you need to specify the emulation type for the mapped volume. The maximum capacity of an external volume depends on the specified emulation type.

### Determining Required External Volume Capacity

The capacity required for the LDEV to be mapped is the total capacity of the data area for storing the actual user data and the control information area for storing the control information. The capacity of the data area (called base data area capacity) and the capacity of the control information area (called control information area capacity) depend on the emulation type. The minimum capacity of data area for Custom-sized Volume (CV) (called minimum data area capacity) also depends on the emulation type. For detailed information about the LDEV capacity for each emulation type, see [Table 61 \(page 154\)](#).

- You can calculate the minimum capacity required for an LDEV (minimum LDEV capacity) for each emulation type using the following equation:

Minimum LDEV capacity = Minimum data area capacity + control information area capacity

If the capacity of the external volume is less than this minimum LDEV capacity, the emulation type cannot be specified.

- You can calculate the base LDEV capacity for each emulation type using the following equation:

Base LDEV capacity = Base data area capacity + Control information area capacity

When the capacity of the external volume is less than the base LDEV capacity of the emulation type, one Custom-sized Volume (CV) is created in the external volume as you map the volume. When the capacity of the external volume is more than the base LDEV capacity of the emulation type, the external volume is divided into multiple LDEVs, each of which has the base LDEV capacity. Because the OPEN-V emulation type supports 4 TB of the volume at the maximum, one LDEV is always created when the external volume is mapped.

If you use the VLL function, you can divide the mapped external volume into 2,048 CVs at the maximum as your demand. However, the LDEVs as they are mapped are used for the OPEN-L emulation type, because the VLL function is not applicable to the OPEN-L emulation type.

When the capacity of the mapped external volume is more than the maximum capacity of the specified emulation type, a certain part of external volume cannot be used. [Table 60 \(page 152\)](#) shows the maximum usable capacity of the external volume of each emulation type. For detailed information about the volume capacity for each emulation type, see [Table 62 \(page 155\)](#).

**Table 60 Maximum Usable Capacity of an External Volume**


Emulation Type	Maximum Usable Capacity of External Volume
OPEN-V	4 TB
OPEN emulation type other than OPEN-V	767.99 GB (1,610,612,640 blocks)
3380 mainframe emulation type	767.99 GB (1,610,612,640 blocks)
3390 mainframe emulation type	927.99 GB (1,946,156,940 blocks)

"[Idea of LDEV Capacity](#)" ([page 153](#)) shows the relationship of the minimum LDEV capacity, base LDEV capacity, minimum data area capacity, base data area capacity, and control information area capacity.


[Figure 46 \(page 153\)](#) shows how to figure out the volume capacity using OPEN-3.



**Figure 45 Idea of LDEV Capacity**



**Figure 46 Example of How to Figure Out the Volume Capacity (For OPEN-3)**



## Capacity List for Each Emulation Type

This section explains the LDEV capacity and volume capacity for each emulation type in the units of blocks and cylinders.

The numbers of cylinders are calculated from the following formulas.

For 3380 mainframe volumes: 1 cylinder = 1,440 blocks

For 3390 mainframe volumes: 1 cylinder = 1,740 blocks

The minimum data area capacity, the base data area capacity, and control information area capacity for each emulation type are listed in the [Table 61 \(page 154\)](#). For the OPEN-L emulation type, CVs cannot be created. Therefore, the base data area capacity and minimum data area capacity for OPEN-L emulation type are the same. For the OPEN-V emulation type, the base data area capacity is not listed because there is no concept of the base data area capacity.

The base LDEV capacity, the minimum LDEV capacity, the maximum external volume capacity, and the number of LDEVs that can be defined for the external volume with maximum capacity are listed in the [Table 62 \(page 155\)](#). For the OPEN-L emulation type, the base LDEV capacity and the minimum LDEV capacity are the same, because CVs cannot be created. For the OPEN-V emulation type, the base LDEV capacity is not listed because there is no concept of the base LDEV capacity.

For an emulation type of an open system other than OPEN-V, the LDEV capacity that can be made when an external volume is mapped is divisible by 1,440 blocks. For an emulation type of a

mainframe system, the LDEV capacity that can be made when an external volume is mapped is an integer when converted into a cylinder.

**Table 61 LDEV Capacity Information for Each Emulation Type**

Emulation Type	Minimum Data Area Capacity		Base Data Area Capacity		Control Information Area Capacity	
	Blocks	Cylinders	Blocks	Cylinders	Blocks	Cylinders
3380-3	72,000	50	4,808,160	3,339	10,080	7
3380-3A	72,000	50	4,808,160	3,339	10,080	7
3380-3B	72,000	50	4,808,160	3,339	10,080	7
3380-3C	72,000	50	4,808,160	3,339	10,080	7
3380-K	72,000	50	3,823,200	2,655	10,080	7
3380-KA	72,000	50	3,823,200	2,655	10,080	7
3380-KB	72,000	50	3,823,200	2,655	10,080	7
3380-KC	72,000	50	3,823,200	2,655	10,080	7
3390-3	87,000	50	5,809,860	3,339	10,440	6
3390-3A	87,000	50	5,809,860	3,339	10,440	6
3390-3B	87,000	50	5,809,860	3,339	10,440	6
3390-3C	87,000	50	5,809,860	3,339	10,440	6
3390-3R	87,000	50	5,809,860	3,339	10,440	6
3390-9	87,000	50	17,429,580	10,017	43,500	25
3390-9A	87,000	50	17,429,580	10,017	43,500	25
3390-9B	87,000	50	17,429,580	10,017	43,500	25
3390-9C	87,000	50	17,429,580	10,017	43,500	25
3390-L	87,000	50	57,002,400	32,760	40,020	23
3390-LA	87,000	50	57,002,400	32,760	40,020	23
3390-LB	87,000	50	57,002,400	32,760	40,020	23
3390-LC	87,000	50	57,002,400	32,760	40,020	23
3390-M	87,000	50	114,004,800	65,520	92,220	53
3390-MA	87,000	50	114,004,800	65,520	92,220	53
3390-MB	87,000	50	114,004,800	65,520	92,220	53
3390-MC	87,000	50	114,004,800	65,520	92,220	53
OPEN-3	72,000	-	4,806,720	-	11,520	-
OPEN-8	72,000	-	14,351,040	-	38,880	-
OPEN-9	72,000	-	14,423,040	-	38,880	-
OPEN-E	72,000	-	28,452,960	-	27,360	-
OPEN-L	71,192,160	-	71,192,160	-	10,080	-
OPEN-V	96,000	-	-	-	0	-

**Table 62 Volume Capacity Information for Each Emulation Type**

Emulation Type	Base LDEV Capacity		Minimum LDEV Capacity		Maximum Capacity of External Volume		Maximum Number of LDEVs <sup>1</sup>
	Blocks	Cylinders	Blocks	Cylinders	Blocks	Cylinders	
3380-3	4,818,240	3,346	82,080	57	1,610,612,640	1,118,481	334
3380-3A	4,818,240	3,346	82,080	57	1,610,612,640	1,118,481	334
3380-3B	4,818,240	3,346	82,080	57	1,610,612,640	1,118,481	334
3380-3C	4,818,240	3,346	82,080	57	1,610,612,640	1,118,481	334
3380-K	3,833,280	2,662	82,080	57	1,610,612,640	1,118,481	420
3380-KA	3,833,280	2,662	82,080	57	1,610,612,640	1,118,481	420
3380-KB	3,833,280	2,662	82,080	57	1,610,612,640	1,118,481	420
3380-KC	3,833,280	2,662	82,080	57	1,610,612,640	1,118,481	420
3390-3	5,820,300	3,345	97,440	56	1,946,156,940	1,118,481	334
3390-3A	5,820,300	3,345	97,440	56	1,946,156,940	1,118,481	334
3390-3B	5,820,300	3,345	97,440	56	1,946,156,940	1,118,481	334
3390-3C	5,820,300	3,345	97,440	56	1,946,156,940	1,118,481	334
3390-3R	5,820,300	3,345	97,440	56	1,946,156,940	1,118,481	334
3390-9	17,473,080	10,042	130,500	75	1,946,156,940	1,118,481	111
3390-9A	17,473,080	10,042	130,500	75	1,946,156,940	1,118,481	111
3390-9B	17,473,080	10,042	130,500	75	1,946,156,940	1,118,481	111
3390-9C	17,473,080	10,042	130,500	75	1,946,156,940	1,118,481	111
3390-L	57,042,420	32,783	127,020	73	1,946,156,940	1,118,481	34
3390-LA	57,042,420	32,783	127,020	73	1,946,156,940	1,118,481	34
3390-LB	57,042,420	32,783	127,020	73	1,946,156,940	1,118,481	34
3390-LC	57,042,420	32,783	127,020	73	1,946,156,940	1,118,481	34
3390-M	114,097,020	65,573	179,220	103	1,946,156,940	1,118,481	17
3390-MA	114,097,020	65,573	179,220	103	1,946,156,940	1,118,481	17
3390-MB	114,097,020	65,573	179,220	103	1,946,156,940	1,118,481	17
3390-MC	114,097,020	65,573	179,220	103	1,946,156,940	1,118,481	17
OPEN-3	4,818,240	-	83,520	-	1,610,612,640	-	334
OPEN-8	14,389,920	-	110,880	-	1,610,612,640	-	111
OPEN-9	14,461,920	-	110,880	-	1,610,612,640	-	111
OPEN-E	28,480,320	-	99,360	-	1,610,612,640	-	56
OPEN-L	71,202,240	-	71,202,240	-	1,610,612,640	-	22
OPEN-V	-	-	96,000	-	8,589,934,592	-	1

1 This number refers to the number of LDEVs when an external volume with maximum capacity is mapped.

## C Adjusting the Volume Capacities for Pairs

When you create a pair, the capacity of an S-VOL must be the same as that of a P-VOL. To set a desired volume to a pair, you may need to adjust the capacity of the volume. This section describes the procedure for adjusting the volume capacity.

For A, B, and C in the following description, see [Figure 47 \(page 156\)](#).

To adjust the capacity of the storage system volume to create a pair (if you want to use an external volume as P-VOL when copying data from an external storage system):


1. Map the external volume (A) as an internal volume (B) of the local storage system. Make sure that the emulation type of the volume is OPEN-V.
2. Select the storage system volume (C) which has the same capacity as the mapped external volume (B), or which has the bigger capacity than the mapped external volume (B). The emulation type of the volume (C) has to be OPEN-V.
3. If you select the storage system volume (C) that has a bigger capacity than the mapped external volume (B), make the CV that has the same capacity as the mapped external volume (B) out of the storage system volume (C) using the VLL function. For the VLL function, see the *HP StorageWorks XP24000/XP20000 Virtual LVI/LUN (VLL) and Volume Shredder User Guide*.

### NOTE:

- When you make the CV that has the same capacity as the mapped external volume (B) using the VLL function, make the capacity of CV according to the **Blocks** capacity that is displayed in the **Capacity** column on the LDEV Information dialog box of XP External Storage (see [\(page 85\)](#)).
- To create an XP Continuous Access pair with an XP1024/XP128 Disk Array or Lightning 9900C series storage system volume, you may not be able to create a CV that has the same capacity as the mapped external volume (B) since the VLL function does not allow you to specify the capacity in Blocks. In this case, you cannot create an XP Continuous Access pair.

4. Create a pair.

**Figure 47 Copying Data from an External Storage System (Using an External Volume as the P-VOL)**




For A, B, and C in the following description, see [Figure 48 \(page 157\)](#).

To adjust the capacity of the external volume to create a pair (if you want to set an external volume as S-VOL when copying data to an external storage system):

1. Map the external volume (A) as an internal volume (B) of the local storage system. Set the emulation type as same as that of the copy source volume (C).
2. Check the capacity of the internal volume (B) where the external volume (A) is mapped. If the capacity of the mapped external volume (B) is not same as the copy source volume (C), use the VLL function to create a CV that has the same capacity as the copy source volume (C) out of the volume (B).
3. Create a pair.

**Figure 48 Copying Data to an External Storage System (Setting an External Volume as an S-VOL)**



---

## D The ExPath Tool

This appendix explains how to use the ExPath tool.

### Overview of the ExPath Tool

The ExPath tool enables you to perform the **Disconnect Volume** command and the **Check Path & Restore Volume** command on the command line. When you use the ExPath tool, you can perform these commands on multiple volumes at a time.

If you use the ExPath tool, you can automate a series of operations for backing up or updating data by using a function of the external storage system. For example, if you want to back up data, you can automate the backup operation by writing the following operations in a batch file. Note that you need to perform some operations before disconnecting the external volumes. For details on the required operations, see [\(page 91\)](#).

1. Perform the disconnect command to disconnect the external volumes.  
The mapped external volumes stop accepting host I/O, and all the data in the cache memory is written into the external volumes (all the data is destaged). The status of the external volumes changes to Disconnect. The local storage system cannot access the external volumes in the Disconnect status.
2. Back up the data in the external volumes by using a function of the external storage system.  
If the external storage system provides a backup command, write this command in the batch file. For details, see the documentation of the external storage system.
3. Perform the checkpath command to resume using the external volumes.  
The local storage system can access the external volumes.

To use the ExPath tool, authentication information (Remote Web Console user ID and password) is required. You can specify the authentication information by one of the following:

- (a) Write the authentication information in a command file.
- (b) Create an authentication file and specify this file as a parameter when executing the ExPath tool.

When you want to encrypt the authentication information or when the SVP has an IPv6 address, creation of an authentication file is required, as explained in (b). Note that users who do not have the permission for using XP External Storage can use the ExPath tool.

### Preparing for Using the ExPath Tool

The following components are required to use the ExPath tool:

- A Windows computer  
The ExPath tool runs on the following operating systems:
  - Windows XP (on the Pentium or equivalent processor (32 bit))
  - Windows Server 2003 (on the Pentium or equivalent processor (32 bit))
  - Windows Vista (on the Pentium or equivalent processor (32 bit))
- The Java Runtime Environment (JRE)  
To use the ExPath tool, you must install Java Runtime Environment on your Windows computer. The JRE version required for running the ExPath tool is the same as the JRE version required for running Remote Web Console. For detailed information about the JRE version required for

running Remote Web Console, see the *HP StorageWorks XP24000/XP20000 Remote Web Console User Guide*.

- The ExPath tool program

The ExPath tool is contained in CD-ROM Disc 2, which is named Host PP. Use the ExPath tool version that is synchronized with the storage system microcode version. If the storage system microcode is upgraded, upgrade the ExPath tool on your computer by using the disk that comes with the storage system microcode.

## Installing the ExPath Tool

To install the ExPath tool on a Windows computer:

1. Log into your computer as Administrator.
2. Insert the ExPath tool installation CD-ROM into the drive.
3. Locate the `ExPthTool` directory in the CD-ROM and copy the directory to the C drive.
4. Eject the installation CD-ROM from the drive.

The `ExPthTool` directory contains sample files. Before using sample files, you can modify the files to suit your needs.

- `checkPath.txt`: A sample file for the `checkpath` command
- `checkStatus.txt`: A sample file for the `checkstatus` command
- `disconnect.txt`: A sample file for the `disconnect` command
- `myPolicy.txt`: A file that contains the script to be added to the Java policy file
- `runWin.bat`: A batch file to run the ExPath tool

## Uninstalling the ExPath Tool

To uninstall the ExPath tool, delete the installed `ExPthTool` directory and all the subdirectories and files in the directory.

## Upgrading the ExPath Tool

If the storage system microcode is upgraded, you must upgrade the ExPath tool to the same version as the storage system microcode version.

To upgrade the ExPath tool:

1. Log into your computer as Administrator.
2. Insert the ExPath tool installation CD-ROM into the drive.
3. Copy the files `JSanRmiServerSx.jar` and `JSanExPthTool.jar` and in the `ExPthTool/lib` directory in the CD-ROM and overwrite the files in the `ExPthTool/lib` directory in the C drive.
4. Make sure that the two files in the C drive have the same modified date as the files in the CD-ROM.
5. Eject the installation CD-ROM from the drive.

## Using the ExPath Tool

Use the ExPath tool in the following steps:

1. Create an authentication file. This step is not required if you write the authentication information in a command file.
2. Edit the Java security policy.
3. Create a command file.
4. Run the ExPath tool.

## Creating an Authentication File

An authentication file is an encrypted file containing a user ID and a password. If the SVP has an IPv6 address, an authentication file is required. To create an authentication file, perform the following command at the command prompt.

### Syntax

```
java -classpath
    "classpath" sanproject.uvmdata.MakeAuthentication svpip UserID Password An_Authentication_File
```

### Parameters

Parameter	Description
<i>classpath</i>	Specifies the paths to the JAR files ("./lib/JSanExPthTool.jar;./lib/JSanRmiServerSx.jar").
<i>svpip</i>	Specifies the IP address of the SVP. If the SVP has an IPv6 address, enclose the IPv6 address in square brackets [ ].
<i>UserID</i>	Specifies the Remote Web Console user ID.
<i>Password</i>	Specifies the password for the Remote Web Console user ID.
<i>An_Authentication_File</i>	Specifies an authentication file name.

### Examples

When the SVP has an IPv4 address:

```
java -classpath "./lib/JSanExPthTool.jar;./lib/JSanRmiServerSx.jar"
sanproject.uvmdata.MakeAuthentication 192.168.0.100 UserID
PASSWORD>Authentication.txt
```

When the SVP has an IPv6 address:

```
java -classpath
    "./lib/JSanExPthTool.jar;./lib/JSanRmiServerSx.jar"
sanproject.uvmdata.MakeAuthentication
[fe80::1234] UserID PASSWORD>Authentication.txt
```

## Editing the Java Security Policy

Add the following script to the Java policy file. This script is contained in the sample file named myPolicy.txt. You can copy and paste it to the Java policy file.

```
grant {
    permission java.security.AllPermission;
};
```

## Creating a Command File

In a command file, you can write authentication information and commands that should be executed on the external volume. Three kinds of commands are provided (disconnect, checkpath, and checkstatus) and you can write only one kind of these commands in one command file. To use the three kinds of these commands, you must create three command files. Sample files for these commands are provided for your use. You can customize these files to suit your needs.

One line must contain only one command. You can specify multiple external volumes for one command, and specify multiple commands in multiple lines. The maximum number of external volumes that can be written in one command file is 256. Characters between semicolon (;) and the end of line are recognized as a comment.

The following is an example of a command file for the disconnect command:



```

; Disconnect

svpip 127.0.0.1
login root password

disconnect E1-1 E1-2
disconnect E2-1 E2-2

```

The svpip and login commands are used for writing the authentication information. If no authentication file is created, the authentication information must be written in a command file as shown above.

## Running the ExPath Tool

To run the ExPath tool, write the following command in a batch file, and execute the batch file on the command line. The ExPath tool cannot be started multiple times concurrently.

A sample batch file (runWin.bat) is provided for your use. You can customize this batch file to suit your needs.

## Syntax

```
java -classpath "classpath" -Dproperties_a_to_e sanproject.uvmdat.RJUvmMain
```

## Parameters

Parameter	Description
<i>classpath</i>	Specifies the paths to the JAR files ("./lib/JSanExPthTool.jar;./lib/JSanRmiServerSx.jar").
(a) -Djava.security.policy= <i>a policy file path</i> (Required)	Specifies the file that contains the Java security policy.
(b) -Duvvm.authentication= <i>an authentication file path</i>	Specifies the file that contains the authentication information. To encrypt the authentication information or to use an IPv6 address of the SVP, this parameter is required. If the parameter is omitted, the authentication information in a command file will be used.
(c) -Duvvm.command= <i>a command file path</i> (Required)	Specifies the file that contains information about the operation and target external volume.
(d) -Duvvm.logpath= <i>a directory where a log file should be created</i>	Specifies the directory where a log file should be created. If this parameter is omitted, a log file will be created in the current directory.
(e) -Duvvm.logfile= <i>a log file name</i>	Specifies the log file name. If the directory already has a log file with the same name, the log file will be overwritten. If this parameter is omitted, a log file named <i>uvvm-MMDDHHMMSS.log</i> will be created. <i>MMDDHHMMSS</i> in the file name will be numbers indicating month, day, hour, minute, and second. In addition, if this parameter is omitted, a new log file will be created every time you start the ExPath tool. Delete unnecessary log files regularly.

## Example

```

java -classpath "./lib/JSanExPthTool.jar;./lib/JSanRmiServerSx.jar"
-Xmx268435456 -Djava.security.policy=myPolicy.txt
-Duvvm.authentication=Authentication.txt -Duvvm.command=command.txt
-Duvvm.logpath=log sanproject.uvmdat.RJUvmMain

```

## Termination Code

0: The ExPath tool finished successfully.

-1: An error occurred.

If multiple external volumes are specified, 0 returns only when all the commands on all the external volumes are finished successfully. When the checkstatus command is executed, different termination codes will return.

An error (the termination code -1) occurs under the following conditions:

- When a command file contains information about an external volume that does not exist.  
When the disconnect or checkpath command is executed, the RMI server error (605, 5828) occurs. When the checkstatus command is executed, the error "Unable to use the external volume group" occurs.
- When the ExPath tool is executed for a storage system other than an HP XP24000/XP20000 Disk Array.
- When the version of the ExPath tool and the version of the storage system microcode do not match.

## Command Reference

You can write commands for the ExPath tool in a command file. The commands that can be written are:

**Table 63 Command List for the ExPath Tool**

Command	Purpose	Description
svpip	For authentication. Required when no authentication file is used.  For external volume operations. Only one of these commands can be written in one file.	Specifies the IP address of the SVP.
login		Specifies the login user ID and the password.
disconnect		Specifies the login user ID and the password.
checkpath		Specifies the login user ID and the password.
checkstatus		Retrieves external volume statuses.

### svpip Command

#### Syntax

```
svpip △ ip-address
```

#### Description

Specifies the IP address of the SVP. When the SVP has an IPv6 address, do not write this command in a command file. Create an authentication file instead. If you specify an authentication file when you run the ExPath tool, this command will be ignored.

#### Parameters

Parameter	Description
<i>ip-address</i>	Specifies the IPv4 address of the SVP.

#### Example

The following example specifies 158.214.127.170 as the IP address of the SVP:

```
svpip 158.214.127.170
```

## login Command

### Syntax

```
login  $\Delta$  user-ID  $\Delta$  password
```

### Description

Specifies the login user ID and the password. The svpip command must be written before this command. If you specify an authentication file when you run the ExPath tool, this command will be ignored.

### Parameters

Parameter	Description
<i>user-ID</i>	Specifies the user ID of Remote Web Console.
<i>password</i>	Specifies the password for the user ID of Remote Web Console.

### Example

The following example uses *root* as a user name and *password* as a password:

```
svpip 158.214.127.170  
login root password
```

## disconnect Command

### Syntax

```
disconnect  $\Delta$  ExG-VPG[  $\Delta$  ExG-VPG...]
```

### Description

Disconnects external volumes. This command executes the same operation as the **Disconnect External Volumes** command which you perform by using the Volume Operation window. After the disconnect command is performed, only the external storage system can access the external volumes.

The disconnect command cannot be performed if the external volume is configured as a P-VOL or S-VOL for the copy program products. See [\(page 91\)](#) for required operations and notes to perform the disconnect command.

The sample file `disconnect.txt` is provided for your use.

### Parameters

Parameter	Description
<i>ExG-VPG</i>	<i>ExG</i> specifies the external volume group in the range of E1 to E16384. <i>VPG</i> specifies the serial number within an external volume group in the range of 1 to 4096.

### Example

The following example disconnects the E1-1 and E1-2 external volumes:

```
disconnect E1-1 E1-2
```

## checkpath Command

### Syntax

```
checkpath △ ExG-VPG[ △ ExG-VPG...]
```

### Description

Resume using external volumes. This command executes the same operation as the **Check Paths & Restore Volume** command which you perform by using the Volume Operation window. After the checkpath command is performed, the local storage system can access the external volumes. For detailed notes on the checkpath command, see [\(page 93\)](#).

The sample file `checkPath.txt` is provided for your use.

### Parameters

Parameter	Description
<i>ExG-VPG</i>	<i>ExG</i> specifies the external volume group in the range of E1 to E16384. <i>VPG</i> specifies the serial number within an external volume group in the range of 1 to 4096.

### Example

The following example resumes using the E1-1 and E1-2 external volumes:

```
checkpath E1-1 E1-2
```

## checkstatus Command

### Syntax

```
checkstatus △ ExG-VPG[ △ ExG-VPG...]
```

### Description

Retrieves external volume statuses and returns the termination code. The sample file `checkStatus.txt` is provided for your use.

The external volume statuses are:

- Normal: The external volume is in the normal status.
- Destage: The writing of data from cache memory to the volume is in progress.
- Disconnect: The connection to the external volume is stopped.
- Checking: The checking of the status of the path to the external volume is in progress.
- Blockade: The external volume is blocked.

### Parameters

Parameter	Description
<i>ExG-VPG</i>	<i>ExG</i> specifies the external volume group in the range of E1 to E16384. <i>VPG</i> specifies the serial number within an external volume group in the range of 1 to 4096.

### Example

The following example retrieves the statuses of the E1-1 and E1-2 external volumes:

```
checkstatus E1-1 E1-2
```

## Termination Code

-1: An error occurred.

See [Table 64 \(page 165\)](#) for other termination codes.

**Table 64 Termination Codes for the checkstatus Command and the External Volume Status**

Termination Code	External Volume Status				
	Normal	Destage	Disconnect	Checking	Blockade
0x01	Exists	N/A	N/A	N/A	N/A
0x02	N/A	Exists	N/A	N/A	N/A
0x03	Exists	Exists	N/A	N/A	N/A
0x04	N/A	N/A	Exists	N/A	N/A
0x05	Exists	N/A	Exists	N/A	N/A
0x06	N/A	Exists	Exists	N/A	N/A
0x07	Exists	Exists	Exists	N/A	N/A
0x08	N/A	N/A	N/A	Exists	N/A
0x09	Exists	N/A	N/A	Exists	N/A
0x0A	N/A	Exists	N/A	Exists	N/A
0x0B	Exists	Exists	N/A	Exists	N/A
0x0C	N/A	N/A	Exists	Exists	N/A
0x0D	Exists	N/A	Exists	Exists	N/A
0x0E	N/A	Exists	Exists	Exists	N/A
0x0F	Exists	Exists	Exists	Exists	N/A
0x10	N/A	N/A	N/A	N/A	Exists
0x11	Exists	N/A	N/A	N/A	Exists
0x12	N/A	Exists	N/A	N/A	Exists
0x13	Exists	Exists	N/A	N/A	Exists
0x14	N/A	N/A	Exists	N/A	Exists
0x15	Exists	N/A	Exists	N/A	Exists
0x16	N/A	Exists	Exists	N/A	Exists
0x17	Exists	Exists	Exists	N/A	Exists
0x18	N/A	N/A	N/A	Exists	Exists
0x19	Exists	N/A	N/A	Exists	Exists
0x1A	N/A	Exists	N/A	Exists	Exists
0x1B	Exists	Exists	N/A	Exists	Exists
0x1C	N/A	N/A	Exists	Exists	Exists
0x1D	Exists	N/A	Exists	Exists	Exists
0x1E	N/A	Exists	Exists	Exists	Exists

**Table 64 Termination Codes for the checkstatus Command and the External Volume Status** *(continued)*

Termination Code	External Volume Status				
	Normal	Destage	Disconnect	Checking	Blockade
0x1F	Exists	Exists	Exists	Exists	Exists
Exists: The volumes in this status exist. N/A: No volume in this status exists.					

---

# Glossary

## A

<b>AMS</b>	Adaptable module storage.
<b>ATA</b>	Advanced Technology Attachment standard.

## C

<b>CHA</b>	Channel adapter. A device that provides the interface between the array and the external host system. Occasionally, this term is used synonymously with the term channel host interface processor (CHIP).
<b>CV</b>	Custom-sized volume.

## E

<b>ESCON</b>	Enterprise systems connection An optical interface used to connect the mainframe to the control unit; a predecessor to FICON.
<b>ExG</b>	External volume group.

## F

<b>FC</b>	Fibre Channel. A network technology primarily used for storage networks.
<b>FICON</b>	Fibre connectivity. Hardware that connects the mainframe to the control unit.

## H

<b>HDD</b>	Hard disk drive.
------------	------------------

## L

<b>LD, LDEV</b>	Logical device. An LDEV is created when a RAID group is carved into pieces according to the selected host emulation mode (that is, OPEN-3, OPEN-8, OPEN-9). The number of resulting LDEVs depends on the selected emulation mode. The term LDEV is also known as <i>term volume</i> .
<b>LDKC</b>	Logical disk controller.
<b>LUN</b>	Logical unit number.

## M

<b>MCU</b>	Main control unit.
<b>MIH</b>	Missing interrupt handler.

## O

<b>OTP</b>	Online transaction processing.
------------	--------------------------------

## P

<b>P-VOL</b>	Primary volume.
<b>PB</b>	Petabyte. 1 PB (petabyte) = 1,000 <sup>5</sup> bytes (hard disk storage) or 1 PB (petabyte) = 1,024 TB or 1,024 <sup>5</sup> bytes (logical storage).
<b>PCB</b>	Printed circuit board.

## R

<b>RCU</b>	Remote control unit.
------------	----------------------

## S

<b>S-VOL</b>	Secondary or remote volume. The copy volume that receives the data from the primary volume.
<b>S-VOL</b>	Source volume (for ShadowImage for Mainframe) or secondary volume (for ShadowImage for Mainframe, XP Continuous Access, and XP Continuous Access Journal).
<b>SATA</b>	Serial Advanced Technology Attachment.
<b>SIM</b>	Service information message.
<b>SSID</b>	Subsystem identifier; storage system identifier.
<b>SVP</b>	Service processor. A computer built into a disk array. The SVP, used only by an HP service representative, provides a direct interface to the disk array.
<b>SVS</b>	Storage Virtualization System

## T

<b>TB</b>	Terabyte. Equivalent to 1,000 Gb for data storage and statistics, or 1,024 Gb for memory.
-----------	---

## U

<b>USP</b>	Universal Storage Platform
------------	----------------------------

## V

<b>VDEV</b>	virtual device
<b>VLL</b>	Virtual LVI/LUN
<b>VMA</b>	volume management area
<b>VOL, vol</b>	Volume.

## W

<b>WWN</b>	World Wide Name
------------	-----------------



# Index

## A

Attributes  
list of emulation type, 17

## B

Block management, ExG, 17

## C

Cache  
logical partition, 18  
memory, 18  
Channels  
ESCON or FICON, 25  
Concept, 13  
conventions  
storage capacity values, 132  
customer support, 131

## D

Destaging data, 18  
document  
related documentation, 132  
documentation  
HP website, 132  
providing feedback, 133

## E

Emulation, OPEN-V, 26  
External Port, 16  
external storage system, 12  
External volume  
group, 17  
migrate existing data, 17  
External Volume Group, 17  
External Volume Mapping, 99

## H

help  
obtaining, 132  
HP  
technical support, 132

## I

Initiator, 63  
Initiator/External MIX mode restrictions  
using, 124

## L

LDEV capacity specifying, 110

## M

Mainframe volumes, 25  
mapping, 12  
Mode  
cross-subsystem path, 19

multi, 19  
single, 19

## O

operation tags  
AddVolumeSetting, 106  
ExternalGroup, 104  
MappedVolume, 104  
SSID, 103  
Overview, 9

## P

Path Operation Window, 56  
Port Operation Tree, 63  
Port Operation Window, 62  
Preview Dialog Box, 54

## R

RCU Target, 63  
related documentation, 132  
Remote Command Devices, 120  
Mapping, 122  
Overview, 119  
XP Continuous Access or XP Continuous Access Journal,  
122

## S

spreadsheets  
example, 117  
mapping external volumes, 106  
operation tags, 102  
saving storage system information, 103  
types, 102  
Status  
cross-subsystem path, 60  
Status:Disable button, 47  
Status:Enable button, 47  
storage capacity values  
conventions, 132  
storage systems  
supported models, 9  
Subscriber's Choice, HP, 133  
support center, 131  
System Requirements, 37

## T

Target, 63  
technical support, 131, 133  
HP, 132

## V

Volume Operation Window, 47

## W

websites  
HP, 133

HP Subscriber's Choice for Business, [133](#)  
product manuals, [132](#)

## X

XP External Storage Requirements, [37](#)