


OPTIMUS®

Professional Series

Audio/Video Receiver

STAV-3680



Introducing the Optimus STAV-3680

Your Optimus STAV-3680 Audio/Video Receiver is the perfect control center for your audio/video system. It combines 500 watts total Pro Logic Surround Sound power with five equal-power discrete amplifiers and provides connections for one tape deck, one VCR, two more tape decks or audio/video playback sources, a turntable, a CD player, and a video monitor.

Your receiver also has special sound options. *Dolby Pro Logic*[®] *Surround Sound* delivers movie theater sound for audio/video programs (especially those encoded with Dolby Surround Sound signals). *Dolby 3CH Logic* provides a wider sound field than ordinary playback. *Studio Effect* simulates the ambiance of a recording studio, adding extra richness to your music. *5-D Theater* provides clear dynamic sound effects by sending audio signals to the rear channel to simulate stereo sounds.

Additional features include:

- Digital-Synthesized Tuner** Precisely tunes to AM and FM stations.
 - Multi-Jog Tuning** Offers you a simple tuning method for either memorized stations or the entire frequency range.
 - 30 Memory Locations** Let you store and recall the frequencies for up to 30 AM/FM stations.
 - Subwoofer Output** Lets you easily connect an amplified subwoofer that delivers the very low frequency bass sounds, bringing out the richness and depth of music plus the full impact of motion-picture special effects for sound you can actually feel.
 - Tape Monitoring** Lets you listen to the actual recording as you record, if your tape deck has a tape-monitoring feature.
 - Built-In Protection Circuits** Automatically turn off the receiver to help avoid power surges or short circuit damage.
 - Remote Control** Lets you use a single remote control for the receiver and other compatible components connected to the receiver.
- Note:** The remote control requires two AA batteries (not supplied).

We recommend you record the receiver's serial number here. The serial number is on the receiver's back panel.

Serial Number: _____

Note to the Cable TV System Installer:



This reminder is provided to call the CATV system installer's attention to article 820-40 of the National Electrical Code that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Manufactured under license from Dolby Laboratories Licensing Corporation.
Dolby, Pro Logic, and the double-D symbol (DD) are trademarks of Dolby Laboratories Licensing Corporation.
© 1997 Tandy Corporation.
All Rights Reserved.
RadioShack and Optimus are registered trademarks used by Tandy Corporation.

IMPORTANT SAFETY INSTRUCTIONS

This receiver is made and tested to meet exacting safety standards. It meets both UL and FCC requirements.

Warning: To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.		



This symbol is intended to alert you to the presence of uninsulated dangerous voltage within the system's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the system's case.




This symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this system.

CAUTION

Power Lines — Locate an outdoor antenna away from power lines.

Nonuse Periods — Unplug the receiver's power cord when you will not use it for extended periods.

Outdoor Antenna Grounding — If an outside antenna or cable system is connected to the receiver, ground the antenna or cable system so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information about proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See the example below.



Careful attention is devoted to quality standards in the manufacture of your receiver, and safety is a major factor in its design. However, safety is also your responsibility.

This section lists important information that will help you properly use and enjoy your receiver and accessories. Read all the included safety and operating instructions before using your receiver. Follow them closely, and retain them for future reference.

Heed Warnings — Follow all warnings on the product and in the operating instructions.

Cleaning — Unplug this product from the wall outlet before cleaning. Use only a damp cloth for cleaning. Do not use liquid or aerosol cleaners.

Attachments — Do not use attachments/accessories not recommended by the product manufacturer, as they might create a hazard.

Water and Moisture — Do not use this product near water (for example, near a bathtub, washbowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool).

Accessories — Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Follow the manufacturer's instructions for mounting, and use a recommended mounting accessory.



Carts — Move the product on a cart carefully. Quick stops, excessive force, and uneven surfaces may cause the product/cart to overturn.

Ventilation — Slots and openings in the cabinet provide ventilation, ensure reliable operation, and protect from overheating. Do not block or cover these openings, and do not place the product on a bed, sofa, rug, or other similar surface. Do not place the product in a built-in bookcase or rack unless it provides proper ventilation as specified by the manufacturer.

Power Sources — Operate this product using only the power source indicated on its marking label. If you are not sure of your home's power type, consult your product dealer or local power company.

Polarization — This product is equipped with a polarized AC line plug (a plug having one blade wider than the other). This plug will fit in the power outlet only one way. This is a safety feature. If you cannot insert the plug fully into the outlet, try reversing the plug. If the plug still doesn't fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. If you need an extension, use a polarized cord.

Power-Cord Protection — Route power-supply cords so they are not likely to be walked on or pinched by items placed on or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

Lightning — For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

Overloading — Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.

Objects and Liquids — Never push objects of any kind into this product through openings, as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

Servicing — Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service — Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged.
- If liquid has been spilled or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance.

Replacement Parts — When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or having the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

Safety Check — Upon completion of service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

Wall or Ceiling Mount — The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

Heat — The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.


Contents

Preparing Your Receiver	5
Positioning Speakers	5
Connecting Speakers	6
Connecting Program Sources	9
Connecting the Antennas	11
Using One Remote Control for More than One Unit	13
Installing the Remote Control's Batteries	13
Using the AC Power Outlet	14
Connecting to AC Power	14
Basic Operation	15
Balance Control	16
Loudness Control	16
Muting the Receiver	16
Using Headphones	16
Tuning the Radio	17
Using FM Mono	18
Cassette Deck/VCR Features	19
Using the VCR/TAPE 1 and TAPE 2 Monitor Buttons	19
Recording a Program Source	19
Dubbing a Cassette Tape	19
Playing and Recording Video Tapes	20
Using Advanced Sound Options	21
Sound Mode Adjustments (Remote Control Only)	22
Using the Remote Control	23
Troubleshooting	25
Returning Controls to Factory Defaults	25
Care and Maintenance	26
The FCC Wants You to Know	27
Specifications	28
Index to Features by Control Name	30

Preparing Your Receiver

Caution: Make all the necessary connections before you plug in or turn on the receiver.

Positioning Speakers



- Surround speakers generally sound best if you position them above ear level.
- To avoid interference with the picture on a nearby TV, use magnetically shielded speaker systems. This is particularly important for the center speaker since it is usually located closest to the TV.


Where you place your speakers (not supplied) can make a noticeable difference in your system's sound. The guidelines in this section will help you choose the best locations. After you use your receiver for a while, you might want to try different locations for your speakers.

Bass response depends largely on speaker location. For strong bass, place the speakers in the corners of the room. If you want even stronger bass, place the speakers directly on the floor. If the bass is too strong, move the speakers slightly away from the corners of the room, or raise them 6 to 18 inches off the floor. You can buy speaker stands at your local RadioShack store.

The distance between the speakers should be about the same as the distance between the normal listening point and the point halfway between the speakers. If you place the speakers too close together, you reduce the stereo separation. If you place them too far apart, you reduce the bass effect and create a "hole" in the middle of the sound.

Most speakers have a tweeter dispersion angle of about 60 degrees. Ideally, your listening position should be just inside the overlap area of the tweeter dispersion. You can angle the speakers toward you for better stereo effect.

To position your speakers for surround sound, place the A or B (front) speakers at the front of your listening area, and place the surround speakers (rear) behind or to the sides of the listening point (see "Using Advanced Sound Options" on Page 21). Also, place the center speaker above, below, or behind the TV. Sound might not appear to coincide with the picture if you place the center speaker beside the TV.



Connecting Speakers


Follow these guidelines when you select and connect speakers.

- Be sure you properly connect all speakers.
- Do not connect two pairs of speakers to a single set of terminals (A or B) at the same time. When you use two pairs of speakers, connect one set to the Speakers A jacks and one set to the Speakers B jacks.
- Optimus and other high-quality speakers have color-coded speaker terminals (red for positive polarity and black for negative polarity). Use these color-coded terminals as a guide to help you properly connect the speakers to the receiver.
- Use 16-gauge (or larger) speaker wire for all speaker connections, and consider possible speaker locations before you decide how much speaker wire you need.

Preparing the Speaker Wires

Speaker wire consists of two conductors (individual wires) encased in insulation and is usually color-coded or marked with a ridge along one side so you can identify each conductor. Use these markings as a guide to help you properly connect the speakers to your receiver.


Follow these steps to prepare the speaker wires.



1. Cut the speaker wires to the necessary length.
2. Separate the wires about 4 inches on each end.
3. Using a wire stripper, carefully strip about $\frac{3}{4}$ inch of insulation from the end of each conductor.
4. Twist the end of each exposed wire to secure any loose strands.

Setting the Impedance Selector Switch


Before connecting speakers, check your speaker system's impedance (see your speaker system's specifications). Normally it is 8W. If it is, leave the **IMPEDANCE SELECTOR** switch set to **8W~16W/ SPEAKER**. If your speaker system has 6W impedance, set the switch to **6Ω~16Ω/SPEAKER**.




Connecting the A and B Speakers

Note: Be sure you connect the receiver's right and left positive (+) and negative (–) terminals to the speaker's corresponding right and left positive (+) and negative (–) terminals.

Follow these steps to connect the right speaker to the receiver's right **FRONT SPEAKERS A** terminals.



1. Lift the receiver's **FRONT SPEAKERS A R (+)** red lever and insert the ridged or color-coded conductor's end into the small hole. Pull back the lever to secure the conductor.



2. Lift the receiver's **FRONT SPEAKERS A R (–)** black lever and insert the other conductor's end into the small hole. Pull back the lever to secure the conductor.
3. Connect the ridged or color-coded conductor's loose end to the right speaker's positive (+) terminal.
4. Connect the remaining loose conductor to the right speaker's negative (–) terminal.

Repeat Steps 1 through 4 to connect the left speaker to the receiver's left **FRONT SPEAKERS A** terminals.

Repeat this entire process to connect a second pair of speakers to the **FRONT SPEAKERS B** terminals.

Connecting Surround-Sound Speakers

You can connect a pair of speakers to the receiver's **REAR SPEAKERS** terminals for surround-sound programs. Follow the steps in "Connecting the A and B Speakers."

Connecting the Center Speaker

The center speaker gives additional ambience to surround sound. Connect the center speaker to the **CENTER SPEAKER** terminals. Follow the steps in "Connecting the A and B Speakers."

Connecting Center Channel and Subwoofer Amplifiers

To increase the center channel's output power, you can connect an amplifier to the **CENTER** jack. Then connect the center channel speaker to the amplifier.


Your receiver includes a line-level subwoofer output. Connecting a subwoofer to your system dramatically extends bass response for incredible richness and depth. When you listen to surround-sound programs, a subwoofer enhances your home theater experience by realistically re-creating the rumble of an earthquake, the bone-jarring percussion of a cannon, and more. To use the subwoofer output, simply connect it to an amplified subwoofer's line-level input or to an amplifier to which you have connected a subwoofer.

RadioShack stores sell a variety of suitable subwoofers and amplifiers.

Connecting Program Sources

You can connect up to six external program sources to your receiver.

Use shielded audio cables with phono connectors for all audio connections.



Connecting a Turntable

Connect a turntable with a magnetic cartridge only. Some older turntables use a ceramic-type cartridge that does not work with this system.

Connect the turntable's left and right cables to the receiver's left and right **PHONO** jacks. Then connect the turntable's ground wire to the receiver's **SIGNAL GND** terminal.

Connecting Cassette Deck(s)

Note: If you place the cassette deck directly above, below, or to the left of the receiver, the receiver could interfere with the cassette deck's operation. If possible, position the cassette deck to the right of the receiver or locate it away from the receiver.

You can connect cassette decks to the **VCR/TAPE 1** and the **TAPE 2 MONITOR** jacks. Connect the cassette deck's output jacks to the **VCR/TAPE 1 IN** (audio) or **TAPE 2 IN PLAY** jacks, and connect the cassette deck's input jacks to the **VCR/TAPE 1 OUT** (audio) or **TAPE 2 OUT REC** jacks.

You can connect a third cassette deck (for playback only) to the **LD/SAT IN** (audio) jacks.


Connecting a CD Player

To connect a CD player to the receiver, connect the CD player's left and right output jacks to the receiver's **CD** jacks.

Connecting Video Sources

Note: If your VCR is monaural, use a Y-adaptor (available at your local RadioShack store) to connect the VCR's audio output to both the L and R audio inputs on the receiver.

If you connect three video sources such as VCRs, laser disc players, or DVD (digital video disc) players to your receiver, you can use the receiver to select each video source. You can also use the receiver to easily record from the video sources to the source connected to **VCR/TAPE 1**.



Connect phono cables from a VCR's audio outputs to the receiver's **VCR/TAPE 1 IN** or **LD/SAT IN** (audio) jacks. Then connect phono cables from the receiver's **VCR/TAPE 1 OUT** (audio) jacks to the VCR's audio input jacks.

Connect video cables from each video source's video outputs to the receiver's **VCR/TAPE 1 VIDEO IN** or **LD/SAT VIDEO IN** jacks. Then connect video cables from the receiver's **VCR/TAPE 1 VIDEO OUT** jack to the VCR's video input.

You can connect a third video source to the **DVD/TV IN** jacks. Connect the source's video output to the receiver's **DVD/TV VIDEO IN** jack, and the source's audio outputs to the receiver's **DVD/TV IN** (audio) jacks.

Connecting a Video Monitor

The monitor (or TV with baseband video input) you connect to the **VIDEO OUT** terminal can monitor any source you connect to the receiver's **VCR/TAPE 1**, **LD/SAT**, or **DVD/TV** input jacks. Connect a video cable from the receiver's **VIDEO OUT TO MONITOR TV** jack to the monitor's video input.

Connecting the Antennas

In many cities, the supplied indoor AM loop and FM antennas provide satisfactory reception.

AM Antennas

Assemble the included antenna's base by swinging the base in the direction of the arrow and inserting the antenna's bottom tabs into the base's slot. Then attach the antenna wires to the **LOOP ANTENNA** terminals (bottom two terminals).


Place the antenna on a flat surface and rotate it for the best AM reception.

If the receiver is in a rack or on a shelf and there is no room for the AM loop antenna, use two screws (not supplied) to mount the base on the wall or another location as shown.

Notes:

- Keep the AM loop antenna connected even when you use another indoor antenna or an outdoor AM antenna.
- Ensure the antenna does not touch the receiver or other metal objects.
- Do not place the antenna near a CD player, a personal computer, or a TV set.
- If the wire between your AM loop antenna and receiver is too short, you can add extra wire, available at your local RadioShack store.


You can also use a RadioShack shortwave antenna kit (Cat. No. 278-758), which makes an excellent outdoor AM antenna. Connect the outdoor AM antenna wire to the receiver's AM terminal, as shown.



Note: For the best results, use 75-ohm coaxial cable to connect an outdoor FM antenna to the receiver.

FM Antennas

Connect the supplied FM antenna to the **FM UNBAL 75Ω** terminal as shown, then extend it.



For better FM reception, you can also use a rabbit-ear TV antenna (for indoor use only) or an outdoor VHF TV antenna. To connect the TV antenna to the receiver, you need a VHF/UHF/FM splitter (not included). RadioShack stores carry a full line of quality outdoor antennas and antenna connection accessories.


Preparing Your Receiver

Warning: To prevent injury, read and follow all cautions and warnings that accompany the outdoor antenna.

For the best radio reception, use an outdoor antenna. Follow these steps to connect an outdoor FM antenna to the receiver using 75Ω cable.


Note: If your antenna has 300Ω twin-lead cable, consult your local RadioShack store for the correct adapter.

1. Disconnect the supplied FM antenna from the receiver's **FM UNBAL 75Ω** terminal.
2. With a stripping tool, remove about 1 ½ inches of the outdoor antenna cable's outer insulation to expose the cable's shielding.
3. Fold back the outer insulation from the inner insulation.
4. Remove about 1 inch of the inner insulation from around the center wire.



Caution: The cable's shielding should only touch the **GND** terminal.

5. Pull the shielding to one side. Connect the center wire to the receiver's **FM UNBAL 75Ω** terminal. Twist the shielding to secure any loose wire strands, and connect it to the ⏏ (ground) terminal.




Note: Grounding is not necessary for reception, but we recommend it to avoid damage from lightning when you use an outdoor FM antenna and for better FM reception. Use a separate piece of thick polyvinyl insulated wire to connect the ⏏ terminal to an earth ground such as a metal cold-water pipe.

Warning: Never connect a wire to a gas pipe for grounding since sparks might ignite the gas.

Using One Remote Control for More than One Unit

Note: When you plug this system's cable into a component's **CONTROL IN** jack, that component's remote sensor is disabled.



If you also have an Optimus professional series CD player, VCR, or cassette deck with the OSR mark (**OSR**), you can connect its **CONTROL IN** jack to the receiver so you can control all of your equipment with a single remote control. You can also use the other component's remote control by pointing it at the receiver's front panel.

1. Connect each component to the receiver as shown in "Connecting Program Sources" on Page 8.

Note: You must connect the audio cables between the receiver and the other audio accessory to use your receiver's remote control to control the accessory.

2. Connect the cable supplied with the CD player, VCR, or cassette deck between the receiver's **CONTROL OUT** jack and the other component's **CONTROL IN** jack.
3. When you want to control more than one other component using the receiver's remote control, daisy-chain the **CONTROL OUT** and **CONTROL IN** connections as shown.


Installing the Remote Control's Batteries

Cautions:

- Use only fresh batteries of the recommended size and type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- Always remove old or weak batteries. Batteries can leak chemicals that can damage electronic circuits.

Note: If the remote's range is reduced, replace the batteries immediately.

The remote control uses two AA batteries (not included). For the longest battery life, we recommend alkaline batteries (RadioShack Cat. No. 23-557).




1. Press and slide open the battery compartment cover.
2. Place two fresh AA batteries in the compartment as indicated by the polarity symbols (+ and -) marked in the compartment.
3. Replace the battery compartment cover.

Preparing Your Receiver

Using the AC Power Outlet

Caution: Do not connect appliances with high power consumption, such as a heater, iron, monitor, or TV, to this AC outlet. Doing so can cause a risk of overheating and fire, and could damage the receiver.

Your receiver has an AC power outlet that you can use to power another electronic device, such as a turntable, cassette deck, or so on. This switched outlet turns on and off with the receiver and provides a maximum of 100 Watts.




Connecting to AC Power

Warning: To prevent electric shock, do not use this polarized plug with an extension cord, receptacle, or other outlet unless you can fully insert the blades to prevent blade exposure.

Before you plug in the receiver's power cord, double check all other connections.

To power the receiver, plug the receiver's power cord into a standard AC outlet. The power cord's plug is polarized and fits only one way.



Basic Operation

Warning: To prevent possible hearing loss, turn **MASTER VOLUME** to **MIN** before you turn on the receiver or change the program sources. After you turn on the receiver or change the program source, adjust **VOLUME** to a comfortable listening level.

Note: If you want to find out what a particular button or control is used for, see Page 23 (for the remote control) or Page 30 (for the front panel) to find the page where the button or control is described.

Note: If you select a source while **TAPE 2 MONITOR** is engaged, **TAPE 2** flashes five times on the display, reminding you to disengage the **TAPE 2 MONITOR** function.

Note: The controls on the remote control work the same as the buttons on the receiver's front panel.

Follow these steps to use the receiver.

1. Press **POWER** to turn on the receiver's power. It takes about 5 seconds to begin hearing sound.
2. Select the speakers. **A** appears when **SPEAKERS A** is selected. **B** appears when **SPEAKERS B** is selected.

If you connected speakers only to the **FRONT SPEAKERS A** (or **B**) terminals, press **SPEAKERS A** (or **B**) to turn on only those speakers.

If you connected speakers to both the **FRONT SPEAKERS A** and **B** terminals, do any of the following:

- Press in **SPEAKERS A** or **B** to turn on either pair of speakers for a two-speaker stereo effect.
- Press in **SPEAKERS A** and **B** to turn on both pairs of speakers for a four-speaker stereo effect.
- Press **SPEAKERS A** and **B** to turn off all speakers so you can listen privately with headphones.

3. Select a program source.

To tune to a radio station, see "Tuning the Radio" on Page 17.

To listen to signals from the component connected to **TAPE 2 MONITOR**, press **TAPE 2 MONITOR** so **TAPE 2** appears on the display.

To listen to a source other than one connected to **TAPE 2 MONITOR**, be sure **TAPE 2** does not show on the display. If necessary, press **TAPE 2 MONITOR** so **TAPE 2** disappears. Then press **VCR/TAPE 1**, **DVD/TV**, **LD/SAT**, **CD**, **TUNER**, **PHONO**, or repeatedly press **FUNCTION** on the remote control to display the desired program source.

4. Adjust **MASTER VOLUME** clockwise to increase the volume or counterclockwise to decrease it. Or, you can use **MASTER VOLUME +/-** on the remote control.
5. Use the **BASS** and **TREBLE** controls to adjust the program's tonal quality.
6. Adjust **BALANCE** to suit your listening preferences. See "Balance Control" on Page 16.
7. Press **POWER** to turn off the receiver.

Balance Control

The **BALANCE** control lets you adjust the sound balance between the left and right speakers. If you properly position the speakers and your listening area is centered between them, the center control setting is usually best (see "Positioning Speakers" on Page 5).

For an unusual speaker placement, adjust **BALANCE** as follows:

1. Select **TUNER**. Then press **FM/AM** to select the FM band.
2. Press **FM MONO** so **MONO** appears. The sound is monaural instead of stereo, so each speaker delivers the same output.
3. Turn **BALANCE** until you hear the sound coming equally from each speaker when you are in the listening area.
4. Press **FM MONO** so **MONO** disappears from the display.

Loudness Control

To increase the high and low ranges of sounds for improved audio at a low listening level, press **LOUDNESS** (**LOUD.** on the remote control) so **LOUDNESS** appears on the display. Press **LOUDNESS** again to turn off this feature.

Muting the Receiver

To temporarily mute the sound, press **MUTING** on the remote control. **MUTING** appears. Press **MUTING** again to restore the audio level.

Using Headphones

To listen with headphones (not supplied), insert the headphones' ¼-inch plug into the receiver's front panel **PHONES** jack. To silence the speakers, press **SPEAKERS A** and **B** to turn off any special sound options.

Listening Safely

To protect your hearing, note the following when using headphones.

- Set the volume to its lowest setting before you begin listening. After you begin listening, adjust volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Once you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Tuning the Radio

You can tune your receiver manually or you can store stations in memory.

Manual Tuning (Front Panel Only)

Follow these steps to manually tune to a station.

1. Press **TUNER**. Then press **FM/AM** to select the desired band.

When you select the AM or FM band, the receiver tunes to and displays the frequency last selected in that band.

2. Press **SELECT** so **FREQ** appears on the **JOG MODE** display.
3. Turn **MULTI JOG** to tune the desired station.

Notes:

- **TUNED** appears on the display when you tune to a strong station.
- **STEREO** appears on the display when the tuner is receiving FM broadcasts.

Memory Tuning

Memory tuning lets you instantly tune to a stored station. You can store up to 30 AM or FM frequencies in three different classes—10 frequencies in each class.

Follow these steps to store a station in a memory location.

1. Press **TUNER**. Then press **FM/AM** to select the desired band.
2. Using manual tuning, select the station you want to store.

If desired, press **FM MONO** for FM monaural sound (see “Using FM Mono” on Page 18). This setting is also stored in memory.

3. Press **MEMORY**. **MEMORY** appears for 5 seconds.
4. While **MEMORY** is on the display, press **CLASS** so the class number you want appears on the display, turn **MULTI JOG** to select the memory number you want, then press **ENTER** to store the frequency in that memory.

The class and memory number flash, then light steadily.

To tune to a stored station, press **SELECT** so **ST** appears on the **JOG MODE** display, then turn **MULTI JOG** until the desired frequency appears on the display. When you reach the last frequency in a class (frequency number 10 moving forward or number 1 moving in reverse), the receiver automatically moves to the next class of memory.

You can also use **◀ STATION ▶** on the remote control to select a station in memory. See “Using the Remote Control” on Page 23.

Notes:

- If you store a frequency in a memory that already contains a frequency, you replace the previous frequency.
- If your receiver is disconnected from AC power for several days, it loses all the stored frequencies.

Using FM Mono

To receive FM stations in stereo, press **FM MONO** so **MONO** disappears from the display. **STEREO** appears on the display when the tuner receives an FM broadcast in stereo.

You can improve the reception of weak FM stations by pressing **FM MONO** so **MONO** appears. This reduces noise while you listen to a weak FM station, but you get monaural instead of stereo sound.

Cassette Deck/VCR Features

You can connect two cassette decks to the receiver. Selecting either **VCR/TAPE 1** or **TAPE 2 MONITOR** lets you hear the playback from the cassette deck you connected to the receiver's corresponding (**VCR/TAPE 1** or **TAPE 2 MONITOR**) jacks.

Using the VCR/TAPE 1 and TAPE 2 Monitor Buttons

Press **VCR/TAPE 1**. **VCR** appears on the display. You hear the playback from the cassette deck or VCR you connected to the receiver's **VCR/TAPE 1** jacks.

Press **TAPE 2 MONITOR**. **TAPE 2** appears on the display along with the last program source you selected. You can hear playback or monitor a recording from the cassette deck you connected to the receiver's **TAPE 2 MONITOR** jacks.

The **TAPE 2 MONITOR REC** jacks continue to output sound from the previously selected source when you press **TAPE 2 MONITOR**.

To return to the previous source, press **TAPE 2 MONITOR** again so **TAPE 2** disappears.

Notes:

- If you press **TAPE 2 MONITOR** when the cassette deck is neither playing nor recording, the receiver mutes the current audio source. To hear the audio source, press **TAPE 2 MONITOR** so **TAPE 2** disappears from the display.
- Do not press **TAPE 2 MONITOR** while you are recording on the deck connected to **TAPE 2 MONITOR REC**. If you do, the recording is interrupted for about 1 second.

Recording a Program Source

The receiver sends the audio program source you select—**VCR/TAPE 1**, **TAPE 2 MONITOR**, **DVD/TV**, **LD/SAT**, **CD**, **TUNER**, or **PHONO**—to the **VCR/TAPE 1 OUT** (audio) and **TAPE 2 MONITOR REC** jacks.

The **VOLUME**, **BALANCE** and tone controls do not affect the signal going to the tape decks.

Dubbing a Cassette Tape

You can copy, or dub, a cassette tape from one cassette deck to another.

You can use either deck as the playback or recording deck. However, if you want to monitor the cassette deck during dubbing, use the deck connected to the **VCR/TAPE 1** jacks as the source, and the deck you connected to the **TAPE 2** jacks as the recording deck. Then press **TAPE 2 MONITOR** so **TAPE 2** appears on the display to hear the recording. See "Using the VCR/TAPE 1 and TAPE 2 Monitor Buttons."

Playing and Recording Video Tapes

You can connect two video sources to the receiver. If you connect a VCR to the **VCR/TAPE 1** audio and video jacks, you can copy video cassette tapes from one VCR to another and monitor the dubbing process.

Playing a Video Cassette Tape

To play a video tape, load the tape into the VCR connected to either **VCR/TAPE 1** or **LD/SAT**. Press the button (**VCR/TAPE 1** or **LD/SAT**) that corresponds to the jack the VCR is connected to. **VCR** or **LD/SAT** appears on the display. Follow the VCR's instructions to begin playback. If you connected a monitor to the receiver's **TO MONITOR TV** jack, you can view the program on that monitor.

Copying a Video Cassette Tape

Follow these steps to copy a video tape from one VCR to another.

1. Load the tape you want to copy into a VCR connected to **LD/SAT**.
2. Load a blank tape (or one you want to record over) into a VCR connected to the **VCR/TAPE 1** jacks.
3. Press **LD/SAT**.
4. Begin recording and playback on the VCRs.

Important: Most material performed in public, such as concerts, plays, and movies, or distributed on prerecorded video tapes is copyrighted. The unauthorized recording or duplication of copyrighted material is a violation of the copyright laws of most countries and such duplication may result in fines, imprisonment, or both. Note, however, that in the United States, it is not a violation of U.S. copyright laws for a consumer to record a broadcast television program for private (in-home) viewing.

Using Advanced Sound Options

Your receiver has three special sound options: Dolby Pro Logic Surround, SFC modes (studio and arena), and 5-D Theater. These special options enhance the sound you hear from a program source.

Notes:

- To get the full benefit from programs encoded with Dolby Surround Sound, you need a stereo VCR.
- Dolby Surround does not operate correctly if the signal passes through a graphic equalizer. If you connected an equalizer to the **TAPE 2 MONITOR** jacks, do not select **TAPE 2 MONITOR** when you listen to Dolby Surround signals.

To activate Dolby Pro Logic Surround, press **DOLBY PRO LOGIC**. For SFC effects or 5-D Theater, repeatedly press **SFC MODE** or **5-D THEATER** until the desired option appears on the display. For Dolby 3CH Logic, repeatedly press the remote control's **C. MODE** button until **3CHLOGIC** appears on the display.

Dolby Pro Logic Surround

Dolby Pro Logic Surround puts you in the middle of the action. The center- and rear-channel speakers add incredible realism by directing the sound to the appropriate speakers, making you feel like you are really there. You can find hundreds of movies, television shows, and compact discs produced with Dolby Surround.

Dolby 3CH Logic

Dolby 3CH Logic produces a more spacious sound field than is possible with ordinary stereo playback by combining the front and rear speaker sounds. Select this mode when you play a Dolby Surround Sound program and do not have rear speakers. The rear channel's sound is sent to the front left and right speakers.

Studio Effect

Studio Effect gives the effect of listening in a recording studio. The front speakers provide normal stereo, and the rear speakers provide a subtly reverberated sound. Select this mode when you listen to sources not encoded with Dolby Surround.

Arena Effect

Arena Effect is ideal for sources such as live performances. The front speakers output the music, and the rear speakers output the sounds and applause of the audience.

5-D Theater

5-D Theater provides clearer and more dynamic sound effects by outputting audio signals through the rear channel to simulate the stereo sound, compared with a standard surround system which provides only monaural signals to the rear speakers. Select **5-D PRO LOGIC** for the sources encoded with Dolby Pro Logic, and select **5-D Surround** for normal stereo sources.

Sound Mode Adjustments (Remote Control Only)

Note: If you do not use a center speaker, the monaural signals are reproduced only if you select **PHANTOM**.

Center Mode Setting

The center mode setting affects the center channel's bass signals. It operates only when you select Dolby Pro Logic Surround Sound. Slide **AUDIO/SURROUND** on the remote control to **SURROUND**. Each time you press **C. MODE** on the remote control, the setting changes, and the receiver displays: **NORMAL**, **WIDE**, **PHANTOM**, or **3CHLOGIC**.

NORMAL — Select this mode if you use a small center speaker. The front left and right speakers play the center-channel bass sounds.

WIDE — Select this mode if you use a medium or large center speaker. The center speaker plays the center-channel bass sounds.

PHANTOM — Select this mode if you have no center speaker. All center-channel sound comes from the front left and right speakers.

3CHLOGIC — Select this mode if you do not have rear speakers. The rear channel's sound is sent to the front left and right speakers.

Test Tone

The test tone feature provides a test tone that lets you balance the signal levels between all your speakers. See “Center Level” and “Rear Level.”

To activate the test tone, select one of the surround sound modes (except **PHANTOM**) and set **AUDIO/SURROUND** on the remote to **AUDIO**. Then press **TEST TONE**. The receiver sounds a 2-second tone from the front left, center, front right, and rear speakers, in sequence.

Notes:

- The center test tone does not sound if you select **PHANTOM** surround sound mode.
- In the Dolby 3CH Logic Sound mode, the receiver sounds a 2-second tone from the left, center, and right speakers, in sequence.

Press **TEST TONE** again to turn off this feature.

Center Level

Slide **AUDIO/SURROUND** to **AUDIO**. Then press – **CENTER LEVEL** + to adjust the center speaker sound level.

Rear Level

Slide **AUDIO/SURROUND** to **SURROUND**. Then press – **REAR** + to adjust the rear speakers' sound level.

Both **CENTER** and **REAR LEVEL** work only for the sound system that supports the center or rear speakers. For example, **REAR LEVEL** does not work for Dolby 3CH Logic.

Note: Use the **VOLUME** control to adjust the overall sound level.

Using the Remote Control

The remote control works up to a distance of about 23 feet, and within a 30-degree angle on either side of the receiver. Point the control at the receiver's front panel and press the desired button(s).

Many buttons on the remote control work the same as buttons on the receiver's front panel. Use these buttons exactly as you would use the corresponding buttons on the receiver.


AUDIO/SURROUND Switch

Some buttons on the remote control have two functions. Set the **AUDIO/SURROUND** switch to **AUDIO** to activate the function printed in green on the remote control's panel. Set the switch to **SURROUND** to use the function printed in gold.

For example, the button marked **C. MODE** and **TEST TONE** operates as the center mode adjust when you set the switch to **SURROUND** and as the test tone function when you set the switch to **AUDIO**.

Receiver/Amplifier Section

- + MASTER VOLUME -** Adjusts the system's volume. See Page 14.
- C. MODE** Selects among the four center mode settings with **AUDIO/SURROUND** set to **SURROUND**. See Page 21.
- TEST TONE** Sounds test tones from each speaker with **AUDIO/SURROUND** set to **AUDIO**. See Page 21.
- CENTER +** Controls the relative volume of the center speaker with **AUDIO/SURROUND** set to **AUDIO**. See Page 21.
- REAR +** Controls the relative volume of the rear speakers with **AUDIO/SURROUND** set to **SURROUND**. See Page 21.
- SFC MODE** Selects between Studio Effect or Arena Effect, or turns the SFC mode off. See Page 20.
- 5-D THEATER** Selects between 5-D Pro Logic or 5-D Surround, or turns the 5-D function off. See Page 20.
- PRO LOGIC** Turns the Dolby Pro Logic Surround on and off. See Page 20.
- LOUD.** Boosts/cuts high and low frequency sounds at low listening levels. See Page 15.
- TAPE 2 MONITOR** Switches the receiver to monitor the source connected to the **TAPE 2 MONITOR** jacks. See Page 18.
- FUNCTION** Selects a program source (VCR/Tape 1, DVD/TV, LD/SAT, CD, tuner, or phono). Repeatedly press **FUNCTION** until the display shows your desired program source. See Page 14.
- RECEIVER POWER** Turns the receiver on and off. See Page 14.
- MUTING** Silences the receiver. Press again to restore the sound to its previous level. See Page 15.
- CLASS** Selects the receiver's memory class with **AUDIO/SURROUND** set to **AUDIO**. See Page 16.
- FM MONO** Selects the FM reception mode with **AUDIO/SURROUND** set to **AUDIO**. See Page 17.
- ◀ STATION ▶** Press to tune to the next higher or lower memory location with **AUDIO/SURROUND** set to **AUDIO**. See Page 16.



CD Player Section

Before operation:

- Press **CD** to select the CD player operation.
- Set **AUDIO/SURROUND** to **AUDIO**.
- You must connect the CD player to both your receiver's **CONTROL OUT** and audio jacks for these functions to work.

CD POWER

Turns the CD player on and off (only for CD players that have the **CONTROL IN/OUT** feature).

|◀ and ▶|

Returns to the beginning of the current track/chapter or advances to the next track/chapter.

◀ DISC ▶

Selects discs in a multi-play CD changer.

Note: ◀ DISC ▶ does not work with all CD players.

▶

Starts playback.

■

Stops playback.

||

Pauses playback.

RANDOM

Plays the tracks on a CD in random order.

BEST

Selects your favorite programs. During play of your favorite program, press **BEST**. The unit memorizes the track number then plays only the memorized tracks later.

Tape Section

Before operation:

- Select the desired equipment (**VCR/TAPE 1** or **TAPE 2 MONITOR**).
- Set **AUDIO/SURROUND** to **AUDIO**.
- For a dual cassette deck, select **DECK 1** or **DECK 2**. If you use a single cassette deck, press **DECK 2**.
- You must connect the tape deck/player to both your receiver's **CONTROL OUT** and audio jacks for these functions to work.

▶

Press to start normal play.

◀

Press to play the reverse side of an auto-reverse cassette deck.

||

Pauses playback.

■

Stops playback.

◀◀ and ▶▶


Lets you rapidly scan a tape/CD either forward or backward.

DECK 1/DECK 2

Selects Deck 1 or Deck 2 when you use a dual cassette deck with **AUDIO/VCR** set to **AUDIO**.

TAPE POWER

Turns the connected cassette deck on and off.



Troubleshooting

If the receiver is not working as it should, the following suggestions might help. If you follow the suggestions in this chart and the receiver still does not work properly, contact your local RadioShack store for assistance.

Problem	Cause	Solution
Power does not turn on.	Power cord is disconnected.	Plug in the power cord.
	Protection circuit is activated.	Unplug the power cord, then plug it in again.
The receiver does not respond to button presses.	Static discharge has affected control.	Unplug the power cord, then plug it in again. (If static electricity is a problem, use the remote control whenever possible.)
No sound.	Incorrect connections.	Check and correct the connections.
	The mute function is activated.	Press MUTING .
	The volume is turned down.	Turn up the volume.
	Speaker wires are disconnected.	Connect the speaker wires.
	Neither set of speakers is selected.	Press in SPEAKERS A or B .
	Tape 2 monitor function is engaged.	Press TAPE 2 MONITOR so TAPE 2 disappears from the display.
No picture when you select a video source.	The selected video source is not set correctly.	Correct the problem with the selected video source.
	Incorrect connections.	Correct the connections.
High noise level.	Station not correctly tuned.	Tune to a stronger station.
	Antenna not connected.	Connect the antenna.
	FM antenna still coiled or is not pointing in the correct direction.	Stretch both ends of the antenna taut and reposition the antenna.
	AM loop antenna not pointing in the correct direction.	Adjust the AM loop antenna.
	Noise is coming from another electrical appliance.	Try using an AC line noise filter to reduce the noise.
Cannot make copies of video tapes.	Tapes are protected by a copy restriction method.	You cannot make a usable copy.
	Video connections are incorrect.	Check and correct the connections.
Remote does not control cassette deck or CD player.	Cassette deck or CD player not compatible.	This feature works only with Optimus Professional Series components.
	Control cable is not plugged in.	Properly connect the control cable.
	Audio cables are not plugged in.	Properly connect the audio cables.

Returning Controls to Factory Defaults

Press **RETURN** on the receiver to return the controls to the following settings.

Tape 2 Monitor	Off
Source	TUNER
Speakers A	On
Band	FM or AM (Set to the last-tuned frequency. If the receiver cannot receive the frequency, it starts searching for the next strong station.)
Surround Mode	Off
Loudness	Off
Muting	Off

Care and Maintenance

Your STAV-3680 Audio/Video Receiver is an example of superior design and craftsmanship. The following suggestions will help you care for the receiver so you can enjoy it for years.



Keep the receiver dry. If it gets wet, wipe it dry immediately. Liquids can contain minerals that can corrode the electronic circuits.



Handle the receiver gently and carefully. Dropping it can damage its circuit boards and can cause the receiver to work improperly.



Use and store the receiver only in normal temperature environments. Temperature extremes can shorten the life of electronic devices, damage batteries, and distort or melt plastic parts.



Keep the receiver away from dust and dirt, which can cause premature wear of parts.



Wipe the receiver with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the receiver.



Use only fresh batteries of the recommended size and type in the remote control. Always remove old or weak batteries. They can leak chemicals that can destroy electronic circuits.

Modifying or tampering with your receiver's internal components can cause a malfunction and might invalidate the receiver's warranty and void your FCC authorization to operate it. If the receiver is not operating as it should, take it to your local RadioShack store for assistance.

The FCC Wants You to Know

Your receiver might cause radio or TV interference even when it is operating properly. To determine whether your receiver is causing the interference, turn off your receiver. If the interference goes away, your receiver is causing it. Try to eliminate the interference by:

- Moving your radio or TV away from the receiver
- Connecting your receiver to an outlet that is on a different electrical circuit from the radio or TV
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using your receiver.

Specifications

Amplifier

Front Channel Average Power Output	100 Watts per Channel into 8 Ohms From 20 to 20,000 Hz, With No More than 0.09% Total Harmonic Distortion Measured Pursuant to the Federal Trade Commission's Trade Regulation Rule on Amplifier Output Power Claims
Front Channel Surround Power Output	100 Watts per Channel
Center Channel Surround Power Output	100 Watts
Continuous Rear Surround Power Output	100 Watts per Channel (1 kHz, 0.8% THD, 8 Ohms)
Input Sensitivity/Impedance	
Phono	2.8 mV/47 kOhms
CD, LD, VCR/TAPE 1, Tape 2 Monitor	200 mV/47 kOhms
Phono Overload Level (0.1% THD, 1 kHz)	100 mV
Frequency Response	
Phono	20 Hz to 20,000 Hz ± 0.3 dB
CD, LD, VCR/TAPE 1, TAPE 2 Monitor	5 Hz to 100,000 Hz $+0/-3$ dB
Output Level/Impedance	
VCR/TAPE 1 REC, Tape 2 Monitor REC	200 mV/2.2 kOhms
Tone Controls	
Bass	± 9 dB (100 Hz)
Treble	± 9 dB (10 kHz)
Loudness	+8 dB/+6 dB (100 Hz/10 kHz)
Signal-to-Noise Ratio (IHF, Short Circuited, A Network)	
Phono	72 dB
CD, LD, VCR/TAPE 1, Tape 2 Monitor	96 dB
Signal-to-Noise Ratio (EIA, at 1 Watt, 1 kHz)	
Phono	75 dB
CD, LD, VCR/TAPE 1, Tape 2 Monitor	79 dB

Video Section

Input Sensitivity/Impedance VCR/TAPE 1, LD	1 Volt Peak-to-Peak/75 Ohms
Output Level/Impedance VCR/TAPE 1, Monitor	1 Volt Peak-to-Peak/75 Ohms
Frequency Response VCR /TAPE 1, LD Monitor	5 Hz to 7MHz $+0/-3$ dB
Signal-to-Noise Ratio	55 dB
Crosstalk	55 dB

FM Tuner

Frequency Range	87.5 to 108 MHz
Usable Sensitivity	Mono: 11.2 dBf, IHF (1.0 μ V/75 Ohms)
50 dB Quieting Sensitivity	
Mono	16.8 dBf (1.9 μ V/75 Ohms)
Stereo	38.6 dBf (23.3 μ V/75 Ohms)
Signal-to-Noise Ratio	
Mono	73 dB (at 85 dBf)
Stereo	70 dB (at 85 dBf)
Distortion Stereo	0.5% (1 kHz)
Alternate Channel Selectivity	60 dB (400 kHz)
Stereo Separation	40 dB (1 kHz)
Frequency Response	30 Hz to 15 kHz (\pm 1 dB)
Antenna Input	75 Ohms Unbalanced

AM Tuner

Frequency Range	530 to 1700 kHz
Sensitivity (IHF, Loop Antenna)	350 μ V/m
Selectivity	25 dB
Signal-to-Noise Ratio	50 dB

General

Power Requirements	120 Volts AC, 60 Hz
Power Consumption	260 Watts, 360 VA (UL)
AC Outlet Ratings Switched	Total 100 Watts (0.8 Amps) Maximum
Dimensions (HWD)	6 $\frac{1}{8}$ \times 16 $\frac{9}{16}$ \times 14 $\frac{3}{4}$ Inches (155 \times 420 \times 374 mm)
Weight	20 lb 1 oz (9.1 kg)

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

Index to Features by Control Name

This table lists the control and indicator names found on the front of your receiver, along with the page number where the control or indicator is discussed. To find a description for the buttons on the remote control, see “Using the Remote Control” on Page 23.

Control	See Page
5-D THEATER	21
BALANCE	16
BASS	15
CD	15
CLASS	17
DOLBY PRO LOGIC	21
DVD/TV	15
FM/AM	17
FM MONO	18
LD/SAT	15
LOUDNESS	16
MEMORY	17
MULTI JOG	17
PHONES	16
PHONO	15
POWER	15
RETURN	25
SELECT	17
SFC MODE	21
SPEAKERS A and B	15
TAPE 2 MONITOR	15, 19
TREBLE	15
TUNER	16
TUNING	17, 24
VCR/TAPE 1	15, 19
MASTER VOLUME	15

Limited Two-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for two (2) years from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W, 100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102