


# Miele

## Operating instructions



Inspira Series  
G 1150  
G 2140

Diamante  
G 2150

To prevent accidents  
and machine damage  
read these instructions  
**before**  
installation or use.

**HG03**

USA CDN

M.-Nr. 06 696 010

# Contents

---

|                                        |    |
|----------------------------------------|----|
| <b>IMPORTANT SAFETY INSTRUCTIONS</b>   | 4  |
| <b>Guide to the dishwasher</b>         | 7  |
| Control panel                          | 8  |
| <b>Caring for the environment</b>      | 9  |
| <b>Before using for the first time</b> | 10 |
| To open the door                       | 10 |
| To close the door                      | 10 |
| Child Safety Lock                      | 10 |
| Rinse aid                              | 11 |
| Adding rinse aid                       | 11 |
| Rinse aid indicator                    | 12 |
| Adjusting the dosage                   | 12 |
| <b>Loading the dishwasher</b>          | 14 |
| Items not recommended for dishwashing  | 15 |
| Cutlery tray                           | 16 |
| Cutlery basket                         | 17 |
| Upper basket                           | 18 |
| Adjusting the upper basket             | 19 |
| Lower basket                           | 20 |
| <b>Basket accessories</b>              | 22 |
| <b>Use</b>                             | 23 |
| Adding detergent                       | 24 |
| Turning on                             | 25 |
| Selecting a program                    | 25 |
| Starting a program                     | 25 |
| Program sequence display               | 25 |
| <b>Program guide</b>                   | 26 |
| <b>Use</b>                             | 27 |
| At the end of a program                | 27 |
| Interrupting a program                 | 27 |
| Changing a program                     | 27 |
| <b>Additional functions</b>            | 28 |

|                                              |    |
|----------------------------------------------|----|
| <b>Frequently asked questions</b>            | 29 |
| Technical faults                             | 29 |
| Problems water intake/drain                  | 30 |
| General problems with the dishwasher         | 31 |
| Sounds                                       | 32 |
| Poor cleaning results                        | 33 |
| <b>After sales service</b>                   | 36 |
| <b>Transport</b>                             | 37 |
| <b>User Maintenance Instructions</b>         | 39 |
| <b>Cleaning and Care</b>                     | 40 |
| Triple filter system                         | 41 |
| Cleaning the spray arms                      | 43 |
| Cleaning the water inlet filter              | 44 |
| Cleaning the drain pump and non-return valve | 45 |
| <b>Installation instructions</b>             | 47 |
| <b>Help to protect the environment</b>       | 48 |
| <b>Electrical connection</b>                 | 49 |
| <b>Plumbing</b>                              | 50 |
| Connection to the water supply               | 50 |
| Drainage                                     | 51 |

# IMPORTANT SAFETY INSTRUCTIONS

---

## WARNING –

**When using your dishwasher, follow basic precautions, including the following:**

**Read all instructions before installation or use of the dishwasher to prevent injury and machine damage.**

The manufacturer cannot be held responsible for damage or injury caused by improper use of this appliance.

Use the dishwasher only for its intended purpose. This appliance is intended for residential use only.

Keep these operating instructions in a safe place and pass them on to any future user.

## Electrical Safety

Before installation, make sure that the voltage and frequency listed on the data plate correspond with the household electrical supply. This data must correspond to prevent injury and machine damage. Consult a qualified electrician if in doubt.

Before installation or service, disconnect the power supply to the work area by unplugging the unit, "tripping" the circuit breaker or removing the fuse.

Do not use an extension cord to connect this appliance to electricity. Extension cords do not guarantee the required safety of the appliance (e.g. danger of overheating).

Be certain your appliance is properly installed and grounded by a qualified technician. To guarantee the electrical safety of this appliance continuity must exist between the appliance and an effective grounding system. It is imperative that this basic safety requirement be met. If there is any doubt, have the electrical system of the house checked by a qualified electrician. The manufacturer cannot be held responsible for damages caused by the lack, or inadequacy, of an effective grounding system.

# IMPORTANT SAFETY INSTRUCTIONS

## Installation

 The dishwasher must be installed and connected in compliance with the installation instructions.

 Installation and repair work should be performed by a Miele authorized service technician. Work by unqualified persons could be dangerous and may void the warranty.

 Do not install or use a damaged dishwasher. A damaged appliance is dangerous. Unplug the machine and call your Miele dealer or the Miele Technical Service Department.

 Ensure that any plastic wrappings, bags, etc. are disposed of safely and kept out of the reach of children. Danger of suffocation!

 This equipment is not designed for maritime use or for use in mobile installations such as recreational vehicles or aircraft. However, under certain conditions it may be possible for an installation in these applications. Please contact the nearest Miele dealer or the Miele Technical Service Department with specific requirements.

 It is recommended that the dishwasher only be connected to the mains with the plug (no hard-wiring). The outlet must be accessible at all times after installation to disconnect the dishwasher.

  **WARNING - Fire hazard**  
Do not cover or crush the plug of the appliance. Ensure that the cabinet opening for the dishwasher provides ample space for the plug. Installing the dishwasher in a tight space may crimp the power cord or put pressure on the plug which could cause overheating.

 This dishwasher should only be installed under a continuous counter top secured to adjacent cabinetry.

 Do not install this dishwasher beneath a cooking surface, oven or any appliance that radiates heat. High temperatures from these units may damage the dishwasher.

 When installing the dishwasher under a counter top and removing the toekick, a build-under toekick must be installed. Use the respective installation kit. Danger of injuries.

 Do not cut the intake hose or submerge it in liquid. This hose contains electrical components that could cause injury or property damage if cut or submerged.

 Only connect the dishwasher to the mains when all installation and plumbing work is complete.

# IMPORTANT SAFETY INSTRUCTIONS

---

## Use

 To reduce the risk of injury, do not allow children to play in, on or near the dishwasher.

 Only use the dishwasher if all panels are properly in place.

 Do not tamper with the controls.

 Do not damage, sit or stand on the door or baskets of the dishwasher. Close the door when not in use.

 Under certain conditions, hydrogen gas may be produced in a hot water system that has not been used for two weeks or more. **HYDROGEN GAS IS EXPLOSIVE.** If the hot water system has not been used for such a period, turn on all hot water faucets and let water flow from each for several minutes before using the dishwasher. This will release any accumulated hydrogen gas. Do not smoke or use an open flame during this time.

 Be sure that all items placed in the dishwasher are "dishwasher safe". For items not labeled, check the manufacturer's recommendations.

 When loading tableware, place sharp items away from the door to prevent damage to the seal. Load sharp items pointing downwards to prevent injuries.

 Only use detergents and rinse aids recommended for residential dishwashers. Keep all detergents and rinse aids out of the reach of children.

 Do not inhale or swallow detergents. Dishwasher detergents contain irritant and corrosive ingredients. They can cause burning in the mouth and throat if swallowed, or inhibit breathing. Consult a doctor immediately if detergent has been swallowed or inhaled.

 Do not drink water from the dishwasher! Harmful residues could be present.

 Do not fill the rinse aid reservoir or salt container with detergent. It will destroy the rinse aid compartment and water softener.

 If the power cord is damaged it must only be replaced by a Miele Service technician with a genuine Miele power cord.

## Disposal of an appliance

 If the appliance is removed from its installation site and will not be used, remove the doorlock to the wash cabinet to prevent children from locking themselves in the machine.


## SAVE THESE INSTRUCTIONS

## Guide to the dishwasher

- ① Upper spray arm (not visible)
- ② Cutlery tray (depending on model)
- ③ Upper basket
- ④ Middle spray arm
- ⑤ Air inlet for drying (depending on model)
- ⑥ Lower spray arm
- ⑦ Filter combination
- ⑧ Data plate
- ⑨ Child Safety Lock in the door handle (not visible)
- ⑩ Rinse aid reservoir
- ⑪ Dual compartment detergent dispenser

# Guide to the dishwasher

## Control panel



① Program selection

② Program button

③ Start/Stop button with indicator

④ Check / Refill indicators

⑤ Program cycle indicators

⑥ ① button (On/Off button)



### Energy saving washing


This dishwasher is exceptionally economical in the use of water and electricity. For best results follow these tips:

- For lowest energy consumption and the gentlest washing of china and crystal, connect the dishwasher to a cold water source.
- For fastest possible wash times, yet higher energy consumption, connect the dishwasher to a hot water source.
- Make full use of the baskets without overloading for the most economical washing.
- Use the correct amount of detergent and rinse aid.
- When using powder or gel detergent, reduce the amount to  $\frac{2}{3}$  of the normal amount when washing a small load.
- Choose a program that best suits the degree of soiling and the type of dishes being washed.
- For small loads select "Short".

## Before using for the first time

---

### To open the door




- Press the release catch inside the door grip.

If the door is opened during operation, the dishwasher will stop running. Once the door is closed the program will restart.

### To close the door

- Push the baskets in.
- Lift the door and push until it clicks into place.

### Child Safety Lock



The Child Safety Lock is designed to prevent children from opening the dishwasher.

- To lock the door, push the slider below the door grip to the right.
- To unlock the door, push the slider to the left.

## Before using for the first time


### Rinse aid

Rinse aid is needed to prevent spotting on dishes and glassware.

The rinse aid is filled in the reservoir and the set amount will be automatically dosed.

⚠ Filling the rinse aid reservoir with detergent will damage the reservoir. Only pour rinse aid formulated for residential dishwashers into the reservoir.

When using "2 in 1" detergents rinse aid is not needed.




- Pour liquid rinse aid into the reservoir until it is visible on the surface of the screen.

The rinse aid reservoir holds approx. 3.7 oz (110 ml).

- Press on the flap until you hear it click shut. Failure to close it all the way allows water to enter the reservoir during the wash program.
- Clean any spilled rinse aid. The flap will remain closed during normal operation.

### Adding rinse aid




- Press the button in the direction of the arrow until the flap springs open.

# Before using for the first time

---

## Rinse aid indicator

When the Rinse aid indicator first comes on, there will be enough rinse aid left for 2 - 3 washes.



## Adjusting the dosage

The dosage selector is preset to 3. This dispenses approximately 3 ml of rinse aid per program. It can be adjusted from 1 to 6.

- Use a higher setting if spots appear on dry glassware.
- Use a lower setting if streaking appears on dishes or glasses.
- Turn the dishwasher off "①".
- Press the "Start/Stop" button and at the same time turn the dishwasher on "①". Hold the "Start/Stop" button until the "Start/Stop" indicator comes on.

If it doesn't come on, start over.

- The rinse aid indicator on the control panel will light when the rinse aid reservoir needs refilling.

## Before using for the first time

---

- Press the program button three times.

The lowest program indicator flashes three times in intervals.

The "Rinse" indicator flashes three times in intervals.

A rinse aid amount of 3 ml is set by default.

The amount set can be recognized by the flashing rhythm of the "Rinse" indicator (see table).

| Rinse aid amount in ml | Flashing rhythm    |
|------------------------|--------------------|
| 0                      | —                  |
| 1                      | Once               |
| 2                      | Twice              |
| <b>3</b>               | <b>Three times</b> |
| 4                      | Four times         |
| 5                      | Five times         |
| 6                      | Six times          |

- Select the desired setting with the "Start/Stop" button. Every touch of the button increases the level.

The programmed dosage is saved.

- Turn the dishwasher off "①".

# Loading the dishwasher

---



Do not wash items soiled with ash, sand, wax, grease or paint in the dishwasher.

Ash and sand do not dissolve and will be distributed throughout the inside of the dishwasher.

Wax, grease and paint will cause permanent discoloration and damage to the dishwasher.

- Scrape food from dishes before placing them in the dishwasher, rinsing is not necessary.
- Some foods contain natural dyes, e.g. carrots or tomatoes. Plastic items may discolor permanently if they come in contact with food dyes.
- All items can be placed anywhere in the baskets.
- Load dishes so that water can reach all surfaces. Do not place dishes or cutlery inside other pieces.
- Make sure that all items are securely positioned.
- Hollow items such as cups and glasses should be placed upside down in the baskets.
- To ensure good water coverage, tall, narrow and hollow items, i.e. vases or champagne glasses, should be placed in the center of the basket rather than in the corners.
- Concave based items such as mugs or bowls, should be placed at an angle so that water does not pool.
- The spray arms must not be blocked by items that are too tall or hang through the baskets. Check clearance by manually rotating the spray arms.
- Place very small items in the cutlery tray or basket so they do not fall to the bottom of the wash cabinet.
- Food residue and spilled liquids should be cleaned from the sides of the dishwasher door. These are outside of the wash cabinet and are not cleaned by water from the spray arms.

## Items not recommended for dishwashing

- Cutlery with wooden handles
- Wooden cutting boards
- Glued items such as old knives with handles glued together around the shank of the blade
- Handmade craft items, antique, metal trimmed or decorative glassware
- Plastic items that are not heat resistant
- Copper, brass, tin or aluminum
- Dishes with color painted over the glaze. These dishes may fade over time
- Fine glassware and crystal items should only be washed using the "China & Crystal" program\*. Otherwise clouding or etching may occur after frequent washing.
- Cast iron pots and pans

\* depending on model

## Glassware:

- There are no standard guidelines for washing glassware, when in doubt wash by hand.
- When purchasing new dishes, glasses and cutlery, make sure they are dishwasher safe. Only wash items marked "dishwasher safe" in the dishwasher.
- If fine glassware is washed in the dishwasher select the "China & Crystal" program\*. This will reduce the risk of clouding.


## Silver and aluminum:

- Silver or aluminum items may tarnish.
- Silverware previously cleaned with a silver polish may be damp or spotted at the end of a program where water has adhered to the polish. This can be rubbed off with a soft, dry cloth. Silver that has been cleaned in an immersion dip is usually dry at the end of a program, but may tarnish.
- If left to dry, foods containing sulfur can discolor silver. These include egg yolk, onions, mayonnaise, mustard, fish and marinades.
- Silverware may tarnish or pit if washed next to stainless steel. Leave space between these metals.
- Clean aluminum items, e.g. grease filters, with domestic dishwasher detergent only.

# Loading the dishwasher

## Cutlery tray

(depending on model)




- Arrange the cutlery as shown in the cutlery tray.

For easier unloading cutlery should be grouped in zones, one for knives, one for forks, one for spoons, etc.

Place knives with the cutting edge down and forks with the prongs between the holders. Spoons should be placed in the opposite direction with the handles between the holders.

The upper spray arm must not be blocked by tall cutlery items.

The cutlery tray insert is removable.




Spoons with thick handles may have to be placed as knives and forks with their heads in the holders



# Loading the dishwasher


## Cutlery basket

(depending on model)




- For best cleaning results, cutlery should be placed in the basket with the handles down. Knives and forks should be loaded with the pointed end down to prevent injuries.
- Place small spoons in the individual slots to either side of the cutlery basket.

## Spoon inserts for the cutlery basket



The supplied insert is designed to wash heavily soiled spoons. The individual slots allow the water to better reach the surface of each spoon.

- Attach the insert when needed to the cutlery basket.




- Insert the cutlery with the handles down into the insert. Arrange the cutlery evenly.

# Loading the dishwasher

## Upper basket

 Always use the dishwasher with the upper and lower basket inserted.




## Cup racks

- Raise the rack to make room for tall glasses. Lower it to double stack smaller pieces.

## Coffee bar

(depending on model)

Glasses can be leaned against the coffee bar for a secure stand.



- The bar can also be used to separate two rows of glasses.


To stack wide items, flip the bar to the right.

### Adjusting the upper basket

The upper basket can be raised or lowered to accommodate tall items.

The basket can also be angled to fit tall items in both, the upper and lower baskets. The angles should not be set to opposite extremes. This will block the middle spray arm. Take care when sliding the basket in and out in this position.

- Slide out the upper basket.



- Pull up the levers at the sides of the upper basket and adjust the basket height.
- Release the levers and the basket will lock in place.

Depending on the setting of the upper basket, a variety of plate dimensions can be accommodated.


For example: If the upper basket is in its highest position a plate with a diameter of  $12 \frac{3}{16}$ " (31 cm) can be fit in the lower basket.

# Loading the dishwasher


## Lower basket

- For larger and heavier items such as plates, serving platters, saucepans, bowls, etc.

## Dishwashers with cutlery tray




## Dishwashers with cutlery basket



## Foldable spikes

Two rows of spikes can be folded down, to create more room for larger dishware, e.g. pots, pans and bowls.




- Lift the spike rows and fold them down on one another.

## Vase/Bottle holder

(depending on model)

The vase/bottle holder, e.g. for vases and baby bottles, can be inserted into the lower basket as shown in the illustration.



If placed anywhere else, water will not reach all surfaces. The bottle will not be properly cleaned.

## Basket accessories

---

Additional inserts for the upper and lower baskets may be purchased from your Miele dealer or Miele. Depending on the model some accessories come standard with the machine.

Glassware insert GGO

To wash long stemmed glassware  
attaches to the upper basket

---

Vase / Bottle holder GF

To wash baby bottles or vases

---

Cappuccinatore insert GCEO

To wash the parts of the  
Cappuccinatore

## Detergent

 Dishwasher detergents contain irritant and corrosive ingredients. Avoid inhaling or swallowing dishwasher detergent. Keep children away from detergent. Fill the detergent dispenser only when you are ready to start the dishwasher.


 Only use detergents formulated for domestic dishwashers.

Use only the recommended amount of detergent. Continued use of too much detergent may cause machine damage.

You can use powder, gel or tab detergents. Follow the dosage information on the detergent packaging.


Detergent tabs are not recommended for use with the program "Short". The tabs may not dissolve completely.

## Adding detergent



- To open, press the latch on the detergent dispenser. The flap will spring open.

The flap is always open at the end of a program.



- Add detergent to compartment II and close the flap.
- If a Pre-rinse is desired, and available for your chosen program, add 1 teaspoon (5 ml) of detergent to compartment I.

The horizontal marks in compartment II indicate the levels of approximately 1 ¼ and 2 tablespoons (20 and 30 ml) respectively. Compartment I holds a maximum of 2 teaspoons (10 ml).



## Turning on

- Make sure the spray arms can rotate freely.
- Close the door.
- Open the water supply, if it is closed.
- Turn the dishwasher on ①.

The "Start/Stop" indicator flashes and the indicator of the last set program lights.

## Selecting a program

Choose your program according to the type of load and soiling.

The "Program guide" describes the programs and use.

## Starting a program

- Select the desired program with the program selector button.

The indicator of the selected program lights.

- Press the "Start/Stop" button.

The program starts. The indicators "Start/Stop", "Rinse" and the last selected program light.

Cancel a program only in the first 5 minutes. Otherwise important program steps (e.g. the water softening) may be interrupted.

## Program sequence display

After a program has been started the current stage of the program is indicated by the program cycle indicator.

# Program guide

| Program      | When to use                                                                                                                                   | Program sequence |   |           |               |             |        |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------|------------------|---|-----------|---------------|-------------|--------|
|              |                                                                                                                                               | Pre-rinse        |   | Main wash | Interim rinse | Final rinse | Drying |
|              |                                                                                                                                               | 1                | 2 |           | 1             | 2           |        |
| Pots & Pans  | For <b>normally soiled pots and pans</b> with <b>dried on food</b> , also for heavily soiled dishware, use 120% of normal detergent dose      |                  | x | x         | x             | x           | x      |
| Normal       | For <b>normally soiled dishware</b>                                                                                                           | x                | x | x         | x             | x           | x      |
| Economy      | For <b>normally soiled</b> dishware, energy saving program with a long soaking time and a low temperature                                     |                  |   | x         | x             | x           | x      |
| SaniWash     | Extended wash time, for <b>sanitizing normally soiled dishware with dried on food</b>                                                         |                  |   | x         | x             | x           | x      |
| Short        | "Quick program" for <b>lightly soiled</b> dishware, e.g. party dishware includes sensor controlled Glasscare, not suitable for detergent tabs |                  |   | x         | x             | x           |        |
| Rinse & Hold | To <b>rinse dishes when a complete program is not needed</b><br>detergent is not recommended                                                  |                  | x |           |               |             |        |

## Usage:

Electric: 0.01 - 1.23 kWh

Water: 1.3 - 6.3 gal (5 - 24 l)

## At the end of a program

When the program has finished the "End" indicator lights.

Dishes tends to chip if removed still hot from the dishwasher.

- Let the dishware cool by opening the door slightly.

The dishes will cool much faster.

- Open the dishwasher and unload the dishes.
- Turn the dishwasher off ①.

The dishwasher continues to use electricity until turned off with the ① button.

- If the dishwasher is not used for a longer period of time, e.g. vacationing, turn off the water supply.

## Interrupting a program

A program is interrupted as soon as the door is opened. If the door is closed, the program will continue from where it was interrupted.

 Open the door with care. The water in the dishwasher is hot. Danger of scalding. Before closing the door again, leave it ajar for approx. 20 secs. This will enable the temperature in the wash cabinet to settle. Close the door firmly until it clicks into place.

## Changing a program

If the detergent flap is already open do not change the program.

If a program has already started and you wish to change it:

- Press the "Start/Stop" button for at least one second.

The program is cancelled. The "Start/Stop" indicator lights.

- Select and start the desired program.

## Additional functions

---

### Factory default

All settings can be reset to the factory default.

- Turn the dishwasher off ①.
- Press the "Start/Stop" button and at the same time turn the dishwasher on ①. Hold the "Start/Stop" button until the "Start/Stop" indicator comes on.

If it does not come on, start over.

- Press the program button 12 times.

The bottom program indicator flashes once long and twice short in intervals.

The "Rinse" indicator shows if a setting was changed.

- The "Rinse" indicator flashes:  
All settings are the factory default.
- The "Rinse" indicator is off:  
At least one setting was changed.
- To reset the dishwasher to the default settings, press the "Start/Stop" button.
- Turn the dishwasher off ①.

## Frequently asked questions

With the aid of the following guide, minor problems can be fixed without a service call.

 Repairs should only be carried out by a qualified and trained person in accordance with local and national safety regulations. Unauthorized repairs could cause personal injury or machine damage.

| Technical faults                                                                         |                                      |                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Issue                                                                                    | Possible fault                       | Solution                                                                                                                                                                                                                                                                                                                                           |
| <b>The Start/Stop indicator does not flash after the dishwasher is turned on with ①.</b> | The machine is not plugged in.       | Insert the plug.                                                                                                                                                                                                                                                                                                                                   |
|                                                                                          | The fuse has tripped.                | Reset the circuit breaker. Make sure it is a 15 A breaker.                                                                                                                                                                                                                                                                                         |
| <b>The dishwasher stops during a program.</b>                                            | The fuse has tripped.                | Reset the circuit breaker. Make sure it is a 15 A breaker.                                                                                                                                                                                                                                                                                         |
| <b>The program cycle indicators "Rinse", "Drying" and "End" flash at the same time.</b>  | There may be a technical fault.      | <ul style="list-style-type: none"> <li>– Turn the dishwasher off ①.</li> </ul> After a few seconds: <ul style="list-style-type: none"> <li>– Turn the dishwasher on.</li> <li>– Select the desired program with the program selector button.</li> <li>– Press the "Start/Stop" button.</li> </ul> If the problem persists, call Technical Service. |
| <b>The drain pump is running when the door is open.</b>                                  | The waterproof system has activated. | <ul style="list-style-type: none"> <li>– Turn off the water supply.</li> <li>– Call Miele Technical Service.</li> </ul>                                                                                                                                                                                                                            |

## Frequently asked questions

| Problems water intake/drain                                            |                                                                      |                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------|----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Issue                                                                  | Possible fault                                                       | Solution                                                                                                                                                                                                                                                                                                     |
| The "Intake/Drain" indicator flashes and lights alternately.           | The water supply is closed.                                          | Open the water supply all the way.                                                                                                                                                                                                                                                                           |
| The dishwasher stops running.<br>The "Intake/Drain" indicator flashes. |                                                                      | Before fixing the fault:<br>– Turn the dishwasher off ①.                                                                                                                                                                                                                                                     |
|                                                                        | Fault in the water intake.                                           | <ul style="list-style-type: none"> <li>– Open the water supply all the way.</li> <li>– Clean the water intake filter, see "User Maintenance Instructions".</li> <li>– The water pressure at the water connection is lower than 4.35 psi. Consult a plumber.</li> </ul>                                       |
|                                                                        | Fault in the water drain.<br>There may be water in the wash cabinet. | <ul style="list-style-type: none"> <li>– Clean the triple filter.</li> <li>– Clean the drain pump and the non-return valve.</li> </ul> <p>See "User Maintenance Instructions" for more information on the above.</p> <ul style="list-style-type: none"> <li>– Remove any kinks in the drain hose.</li> </ul> |

## Frequently asked questions

### General problems with the dishwasher

| Issue                                                                              | Possible fault                                                                | Solution                                                                     |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| <b>Detergent is left in the dispenser at the end of a program.</b>                 | The dispenser was damp when detergent was added.                              | Dry the dispenser before adding detergent.                                   |
| <b>The detergent lid cannot be closed properly.</b>                                | Detergent residue is blocking the catch.                                      | Remove the residue.                                                          |
| <b>The door and the interior walls are still wet after a program has finished.</b> | This is not a fault!<br>It is the normal operating mode of the drying system. | The moisture will evaporate after a short time.                              |
| <b>Water remains in the wash cabinet at the end of a program.</b>                  |                                                                               | Before fixing the fault:<br>– Turn the dishwasher off ①.                     |
|                                                                                    | The triple filter in the wash cabinet is clogged.                             | Clean the triple filter. See "User Maintenance Instructions".                |
|                                                                                    | The drain pump or the non-return valve may be blocked.                        | Clean the drain pump and the non-return valve, see maintenance instructions. |
|                                                                                    | The drain hose is kinked.                                                     | Remove any kinks from the drain hose.                                        |

## Frequently asked questions

---

| Sounds                                                |                                                                     |                                                                      |
|-------------------------------------------------------|---------------------------------------------------------------------|----------------------------------------------------------------------|
| Issue                                                 | Possible fault                                                      | Solution                                                             |
| <b>There is a knocking noise in the wash cabinet.</b> | The spray arm is hitting an item in the basket.                     | Interrupt the program, rearrange items blocking the spray arms.      |
| <b>There is a rattling noise in the wash cabinet.</b> | Items are not secure in the wash cabinet.                           | Interrupt the program and rearrange loose pieces.                    |
| <b>There is a knocking noise in the water pipes.</b>  | This may be caused by the installation or the diameter of the pipe. | This has no effect on the dishwasher. If in doubt contact a plumber. |



## Frequently asked questions

### Poor cleaning results

| Issue                                                                                                                        | Possible fault                                                                                                                 | Solution                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
| <b>The dishes are not clean.</b>                                                                                             | The dishes were not loaded correctly.                                                                                          | See "Loading the dishwasher".                                                                                  |
|                                                                                                                              | The program was not powerful enough.                                                                                           | Select a more intensive program, see "Program Guide".                                                          |
|                                                                                                                              | Not enough detergent was dispensed.                                                                                            | Use more detergent, see "Adding detergent".                                                                    |
|                                                                                                                              | The spray arms are blocked by items.                                                                                           | Turn the spray arm and rearrange the dishes if necessary.                                                      |
|                                                                                                                              | The triple filter in the base of the wash cabinet is not clean or not correctly inserted. The spray arm jets might be clogged. | Clean the filter and insert it correctly.<br>Clean the spray arm jets.<br>See "User Maintenance Instructions". |
|                                                                                                                              | The drain pump or the non-return valve is blocked. Wash water will run back into the wash cabinet.                             | Clean the drain pump and the non-return valve, see maintenance instructions.                                   |
| <b>Glasses and cutlery show streaks. There is a bluish sheen on the surface of glasses and a film that can be wiped off.</b> | The rinse aid dosage is set too high.                                                                                          | Reduce the dosage, see "Before using for the first time".                                                      |

## Frequently asked questions

| Issue                                                                                                          | Possible fault                                                             | Solution                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Dishes are still wet, glasses and cutlery are spotted.</b>                                                  | The rinse aid setting may be too low, or the rinse aid reservoir is empty. | Increase the dosage, refill the reservoir or switch the rinse aid product when refilling, see "Before using for the first time". |
|                                                                                                                | Dishes were taken out too soon.                                            | Leave dishes in longer, see "Use".                                                                                               |
|                                                                                                                | "2 in 1" products were used. These products have a low drying effect.      | Use powder detergent and add rinse aid.                                                                                          |
| <b>White residue is visible on cutlery and dishes. clouding occurs on glassware and film can be wiped off.</b> | Not enough rinse aid was used.                                             | Increase the dosage, see "Before using for the first time".                                                                      |
|                                                                                                                | Unsuitable "2 in 1" or "3 in 1" products were used.                        | Use a different detergent, normal tabs or normal powder detergent.                                                               |

## Frequently asked questions

| Issue                                                             | Possible fault                                                                                                | Solution                                                                 |
|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| <b>Glasses are discolored and the film cannot be wiped off.</b>   | Detergent ingredients have been deposited on the glassware.                                                   | Use a different detergent.                                               |
| <b>Glasses are dull and discolored, film cannot be wiped off.</b> | Glasses are not dishwasher safe.                                                                              | There is no remedy. Only wash dishwasher safe glasses in the dishwasher. |
| <b>Tea or lipstick stains have not been completely removed.</b>   | The wash temperature of the selected program was too low.                                                     | Select the "Economy" or "Sani Wash" program.                             |
|                                                                   | The detergent has a low bleaching effect.                                                                     | Use a different detergent.                                               |
| <b>Plastics are discolored.</b>                                   | Natural dyes e.g. from vegetables may be the cause. Not enough detergent was used to break down natural dyes. | Use more detergent, see "Adding detergent". Discoloration is permanent.  |
| <b>There are rust stains on cutlery.</b>                          | The affected items are not corrosion resistant.                                                               | There is no remedy. Only wash dishwasher safe cutlery in the dishwasher. |

## After sales service

---

### Repairs

In the event of a fault which you cannot correct yourself please contact the Miele Service Department at the phone number on the back of this booklet.

- Please quote the model type and number of your appliance.

These can be found on the data plate along the right edge of the door.

### PC Update

The Program Correction (PC) allows a technician to update the dishwasher to make use of new technology.

When, for example, technological developments offer advanced modifications to your existing program cycles a service technician will be able to input these into your machine controls via the indicator light marked PC. Miele will provide information when such possibilities become available.

### MieleCare

**MieleCare**, our Extended Service Contract program, gives you the assurance of knowing that your appliance investment is covered by 5 years of worry free ownership.

**MieleCare** is the only Extended Service Contract in the industry that guarantees repairs by a Miele Authorized Service Provider using genuine Miele parts. Only genuine Miele parts installed by factory trained professionals can guarantee the safety, reliability, and longevity of your Miele appliance.

Please note that unless expressly approved in writing by Miele's Service department, Extended Service Contracts offered by other providers for Miele products will not be recognized by Miele. Our goal is to prevent unauthorized (and untrained) service personnel from working on your Miele products, possibly doing further damage to them, you and/or your home.


To learn more about **MieleCare** Extended Service Contracts, please contact your appliance dealer or visit us online at:

**[www.store.miele.com](http://www.store.miele.com)**

To transport the dishwasher, e.g. when moving to a new home, note the following:

- Empty the dishwasher.
- Secure any loose parts, e.g. hoses, cables, cutlery baskets.
- Transport the dishwasher in the upright position. If unavoidable it may be transported on its back. Do not transport it on its side or on the door. Residual water in the machine could leak and cause electrical damage.





## User Maintenance Instructions

To prevent accidents  
and machine damage,  
read these instructions  
**before** installation or use.

# Cleaning and Care

---

Check and clean your dishwasher regularly (approx. every 4-6 months). This will help avoid problems and faults.

 Abrasive cleaning agents, glass cleaning agents, all-purpose cleaners, thinner or ammonium cleaners should not be used on the dishwasher. They **will** damage the surface.

## Wash cabinet

Generally, the wash cabinet is self cleaning if the correct amount of detergent is used.

The wash cabinet can be cleaned with a dishwasher cleaner such as "Dis Cleaner" available from your Miele dealer, Miele or online at [www.store.miele.com](http://www.store.miele.com).

## Door and the door seal

- Wipe the door seals regularly with a damp cloth to remove food deposits.
- Food residue and spilled liquids should be wiped from the sides of the dishwasher door. These are outside of the wash cabinet and are not cleaned by water from the spray arms.

## Exterior

- Only use a conditioner suitable for your kitchen cabinetry.
- Clean wood only with a damp cloth and wipe dry.
- Stainless steel surfaces can be cleaned using a non-abrasive stainless steel cleaner or with dishwashing detergent and warm water.
- To help prevent resoiling, a conditioner for stainless steel can also be used. Apply sparingly with even pressure.

## Control panel

- Plastic control panel should only be wiped with a damp cloth or suitable cleaning agent designed for use on plastic.
- For stainless steel panels see information above.

 The stainless steel surfaces and controls may become discolored or damaged if not cleaned regularly. The appliance front and controls are not scratch proof. Remove spills immediately.



### Triple filter system


The triple filter system in the base of the wash cabinet prevents food from being redeposited on dishes. It also protects the circulation pump from damage caused by foreign objects (e.g. broken glass, bones).

 The machine must not be used without all the filters in place!

- Check and clean the filter system every 4-6 months or whenever a foreign object is trapped.


The level of soiling and time it takes before the filters need cleaning will vary depending on your household.

- Turn off the dishwasher before cleaning.




- Turn the handle counterclockwise to release the triple filter system.
- Lift the filter combination out of the machine. Remove any solid particles and rinse under running water. Scrub with a nylon brush if necessary.

## Cleaning and Care



To clean the inside of the filter, the flap must be opened.

- Push the clips together ① and open the flap ②.
- Rinse under running water.
- Close the flap so that the clip engages.



- Return the filter so it lies flat in the base of the wash cabinet.
- Lock the filter by turning the handle clockwise.

 The triple filter system must be inserted and locked. Large particles could get in the circulation system and cause a blockage.


## Cleaning the spray arms

Sometimes particles of food get stuck in the spray arm jets. The spray arms should be inspected and cleaned every 4 - 6 months.


- Turn off the dishwasher before cleaning.

## Removing the spray arms


- Remove the cutlery tray (if present).
- Press the **top** spray arm up to engage the inner ratchet and unscrew the spray arm.



- Pull the **lower** spray arm firmly upwards to remove.



- Lift up the **middle** spray arm, ①, to engage the ratchet and unscrew the spray arm, ②.
- Remove the lower basket.




- Use a pointed object such as a toothpick to push food particles into the spray arm jets.
- Rinse thoroughly under running water.
- Return the spray arms and check that they rotate freely.

# Cleaning and Care

## Cleaning the water inlet filter

A filter is incorporated into the intake hose attached to the dishwasher's shut off valve. If your water is hard or the pipes contain sediment, this filter may clog and prevent enough water from entering the wash cabinet.

⚠ The plastic housing of the water connection contains electrical wiring. Do not submerge the housing in liquid. Do not cut the intake hose or submerge it in liquid.



## Installing an in-line water filter

If your water contains a large number of insoluble substances, a filter between the water valve and the intake hose connection is recommended. These filters can be purchased from Miele.

## Cleaning the filter


- Turn off the dishwasher and pull the plug.
- Turn off the water supply.
- Unscrew the intake hose.

- Carefully remove the rubber seal.
- Remove the filter using needle nose pliers and rinse it under running water.
- Reinsert the filter and seal. Make sure they are seated correctly.
- Screw the intake hose back on the water valve, checking that it is not cross-threaded.
- Slowly turn on the water supply and test for leaks.


### Cleaning the drain pump and non-return valve

If the dishwasher is not completely drained at the end of a program, the drain pump or non-return valve may be blocked.

- Turn off the dishwasher and pull the plug.
- Remove the triple filter (see "Triple filter system").
- Use a jug or bowl to scoop water out of the wash cabinet.



The drain pump is beneath the non-return valve (see arrow).




- Tilt the locking clamp to the side ①.
- Pull out the non-return valve ② and rinse it under running water.
- Remove all foreign objects from the non-return valve.

- Remove all foreign objects from the drain pump (glass or bone splinters).
- Before returning the non-return valve, check that the drain pump is not blocked. Spin the propeller several times in both directions to check for obstructions.
- Carefully reinsert the non-return valve and secure it with the locking clamp.

 Make sure the locking clamp clicks into place!





## Installation Instructions

For installation of the dishwasher  
please refer to the Installation Sheet  
supplied with these instructions.

## Help to protect the environment

---

### **Disposal of the packing material**

The cardboard box and packaging protect the appliance during shipping. These materials are biodegradable and recyclable. Please recycle.

Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of children.  
Danger of suffocation!

### **Disposal of an old machine**

Old appliances may contain materials that can be recycled. Please contact your local recycling authority about the possibility of recycling these materials.

Ensure that the appliance presents no danger to children while being stored for disposal. Before discarding an old appliance, unplug it from the outlet, cut off its power cord and remove any doors to prevent hazards.



 Installation, repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held responsible for unauthorized work.

Check that the voltage, frequency and fuse rating shown on the data plate match the household mains supply.

The power outlet must be accessible after installation. Do not use an extension cord to connect the dishwasher to the mains. Danger of overheating! See data plate on the right side of the door.

A damaged power cord must only be replaced with a genuine Miele cord by a Miele service technician.

### GROUNDING INSTRUCTIONS

**THIS APPLIANCE MUST BE GROUNDED.**

In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for the electrical current. This appliance is equipped with a cord having an equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is installed and grounded in accordance with all local codes and ordinances.

 **Improper connection of the equipment grounding conductor can result in electric shock. Do not modify the plug provided with the appliance; if it will not fit the outlet, have a proper outlet installed by a qualified electrician. If there is any question concerning the proper electrical connection or grounding of this appliance to the power supply, please consult a licensed electrician or call Miele's Technical Service Department:**

 1-800-999-1360

 1-800-565-6435

### Specifications


The dishwasher comes equipped with a 4 ft (1.2 m) power cord with a molded plug for connection to 120 V, 60 Hz, 15 A grounded receptacle.

# Plumbing

## Connection to the water supply

 Do not drink water from the dishwasher!

- The dishwasher can heat its own water to the temperature required by the wash program. This allows for connection of the machine to either a hot or cold water source. For lowest energy consumption connect the dishwasher to a cold water source. For fastest possible wash times, with slightly higher energy consumption, connect the dishwasher to a hot water source. All programs use hot water in the rinse cycles.
- The inlet hose is approx. 5 ft. (1.5 m) long. A 5 ft (1.5 m) flexible metal hose (pressure resistant up to 2030 psi) is available.
- The water inlet hose comes equipped with a 3/4" female hose thread connector. This can be directly connected to a water supply with 3/4" MHT (male hose thread ends).
- Water pressure: Must be between 4.5 - 145 psi (0.3 - 10 bar).



 Do not cut the intake hose. It contains electrical wiring. If the hose is cut, the dishwasher will not work. There will be a waterleak and you could be injured. If the hose is too long, coil it neatly and place it behind the machine.


## Drainage

- The machine comes equipped with a built-in non-return valve on the discharge side to prevent waste water from flowing back into the dishwasher.
- The dishwasher is equipped with a 5 ft (1.5 m) flexible drain hose with an internal diameter of 7/8" (22 mm).
- Drain hose extensions and adapters can be ordered from Miele. The maximum drain hose length is 13 ft. (4 m), max. drain height: 39" (1 m).
- If the hose is to be directly fitted to the drainage outlet on site, use the supplied hose clip.
- The hose can be installed to the left or right side.
- The existing drain pipe for the drain hose is designed for various hose diameters. The drain pipe must be shortened if the drain pipe extends too far into the drain hose. The drain hose could get clogged.
- The drain hose must not be shortened.
- Make sure the hose is installed without kinking, pressure or being pulled.

## Venting the drainage system

If the dishwasher drain hose is connected to a floor drain or to a drain pipe that is less than 8" (20 cm) above the floor, the drain must be vented. Otherwise the water inside the dishwasher may siphon out during the wash program.

- Open the dishwasher door and remove the lower basket.
- Pull the lower spray arm firmly upwards to remove.



- Cut off the vent cap located at the right rear of the triple filter system, as illustrated.

When contacting the Technical Service,  
please quote the model and serial number  
of your appliance.

---



**Miele, Inc.** (USA)

**National Headquarters**

9 Independence Way  
Princeton, NJ 08540  
Phone: 800-843-7231  
609-419-9898  
Fax: 609-419-4298  
[www.miele.com](http://www.miele.com)

**Technical Service & Support  
Nationwide**

Phone: 800-999-1360  
Fax: 888-586-8056

**Miele Limited** (CDN)

**National Headquarters**

55G East Beaver Creek Road  
Richmond Hill, ON L4B 1E5  
Phone: 800-643-5381  
905-707-1171  
Fax: 905-707-0177  
[www.miele.ca](http://www.miele.ca)  
[info@miele.ca](mailto:info@miele.ca) (general enquiries)  
[professional@miele.ca](mailto:professional@miele.ca) (commercial enquiries)

**Mielecare National Service**

Phone: 800-565-6435  
905-850-7456  
Fax: 905-850-6651  
[service@miele.ca](mailto:service@miele.ca) (Tech. Service)