




**Miller**®

November 1995 Form: OM-2204F  
Effective With Serial No. KG017632

# OWNER'S MANUAL



## XMT® 300 CC/TIG

- CC/DC Welding Power Source
- For GTAW, GTAW-P, And SMAW Welding
- 300 Amperes, 32 Volts DC At 60% Duty Cycle
- Uses Single-Phase Or Three-Phase Input Power
- Protection For Control Circuit, 24 VAC, And Overheating
- AUTO-LINK™ Circuitry And Built-In High Frequency
- 14-Pin Remote Control Receptacle
- For Options And Accessories, See Rear Cover



- Read and follow these instructions and all safety blocks carefully.
- Have only trained and qualified persons install, operate, or service this unit.
- Call your distributor if you do not understand the directions.



- Give this manual to the operator.



- For help, call your distributor
- or: MILLER Electric Mfg. Co., P.O. Box 1079, Appleton, WI 54912 414-734-9821

# MILLER'S TRUE BLUE™ LIMITED WARRANTY

Effective January 1, 1995  
(Equipment with a serial number preface of "KD" or newer)

This limited warranty supersedes all previous MILLER warranties and is exclusive with no other guarantees or warranties expressed or implied.

**LIMITED WARRANTY** — Subject to the terms and conditions below, MILLER Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new MILLER equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by MILLER. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, MILLER will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. MILLER must be notified in writing within thirty (30) days of such defect or failure, at which time MILLER will provide instructions on the warranty claim procedures to be followed.

MILLER shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor or eighteen months after the equipment is sent to an International distributor.

1. **5 Years Parts — 3 Years Labor**
  - Original main power rectifiers
  - Inverters (input and output rectifiers only)
2. **3 Years — Parts and Labor**
  - Transformer/Rectifier Power Sources
  - Plasma Arc Cutting Power Sources
  - Semi-Automatic and Automatic Wire Feeders
  - Inverter Power Supplies
  - Intelligits
  - Robots
3. **2 Years — Parts and Labor**
  - Engine Driven Welding Generators  
(NOTE: Engines are warranted separately by the engine manufacturer.)
  - Air Compressors
4. **1 Year — Parts and Labor**
  - Motor Driven Guns
  - Process Controllers
  - IHPS Power Sources
  - Water Coolant Systems
  - HF Units
  - Grids
  - Spot Welders
  - Load Banks
  - SDX Transformers
  - Running Gear/Trailers
  - Plasma Cutting Torches (except APT, ZIPCUT & PLAZCUT Models)
  - Tecumseh Engines
  - Deutz Engines (outside North America)
  - Field Options

(NOTE: Field options are covered under True Blue™ for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
5. **6 Months — Batteries**

6. **90 Days — Parts and Labor**
  - MIG Guns/TIG Torches
  - APT, ZIPCUT & PLAZCUT Model Plasma Cutting Torches
  - Remote Controls
  - Accessory Kits
  - Replacement Parts

MILLER'S True Blue™ Limited Warranty shall not apply to:

1. Items furnished by MILLER, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
2. Consumable components; such as contact tips, cutting nozzles, contactors and relays or parts that fail due to normal wear.
3. Equipment that has been modified by any party other than MILLER, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at MILLER'S option: (1) repair; or (2) replacement; or, where authorized in writing by MILLER in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized MILLER service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. MILLER'S option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a MILLER authorized service facility as determined by MILLER. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.

## RECEIVING-HANDLING

Before unpacking equipment, check carton for any damage that may have occurred during shipment. File any claims for loss or damage **with the delivering carrier**. Assistance for filing or settling claims may be obtained from distributor and/or equipment manufacturer's Transportation Department.

When requesting information about this equipment, always provide Model Designation and Serial or Style Number.

Use the following spaces to record Model Designation and Serial or Style Number of your unit. The information is located on the rating label or nameplate.

Model \_\_\_\_\_

Serial or Style No. \_\_\_\_\_

Date of Purchase \_\_\_\_\_

# ARC WELDING SAFETY PRECAUTIONS



## WARNING

ARC WELDING can be hazardous.

**PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS KEEP AWAY UNTIL CONSULTING YOUR DOCTOR.**

In welding, as in most jobs, exposure to certain hazards occurs. Welding is safe when precautions are taken. The safety information given below is only a summary of the more complete safety information that will be found in the Safety Standards listed on the next page. Read and follow all Safety Standards.

**HAVE ALL INSTALLATION, OPERATION, MAINTENANCE, AND REPAIR WORK PERFORMED ONLY BY QUALIFIED PEOPLE.**



### ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

1. Do not touch live electrical parts.
2. Wear dry, hole-free insulating gloves and body protection.
3. Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
4. Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
5. Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
6. Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground

terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.

7. When making input connections, attach proper grounding conductor first – double-check connections.
8. Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
9. Turn off all equipment when not in use.
10. Do not use worn, damaged, undersized, or poorly spliced cables.
11. Do not drape cables over your body.
12. If earth grounding of the workpiece is required, ground it directly with a separate cable – do not use work clamp or work cable.
13. Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
14. Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
15. Wear a safety harness if working above floor level.
16. Keep all panels and covers securely in place.
17. Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.



### ARC RAYS can burn eyes and skin; NOISE can damage hearing; FLYING SLAG OR SPARKS can injure eyes.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Noise from some processes can damage hearing. Chipping, grinding, and welds cooling throw off pieces of metal or slag.

#### NOISE

1. Use approved ear plugs or ear muffs if noise level is high.

#### ARC RAYS

2. Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
3. Wear approved safety glasses with side shields.
4. Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
5. Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.



### FUMES AND GASES can be hazardous to your health.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

1. Keep your head out of the fumes. Do not breathe the fumes.
2. If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
3. If ventilation is poor, use an approved air-supplied respirator.
4. Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instruction for metals, consumables, coatings, cleaners, and degreasers.

5. Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
6. Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
7. Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



### CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

1. Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs.
2. Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
3. Keep cylinders away from any welding or other electrical circuits.

4. Never drape a welding torch over a gas cylinder.
5. Never allow a welding electrode to touch any cylinder.
6. Never weld on a pressurized cylinder – explosion will result.
7. Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
8. Turn face away from valve outlet when opening cylinder valve.
9. Keep protective cap in place over valve except when cylinder is in use or connected for use.
10. Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.



### WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

1. Protect yourself and others from flying sparks and hot metal.
2. Do not weld where flying sparks can strike flammable material.
3. Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
4. Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
5. Watch for fire, and keep a fire extinguisher nearby.
6. Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
7. Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
8. Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
9. Do not use welder to thaw frozen pipes.
10. Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
11. Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
12. Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.



## WARNING

### ENGINES can be hazardous.



### ENGINE EXHAUST GASES can kill.

Engines produce harmful exhaust gases.

1. Use equipment outside in open, well-ventilated areas.
2. If used in a closed area, vent engine exhaust outside and away from any building air intakes.



### ENGINE FUEL can cause fire or explosion.

Engine fuel is highly flammable.

3. Do not overfill tank -- allow room for fuel to expand.
4. Do not spill fuel. If fuel is spilled, clean up before starting engine.

1. Stop engine and let it cool off before checking or adding fuel.
2. Do not add fuel while smoking or if unit is near any sparks or open flames.



### MOVING PARTS can cause injury.

Moving parts, such as fans, rotors, and belts can cut fingers and hands and catch loose clothing.

3. Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
4. To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
5. Keep hands, hair, loose clothing, and tools away from moving parts.
6. Reinstall panels or guards and close doors when servicing is finished and before starting engine.

1. Keep all doors, panels, covers, and guards closed and securely in place.
2. Stop engine before installing or connecting unit.



### SPARKS can cause BATTERY GASES TO EXPLODE; BATTERY ACID can burn eyes and skin.

Batteries contain acid and generate explosive gases.

1. Always wear a face shield when working on a battery.
2. Stop engine before disconnecting or connecting battery cables.
3. Do not allow tools to cause sparks when working on a battery.
4. Do not use welder to charge batteries or jump start vehicles.
5. Observe correct polarity (+ and -) on batteries.



### STEAM AND PRESSURIZED HOT COOLANT can burn face, eyes, and skin.

It is best to check coolant level when engine is cold to avoid scalding.

1. If the engine is warm and checking is needed, follow steps 2 and 3.
2. Wear safety glasses and gloves and put a rag over cap.
3. Turn cap slightly and let pressure escape slowly before completely removing cap.

## PRINCIPAL SAFETY STANDARDS

*Safety in Welding and Cutting*, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126

*Safety and Health Standards*, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

*Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances*, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126

*National Electrical Code*, NFPA Standard 70, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1, from Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

*Code for Safety in Welding and Cutting*, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.

*Safe Practices For Occupation And Educational Eye And Face Protection*, ANSI Standard Z87.1, from American National Standards Institute, 1430 Broadway, New York, NY 10018.

*Cutting And Welding Processes*, NFPA Standard 51B, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

# EMF INFORMATION

## NOTE

### *Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields*

The following is a quotation from the General Conclusions Section of the U.S. Congress, Office of Technology Assessment, *Biological Effects of Power Frequency Electric & Magnetic Fields – Background Paper*, OTA-BP-E-53 (Washington, DC: U.S. Government Printing Office, May 1989): “. . . there is now a very large volume of scientific findings based on experiments at the cellular level and from studies with animals and people which clearly establish that low frequency magnetic fields can interact with, and produce changes in, biological systems. While most of this work is of very high quality, the results are complex. Current scientific understanding does not yet allow us to interpret the evidence in a single coherent framework. Even more frustrating, it does not yet allow us to draw definite conclusions about questions of possible risk or to offer clear science-based advice on strategies to minimize or avoid potential risks.”

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around the body.
4. Keep welding power source and cables as far away as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

**About Pacemakers:**

The above procedures are among those also normally recommended for pacemaker wearers. Consult your doctor for complete information.

mod10.1 4/93


## TABLE OF CONTENTS

<b>SECTION 1 – SAFETY INFORMATION</b> .....	1
<b>SECTION 2 – SPECIFICATIONS</b> .....	1
2-1. Volt-Ampere Curves .....	2
2-2. Duty Cycle .....	2
<b>SECTION 3 – INSTALLATION</b> .....	3
3-1. Typical Process Connections .....	3
3-2. Selecting A Location And Moving Welding Power Source .....	4
3-3. Selecting And Preparing Weld Output Cables .....	5
3-4. Connecting To Weld Output Receptacles .....	6
3-5. Remote 14 Receptacle RC2 Information And Connections .....	6
3-6. Installing Gas Supply .....	7
3-7. Connecting Input Power .....	8
<b>SECTION 4 – OPERATION</b> .....	9
<b>SECTION 5 – MAINTENANCE &amp; TROUBLESHOOTING</b> .....	15
5-1. Routine Maintenance .....	15
5-2. Removing Case And Measuring Input Capacitor Voltage .....	16
5-3. Overload Protection .....	17
5-4. Changing Amperage/Voltage Meter Hold Function .....	18
5-5. Troubleshooting .....	18
<b>SECTION 6 – ELECTRICAL DIAGRAMS</b> .....	20
<b>SECTION 7 – HIGH FREQUENCY</b> .....	24
<b>SECTION 8 – TUNGSTEN ELECTRODE</b> .....	26
8-1. Selecting Tungsten Electrode .....	26
8-2. Preparing Tungsten .....	27
<b>SECTION 9 – PARTS LIST</b> .....	28
Figure 9-1. Main Assembly (208-230/460V Model Illustrated) .....	28
Figure 9-2. Chassis, Mid (208-230/460V Model Illustrated) .....	30
Figure 9-3. Panel, Front w/Components .....	33



# SECTION 1 – SAFETY INFORMATION

mod1.1 2/93



- Read all safety messages throughout this manual.
- Obey all safety messages to avoid injury.
- Learn the meaning of WARNING and CAUTION.

1

2 **WARNING**

3 **ELECTRIC SHOCK can kill.**

4

- Do not touch live electrical parts.
- Disconnect input power before installing or servicing.

5

2

**CAUTION**

**MOVING PARTS can injure.**

- Keep away from moving parts.
- Keep all panels and covers closed when operating.

6 **WARNING** **READ SAFETY BLOCKS at start of Section 3-1 before proceeding.**

7 **NOTE** *Turn Off switch when using high frequency.*

1 Safety Alert Symbol

2 Signal Word

WARNING means possible death or serious injury can happen.

CAUTION means possible minor injury or equipment damage can happen.

3 Statement Of Hazard And Result

4 Safety Instructions To Avoid Hazard

5 Hazard Symbol (If Available)

6 Safety Banner

Read safety blocks for each symbol shown.

7 NOTE

Special instructions for best operation – not related to safety.

Figure 1-1. Safety Information

# SECTION 2 – SPECIFICATIONS

Table 2-1. Welding Power Source

Specification	Description	
Type Of Output	Constant Current/Direct Current (CC/DC)	
Welding Processes	Gas Tungsten Arc (GTAW), Gas Tungsten Arc - Pulsed (GTAW-P), Shielded Metal Arc Welding (SMAW)	
Input Power Cord	12 ft (3.7 m)	
Overall Dimensions	Length: 21-3/4 in (522 mm); Width: 12 in (305 mm); Height: 17-3/8 in (441 mm)	
Weight	Net: 84 lb (38 kg); Ship: 89 lb (40 kg)	
	With Three-Phase Input	With Single-Phase Input
Rated Weld Output	300 Amperes, 32 Volts DC At 60% Duty Cycle (See Section 2-2)	225 Amperes, 29 Volts DC At 60% Duty Cycle (See Section 2-2)
Type Of Input	230, 460, Or 575 Volts AC; 50/60 Hz	230, 460, Or 575 Volts AC; 50/60 Hz
Input Amperes At Rated Output	42 A At 230 V, 21 A At 460 V, 16.4 A At 575 V	50.8 A At 230 V, 29 A At 460 V, 23.6 A At 575 V
Input Amperes While Idling (Fan Not Running)	1.2 A At 230 V, 0.6 A At 460 V, 0.6 A At 575 V	1.1 A At 230 V, 0.6 A At 460 V, 0.6 A At 575 V
KVA/KW Used At Rated Output	16.1 kVA/11.3 kW	12.8 kVA/7.8 kW
Amperage Range	5-375 A	5-225 A
Max. Open-Circuit Voltage	80 Volts DC	80 Volts DC

## 2-1. Volt-Ampere Curves




Figure 2-1. Volt-Ampere Curves

## 2-2. Duty Cycle





Figure 2-2. Duty Cycle Chart

# SECTION 3 – INSTALLATION

## ⚠ WARNING



**HIGH-FREQUENCY RADIATION can interfere with radio navigation, safety services, computers, and communications equipment.**

- Have only qualified person familiar with electronic equipment perform this installation.
- Read and follow entire Section 7 for proper location and installation requirements for high-frequency equipment before installing unit.

swam13.1 4/93

### 3-1. Typical Process Connections





Figure 3-1. Typical Process Connections

### 3-2. Selecting A Location And Moving Welding Power Source


 <b>WARNING</b>			
	<b>ELECTRIC SHOCK can kill.</b> <ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Disconnect input power conductors from de-energized supply line <b>BEFORE</b> moving welding power source.</li> </ul>		<b>FUMES can be hazardous; LACK OF FRESH AIR AND PROPER VENTILATION can be harmful.</b> <ul style="list-style-type: none"> <li>Do not breathe welding fumes.</li> <li>Place unit only where there is a good fresh air supply and proper ventilation.</li> </ul>
	<b>FIRE OR EXPLOSION can result from placing unit on, over, or near combustible surfaces.</b> <ul style="list-style-type: none"> <li>Do not locate unit on, over, or near combustible surfaces.</li> <li>Do not install unit near flammables.</li> </ul>		<b>FALLING EQUIPMENT can cause serious personal injury and equipment damage.</b> <ul style="list-style-type: none"> <li>Lift unit at handles.</li> <li>Have two persons of adequate physical strength lift unit.</li> <li>Move unit with hand cart or similar device of adequate capacity.</li> <li>If using a fork lift vehicle, secure unit on a proper skid before transporting.</li> </ul>
	<b>BLOCKED AIRFLOW causes overheating and possible damage to unit.</b> <ul style="list-style-type: none"> <li>Do not block airflow.</li> <li>Use only factory-approved filter.</li> </ul> <p>Warranty is void if any unapproved filter is used.</p>		swam11.1* 12/94

#### Movement



- 1 Lifting Handles  
Use handles to lift unit.
- 2 Hand Cart  
Use cart or similar device to move unit.
- 3 Rating Label  
Use rating label to determine input power needs.
- 4 Line Disconnect Device  
Locate unit near correct input power supply.

#### Location And Airflow



ssb9.1\* 5/94 - ST-146 123-A / Ref. ST-151 556

Figure 3-2. Location And Movement Of Welding Power Source

### 3-3. Selecting And Preparing Weld Output Cables




Figure 3-3. Selecting And Preparing Weld Output Cables




Figure 3-4. Dinse-Type Connector Assembly

Table 3-1. Weld Cable Size\*

Welding Amperes	Total Cable (Copper) Length In Weld Circuit Not Exceeding							
	100 ft (30 m) Or Less		150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)
	10 To 60% Duty Cycle	60 Thru 100% Duty Cycle	10 Thru 100% Duty Cycle					
100	4	4	4	3	2	1	1/0	1/0
150	3	3	2	1	1/0	2/0	3/0	3/0
200	3	2	1	1/0	2/0	3/0	4/0	4/0
250	2	1	1/0	2/0	3/0	4/0	2-2/0	2-2/0
300	1	1/0	2/0	3/0	4/0	2-2/0	2-3/0	2-3/0
350	1/0	2/0	3/0	4/0	2-2/0	2-3/0	2-3/0	2-4/0
400	1/0	2/0	3/0	4/0	2-2/0	2-3/0	2-4/0	2-4/0
500	2/0	3/0	4/0	2-2/0	2-3/0	2-4/0	3-3/0	3-3/0

\*Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.

### 3-4. Connecting To Weld Output Receptacles

⚠


## WARNING




**ELECTRIC SHOCK can kill; ARCING can burn skin or damage electrical equipment.**

- Do not touch live electrical parts.
- Turn Off welding power source before making any weld output connections.
- Do not change position of welding cable connectors while welding.
- Be sure connectors are secure in receptacles before welding.

swam12.2 2/93





- 1 Positive (+) Weld Output Receptacle
- 2 Negative (-) Weld Output Receptacle
- 3 Connector

For DC Electrode Positive (DCEP), connect work cable connector to negative (-) receptacle and electrode holder cable connector to positive (+) receptacle.

For DC Electrode Negative (DCEN), reverse cable connections.


See Figure 3-1 for typical polarity choices.

To connect to receptacle, align keyway, insert connector, and turn clockwise until tight.

Ref. ST-155 091 / Ref. ST-153 625


Figure 3-5. Connecting To Weld Output Receptacles

### 3-5. Remote 14 Receptacle RC2 Information And Connections



- 1 Remote 14 Receptacle RC2 (See Table 3-2)
- 2 Keyway
- 3 Plug
- 4 Threaded Collar

To connect to receptacle, align keyway, insert plug, and tighten threaded collar.



sb7.1 5/94 - ST-800 829 / Ref. S-0004-A / S-0750

Figure 3-6. Remote 14 Connections

Table 3-2. Remote 14 Socket Information


 REMOTE 14	Socket*	Socket Information
 OUTPUT (CONTACTOR)	A	24 volts ac. Protected by fuse F2.
	B	Contact closure to A completes 24 volts ac contactor control circuit.
<b>A</b> AMPERAGE	C	+10 volts dc output to remote control.
	D	Remote control circuit common.
	E	0 to +10 volts dc input command signal from remote control.
	K	Chassis common.

\*The remaining sockets are not used.

### 3-6. Installing Gas Supply

<b>⚠ WARNING</b>	
	<p><b>CYLINDERS can explode if damaged.</b></p> <ul style="list-style-type: none"> <li>• Keep cylinders away from welding and other electrical circuits.</li> <li>• Never touch cylinder with welding electrode.</li> <li>• Always secure cylinder to running gear, wall, or other stationary support.</li> </ul>
	<p><b>BUILDUP OF SHIELDING GAS can harm health or kill.</b></p> <ul style="list-style-type: none"> <li>• Shut off shielding gas supply when not in use.</li> </ul>
wam4.1 9/91	



Obtain gas cylinder and chain to running gear, wall, or other stationary support so cylinder cannot fall and break off valve.

- 1 Cap
- 2 Cylinder Valve

Remove cap, stand to side of valve, and open valve slightly. Gas flow blows dust and dirt from valve. Close valve.

- 3 Cylinder
- 4 Regulator/Flowmeter

Install so face is vertical.

- 5 Gas Hose Connection

Fitting has 5/8-18 right-hand threads. Obtain and install gas hose.

- 6 Flow Adjust

Typical flow rate is 15 cfh (cubic feet per hour).

Make sure flow adjust is closed when opening cylinder to avoid damage to the flowmeter.

- 7 Gas In Fitting
- 8 Gas Out Fitting

The Gas In and Gas Out fittings have 5/8-18 right hand threads. Obtain proper size, type, and length hose and make connections as follows:

Connect hose from shielding gas supply regulator/flowmeter to Gas In fitting.

Connect shielding gas hose from torch to Gas Out fitting.

**Tools Needed:**






 5/8, 1-1/8 in

ssb3.3\* 5/94 – Ref. ST-158 697-A / Ref. S-0004-A / Ref. ST-153 625 / Ref. S-0621-C

Figure 3-7. Typical Regulator/Flowmeter Installation

### 3-7. Connecting Input Power

<b>⚠ WARNING</b>	
	<p><b>HIGH-FREQUENCY RADIATION can interfere with radio navigation, safety services, computers, and communications equipment.</b></p> <ul style="list-style-type: none"> <li>• Have only qualified person familiar with electronic equipment perform this installation.</li> <li>• Read and follow entire Section 7 for proper location and installation requirements for high-frequency equipment before installing unit.</li> </ul>
	<p><b>ELECTRIC SHOCK can kill.</b></p> <ul style="list-style-type: none"> <li>• Do not touch live electrical parts.</li> <li>• Turn Off welding power source, and disconnect input power before inspecting or installing.</li> <li>• Have only qualified persons install unit.</li> <li>• Installation must meet National Electrical Code and all other codes.</li> </ul>
swam13.2 4/93	

<p><b>Three-Phase System</b></p> 	<p><b>Single-Phase System</b></p> 	
		
<p>OR</p> 		
		
		
<p><b>1 Rating Label</b></p> <p>Use single or three-phase, 50/60 Hz, ac input power which matches one of the voltages shown. The AUTO-LINK circuitry senses the input voltage and automatically links the unit for operation.</p> <p><b>2 Line Disconnect Device Of Proper Rating</b></p> <p><b>3 Input Power Cord</b></p> <p><b>4 Grounding Conductor – Green Or Green With Yellow Stripe(s)</b></p> <p>Install grounding conductor and input conductors from unit to deenergized line disconnect device.</p> <p>Connect grounding conductor first, then line input conductors.</p> <p>Be sure grounding conductor goes to an earth ground.</p> <p><b>5 Black And White Input Conductor</b></p> <p><b>6 Insulation Sleeving</b></p> <p><b>7 Electrical Tape</b></p> <p><b>8 Red Input Conductor</b></p> <p>Red conductor not used in single-phase system. Insulate and isolate conductor by sliding insulation sleeving over end of lead, bending lead back, and taping to power cord.</p> <p><b>9 Overcurrent Protection</b></p> <p>Select type and size using Table 3-3. Install into deenergized line disconnect device (fused disconnect switch shown).</p>		
ssb2.3* 11/93 – Ref. ST-144 221 / Ref. ST-070 399-C / Ref. ST-146 123-A / S-0657 / Ref. S-0092-A		

**Figure 3-8. Input Power Connections**

Table 3-3. Electrical Service Guide

Input Voltage	Three-Phase			Single-Phase		
	230	460	575	230	460	575
Input Amperes At Rated Output	42	21	16.4	50.8	29	23.6
Max Recommended Standard Fuse Or Circuit Breaker Rating In Amperes	60	30	25	80	40	35
Reference: 1993 National Electrical Code (NEC).						S-0092J

## SECTION 4 – OPERATION

 <b>WARNING</b>			
 <p><b>ELECTRIC SHOCK can kill.</b></p> <ul style="list-style-type: none"> <li>Always wear dry insulating gloves.</li> <li>Insulate yourself from work and ground.</li> <li>Do not touch live electrical parts.</li> <li>Keep all panels and covers securely in place.</li> </ul>	 <p><b>ARC RAYS can burn eyes and skin; NOISE can damage hearing.</b></p> <ul style="list-style-type: none"> <li>Wear welding helmet with correct shade of filter.</li> <li>Wear correct eye, ear, and body protection.</li> </ul>		
 <p><b>FUMES AND GASES can be hazardous to your health.</b></p> <ul style="list-style-type: none"> <li>Keep your head out of the fumes.</li> <li>Ventilate area, or use breathing device.</li> <li>Read Material Safety Data Sheets (MSDSs) and manufacturer's instructions for material used.</li> </ul>	 <p><b>MOVING PARTS can cause injury.</b></p> <ul style="list-style-type: none"> <li>Keep away from moving parts.</li> <li>Keep all doors, panels, covers, and guards closed and securely in place.</li> </ul>		
 <p><b>WELDING can cause fire or explosion.</b></p> <ul style="list-style-type: none"> <li>Do not weld near flammable material.</li> <li>Watch for fire; keep extinguisher nearby.</li> <li>Do not locate unit over combustible surfaces.</li> <li>Do not weld on closed containers.</li> <li>Allow work and equipment to cool before handling.</li> </ul>	 <p><b>MAGNETIC FIELDS FROM HIGH CURRENTS can affect pacemaker operation.</b></p> <ul style="list-style-type: none"> <li>Pacemaker wearers keep away.</li> <li>Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.</li> </ul>		
		<p>See Safety Precautions at beginning of manual for basic welding safety information. <span style="float: right;">swam6.1 10/91</span></p>	





Figure 4-1. Controls




Wear the following while welding:

- 1 Dry, Insulating Gloves
- 2 Safety Glasses With Side Shields
- 3 Welding Helmet With Correct Shade Of Filter (See ANSI Z49.1)

sb3.1 1/94

Figure 4-2. Safety Equipment




1 Work Clamp

Connect work clamp to a clean, paint-free location on workpiece, as close to weld area as possible.

Use wire brush or sandpaper to clean metal at weld joint area. Use chipping hammer to remove slag after welding.

sb4.1 2/93

Figure 4-3. Work Clamp




1 Process Selector Switch

Use switch to select type of weld output. Use left position for SMAW Welding. Use right position for GTAW Welding with High Frequency for arc starting, and center position for GTAW Welding without High Frequency.

Switch position determines the operation of the Arc Force (Dig), Pre-flow, and Postflow controls (see Figure 4-6 and Figure 4-9).

Ref. ST-153 625-A


Figure 4-4. Process Selector Switch



1 Amperage Control

Use control to select weld amperage. Amperage may be adjusted while welding.

Figure 4-5. Amperage Control



**1 Arc Force Control (Dig)**

This control is used for SMAW welding and only works when Process Selector switch (see Figure 4-4) is in the SMAW position.

Use control to help start an arc or make vertical or overhead welds. Control increases amperage at low arc voltage (see Figure 2-1).

When set at 0, short-circuit amperage is the same as normal welding amperage.

When set at 100, short-circuit amperage increases to help arc starting.

Select setting best suited for application. Numbers around control are for reference only.


Set control at 0 for GTAW welding.

**Figure 4-6. Arc Force Control (Dig)**

<b>⚠ WARNING</b>	
	<p><b>ELECTRIC SHOCK can kill.</b></p> <ul style="list-style-type: none"> <li>• Do not touch live electrical parts.</li> <li>• Do not touch weld output terminals when contactor is energized.</li> <li>• Do not touch electrode and work clamp at the same time.</li> </ul>
	<small>swam7.1 10/91</small>


	<p><b>1 Output (Contactor) Switch</b></p> <p>Use switch to select way of controlling output.</p> <p>For front panel control, place switch in On position.</p> <p>For remote output control and to preset amperage using optional digital meter, place switch in Remote 14 position (see Section 3-5).</p>
<p><b>⚠ Weld output terminals are energized when switch is On and Power is On.</b></p>	

**Figure 4-7. Output (Contactor) Switch**




- 1 Amperage Control Switch  
Use switch to select way of controlling amperage adjustment.  
For front panel control, place switch in Panel position.  
For remote control, place switch in Remote 14 position (see Section 3-5).  
Remote control at Remote 14 is percent of front panel setting.
- 2 Fingertip Control
- 3 Remote Hand Control
- 4 Remote Foot Control  
See example below.

**Example: Combination Remote Amperage Control**



ST-159 059 / S-0769 / S-0774

**Figure 4-8. Amperage Control Switch**



- The scale around each control is marked in seconds.
- 1 Preflow Time Control  
Use control to adjust the time that gas flows before the welding arc is started.
  - 2 Postflow Time Control  
Use control to adjust the time that gas flows after the welding arc stops.
- These controls are for GTAW welding and only work when Process Selector switch (see Figure 4-4) is in one of the GTAW positions.

**Figure 4-9. Preflow/Postflow Time Controls**




Figure 4-10. Amperage/Voltage Meter And Switch (Optional)




Figure 4-11. Power Switch And Pilot Light



# WARNING




**BUILDUP OF SHIELDING GAS** can harm health or kill.

- Shut off shielding gas supply when not in use.

wam1.1 9/91



OR



- 1 Shielding Gas Cylinder
- 2 Valve
- 3 Torch Output Control
- 4 Foot Control


Open valve on cylinder just before welding.

Torch output control or foot control turns weld output and gas flow on and off.

Close valve on cylinder when finished welding.


sb5.2\* 5/94 – S-0621-C / S-0769

**Figure 4-12. Shielding Gas**




ssb8.1\* 12/92

**Figure 4-13. Sequence Of Gas Tungsten Arc Welding (GTAW)**



**Figure 4-14. Sequence Of Gas Tungsten Arc Welding – Pulsed (GTAW-P)**



ssb7.1 9/92

**Figure 4-15. Sequence Of Shielded Metal Arc Welding (SMAW)**

# SECTION 5 – MAINTENANCE & TROUBLESHOOTING

 <b>WARNING</b>			
	<p><b>ELECTRIC SHOCK can kill; SIGNIFICANT DC VOLTAGE exists after removal of input power.</b></p> <ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Turn Off welding power source, disconnect input power, wait 60 seconds, measure voltage on input capacitors according to Section 5-2, and be sure voltage is near zero before touching any parts.</li> </ul>		<p><b>MOVING PARTS can cause injury.</b></p> <ul style="list-style-type: none"> <li>Keep away from moving parts.</li> </ul>
	<p><b>HOT PARTS can cause severe burns.</b></p> <ul style="list-style-type: none"> <li>Allow cooling period before maintaining or servicing.</li> </ul>		<p><b>STATIC ELECTRICITY can damage parts on circuit boards.</b></p> <ul style="list-style-type: none"> <li>Put on grounded wrist strap BEFORE handling boards or parts.</li> <li>Use proper static-proof bags and boxes.</li> </ul>
		<p>Maintenance to be performed only by qualified persons.</p>	

swam8.3 2/94

## 5-1. Routine Maintenance




Figure 5-1. Maintenance Schedule

## 5-2. Removing Case And Measuring Input Capacitor Voltage

**WARNING**



**READ SAFETY BLOCKS at start of Section 5 before proceeding.**

**Significant DC voltage can remain on capacitors after unit is Off. Always check capacitors as shown to be sure they have discharged before working on unit.**

Turn Off welding power source and disconnect input power.

- 1 Top Of Case
- 2 Handles
- 3 Outside Handle Screws
- 4 Side Bolts

To loosen top, remove two outside handle screws from both handles and all side bolts.

- 5 Bottom Of Case
- 6 Mounts

To loosen bottom, remove all side bolts, carefully place unit on its side and remove the four mounts.


- 7 Input Capacitors C12, C13
  - 8 Input Capacitors C8, C9
- Locate on lower left side.

- 9 Voltmeter

Check both sets of input capacitors.


Measure dc voltage across positive (+) and negative (-) terminals until voltage drops to near 0 (zero) volts.

After task is completed, reinstall case.



Front Panel  
(Controls Vary  
According To Model)

Tools Needed:




Ref. ST-152 114-E

**Figure 5-2. Removing Case And Measuring Input Capacitor Voltage**

### 5-3. Overload Protection

<b>WARNING</b>		<p><b>READ SAFETY BLOCKS</b> at start of Section 5 before proceeding.</p>
----------------	--	---

#### A. Overheating



**Figure 5-3. Overheating**

#### B. Fuses

Turn Off welding power source, disconnect input power, and check voltage on input capacitors according to Section 5-2 before proceeding.

**1 Fuse F2**

F2 protects the 24 volts ac winding of control transformer T2. If F2 opens, remote control devices connected to Remote 14 receptacle RC2 shut down.

Remove top cover (see Section 5-2) to check and replace fuse.

See Parts List for fuse size. Use proper tool when removing fuse.

**2 Fuse Holder**

**Tools Needed:**


ST-146 126-F / Ref. ST-146 122-D

**Figure 5-4. Overload Protection**

## 5-4. Changing Amperage/Voltage Meter Hold Function

 <b>WARNING</b>		<b>READ SAFETY BLOCKS at start of Section 5 before proceeding.</b>
--	---	--



Front Panel  
(Controls Vary According To Model)

**Tools Needed:**  
  
 Non-Conductive

The Amperage/Voltage meter is able to hold the displayed weld output value for 15 seconds after welding stops. If the hold function is not used, the displayed value leaves when welding stops.

This procedure allows the hold function to be turned On or Off.

Turn Off welding power source, disconnect input power, and check voltage on input capacitors according to Section 5-2 before proceeding.

- 1 AV Meter Board PC5
- 2 DIP Switch S2

S2 is accessible from the left side of the unit.

- 3 Toggle 1
- 4 Toggle 2

Set toggles in desired position.  
Reinstall case.

ST-159 050-B

Figure 5-5. Changing Amperage/Voltage Meter Hold Function

## 5-5. Troubleshooting

 <b>WARNING</b>			
	<p><b>ELECTRIC SHOCK can kill. SIGNIFICANT DC VOLTAGE exists after removal of input power.</b></p> <ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Turn Off welding power source, disconnect input power, wait 60 seconds, measure voltage on input capacitors according to Section 5-2, and be sure voltage is near zero before touching any parts.</li> </ul>		<p><b>MOVING PARTS can cause injury.</b></p> <ul style="list-style-type: none"> <li>Keep away from moving parts.</li> </ul>
	<p><b>HOT PARTS can cause severe burns.</b></p> <ul style="list-style-type: none"> <li>Allow cooling period before servicing.</li> </ul>		<p><b>STATIC ELECTRICITY can damage parts on circuit boards.</b></p> <ul style="list-style-type: none"> <li>Put on grounded wrist strap BEFORE handling boards or parts.</li> <li>Use proper static-proof bags and boxes.</li> </ul>
		<p>Troubleshooting to be performed only by qualified persons.</p>	
swam9.3 2/94			

Table 5-1. Welding Trouble

Trouble	Remedy	Section
<div style="border: 1px solid black; padding: 5px; width: fit-content;">                     No weld output; unit completely inoperative.                 </div>	Be sure Power switch is On.	Figure 4-11
	Be sure line disconnect switch is On.	3-7
	Check line fuse(s) and replace if necessary. Reset circuit breakers.	3-7
	Check for proper input connections.	3-7

Trouble	Remedy	Section
No weld output; fan motor FM running and pilot light on.	Check position of Output (Contactor) switch.	Figure 4-7
	Thermostat TP1 open (overheating). Allow fan to run; thermostat closes when unit has cooled.	5-3A
Low weld output with no control.	Check position of Amperage Control switch.	Figure 4-8
	Have Factory Authorized Service Station/Service Distributor check control board PC1.	--
Limited output and low open-circuit voltage.	Check incoming power for correct voltage. Replace line fuse if open or reset circuit breaker.	3-7
	Check for proper input and output connections.	3-3, 3-4, 3-7
Erratic or improper weld output.	Tighten all welding cable connections.	3-3, 3-4
	Check for proper size and type of cable.	3-3
	Check for proper input and output connections.	3-3, 3-4, 3-7
	Replace electrode.	8-1, 8-2
Remote device completely inoperative.	Connect remote control to Remote 14 receptacle RC2.	3-5
	Check fuse F2 and replace if necessary.	5-3B
Fan motor FM does not run.	Have Factory Authorized Service Station/Service Distributor check thermostats TP2 and/or TP3 and fan motor.	--
Wandering arc; poor control of arc direction.	Reduce flow rate.	--
	Select proper size tungsten.	8-1
	Properly prepare tungsten.	8-2
Tungsten electrode oxidizing and not remaining bright after conclusion of weld.	Shield weld zone from drafts.	--
	Increase postflow time.	--
	Check and tighten all gas fittings.	--
	Water in torch. Refer to torch Owner's Manual for part(s) requiring replacement, and repair torch as necessary.	--
Lack of high frequency; difficulty in establishing an arc.	Be sure torch cable is not near any grounded metal.	--
	Check work and torch cable for damaged insulation or bad connections, and repair as necessary.	--
No high frequency.	Check position of Process Selector switch.	Figure 4-4
	Have Factory Authorized Service Station/Service Distributor check high frequency board PC2.	--

# SECTION 6 – ELECTRICAL DIAGRAMS





Figure 6-1. Circuit Diagram For 230/460 Volt Models








Figure 6-2. Circuit Diagram For 460/575 Volt Models



# SECTION 7 – HIGH FREQUENCY


mod6.1 5/94

## ⚠ WARNING




**HIGH-FREQUENCY RADIATION** can interfere with radio navigation, safety services, computers, and communications equipment.

- Have only qualified person familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding as shown in Figure 7-3 to minimize the possibility of interference.



Gas Tungsten Arc Welding (GTAW)




Submerged Arc Welding (SAW)

- 1 Gas Tungsten Arc Torch
- 2 High-Frequency Voltage  
Used to help arc jump air gap between torch and workpiece and/or stabilize the arc.
- 3 Submerged Arc Welding Gun
- 4 Flux
- 5 High-Frequency Voltage  
Used to help arc reach workpiece through flux granules.

S-0693


Figure 7-1. Welding Processes Requiring High Frequency



- 1 Sources Of Direct High-Frequency Radiation  
High-frequency source (welding power source with built-in HF or separate HF unit), weld cables, torch, work clamp, workpiece, and work table.
- 2 Sources Of Conduction Of High Frequency  
Input power cable, line disconnect device, and input supply wiring.
- 3 Sources Of Reradiation Of High Frequency  
Ungrounded metal objects, lighting, wiring, water pipe and fixtures, external phone and power lines.

S-0694

Figure 7-2. Sources Of High-Frequency Radiation From Incorrect Installation



S-0695

**1 High-Frequency Source (Welder With Built-In HF Or Separate HF Unit)**

Ground metal machine case, work output terminal, line disconnect device, input supply, and worktable.

**2 Center Point Of Welding Zone**

Midpoint between high-frequency source and welding torch.

**3 Welding Zone**

A circle 50 ft (15 m) from center point in all directions.

**4 Weld Output Cables**

Keep cables short and close together.

**5 Conduit Joint Bonding**

Electrically join (bond) all conduit sections using copper straps or braided wire. Ground conduit every 50 ft (15 m).

**6 Water Pipe And Fixtures**

Ground water pipe every 50 ft (15 m).

**7 External Power Or Telephone Lines**

Locate high-frequency source at least 50 ft (15 m) away from power and phone lines.

**8 Metal Building Panel Bonding Methods**

Bolt or weld building panels together, install copper straps or braided wire across seams, and ground frame.

**9 Grounding Rod**

Consult the National Electrical Code for specifications.

**10 Windows And Doorways**

Cover all windows and doorways with grounded copper screen of not more than 1/4 in (6.4 mm) mesh.

**11 Overhead Door Track**

Ground the track.

**Figure 7-3. Correct Installation**

# SECTION 8 – TUNGSTEN ELECTRODE

mod2.1 1/94

## NOTE

For additional information, see your distributor for a handbook on the Gas Tungsten Arc Welding (GTAW) process.

Wear clean gloves to prevent contamination of tungsten electrode.

## 8-1. Selecting Tungsten Electrode

Table 8-1. Tungsten Size

Electrode Diameter	Amperage Range - Gas Type♦ - Polarity			
	DC – Argon – Electrode Negative/Straight Polarity	DC – Argon – Electrode Positive/Reverse Polarity	AC – Argon – Using High Frequency	AC – Argon – Balanced Wave Using High Freq.
<b>Pure Tungsten (Green Band)</b>				
.010"	Up to 15	*	Up to 15	Up to 10
.020"	5-20	*	5-20	10-20
.040"	15-80	*	10-60	20-30
1/16"	70-150	10-20	50-100	30-80
3/32"	125-225	15-30	100-160	60-130
1/8"	225-360	25-40	150-210	100-180
5/32"	360-450	40-55	200-275	160-240
3/16"	450-720	55-80	250-350	190-300
1/4"	720-950	80-125	325-450	250-400
<b>2% Thorium Alloyed Tungsten (Red Band)</b>				
.010"	Up to 25	*	Up to 20	Up to 15
.020"	15-40	*	15-35	5-20
.040"	25-85	*	20-80	20-60
1/16"	50-160	10-20	50-150	60-120
3/32"	135-235	15-30	130-250	100-180
1/8"	250-400	25-40	225-360	160-250
5/32"	400-500	40-55	300-450	200-320
3/16"	500-750	55-80	400-500	290-390
1/4"	750-1000	80-125	600-800	340-525
<b>Zirconium Alloyed Tungsten (Brown Band)</b>				
.010"	*	*	Up to 20	Up to 15
.020"	*	*	15-35	5-20
.040"	*	*	20-80	20-60
1/16"	*	*	50-150	60-120
3/32"	*	*	130-250	100-180
1/8"	*	*	225-360	160-250
5/32"	*	*	300-450	200-320
3/16"	*	*	400-550	290-390
1/4"	*	*	600-800	340-525

♦ Typical argon shielding gas flow rates are 15 to 35 cfh (cubic feet per hour).

\*Not Recommended.

The figures listed are intended as a guide and are a composite of recommendations from American Welding Society (AWS) and electrode manufacturers.

S-0009

## 8-2. Preparing Tungsten




Figure 8-1. Preparing Tungsten For AC Or DC Electrode Positive (DCEP) Welding

**CAUTION**

**FLYING SPARKS AND HOT METAL can cause injury and start fires.**

- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Keep flammables away.

wam2.1 9/91






Figure 8-2. Preparing Tungsten For DC Electrode Negative (DCEN) Welding

# SECTION 9 – PARTS LIST




Figure 9-1. Main Assembly (208-230/460V Model Illustrated)

ST-146 121-F

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				208-230/460V	460/575V

**Figure 9-1. Main Assembly**


1		126 415	CLAMP, saddle	2	2
2		126 416	HANDLE, molded plastic	2	2
3		138 442	LABEL, caution falling equipment can cause injury	2	2
4		+141 350	CASE	1	1
5		+141 574	CASE, bottom	1	1
6	C25	135 289	CAPACITOR	1	1
7	SR4	149 219	KIT, rectifier integ 35A	1	1
8		136 191	CAP, protective vinyl .313 ID x .500 lg	1	1
9	R17	136 185	RESISTOR	1	1
10		Fig 9-3	PANEL, front w/components	1	1
11		133 405	NUT, speed 10-24 flat type rectangular	4	4
12		108 105	CLAMP, capacitor 2.500dia	4	4
13		136 227	STRIP, mtg capacitor bracket	2	2
14	L1-4	133 639	CHOKE, DVDT	2	2
15		145 245	INSULATOR, elctlt	2	2
16		155 642	SCREW, set .250-28 x 1.000 cup pt sch stl	8	8
17	C10,11	164 812	CAPACITOR	2	2
18		143 748	BUS BAR	2	2
19	C8,9,12,13	135 786	CAPACITOR, elctlt 4000uf 250VDC	4	
19	C8,9,12,13	140 981	CAPACITOR, elctlt 2800uf 300VDC		4
20	W1A	157 661	INTERLOCK, cntor IEC 2NO-2NC 10A 4P	1	
		158 567	LINK, jumper	3	
21	W1	157 660	CONTACTOR, IEC 25A 4P 2NO-2NC contacts	1	
		158 567	LINK, jumper	1	
		158 568	LINK, jumper large	1	
	PLG21	131 054	CONNECTOR & SOCKETS, (consisting of)	1	1
		113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2	2
	RC21	135 635	CONNECTOR & PINS, (consisting of)	1	1
		114 656	CONNECTOR, rect pin 24-18ga Molex 39-00-0040	2	2
		146 112	BLANK, snap-in nyl .218mtg hole		2
22	CT1	158 555	TRANSFORMER, current	1	1
23		020 265	CABLE TIE, 0-1.750 bundle	1	1
24	T1	172 012	TRANSFORMER, HF	1	1
25	R13-16	139 812	RESISTOR, WW fxd 30W 5K ohm	4	4
26		Fig 9-2	CHASSIS, mid	1	1
27		126 026	LABEL, warning electric shock	1	1
28		+161 438	CASE SECTION, front/bottom/back (consisting of)	1	1
		161 136	NUT, .312-18 stl insert	4	4
		161 135	NUT,10-32 stl insert	4	4
		148 329	LABEL, caution incorrect voltage will damage unit	1	
		148 330	LABEL, caution incorrect voltage will damage unit		1
29		134 229	BUSHING, strain relief .640/.770 x 1.470mtg hole	1	1
30		158 559	CABLE, pwr 12ft	1	
30		152 710	CABLE, port No. 10 4/c (order by ft)		12ft
31	Z1,2	141 437	STABILIZER	2	2
32	T2	165 658	TRANSFORMER, control	1	
32	T2	162 166	TRANSFORMER, control		1
	PLG7	166 680	CONNECTOR & PINS, (consisting of)	1	1
		113 633	CONNECTOR, rect pin 20-14ga Amp 350218-1	12	12
	RC7	166 679	CONNECTOR & SOCKETS, (consisting of)	1	1
		114 066	CONNECTOR, rect skt 20-14ga Amp 350536-1	12	12
33		140 894	BRACKET, mtg stab	1	1
34		605 227	NUT, nyl hex jam .750NPST	1	1
35	GS1	158 583	VALVE, 24VAC 2way custom port 1/8 orf	1	1
36	T3	134 383	ARC STARTER, pulser HF	1	1
37		136 190	NUT, speed U type 10-32	2	2
38		134 421	BUS BAR	1	1
39	C7	138 115	CAPACITOR	1	1
40	C26	031 613	CAPACITOR, elctlt 100uf 150VDC	1	1
41	R18	601 394	RESISTOR, C 2W 10K ohm	1	1

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				208-230/460V	460/575V

**Figure 9-1. Main Assembly (Continued)**

42	R6	134 198	RESISTOR, WW fxd 40W 500 ohm	1	1
43		162 960	ENCLOSURE, arc starter (consisting of)	1	1
		137 198	NUT, insert 10-24	2	2
44		015 712	GROMMET, rbr .625 ID x .875mtg hole	1	1
45		141 690	GROMMET, scr No. 8/10 panel hole .281sq .197 high	4	4
46		134 386	INSULATOR, arc starter	1	1
47	PC2	151 248	KIT, circuit card arc starter	1	1
	PLG5	146 099	CONNECTOR & SOCKETS, (consisting of)	1	1
		125 748	CONNECTOR, rect skt 22-18ga JST SVH-21T-1.1	4	4
	PLG14	165 884	CONNECTOR & SOCKETS, (consisting of)	1	1
		125 748	CONNECTOR, rect skt 22-18ga JST SVH-21T-1.1	3	3
48		134 327	LABEL, warning general precautionary	2	2
49		133 948	FOOT, mtg	4	4
50		143 915	MOUNT, sgl stud 1.5dia x 1.000 lg .312-18 stud	4	4
	PLG20	115 093	CONNECTOR & SOCKETS, (consisting of)	1	1
		113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	6	6
	RC20	131 059	CONNECTOR & PINS, (consisting of)	1	1
		114 656	CONNECTOR, rect pin 24-18ga Molex 39-00-0040	6	6
51		169 771	SCREW, shld stl hexhd 10-32 x .875	8	8

+When ordering a component originally displaying a precautionary label, the label should also be ordered.  
**BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.**



ST-146 122-E

**Figure 9-2. Chassis, Mid (208-230/460V Model Illustrated)**

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				208-230/460V	460/575V

Figure 9-2. Chassis, Mid (Fig 9-1 Item 26)

...	1	HD1	156 313	TRANSDUCER, current 300A	1	1
		PLG62	130 204	CONNECTOR & SOCKETS, (consisting of)	1	1
			114 066	CONNECTOR, rect skt 20-14ga Amp 350536-1	3	3
...	2		083 147	GROMMET, scr No. 8/10 panel hole .312sq .500 high	10	10
...	3	PC3	163 784	CIRCUIT CARD, HF preflow/postflow	1	1
		PLG11,13	130 203	CONNECTOR & SOCKETS, (consisting of)	2	2
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	12	12
		PLG19	131 054	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2	2
...	4		010 116	GROMMET, rbr .375 ID x .500mtg hole	2	2
...	5	PC1	171 902	CIRCUIT CARD, control	1	1
...	5	PC1	171 907	CIRCUIT CARD, control	1	1
		PLG2	131 054	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2	2
		PLG4	115 094	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	4	4
		PLG6	115 093	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	6	6
		PLG8,18,28	115 092	CONNECTOR & SOCKETS, (consisting of)	3	3
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	8	8
		PLG10	115 091	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	10	10
		PLG12	130 203	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	12	12
...	6		162 096	TRAY, mtg PC card	1	1
...	7		137 768	GROMMET, rbr .750 ID x .875mtg hole	1	1
...	8		141 588	STAND-OFF, 8-32 x .500 lg	4	4
...	9	PC6	168 777	CIRCUIT CARD, driver	1	1
		PLG1	115 091	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	10	10
		PLG22	131 054	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2	2
...	9	R27,28	136 076	RESISTOR, WW fxd 30W 200 ohm		2
...	10		072 253	STUD, connection single 10-32 x .500 x 1.250mtg	1	1
...	11		012 571	HOLDER, fuse mintr	1	1
...	12	F2	*012 654	FUSE, mintr gl 2A	1	1
...	13	SN1	152 776	SUPPRESSOR	1	1
...	14		152 785	RECTIFIER, si diode LH (consisting of)	1	1
		C40-43	031 689	CAPACITOR	4	4
		D9-12	149 209	KIT, diode fast recovery	4	4
		TP3	086 323	THERMOSTAT, NO	1	1
			133 290	HEAT SINK, rect	1	1
			072 253	STUD, connection single 10-32 x .500 x 1.250mtg	4	4
...	15		158 549	IGBT, LH (consisting of)	1	1
...	15		161 221	IGBT, LH (consisting of)	1	1
		C14,15	157 451	CAPACITOR, polye met film .01uf 1600V	2	2
		PM1	150 912	KIT, transistor IGBT module	1	1
		PM1	150 913	KIT, transistor IGBT module	1	1
		R9,10	123 231	RESISTOR, WW fxd 50W 35 ohm	2	2
			169 402	HEAT SINK, IGBT LH	1	1
...	16		152 780	BAFFLE, air wind tunnel LH	1	1
...	17		000 527	BLANK, snap-in nyl .875mtg hole	2	2
...	18		146 581	WIND TUNNEL, 6.500 in	1	1
...	19		133 295	CHAMBER, plenum 6.500 in	1	1
...	20		135 661	EDGE TRIM, style 3100-1/16 (order by ft)	2ft	2ft
...	21	FM	132 232	MOTOR, fan 220/230V 50/60Hz 3000RPM	1	1
		PLG9	131 054	CONNECTOR & SOCKETS, (consisting of)	1	1
			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2	2

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				208-230/460V	460/575V
<b>Figure 9-2. Chassis, Mid (Fig 9-1 Item 26)</b>					
<b>(Continued)</b>					
	RC9	135 635	CONNECTOR & PINS, (consisting of)	1	1
		114 656	CONNECTOR, rect pin 24-18ga Molex 39-00-0040	2	2
22		155 426	KIT, fan blade (consisting of)	1	1
23		134 209	NUT, speed push-on type .250	1	1
24	R27	136 076	RESISTOR, WW fxd 30W 200 ohm	1	
24	CR1	052 964	RELAY, encl 24VDC DPDT		1
25	C50	114 215	CAPACITOR, polye film 2.3uf 250VAC	1	
26		146 689	BAFFLE, air wind tunnel RH	1	1
27		158 815	IGBT, RH (consisting of)	1	
27		161 222	IGBT, RH (consisting of)		1
	C16,17	157 451	CAPACITOR, polye met film .01uf 1600V	2	2
	PM2	150 912	KIT, transistor IGBT module	1	
	PM2	150 913	KIT, transistor IGBT module		1
	R11,12	123 231	RESISTOR, WW fxd 50W 35 ohm	2	2
	SR1	149 208	KIT, diode pwr module	1	1
	TP1	006 334	THERMOSTAT, NC	1	1
	TP2	155 053	THERMOSTAT, NO	1	1
		158 816	HEAT SINK, IGBT RH	1	
		169 403	HEAT SINK, IGBT RH		1
	VR5	091 033	VARISTOR	1	
28		133 968	RECTIFIER, si diode RH (consisting of)	1	1
	C44-47	031 689	CAPACITOR	4	4
	D13-16	149 209	KIT, diode fast recovery	4	4
		133 290	HEAT SINK, rect	1	1
		072 253	STUD, connection single 10-32 x .500 x 1.250mtg	4	4
		601 835	NUT, brs hex 10-32	14	
29		139 743	INSULATOR, heat sink lower	1	1
30		030 170	BUSHING, snap-in nyl .750 ID x 1.000mtg hole	2	2
31	W2	145 407	CONTACTOR, def prp 25A 2P 24VAC	1	
31	W1	145 407	CONTACTOR, def prp 25A 2P 24VAC		1
	SN2	152 775	SNUBBER, poly met film .1uf 600VDC		1
32		136 190	NUT, speed U type 10-32	6	6
33		+158 442	PANEL, center	1	1
		099 037	EDGE TRIM, style 62-1/16 (order by ft)		1ft
34		153 178	LABEL, warning exploding parts	2	2
35	VCM1	164 849	MODULE, varistor/capacitor 4 400 joule 1620-1980VDC	1	1
36		126 026	LABEL, warning electric shock	2	2
37		145 053	WASHER, shldr nyl .298 OD x .203 ID x 1.000 x .062shldr	4	4
38		099 037	EDGE TRIM, style 62-1/16 (order by ft)	1ft	1ft
39		010 493	BUSHING, snap-in nyl. 625 ID x .875mtg hole	1	1
40		006 426	CLAMP, capacitor 2.000dia	2	2
41		133 405	NUT, speed 10-24 flat type rectangular	2	2
42	C1,2	132 844	CAPACITOR, polyp film 2.1uf 1000VDC	2	2
43		158 557	BUS BAR, interconnecting	1	1
44		158 443	INSULATOR, heat sink upper	1	1
45		158 444	STRIP, bus rect	1	1
46		134 058	STAND-OFF SUPPORT, PC card .156dia	2	2

◆PLG8 is part of 042 517 Optional Meter Kit.

\*Recommended Spare Parts.


+When ordering a component originally displaying a precautionary label, the label should also be ordered.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

**Figure 9-3. Panel, Front w/Components (Fig 9-1 Item 10)**

1	R2	073 562	POTENTIOMETER, C std slot 1/T 2W 10K ohm	1
2	R3	035 897	POTENTIOMETER, C std slot 1/T 2W 1K ohm	1
3	S5	134 849	SWITCH, tgl DPDT 15A 125VAC	1
4	S4	134 847	SWITCH, tgl SPDT 15A 125VAC	1
5	S3	134 848	SWITCH, tgl DPDT 15A 125VAC	1
6	PC5	◆157 011	CIRCUIT CARD, meter	1
	PLG50	◆089 222	CONNECTOR, rect 11skt plug Amp 1-640440-1	1
7		◆134 058	STAND-OFF SUPPORT, PC card .156dia	4
8		◆158 563	STRIP, protector PC card	1
		136 339	COVER, opening meter (not used when unit has Meter Kit)	1
		120 304	BLANK, snap-in nyl .250mtg hole (not used when unit has Meter Kit)	1
9		148 297	NUT, speed U type 10-32	2
10	S1	128 756	SWITCH, tgl 3PST 40A 600VAC	1
	PLG3	131 054	CONNECTOR & SOCKETS, (consisting of)	1
		113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	2
	RC3	135 635	CONNECTOR & PINS, (consisting of)	1
		114 656	CONNECTOR, rect pin 24-18ga Molex 39-00-0040	2
11		146 684	INSULATOR, switch power	1
12	R4,5	121 770	POTENTIOMETER, C sltd sft 1/T 1W 100K ohm	2
13	RC2	143 976	CONNECTOR w/SOCKETS, (consisting of)	1
		079 534	CONNECTOR, circ skt push-in 14-18ga Amp 66358-6	14



**Figure 9-3. Panel, Front w/Components**

ST-146 120-C

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
<b>Figure 9-3. Panel, Front w/Components (Fig 9-1 Item 10) (Continued)</b>				
.....		134 734 ..	CONNECTOR, circ 14 pin plug Amp 213571-2	
.....		134 731 ..	CONNECTOR, circ pin push-in 14-18ga Amp 213603-1	
.....		079 739 ..	CONNECTOR, circ clamp str rlf sz 17-20 Amp 206322-2 (or)	
.....		143 922 ..	CONNECTOR, circ clamp str rlf sz 17-20 Amp 206070-3	
... 14 .....		115 440 ..	STAND-OFF, 6-32 x .687 lg .....	4
... 15 .....	PC4 .....	166 064 ..	CIRCUIT CARD, receptacle bypass .....	1
.....	PLG30,31 ..	130 203 ..	CONNECTOR & SOCKETS, (consisting of) .....	2
.....		113 746 ..	CONNECTOR, rect skt 24-18ga Molex 39-00-0038 .....	12
... 16 .....	C6 .....	138 115 ..	CAPACITOR .....	1
... 17 .....	Pos,Neg ..	129 525 ..	RECEPTACLE, twlk insul fem (Dinse type) 50/70 series .....	2
.....		042 418 ..	CONNECTOR KIT, Dinse male 50 series (consisting of) .....	2
.....		134 746 ..	WRENCH, hex 5mm short .....	1
... 18 .....		134 834 ..	HOSE, SAE .187 ID x .410 OD (order by ft) .....	2ft
... 19 .....		120 854 ..	FITTING, gas .....	1
... 20 .....		039 885 ..	CONNECTOR, circ protective cap Amphenol 9760-20 .....	1
... 21 .....			NAMEPLATE, (order by model and serial number) .....	1
... 22 .....		093 551 ..	KNOB, .125dia shaft w/.125 setscrews .....	2
... 23 .....	PL1 .....	157 958 ..	LIGHT, ind wht lens 28V .....	1
... 24 .....		097 924 ..	KNOB, pointer .....	1
... 25 .....		135 299 ..	LOCK, shaft knob .375-32 x .250dia shaft .....	1
... 26 .....		097 922 ..	KNOB, pointer .....	1

◆Part of 042 517 Optional Meter Kit.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.

# NOTES



## OPTIONS AND ACCESSORIES

### INTELLITIG™ 4 PRECISION TIG CONTROLLER (#042 598)

Provides high-frequency arc starting, timed gas solenoid control and metering, pulsing, sequencing, sloping, on-screen voltage and amperage metering, and two relay contacts for fixturing. The control provides four modes of operation: Automatic, Semiautomatic, Manual GTAW and SMAW. For detailed information, refer to product Literature Index No. AY/9.0.

### PC-300 PULSED GTAW (DC TIG) CONTROL (#042 297)

Can be used with power sources that have built-in high frequency, or it can be use with an external high-frequency unit. The control has two internally switchable scales: a 0.5 to 20 pulses-per-second scale for both inverter and non-inverter type power sources, and a 10 to 300 pulses-per-second scale for inverter power sources only.

Control includes 8 ft. (2.4 m) interconnecting cord and 115 VAC power cord. Front panel controls provide:

- Peak Amperage Adjustment
- Background Amperage Adjustment
- Pulses-Per-Second Adjustment (0.5 to 20 pulses-per-second scale or 10 to 300 pulses-per-second scale)
- Percent On Time Control
- Amperage Remote/Panel Control
- Output Contactor On/Off Control
- Pulser On/Off
- Power On/Off
- Remote Control Receptacle (for remote hand or foot controls)

### MMP MANUAL MIG PULSER PENDANT CONTROL (#042 727)

The MMP Manual MIG Pulser Control allows manual control of the pulse wave form. This control provides independent control of the four parameters that affect the pulse process:

- Frequency: Adjust the pulse rate within a range of 20 pulses-per-second to 200 pulses-per-second.
- Pulse Width: Adjust the amount of "on" time. Maintains arc stability. Adjusts from 1 to 5 milliseconds.
- Peak Current Level: Set the "peak" amperage that the pulse wave form will allow (25% to 100% of maximum output of power source). Helps "pinch" off the electrode droplet.
- Background Current Level: Set the background current level to sustain the arc (3% to 25% of maximum output of power source).

This control allows precision pulse welding with a wide variety of wire sizes, gases, materials, and joint configurations.

Includes 25 ft. (7.6 m) connector cord and a 17-pin plug for direct connection to the front of the power source.

*Note: For best performance, do not run the XMT on 200 or 208 primary voltage when using this accessory.*

## REMOTE CONTROLS

### RFC-14 FOOT CONTROL (#129 339)

Foot current and contactor control. Includes 20 ft. (6 m) cord and 14-pin plug.

### RHC-14 HAND CONTROL (#129 340)

Miniature hand control for remote current and contactor control. Dimensions: 4 in. (102 mm) x 4 in. (102 mm) x 3-1/4 in. (82 mm). Includes 20 ft. (6 m) cord and 14-pin plug.

## TORCH-MOUNTED REMOTE HAND CONTROLS

### RMLS-14 (#129 337)

Momentary- and maintained-contact rocker switch for contactor control. Push forward for maintained contact and back

for momentary contact. Includes 20 ft. (6 m) cord and 14-pin Amphenol plug.

### RCC-14 REMOTE CONTACTOR AND CURRENT CONTROL (#151 086) 14-pin plug

Rotary motion fingertip control fastens to TIG torch using two Velcro straps. Includes 28 ft. (8.5 m) control cord.

## EXTENSION CORDS FOR REMOTE CONTROLS AND 24 VAC WIRE FEEDERS

14-pin Amphenol plug to a 14-pin Amphenol socket.

- 10 ft. (3 m) (#122 972)
- 25 ft. (7.6 m) (#122 973)
- 50 ft. (15.2 m) (#122 974)
- 75 ft. (22.8 m) (#122 975)

## XMT RACK

### 8 Pak Rack (#042 813)

For operation on 460 or 575 VAC

### 8 Pak Rack (#042 648)

For operation on 230 or 460 VAC

### 4 Pak Rack (#042 812)

For operation on 230 or 460 VAC

The rugged 8 Pak Rack houses and powers up to eight XMT 300 power sources. The rack measures 66 in. (1.68 m) wide x 41 in. (1.04 m) deep x 72 in. (1.83 m) tall, and weighs 1700 lbs. (771 kg) when loaded with eight XMTs (with no welding cables). The 4 Pak Rack measures 66 in. (1.68 m) wide x 41 in. (1.04 m) deep x 57 in. (1.45 m) tall, and weighs just 800 lbs. (363 kg) with four XMT 300 units.

The XMT Rack provides many important features:

- Two – 115 VAC, 20 Amp GFCI duplex receptacles for auxiliary tools (8 Pak Racks only)
- Provisions for paralleling power sources or common work connections
- Power sources can be locked down to prevent theft
- Captured secondary cable hangers for work leads and weld cables
- Center lifting eye
- Rugged skids for dragging or pushing

## OPTIONS AND ACCESSORIES

### **XMT ECONOMY CART (#134 505)**

Small and lightweight. Slanted for convenient access to front panel controls. Storage compartment for gloves, helmet, etc.

### **XMT WIRE FEEDER QUICK DISCONNECT (#042 491)**

Attaches S-21E or S-22A wire feeder to XMT case.

### **XMT CYLINDER CART (#042 537)**

Has adjustable handles and is slanted for convenient access to power source front panel controls. Carries two 160 lb. (72.6 kg) gas cylinders, or one gas cylinder and one coolant system for GTAW (TIG) welding. Feeder mounted to tray above power source. Can be used with the Maxtron™, Miller Arc Pak™ or XMT inverter power supplies. Also accommodates

Radiator, Watermate™, or Coolmate™ coolant systems.

### **UNIVERSAL CARRYING CART AND CYLINDER RACK (#042 934)**

Accommodates any XMT power source, plus gas cylinder up to 56 in. (142.2 cm) high measuring 6 to 9 inches (15.2 to 22.8 cm) in diameter. Also provides storage for auxiliary items such as electrodes, helmets, gloves, etc. Can also be used with Econotig™, Maxstar® Series, Millermatic® 130 and Millermatic® 150 power sources.

### **BACK-LIT LCD DIGITAL METERS**

**(#042 518 Field)**

Allows presetability and real time display of voltage and amperage. Presetting welding current and voltage helps to provide optimum welding conditions. Meters feature a "hold" function that allows

operator to read actual weld values after welding is stopped. Weld setting is held for 15 seconds before meter is automatically cleared. Meters are easy to read in indoor or outdoor environment.

### **XMT INVERTER POWER SOURCES VIDEOTAPE (#137 760)**

An 8 minute VHS videotape describing the XMT family of inverter power sources.

### **MILLER EXPERT PROGRAM™ (#042 623)**

Easy-to-use computerized software program used to diagnose and service the power source. For detailed information, reference Miller Expert Program Literature Index No. AV/6.0.

*Note: The serial number of the power source and diskette size (5-1/4 or 3-1/2 in.) must be specified when ordering any Miller Expert Program diskette.*

## INTERNATIONAL-STYLE CONNECTORS (Will accept Dinse™ or other International connectors.)

All XMT power sources are equipped with International-style connectors for secondary connections. (Power source is shipped with two - 50 mm male International-style plugs for use with #1 or #2 AWG size cable.)

### **INTERNATIONAL-STYLE CONNECTOR KIT**

**(#042 418) 50 mm**

Accepts #1 or #2 AWG cable size. Required if male plugs shipped with power source must be replaced, if additional plugs are needed.

**(#042 533) 70 mm**

Accepts #1/0 or #2/0 AWG cable size. Required if #1/0 or #2/0 AWG size cable is to be used.

Kit includes one International-style male plug which attaches to the work and/or weld cables and plugs into the International style receptacles on the power source.

### **EXTENSION KIT FOR INTERNATIONAL-STYLE CABLE CONNECTORS**

Used to adapt or extend weld and/or work cables.

Kit includes one male International-style plug and one in-line female International-style receptacle.

**(#042 419) 50 mm**

Accepts #1 or #2 AWG size cable.

**(#042 534) 70 mm**

Accepts #1/0 or #2/0 AWG size cable.

### **INTERNATIONAL/TWECO® ADAPTER**

**(#042 465)**

A one-piece adapter which has an International-style male plug (to power source) on one end and a female Tweco receptacle (for weld cable connection) on other end.

### **INTERNATIONAL/CAM-LOK ADAPTER**

**(#042 466)**

A one-piece adapter which has an International-style male plug (to

power source) on one end and a Cam-Lok receptacle (for weld cable connection) on other end.

### **INTERNATIONAL/TIG TORCH CONNECTOR**

Required for direct connection of water-cooled torches or air-cooled torches with a one-piece cable assembly.

Kit includes gas hose, gas hose fitting, and International-style TIG Block.

**(#135 492)**

For 80 Amp, air-cooled torch with one-piece cable assembly.

**(#135 493)**

For 150 Amp, air-cooled torch with one-piece cable assembly.

**(#135 494)**

For 200 Amp, air-cooled torch with one-piece cable assembly.

**(#135 495)**

For 250/300 Amp, water-cooled torch with one-piece cable assembly.