

Z200Y
LZ200Y

SERVICE MANUAL



LIT-18616-02-10

68F-28197-Z9-11

PREFACE

This manual has been prepared by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because the Yamaha Motor Company, Ltd. has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

CAUTION

USE UNLEADED STRAIGHT GASOLINE ONLY

- Gasoline containing lead can cause performance lose and engine damage.
- Do not use gasoline mixed with oil (premix).
- Use YAMALUBE 2 stroke outboard oil or another 2-stroke engine oil with a BIA-certified TC-W3 rate.

Z200Y, LZ200Y SERVICE MANUAL

©1999 Yamaha Motor Co., Ltd.

1st Edition, September 1999

All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means including photocopying and recording without the written permission of the copyright holder.

Such written permission must also be obtained before any part of this publication is stored in a retrieval system of any nature.

Printed in USA

LIT-18616-02-10

HOW TO USE THIS MANUAL

MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and check operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
Pitting/scratches → Replace.

To assist you in finding your way through this manual, the section title and major heading is given at the top of every page.

MODEL INDICATION

Multiple models are mentioned in this manual and their model indications are noted as follows.

Model name	Z200NETO	LZ200NETO
USA and Canada name	Z200TR	LZ200TR
Indication	Z200NETO	LZ200NETO

ILLUSTRATIONS


The illustrations within this service manual represent all of the designated models.

CROSS REFERENCES

The cross references have been kept to a minimum. Cross references will direct you to the appropriate section or chapter.

IMPORTANT INFORMATION

In this Service Manual particularly important information is distinguished in the following ways.

 The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the outboard motor.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the outboard motor.

NOTE:


A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

- ① The main points regarding removing/installing and disassembling/assembling procedures are shown in the exploded views.
- ② The numbers in the exploded views indicate the required sequence of the procedure and should be observed accordingly.
- ③ Symbols are used in the exploded views to indicate important aspects of the procedure. A list of meanings for these symbols is provided on the following page.
- ④ It is important to refer to the job instruction charts at the same time as the exploded views. These charts list the sequence that the procedures should be carried out in, as well as providing explanations on part names, quantities, dimensions and important points relating to each relevant task.

Example:


O-ring size 39.5×2.5 mm: inside diameter (D) \times ring diameter (d)



- ⑤ In addition to tightening torques, the dimensions of the bolts or screws are also mentioned.

Example:

Bolt or screw size 10×25 mm : diameter (D) \times length (L)



- ⑥ In addition to the exploded views and job instruction charts, this manual provides individual illustrations when further explanations are required to explain the relevant procedure.

LOWR LOWER UNIT (REGULAR ROTATION MODELS) E

LOWER UNIT (REGULAR ROTATION MODELS)
 REMOVING/INSTALLING THE LOWER UNIT

Order	Job/Part	Qty	Remarks
1	Speedometer hose	1	
2	Propeller nut	1	
3	Washer	1	
4	Propeller	1	
5	Spacer	1	
6	Bolt	1	
7	Trim tab	1	
8	Bolt	1	(with washer)
9	Bolt	6	(with washer)
10	Lower unit	1	
11	Dowel pin	2	

For installation, reverse the removal procedure.

6-1

LOWR DRIVE SHAFT (REGULAR ROTATION MODELS) E

REMOVING THE DRIVE SHAFT
 Loosen:
 • Pinion nut

- ① Drive shaft holder ①
- ② YB-06201 / 90890-06520
- ③ Pinion nut holder ②
- ④ 90890-06505
- ⑤ Pinion nut holder attachment ③
- ⑥ 90890-06507

DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY
 Remove:
 • Needle bearing

- ① Bearing/oil seal attachment.... ①
- ② YB-06196 / 90890-06610
- ③ Driver rod ②
- ④ YB-06071 / 90890-06652

DISASSEMBLING THE FORWARD GEAR ASSEMBLY
 1. Remove:
 • Tapered roller bearing

























- ① Bearing separator ①
- ② YB-06219 / 90890-06534

CAUTION:
 Do not reuse the bearing, always replace it with a new one.

2. Remove:
 • Needle bearing

- ① Slide hammer..... ①
- ② YB-06096
- ③ Guide plate..... ②
- ④ 90890-06501
- ⑤ Guide plate stand ③
- ⑥ 90890-06538
- ⑦ Bearing puller..... ④
- ⑧ 90890-06535
- ⑨ Small universal claws ⑤
- ⑩ 90890-06536

6-18

① GEN INFO 	② SPEC 
③ INSP ADJ 	④ FUEL 
⑤ POWR 	⑥ LOWR 
⑦ BRKT 	⑧ ELEC 
⑨ TRBL ANLS 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 

SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

- ① General information
- ② Specifications
- ③ Periodic inspections and adjustments
- ④ Fuel system
- ⑤ Power unit
- ⑥ Lower unit
- ⑦ Bracket unit
- ⑧ Electrical systems
- ⑨ Trouble analysis

Symbols ⑩ to ⑮ indicate specific data.

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical value
[Resistance (Ω), Voltage (V), Electric current (A)]










Symbol ⑯ to ⑱ in an exploded diagram indicate the grade of lubricant and the location of the lubrication point.

- ⑯ Apply Yamaha 2-stroke outboard motor oil (TC-W3)
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply molybdenum disulfide oil

Symbols ⑲ to ㉔ in an exploded diagram indicate the grade of the sealing or locking agent and the location of the application point.

- ⑲ Apply Gasket Maker[®]
- ⑳ Apply Yamabond #4 (Yamaha bond number 4)
- ㉑ Apply LOCTITE[®] No. 271 (Red LOCTITE)
- ㉒ Apply LOCTITE[®] No. 242 (Blue LOCTITE)
- ㉓ Apply LOCTITE[®] No. 572
- ㉔ Apply silicon sealant

CONTENTS

GENERAL INFORMATION	 GEN INFO	1
SPECIFICATIONS	 SPEC	2
PERIODIC INSPECTIONS AND ADJUSTMENTS	 INSP ADJ	3
FUEL SYSTEM	 FUEL	4
POWER UNIT	 POWR	5
LOWER UNIT	 LOWR	6
BRACKET UNIT	 BRKT	7
ELECTRICAL SYSTEMS	 ELEC	8
TROUBLE ANALYSIS	 TRBL ANLS	9




CHAPTER 1 GENERAL INFORMATION

IDENTIFICATION	1-1
SERIAL NUMBER	1-1
STARTING SERIAL NUMBERS	1-1
SAFETY WHILE WORKING	1-2
FIRE PREVENTION	1-2
VENTILATION.....	1-2
SELF-PROTECTION.....	1-2
OILS, GREASES AND SEALING FLUIDS.....	1-2
GOOD WORKING PRACTICES	1-3
DISASSEMBLY AND ASSEMBLY	1-4
SPECIAL TOOLS	1-5
MEASURING	1-5
REMOVING AND INSTALLING	1-8



IDENTIFICATION


E



IDENTIFICATION SERIAL NUMBER

The outboard motor's serial number is stamped on a label which is attached to the port side of the clamp bracket.

NOTE: _____
 If the serial number label is removed, "VOID" marks will be appear on the label.



- ① Model name
- ② Approved model code
- ③ Transom height
- ④ Serial number

STARTING SERIAL NUMBERS


The starting serial number blocks are as follows:

Model name			Approved model code	Starting serial number
Worldwide	USA	Canada		
Z200NETO	Z200TR	Z200TR	6G6	X: 100101 -
LZ200NETO	LZ200TR	—	6K1	X: 100101 -




SAFETY WHILE WORKING

The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.




FIRE PREVENTION

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline and keep it away from heat, sparks and open flames.




VENTILATION

Petroleum vapor is heavier than air and is deadly if inhaled in large quantities. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.



SELF-PROTECTION

Protect your eyes with suitable safety glasses or safety goggles, when grinding or when doing any operation which may cause particles to fly off. Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.



OILS, GREASES AND SEALING FLUIDS

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.




SAFETY WHILE WORKING

E

Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized. A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in your pocket.
4. Hands and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working, is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.




GOOD WORKING PRACTICES

1. The right tools
Use the recommended special tools to protect parts from damage. Use the right tool in the right manner – do not improvise.
2. Tightening torque
Follow the tightening torque instructions. When tightening bolts, nuts and screws, tighten the large sizes first, and tighten inner-positioned fixings before outer-positioned ones.




SAFETY WHILE WORKING

E




3. Non-reusable items

Always use new gaskets, packings, O-rings, split-pins, circlips, etc., on reassembly.



DISASSEMBLY AND ASSEMBLY

1. Clean parts with compressed air when disassembling.
2. Oil the contact surfaces of moving parts before assembly.



3. After assembly, check that moving parts operate normally.


4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.
5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.

SPECIAL TOOLS

Using the correct special tools recommended by Yamaha, will aid the work and enable accurate assembly and tune-up. Improvising and using improper tools can damage the equipment.


NOTE:

- For USA and Canada, use part numbers that start with "J-", "YB-", "YM-", "YS-", "YU-" or "YW-".
- For worldwide, use part numbers that start with "90890-".



MEASURING

- ① Tachometer
 P/N. YU-08036-A (a)
 90890-06760 (b)
- ② Fuel pressure gauge
 P/N. YB-06766
 90890-06786
- ③ Mity vac
 P/N. YB-35956
 90890-06756
- ④ Pressure tester
 P/N. YB-35956
 90890-06762
- ⑤ Digital caliper
 P/N. 90890-06704
- ⑥ Pinion height gauge
 P/N. YB-34432-7, YB-34432-11 (a)
 90890-06702 (b)
- ⑦ Shimming gauge
 P/N. YB-34446-1, YB-34446-3,
 YB-34446-4, YB-34446-7,
 YB-34446-8
- ⑧ Shimming gauge
 P/N. YB-34468-1, YB-34468-2
- ⑨ Shimming plate
 P/N. 90890-06701
- ⑩ Shift rod wrench
 P/N. YB-06052 (a)
 90890-06052 (b)



- ⑪ Magnetic base
P/N. YU-34481
90890-06705
- ⑫ Magnetic base attaching plate
P/N. YB-07003
90890-07003
- ⑬ Backlash indicator
P/N. YB-06265
90890-06706
- ⑭ Dial gauge set
P/N. YU-03097
90890-01252
- ⑮ Hydraulic pressure gauge
P/N. 90890-06776
- ⑯ Up-relief valve attachment
P/N. 90890-06773
Down-relief valve attachment
P/N. 90890-06774
- ⑰ Digital tester
P/N. J-39299 (a)
90890-06752 (b)
- ⑱ Peak voltage adapter
P/N. YU-39991 (a)
90890-03169 (b)
- ⑲ Spark gap tester
P/N. YM-34487 (a)
90890-06754 (b)
- ⑳ Test harness
P/N. YB-06443, YB-06767,
YB-06768, YB-06769,
YB-06779, YB-06787,
YB-06788
90890-06757, 90890-06767,
90890-06768, 90890-06769,
90890-06779, 90890-06787,
90890-06788
- ㉑ Diagnostic indicator
P/N. YB-06765
90890-06765



- ② Diagnostic unit
Check the engine condition by using a personal computer when it is connected to the Electronic Control Unit (ECU).

Diagnosis:
Indicates the name of a failed part.

Diagnosis record:
Displays the name of the part whose diagnosis is detected, along with the engine running total hours.

Static test:
Checks operation sound and ignition sparks by activating the electric fuel pump, electric oil pump, injector and spark plug while the engine is stopped.


Dynamic test:
Checks the engine for operation through any change in its speed by stopping the operation of the spark plug on each cylinder while the engine is in the neutral position.

Engine monitor:
Indicates information on the sensors and switches by converting it to each value while the engine is running.

Data logger:
Indicates in numeric values the engine speed, throttle opening voltage, oxygen density sensor voltage, water temperature sensor voltage and fuel pressure sensor voltage that occurred within 13 minutes.

ECU information:
Displays the ECU identification number.

NOTE: _____
To use any of these functions a personal computer, connection cables, adapter and communication software are required.
The personal computer should be compatible with Windows® 95/98, equipped with a CD-ROM and the RS232C terminal.




REMOVING AND INSTALLING

- ① Flywheel magnet assembly holder
 P/N. YB-06139 (a)
 90890-06522 (b)
- ② Universal puller
 P/N. YB-06117 (a)
 90890-06521 (b)
- ③ Bearing/oil seal attachment
 P/N. YB-06205 (a)
 90890-06663 (b)
- ④ Piston ring compressor
 P/N. YU-33294 (a)
 90890-06530 (b)
- ⑤ Bearing separator
 P/N. YB-06219 (a)
 90890-06534 (b)
- ⑥ Guide plate stand
 P/N. 90890-06538
- ⑦ Guide plate
 P/N. 90890-06501
- ⑧ Bearing puller
 P/N. 90890-06535
- ⑨ Small universal claws
 P/N. 90890-06536
- ⑩ Ring nut wrench
 P/N. YB-34447 (a)
 90890-06512 (b)
- ⑪ Ring nut wrench extension
 P/N. 90890-06513



SPECIAL TOOLS

E




- ⑫ Propeller shaft housing puller
 P/N. YB-06207 ①
 90890-06502 ②
- ⑬ Center bolt
 P/N. 90890-06504
- ⑭ Slide hammer
 P/N. YB-06096
 90890-06531
- ⑮ Drive shaft holder
 P/N. YB-06201
 90890-06520
- ⑯ Pinion nut holder
 P/N. 90890-06505
- ⑰ Pinion nut holder attachment
 P/N. 90890-06508
- ⑱ Bearing puller
 P/N. YB-06029, YB-06247
 90890-06523
- ⑲ Large universal claws
 P/N. 90890-06532
- ⑳ Driver rod
 P/N. YB-06071
 90890-06604, 90890-06605,
 90890-06606, 90890-06652
- ㉑ Bearing/oil seal depth plate
 P/N. 90890-06603
- ㉒ Bearing/oil seal attachment
 P/N. YB-06194, YB-06196, YB-06246
- ㉓ Bearing/oil seal attachment
 P/N. YB-06195, YB-06258
- ㉔ Bearing/oil seal attachment
 P/N. YB-06200
- ㉕ Bearing/oil seal attachment
 P/N. YB-06336
- ㉖ Bearing/oil seal attachment
 P/N. 90890-06610, 90890-06612,
 90890-06631, 90890-06633,
 90890-06636, 90890-06653,
 90890-06654
- ㉗ Bearing/oil seal attachment
 P/N. 90890-06619, 90890-06622
- ㉘ Bearing/oil seal attachment
 P/N. 90890-06629



SPECIAL TOOLS

E



- ②⑨ Bearing/oil seal attachment
P/N. 90890-06637
- ③⑩ Bearing/oil seal attachment
P/N. 90890-06659, 90890-06660,
90890-06661, 90890-06662
- ③① Slide hammer attachment
P/N. YB-06335
90890-06514
- ③② End screw wrench
P/N. YB-06548
90890-06548
- ③③ End screw wrench
P/N. YB-06175-1A
- ③④ Universal holder
P/N. YU-01235
90890-01235
- ③⑤ Sheave holder
P/N. YS-1880-A
90890-01701
- ③⑥ Universal puller
P/N. YB-06540
90890-06540



CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-3
POWER UNIT.....	2-3
LOWER UNIT.....	2-5
ELECTRICAL	2-5
DIMENSIONS	2-9
TIGHTENING TORQUES	2-11
SPECIFIED TORQUES	2-11
GENERAL TORQUES.....	2-13



GENERAL SPECIFICATIONS

E

GENERAL SPECIFICATIONS

Item	Worldwide USA Canada		Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
DIMENSION					
Overall length		mm (in)	792 (31.2)		
Overall width		mm (in)	554 (21.8)		
Overall height (X)		mm (in)	1,782 (70.2)		
Boat transom height (X)		mm (in)	635 (25.0)		
WEIGHT					
(with aluminum propeller) (X)		kg (lb)	218 (480.6)		
(with stainless steel propeller) (X)		kg (lb)	222 (489.4)		
PERFORMANCE					
Maximum output (ISO)		kW (hp) @ 5,000 r/min	147.1 (200)		
Full throttle operating range		r/min	4,500 - 5,500		
Maximum fuel consumption		L (US gal, Imp gal)/hr @ 5,500 r/min	68 (18.0, 15.0)		
POWER UNIT					
Type			2 stroke - V		
Number of cylinders			6		
Displacement		cm ³ (cu. in)	2,596 (158.4)		
Bore × stroke		mm (in)	90.0 × 68.0 (3.54 × 2.68)		
Compression ratio			Cylinders #1 - #4: 6.4 Cylinders #5 - #6: 6.1		
Fuel system			Electronic fuel injection		
Fuel injection system			Sequential injection		
Intake system			Reed valve		
Induction system			Loop charge		
Starting system			Electric		
Ignition control system			Microcomputer		
Alternator output		V - A	12 - 45		
Spark plugs (NGK)			BKR7ES-11		
Cooling system			Water		
Exhaust system			Through propeller boss		
Lubrication system			Oil injection		



GENERAL SPECIFICATIONS

E

Item			Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
FUEL AND OIL					
Fuel type			Unleaded regular gasoline		
Fuel rating			*PON 86 RON 91		
Engine oil type			2-stroke outboard engine oil		
Engine oil grade			TC-W3		
Engine oil capacity (engine oil tank)	L (US qt, Imp qt)		0.9 (0.95, 0.79)		
(sub-oil tank)	L (US qt, Imp qt)		10.5 (11.1, 9.2)		
Gear oil type			Hypoid gear oil SAE 90		
Gear oil total quantity	cm ³ (US oz, Imp oz)		980 (33.1, 34.5)	870 (29.4, 30.6)	
BRACKET					
Trim angle (at 12° boat transom)	Degree		-4 - 16		
Tilt-up angle	Degree		70		
Steering angle	Degree		32 + 32		
DRIVE UNIT					
Gear shift positions			F-N-R		
Gear ratio			1.86 (26/14)		
Reduction gear type			Spiral bevel gear		
Clutch type			Dog clutch		
Propeller shaft type			Spline		
Propeller direction (rear view)			Clockwise	Counterclockwise	
Propeller mark			M	ML	
ELECTRICAL					
Battery capacity	Ah (kC)		100 (360)		
Minimum cold cranking performance	A		512		






* PON: Pump Octane Number (Research octane + Motor octane)/2
 RON: Research Octane Number




MAINTENANCE SPECIFICATIONS

E






**MAINTENANCE SPECIFICATIONS
 POWER UNIT**

Item	Worldwide USA Canada	Unit	Model	
			Z200NETO	LZ200NETO
			Z200TR	LZ200TR
			Z200TR	—
CYLINDER HEADS				
Warpage limit		mm (in)	0.1 (0.004)	
 <p>(lines indicate straightedge position)</p>				
CYLINDERS				
Bore size		mm (in)	90.00 - 90.02 (3.543 - 3.544)	
Wear limit		mm (in)	90.1 (3.55)	
Taper limit		mm (in)	0.08 (0.003)	
Out-of-round limit		mm (in)	0.05 (0.002)	
PISTONS				
Piston diameter (D)		mm (in)	89.845 - 89.869 (3.5372 - 3.5381)	
Measuring point (H)		mm (in)	10 (0.4)	
Piston-to-cylinder clearance <Limit>		mm (in)	0.150 - 0.156 (0.0059 - 0.0061)	
		mm (in)	0.206 (0.0081)	
Oversize piston diameter				
1st	mm (in)	90.11 (3.548)		
2nd	mm (in)	90.36 (3.557)		
PISTON RINGS				
Type			Keystone	
(B)		mm (in)	2.0 (0.079)	
(T)		mm (in)	2.8 (0.110)	
End gap (installed) <Limit>		mm (in)	0.30 - 0.40 (0.012 - 0.016)	
	mm (in)	0.60 (0.024)		
Side clearance	mm (in)	0.02 - 0.06 (0.001 - 0.002)		
CRANKSHAFT				
Runout limit		mm (in)	0.05 (0.002)	
				



MAINTENANCE SPECIFICATIONS

E

Item	Worldwide USA Canada		Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
CONNECTING RODS					
Small-end axial play limit (F)			mm (in)	2.0 (0.08)	
Big-end side clearance (E)			mm (in)	0.12 - 0.26 (0.005 - 0.010)	
OIL INJECTION PUMP					
ID mark				68F00	
Bleeding				Screw type	
REED VALVES					
Reed valve stopper height (a)			mm (in)	9.0 ± 0.35 (0.35 ± 0.01)	
Warpage limit (b)			mm (in)	0.2 (0.008)	
THERMOSTATS					
Opening temperature			°C (°F)	48 - 52 (118 - 126)	
Full-open temperature			°C (°F)	60 (140)	
					
Valve open lower limit			mm (in)	3 (0.12)	
ENGINE SPEED					
Idling speed			r/min	700 ± 30	



MAINTENANCE SPECIFICATIONS

E

LOWER UNIT

Item	Model	
	Worldwide	Unit
	USA	Z200NETO
	Canada	LZ200NETO
		Z200TR
GEAR BACKLASH		
Pinion - forward gear	mm (in)	0.25 - 0.46 (0.010 - 0.018)
Pinion - reverse gear	mm (in)	0.74 - 1.29 (0.029 - 0.051)
Pinion shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50
Forward gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50
Reverse gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50

ELECTRICAL

Item	Model	
	Worldwide	Unit
	USA	Z200NETO
	Canada	LZ200NETO
		Z200TR
IGNITION SYSTEM		
Ignition timing (#1)	Degree	ATDC 3 - BTDC 17
Fuse 1	V-A	12-80
Fuse 2	V-A	12-30
Fuse 3	V-A	12-20
Control unit (B/O, B/Y, B/L, B/Br, B/G, B/W - R/Y)		
Output peak voltage lower limit		
@ cranking 1	V	—
@ cranking 2	V	140
@ 1,500 r/min	V	205
@ 3,500 r/min	V	220
Pulser coil (W/R, W/Y, W/G, W/B, W/L, W/Br - B)		
Output peak voltage lower limit		
@ cranking 1	V	5.0
@ cranking 2	V	5.0
@ 1,500 r/min	V	20
@ 3,500 r/min	V	35

* Cranking 1: Open circuit voltage.
 Cranking 2: Loaded circuit voltage.



MAINTENANCE SPECIFICATIONS

E


Item	Unit		Model			
			Z200NETO	LZ200NETO		
			Z200TR	LZ200TR		
			Z200TR	—		
IGNITION CONTROL SYSTEM						
Crank position sensor (G/L)	mm (in)	$1.0 \pm 0.5 (0.04 \pm 0.02)$				
Crank-position-sensor-to-flywheel gap						
Output peak voltage lower limit						
@ cranking 1					V	4.5
@ cranking 2					V	4.0
		V	13			
		V	20			
Engine cooling water temperature sensor						
Resistance (B/Y – B/Y)						
@ 5°C (41°F)	kΩ	128				
@ 20°C (68°F)	kΩ	54 - 69				
@ 100°C (212°F)	kΩ	3.02 - 3.48				
Throttle position sensor						
Input voltage (O – R)	V	4.75 - 5.25				
Output voltage (P – O)	V	0.50 ± 0.02				
Thermo switch (P – B)						
OFF → ON	°C (°F)	84 - 90 (183 - 194)				
ON → OFF	°C (°F)	60 - 74 (140 - 165)				
FUEL CONTROL SYSTEM						
Oxygen density sensor						
Heater resistance (R/W – B)	Ω	2 - 100				
Output voltage (Gy – B/W)	V	0.0 - 1.0				
Atmospheric pressure sensor						
Output voltage (at 101.32 kPa) (P – B)	V	3.2 - 4.6				
Intake air temperature sensor						
Resistance (B/Y – B/Y)	kΩ	1.5 - 4.0				
Injector driver (O/R – Pu/R, O/B – Pu/B, O/Y – Pu/Y, O/G – Pu/G, O/L – Pu/L, O/W – Pu/W)						
Output peak voltage lower limit						
@ cranking 1	V	65				
@ cranking 2	V	60				
@ 1,500 r/min	V	65				
@ 3,500 r/min	V	65				

* Cranking 1: Open circuit voltage.
 Cranking 2: Loaded circuit voltage.



MAINTENANCE SPECIFICATIONS

E

Item			Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
Fuel pressure sensor Output voltage (P – B)		V	2.8 - 3.2		
Water detection switch Float position ① "ON"		mm (in)	47		
STARTER MOTOR					
Type			Sliding gear		
Output		kW	1.4		
Cranking time limit		Second	30		
Brushes					
Standard length		mm (in)	15.5 (0.61)		
Wear limit		mm (in)	9.5 (0.37)		
Commutator					
Standard diameter		mm (in)	29.0 (1.14)		
Wear limit		mm (in)	28.0 (1.10)		
Mica					
Standard undercut		mm (in)	0.5 - 0.8 (0.02 - 0.03)		
Wear limit		mm (in)	0.2 (0.01)		
CHARGING SYSTEM					
Rectifier/regulator (R – B)					
Output peak voltage lower limit					
@ cranking 1		V	—		
@ cranking 2		V	7.5		
@ 1,500 r/min		V	12.7		
@ 3,500 r/min		V	12.7		
Lighting coil (G – G)					
Output peak voltage lower limit					
@ cranking 1		V	7.5		
@ cranking 2		V	8.0		
@ 1,500 r/min		V	12		
@ 3,500 r/min		V	12		

* Cranking 1: Open circuit voltage.
 Cranking 2: Loaded circuit voltage.



MAINTENANCE SPECIFICATIONS

E


Item			Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
OIL FEED PUMP CONTROL SYSTEM					
Oil level sensor (engine oil tank)			mm (in)	3 - 6 (0.12 - 0.24)	
Float position ① "OFF"			mm (in)	33 - 36 (1.30 - 1.42)	
Float position ② "ON"			mm (in)	53 - 56 (2.09 - 2.20)	
Oil level switch (sub-oil tank)			mm (in)	150 - 153 (5.91 - 6.02)	
Float position ④ "ON"			mm (in)		
POWER TRIM AND TILT SYSTEM					
Trim sensor					
Setting resistance			Ω	80 ± 12	
Resistance (P - B)			Ω	582 - 873	
Resistance (O - B)			Ω	800 - 1,200	
POWER TRIM AND TILT MOTOR					
Fluid type				ATF Dexron II	
Brushes					
Standard length			mm (in)	9.8 (0.39)	
Wear limit			mm (in)	4.8 (0.19)	
Commutator					
Standard diameter			mm (in)	22.0 (0.87)	
Wear limit			mm (in)	21.0 (0.83)	
Mica					
Standard undercut			mm (in)	1.35 (0.05)	
Wear limit			mm (in)	0.85 (0.03)	



MAINTENANCE SPECIFICATIONS

E

DIMENSIONS




Symbol	Worldwide		Unit	Models	
	USA	Canada		Z200NETO	LZ200NETO
				Z200TR	LZ200TR
L1			mm (in)		613 (24.1)
L2			mm (in)		180 (7.1)
L4			mm (in)		646 (25.4)
L5			mm (in)		69 (2.7)
L6			mm (in)		1,150 (45.3)
L7			mm (in)		574 (22.6)
H1			mm (in)		1,074 (42.3)
H2			mm (in)		708 (27.9)
H3			mm (in)		211 (8.3)
H4			mm (in)		643 (25.3)
H6			mm (in)		850 (33.4)
H7			mm (in)		308 (12.1)
H9			mm (in)		835 (32.9)
W1			mm (in)		277 (10.9)
W5			mm (in)		396 (15.6)

SPEC



MAINTENANCE SPECIFICATIONS

E



Symbol	Unit	Models	
		Z200NETO	LZ200NETO
Worldwide		Z200TR	LZ200TR
USA		Z200TR	—
Canada			
B1	mm (in)	125.4 (4.9)	
B2	mm (in)	254 (10.0)	
B3	mm (in)	163.5 (6.4)	
B4	mm (in)	50.8 (2.0)	
B5	mm (in)	180 (7.1)	
B6	mm (in)	367 (14.4)	
B9	mm (in)	18.5 (0.7)	
C3	mm (in)	82 (3.2)	
D1	mm (in)	13 (0.5)	
D2	mm (in)	55.5 (2.2)	



TIGHTENING TORQUES

E

TIGHTENING TORQUES SPECIFIED TORQUES

Part to be tightened		Thread size	Tightening torques		
			Nm	m•kgf	ft•lb
POWER UNIT					
Intake silencer		M6	3	0.3	2.2
Electric oil pump		M6	8	0.8	5.8
Fuel injection unit		M6	10	1.0	7.2
Atmospheric pressure sensor		M6	4	0.4	2.9
Electric oil pump bracket		M6	8	0.8	5.8
Throttle position sensor		M5	4	0.4	2.9
Intake air temperature sensor		M12	8	0.8	5.8
Drive belt tensioner		M10	40	4.0	29
Mechanical fuel pump		M8	23	2.3	17
Fuel rail		M8	23	2.3	17
Fuel injector cap		M8	26	2.6	19
Fuel filter nut holder		M6	8	0.8	5.8
Oil pump		M6	7	0.7	5.1
Emergency switch		—	4	0.4	2.9
Flywheel magnet assembly		M20	190	19	137
Negative battery lead		M8	9	0.9	6.5
Positive battery lead		M8	9	0.9	6.5
Apron		M6	8	0.8	5.8
Power unit mount		M8	21	2.1	15
Starter relay holder		M5	3	0.3	2.2
Oxygen density sensor cover		M6	9	0.9	6.5
Oxygen density sensor bracket		M6	14	1.4	10
Oxygen density sensor		M18	49	4.9	35
Reed valve assembly		M6	10	1.0	7.2
Reed valve		M5	3	0.3	2.2
Reed valve stopper		M3	1	0.1	0.7
Shift position switch		M4	3	0.3	2.2
Spark plug		M14	25	2.5	18
Thermostat cover	1st	M6	5	0.5	3.6
	2nd		11	1.1	8.0
Cylinder head cover	1st	M6	5	0.5	3.6
	2nd		11	1.1	8.0
Engine cooling water temperature sensor		—	15	1.5	11
Cylinder head	1st	M8	15	1.5	11
	2nd		30	3.0	22
Cooling water pressure control valve cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Exhaust port outer cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8



TIGHTENING TORQUES

E

Part to be tightened		Thread size	Tightening torques		
			Nm	m•kgf	ft•lb
Crankcase	1st	M8	10	1.0	7.2
	2nd		18	1.8	13
	1st	M10	20	2.0	14
	2nd		40	4.0	29
Connecting rod	1st	M8	19	1.9	14
	2nd		37	3.7	27
	3rd		*		
	4th		19	1.9	14
	5th		37	3.7	27
LOWER UNIT					
Propeller		M18	55	5.5	40
Lower unit		M10	40	4.0	29
Ring nut		—	145	14.5	105
Pinion nut		M22	95	9.5	68
Gear oil drain screw		—	7	0.7	5.1
Gear oil level check screw		—	7	0.7	5.1
BRACKET UNIT					
Flushing hose		M5	5	0.5	3.6
Shift rod detent mechanism screw		—	24	2.4	17
Upper mount		M12	53	5.3	38
Lower mount		M14	73	7.3	53
Exhaust manifold assembly		M8	21	2.1	15
Muffler		M8	18	1.8	13
Exhaust manifold		M8	18	1.8	13
Lower exhaust manifold guide		M8	18	1.8	13
Clamp bracket		M22	15	1.5	11
Trim sensor stopper		M6	2	0.2	1.4
Trim stopper		—	37	3.7	27
POWER TRIM AND TILT UNIT					
Power trim and tilt reservoir cap		—	8	0.8	5.8
Power trim and tilt reservoir		1/4"	5	0.5	3.6
Power trim and tilt motor		1/4"	5	0.5	3.6
Manual valve		—	4	0.4	2.9
Tilt ram end screw		—	130	13	94
Gear pump unit		5/16"	9	0.9	6.5
Gear pump		—	6	0.6	4.3
Trim ram end screw		—	80	8.0	52

*: Loosen




TIGHTENING TORQUES

E

Nut (A)	Bolt (B)	General torque specifications		
		Nm	m•kgf	ft•lb
8 mm	M5	5	0.5	3.6
10 mm	M6	8	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

GENERAL TORQUES

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided in applicable sections of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.





CHAPTER 3

PERIODIC INSPECTIONS AND ADJUSTMENTS

MAINTENANCE INTERVAL CHART	3-1
TOP COWLING	3-3
CHECKING THE TOP COWLING FIT	3-3
FUEL SYSTEM	3-3
CHECKING THE FUEL LINE	3-3
CHECKING THE FUEL FILTER	3-4
MEASURING THE FUEL PRESSURE (MEDIUM-PRESSURE FUEL LINE)	3-5
CHECKING THE FUEL PRESSURE (MECHANICAL FUEL PUMP)	3-5
CHECKING THE MECHANICAL FUEL PUMP OIL LEVEL	3-6
CHANGING THE MECHANICAL FUEL PUMP OIL	3-6
CONTROL SYSTEM	3-7
SYNCHRONIZING THE THROTTLE VALVES	3-7
ADJUSTING THE THROTTLE POSITION SENSOR	3-8
ADJUSTING THE ENGINE IDLING SPEED	3-9
ADJUSTING THE REMOTE CONTROL SHIFT CABLE	3-10
ADJUSTING THE REMOTE CONTROL THROTTLE CABLE	3-10
CHECKING THE DRIVE BELT	3-11
ADJUSTING THE CRANK POSITION SENSOR	3-12
COOLING SYSTEM	3-12
CHECKING THE COOLING WATER DISCHARGE	3-12
OIL INJECTION SYSTEM	3-12
CHECKING THE OIL STRAINER	3-12
SYNCHRONIZING THE OIL PUMP	3-13
AIR BLEEDING THE OIL INJECTION SYSTEM	3-14
CHECKING THE ELECTRIC OIL PUMP	3-14
POWER TRIM AND TILT SYSTEM	3-15
CHECKING THE POWER TRIM AND TILT FLUID LEVEL	3-15
ADJUSTING THE TRIM SENSOR CAM	3-16
LOWER UNIT	3-16
CHECKING THE GEAR OIL LEVEL	3-16
CHANGING AND CHECKING THE GEAR OIL	3-17
CHECKING THE LOWER UNIT (FOR AIR LEAKS)	3-18



GENERAL	3-18
CHECKING THE ANODES.....	3-18
CHECKING THE BATTERY.....	3-19
CHECKING THE SPARK PLUGS.....	3-20
LUBRICATION POINTS.....	3-22



MAINTENANCE INTERVAL CHART

E

MAINTENANCE INTERVAL CHART

Use the following chart as a guide to general maintenance intervals.

Dependant on operating conditions, adjust the maintenance intervals accordingly.

Item	Remarks	Initial		Every		Refer to page
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
TOP COWLING						
Top cowling fit	Check				○	3-3
FUEL SYSTEM						
Fuel line	Check	○	○	○		3-3
Fuel filter	Clean/check	○	○	○		3-4
Mechanical fuel pump oil	Change				○	3-6
Fuel tank	Clean				○	—
POWER UNIT						
Water leakage	Check	○	○	○		—
Motor exterior	Check	○	○	○		—
Exhaust leakage	Check	○	○	○		—
Cooling water passage ^(*1)	Clean		○	○		—
CONTROL SYSTEM						
Throttle valve synchronization	Check/adjust				○	3-7
Engine idling speed	Check/adjust	○		○		3-9
Throttle position sensor	Check/adjust				○	3-8
Remote control shift cable	Check/adjust				○	3-10
Remote control throttle cable	Check/adjust				○	3-10
Drive belt ^(*2)	Check/adjust				○	3-11
OIL INJECTION SYSTEM						
Oil tank water drain	Clean	○	○	○		—
Oil pump lever	Check/adjust	○				3-13
POWER TRIM AND TILT UNIT						
Power trim and tilt fluid	Check	○	○	○		3-15
LOWER UNIT						
Gear oil	Change	○		○		3-16
Lower unit leakage	Check				○	3-18
Propeller and cotter pin	Check/replace	○	○	○		6-3, 6-30

(*1) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

(*2) Be sure to replace the drive belt after every 1,000 hours (5 years) of operation.