



www.delta.com.tw/industrialautomation

ASIA

Delta Electronics, Inc.

31-1, Xingbang Road, Guishan Industrial Zone, Taoyuan County 33370, Taiwan TEL: 886-3-362-6301 / FAX: 886-3-362-7267

Delta Electronics (Jiang Su) Ltd.

Wujiang Plant3
1688 Jiangxing East Road,
Wujiang Economy Development Zone,
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Electronics (Japan), Inc.

Delta Shibadaimon Building, 2-1-14 Shibadaimon, Minato-Ku, Tokyo, 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211



Delta Electronics (Korea), Inc. Donghwa B/D 3F, 235-6, Nonhyun-dong, Kangnam-gu, Seoul 135-010, Korea TEL: 82-2-515-5303/5 / FAX: 82-2-515-5302

Delta Electronics (Singapore) Pte. Ltd. 8 Kaki Bukit Road 2, #04-18 Ruby Warehouse Complex, Singapore 417841 TEL: 65-747-5155 / FAX: 65-744-9228

AMERICA

Delta Products Corporation (USA)

Raleigh Office
P.O. Box 12173,5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

EUROPE

Deltronics (The Netherlands) B.V.

De Witbogt 15, 5652 AG Eindhoven, The Netherlands TEL: 31-40-2592850 / FAX: 31-40-2592851

*We reserve the right to change the information in this manual without prior notice



ANELTA W-D-G

User Manual

Specific AC Motor Drives for Plastic Molding and Air Compressors Machinery



Preface

Thank you for choosing DELTA's VFD-G series for plastic molding and air compressors machinery. VFD-G Series are manufactured by adopting high-quality components, material and incorporating the latest microprocessor technology available.


Getting Started

This manual will be helpful in the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drives. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC drives. Keep this operating manual handy and distribute to all users for reference.





Always read this manual thoroughly before using VFD-G series AC Motor Drives.





CAUTION! There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To avoid damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.



DANGER! A charge may still remain in the DC-link capacitor with hazardous voltages even if the power has been turned off. To avoid personal injury, do not remove the cover of the AC drive until all "DISPLAY LED" lights on the digital keypad are off. Please note that there are live components exposed within the AC drive. Do not touch these live parts.



CAUTION! Ground the VFD-G using the ground terminal. The grounding method must comply with the laws of the country where the AC drive is to be installed. Refer to Basic Wiring Diagram.



DANGER! The AC drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC drive output terminals U/T1, V/T2, and W/T3 directly to the AC main circuit power supply.



CAUTION! The final enclosures of the AC drive must comply with EN50178. (Live parts shall be arranged in enclosures or located behind barriers that meet at least the requirements of the Protective Type IP20. The top surface of the enclosures or barrier that is easily accessible shall meet at least the requirements of the Protective Type IP40). (VFD-G series corresponds with this regulation.)



CAUTION! Heat sink may heat up over 70°C (158°F), during the operation. Do not touch the heat sink.



CHAPTER 1	RECEIVING AND INSPECTIONS
1.1 Namep	plate Information1 - 1
1.2 Model	Explanation1 - 1
1.3 Serial I	Number Explanation1 - 2
CHAPTER 2	STORAGE AND INSTALLATION
2.1 Storage	e2 - 1
2.2 Installa	tion2 - 2
CHAPTER 3	WIRING
3.1 Basic V	Viring Diagram3 - 2
3.2 Termina	al Explanations3-4
3.3 Contro	l Terminal Explanations3 - 4
3.4 Main C	ircuit Wiring3 - 5
3.5 Wiring	Notes3 - 9
3.6 Motor (Operation Precautions3-10
CHAPTER 4	DIGITAL KEYPAD OPERATION
4.1 Descrip	otion of the Digital Keypad VFD-PU014 - 2
4.2 Operat	ion steps of the Digital Keypad VFD-PU014 - 4
CHAPTER 5	DESCRIPTION OF PARAMETER SETTINGS
5.1 Group	0: AC Drive Status Parameters5 - 1
5.2 Group	1: Basic Parameters5 - 4
5.3 Group	2: Operation Method Parameters5 - 8



5.4 Group 3	3: Output Function Parameters	5-13
5.5 Group 4	4: Input Function Parameters	5-16
5.6 Group 5	5: Multi-step Speed Frequency Parameters	5-21
5.7 Group 6	S: Protection Function Parameters	5-27
5.8 Group 7	7: AC Drive and Motor Parameters	5-33
5.9 Group 8	8: Special Parameters	5-37
5.10 Group	9: Communication Parameters	5-43
5.11 Group	10: PID Control Parameters	5-59
CHAPTER 6	MAINTENANCE AND INSPECTIONS	
6.1 Periodic	Inspection	6 - 1
6.2 Periodic	Maintenance	6 - 1
CHAPTER 7	TROUBLESHOOTING AND FAULT INFORMATION	7 - 1
CHAPTER 8	PARAMETER SUMMARY	8 - 1
APPENDIX A	SPECIFICATIONS	A - 1
APPENDIX B	ACCESSORIES	
B.1 All Brak	ring Resistors & Braking Units Use in AC Drives	B - 1
APPENDIX C	DIMENSIONS	C - 1








CHAPTER 1 RECEIVING AND INSPECTION

This VFD-G AC drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC drive, please check for the following:


Receiving

- ✓ Check to make sure that the package includes an AC drive, the User Manual, dust covers and rubber bushings.
- ✓ Inspect the unit to insure it was not damaged during shipment.
- ✓ Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

1.1 Nameplate Information: Example for 10HP/7.5kW 3-phase 460V AC drive




1.2 Model Explanation





1.3 Serial Number Explanation



If there is any nameplate information not corresponding to your purchase order or any problem, please contact your distributor.



CHAPTER 2 STORAGE AND INSTALLATION

2.1 Storage

The AC drive should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time.

Ambient Conditions:

Operation Air Temperature: -10° C to $+40^{\circ}$ C (14°F to 104°F)

+50°C (122°F) without dust cover.

Atmosphere pressure: 86 to 106 kPa Installation Site Altitude: below 1000m

Vibration: Maximum 9.80 m/s² (1G) at less than 20Hz Maximum 5.88 m/s² (0.6G) at 20Hz to 50Hz

Storage Temperature: -20°C to +65°C (-4°F to 149°F)

Relative Humidity: Less than 90%, no condensation allowed

Atmosphere pressure: 86 to 106 kPa

Transportation Temperature: -20°C to +60°C (-4°F to 140°F)

Relative Humidity: Less than 90%, no condensation allowed

Atmosphere pressure: 86 to 106 kPa

Vibration: Maximum 9.86 m/s² (1G) at less than 20Hz, Maximum 5.88

 m/s^2 (0.6G) at 20Hz to 50Hz

Pollution Degree 2: good for a factory type environment.



2.2 Installation

• CAUTION


The control, power supply and motor leads must be laid separately. They must not be fed through the same cable conduit / trunking.


High voltage insulation test equipment must not be used on cables connected to the drive.

Improper installation of the AC drive will greatly reduce its life. Be sure to observe the following precautions when selecting a mounting location.

Failure to observe these precautions may void the warranty!

- Do not mount the AC drive near heat-radiating elements or in direct sunlight.
- Do not install the AC drive in a place subjected to high temperature, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- Mount the AC drive vertically and do not restrict the air flow to the heat sink fins.
- The AC drive generates heat. Allow sufficient space around the unit for heat dissipation.







CHAPTER 3 WIRING



DANGER

Hazardous Voltage

Before accessing the AC drive:

- Disconnect all power to the AC drive.
- Wait five minutes for DC bus capacitors discharge.

Any electrical or mechanical modification to this equipment without prior written consent of Delta Electronics, Inc. will void all warranties and may result in a safety hazard in addition to voiding the UL listing.


Short Circuit Withstand:

The rated voltage must be equal to or less than 480V and the current must be equal to or less than 5000A RMS. (the model of 51HP and above is 10000A RMS)




3.1 Basic Wiring Diagram

Users must connect wires according to the following circuit diagram shown below. Do not plug a Modem or telephone line to the RS-485 communication port, permanent damage may result. Pins 1 & 2 are the power sources for the optional copy keypad and should not be used while using RS-485 communication.





Wiring for SINK mode and SOURCE mode





3.2 Terminal Explanations

Terminal Symbol	Explanation of Terminal Function		
R/L1, S/L2, T/L3	AC line input terminals		
U/T1, V/T2, W/T3	AC drive output terminals motor connections		
+1, +2	Connections for DC Link Reactor (optional)		
+2/B1~B2	Connections for Braking Resistor (optional)		
+2~ -, +2/B1~ -	Connections for External Braking Unit (VFDB series)		
(<u>+</u>)	Earth Ground		

3.3 Control Terminal Explanations


Terminal Symbols	Terminal Functions	Factory Settings
FWD	Forward-Stop command	
REV	Reverse- Stop command	
EF	External fault	
MI1	Multi-function Input 1	Factory default: Multi-step speed command 1
MI2	Multi-function Input 2	Factory default: Multi-step speed command 2
MI3	Multi-function Input 3	Factory default: Multi-step speed command 3
MI4	Multi-function Input 4	Factory default: Multi-step speed command 4
+24V	DC Voltage Source	(+24V, 20mA), used for source mode.
DCM	Digital Signal Common	Used as common for digital inputs and used for sink mode.
AFM 1	Analog frequency /current meter 1	0 to 10V correspond to Max. operation frequency
AFM 2	Analog frequency /current meter 2	4 to 20mA correspond to 2 times of output current
AOM	Analog control signal (common)	
RA 1	Multi-function Relay1 output (N.O.) a	1.5A(N.O.)/1A(N.C.) 240VAC
RB 1	Multi-function Relay1 output (N.C.) b	1.5A(N.O.)/1A(N.C.) 24VDC Refer to Pr.03-00 to Pr.03-01
RC 1	Multi-function Relay1 common	Therefore I have be to I have or
+12V/ACM	Potentiometer power source	+12V 20mA
Al1	Analog voltage Input	0 to +10V / 0 to 1A correspond to Max. operation frequency
Al2	Analog current Input	0 to +10V / 0 to 1A correspond to Max. operation frequency
AC1/AC2	Analog control signal common	

^{*} Control signal wiring size: 18 AWG (0.75 mm²).



3.4 Main Circuit Wiring

7.5 HP to 20 HP (VFD055F43B-G, VFD075F43B-G, VFD110F43A-G, VFD150F43A-G)



Control Terminal

Torque: 4Kgf-cm (3 in-lbf)

Wire: 12-24 AWG

Power Terminal

Torque: 30Kgf-cm (26 in-lbf)

Wire: 12-8 AWG


Wire Type: Stranded copper only, 75° C

NOTE: If wiring of the terminal utilizes the wire with a 6AWG-diameter, it is thus necessary

to use the Recognized Ring Terminal to conduct a proper wiring.



25 HP to 40 HP (VFD185F43A-G, VFD220F43A-G, VFD300F43A-G)



Control Terminal

Torque: 4Kgf-cm (3 in-lbf)

Wire: 12-24 AWG

Power Terminal

Torque: 30Kgf-cm (26 in-lbf)

Wire: 8-2 AWG


Wire Type: Stranded copper only, 75° C

NOTE: If wiring of the terminal utilizes the wire with a 1AWG-diameter, it is thus necessary

to use the Recognized Ring Terminal to conduct a proper wiring.



50 HP to 60 HP (VFD370F43A-G, VFD450F43A-G)



Control Terminal

Torque: 4Kgf-cm (3 in-lbf)

Wire: 12-24 AWG

Power Terminal


Torque: 57kgf-cm (49.5 in-lbf) min. Wire Gauge: VFD370F43A-G: 3AWG

VFD450F43A-G: 2AWG

Wire Type: Stranded copper only, 75° C



75 HP to 100 HP (VFD550F43A-G, VFD750F43A-G)



Control Terminal

Torque: 4Kgf-cm (3 in-lbf)

Wire: 12-24 AWG

Power Terminal

Torque: 200kgf-cm (173 in-lbf)

Wire Gauge: VFD550F43A-G: 1/0-4/0 AWG


VFD750F43A-G: 3/0-4/0 AWG

Wire Type: Stranded copper only, 75°C



3.5 Wiring Notes: PLEASE READ PRIOR TO INSTALLATION.

- 1. CAUTION: Do not connect the AC power to the U/T1, V/T2, W/T3 terminals, as it will damage the AC drive.
- 2. **WARNING**: Ensure all screws are tightened to the proper torque rating.
- 3. During installation, follow all local electrical, construction, and safety codes for the country the drive is to be installed in.
- 4. Ensure that the appropriate protective devices (circuit breaker or fuses) are connected between the power supply and AC drive.
- 5. Make sure that the leads are connected correctly and the AC drive is properly grounded. (Ground resistance should not exceed $0.1\,\Omega$.)
- 6. Use ground leads that comply with AWG/MCM standards and keep them as short as possible.
- 7. Multiple VFD-G units can be installed in one location. All the units should be grounded directly to a common ground terminal. The VFD-G ground terminals may also be connected in parallel, as shown in the figure below. **Ensure there are no ground loops.**



- 8. When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3, respectively, the motor will rotate counterclockwise (as viewed from the shaft ends of the motor) when a forward operation command is received. To reverse the direction of motor rotation, switch over any of the two motor leads.
- 9. Make sure that the power source is capable of supplying the correct voltage and required current to the AC drive.
- 10. Do not attach or remove wiring when power is applied to the AC drive.
- 11. Do not inspect components unless inside "CHARGE" lamp is turned off.
- 12. Do not monitor the signals on the circuit board while the AC drive is in operation.



- 13. For the single-phase rated AC drives, the AC power can be connected to any two of the three input terminals R/L1, S/L2, T/L3. **Note: This drive is not intended for the use with single-phase motors.**
- 14. Route the power and control wires separately, or at 90° angle to each other.
- 15. If a filter is required for reducing EMI (Electro Magnetic Interference), install it as close as possible to AC drive. EMI can also be reduced by lowering the Carrier Frequency.
- 16. If the AC drive is installed in the place where a load reactor is needed, install the filter close to U/T1, V/T2, W/T3, side of AC drive. Do not use a Capacitor or L-C Filter (Inductance-Capacitance) or R-C Filter (Resistance-Capacitance), unless approved by Delta.
- 17. When using a GFCI (Ground Fault Circuit Interrupt), select current sensor with sensitivity of 200mA, and not less than 0.1-second detection to avoid nuisance tripping.

3.6 Motor Operation Precautions

- 1. When using the AC drive to operate a standard 3-phase induction motor, notice that the energy loss is greater than for an inverter duty motor.
- 2. Avoid running a standard induction motor at low speed. Under these conditions, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan.
- 3. When the standard motor operates at low speed, the output load must be decreased.
- 4. If 100% output torque is desired at low speed, it may be necessary to use a special "inverter-duty" rated motor.




CHAPTER 4 DIGITAL KEYPAD OPERATION

This chapter describes the various controls and indicators found on the digital keypad/display PU01. The information in this chapter should be read and understood before performing the start—up procedures described in the chapter of parameter settings.


- ♦ Description of the Keypad
- ♦ Description of Display

VFD-PU01 Dimensions: mm (inch)





4.1 Description of the Digital Keypad VFD-PU01




Display Message	Descriptions	
[*] 80.00	Display the AC drive Master Frequency.	
H 50.00	Display the actual operation frequency present at terminals U/T1, V/T2, and W/T3.	
1800.0	Display voltage (V), Current (A), power factor and feedback signal (P)	




Display Message	Descriptions
8 5.0	Display the output current present at terminals U/T1, V/T2, and W/T3.
-F-d-	Display the AC drive forward run status.
50-	The AC drive reverse run status.
08-00	Display the specified parameter setting.
	Display the actual value stored within the specified parameter.
E.F.	External Fault.
-End-	Display "End" for approximately 1 second if input has been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the or keys.
-8	Display "Err", if the input is invalid.



4.2 Operation steps of the Digital Keypad VFD-PU01



Setting direction





CHAPTER 5 DESCRIPTION OF PARAMETER SETTINGS

5.1 Group 0: AC Drive Status Parameters

Group 0 is read-only.

00 - 00 Software Version Factory setting: Read Only

This parameter displays the software version of AC drive.

00 - 01 AC Drive Status Indication 1 Factory setting: Read Only

This parameter displays the AC drive status.

Code	AC Drive Status	Explanation
00	No fault occurred	·
01	ос	over current
02	OV	over voltage
03	оН	over temperature
04	oL	overload
05	oL1	electronic thermal relay
06	EF (external fault)	EF-DCM is closed
07	occ (AC drive IGBT fault)	IGBT short circuit protection
80	CF3 (CPU failure)	Abnormal A/D reading during self-check
09	HPF (hardware protection failure)	Hardware protection function activated
		during self-check.
10	ocA (over current during acceleration)	Output current exceeds protection level
		during acceleration
11	ocd (over current during deceleration)	Output current exceeds protection level
		during deceleration
12	Ocn (over current during steady state)	Output current exceeds protection level
		during steady state operation.
13	GFF (ground fault)	Ground fault protection feature activated
14	Lv (under voltage)	Low input voltage
15	CF1	EEPROM input data is abnormal
16	CF2	EEPROM output data is abnormal
17	bb (base block)	BB is set and activated
18	oL2 (over load 2)	Output current exceeds rated motor
		current
19	Reserved	
20	codE	software or password protection
21	EF1 (external emergency stop)	EF1 (a multifunction-DCM is enabled)
22	PHL (phase loss)	Input power lacks phase.
		3-phase input power is unbalance and
		exceeds specification.
23	Lc (Low Current)	Low current detection during operation.
24	FbL(Feedback Loss)	Feedback signal is abnormal.
25	Reserved	



00 - 02 AC Drive Status Indication 2 Factory setting: Read Only Display Bit 0~1: 00: Run LED is off and stop led is on. (AC Drive stopping) 01: Run LED is blink and stop led is on. (AC Drive deceleration to stop) 10: Run LED is on and stop led is blink. (AC Drive standby) 11: Run LED is on and stop led is off. (AC Drive running) Bit 2: 1: Jog on. Bit 3~4: 00: Rev LED is off and FWD led is on. (Forward) 01: Rev LED is blink and FWD led is on. (Reverse to Forward) 10: Rev LED is on and FWD led is blink. (Forward to Reverse) 11: Rev LED is on and FWD led is off. (Reverse) Bit 5-7: Reserved Bit 8: Master frequency source via communication interface Bit 9: Master frequency source via analog Bit10: Running command via communication interface Bit11: Parameter locked Bit12~15: Reserved Frequency Setting (F) or Closed Loop Control Setting Factory setting: Read Only 00 - 03Point This parameter displays the frequency command set by the user. Output Frequency (H) Factory setting: Read Only This parameter displays actual output frequency of the AC drive. 00 - 05 Output Current (A) Factory setting: Read Only This parameter displays actual output current of the AC drive. 00 - 06 DC-BUS Voltage (U) Factory setting: Read Only This parameter displays DC-BUS voltage of the AC drive. **00 - 07** Output Voltage (E) Factory setting: Read Only This parameter displays output voltage of the AC drive. 00 - 08 Output Power Factor (n) Factory setting: Read Only This parameter displays output power factor. 00 - 09 Output Power (kW) Factory setting: Read Only This parameter displays output power of the AC drive. 00 - 10 Feedback Signal Actual Value Factory setting: Read Only This parameter displays feedback signal value. Feedback Signal (%) Factory setting: Read Only

This parameter displays feedback signal value(%).



00 - 12 User Target Value (Low bit) uL 0-99.99	Factory setting: Read Only		
00 - 13 User Target Value (High bit) uH 0-9999	Factory setting: Read Only		
☐ User Target Value = Actual output frequency (0-04) × User Defined Multiplier (02-10).			
Maximum summed display of both parameters is 999999.99.			
When User Target Value <=99.99, 00-12=0.			
00 - 14 PLC Time	Factory setting: Read Only		
This parameter displays remaining time of PLC each step.			
00 - 15 Output Reactive Power (KVAR)	Factory setting: Read Only		

☐ This parameter displays reactive power of AC drives.



5 2	Grau	n 1-	Pacie	Param	otore
J. 2	: Grou	D II	Dasic	Param	eters

01 - 00 Maximum Output Frequency

Factory Setting: 60.00

Settings 50.00~160.00Hz

This parameter determines the AC drives maximum output frequency. All master frequency commands set by the keypad or analog inputs are limited by this parameter. The analog commands (ACI1 and ACI2) may be scaled to correspond to the output frequency range. (Please refer to 04-05~04-12.)

01 - 01 Maximum Voltage Frequency (Base Frequency)

Factory Setting: 60.00

Settings 0.10~160.00 Hz

- This parameter sets the frequency, where the maximum output voltage (Pr. 01-02) will be reached. The output frequency may exceed this setting, but the output voltage doesn't increase beyond this point. This parameter should be set according to the rated frequency of the motor as indicated on the motor nameplate.
- If this parameter setting is smaller than the rated frequency of the motor, nuisance over current faults or damage to the AC drive may occur.
- If this parameter setting is greater than the rated frequency of the motor, the motor will encounter torque loss.

01 - 02 Maximum Output Voltage

Factory Setting: 440.0

Settings 0.2V ~ 510.0V

- This parameter determines the Maximum Output Voltage of the AC drive. This parameter setting should be set according to rated voltage of the motor as indicated on the motor nameplate. If rated voltage of the motor is 440V, this parameter must be set to 440V. If rated voltage of the motor is 380V, this parameter must be set to 380V.
- If this setting is greater than the rated voltage of the motor, nuisance over current faults or damage to the AC drive may occur.

01 - 03 Mid-point Frequency

Factory Setting: 3.00

Settings 0.10~160.00 Hz

- This parameter sets the Mid-point Frequency of the V/F curve.
- \square This parameter must meet the following argument. Pr.1-01 >= Pr.1-03 >= Pr.1-05.

01 - 04 Mid-point Voltage

Factory Setting: 11.0

Settings 0.2V~510.0V

This parameter sets the Mid-point Voltage of the V/F curve.



This parameter must meet the following argument. Pr.1-02 >= Pr.1-04 >= Pr.1-06.

01 - 05 Minimum Output Frequency

Factory Setting: 3.00

Settings

0.10~20.00 Hz

This parameter sets the Minimum Output Frequency of the AC drive. This parameter must be lower than or equal to the Mid-point frequency

01 - 06 Minimum Output Voltage

Factory Setting: 11.0

Settings

0.2V~100.0V

This parameter sets the Minimum Output Voltage of the AC Drive. The parameter must be lower than or equal to the Mid-point Voltage.

01 - 07 Upper Bound Frequency

Factory Setting: 60.00

Settings

0.00~160.00 Hz

This parameter will limit the maximum output frequency of AC drive. If slip compensation (Pr.07-02~07-05) or feedback control (Pr.10-00~10-09) are enabled, the output frequency of AC drive may exceed the Master Frequency Command, but it will continue to be limited by this parameter setting.


01 - 08 Lower Bound Frequency

Factory Setting: 0.00

Settings

0.00~160.00 Hz

- This parameter will limit the minimum output frequency. Any Master Frequency Command below Pr.1-08, will result in an output equal to Pr.1-08.
- ☐ Upon a start command, the drive will accelerate from Pr.1-05 Minimum Output Frequency to the Master Frequency Command point.





01 - 09 Acceleration Time 1	×	Factory Setting: 10.0/60.0
01 - 10 Deceleration Time 1	×	Factory Setting: 10.0/60.0
01 - 11 Acceleration Time 2	×	Factory Setting: 10.0/60.0
01 - 12 Deceleration Time 2	×	Factory Setting: 10.0/60.0
01 - 13 Acceleration Time 3	×	Factory Setting: 10.0/60.0
01 - 14 Deceleration Time 3	×	Factory Setting: 10.0/60.0
01 - 15 Acceleration Time 4	×	Factory Setting: 10.0/60.0
01 - 16 Deceleration Time 4	×	Factory Setting: 10.0/60.0
01 - 17 JOG Acceleration Time	×	Factory Setting: 10.0/60.0
01 - 18 JOG Deceleration Time	×	Factory Setting: 10.0/60.0
01 - 14 Deceleration Time 3 01 - 15 Acceleration Time 4 01 - 16 Deceleration Time 4 01 - 17 JOG Acceleration Time	<i>X X</i>	Factory Setting: 10.0/6 Factory Setting: 10.0/6 Factory Setting: 10.0/6 Factory Setting: 10.0/6

Settings 0.1~3600.0 Sec Unit: 0.1sec

- Factory setting for 30HP and higher models is 60.0 seconds.
- Acceleration time is the time required for the AC drive to ramp from 0 Hz to its Maximum Output Frequency (Pr.1-00). Deceleration time is the time required for the AC drive to decelerate from Maximum Output Frequency (Pr.1-00) down to 0 Hz.
- An Acceleration or Deceleration time that is too quickly, may cause the AC drives protection features to enable (over-current stall prevention during Accel 06-01 or over-voltage stall prevention 06-00). If this occurs, the actual Accel/Decel time will be longer than this setting.
- Warning: An acceleration or deceleration that is too quickly, may cause excess loads on the AC drive and may permanently damage the drive.
- If you want to decelerate the AC drive in short time period, we recommend adding an external braking module and braking resistor.
- You can set 1st to 4th Accel/Decel time via multi-function input terminals 04-00 to 04-03.

01 -	19 JOG Freque	ency	×	Factory Setting: 6.00	
	Settings	0.0 Hz~160.00 Hz		Unit: 0.1sec	
□ V	When the JOG fu	nction is to be utilized, users need to use t	he m	nulti-function input terminals	
((Pr. 04-00 to 04-03 set to 07) or the JOG key on keypad. Once a JOG command is initiated,				
t	the AC drive will accelerate from the Minimum Output Frequency (Pr.01-05) to the JOG				
f	requency (Pr.01-	19).			
	The accel/decel ti	me of the JOG operation is determined b	y the	e JOG accel/decel speed	



01 - 20 S Curve Delay Time in Accel Factory Setting: 0.00

01 - 21 S Curve Delay Time in Decel

Settings 0.00~2.50sec

These parameters enable the S curve. The longer the S curve time period the smoother the transition between speeds.

01 - 22Modulation Index✓Factory Setting: 1.00Settings0.90~1.20Unit: 0.1

This parameter sets the ratio of the Maximum Output Voltage to the input voltage.

The Maximum Output Voltage (Pr.01-02) is normally limited to the input voltage. With the Modulation Index parameter, the user is able to increase the output voltage beyond the incoming line voltage.

A Modulation Index of 1, defines the Maximum Output Voltage (Pr. 1-02) is equal to the input voltage.

A Modulation index of 1.2, defines the Maximum Output Voltage (Pr. 1-02) is 20% higher than in the input voltage. Please note, the output voltage wave form will be distorted due to harmonics and may increase torque ripple and noise in the motor.

01 - 23 Accel/Decel Time Unit

Factory Setting: 01

Settings 00: Unit is 1 Sec

01: Unit is 0.1 Sec 02: Unit is 0.01 Sec

This parameter sets the resolution of accel/decel time (Pr.01-09 to 01-18).

A high resolution decreases the accel/decel time range as shown in the following chart.

01-23	Accel/Decel time unit	Accel/Decel time range
00	1 Sec	1~36000 Sec
01	0.1 Sec	0.1~3600.0 Sec
02	0.01 Sec	0.01~360.00 Sec



5.3 Group 2: Operation Method Parameters

Settings 00: via keypad

01: via analog input AI1 (10bit) 02: via analog input AI2 (10bit)

03: via RS485 serial communication (RJ-11)

04: via External Reference

Settings:

00: Frequency command source is the keypad. User may use UP/DOWN keys to adjust the frequency command. Also if the Multi-Function Input terminals (Pr.04-00 to 04-03) are set to 13 or 14, their function will be the same as the UP/DOWN keys.

01: Frequency command source is the analog input terminal Al1.

02: Frequency command source is the analog input terminal AI2.

03: Frequency command source is the RS485 serial communication.

04: Frequency command source depends on the setting of Pr. 04-20.

02 - 01 Source of Operation Command ✓ Factory Setting: 00

Settings 00: Controlled by the digital keypad

01: Controlled by the external terminals, keypad STOP enabled.

02: Controlled by the external terminals, keypad STOP disabled.

03: Controlled by the RS-485 communication interface, keypad STOP enabled.

04: Controlled by the RS-485 communication interface, keypad STOP disabled.


This parameter sets the operation command source of the AC drive.

Settings 00:Stop = ramp to stop, E.F. (External Fault) = coast to stop 01:Stop = coast to stop, E.F. = coast to stop 02:Stop = ramp to stop, E.F. = ramp to stop 03:Stop = coast to stop, E.F. = ramp to stop

- Ramp: The AC drive decelerates the motor to minimum output frequency according to the deceleration time setting.
- Coast: The AC drive output instantly stops upon command and the motor free spins until it comes to a complete stop.
- External Fault may be enabled by the EF terminal or a Multi-Function terminal. Please refer to Pr.04-00 to 04-03.



Factory Setting: 00



02 - 03 PWM Carrier Frequency Selections	Factory Setting: Depend on model type
--	---------------------------------------

Settings 1K~6KHz

- This parameter sets the carrier frequency of PWM output. The factory setting and setting range depend on the model type.
- When the temperature of the heat sink is greater than its limit, the AC drive will automatic lower the carrier frequency to avoid over heating the AC drive.
- The Carrier frequency of the PWM output has a signification influence on the electromagnetic noise, heat dissipation of the AC drive, and the acoustic noise to the motor as shown in the following chart.

Carrier	Acoustic Noise	Electromagnetic	Leakage	Heat
Frequency		Noise	Current	Dissipation
Signification Minimal	Minimal ▼ Signification	Signification Minimal	Signification Winimal	Signification Minimal

When the carrier frequency is low, current ripple of the AC drive is large. This may result in a current display value greater than the actual value.

02 - 04 Forward/Reverse Enabled

Settings 00: Forward/Reverse enabled

01: Reverse disabled02: Forward disabled

This parameter enables the direction of the AC drive.



02 - 05 2-wire/3-wire Operation Control Modes

Factory Setting: 00

Settings 00: 2-wire (#1), FWD / STOP, REV / STOP

01: 2-wire (#2), RUN/STOP, FWD/REV

02: 3-wire operation

This parameter sets the operation mode when operating by external terminals.

Please refer to 02-01.

02-05	External Terminal		
00 (2-wire #1) FWD / STOP REV / STOP	FWD/STOP FWD:("OPEN":STOP) ("CLOSE":FWD) REV:("OPEN":STOP) DCM ("CLOSE":REV) VFD-G		
01 (2-wire #2) REV / FWD RUN / STOP	RUN/STOP —OO— FWD:("OPEN":STOP) ("CLOSE":RUN) REV :("OPEN":FWD) ("CLOSE":REV) DCM VFD-G		
02 3-wire	STOP LRUN FWD ("CLOSE":RUN) EF ("OPEN":STOP) REV ("OPEN":FWD) ("CLOSE":REV) DCM VFD-G		

02 - 06 Line Start Lockout

Factory Setting: 01

Settings 00: Disabled 01: Enabled

When enabled, the AC drive will not start when powered up with a run command applied. The AC drive must see the run command transition from stop to run after power up. When Line Start Lockout is disabled (also known as Auto-Start), the AC drive will start when powered-up with run commands applied.

02 - 07 Reserved

02 - 08 Start-up Display Selection

Factory Setting: 00

Settings Bit0~1: 00 = F LED

01 = H LED

10 = U LED (special display)

11 = Fwd / Rev

Bit2: 0 = Fwd LED / 1 = Rev LED

Bit3~5: 000 = 1st 7-step

001 = 2nd 7-step

010 = 3rd 7-step

011 = 4th 7-step

100 = 5th 7-step

Bit6~7: Reserved



- This parameter determines the display on keypad after each power up.
- To program this parameter the user must first generate a Hex value with the information above. Then using the Hex to Decimal conversion to find the corresponding Decimal value and enter it into this parameter.
- For example, a setting of 21 (decimal 21= hex 010101) will display the "H" and "REV" LEDs and the cursor will stay at the 3rd 7-step display upon power up.
- When setting to U LED, please refer to 02-09.

Settings

00: A displays output current of AC drive

01: U displays DC-Bus voltage of AC drive02: E displays RMS of output voltage

03: P displays feedback signal

04: PLC display auto procedure state

- This parameter chooses the display on the keypad immediately following the "U" user defined setting.
- "MODE" key will scroll from "F", "H", "U", (Pr. 02-09), FWD, and back to "F".
- Users may also use the "LEFT" key on the digital keypad to switch display content.

02 - 10 User Defined Coefficient		×	Factory Setting: 1.00
Settings	0.01~160.00		Unit: 0.01

- When this parameter is set, the "H "display value = actual output frequency of AC drive x 02-10.
- If output frequency of AC drive is 90Hz, set 02-10 to 2.5. When H LED lights, the value on the display is 225.00.

Settings 00: Disabled

01: Enabled (DC braking disabled)

- When the AC drive starts into a running motor (Flying Start), it may cause an over current on the drive and may damage the motor. Using speed search upon start-up will allow the drive to slowly find the motor speed, smoothly take control of the motor, and bring it to command speed.
- If the Flying Start feature is enabled upon start-up, the DC braking 08-01 will be disabled.



02 - 12 Flying Start	Frequency	×	Factory Setting: 00
Settings	Settings 00: Begin search from Master Frequency Command 01: Begin search from Maximum Frequency (Pr.01-00)		
02 - 13 Master Fre	quency Memory Setting	×	Factory Setting: 01
Settings	Settings 00: Do not remember the last known frequency 01: Remember the last known frequency		
If this parameter is set to 00: The AC drive will not store the last known master frequency command, after power is removed.			
If this parameter is set to 01: The AC drive will memorize the last known master frequency command after power off. Upon power up the last known frequency is displayed.			
After a fault, the AC drive will always remember the last know master frequency command.			
This feature is only enabled when Pr. 02-00 is set for 0 or 4.			



Factory Setting: 01

5.4 Group 3: Output Function Parameters

03 - 00 Multi-function Output terminal 1 (Relay)

Settings 00-21

Setting	Functions	Descriptions
00	Disabled	
01	Indication during operation	The corresponding output will be closed during operation (including DC braking time).
02	Master frequency attained	The corresponding output will be closed when output frequency reaches master frequency command.
03	Zero Speed (including shutdown)	The corresponding output will be closed when the AC drive has no output voltage signal.
04	Over-torque	The corresponding output relay will be closed when the AC drives output current exceeds the over-torque detection level 06-04.
05	External Fault	The corresponding output will be closed when the EF is enabled. (Pr. 04-00 to 04-03)
06	Low voltage detection	The corresponding output will be closed when the DC Bus voltage drops below our threshold. The keypad will display "Lu".
07	Operation Mode indication	The corresponding output will be closed when the AC drives "Operation Command" is controlled by the external terminals.
80	Fault Indication	The corresponding output will be closed when AC drive has experienced a fault.
09	Master Frequency Attained 1	The corresponding output will be closed when the AC drives output frequency exceeds (Pr.03-08) Master Frequency Attained 1.
10	Master Frequency Attained 2	The corresponding output will be closed when the AC drives output frequency exceeds (Pr.03-09) Master Frequency Attained 2.
11	Over Temperature indication	The corresponding output will be closed when the AC drive temperature exceeds its rating.
12	Drive Ready	The corresponding output will be closed the when the AC drive is ready and has no faults.
13	External Emergency Stop (EF1)	The corresponding output will be closed when multi-function input terminals (Pr.04-00 to 04-03) are set to emergency stop and then activated.
14	Software braking output	The corresponding output will be closed when the AC drives DC bus voltage exceeds (Pr.08-19) the braking level.
15	OL or OL1 overload warning	The corresponding output will be closed upon an overload (OL or OL1) fault.




Setting	Functions	Descriptions
16	Low current indication	The corresponding output will be closed when the AC drives output current is lower than the Low Current setting (Pr.06-08).
17	PID feedback error indication	The corresponding output will be closed when the PID feedback signal has an error.
18	Auto Running Command	The Output will be closed when PLC Program is running.
19	1-Step Running Completed	The Output will be closed for 0.5 sec when each multi-step speed is attained.
20	Auto Running Completed	The output will be closed for 0.5 sec when the PLC program cycle has completed
21	Auto Running Paused	The output will be closed when PLC operation is paused.

- ☐ Standard relay specifications = 10A/250VAC or 12A/24VDC.
- Relay delay time is 5~10 msec.

03 - 01 Reserved		
03 - 02 Master Fre	equency Attained 1	Factory Setting: 0.00
03 - 03 Master Fre	equency Attained 2	
Settings	0.00~160.00 Hz	Unit: 0.01

- An output relay may be programmed to activate when the output frequency exceeds the desired attained frequency setting of these two parameters.
- There is a ±2Hz window of operation. If the master frequency attained is 20Hz and the output frequency exceeds 20Hz, the corresponding output relay will be "closed". When the output frequency is less than 18Hz, the corresponding output relay will be "opened" as the following diagram shows.





03 - 04 DC Fan Control

Factory Setting: 00

Settings

00: Fan runs on power up.

01: Fan begins upon a RUN command. Fan stops 1 minute after a STOP command.

02: Fan begins upon a RUN command. Fan stops after a STOP command

03: Fan is controlled by temperature. Fan will be started at approximate 60°C.

This parameter determines DC fan control method.

03 - 05 Analog Output 1, (AFM1) 0~10Vdc	Factory Setting: 00
03 - 06 Analog Output 2, (AFM2) 0/4~ 20mA	Factory Setting: 01

Settings 00: Output frequency

01: Output current02: Output voltage

03: Frequency command 04: Power factor loading

- These parameters select the content of the analog output signals AFM1 and AFM2.
- \square Setting 00: 0-10V = 0 (Pr.01-00)
- Setting 01: 0-10V = 0 (Double rated current)
- \square Setting 02: 0-10V = 0 (Pr.01-02)
- Setting 03: 0-10V = 0 Master Freq. command
- □ Setting 04: 0-10V = 0.0 output power factor 1.0
- When using 0-20mA output, please refer to Pr. 3-14.
- Maximum impedance loading of analog output 2 (AFM2) can't be greater than 500 ohms.

03 - 07 Analog Output Gain 1	×	Factory Setting: 100
03 - 08 Analog Output Gain 2		Factory Setting: 100

Settings 01~200%

- These parameters are to determine analog output gain.
- The analog output is limited to 10V and 20mA. The gain is designed to offer a normally small output signal to be enlarged for easier viewing on a meter.

03 - 09 Analog Output 2 Selection

Factory Setting: 01

Settings 0

00: 0~20mA

01: 4~20mA

This parameter selects the output range of Analog Output 2 (AFM2).



5.5 Group 4: Input Function Parameters

04 - 00 Multi-function Input terminal 1	Factory Setting: 01
04 - 01 Multi-function Input terminal 2	Factory Setting: 02
04 - 02 Multi-function Input terminal 3	Factory Setting: 03
04 - 03 Multi-function Input terminal 4	Factory Setting: 04

Settings 00~31

Setting	Functions	Descriptions
00	Disabled	All unused terminals should be set to 00, to
		assure they have no effect on drive operation.
01	Multi-Speed terminal 1	Allows selection of the 15 multi-step speeds.
02	Multi-Speed terminal 2	Please refer to 05-00 to 05-14 to program the
03	Multi-Speed terminal 3	15 step speeds.
04	Multi-Speed terminal 4	
05	Reset (NO)	Clears (Reset) a fault and returns the AC drive
06	Reset (NC)	to normal operation.
07	Jog operation (JOG)	Enables the JOG command. Works identical to the JOG key on the digital keypad.
80	Accel/Decel disable	Stops the acceleration or deceleration of the AC drive. AC drive then maintains a constant speed.
09	1st and 2nd Accel/Decel selection	A corresponding terminal set to value 09 and
10	3rd and 4th Accel/Decel selection	closed selects Accel/Decel time 2. A corresponding terminal set to value 10 and closed selects Accel/Decel time 3. Accel/Decel time 4 is selected when both terminals are closed.
11	B.B. (NO) input	Enables the base block (pause) function.
12	B.B. (NC) input	Please refer to Pr.08-08, for base block functions.
13	Increase Frequency	Enables the external terminals to increase or
14	Decrease Frequency	decrease the Master Frequency command each time an input is received. Terminals are not active during a stop command.
15	Emergency stop (NO)	Generates an external fault (EF1). The
16	Emergency stop (NC)	function is identical to the external terminal (EF).
17	KEYPAD(open), EXT(close)	External selection of the Operation Command Source. (Keypad = terminal open) or (External terminals = terminal closed). This setting is valid when Pr.02-01 is set to 00. Otherwise, the Operation Command Source will follow the setting in Pr.02-01.



		CARELIA VI E O GOILOS
Setting	Functions	Descriptions
18	PID disabled	Disable PID feedback control and operate via Master Frequency Command source Pr.02-00.
19	Run PLC Program	Parameter value 32 programs Multi-Function
20	Pause PLC Program	Input Terminal to enable the AC drive internal PLC program. Parameter value 33 programs an input terminal to pause the PLC program. Note: Pr.05-00 to Pr.05-16 defines the PLC program.
21	1st Output Frequency Gain (Pr.04-30)	Output frequency multiplies a gain (Pr.04-30) , H=F*(Pr.04-30)
22	2nd Output Frequency Gain (Pr.04-31)	Output frequency multiplies a gain (Pr.04-31) , H=F*(Pr.04-31)
23	3rd Output Frequency Gain (Pr.04-32)	Output frequency multiplies a gain (Pr.04-32) , H=F*(Pr.04-32)

04 - 04	4 Digital Input	Terminal Response Time	Factory Setting: 01
	Settings	01~20	
This	s parameter se	elects the response time of digital input te	rminals MI1 to MI4, EF and

- FWD.
- AC drive will scan the digital input terminals once every 2msec. During each scan the drive will check the status of each terminal (open or closed).
- In noisy environments, it would be advantageous to verify the terminal status several times before executing a new command, nearly eliminating false signals.
- Example: If Pr.04-04 is set to 4, the AC drive will confirm the terminal status (4+1 = 5) 5 times before a change is made. This correlates to an 8~10msec time response from input command to execution.
- It is not recommended to set this parameter to 00, since interference may cause improper operation of the AC drive.


Factory Setting: 0	04 - 05 Minimum Al1 Analog Input	
Factory Setting: 100	04 - 06 Maximum Al1 Analog Input	
Unit: 1	Settings 0 ~ 100%	
Factory Setting: 0.00	04 - 07 Minimum Output that corresponds to Al1	
Factory Setting: 100.00	04 - 08 Maximum Output that corresponds to Al1	
Unit: 0.01	Settings 0.00~100.00%	



		
04 - 09 Minimum Al2 Analog Input		Factory Setting: 0
04 - 10 Maximum Al2 Analog Input		Factory Setting: 100
Settings 0 ~ 100%		Unit: 1
04 - 11 Minimum Output that corresponds to Al2		Factory Setting: 0.00
04 - 12 Maximum Output that corresponds to Al2		Factory Setting: 100.00
Settings 0.0~100.0%		Unit: 0.01
04 - 13 1st Al1 Gain	N	Factory Setting: 100.0
04 - 14 2nd Al1 Gain	×	Factory Setting: 100.0
04 - 15 3rd Al1 Gain	×	Factory Setting: 100.0
04 - 16 4th Al1 Gain	×	Factory Setting: 100.0
04 - 17 5th Al1 Gain	N	Factory Setting: 100.0
04 - 18 1st Al2 Gain	N	Factory Setting: 100.0
04 - 19 2nd Al2 Gain	N	Factory Setting: 100.0
04 - 20 3rd Al2 Gain	N	Factory Setting: 100.0
04 - 21 4th Al2 Gain	N	Factory Setting: 100.0
04 - 22 5th Al2 Gain	N	Factory Setting: 100.0
Settings 0.0~100.0%	•	Unit: 0.1

These parameters set analog input value and maximum output frequency (01-00, used in open-loop control) or the corresponding function of the detection reference value (10-01, used in PID closed-loop control). They divide output frequency into several sections according to Pr.04-26 to Pr.04-29. There is an independent gain and minimum output frequency in every section. We can reduce inferior products and improve working efficiency via parameter modification. For example, we set frequency via two groups analog input terminals. When the frequency we set is 0-15Hz and the gain is 50%, the minimum output frequency will be 5Hz; when the frequency we set is 15-35Hz and the gain is 80%, the minimum output frequency will be 15Hz; when the frequency we set is 35-50Hz and the gain is 150%, the minimum output frequency will be 35Hz as the following diagram shows.





04 - 23 Analog Input Delay Al1	Factory Setting: 0.50
04 - 24 Analog Input Delay AI2	Factory Setting: 0.50
Settings 0.00 ~ 10.00 Sec	Unit: 0.01

- These parameters select the time constant for the analog input signal filter. A properly adjusted time constant may help filter noise on the analog input terminals.
- ☐ If the input delay is set too long, the system may experience oscillation. Be careful setting these parameters.

04 - 25 Summation of External Frequency Sources

Factory Setting: 00

Settings

00: disabled

01: Al1*(Al1 Gain)+Al2*(Al2 Gain) 02: Al1*(Al1 Gain)-Al2*(Al2 Gain) 03: Al1*(Al1 Gain)*Al2*(Al2 Gain)

04: Reserved

05: Communication master frequency +AI1*(AI1 Gain)06: Communication master frequency +AI2*(AI2 Gain)

07: Max (Al1*(Al1 Gain), Al2*(Al2 Gain))

- This parameter selects the terminals used for summation of the External Frequency Sources.
- Setting 07 is used to compare Al1*(Al1 Gain) with Al2*(Al2 Gain). If Al1*(Al1 Gain) > Al2*(Al2 Gain), it indicates that command source is from Al1, otherwise is from Al2.



04 - 26 1st Analog Input Frequency Gain	×	Factory Setting: 0.00
04 - 27 2nd Analog Input Frequency Gain	×	Factory Setting: 0.00
04 - 28 3rd Analog Input Frequency Gain	×	Factory Setting: 0.00
04 - 29 4th Analog Input Frequency Gain	×	Factory Setting: 0.00

Settings 0.00~160.00Hz Unit: 0.01

These parameters divide output frequency into several sections. (Refer to Pr.04-22).

04 - 30 1st Output Frequency Gain	×	Factory Setting: 100.0
04 - 31 2nd Output Frequency Gain	×	Factory Setting: 100.0
04 - 32 3rd Output Frequency Gain	×	Factory Setting: 100.0
Settings 0.0~200.0%		Unit: 0.1

These parameters set output frequency gain. We can select the functions of 21st to 23rd via multi-function terminal. When the multi-function terminal is active, output frequency multiplies a gain, i.e. output frequency H=F*(Pr.04-30/04-31/04-32).



5.6 Group 5: Multi-step Speed Frequency Parameters

05 - 00 1st Step Speed Frequency	Factory Setting: 0.00
05 - 01 2nd Step Speed Frequency	Factory Setting: 0.00
05 - 02 3rd Step Speed Frequency	Factory Setting: 0.00
05 - 03 4th Step Speed Frequency	
05 - 04 5th Step Speed Frequency	
05 - 05 6th Step Speed Frequency	
05 - 06 7th Step Speed Frequency	
05 - 07 8th Step Speed Frequency	
05 - 08 9th Step Speed Frequency	
05 - 09 10th Step Speed Frequency	
05 - 10 11th Step Speed Frequency	
05 - 11 12th Step Speed Frequency	
05 - 12 13th Step Speed Frequency	
05 - 13 14th Step Speed Frequency	
05 - 14 15th Step Speed Frequency	
	·

Settings 0.00~160.00 Hz

Unit: 0.01

The Multi-Function Input Terminals (refer to Pr.04-00 to 04-03) are used to select one of the AC drive Multi-Step speeds. The speeds (frequencies) are determined by Pr.05-00 to 05-14 shown above.

05 - 15 PLC Mode		Factory Setting: 00
Settings	00	Disable PLC operation
	01	Execute one program cycle only
	02	Continuously execute program cycles
	03	Execute one program cycle only and step by step
	04	Continuously execute program cycles step by step
This parameter sel	ects	the mode of PLC operation for the AC drive. The AC drive will

change speeds and directions according to the user's desired programming.



Example 1 (Pr.05-15 = 1): Execute one cycle of the PLC program. Its relative parameter settings are:

Pr.05-00 to 05-14: 1st to 15th step speeds (sets the frequency of each step speed)

Pr.04-00 to 04-03: Multi-Function Input Terminals (set one multi-function terminal as 32

- PLC auto-operation).


Pr.03-00: Multi-Function Output Terminals (set a Multi-Function Terminal as

34-PLC running indication, 35-PLC step completed or 36-PLC

program completed).

Pr.05-16: Direction of the 1st to 15th step speeds.

Pr.05-17 to 05-31: Operation time setting for each corresponding step speed.



Note: The above diagram shows one complete PLC operation cycle. To restart this cycle, turn the multi-function input terminal that designed as PLC program off and on again.


Example 2 (Pr.05-15 = 2): Continuously executes program cycles:

The diagram above shows the PLC program stepping through each speed. Set Pr.05-15 to 2 for continuous program execution. To stop the PLC program, one must either pause the function or turn it off. (Refer to Pr.04-00 to 04-03 values 32 and 33).



Example 3 (Pr.05-15 = 3) Execute one cycle step by step:

The example below shows how the PLC can perform one cycle at a time, within in a complete cycle. Each step will use the accel/decel times in Pr.01-09 to Pr.01-16. It should be noticed that the time each step spends at its intended frequency is diminished, due to the time spent during accel/decel.



05 - 16 PLC Forward/Reverse Motion


Factory Setting: 00


Settings 00 to 32767 (0:Forward, 1:Reverse)

This parameter controls the direction of motion for the Multi-Step Speeds Pr.05-00 to Pr.05-14 during PLC mode. All other direction commands are invalid during the PLC mode.

Note: The equivalent 15-bit number is used to program the forward/reverse motion for each of the 15 speed steps. The binary notation for the 15-bit number must be translated into decimal notation and then entered.







The setting value = bit14x2¹⁴+bit13x2¹³+....+bit2x2²+bit1x2¹+bit0x2⁶ = 1x2¹⁴+1x2¹¹+1x2¹⁰+1x2⁶+1x2⁵+1x2⁴+1x2¹ =16384+2048+1024+64+32+16+2 =19570

Setting 05-16=19570

NOTE:	. 13	. 12	. 11	. 10
2 =16384	2 ¹³ =8192	2 =4096	2 =2048	2 =1024
2 ⁹ =512	2 ⁸ =256	2 ⁷ =128	2 ⁶ =64	2 ⁵ =32
2 ⁴ =16	2 ³ =8	2 ² =4	2 =2	2°=1




05 - 17	Time Duration of 1st Step Speed	Factory Setting: 0.0
05 - 18	Time Duration of 2nd Step Speed	Factory Setting: 0.0
05 - 19	Time Duration of 3rd Step Speed	Factory Setting: 0.0
05 - 10	Time Duration of 4th Step Speed	Factory Setting: 0.0
05 - 21	Time Duration of 5th Step Speed	Factory Setting: 0.0
05 - 22	Time Duration of 6th Step Speed	Factory Setting: 0.0
05 - 23	Time Duration of 7th Step Speed	Factory Setting: 0.0
05 - 24	Time Duration of 8th Step Speed	Factory Setting: 0.0
05 - 25	Time Duration of 9th Step Speed	Factory Setting: 0.0
05 - 26	Time Duration of 10th Step Speed	Factory Setting: 0.0
05 - 27	Time Duration of 11th Step Speed	Factory Setting: 0.0
05 - 28	Time Duration of 12th Step Speed	Factory Setting: 0.0
05 - 29	Time Duration of 13th Step Speed	Factory Setting: 0.0
05 - 30	Time Duration of 14th Step Speed	Factory Setting: 0.0
05 - 31	Time Duration of 15th Step Speed	Factory Setting: 0.0
	Settings 0.0 to 65500	Unit: 1 /0.1sec

Pr.05-17 to Pr.05-31 correspond to operation time of each step speed defined by Pr.05-00 to Pr.05-14. The maximum setting 65500 seconds will be displayed as t6550. If it is displayed t6550, that means 6550 seconds.

Note: If a parameter is set to "00" (0 sec), the corresponding step will be skipped. This is commonly used to reduce the number of program steps.





05 - 32 Time Unit Settings Factory	Setting: 00
------------------------------------	-------------

Settings 00 1 Sec

01 0.1 Sec

This parameter determines the time unit for Pr.05-17~Pr.05-31.




5.7 Group 6: Protection Function Parameters

06 - 00 Over-voltage Stall Prevention Factory Setting: 780.0

Settings 660.0V~820.0VDC

00: Disabled

- This parameter selects the voltage level for the Over-Voltage Stall Prevention function.
- During decelerations, the DC bus voltage may exceed its maximum allowable value due to motor regeneration. When this function is enabled, the AC drive will stop decelerating and maintain a constant output frequency. The AC drive will only resume deceleration when the voltage drops below the preset value.
- With moderate inertial loads, the over-voltage stall prevention will not occur and the deceleration time should be equal to Pr.1-10. With high inertial loads, the AC drive will automatically extend the deceleration time due to the step function shown below. If the deceleration time is critical for the application, then dynamic braking resistors should be used.




06 - 01 Over-current Stall Prevention during Acceleration Factory Setting: 150%

Settings 20~250%

Unit: 1

- This parameter selects the percentage of allowable over-current during acceleration before the stall prevention is enabled.
- During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06-01 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and maintain a constant output frequency. The AC drive will only resume acceleration when the current drops below the value set in Pr.06-01 (please see the graph below).
- When the over-current stall prevention is activated, the acceleration time of the AC drive will be longer than the time set in Pr. 01-09.






Over-current Stall Prevention during Acceleration

06 - 02 Over-curre	nt Stall Prevention during operation	Factory Setting: 150%
Settings	20~250%	Unit: 1


- This parameter selects the percentage of allowable over-current during operation before the stall prevention function is enabled.
- If the output current exceeds the value specified in Pr.06-02 when the drive is operating at steady state speed, the drive will decrease its output frequency to prevent the drive from faulting with an OC. Once the current falls below the value specified in Pr.06-02, the drive will then accelerate to catch up with the command frequency.





06 - 03 Over-torque	e Detection Selection	Factory Setting: 00
Settings	(OL2), and operation continuous: Over-torque detection enabl (OL2), and operation halted. O3: Over-torque detection enabl operation continues.	led during constant speed operation ues. led during constant speed operation led during operation (OL2), and led during constant speed operation
☐ This parameter se	elects the Over-torque Detection of	peration.
If this parameter in the second control of the second control o	s set to 01 or 02, over-torque detec	ction will not occur during acceleration.
06 - 04 Over-torque	e Detection Level	Factory Setting: 110
Settings	30~150%	Unit: 1
This parameter se	ets the Over-torque Detection level	based on the AC drive rated current.
06 - 05 Over-torque	e Detection Time	Factory Setting: 0.1
Settings	0.1~60.0 Sec	Unit: 0.1
faults with an OL2 When the output and display "OL2	current exceeds Pr.06-04 for the tir	me set in Pr06-05, AC drive will fault
06 - 06 Electronic T	hermal Relay Selection	Factory Setting: 02
•		•
06 - 07 Electronic T	hermal Characteristic	Factory Setting: 60
Settings	30~600 Sec	Unit: 1
This parameter se activate.	elects the time required for the elec	ctronic thermal protection function to
	set for 1 or 2 and the output curren will fault with an OL1.	t exceeds Pr.7-02 for the time set in
	v. The actual reaction time will vary	6 output current for 1 minute) is shown depending on output current.





Factory Setting: 00	06 - 08 Low Current Detection Level			
Unit: 1	Settings 00~100% (00 disabled)			
Factory Setting: 10.0	06 - 09 Low Current Detection Time			
Unit: 0.1	0.1~ 3600.0 Sec	Settings		
Factory Setting: 01	nt Detection Treatment	06 - 10 Low Currer		
	00: Warn and Ramp to stop 01: Warn and Coast to stop 02: Warn and keep operating	Settings		

These parameters set the low current detection mode, time, and operation.

06 - 11 Present Fault Record		Factory Setting: 00	
06 - 12 2nd Most Recent Fault Record		Factory Setting: 00	
06 - 13 3rd Most Recent Fault Record		Factory Setting: 00	
06 - 14 4th Recent	4th Recent Fault Record Factory Set		Factory Setting: 00
Settings	00	No fault occurred	
	01	Over-current (oc)	
	02	Over-voltage (ov)	
	03 Overheat (oH)		
	04 Overload (oL)		
	05	Overload1 (oL1)	
06 External fault (EF)		External fault (EF)	
07 IGBT protection (occ)		IGBT protection (occ)	
	80	CPU failure (CF3)	



- 09 Hardware protection failure (HPF)
- 10 Over-current during acceleration (OcA)
- 11 Current exceeds 2 times rated current during decel. (ocd)
- 12 Current exceeds 2 times rated current during steady state operation (ocn)
- 13 Ground fault (GFF)
- 14 Low voltage (Lv)
- 15 CPU READ failure (CF1)
- 16 CPU WRITE failure (CF2)
- 17 Base Block (bb)
- 18 Motor over load (oL2)
- 19 Reserved
- 20 Software/password protection (codE)
- 21 Emergency stop (EF1)
- 22 Phase-Loss (PHL)
- 23 Low-current (Lc)
- 24 Feedback Loss (FbL)
- 25 Reserved

06 - 15 Parameter Reset

Factory Setting: 00

Settings

00~65535

09: Reset parameters (50Hz, 380)

10: Reset parameters (60Hz, 440)

This parameter resets all parameters to the factory setting.

06 - 16 Parameter Protection Password Input

Factory Setting: 00

Settings

00~65535

- This parameter allows the user to enter their password to unlock the Parameter Protection feature. The password entered must match the value entered into Pr.6-17. After three invalid password attempts, the drive will no longer allow any operation. The drive must then be powered off and back on again.
- After successfully entering the password, the user may change parameters as they wish. Once the drive is powered off, the drive has locked the parameters again. To clear the password, the user must enter the correct password in Pr.6-16 and then set Pr.6-17 to 00.



06 - 17 Parameter Protection Password Setting Factory Setting: 00

Settings 00~65535

00: No password protection

- This parameter allows the user to set a password for parameter protection. After entering a password, Pr.6-17 will display 1.
- Be sure to keep the password in a safe place. If the password is lost, please return the drive to DELTA.



5.8 Group 7: AC Drive and Motor Parameters

07 - 00 Identity Code of AC Drive

Factory Setting: ##

Settings Display by model type

This parameter displays the AC drive model code.

This parameter is read-only.

07 - 01 Rated Current of AC Drive

Factory Setting: ##

Settings Display by model type

This parameter displays rated output current of the AC drive. The following chart may be used to look up the identity code, current, and hp of your drive.

KW	5.5	7.5	11	15	18.5	22	30	37	45	55	75
HP	7.5	10	15	20	25	30	40	50	60	75	100
Pr.07-00	13	15	17	19	21	23	25	27	29	31	33
Rated Current (A)	13	18	24	32	38	45	60	73	91	110	150
Max. Carried Freq.	6K	Hz		6K	Hz		6KHz				
Min. Carried Freq.	4K	Hz		3K	Ήz		2KHz				
Factory Setting	6K	Hz		6K	Hz		4KHz			•	

This parameter is read-only.

07 - 02	Full-load Cur	rent of Motor	×	Factory Setting: 100%
	Settings	30~120%		Unit: 1

- This parameter selects the full load current of the motor.
- Pr7-02 = (full load motor current / drive rated current)
- Example: If the rated current of AC drive is 150A, full-load current of motor is 120A, then Pr.7-02 should be set to 80%.
- This parameter is used with slip compensation Pr.7-04 to Pr.7-05 and electronic thermal relay Pr.6-06 to Pr.6-07. An incorrect setting will cause these functions to not work incorrectly and may damage the motor and drive.
- The full-load current of the motor must be equal to or less than (but not less than 50%) the rated current of the AC drive.

07 - 03 No-load Cu	rrent of Motor	×	Factory Setting: 30%
Settings	1~99%		Unit: 1



This parameter sets the no-load current of the motor.

Pr.7-03 = (no load current / drive rated current)

Example: If the rated current of the AC drive is 150A and no-load current of the motor is 40A, then Pr.7-03 should be set to 27%.

- This parameter is used with slip compensation Pr.7-04 and Pr.7-05. An incorrect setting will cause the function to work incorrectly and may damage the motor and drive.
- If the no-load current of the motor is unavailable, it may be found by running the motor with no load and reading the current on the keypad display.

07 - 04 Auto Slip C	Compensation Gain	<i>★</i>	Factory Setting: 0.0
Settings	0.0~3.0		Unit: 0.1

- This parameter is set to auto slip compensation gain.
- Rotor speed of the motor (output frequency of AC drive) can't synchronize due to induction motor characteristic. The difference between synchronization speed and rotor speed is called slip frequency. Slip frequency is in direct proportion with output torque and output current. Therefore, slip compensation could make rotor speed and master frequency command the same according output current (lo).
- The equation of slip compensation is (07-05) X (07-04) X (lo-(07-03)) / ((07-02)-(07-03)). If rated current of AC drive is 150A, full-load current of the motor is 120A, no-load current is 40A, rated slip frequency is 5Hz and output current of AC drive is 100A. At this time, slip compensation is (07-04) X 5 X (100-40) / (120-40) = 3.75 X (07-04). If 07-04 is set to 1.0 and the compensation is 3.75. If master frequency command is set to 50Hz and output frequency is 53.75.
- Output frequency after compensation is limited by 01-07 upper bound frequency. When using slip compensation, 01-07 should be set to the suitable value.
- When PID feedback control, slip compensation function will be disabled.
- Unsuitable setting value may cause over compensation.

motor is 60Hz-(1650rpm X 4/120) = 5Hz.

O7 - 05 Rated Slip Frequency of Motor Factory Setting: 0.00 Settings 0.00~20.00Hz Unit: 0.01 ☐ This parameter is to set rated slip of loaded motor. Users need to input rated rotation speed according to nameplate of loaded motor. If rated frequency of motor is 60Hz, number of motor poles is 4 and rated rotation speed of motor is 1650rpm. The rated slip frequency of



This parameter has relation with 07-04 slip compensation. To have the best slip compensation, this parameter must be set correctly. Incorrect setting may cause above functions disable and even damage the motor and AC drive.

07 - 06 Auto Torque	Compensation Gain	N	~	Factory Setting: 0.0
Settings	0.0~10.0			Unit: 0.1

- This parameter is to set auto torque compensation gain.
- When motor loading is high, a part of output frequency of AC drive will be absorbed by impedance of stator winding to make voltage of exciting inductance of motor is not enough. Therefore, the short of gap magnet field will make a high output current but low output torque. Auto torque compensation gain could adjust output voltage automatically according to loading to maintain in a fixed gap magnet of the motor to get the best running situation.
- If the setting of compensation gain is too great, over-exciting magnet will cause the following situation: output current of AC drive is too great, motor is over-heating or protection function occurs.

07 - 07	Torque Comp	pensation Gain by Manual Operation	×	Factory Setting: 0.0
	Settings	0.0~10.0		Unit: 1.0

- This parameter determines torque compensation gain by manual operation.
- Torque compensation gain by manual operation won't refer to the loading situation and adds compensation voltage on the setting V/F curve. Basically, it just changes V/F curve. It could be reached by adjusting V/F curve.

07 - 08 Calculate Total Running Time of the Motor (Min)	Factory Setting: 00
Settings 00 to 1439 Min	Unit: 1
07 - 09 Calculate Total Running Time of the Motor (Day)	Factory Setting: 00
Settings 00 to 65535 Day	Unit: 1
This parameter could display running time of the motor.	
07 - 10 Electric Bill for One Time	Factory Setting: Read Only
07 - 11 Accumulated Electric Bill (per currency unit)	Factory Setting: Read Only
07 - 12 Accumulated Electric Bill (per 10 ⁴ currency unit)	Factory Setting: Read Only
07 - 13 Electric Rate (per currency unit)	Factory Setting: 0.6
Settings 0.01 to 655.35	Unit: 1



You can get electric bill from Pr. 07-10 to Pr. 07-12 after inputting local electric rate into Pr. 07-13.



5.9 Group 8: Special Parameters

08 - 00 DC Braking Current Level	Factory Setting: 00

Settings 00~100% Unit: 1

This parameter determines the level of DC braking current output.

08 - 01DC Braking Time during Start-upFactory Setting: 0.0

Settings 0.0~60.0 Sec Unit: 0.1

- This parameter determines the duration of time that the DC braking current will be applied to the motor during the AC drive start-up.
- The motor may rotate by external force or inertia itself before operating. It may damage the motor or start the AC drive protection function by an over current if the AC drive added at this time. This parameter enable the AC drive to output a direct current before running the motor that will produce a torque to forced motor stop and get a steady start-up characteristic.

08 - 02 DC Braking Time during Stopping Factory Setting: 0.0

Settings 0.00~60.00 Hz

Unit: 0.01

- This parameter determines the duration of time that the DC braking current will be applied to the motor during stopping.
- Motor may be in rotation status after AC drive stops output and can't in stop status accuracy when motor is running with external force or itself inertia. After AC drive stops output, this parameter could output a DC current to produce torque force motor to stop and make sure the motor has stopped accuracy.


08 - 03 Start-point for DC Braking Factory Setting: 0.00

Settings 0.00~160.00 Hz

Unit: 0.01

- This parameter determines the frequency when DC braking will begin during deceleration.
- If this parameter is set greater than 01-05 minimum frequency setting, it won't decelerate to 01-05 and enter DC braking status when AC drive brakes. Suitable DC braking start-up frequency setting will get better braking characteristic.





DC Braking Time

08 - 04 Momentary Power Loss Operation Selection

Factory Setting: 00

Settings 00: Disabled

01: Trace from top downward02: Trace from bottom upward

- This parameter determines the start-up mode after momentary power loss operation.
- The power system connects to AC drive may occurred momentary power loss by any probably reason. This function can make AC drive output voltage continuously after power loss and AC drive won't stop by power loss.
- If this parameter is set to 01, AC drive will trace from the last frequency before power loss downward. After output frequency of AC drive and running speed of the motor is synchronization, it will accelerate to master frequency command. It is recommended to use this setting if the motor loading has the characteristics of high inertial and low resistance.
- If this parameter is set to 02, AC drive will trace from the Min. frequency upward. After output frequency of AC drive and running speed of the motor is synchronization, it will accelerate to master frequency command. It is recommended to use this setting if the motor loading has the characteristics of low inertial and high resistance.

08 - 05 Maximum Allowable Power Loss Time

Factory Setting: 2.0

Settings 0.1~5.0 Sec

Unit: 0.1

- This parameter determines the maximum allowable power loss time. If the power loss time is less than the time defined by this parameter, the AC drive will execute 08-04 momentary power loss operation.
- The allowable power loss time is beginning to count time after AC drive displays Lu. Therefore, actual allowable power loss time will change with loading.




The allowable power loss time must in the condition that AC drive auxiliary power is working normally. If auxiliary power is turned off in the allowable power loss time, the actual allowable power loss time will be shorter than the parameter setting.

08 - 06Speed Search TimeFactory Setting: 0.5Settings0.1~5.0 SecUnit: 0.1


This parameter determines the delay time from fault (power loss, OV, OC or BB) recovery to start to execute the function of speed search time.

08 - 07Maximum Speed Search CurrentFactory Setting: 110Settings30~150%Unit: 1

- This parameter determines maximum current of speed search.
- Maximum speed search current will have influence with synchronization attained time. The greater this parameter is set, the faster it will be synchronization. But if the parameter setting value is too great, it may occur over-loaded protection.
- If 08-04 is set to 01: when speed search is from top downward, output frequency is searched from master frequency command downward. Now output voltage and output current will be added from zero. When output current is equal to 08-07 setting value, AC drive output current will retain in a fixed value and output frequency will keep on searching from top downward. When output frequency and output voltage is overlapped with V/F setting frequency, AC drive will judge that is synchronization attained and accelerates from V/F curve to master frequency command.
- If 08-04 is set to 02: AC drive will accelerate according to V/F curve and won't do any special treatment.







08 - 08 BB Speed Search Method

Factory Setting: 00

Settings

00: Trace from top downward

01: Trace from bottom upward

- This parameter determines BB speed search method when multi-function input terminal 04-00 to 04-03 is set to BB External interrupt (11 or 12) and activates.
- BB speed search method is the same with restart speed search after momentary loss power.

08 - 09 Auto Restart Times After Fault

Factory Setting: 00

Settings

00 ~10

- This parameter determines the times of auto restart after fault.
- When AC drive occurs fault (OV, OC or OCC) and fault disappeared automatically, this parameter allows AC drive reset and runs with the parameter that is set before fault occurred.
- If fault occurred times exceed 08-09 setting, AC drive will reject to restart and need to reset by users to keep on running.



08 - 10 Auto Resta	rt Time after Fault	Factory Setting: 600
Settings	00 to 60000 sec	Unit: 1

This parameter determines auto restart time after fault. After fault occurs and restart, there is no fault occurs during 08-10 setting time, AC drive will reset fault occurred record to zero.

08 - 11 Operation Frequency Inhibition 1 UP	Factory Setting: 0.00
08 - 12 Operation Frequency Inhibition 1 DOWN	Factory Setting: 0.00
08 - 13 Operation Frequency Inhibition 2 UP	Factory Setting: 0.00
08 - 14 Operation Frequency Inhibition 2 DOWN	Factory Setting: 0.00
08 - 15 Operation Frequency Inhibition 3 UP	Factory Setting: 0.00
08 - 16 Operation Frequency Inhibition 3 DOWN	Factory Setting: 0.00
Cottings 0.00 400 00 II-	

Settings 0.00~160.00 Hz Unit: 0.01

- These parameters determine the inhibition operation frequency range. This function will let AC drive not run continuous in the resonance frequency of the motor or loading system, or inhibition operation frequency.
- The settings of these parameters should follow as $08-11 \ge 08-12 \ge 08-13 \ge 08-14 \ge 08-15 \ge 08-16$.
- Master frequency command can be set in inhibition operation frequency range. Now the output frequency will be limited in the lower bound of inhibition operation frequency.
- When AC drive accelerates or decelerates, output frequency will pass through inhibition operation frequency range.

08 - 17 Automatic Energy-saving


Factory Setting: 00

Settings

00: Energy-saving operation disabled

01: Energy-saving operation enabled

This parameter determines automatic energy-saving function.



Automatic Energy-saving Operation



08 - 18 Automatic	Voltage Regulation (AVR)		Factory Setting: 00			
Settings	00: AVR function enabled01: AVR function disabled02: AVR function disabled for deceleration	ıtion				
This parameter disabled.	determines the function of Automatic Volta	ige R	Regulation is enabled or			
voltage by DC B	This parameter is set to 01: when AVR function is disabled, AC drive will calculate input voltage by DC Bus value (620VDC). Output voltage will vary by DC Bus varying and may cause output current insufficiently, over current or oscillation.					
•	This parameter is set to 00: when AVR function is enabled, AC drive will calculate output voltage by actual voltage value of DC Bus. Output voltage won't vary by DC Bus varying.					
•	This parameter is set to 02: AC drive will disable AVR function during decelerate to stop. It can speed up braking in some degree.					
	Setting of the Braking Level level of the braking resistor)	×	Factory Setting: 760.0			
Settings	740.0V~820.0VDC 00: Disabled		Unit: 0.1			
This parameter	determines software setting of the braking	leve	ıl.			
	055~150F43A has braking chip, user could deceleration characteristics.	d sel	ect suitable braking resistor			
The action level	The action level of the braking resistor could be set by this parameter.					
08 - 20 Vibration C	Compensation Factor	N	Factory Setting: 00			
Settings	00~1000		Unit: 1			
•	will minimize vibration at low speed during SAIN. The higher the value, the more vibra					



5.10 Group 9: Communication Parameters

09 - 00 Communication Address

✓ Factory Setting: 01

Settings 01-254

00: Disabled

If the AC drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter.

Settings 00: Baud rate 4800

01: Baud rate 9600 02: Baud rate 19200 03: Baud rate 38400

This parameter determines transmission speed of AC drive communication.

09 - 02 Transmission Fault Treatment

Factory Setting: 03

Settings 00: Warn and keep operating

01: Warn and RAMP to stop02: Warn and COAST to stop03: No warning and no display

This parameter is set to detect if an error occurs and take actions.

09 - 03 Time-out Detection during Transmission

Factory Setting: 00

Settings 00: Disabled

01: Enabled

This parameter is used for ASCII mode. When this parameter is set to 01, indicates that the time-out detection is enable, the time slot between each character can't exceed 500 ms.

09 - 04 Communication Format

Factory Setting: 00

Settings 00: 7-bit for ASCII

01: 8-bit for ASCII 02: 8-bit for RTU

09 - 05 Even/Odd Parity and Stopping Parity Setting

Factory Setting: 00

Settings 00: None parity + 2 stop bit

01: Even parity + 2 stop bit 02: Odd parity + 2 stop bit 03: None parity + 1 stop bit 04: Even parity + 1 stop bit 05: Odd parity + 1 stop bit

This parameter determines the communication format of serial communication.




09 - 06 Communic	ation Operation Command 1	N	Factory Setting: 00
Settings	Bit0~1: 00: Disabled 01: Stop 10: Start-up 11: JOG start-up	<u> </u>	r dotory coming to
	Bit2~3: Reserved		
	Bit4~5: 00: Disabled 01: FWD command 10: REV command 11: Direction change command		
	Bit6~7: 00: 1st step acce/decel speed 01: 2nd step acce/decel speed 10: 3rd step acce/decel speed 11: 4th step acce/decel speed		
	Bit8~11: 0000: Master speed 0001: 1st step speed 0010: 2nd step speed 0011: 3rd step speed 0100: 4th step speed 0101: 5th step speed 0110: 6th step speed 0111: 7th step speed 1000: 8th step speed 1001: 9th step speed 1001: 10th step speed 1011: 11th step speed 1100: 12th step speed 1101: 13th step speed 1101: 13th step speed 1110: 14th step speed 1111: 15th step speed		
	Bit13~15: Reserved		
☐ This parameter o	can be set by communication settings. It can	an't l	be set by keypad.
-			
	ation Frequency Setting	×	Factory Setting: 60.00
Settings This parameter of	0~160.00Hz can be set by communication settings. It can	an't l	Unit: 0.01 be set by keypad.
-	ation Operation Command 2	<i>N</i>	Factory Setting: 00
Settings	Bit0: 1: EF ON Bit1: 1: Reset	<u> </u>	i actory Setting. 00

Bit2: 0: BB OFF, 1: BB ON

Bit3~15: Reserved



- This parameter can be set by communication settings. It can't be set by keypad.
- If you set BB action by this parameter and you also need to disable BB action by this parameter.
- 1. There is a built-in RS-485 serial interface, marked (RJ-11 jack) on the control terminal block. The pins are defined below:



Each AC drive has a pre-assigned communication address specified by 9-00. The computer then controls each AC drive according to its communication address.

AC drive can be setup to communicate on Modbus networks using one of the following modes: ASCII (American Standard Code for Information interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in 09-04 and 09-05.

Code Description:

ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

1				1			1	1
Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII Code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII Code	38H	39H	41H	42H	43H	44H	45H	46H


RTU mode:

Each 8-bit is the combination of two 4-bit hexadecimal characters. For example, 64 Hex.




2. Data format


- 2.1 10-bit character frame (for 7-bit):
 - **❖** (7, N, 2: 9-04=0, 9-05=0)




❖ (7, E, 1: 9-04=0, 9-05=04)




4 (7, O, 1: 9-04=0, 9-05=05)



- 2.2 11-bit character frame (for 8-bit):
 - **♦** (8, N, 2: 9-04=1 or 2, 9-05=00)




♦ (8, E, 1: 9-04=1 or 2, 9-05=04)





♦ (8, O, 1: 9-04=1 or 2, 9-05=05)



3. Communication Protocol

3.1 Communication Data Frame:

ASCII mode:

STX	Start character ':' (3AH)				
ADR 1	Communication address: 8-bit address consists of 2 ASCII codes				
ADR 0					
CMD 1	Command code:				
CMD 0	8-bit command consists of 2 ASCII codes				
DATA (n-1)	Contents of data:				
	N X 8-bit data consists of 2n ASCII codes. n<=25, maximum of 50 ASCII codes				
DATA 0					
LRC CHK 1	LRC check sum:				
LRC CHK 0	8-bit check sum consists of 2 ASCII codes				
END 1	nd characters:				
END 0	END1= CR (0DH), END0= LF(0AH)				

RTU mode:

START	A silent interval of more than 10 ms				
ADR	Communication address: 8-bit address				
CMD	Command code: 8-bit command				
DATA (n-1)	Contents of data:				
	N X 8-bit data, n<=25				
DATA 0					
CRC CHK Low	CRC check sum:				
CRC CHK High	16-bit check sum consists of 2 8-bit characters				
END	A silent interval of more than 10 ms				



3.2 ADR (communication address)

Valid communication addresses are in the range of 0 to 254. a communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

For example, communication to AMD with address 16 decimal:

ASCII mode: (ADR 1, ADR 0) = '1','0' => '1'=31H, '0'=30H

RTU mode: (ADR) = 10H

3.3 CMD (command code) and DATA (data character)

The format of data characters depends on the command code. The available command codes are described as followed:

● Command code: 03H, read N words. The maximum value of N is 10. for example, reading parameters 01-01 and 01-02 from address 01H.

ASCII mode:

Command message:

STX	·.,
ADR 1	'0'
ADR 0	'1'
CMD 1	'0'
CMD 0	'3'
Starting	'0'
data	'1'
address	'0'
	'1'
Number	'0'
of	'O'
data	'0'
(Word)	'2'
LRC CHK 1	'D'
LRC CHK 0	'7'
END 1	CR
END 0	LF

Response message:

STX	·.,
ADR 1	'0'
ADR 0	'1'
CMD 1	'0'
CMD 0	'3'
Number of	'0'
data(Word)	'4'
Data	'1'
of	'7'
0101H	'7'
	'0'
Data	' 0'
of	'8 '
0102H	9
	' 8'
LRC CHK 1	'D'
LRC CHK 0	'1'
END 1	CR
END 0	LF

Error response message

STX	(.) ·
ADR 1	'O'
ADR 0	'1'
CMD 1	'8'
CMD 0	'3'
Error code	' 0'
	'2'
LRC CHK 0	'6'
LRC CHK 1	Ď,
END 1	CR
END 0	LF



Command message:

ADR	01H
CMD	03H
Starting data	01H
address	01H
Number of data	00H'
(Word)	02H
CRC CHK Low	94H
CRC CHK High	37H

	Response	message:
--	----------	----------

ADR	01H
CMD	03H
Number of	04H
data	
data 0101H	17H
content	70H
0102H	08H
content	98H
CRC CHK	FBH
LOW	
CRC CHK	36H
HIGH	

Error response message

ADR	01H
CMD	90H
Error code	02H
CRC CHK LOW	CDH
CRC CHK HIGH	C1H

Command code: 06H, write a word

For every law writing (0000/4770LI) to add to

For example, writing 6000(1770H) to address 0100H of AMD with address 01H.

ASCII mode:

Command message:

·.,
'O'
'1'
'O'
'6'
'0'
'1'
'0'
'O'
'1'
'7'
'7'
'O'
'7'
'7'
CR
LF

Response message:

STX	'' ·
ADR 1	'0'
ADR 0	'1'
CMD 1	'0'
CMD 0	'6'
data	'0'
starting	'1'
address	'0'
	'0'
data	'1'
	'7'
	'7'
	'0'
LRC CHK 1	'7'
LRC CHK 0	'7'
END 1	CR
END 0	LF

Error response message

STX	·.·
ADR 1	'0'
ADR 0	'1'
CMD 1	'8'
CMD 0	'6'
Error	'0'
code	'2'
LRC CHK 0	·6'
LRC CHK 1	,D,
END 1	CR
END 0	LF



Command message:

ADR	01H
CMD	06H
data	01H
Starting	00H
address	
data	17H
	00H
CRC CHK	87H
LOW	
CRC CHK	C6H
HIGH	

Response message:

ADR	01H
CMD 1	06H
data	01H
Starting address	00H
data	17H
	70H
CRC CHK LOW	87H
CRC CHK HIGH	C6H

Error response message

ADR	01H
CMD 1	86H
Error code	02
CRC CHK LOW	СЗН
CRC CHK HIGH	A1H

• Command code: 08H, loop detection

This command is used to test the communication condition between master control equipment (usually is PC or PLC) and AC drive. AC drive will deliver the data that received from AC drive to master control equipment.

For example:

ASCII mode:

Command message:

· . ,
'0'
'1'
'0'
'8'
'0'
'0'
'0'
'0'
'1'
'7'
'7 '
'0'
'7'
'0'
CR
LF

Response message:

·.·
'O'
'1'
'0'
'8'
' 0'
'0'
' 0'
'0'
'1'
'7'
'7'
' 0'
'7'
' 0'
CR
LF

Error response message

STX	·.·
ADR 1	'0'
ADR 0	'1'
CMD 1	'8'
CMD 0	'8'
Error	'0'
code	'2'
LRC CHK 0	'6 '
LRC CHK 1	'D'
END 1	CR
END 0	LF



Command message:

ADR	01H
CMD	H80
data	00H
Starting	00H
address	
data	17H
	70H
CRC CHK	EEH
LOW	
CRC CHK	EFH
HIGH	

Response message:

ADR	01H
CMD 1	08H
data	00H
Starting	00H
address	
data	17H
	70H
CRC CHK	EEH
LOW	
CRC CHK	EFH
HIGH	

Error response message

ADR	01H
CMD 1	88H
Error code	02
CRC CHK LOW	E0H
CRC CHK	6DH
HIGH	

• Command code: 10H, write continuous words

For example, modify multi-step speed setting of AC drive (address 01H) 05-00=50.00(1388H) , 05-01=40.00(0FA0H)

ASCII mode:

Command message:

STX	(.) -
ADR 1	'0'
ADR 0	'1'
CMD 1	'1'
CMD 0	' 0'
Data	' 0'
Starting	' 5'
address	'O'
	'0'
Number	'0'
Of	'0'
data	'0'
(Word)	'2'
Number of	'O'
data (Byte)	'4'
The first	'1'
data	'3'
	'8'
	'8'
The second	' 0'
data	'F'
	'A'
	'0'

Response message:

STX	·.·
ADR 1	'0'
ADR 0	'1'
CMD 1	'1'
CMD 0	'0'
Data	'0'
address	' 5'
	'0'
	'0'
Number	'O'
Of	'0'
data	'0'
(Word)	'2'
LRC CHK 1	È
LRCCHK 0	'8'
END 1	CR
END 0	LF

Error response message

STX	·.·
ADR 1	'0'
ADR 0	'1'
CMD 1	' 9'
CMD 0	'0'
Error	'0'
code	'2'
LRC CHK 0	'6 '
LRC CHK 1	ʻD'
END 1	CR
END 0	LF



LRC CHK 1	'9'
LRC CHK 0	'A'
END 1	CR
END 0	LF

Command message:

ADR	01H
CMD	10H
Data	05H
starting	
address	00H
Number of	00H
data (Word)	
	02H
Number of	04
data (Byte)	
The first	13H
data	88H
The second	0FH
data	A0H
CRC CHK	4DH
LOW	
CRC CHK	D9H
HIGH	

Response message:

ADR	01H
CMD 1	10H
Data	05H
starting	
address	00H
Number of	00H
data (Word)	
	02H
CRC CHK	41H
LOW	
CRC CHK	04H
HIGH	

Error response message

ADR	01H
CMD 1	90H
Error	02H
CRC CHK LOW	CDH
CRC CHK HIGH	C1H

3.4 CHK (check sum)

ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.



STX	· . ,
ADR 1	' 0'
ADR 0	'1'
CMD 1	' 0'
CMD 0	'3'
Data starting address	' 0'
	'4'
	' 0'
	'1'
Number of data	' 0'
	'0'
	' 0'
	'1'
LRC CHK 1	'F'
LRC CHK 0	'6 '
END 1	CR
END 0	LF

01H+03H+04H+01H+00H+01H=0AH, 2's complement of 0AH is **F6**H.

RTU mode:

RTU mode uses CRC (Cyclical Redundancy Check) detect value. CRC (Cyclical Redundancy Check) is calculated by the following steps:

- Step 1: Load a 16-bit register (called CRC register) with FFFFH.
- Step 2: Excusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.
- Step 3: Examine the LSB of CRC register.
- Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zerofilling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zerofilling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.
- Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

For example, read 2 words from the to address 2102H of AMD with address 01H. The CRC register content of last byte from ADR to number of data is F76FH. The command message is as following. 6FH will transmit before F7H.



}

Command message:

ADR	01H
CMD	03H
Data starting address	02H
	02H
Number of data	00H
(word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC values as a type of unsigned integer.

```
unsigned int crc_chk(unsigned char* data, unsigned char length){
  int j;
  unsigned int reg_crc=0xFFFF;
  while(length--){
    reg_crc ^= *data++;
    for(j=0;j<8;j++){
      if(reg_crc & 0x01){ /* LSB(b0)=1 */
         reg_crc=(reg_crc>>1) ^ 0xA001;
      }else{
        reg_crc=reg_crc >>1;
      }
    }
  }
  return reg_crc;
```



3.5 Address list:

The contents of available addresses are shown as below:

Content	Address	Function	
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 04-01 is 0401H. Refer to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can be read for one time.	
Command Write only	2000H	Bit 0-1 00B: Disabled 01B: Stop 10B: Run 11B: Jog + Run	
		Bit 2-3	Reserved
		Bit 4-5	00B: Disabled 01B: FWD command 10B: REV command 11B: Direction change command
		Bit 6-7	00B: 1st step acce/decel speed 01B: 2nd step acce/decel speed 10B: 3rd step acce/decel speed 11B: 4th step acce/decel speed
		Bit 8-11 0000B: Master speed 0001B: 1st step speed 0010B: 2nd step speed 0010B: 3rd step speed 0010B: 4th step speed 0100B: 4th step speed 0101B: 5th step speed 0110B: 6th step speed 0111B: 7th step speed 1000B: 8th step speed 1001B: 9th step speed 1010B: 10th step speed 1011B: 11th step speed 1100B: 12th step speed 1101B: 13th step speed 1101B: 13th step speed 1101B: 14th step speed 1111B: 15th step speed	
		Bit 13-15	Select Bit6~11 function Reserved
Command	2001H		
Write only	2001H 2002H	Freq. command Bit 0 1: EF (external fault) on	
	2002	Bit 1	1: Reset
		Bit 2	0: BB OFF 1: BB ON
Status monitor	2100H	Fault code:	
Read only		00: No error occurred	



Content	Address		Function
		01: Over-current (oc)	
		02: Over-voltage (,
		03: Overheat (oH)	,
		04: Overload (oL)	
		05: Overload1 (oL	1)
		06: External fault (,
			cuit protection (occ)
		08: CPU failure (cl	F3)
		09: Hardware prot	ection failure (HPF)
		10: Current exceed	ds 2 times rated current during accel (ocA)
		11: Current exceed	ds 2 times rated current during decel (ocd)
		12: Current exceed	ds 2 times rated current during steady state
		operation (ocn)	
		13: Ground Fault (GFF)
		14: Low voltage (L	.v)
		15: CPU failure 1 (1
		16: CPU failure 2 (
		17: Base Block (bb	,
		18: Overload (oL2)	
		19: Auto accel/dec	
			ection enabled (codE)
		21: EF1 Emergend	
		22: PHL (Phase-Loss)	
		23: Lc (Low-current)	
		24: FbL(Feedback Loss)	
		25: Reserved	
	2101H	Status of AC drive	
		Bit 0-1	00: Run LED is off and stop led is on. (AC
			Drive stopping)
			01: Run LED is blink and stop led is on.
			(AC Drive deceleration to stop)
			10: Run LED is on and stop led is blink. (AC Drive standby)
			11: Run LED is on and stop led is off. (AC
			Drive running)
		Bit 2	1: Jog on.
		Bit 3-4	00: Rev LED is off and FWD led is on.
		Dit o	(Forward)
			01: Rev LED is blink and FWD led is on.
			(Reverse to Forward)
			10: Rev LED is on and FWD led is blink.
			(Forward to Reverse)
			11: Rev LED is on and FWD led is off.
			(Reverse)
		Bit 5-7	Reserved



			CABELIZ VI B 8 GOING
Content	Address	Function	
		Bit 8	Master frequency source via
			communication interface
		Bit 9	Master frequency source via analog
		Bit 10	Running command via communication
			interface
		Bit 11	Parameter locked
		Bit 12-15	Reserved
	2102H	Frequency comma	and (F)
	2103H	Output frequency	(H)
	2104H	Output current (AXXX.X)	
	2105H	DC-BUS Voltage U (XXX.X)	
	2106H	Output voltage E (XXX.X)	
	2107H	Power Factor (n)	
	2108H	Output power (XX.XXKW)	
	2109H	Feedback Signal	
	210AH	Feedback Signal (%)	
	210BH	Estimated torque ratio	
	210CH	User output (Low) uL 0-99.99	
	210DH	User output (High) uH 0-9999	
	210EH	PLC Time	
	210FH	Reserved	

3.6 Exception response:

The AC drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions that no normal response is replied to the master device.

The AC drive does not receive the messages due to a communication error; thus, the AC drive has no response. The master device will eventually process a timeout condition.

The AC drive receives the messages without a communication error, but cannot handle it, an exception response will return to the master device and an error message "CExx" will display on the keypad of AC drive. The xx of "CExx" is a decimal code equal to the exception code that will describe below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code explains the condition that caused the exception is returned. An example of exception response of command code 06H and exception code 02H:



ASCII mode:

STX	·.,
ADR 1	'0'
ADR 0	'1'
CMD 1	'8'
CMD 0	'6 '
Error code	'0'
Lifoi code	'2'
LRC CHK 1	'7'
LRC CHK 0	'7'
END 1	CR
END 0	LF

RTU mode:

ADR	01H
CMD	86H
Exception code	02H
CRC CHK Low	C3H
CRC CHK High	A1H

The explanation of exception codes:

Exception code	Explanation	
01	Illegal command code: The command message is not available for the AC drive.	
02	Illegal data address: The data address received in the command message is not available for the AC drive.	
03	Illegal data value: The data value received in the command message is not available for the AC drive	
04	Slave device failure: The AC drive is unable to perform the requested action.	
10	Communication time-out:	



5.11 Group 10: PID Control Parameters

10 - 00 Input Terminal for PID Feedback

Factory Setting: 00


Settings 00: Disabled

01: Input via AI1 02: Input via AI2

03: Input via External Reference

- This parameter is to set the source of PID control feedback signal. The source could be AI1, AI2 or external reference that defined by 04-20.
- When this parameter is set to 00, PID feedback control function is disabled.
- If this parameter isn't set to 00, AC drive will automatically start-up PID feedback control.

 Output frequency is calculated by master frequency and PID feedback signal.



10 - 01 PID Control Detection Signal Reference

Factory Setting: 1000.0

Settings 1.0-6550.0

Unit: 0.1

Please refer to 04-05 to 04-12 if this parameter is set to PID feedback control.

10 - 02 PID Feedback Control Method

Factory Setting: 00

Settings 00: Normal (Err=SP-FB)

01: Inverse (Err=FB-SP)

- This parameter could set the calculation method of deviation signal during PID feedback control circuit.
- When this parameter is set to 00: when negative feedback control, the deviation equation is deviation = target value detection signal. When increasing output frequency will increase detection value, this setting should be chose.



$ ilde{\square}$ When this parameter is set to 01: when positive control, the deviation equation is deviation			
= detection signal - target value. When increasing output frequency will decrease detection			
value, this setting should be chose.			

10 - 03 Proportional Gain (P)

Factory Setting: 1.0

Settings 0.0~10.0

Unit: 0.1

This parameter is to set proportional gain (P). This gain determines the response degree of P controller to feedback deviation. If gain value is large, the response is fast. But if the gain value is too great, oscillation will occur. If gain value is small, the response is slow.

10 - 04 Integral Time (I)

Factory Setting: 1.00

Settings

0.00~100.00 Sec

Unit: 0.01

- This parameter is set to integral gain of I controller. When much integral time is to be set, the gain of I controller is small and the response is slow. The control ability to external is poor. When less integral time is to be set, the gain of I controller is large and the response is fast. The control ability to external is fast.
- If the setting of integral time is too small, output frequency and system may occur oscillation.
- If integral time is set to 0.00, I controller is closed.

10 - 05 Differential Time (D)

Factory Setting: 0.00

Settings

0.00~1.00 Sec

Unit: 0.01

- This parameter is set to D controller gain. This gain determines D controller to the response of change of deviation. Suitable differential time could decrease overshoot of P and I controller. The oscillation will be attenuation and steady quickly. But if much differential time is to be set, it may cause system oscillation.
- Interference immunity ability is poor due to differential controller activates to change of deviation. It's not recommended to use, especially during interferences.

10 - 06 Upper Bound for Integral Control

Factory Setting: 100

Settings

00~200%

Unit: 1

This parameter could set the upper bound of I controller. In other words, upper bound for integral control = (01-00) X (10-04) %

10 - 07 Primary Low Pass Filter Time

Factory Setting: 0.0

Settings

0.0~2.5 Sec

Unit: 0.1

This parameter determines primary Low Pass filter time.



- Output frequency of PID controller will filter by primary low pass function. This function could decrease change of output frequency. A long primary low pass time means filter degree is high and vice versa.
- Unsuitable primary low pass filter time setting may cause system oscillation.

10 - 08 PID Feedback Signal Range

Factory Setting: 600.00

Settings 0.01~160.00Hz

Unit: 0.01

- This parameter setting could allow the maximum of PID deviation.
- If PID function is normally, it should control the detective value to target value accurately in the certain time. If AC drive can't control deviation in the 10-08 setting range during 10-07 setting time, it means PID feedback control is abnormal. The treatment is set as 10-10.

10 - 09 PID Feedback Signal Fault Treatment Time

Factory Setting: 0.0

Settings 0.0~3600.0 Sec

Unit: 0.1

This parameter is to set the detection time of abnormal PID derivative. If PID deviation detection time is set to 0.0, the function is disabled.

10 - 10 PID Feedback Signal Fault Treatment

N

Factory Setting: 01

Settings 00: Warn and RAMP stop

01: Warn and COAST stop
02: Warn and keep operating

This parameter is to set treatment of the abnormal PID deviation.

10 - 11 V/F Curve Selection

Factory Setting: 00

Settings 00: Determined by group 1


01: 1.5 power curve 02: 1.7 power curve 03: 2 power curve 04: 3 power curve

- This parameter is to set V/F curve. If this parameter isn't set to 00, parameter 01-03 and 01-04 will disable.
- Input current of the motor could divide into two orthogonal vectors: magnetic vector and torque vector. Gap flux, which is produced by Magnetic vector, is in direct proportion with output voltage of motor. Torque vector produces torque. Torque is in direct proportion with the result of magnetic vector multiply by torque vector. In theory, if the value of magnet vector is the same with torque vector (in unsaturated flux condition), the input current is minimum. If motor loading is unsteady torque loading (loading torque is in direct proportion with speed. For example, the loading of fan or pump), loading torque is low during low



speed, suitable lower input voltage will decrease input current of magnetic field to lower flux loss and iron loss of the motor and promote whole efficiency.

When this parameter is set to high power V/F curve and low frequency torque is lower, it is not suitable for AC drive to accel/decel quickly. If it needs to accel/decel quickly, it is not recommended to use this parameter.





CHAPTER 6 MAINTENANCE AND INSPECTIONS

Modern AC drives are based on solid state electronics technology, preventive maintenance is required to operate this AC drive in its optimal condition, and to ensure a long life. It is recommended to perform a monthly check up of the AC drive by a qualified technician. Before the check up, always turn off the AC Input Power to the unit. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between B1 and Ground using a multimeter set to measure DC.

6.1 Periodic Inspection

Basic check up items to detect if there were any abnormality during the operation:

- 1. Whether the motors are operating as expected.
- 2. Whether the installation environment is abnormal.
- 3. Whether the cooling system is operating as expected.
- 4. Whether any irregular vibration or sound occurred during the operation.
- 5. Whether the motors are overheated during the operation.
- 6. Always check the input voltage of the AC drive with Voltmeter.

6.2 Periodic Maintenance

WARNING! Disconnecting AC power before processing!

- Tighten and reinforce the screws of the AC drive if necessary, cause it may loose due to the vibration or changing of temperatures.
- 2. Whether the conductors or insulators were corroded and damaged.
- 3. Check the resistance of the insulation with Meg-ohmmeter.
- 4. Often check and change the capacitors and relays.
- 5. If use of the AC drive is discontinued for a long period of time, turn the power on at least once every two years and confirm that it still functions properly. To confirm functionality, disconnect the motor and energize the AC drive for 5 hours or more before attempting to run a motor with it.
- 6. Clean off any dust and dirt with a vacuum cleaner. Place special emphasis on cleaning the ventilation ports and PCBs. Always keep these areas clean, as accumulation of dust and dirt can cause unforeseen failures.







CHAPTER 7 Troubleshooting and Fault Information

The AC drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC drive digital keypad display. The four most recent faults can be read on the digital keypad display.

NOTE: Faults can be cleared by a reset from the keypad or Input Terminal.

Common Problems and Solutions:

Fault Name	Fault Descriptions	Corrective Actions
ос	The AC drive detects an abnormal increase in current.	Check whether the motors horsepower corresponds to the AC drive output power
occ	IGBT protection (Insulated Gate Bipolar Transistor)	 drive output power. 2. Check the wiring connections between the AC drive and motor for possible short circuits. 3. Increase the Acceleration time. 4. Check for possible excessive loading conditions at the motor. 5. If there are any abnormal condition when operating the AC drive after short-circuit being removed, it should be sent back to manufacturer.
oυ	The AC drive detects that the DC bus voltage has exceeded its maximum allowable value.	 Check whether the input voltage falls within the rated AC drive input voltage. Check for possible voltage transients. Bus over-voltage may also be caused by motor regeneration. Either increase the decel time or add an optional braking resistor. Check whether the required braking power is within the specified limits.



Fault	VFD-G Series	
Name	Fault Descriptions	Corrective Actions
oΗ	The AC drive temperature sensor detects excessive heat.	 Ensure that the ambient temperature falls within the specified temperature range. Make sure that the ventilation holes are not obstructed. Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins. Provide enough spacing for adequate ventilation.
٤٠	The AC drive detects that the DC bus voltage has fallen below its minimum value.	Check whether the input voltage falls within the rated AC drive's input voltage.
οL	The AC drive detects excessive drive output current. Note: The AC drive can withstand up to 150% of the rated current for a maximum of 60 seconds.	 Check whether the motor is overloaded. Reduce torque compensation setting as set in Pr.7-02. Increase the AC drive's output capacity, i.e. bigger horsepower drive.
oL i	Internal electronic overload trip	 Check for possible motor overload. Check electronic thermal overload setting. Increase motor capacity, i.e. larger horsepower motor. Reduce the current level so that the drive output current does not exceed the value set by the Motor Rated Current Pr.7-00.
oL2	Motor overload. Check the parameter settings (Pr.6-03 to Pr.6-05)	 Reduce the motor load. Adjust the over-torque detection setting to an appropriate setting (Pr.06-03 to Pr.06-05).
cE-	Communication Error	 Check the connection between the AC drive and computer for loose wires. Check if the communication protocol is properly set.



CANELTA VFD-G Series			
Fault Name	Fault Descriptions	Corrective Actions	
ocA	Over-current during acceleration: 1. Short-circuit at motor output. 2. Torque boost too high. 3. Acceleration time too short. 4. AC drive output capacity is too small.	 Check for possible poor insulation at the output line. Decrease the torque boost setting in Pr.7-02. Increase the acceleration time. Replace with the AC drive with one that has a higher output capacity (next HP size). 	
೦೦ರ	Over-current during deceleration: 1. Short-circuit at motor output. 2. Deceleration time too short. 3. AC drive output capacity is too small.	 Check for possible poor insulation at the output line. Increase the deceleration time. Replace with the AC drive with one that has a higher output capacity (next HP size). 	
ocn	Over-current during steady state operation: 1. Short-circuit at motor output. 2. Sudden increase in motor loading. 3. AC drive output capacity is too small.	 Check for possible poor insulation at the output line. Check for possible motor stall. Replace with the AC drive with one that has a higher output capacity (next HP size). 	
EF.	The external terminal EF-GND goes from OFF to ON.	 When external terminal EF-GND is closed, the output will be turned off. (Under N.O. E.F.) Press RESET after fault has been cleared. 	
EF:	Emergency stop. When the multi-function input terminals (MI1 to MI6) stop, AC drive stops any output.	Press RESET after fault has been cleared.	
codE	Software protection failure	Return to the factory.	



EX NELTA VFD-G Series					
Fault Name	Fault Descriptions	Corrective Actions			
GFF	Ground fault: The AC drive output is abnormal. When the output terminal is grounded (short circuit current is 50% more than the AC drive rated current), the AC drive power module may be damaged. The short circuit protection is provided for AC drive protection, not user protection.	Ground fault: 1. Check whether the IGBT power module is damaged. 2. Check for possible poor insulation at the output line.			
ხხ	External Base Block. AC drive output is turned off. (Refer to Pr. 08-08)	 When the external input terminal (B.B) is active, the AC drive output will be turned off. Disable this connection and the AC drive will begin to work again. 			
Lc	Low Current	 Check Load current Check Pr.06-08 to Pr.06-10 setting 			
PHL	Phase Loss	Check Power Source Input			
FbL	Feedback Loss	Check Pr. 10-00 and wiring of feedback signal.			
HPF. I	GFF hardware error				
HPF2	CC (current clamp)				
HPF.3	OC hardware error	Return to the factory			
HPFY	OV hardware error	·			
HPFS	OH hardware error				
cF:	Internal memory IC cannot be programmed.	 Return to the factory. Check the EEPROM on the control board. 			
cF2	Internal memory IC cannot be read.	 Return to the factory. Reset drive to factory defaults. 			
cF33	U-phase error				
cF34	V-phase error				
cF35	W-phase error	Determ to the first of			
cF38	OV or LV	Return to the factory			
cF37	Isum error				
cF38	OH error				
<u> </u>					



CHAPTER 8 PARAMETER SUMMARY

Group 0 AC Drive Status Parameter

Parameters	Functions	Settings	Factory Setting	Customer
00-00	Software Version	Read only		
00-01	AC Drive Status Indication 1	·	Read	



Parameters	Functions	Settings	Factory Setting	Custome
00-02		Bit 0~1: 00: Run led is off and stop led is on. 01: Run led is blink and stop led is on. 10: Run led is on and stop led is blink. 11: Run led is on and stop led is off. Bit 2: 1: Jog on. Bit 3~4: 00: Rev led is off and FWD led is on. 01: Rev led is blink and FWD led is on. 10: Rev led is on and FWD led is on and FWD led is on and FWD led is off. Bit 5-7: Reserved Bit 5-7: Reserved Bit 8: Master frequency source via communication interface Bit 9: Master frequency source via analog Bit10: Running command via communication interface Bit11: Parameter locked Bit12~15: Reserved	Read	
00-03	Frequency Setting (F) or Closed Loop Control Setting Point		Read	
00-04	Output Frequency (H)	Read only	Read	
00-05	Output Current (A)	Read only	Read	
00-06	DC-BUS Voltage (U)	Read only	Read	
00-07	Output Voltage (E)	Read only	Read	
00-08	Output Power Factor (n)	Read only	Read	
00-09	Output Power (kW)	Read only	Read	
	Feedback Signal Actual Value	Read only	Read	
00-11	Feedback Signal (%)	Read only	Read	
00-12	User Target Value (Low bit) uL 0-99.99	Read only	Read	
00-13	User Target Value (High bit) uH 0-9999	Read only	Read	
00-14	PLC Time	Read only	Read	
00-15	Output Reactive Power (KVAR)	Read only	Read	



Group 1 Basic Parameter

	Parameters	Functions	Settings	Factory Setting	Customer
	01-00	Maximum Output Frequency	50.00~160.00Hz	60.00	
	01-01	Maximum Voltage Frequency (Base Frequency)	0.10~160.00 Hz	60.00	
	01-02	Maximum Output Voltage	0.2V ~ 510.0V	440.0	
	01-03	Mid-point Frequency	0.10~120 Hz	3.00	
	01-04	Mid-point Voltage	0.2V~510.0V	11.0	
	01-05	Minimum Output Frequency	0.10~20.00 Hz	3.00	
	01-06	Minimum Output Voltage	0.2V~100.0V	11.0	
	01-07	Upper Bound Frequency	0.00~160.00 Hz	60.00	
	01-08	Lower Bound Frequency	0.00~160.00 Hz	0.00	
N	01-09	Acceleration Time 1	0.1~3600.0 Sec	10.0/	
				60.0	
N	01-10	Deceleration Time 1	0.1~3600.0 Sec	10.0/ 60.0	
N	01-11	Acceleration Time 2	0.1~3600.0 Sec	10.0/	
N	01-12	Deceleration Time 2	0.1~3600.0 Sec	10.0/ 60.0	
×	01-13	Acceleration Time 3	0.1~3600.0 Sec	10.0/	
N	01-14	Deceleration Time 3	0.1~3600.0 Sec	10.0/	
N	01-15	Acceleration Time 4	0.1~3600.0 Sec	10.0/	
N	01-16	Deceleration Time 4	0.1~3600.0 Sec	10.0/	
×	01-17	JOG Acceleration Time	0.1~3600.0 Sec	10.0/	
×	01-18	JOG Deceleration Time	0.1~3600.0 Sec	10.0/	
N	01-19	JOG Frequency	0.0 Hz~160.00 Hz	6.00	
	01-20	S Curve Delay Time in Accel	0.00~2.50sec	0.00	
	01-21	S Curve Delay Time in Decel	0.00~2.50sec	0.00	
N	01-22	Modulation Index	0.90~1.20	1.00	
	01-23	Accel/Decel Time Unit	00: Unit is 1 Sec 01: Unit is 0.1 Sec 02: Unit is 0.01 Sec	01	



Group 2 Digital Output/Input Parameter

	Parameters	Functions	Settings	Factory Setting	Customer
*	02-00	Source of Frequency Command	00: via keypad 01: via analog input AI1 02: via analog input AI2 03: via RS485 serial communication 04: via External Reference	00	
*	02-01	Source of Operation Command	 00: Controlled by the digital keypad 01: Controlled by the external terminals, keypad STOP enabled. 02: Controlled by external terminals, keypad STOP disabled. 03: Controlled by the RS-485 communication interface, keypad STOP enabled. 04: Controlled by the RS-485 communication interface, keypad STOP disabled. 	00	
	02-02	Stop Method	 O0: Stop = ramp to stop, E.F. (External Fault) = coast to stop O1: Stop = coast to stop, E.F. = coast to stop O2: Stop = ramp to stop, E.F. = ramp to stop O3: Stop = coast to stop, E.F. = ramp to stop 	00	
N	02-03	PWM Carrier Frequency Selections	1K~6KHz	##	
	02-04	Forward/Reverse Enable	00: Forward enabled 01: Reverse disabled 02: Forward disabled	00	
	02-05	2-wire/3-wire Operation Control Modes	00: 2-wire: FWD/STOP, REV/STOP 01: 2-wire: FWD/REV, RUN/STOP 02: 3-wire operation	00	
	02-06	Line Start Lockout	00: Disabled 01: Enabled	01	
	02-07	Reserved			



	EARELA VI D-O GENES				
	Parameters	Functions	Settings	Factory Setting	Customer
	02-08	Start-up Display Selection	Bit0~1: 00 = F LED	00	
*	02-09	Special Display	O0: A displays output current of AC drive O1: U displays DC-Bus voltage of AC drive O2: E displays RMS of output voltage O3: P displays feedback Signal O4: PLC display auto procedure state	00	
×	02-10	User Defined Coefficient	0.01~160.00	1.00	
*	02-11	Flying Start	00: Disabled 01: Enable (Dc braking disabled)	00	
×	02-12	Flying Start Frequency	00: Trace from master frequency command 01: Trace from maximum setting frequency 01-00	00	
×	02-13	Master Frequency Memory Setting	00: Do not remember the last known frequency 01: Remember the last known frequency	01	



Group 3 Output Function Parameters

Parameters	Functions	Settings	Factory Setting	Customer
03-00	Multi-function Output Terminal 1 (Relay)	 00: disabled 01: Indication during operation 02: Master frequency attained 03: Zero Speed (including shutdown) 04: Over-torque 05: External Fault 06: Low voltage detection 07: Operation Mode indication 08: Fault indication 09: Master Frequency Attained 1 10: Master Frequency Attained 2 11: Over Temperature indication 12: Drive Ready 13: External Emergency Stop (EF1) 14: Software Braking Output 15: OL or OL1 Overload Warning 16: Low Current Indication 17: PID Feedback Error Indication 18: PLC Program Running 19: PLC Program Step Completed 20: PLC Program Completed 21: PLC Operation Paused 	01	
03-01	Reserved	1		
03-02	Master Frequency Attained 1	0.00~160.00 Hz	0.00	
03-03	Master Frequency Attained 2	0.00~160.00 Hz	0.00	
03-04	DC Fan Control	 00: Fan runs on power up. 01: Fan begins upon a RUN command. Fan stops 1 minute after a STOP command. 02: Fan begins upon a RUN command. Fan stops after a STOP command 03: Fan is controlled by temperature. Fan will be started at approximate 60°C. 	00	



Parameters	Functions	Settings	Factory Setting	Customer
03-05	r indiog Odipat Olgital i	00: Output frequency 01: Output current	00	
03-06		02: Output voltage 03: Frequency command 04: Power factor loading	01	
03-07	Analog Output Gain 1	01~200%	100	
03-08	Analog Output Gain 2	01~200%	100	
03-09	Analog Output 2 Selection	00: 0~20mA 01: 4~20mA	01	



Group 4 Input Function Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	04-00	Multi-function Input Terminal 1	00: disabled	01	
	04-01	Multi-function Input Terminal 2		02	
	04-02	Multi-function Input Terminal 3		03	
	04-03	Multi-function Input Terminal 4	03: Multi-Speed terminal 3	04	
	04-03		 04: Multi-Speed terminal 4 05: Reset (NO) 06: Reset (NC) 07: Jog operation (JOG) 08: Accel/Decel disabled 09: 1st and 2nd Accel/Decel selection 10: 3rd and 4th Accel/Decel selection 11: B.B. (NO) input 12: B.B. (NC) input 13: Increase Frequency 14: Decrease Frequency 15: Emergency stop (NO) 16: Emergency stop (NC) 17: KEYPAD(open), EXT(close) 18: PID disable 19: Run PLC Program 20: Pause PLC Program 21: 1st Output Frequency Gain (Pr.04-30) 22: 2nd Output Frequency 	04	
			Gain (Pr.04-31) 23: 3rd Output Frequency		
			Gain (Pr.04-32)		
	04-04	Digital Input Terminal Response Time	01~20	01	
	04-05	Minimum AI1 Analog Input	0 ~ 100%	0	
	04-06		0 ~ 100%	100	
	04-07	corresponds to AI1	0.00~100.00%	0.00	
	04-08	corresponds to AI1	0.00~100.00%	100.00	
	04-09	Minimum Al2 Analog Input	0 ~ 100%	0	
	04-10		0 ~ 100%	100	
	04-11	Minimum Output that corresponds to Al2	0.0~100.0%	0.00	
	04-12		0.0~100.0%	100.00	
×	04-13	1st Al1 Gain	0.0~100.0%	100.0	



		VFD-G Series				
	Parameters	Functions	Settings	Factory Setting	Customer	
N	04-14	2nd AI1 Gain	0.0~100.0%	100.0		
N	04-15	3rd Al1 Gain	0.0~100.0%	100.0		
N	04-16	4th AI1 Gain	0.0~100.0%	100.0		
N	04-17	5th AI1 Gain	0.0~100.0%	100.0		
N	04-18	1st Al2 Gain	0.0~100.0%	100.0		
N	04-19	2nd AI2 Gain	0.0~100.0%	100.0		
N	04-20	3rd AI2 Gain	0.0~100.0%	100.0		
N	04-21	4th AI2 Gain	0.0~100.0%	100.0		
N	04-22	5th AI2 Gain	0.0~100.0%	100.0		
	04-23	Analog Input Delay AI1	0.00~10.00 Sec	0.50		
	04-24	Analog Input Delay Al2	0.00~10.00 Sec	0.50		
	04-25	Summation of External	00: Disabled	00		
		Frequency Sources	01:AI1*(AI1 Gain) +			
		, ,	Al2*(Al2 Gain)			
			02:AI1*(AI1 Gain) -			
			Al2*(Al2 Gain)			
			03: Al1*(Al1 Gain) * Al2			
			*(Al2 Gain)			
			04: Reserved			
			05: Communication master			
			frequency+AI1*(AI1			
			Gain)			
			06: Communication master			
			frequency+Al2*(Al2			
			Gain)			
			07: Max (Al1*(Al1 Gain), Al2*(Al2 Gain))			
	04-26	1st Al Fraguency Gain	0.00: Disabled	0.00		
	U 4 -20	1st Al Frequency Gain	0.01~160.00 Hz	0.00		
	04-27	2nd Al Frequency Gain	0.00: Disabled	0.00		
	0127	Zila / li roquonoy Gain	0.01~160.00 Hz	0.00		
	04-28	3rd Al Frequency Gain	0.00: Disabled	0.00		
		, ,	0.01~160.00 Hz			
	04-29	4th Al Frequency Gain	0.00: Disabled	0.00		
			0.01~160.00 Hz			
	04-30	1st Out Frequency Gain	0.0 to 200.0%	100.0		
	04-31	2nd Out Frequency Gain	0.0 to 200.0%	100.0		
Ш	04-32	3rd Out Frequency Gain	0.0 to 200.0%	100.0		



Group 5 Multi-step Speed Frequency Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
N	05-00	1st Step Speed Frequency	0.00~160.00 Hz	0.00	
×	05-01	2nd Step Speed Frequency	0.00~160.00 Hz	0.00	
×	05-02	3rd Step Speed Frequency	0.00~160.00 Hz	0.00	
N	05-03	4th Step Speed Frequency	0.00~160.00 Hz	0.00	
×	05-04	5th Step Speed Frequency	0.00~160.00 Hz	0.00	
N	05-05	6th Step Speed Frequency	0.00~160.00 Hz	0.00	
N	05-06	7th Step Speed Frequency	0.00~160.00 Hz	0.00	
×	05-07		0.00~160.00 Hz	0.00	
N	05-08		0.00~160.00 Hz	0.00	
<i>×</i>	05-09	10th Step Speed Frequency		0.00	
, ·	05-10	11th Step Speed Frequency		0.00	
<u> </u>	05-11	12th Step Speed Frequency		0.00	
<u> </u>	05-12	13th Step Speed Frequency		0.00	
<i>^</i> `	05-13	14th Step Speed Frequency		0.00	
<u> </u>	05-14	15th Step Speed Frequency			
/	05-14	PLC Mode	00: Disable PLC Operation	0.00	
			 01: Execute one program cycle 02: Continuously execute program cycles 03: Execute one program cycle step by step 04: Continuously execute program cycles step by step 		
	05-16	PLC Forward/ Reverse Motion	00 to 32767 (00: FWD 01: REV)	00	
	05-17	Time Duration Step 1	0.0 to 65500 sec	0.0	
	05-18	Time Duration Step 2	0.0 to 65500 sec	0.0	
	05-19	Time Duration Step 3	0.0 to 65500 sec	0.0	
	05-20	Time Duration Step 4	0.0 to 65500 sec	0.0	
	05-21	Time Duration Step 5	0.0 to 65500 sec	0.0	
	05-22	Time Duration Step 6	0.0 to 65500 sec 0.0 to 65500 sec	0.0	
	05-23 05-24	Time Duration Step 7 Time Duration Step 8	0.0 to 65500 Sec	0.0	
	05-24	Time Duration Step 9	0.0 to 65500 Sec	0.0	
	05-26	Time Duration Step 10	0.0 to 65500 Sec	0.0	
	05-27	Time Duration Step 11	0.0 to 65500 Sec	0.0	



Parameters	Functions	Settings	Factory Setting	Customer
05-28	Time Duration Step 12	0.0 to 65500 Sec	0.0	
05-29	Time Duration Step 13	0.0 to 65500 Sec	0.0	
05-30	Time Duration Step 14	0.0 to 65500 Sec	0.0	
05-31	Time Duration Step 15	0.0 to 65500 Sec	0.0	
05-32	Time Unit Settings	00: 1 Sec 01: 0.1 Sec	00	



Group 6 Protection Function Parameters

Parameters	Functions	Settings	Factory Setting	Customer
06-00	Over-voltage Stall Prevention	660.0V~820.0VDC 00: Disabled	780.0	
06-01	Over-current Stall Prevention during Acceleration	20~250% 00: Disabled	150%	
06-02	Over-current Stall Prevention during operation	20~250% 00: Disabled	150%	
06-03	Over-torque Detection Selection	 00: Over-torque detection disabled. 01: Over-torque detection enabled during constant speed operation (OL2), and operation continues. 02: Over-torque detection enabled during constant speed operation (OL2), and operation halted. 03: Over-torque detection enabled during operation (OL2), and operation continues. 04: Over-torque detection enabled during operation (OL2), and operation (OL2), and operation halted. 	00	
06-04	Over-torque Detection Level	30~150%	110	
06-05	Over-torque Detection Time	0.1~60.0 Sec	0.1	
06-06	Electronic Thermal Relay Selection	00: Operate disabled.01: Operate with a standard motor.02: Operate with a special motor.	02	
06-07	Electronic Thermal Characteristic	30~600 Sec	60	
06-08	Low Current Detection Level	00~100% (00 disabled)	00	
06-09	Low Current Detection Time	0.1~ 3600.0 Sec	10.0	
06-10	Low Current Detection Treatment	00: Warn and Ramp to stop 01: Warn and Coast to stop 02: Warn and keep operating	01	



Parameters	Functions	Settings	Factory Setting	Customer
06-11	Present Fault Record	00: No Fault	00	
06-12	Second Most Recent Fault Record	01: Oc (over-current) 02: Ov (over-voltage)	00	
06-13	Third Most Recent Fault Record	03: OH (over temperature) 04: OL (over load)	00	
06-14	Fourth Recent Fault Record	 05: oL1 (over load 1) 06: EF (external fault) 07: Occ (IGBT module is abnormal) 08: CF3 (driver's internal circuitry is abnormal) 09: HPF (hardware protection failure) 10: OcA (over-current during acceleration) 11: Ocd (over-current during deceleration) 12: Ocn (over-current during steady state operation) 13: GFF(Ground Fault) 14: Lv (Low voltage) 15: CF1 (CPU READ failure) 16: CF2 (CPU WRITE failure) 17: bb (Base Block) 18: OL2 (over load2) 19: Reserved 20: Code (software/password protection) 21: EF1 (Emergency stop) 22: PHL (phase-loss) 23: Lc (Low Current) 24: FbL(Feedback Loss) 25: Reserved 	00	
06-15	Parameter Reset	00~65535 09: Reset parameters (50Hz, 380) 10: Reset parameters (60Hz, 440)	00	
06-16	Parameter Protection Password Input	00~65535	00	
06-17	Parameter Protection Password Setting	00~65535 00: No password protection	00	



Group 7 AC Drive and Motor Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	07-00	Identity Code of AC Drive	Display by model type	##	
	07-01	Rated Current of AC Drive	Display by model type	##	
N	07-02	Full-load Current of Motor	30~120%	100%	
N	07-03	No-load Current of Motor	1~99%	30%	
N	07-04	Auto Slip Compensation Gain	0.0~3.0	0.0	
	07-05	Rated Slip Frequency of Motor	0.00~20.00Hz	0.00	
×	07-06	Auto Torque Compensation Gain	0.0~10.0	0.0	
×	07-07	Torque Compensation Gain by Manually	0.0~10.0	0.0	
	07-08	Calculate Total Running Time of the Motor (Min)	00 to 1439 Min	00	
	07-09	Calculate Total Running Time of the Motor (Day)	00 to 65535 Day	00	
	07-10	Electric Bill for One Time	Read Only	Read	
	07-11 Accumulated Electric Bill (per currency unit)		Read Only	Read	
	07-12	Accumulated Electric Bill (per 10 ⁴ currency unit)	Read Only	Read	
	07-13	Electric Rate (per currency unit)	0.01 to 655.35	0.6	



Group 8 Special Parameters

Parameters	Functions	Settings	Factory Setting	Custome
08-00	DC Braking Current Level	00~100%	00	
08-01	DC Braking Time during Start-up	0.0~60.0 Sec	0.0	
08-02	DC Braking Time during Stopping	0.00~60.00 Hz	0.0	
08-03	Start-point for DC Braking	0.00~160.00 Hz	0.00	
08-04	Momentary Power Loss Operation Selection	00: Disable 01: Trace from top downward 02: Trace from bottom upward	00	
08-05	Maximum Allowable Power Loss Time	0.1~5.0 Sec	2.0	
08-06	Speed Search Time	0.1~5.0 Sec	0.5	
08-07	Maximum Speed Search Current	30~150%	110	
08-08	BB speed search method	00: Trace from top downward 01: Trace from bottom upward	00	
08-09	Auto Restart Times after Fault	00~10	00	
08-10	Auto Restart Time after Fault	00 to 60000 sec	600	
08-11	Operation Frequency Inhibition 1 UP	0.00~160.00 Hz	0.00	
08-12	Operation Frequency Inhibition 1 DOWN	0.00~160.00 Hz	0.00	
08-13	Operation Frequency Inhibition 2 UP	0.00~160.00 Hz	0.00	
08-14	Operation Frequency Inhibition 2 DOWN	0.00~160.00 Hz	0.00	
08-15	Operation Frequency Inhibition 3 UP	0.00~160.00 Hz	0.00	
08-16	Operation Frequency Inhibition 3 DOWN	0.00~160.00 Hz	0.00	
08-17	Automatic Energy-saving	00: Energy-saving operation disabled 01: Energy-saving operation enabled	00	
08-18	Automatic Voltage Regulation (AVR)	00: AVR function enabled 01: AVR function disabled 02: AVR function disabled for deceleration	00	
08-19	Software Setting of the Braking Level (the action level of the braking resistor)	740V~820VDC 00:Disabled	760	
08-20	Vibration Compensation Factor	00~1000	00	



Group 9 Communication Parameters

GI	oup a comi	nunication Parameters	T	T	1 1
	Parameters	Functions	Settings	Factory Setting	Customer
×	09-00	Communication Address	01-254 00:Disabled	01	
×	09-01	Transmission Speed (Baud Rate)	00: Baud rate 4800 01: Baud rate 9600 02: Baud rate 19200 03: Baud rate 38400	01	
×	09-02	Transmission Fault Treatment	00: Warn and keep operating 01: Warn and RAMP to stop 02: Warn and COAST to stop 03: No warning and no display	03	
	09-03	Over Time Detection during Transmission	00: Disabled 01: Enabled	00	
	09-04	Communication Format	00: 7-bit for ASCII 01: 8-bit for ASCII 02: 8-bit for RTU	00	
	09-05	Even/Odd Parity and Stopping Parity Setting	00: None parity + 2 stop bit 01: Even parity + 2 stop bit 02: Odd parity + 2 stop bit 03: None parity + 1 stop bit 04: Even parity + 1 stop bit 05: Odd parity + 1 stop bit	00	
	09-06	Communication Operation Command 1	Bit0~1: 00: Disable 01: Stop 10: Start-up 11: JOG start-up Bit2~3: Reserved Bit4~5: 00: No function 01: FWD command 10: REV command 11: Change direction command Bit6~7: 00: 1st step accel/decel speed 01: 2nd step accel/decel speed 10: 3rd step accel/decel speed 11: 4th step accel/decel speed	00	



	Parameters	Functions	Settings	Factory Setting	Customer
N	09-06	Communication Operation	Bit8~11:	00	
		Command 1	0000: Master speed		
			0001: 1 st step speed		
			0010: 2 nd step speed		
			0011: 3rd step speed		
			0100: 4th step speed		
			0101: 5th step speed		
			0110: 6th step speed		
			0111: 7th step speed		
			1000: 8th step speed		
			1001: 9th step speed		
			1010: 10th step speed		
			1011: 11th step speed		
			1100: 12th step speed		
			1101: 13th step speed		
			1110: 14th step speed		
			1111: 15th step speed		
			Bit12: Select Bit6~11 function		
			Bit13~15 Reserved		
N	09-07	Communication	0~160.00Hz	60.00	
		Frequency Setting			
N	09-08	Communication Operation	Bit0: 1: EF ON	00	
		Command 2	Bit1: 1: Reset		
			Bit2: 0: BB OFF, 1: BB ON		
			Bit3~15: Reserved		



Group 10 PID Controls

<u> </u>	oup to PID C	201111 013			
	Parameters	Functions	Settings	Factory Setting	Customer
	Feedback		00: Disabled 01: Input via AI1 02: Input via AI2 03: Input via External Reference	00	
	10-01	PID Control Detection Signal Reference	1.0-6550.0	1000.0	
	10-02	PID Feedback Control Method	00: Normal (Err=SP-FB) 01: Inverse (Err=FB-SP)	00	
	10-03	Proportional Gain (P)	0.0~10.0	1.0	
	10-04 Integral Time (I)		0.00~100.00 Sec	1.00	
	10-05	Differential Time (D)	0.00~1.00 Sec	0.00	
	10-06	Upper Bound for Integral Control	00~200%	100	
	10-07	Primary Low Pass Filter Time	0.0~2.5 Sec	0.0	
	10-08	PID Feedback Signal Range	0.01 to 10-01	600.0	
	10-09	PID Feedback Signal Fault Treatment Time	0. 0~3600.0 Sec 0.0: Disabled	0.0	
*	10-10	PID Feedback Signal Fault Treatment	00: Warn and RAMP stop 01: Warn and COAST stop 02: Warn and keep operating	01	
	10-11	V/F Curve Selection	00: Determined by group 01 01: 1.5 power curve 02: 1.7 power curve 03: 2 power curve 04: 3 power curve	00	



Specifications

	Voltage	Class					4	60V Cla	ss				
Мо	del Number VI	FD-0000G43X	055	075	110	150	185	220	300	370	450	550	750
Max.	Applicable Mo	5.5	7.5	11	15	18.5	22	30	37	45	55	75	
Max.	x. Applicable Motor Output (HP)			10	15	20	25	30	40	50	60	75	100
g	Rated Outpu	it Capacity (KVA)	10	14	18	25	29	34	46	56	69	84	114
Output Rating	Rated Out	put Current (A)	13	18	24	32	38	45	60	73	91	110	150
T T	Maximum O	utput Voltage (V)				Р	roportion	nal to Inp	out Volta	ige			
Jutp	Rated From	equency (Hz)			•		0.1	0-120.0	0Hz				
	Carrier Fre	equency (kHz)	4	-6		3-	-6				2-6		
t gc		out Current (A)	14	19	25	32	39	49	60	73	91	120	160
Input Rating		d Voltage					3-pha		:-528 V				
_ 12	•	cy Tolerance						17 – 63 l					
S	-	ol System		SPWN	/I (Sinus	oidal Pu	lse Widt			arrier fre	quency 2	2-6kHz)	
stic	Output Frequ	uency Resolution						0.01Hz					
Control Characteristics	Torque C	haracteristics	Incl	uding the	e auto-to			1.0Hz			orque ca	n be 150)% at
har	Overload	d Endurance					% of rate						
itrol C	Accel/I	Decel Time	1-36	1-36000/0.1-3600.0/0.01-360.00 seconds (3 Independent settings for Accel/Decel Time)									
Š	V/F	Adjustable V/F pattern											
	Stall Prev	vention Level	20 to 150%, Setting of Rated Current										
	Frequency Keypad		Frequency										
istics	Setting	External Signal	2 sets of analog inputs, 15 Multi-Function Inputs, RS-485 interface (MODBUS), Extension terminals UP/DOWN Key						External				
cter	Operation	Keypad	Set by RUN, STOP and JOG										
hara	Setting Signal	External Signal			•						n operati		
ting C	Multi-Funct	ion Input Signal	Multi-step selection 0 to 15, Jog, accel/decel inhibit, first to forth accel/decel switches, counter, external Base Block (NC, NO), JOG							vitches,			
Operating Characteristics		nction Output dication	AC Drive Operating, Frequency Attained, Desired Frequency Attained, Zero speed, Base Block, Fault Indication and Local/Remote indication							peed,			
	Analog C	Output Signal	2 sets of Analog frequency/current signal output										
	Other Fur	nctions	Reve	AVR, 2 types of S-Curve, Over-Voltage, Over-Current Stall Prevention, Fault Records, Reverse inhibition, DC Braking, Momentary Power Loss restart, Auto torque and slip compensation, PID Control, Parameter Lock/Reset, Frequency Limits, Adjustable Carrier Frequency						nd slip			
	Protec	tion	Sel								erload, (Phase-lo		ting,
	Cooling M	lethods						ed Fan-d					
	Installation	on Location		Altituc	le 1,000	m or lov	ver, keep	o from c	orrosive	gasses,	liquid a	nd dust	
Ħ	Pollutio	on Degree						2					
me		Temperature			-10	OC to 40	OoC Nor	-Conde	nsing an	nd not fro	ozen		
Environment		ransportation perature					-20	OC to 6	0oC				
面	Ambien	t Humidity				Belo	w 90%	RH (non	-conder	nsing)			
Vibration 9.80665m/s2 (1G) less than 20Hz, 5.88m						88m/s2 (0.6G) at 20 to 50Hz							







ACCESSORIES

B.1 All Braking Resistors & Braking Units Use in AC Drives

Note: Please only use DELTA resistors and recommended values. Other resistors and values will void Delta's warranty. Please contact your nearest Delta representative for use of special resistors. For instance, in 460 V series, 100 HP, AC drive has 2 braking units with total of 16 braking resistors, so each braking unit uses 8 braking resistors. There should be at least 10 cm away from AC drive to avoid possible noise. Refer to the "Braking Unit Module User Manual" for further detail.

ıge	Applicable Motor HP kW ★Full Load Torque KG-M			Equivalent Resistors	Braking Unit		Braking Resistors		Braking	Minimum Equivalent Resistor
Voltage			Torque Specification for Each AC		Model VFDB No. of Unit Used		Model No. of Units Used		Torque 10%ED%	Value for Each AC Drive
	7.5	5.5	3.111	500W 100 Ω			BR500W100	1	125	60 Ω
	10	7.5	4.148	1000W 75 Ω			BR1K0W075	1	125	45 Ω
	15	11	6.186	1000W 50 Ω			BR1K0W050	1	125	50Ω
S	20	15	8.248	1500W 40 Ω			BR1K5W040	1	125	40 Ω
Series	25	18.5	10.281	4800W 32 Ω	4030	1	BR1K2W008	4	125	32Ω
	30	22	12.338	4800W 27.2 Ω	4030	1	BR1K2W6P8	4	125	27.2 Ω
460V	40	30	16.497	6000W 20 Ω	4030	1	BR1K5W005	4	125	20 Ω
46	50	37	20.6	9600W 16Ω	4045	1	BR1K2W008	8	125	16 Ω
	60	45	24.745	9600W 13.6Ω	4045	1	BR1K2W6P8	8	125	13.6 Ω
	75	55	31.11	12000W 10 Ω	4030	2	BR1K5W005	8	125	10Ω
	100	75	42.7	19200W 6.8Ω	4045	2	BR1K2W6P8	16	125	6.8 Ω

Note:

- 1. Please select the factory default resistance value (Watt) and the frequency value (ED%)
- 2. If damage resulted in the drive or other equipments due to the fact that the braking resistors and the braking modules in use are not provided by Delta, the warranty will be void.
- 3. Take into consideration the safety of the environment when installing the braking resistors.
- 4. If the minimum resistance value is to be utilized, consult local dealers for the calculation of the Watt figures.
- 5. Please select thermal relay trip contact to prevent resistor over load.
- 6. When using more than 2 braking units, equivalent resistor value of parallel braking unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the right-most column in the table).








DIMENSIONS


VFD055F43B-G


VFD075F43B-G

VFD110F43A-G

VFD150F43A-G










VFD185F43A-G


VFD220F43A-G

VFD300F43A-G





VFD370F43A-G VFD450F43A-G VFD550F43A-G





VFD750F43A-G

