



Washer-dryer



BOSCH

en Installation and operating instructions

Contents

Operating instructions	General safety information	3
	Environmental protection/economy tips	4
	Your new washer-dryer	5
	Before washing for the first time	7
	Preparing and sorting the laundry	7
	Detergents and Care Products.....	9
	Programmes.....	11
	Washing and drying options	13
	Washing and drying	15
	Cleaning and care	17
	What to do if... ..	19
	After-sales service	22
Installation instructions	Installation instructions	23
Appendix	Table of programmes.....	28
	Consumption rates.....	29
	Index.....	30



Please read the Installation and operating instructions and all the other information supplied and handle the appliance accordingly.

Keep all documents in a safe place for future reference, or to pass on to the next owner.

For further information and a selection of our products, visit our website:

www.bosch-home.com

General safety information

Intended use

The washer-dryer is designed for:

- domestic use only.
- machine-washable fabrics in detergent solution and drying these fabrics.
- operation with cold drinking water and commercially available detergents and care products that are suitable for use in washing machines.

This washer-dryer complies with the relevant safety regulations..

Hazard warnings



- Keep packaging and packing materials out of the reach of children. **Risk of suffocation** from plastic film and collapsible boxes.
- When an appliance is worn out, unplug it from the mains. Cut through the mains cable and remove it together with the plug. Destroy the lock on the door. This will prevent children from getting locked in and **putting their lives in danger**.

Do not use the washer-dryer if the laundry:

- has been treated with solvents, oil, wax, fat or dye (e.g. stain remover, cleaning solvent, hairspray, nail varnish remover).
- has come into contact with hairspray, nail varnish remover, or similar substances. **Risk of fire or explosion!**
- contains dust residues, e.g. coal dust or flour **Risk of explosion!**
- contains foam/rubber.

Before using for the first time

- Set up the washer-dryer according to the installation instructions → page 23.
- Remove the transport safety bolts and keep them in a safe place.
- Do not operate the washer-dryer if it has any visible damage. If you are in any doubt, please consult our after-sales service or your retailer.

When washing and drying

- Remove all objects from pockets, particularly sources of ignition (e.g. lighters, matches, etc.).
- Do not leave children unsupervised near the washer-dryer.
- The washer-dryer must not be used by children or persons who have not been instructed in its use.
- Keep pets away from the washer-dryer.
- Take care when Draining hot detergent solution.
- The washing machine door can become very hot during operation.
- Condensed water is not drinking water quality and may be contaminated with fluff.

To protect the washer-dryer

- Do not climb onto the washer-dryer.
- Do not lean on the open door of the washer-dryer.
- Do not install the washer-dryer in areas that are at risk of frost.
- Do not transport the washer-dryer without the transport safety bolts in place.

Environmental protection/economy tips

- Separate out the various waste materials of the packaging and take them to the nearest collection point.
- Always fill the washer-dryer with the maximum load for the relevant programme.
- Wash normally soiled laundry without a prewash.
- Instead of **Resistentes/Algod. (Cottons/Coloureds) 90 °C**, select the **Color eco/Cor eco (Cottons Eco) 60 °C** programme. This gives comparable results, but uses less energy.
- Measure the detergent according to the manufacturer's instructions and in line with the local water hardness.

WEEE



This appliance is labelled in accordance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment - WEEE. The directive provides an EU-wide framework for the return and recycling of used appliances.

Your new washer-dryer

Description of the washer-dryer

The washer-dryer can be used in 3 ways -> page 15:

- washing only
- drying only
- successive washing and drying.

The successive wash-dry programme automatically shifts from the wash cycle to the dry cycle without further intervention.

Drying is achieved using the condensation principle. The condensate that is produced during drying runs via the Drain hose into the Drain tank.

Caution: the water supply hose and water Drain hose must be correctly connected during washing and drying -> page 26. The tap must be open.

Door

A safety device prevents the door from being opened during operation.

Before opening

Make sure that there is no water in the drum and that the drum is not moving.

Emergency release

In the event of a power cut, the door can be released mechanically -> page 21.

Control panel

Indicator lamp

Indicates the settings that have been selected for:

- Temperature: ☼ - 90°C.
- Spin speed: ☹ - 1400 rpm.
- Options/signal.


Display panel

Shows the settings that have been selected (e.g. spin speed, drying time), the progress of the current programme and the programme status.

Programme progress ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹	Pre-wash, Main wash, Rinse, Final spin, Drying.
Drying options ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹	Time-controlled drying, Iron-damp, Cupboard-dry, Extra-dry.
Auxiliary displays ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹ ☹	Finished in time, Programme start, Childproof lock, Fluff-removal cycle, recommended load.

Indicator lamp

Display panel



Buttons

Programme selector

Washing and drying options -> page 13

- **°C (Temperature):** individual adjustment of the washing temperature.
- **☹ (Spin speed):** individual adjustment of the spin speed.
- **menu (Options):** sets washing options.
- **selec.:** activation/deactivation of the selected washing options.
- **☹ (Finished in time):** delays the Programme start.
- **Secar (Drying):** sets the drying options

☹☹ (Start/Pause):

starts and stops the washing programme -> page 14.

Programme selector -> page 11

For switching the washer-dryer on and off and for selecting the programme, can be turned in both directions. Do not adjust the programme selector while washing/drying is in progress.

Before washing for the first time

The washer-dryer was tested before leaving the factory. To remove any water that may be left over from the test, do not load any laundry the first time that you run a wash programme.

- ☐ Make sure that the transport safety bolts on the rear of the washer-dryer have been removed → page 24.
- ☐ Do not load any laundry.
- ☐ Close the door.
- ☐ Turn on the tap.
- ☐ Pull out the detergent drawer.
- ☐ Add ½ a measuring cup of detergent to **compartment II** → page 9.



Do not use detergents for wool or delicates (these cause foam to be created).

- ☐ Close the detergent drawer.
- ☐ Turn the programme selector to the **60 °C** programme.
- ☐ Press the  (**Start/Pause**) button.
- ☐ At the end of the programme, turn the programme selector to **Stop**.
- ☐ Open the door.



Leave the door open to allow the inside of the washer-dryer to dry.

Preparing and sorting the laundry

Sorting laundry for washing

- Wash white laundry separately from coloureds.
- Unhemmed or torn items should not be washed in the washer-dryer, as they may fray.
- The laundry may be damaged if you do not observe the fabric care symbols.

Sorting laundry according to the information on the care labels

Only wash laundry with the following care labels:

Care label	Type of laundry
	Cottons 90 °C.
	Coloureds 60 °C, 40 °C, 30 °C.
	Easy-care 60 °C, 40 °C, 30 °C.
	Hand- and machine-washable silk, 40 °C, 30 °C, cold.

Laundry with care symbol  **Do not wash.**

Sorting laundry for drying

Sorting laundry according to the information on the care labels

Only dry laundry that is labelled "**suitable for tumble-drying**" or which has the following care symbols:

Care label	Type of laundry
	Dry at normal temperature.
	Dry at low temperature (delicate drying).

Do **not** wash the following fabrics in the washer-dryer:

- Do not machine dry laundry with the  care symbol.
- Airtight fabrics (e.g. rubber-coated fabrics).
- Delicate materials (silk, curtains made from synthetic fabrics) - **they may crease.**
- Dripping-wet laundry - **high energy consumption**
- Wool or fabrics containing wool.

Preparing laundry for washing

Loose foreign bodies (e.g. coins, paper-clips, needles, nails) may damage the laundry and components of the washer-dryer (e.g. the drum).

- ☐ Drain the pockets of all items.
- ☐ Brush any sand out of pockets and collars.
- ☐ Pretreat any stains.
- ☐ Close zips, do up cover buttons.
- ☐ Remove curtain fittings or place curtains in a laundry bag.
- ☐ Wash the following in a laundry bag/pillowcase:
 - Delicates, e.g. tights, curtains,
 - Small items, e.g. socks or handkerchiefs,
 - Underwired bras (the underwiring may come loose during the washing process and cause damage).
- ☐ Turn trousers, knitwear and knitted fabrics, e.g. jerseys, T-shirts or sweatshirts inside out.

Preparing laundry for drying

- ☐ Only dry fabrics that have already been washed, rinsed and spun.
- ☐ Also spin easy-care fabrics before drying.
- ☐ Sort the items for washing according to material and desired level of dryness to ensure even drying.

Loading the laundry




Before loading the washer-dryer, make sure that there are no foreign bodies or pets in the drum.

Risk of explosion. items that have been treated with cleaning agents containing solvents, e.g. stain remover or, must be carefully rinsed out before they are loaded into the washer-dryer, otherwise there is the risk of an explosion.

- ☐ Unfold the laundry and place it loosely in the drum. Load a mixture of small and large items.
- ☐ Observe the maximum drum loads, Programme table → page 28.
- ☐ Take care not to trap items of laundry between the door and the rubber seal.
- ☐ Close the door. You will hear it click shut.
- ☐ Measure out and add detergent and care products for only a washing programme or a combined washing and drying programme.
- ☐ Turn on the tap.

Detergents and Care Products

Detergent drawer



The detergent drawer is divided into three compartments

Compartment I : detergent for pre-wash.

Compartment II : detergent for main wash,

Compartment * : Liquid additives, such as starch or fabric softener. Additives are automatically dispensed during the final rinse cycle.

- Do not exceed the maximum capacity, otherwise compartment * may be emptied too early.
- Dilute viscous additives with water to prevent blockages.

Liquid detergent insert: this must be inserted before liquid detergents are used.

To do this:

- ☐ Pull out the detergent drawer as far as the stop.
- ☐ Press on the zone labelled **PUSH** and take out the detergent drawer.
- ☐ Pull the insert in **compartment II** forwards as far as the stop **and** push it down.
- ☐ Insert the detergent drawer.

Descaler

Descaler can be added to **compartments I** and **II** according to the manufacturer's instructions. Add detergent first, followed by the descaler.

Detergents and care products



Risk of poisoning

Keep detergents and care products out of the reach of children.

Risk of chemical burns

Take care when opening the detergent drawer. There may still be detergent residues in the drawer.

Select the correct dosage for the detergent according to:

- the size of the load,
- the instructions of the detergent manufacturer,
- how dirty the laundry is,
- the water hardness. You can find out about water hardness in your area from your local waterworks.



Using the correct dosage reduces the impact on the environment and gives a good washing result.



Only use pH-neutral wool detergent for woollens programmes.

Measuring washing powder

Normally soiled laundry

- ☐ Set the programme.
- ☐ Do **not** select **↵ (Pre-wash)** -> page 13.
- ☐ Add all the detergent, according to the manufacturer's instructions, to **compartment II** of the detergent drawer.

Heavily soiled laundry

- ☐ Set the programme.
- ☐ Select **↵ (Pre-wash)** -> page 13.
- ☐ Add 1/4 of the recommended amount of detergent to **compartment I** of the detergent drawer and 3/4 of the detergent to **compartment II**.

Measuring liquid detergent

Only use liquid detergent for the main wash cycle **with no prewash**.

To do this:

- ☐ Add the recommended amount of detergent to a liquid detergent measuring aid and place it in the drum.

or

- ☐ After folding down the **liquid detergent insert**, pour the detergent into **compartment II** of the detergent drawer.

 The scale on the **liquid detergent insert** helps to measure the correct dosage of liquid detergent.

 If **compartment II** is used for washing powder, the **liquid detergent insert** must be folded up.

Programmes

Programme selector

The programme selector is used to set the washing and drying programmes.



The time remaining until the end of the programme and the Beladungsmenge (Load) are shown on the display panel.

Washing programmes*

*depends on the model

Resistentes/Algod. (Cottons/Coloureds)

Suitable for hard-wearing fabrics, heat-resistant fabrics made from cotton or linen.

- Coloureds up to 60 °C.
- Whites 60 °C to 90 °C.

Color eco/Cor eco (Cottons Eco)

Washing programme for the best possible washing result with minimum energy and water consumption.

Sintéticos (Easy Care)

Washing programme for less hard-wearing fabrics made from cotton, linen, synthetic fibres or blended fabrics. It is advisable to sort the laundry by colour.

Delicados (Delicates/Silk)

Gentle programme for delicate, washable fabrics, e.g. silk, satin, synthetics or blended fabrics (e.g. curtains). Gentle spinning between the rinse cycles and reduced final spin speed.

Lana/Lã (Woollens)

Wool becomes matted when subjected to heat, moisture and movement. The woollens programme takes these qualities into account and finds a compromise between standing still and movement.

Suitable for hand- or machine-washable fabrics made from wool or a wool blend.

Rápido 15' (Rapid 15)

Short programme for easy-care, lightly soiled fabrics made from cotton, linen, synthetics or blends. Suitable for freshening up items or for washing new items before wearing for the first time. The programme takes 15 minutes.

Mix Rápido (Mix)

For mixed items of laundry made of various hard-wearing and easy-care fabrics.

Sport (Sport Wash)

For washing functional clothing and sports wear made from microfibre and synthetics. Reduced creasing and additional rinse cycle.

Washing programmes*

* depends on the model

Clinic Wash

For washing fabrics with increased hygiene requirements or those that will be used by allergy sufferers. The temperature remains constant during the washing process. More intensive rinsing with increased water level. For hard-wearing and easy-care fabrics made from cotton or linen.

Nocturno (Night Wash)

Particularly quiet wash programme with a reduced final spin.

Sleep mode. Once the programme has finished, the display goes out, but can be reactivated by pressing any button.

Drying programmes

Secar Normal (Intensive Dry)

Intensive drying for  (robust fabrics), at 90°C.

Secar Suave (Gentle Dry)

Gentle drying for  (easy-care fabrics), 60°C.

Special programmes

limp. pelusas/fios (Fluff removal cycle)

This programme is designed to clean the drying cycle of any fluff deposits. After 10 drying cycles, the washer-dryer uses the symbol  (**Fluff removal cycle**) in the display panel to show that this programme should be run. The electronic cycle counter is then automatically reset. The  (**Fluff removal cycle**) symbol goes out after the programme starts.

To run the **limp. pelusas/fios** (Fluff removal cycle), proceed as follows:

- ☐ Make sure that the drum is completely empty and close the door.
- ☐ Turn the programme selector to  (Fluff removal cycle).
- ☐ Press the  (**Start/Pause**) button.



The **limp. pelusas/fios** (Fluff removal cycle) programme can also be run at any time without prompting by the appliance.

+ **Rinse + Spin:**

An additional rinse cycle with a final spin. If the laundry is to be removed dripping wet, set the Spin speed to  (**Rinse hold**) before Programme start → page 13.

+ **Empty + Spin:**

Drain the rinsing water following a programme with  (Rinse hold) → page 13.

- ☐ Turn the programme selector to  +  **Empty + Spin.**
- ☐ Set the spin speed to  (**Rinse hold**).
- ☐ Press the  (**Start/Pause**) button.

or

Drain **and** spin at the desired spin speed:

- ☐ Turn the programme selector to  +  **Empty + Spin.**
- ☐ Press the  button repeatedly until the desired spin speed is set.
- ☐ Press the  (**Start/Pause**) button.

Washing and drying options

°C (Temperature) button

The temperature can be adjusted individually for each programme. To adjust it, press the **°C (Temperature) button** repeatedly until the required temperature is displayed.

⦿ (Spin speed) button

The spin speed can be individually adjusted for each programme. To set the spin speed, press the **⦿ (Spin) button** repeatedly until the required spin speed is displayed.

Rinse hold

☒ (Rinse hold) deactivates the spin function. The laundry remains in the rinsing water.

Unbalanced load detection system

The automatic unbalanced load detection system ensures that the laundry is evenly distributed using several initial spins. If the laundry is extremely unevenly distributed, the speed of the final spin is reduced or the spin cycle is not performed for safety reasons.

Menu button

The set programmes can be individually adjusted.

To choose the required option:

- ☐ Press the **menu (Option)** button repeatedly until the required option is selected (indicator lamp flashes).
- ☐ Press the **selec. (Set)** button to switch the option on/off (indicator lamp lights up/does not light up).

Selec. button



If you press and hold the **menu (Option) →** button, all the options scroll through.

Options (symbols on the display panel)

 Pre-wash	Prewash at 35 °C. Suitable for heavily soiled laundry.
 Intensive	Prolonged washing time. Suitable for particularly heavily soiled laundry with dried-on stains. Cannot be combined with Flexi Time .
 Easy-iron	Special spin sequence with subsequent fluffing. Gentle final spin at reduced speed. Slightly increased residual moisture in the laundry. Reduces creasing and laundry is easier to iron.
 Water Plus	Increased water level and additional rinse cycle. For regions with very soft water or for further improving the rinsing result. Any detergent residues are removed.
 Flexi Time	Sets the washing time. <i>normal-medium-short</i> .
 Signal	Activates or deactivates the audible signal.

🕒 Finished in button

You can postpone Programme start before it begins. Using the Remaining time, you can determine when the selected programme is to end. The remaining time can be set in one-hour increments, up to a maximum of 24 hours. Press the **🕒 (Finished in)** button repeatedly until the required number of hours is displayed.

Then press the **▶⏸ (Start/Pause)** button, the programme will start after a delay according to the set Remaining time. The required time to the end of the programme is shown on the display panel.

Secar (Drying) button

The drying programmes → page 12 can be individually adapted by selecting the drying options.

- Press the **Secar** (Drying) button repeatedly until the required drying option is shown on the display panel.
- To deactivate, press the **Secar** (Drying) button repeatedly until **00:00** is shown on the display.

Drying options (symbols on the display panel)

Time-controlled drying	The drying time can be set to between 2:40 and 0:00 by repeatedly pressing the Secar (Drying) button.
Iron-damp	The residual moisture in the washing is increased. Enables easier ironing.
Cupboard-dry	The laundry is dry and ready to put away.
Extra-dry	The laundry is dried intensively. Suitable for laundry that is hard to dry.

Start/Pause button

Press the (**Start/Pause**) button to start the selected programme.



The (Remaining time) is shown on the display panel.
The (programme start) symbol is lit.

Programme progress

The programme progress is shown on the display panel:

- Pre-wash
- Main wash
- Rinse
- Final spin
- Drying

Changing the programme

To change the programme:

- ☐ Select a new programme.
- ☐ Press the (**Start/Pause**) button.



The new programme starts.

Pausing the programme

Press and hold the (**Start/Pause**) button while the programme is in progress until **PAUSE** appears on the display panel. **PAUSE** and the Remaining time appear alternately on the display while the programme is paused.

Press the (**Start/Pause**) button to continue with the programme.

Cancelling the programme

Press and hold button (**Start/Pause**) until **00:00** is displayed.

For washing programmes at high temperatures:

- Cooling down laundry: choose + (**Rinse + Spin**).
- Press the (**Start/Pause**) button.

For programmes at low temperatures:

- choose + (**Empty + Spin**).
- Select the (**Start/Pause**) button.



If you cancel the Drying programme, the laundry may still be very hot.

Washing and drying

Washing only

- ☐ Turn the programme selector to the desired programme, e.g. **Resistentes/Algod. (Cottons/Coloureds) 60°C**.
 - The display panel alternately shows ⌚ (Remaining time) and the recommended load in **kg**. The ⓘ symbol flashes.
- ☐ If necessary, adjust the temperature and the spin speed and select any options for your individualised programme, → page 13.
 - The **Secar** (Drying) function must not be activated.
- ☐ Load the laundry → page 8.
 - Observe the maximum load, Programme table → page 28.
- ☐ Press the ⏻ (Start/Pause) button.
 - ⌚ (**Remaining time**) is shown on the display panel. The ⓘ (**Programme start**) symbol lights up.
 - The washing programme starts.



Drying only

- ☐ Turn the programme selector to the desired drying programme.
 - The display panel alternately shows ⌚ (Remaining time) and the recommended load in **kg**.
- ☐ Press the **Secar** (Drying) button to set the **drying options** → page 14
- ☐ If you do not make a selection, the 🗄️ (**Cupboard-dry**) option is set.
- ☐ Load the laundry → page 8.
 - Observe the maximum load, Programme table → page 28.
- ☐ Press the ⏻ (Start/Pause) button.
 - ⌚ (**Remaining time**) is shown on the display panel and the **Secar** (Drying) and ⓘ (**Programme start**) symbols light up.
 - The drying programme starts.



Washing and drying

- Successive washing and drying.
 - ☐ Set the programme selector to the desired programme, e.g. **Resistentes/Algod. (Cottons/Coloureds) 60°C**.
 - ⌚ (**Remaining time**) and the recommended load in **kg** are shown alternately on the display panel. The ⓘ symbol flashes.
 - ☐ If necessary, adjust the temperature and the spin speed and select any options for your individualised programme, → page 13.
 - ☐ Press the **Secar** (Drying) button to set the **drying options** → page 14
 - ☐ Load the laundry → page 8.
 - Observe the maximum load in **kg**, Programme table → page 28.
 - ☐ Press the ⏻ (Start/Pause) button.
- ☐ The drying programme that is carried out is automatically determined by the washing programme, see the Programme table → page 28.



End of the programme

The washing and drying programmes are ended automatically. **End** appears on the display panel.

- ☐ Turn the programme selector to **Stop**.
- ☐ Remove the washing from the drum.
- ☐ Leave the door open to allow the inside of the washer-dryer to dry out.
- ☐ Turn off the tap (not necessary on models with Aqua-Stop).

Rinse hold

If the spin function was deactivated at the start of the wash cycle,  (no final spin = laundry remains in last rinsing water), the washing programme is automatically stopped after the final rinse. The display panel shows **5:00** alternating with **0:00**.

In order to Drain the rinsing water and, if required, spin the laundry:

- ☐ Press the  (**Spin**) button repeatedly until the required spin speed is set. The water is Drained and the washer-dryer spins the laundry. The programme is completed when **0:00** appears in the display field.



The maximum spin speed depends on the selected wash programme.

If you do **not** wish to spin the laundry:

- ☐ Press the  (**Spin**) button (remaining time for Draining is displayed). The water is Drained, but the washer-dryer does not spin the laundry. The programme is complete when **End** appears on the display panel.
- ☐ Set the programme selector to **Stop**.
- ☐ Remove the laundry.
- ☐ Leave the door open to allow the inside of the washer-dryer to dry out.
- ☐ Turn off the tap (not necessary on models with Aqua-Stop).

Childproof lock

For preventing the washer-dryer functions that you have set from being changed inadvertently.

Activate/Deactivate: Press the **menu** and **selec.** buttons at the same time to activate or deactivate the Childproof lock. When the childproof lock is activated,  lights up on the display.

Cleaning and care

Safety information

Risk of electric shock

You must disconnect the appliance from the mains first. Never clean the washer-dryer with a water jet.



Risk of explosion.

Never clean the washer-dryer with solvents.

Risk of scalding

Hot washing water must be cooled before Draining.

Housing and control panel

Wipe with a soft, damp cloth.

Remove detergent and cleaning agent residue immediately.

Do not clean with a jet of water.

Drum

Remove any foreign bodies from the drum and rubber seals.


Descaling the drum:

- Only use a proprietary brand of descaler with corrosion inhibitor for washing machines for descaling the washer-dryer.
- Observe the manufacturer's instructions regarding use and dosage.
- After descaling and removing rust from the drum, run the  +  (**Rinse + Spin**) programme several times to remove any remaining acid.

If any remaining metal objects (e.g. coins, paper clips, needles, nails) have caused rust spots:

- Use chlorine-free cleaning agents; observe the manufacturer's instructions. Never use steel wool.



Detergent drawer



If there are detergent or care product residues:

- ☐ Pull out the detergent drawer as far as the stop.
- ☐ Press on the blue zone labelled **PUSH** and take out the detergent drawer.
- ☐ Clean the detergent drawer guide.
- ☐ Remove the blue fabric softener compartment insert.
- ☐ Clean the detergent drawer and fabric softener compartment insert under running water.
- ☐ Insert the fabric softener compartment insert.
- ☐ Insert the detergent drawer.

Drain pump




- ☐ Set the programme selector to **Stop**.
- ☐ Use a screwdriver to release the lock pins.
- ☐ Tip the kick panel and pull upwards to remove.

Draining the water




- ☐ Take the Drain hose out of the retainer.
- ☐ Remove the plug from the Drain hose and release the washing water.
 - The container for the Drained water may have to be emptied several times.
 - When no more water runs out, replace the plug.
- ☐ Place the Drain hose into the retainer.

Cleaning the Drain pump



- ☐ Unscrew the pump cover.
 - Clean the pump housing and remove any foreign objects.
 - Make sure that the impeller can turn freely.
- ☐ Replace the pump cover and screw firmly in place.
- ☐ Place the kick panel in the 4 clip-in slots and secure to the housing using the lock pins.

Filter in the water supply hose



If no water runs into the washer-dryer, or only an insufficient amount, you must first reduce the water pressure in the supply hose:

- ☐ Turn off the tap.  +  (**Empty + Spin**).
- ☐ Press the  (**Start/Pause**) button.
- ☐ Allow the programme to run for approximately 40 seconds.
- ☐ Set the programme selector to **Stop**.
- ☐ Unplug the mains plug from the socket.
- ☐ Unscrew the water supply hose from the tap.
- ☐ Clean the filter with a small brush.
- ☐ Reconnect the hose.
- ☐ Turn on the tap.
- ☐ Check whether water comes out of the end of the hose.
- ☐ If water is escaping, check that the filter is correctly seated.

Descaling the washer-dryer

This should not be necessary if the correct detergent dosage has been used. If it is necessary, however, proceed according to the descaling agent manufacturer's instructions. Suitable descalers can be obtained via our website or from our after-sales service → page 22.

What to do if...



Risk of electric shock.

Repairs must only be carried out by customer services or authorised technicians.

If repairs are needed, or if you cannot rectify a fault yourself with the help of the following table:

- ☐ Set the programme selector to **Stop**.
- ☐ Disconnect the washer-dryer from the power supply.
- ☐ Turn off the tap.
- ☐ Call the after-sales service → page 22.

Fault code	
	The door is not properly closed. Close the door.
	The water control system has been activated. Disconnect the appliance from the mains, turn off the tap and advise the after-sales service.
	Water is not entering the appliance. See the fault Water is not flowing in .
	The water is not Drained. See the fault Water is not Drained .
 	Maximum or minimum drying load not taken into account. HI/End or LO/End flash alternately in the display. See information for the Drying result not satisfactory fault.


Other fault codes are only for use by the after-sales service. Make a note of the fault code to inform the after-sales service.

Fault	Possible cause	Remedial action
Programme does not start.	The ▷ (Start/Pause) button has not been pressed.	Press the ▷ (Start /Pause) button.
	A delayed start time has been selected.	Washer dryer starts on completion of the delay period. Change the “finished in time” if necessary → page 13.
	Power cut. The delayed start time that was selected has been cleared.	Reselect the delayed start time or start the programme immediately. Press the ▷ (Start /Pause) button.
	The door is not properly closed.	Close the door.
	Plug not inserted properly into socket.	Insert plug correctly.
The maximum spin speed cannot be set.	The maximum spin speed depends on the programme selected.	Change programme as required.
The water is not Drained.	Drain hose is twisted.	Fit the Drain hose correctly.
	Detergent pump is blocked.	Clean the Drain pump → page 18.
Detergent residues in the detergent drawer.	Damp or lumpy detergent.	Clean and dry the detergent drawer – > page 17.
		Use the measuring aid for liquid detergent.

Water is not flowing in.	The mains plug is not correctly plugged in.	Plug in the mains plug correctly.
	The door is not properly closed.	Close the door.
	The tap is not turned on.	Turn on the tap.
	The filter in the water supply hose is blocked.	Clean the filter in the water supply hose → page 18.
	The water supply hose is pinched or kinked.	Check the water inlet hose.
Intense vibrations during spinning.	The washer-dryer is not correctly levelled.	Level the washer-dryer → page 25.
	The transport safety bolts have not been removed.	Remove the transport safety bolts → page 24.
Washer-dryer fills with water and continuously Drains it away.	Drain hose fitted too low.	Fit the Drain hose correctly → page 26.
No water can be seen in the drum.	Not a fault.	During certain programmes the water level is below the visible range.
Water leaks from the bottom of the appliance.	Supply hose screw connection is leaking.	Tighten the screw connection.
	Drain hose is leaking.	Have the Drain hose replaced by the after-sales service.
Foam escapes from detergent drawer.	Too much detergent has been used.	Only use detergent which is correct for textiles, and suitable for use in automatic washing machines. Make sure that you use the correct dosage.
Several attempts to start spinning.	Not a fault. The unbalanced load detection system attempts to redistribute an unbalanced load by starting to spin several times.	Always wash large and small items together.
Washing is not spun properly.	Large items of laundry are not evenly distributed in the drum. The spin speed is automatically reduced for safety reasons.	Always wash large and small items together.
Washing results not satisfactory.	Uncleaned areas worse than expected.	Select a suitable programme, e.g. a programme with Pre-wash. Pretreat stains if necessary.
	Too little or incorrect detergent used.	Use the correct dosage of a suitable detergent, in accordance with the manufacturer's instructions.
	Maximum load exceeded.	Select the load appropriate for the programme.
Detergent residues on the washing.	Some phosphate-free detergents contain water-insoluble residues which appear on washing as light specks.	Rinse the laundry again or change to using liquid detergent. Brush the laundry after it has dried.
Grey residues on the washing.	Soiling caused by ointments, grease or oil.	Wash the laundry using the maximum detergent dosage and the maximum permissible temperature – see the care label.

Programme terminated unexpectedly.	The ▷⏏ (Start/Pause) button was selected accidentally.	Press the button again to restart the programme.
Spinning during drying	No fault	"Thermo spin", which is for energy-efficient drying, starts after a drying time of approx. 10 minutes.
Drying result not satisfactory.	The laundry clings to the sides of the drum after being spun.	Loosen up the laundry by hand; start the drying programme → page 15.
	Closed tap	Turn on the tap.
	Selected drying time too short.	Select the drying time according to the Load.
	Maximum or minimum load not taken into account → page 28	Once the programme has ended: adjust the load quantity, select a suitable drying programme and restart.
The fabric softener is not completely flushed in or too much water remains in the compartment ☼.	The fabric softener compartment insert is not correctly attached or is blocked.	If necessary, clean the fabric softener compartment insert and fit it correctly in compartment ☼ → page 17.
The laundry is not dried.	The tap is turned off.	Turn on the tap.
	The load is too large.	Reduce the load size.
	The drying time is too short.	Select a suitable drying time.
No display on the display panel.	Power cut.	The programme continues when power is restored. If you wish to remove the laundry during a power cut, you must first Drain out the water → page 18. Check whether: – the plug is plugged into the socket correctly. – the circuit breaker (fuse) has tripped; if it has, call the after-sales service → page 22.
The door cannot be opened.	☒ (Rinse hold) has been selected.	Select the programme ☒ + ⏏ (Empty + Spin) and press the ▷⏏ (Start/Pause) button.
	The programme is running or the door is locked for safety reasons.	Wait until ☒ appears on the display panel.
	Power cut.	Unlock the door mechanically.

Emergency release



- To release the door mechanically in the event of a power cut:
- ☐ turn the programme selector to **Stop** and unplug the mains plug from the socket.
 - ☐ open the base panel and Drain out the water → page 18.
 - ☐ pull the emergency release downwards and open the door at the same time.
- Before opening the door, make sure that there is no water or hot detergent solution in the washer dryer.

Under no circumstances open the door with the emergency release while the drum is still turning.

If you cannot correct a fault yourself (switching on/off) or a repair is required:

- Turn the programme selector to **Stop** and unplug the mains plug from the socket.
- Turn off the tap and call the after-sales service → page 22.

After-sales service

Before you call the after-sales service, please check whether you can correct the fault yourself → page 19.

You will be charged if a technician is called out, even during the warranty period.

You can find information about your nearest after-sales service here or in the After-sales service directory (depending on the model).

Please give the after-sales service the product number (E-Nr.) and production number (FD) of the appliance.

E-Nr. _____ FD _____

Enter the number of your appliance here.

You can find this information on the rating plate in the frame of the door.

Please help us to avoid unnecessary call-outs by quoting the product and production numbers. This will also save you the associated additional costs.

You can rely on the competence of the manufacturer. Please contact us. This way, you can ensure the repair is carried out by trained service technicians who are equipped with genuine spare parts.

Installation instructions

Safety information



The washer-dryer is very heavy. Take care when lifting it.

Do not operate the washer-dryer if it has any visible damage. If you are in any doubt, please consult our after-sales service or your retailer.

Do not install the washer-dryer outdoors or in areas exposed to frost. Frozen hoses can crack or burst. As a result, the washer-dryer could be damaged.

Do not stand the washer-dryer upside down or on its side. Do not lift the washer-dryer by protruding parts (e.g. door).

Do not place the washer-dryer behind a door or a sliding door which could prevent the washer-dryer door from being opened. This will prevent children from locking themselves in and putting their lives in danger.

Remove the transport braces and cross connectors and store in a safe place.

In addition to the instructions provided in this document, special regulations from the relevant water and electric utility companies may apply.

If in doubt, have a technician connect the appliance.

Included with the appliance



Number	Description
4	Covers for openings left after removing the transport bolts.
1	Spanner
1	24-40 mm dia. hose clamp for connection to a siphon.
1	Door template
2	Door hinges with screws

On the back of the washer-dryer:

- Water Drain hose
- Water supply hose
- Mains cable with plug
- Instruction manual and booklet containing after-sales service addresses

Moisture may remain in the drum following the final inspection which every washer-dryer undergoes before leaving the factory.

Removing the transport safety bolts

	
Unscrew all four screws using the spanner supplied.	Remove all 4 transport safety bolts completely and take the mains cable out of the retainers.
 Insert the protective covers.	– Before using the appliance for the first time, you must make sure that all 4 transport safety bolts have been removed and kept safe for any subsequent transport. – If you need to transport the appliance at a later date, always refit the transport safety bolts to prevent damage to the washer-dryer.


Positioning and levelling

- Appliance stability is essential to ensure that the washer-dryer does not “creep” during spin cycles.
- The installation area must be firm, clean and level.
- Parquet floors and soft floor coverings, e.g. carpets or foam-backed floor coverings, are unsuitable.

Positioning

Slide sheets make it easier to slide the washing machine into the installation recess.


- Can be ordered from the after-sales service, spare part no. 66 1827.
- Moisten the slide sheets with a mixture of water and washing-up liquid before sliding the washer-dryer into place. Do not use grease and/or oil.



Levelling

Intense noise, vibrations and “wandering” may be the result of incorrect levelling.

- All four appliance feet must stand firmly on the ground.
- The washer-dryer must not wobble.
- Check the levelness of the washer-dryer with a spirit level and correct if necessary.
- The washer-dryer must not rest against the sides of the installation recess.
- The lock nuts of the front appliance feet must be screwed tightly against the housing.




Hose and cable lengths

Left-hand connection

or

Right-hand connection



Dimensions in mm

Dimensions

Width x depth x height

595 mm x 584 mm x 820 mm

Weight

85 kg

Water connection

To prevent leaks or water damage, you must observe the instructions in this section.

If in doubt, have a technician connect the appliance.

The water supply and Drain hoses can be routed to the left or right, depending on installation conditions.

Do not use a used inlet hose. Only use the inlet hose supplied or one which was purchased from an authorised specialist retailer.

Water supply

Do not allow the water supply hose to be:

- kinked or squashed,
- altered or cut (strength no longer guaranteed).

Note the water pressure in the mains supply:

The water pressure should be between 50-900 kPa (0.5-9 bar) (at least 8 litres of water flow out per minute when the tap is turned on).

If the water pressure is higher, a pressure reducing valve must be fitted.

Connect the cold-water supply hose (**blue** union nut) to the cold water tap with $\frac{3}{4}$ " pipe ($\frac{3}{4}$ " = 26,4 mm) thread.

Only tighten plastic screw connections by hand.


Do not remove the filter from the supply hose.

After connecting the water supply hose:

- Turn the tap on fully.
- Check the connections for leaks.

Water Drainage

Drainage into a siphon



- Do not kink the Drain hose or pull it lengthways.
- Height difference between the installation surface and the Drain: max. 90 cm, min. 50 cm.

Secure the connection with the 24-40 mm hose clamp (included with the appliance).

Electrical connection

The washer-dryer must only be connected to an alternating current supply via a properly installed earthed socket.

If a residual current circuit breaker is used, only use a type which displays this symbol: .

Only this symbol guarantees compliance with the currently applicable regulations.

The mains voltage must match the voltage specifications on the washer-dryer (rating plate).

The connected load and fuse required are shown on the rating plate.

Make sure that:

- the mains plug fits the socket.
- the cable cross-section is adequate.
- the earthing system is properly installed.
- the appliance is not standing on the mains cable.
- the mains plug is accessible at all times.

Changes to the mains cable may only be carried out by an electrician.

Do not use multiple plugs/adapters or extension cables.

Do not plug in or unplug the mains plug with wet hands.

Only pull the mains plug out by the plug itself.

Fitting the door hinges to the washer-dryer

Once the washer-dryer has been installed in a kitchen unit, it can be concealed with a door. If you wish to do this, you must fit the hinges supplied to the washer-dryer.




Table of programmes

Observe the information on care labels, fabric type and load quantity. In order to select the most suitable programme for the laundry, observe the information on the labels that are attached to most items.

			Type of laundry     	Options*					Drying	
Programmes*	°C	max.								
Resistentes/Algod. (Cottons/Coloureds)	cold-30-40-60-75-90	6 kg/ 4 kg**	Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen.	✓	✓	✓	✓	✓	✓	–
Color eco/Cor eco (Coloureds eco)	cold-30-40-60			✓	–	✓	✓	✓	✓	–
Clinic Wash 	cold-30-40-60		Hard-wearing fabrics made of cotton or linen.	✓	✓	✓	✓	✓	✓	–
Nocturno (Night Wash)	cold-30-40-60	3 kg**	Quiet wash programme with a reduced final spin.	✓	✓	✓	✓	–	–	✓
Sintéticos (Easy-Care)	cold-30-40-60	3 kg	Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics.	✓	✓	–	✓	✓	–	✓
Mix Rápido (Quick/Mix)	cold-30-40		Fabrics made from cotton or easy-care fabrics.	✓	✓	✓	✓	✓	–	✓
Delicados (Delicate/Silk)	cold-30-40	2 kg	For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains).	–	✓	–	✓	–	–	–
Lana/Lã  (Woollens)	cold-30-40		Suitable for hand or machine-washable fabrics made from wool or a wool blend.	–	–	–	–	–	–	–
Rápido 15' (Rapid 15)	cold-30		Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics.	–	–	–	–	–	–	–
Sport  (Sports Wash)	cold-30-40		Fabrics made from microfibre.	–	✓	–	✓	✓	–	–

*Programmes and options depend on the model

**Reduced load quantity for successive washing and drying programme

Consumption rates

Washing				
Programme	Load	Power***	Water***	Programme duration***
Resistentes/Algod. (Cottons/Coloureds) 40 °C	6 kg	0,8 kWh	60 l	1:52 h
Resistentes/Algod. (Cottons/Coloureds) 90 °C		2,1 kWh	65 l	2:22 h
Color eco/Cor eco (Cottons Eco) 60 °C**		1,02 kWh	45 l	2:10 h
Mix Rápido (Quick/Mix) 40 °C**	3 kg	0,45 kWh	40 l	0:49 h
Sintéticos (Easy-care) 40 °C		0,45 kWh	40 l	1:31 h
Delicados (Delicate/Silk) ❄ (cold)	2 kg	0,05 kWh	35 l	0:36 h
Delicados (Delicate/Silk) 30 °C		0,11 kWh	35 l	0:36 h
Lana/Lä (Woollens) ❄ (cold)		0,05 kWh	49 l	0:47 h
Lana/Lä (Woollens) 30 °C		0,20 kWh	49 l	0:47 h
Color eco/Cor eco (Cottons Eco) 60 °C secar normal 🌞 (2 cycles)*	6 kg/3 kg	4,81 kWh	79 l	6:03 h

*Programme setting for testing and energy labelling in accordance with EN50229, EU Directive 96/60/EC.

Programme setting for testing in accordance with valid standard EN60456. Note on comparative tests: For testing the test programmes, wash the specified load using the maximum spin speed. As a **short programme for coloureds, select the **Mix Rápido (Quick/Mix) 40 °C** programme with the maximum spin speed.

***The values may deviate from the indicated values depending on water pressure, water hardness and supply temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Drying*			
Programme	Load	Cupboard dry	Iron dry
Secar Normal 🌞 (Intensive Dry)	1,5 kg	90 min	60 min
	2 kg	90 min	60 min
	2,5 kg	100 min	90 min
	3 kg	110 min	100 min
	3,5 kg	130 min	110 min
	4 kg	150 min	130 min
Secar Suave ❄ (Gentle Dry)	1,5 kg	90 min	60 min
	2 kg	100 min	60 min
	2,5 kg	110 min	90 min
	3 kg	130 min	100 min

*)The values may diverge from those specified depending on over and undervoltage, fabric type, composition of the laundry to be dried, residual moisture in the fabric and the amount of the load.

Index

C	D	E
Care information	Descaling 18	Easy-iron
-Drying8	Detergent 9	-Display panel6
-Washing7	-Liquid detergent insert . 9, 10	Electrical connection27
Care product9	Liquid detergent insert 10	Emergency release21
Childproof lock16	Detergent drawer	End of the programme 16
-Display panel6	-Cleaning 17	Environment
Cleaning	-Description 9	-Energy consumption8
-Control panel	Dimensions 25	-Protection4
17	Display	Extra-dry
-Detergent drawer17	-Fault message 19	-Display panel6
-Drain pump18	Door 5, 16	-Drying options 14
-Drum17	Door hinges 27	
-Housing17	Drain 12	
-Water supply hose18	Drain pump	F
Connection fittings26	-Cleaning 18	Fabric softener compartment
Conservation information4	Draining the water 18	insert 17
Consumption rates29	Draining water 16	Fault message 19
Control panel6	Drum	Faults 19
-Cleaning17	-Cleaning 17	Filter
Cupboard-dry6	Drying 14, 15	-Water supply hose 18
-Drying options14	-Button 6	Final spin
	-Display panel 6	-Display panel6
	-Options 14	Finished in
	-Synthetics 8	-Button6
	-Woollens 8	Finished in button6
	Drying programmes 12	First wash7
		Fluff-removal cycle
		-Display panel6
		Foam3

H	P	T
Hazard information3	Positioning	Temperature
Hazard warnings	-Washer-dryer 24	-Button6
-Detergent9	Power 29	-Indicator lamp6
Housing	Pre-wash	Time-controlled drying
-Cleaning17	-Display panel 6	-Drying options 14
	-Programme 13	Transport safety bolts24
I	Programme	
Included with the appliance23	-Cancelling 14	U
Installation surface23	-Changing 14	Unbalanced load detection
Iron-damp	-Pausing 14	system 13
-Drying options14	-Progress 14	Use 15
	Programme selector 6, 11	
L	Programme start	W
Laundry	-Display panel 6	Washer-dryer
-Creasing8		Positioning and levelling ...24
-Loading8	R	Washing 15
-Preparing for drying8	Remedial action 19	and drying 15
-Preparing for washing8	Rinse	-Washing options 13
-Sorting for drying8	-Display panel 6	Washing options
-Sorting for washing7	Rinse hold 13, 16	-Indicator lamp6
Levelling25	Rubber 3	Washing programmes 11, 12
-Washer-dryer24		Washing temperature 13
Liquid detergent insert9	S	Water29
	Safety information ... 3, 17, 19, 23	Water drainage26
M	Set 13	Water supply26
Main wash	Set (Selec.)	Water supply hose
-Display panel6	-Tecla 6	-Cleaning 18
	Signal	WEEE4
O	-Indicator lamp 6	
Option13	Solvents 3	
Options6	Special programmes 12	
-Button6	Spin 12	
-Drying options14	Spin speed 13	
-Washing options13	-Button 6	
	-Indicator lamp 6	
	Start/Pause 6	

Robert Bosch Hausgeräte GmbH
Carl-Wery-Straße 34
81739 München
DEUTSCHLAND

wkd28540ee
10.2011
9000493030