


ICE/BEVERAGE DISPENSER

MODELS: ENDURO-150 (SIX VALVE)

INSTALLATION MANUAL



Release Date: February 24, 2004

Publication Number: 91971RINS

Revision Date: August 3, 2010

Revision: E

Visit the IMI Cornelius web site at www.cornelius.com for all your Literature needs.

The products, technical information, and instructions contained in this manual are subject to change without notice. These instructions are not intended to cover all details or variations of the equipment, nor to provide for every possible contingency in the installation, operation or maintenance of this equipment. This manual assumes that the person(s) working on the equipment have been trained and are skilled in working with electrical, plumbing, pneumatic, and mechanical equipment. It is assumed that appropriate safety precautions are taken and that all local safety and construction requirements are being met, in addition to the information contained in this manual.

This Product is warranted only as provided in Cornelius' Commercial Warrant applicable to this Product and is subject to all of the restrictions and limitations contained in the Commercial Warranty.

Cornelius will not be responsible for any repair, replacement or other service required by or loss or damage resulting from any of the following occurrences, including but not limited to, (1) other than normal and proper use and normal service conditions with respect to the Product, (2) improper voltage, (3) inadequate wiring, (4) abuse, (5) accident, (6) alteration, (7) misuse, (8) neglect, (9) unauthorized repair or the failure to utilize suitably qualified and trained persons to perform service and/or repair of the Product, (10) improper cleaning, (11) failure to follow installation, operating, cleaning or maintenance instructions, (12) use of "non-authorized" parts (i.e., parts that are not 100% compatible with the Product) which use voids the entire warranty, (13) Product parts in contact with water or the product dispensed which are adversely impacted by changes in liquid scale or chemical composition.

Contact Information:

To inquire about current revisions of this and other documentation or for assistance with any Cornelius product contact:

www.cornelius.com

800-238-3600

Trademarks and Copyrights:

This document contains proprietary information and it may not be reproduced in any way without permission from Cornelius.

Printed in U.S.A.



TABLE OF CONTENTS

Safety Instructions 1

Read And Follow All Safety Instructions	1
Safety Overview	1
Recognition.	1
Different Types Of Alerts.	1
Safety Tips	1
Qualified Service Personnel	1
Safety Precautions	2
Shipping And Storage	2
Co2 (Carbon Dioxide) Warning.	2
Mounting In Or On A Counter	2

Description.	3
-----------------------------	----------

Installation Instructions	4
--	----------

Installation	4
Adjust Water -to-syrup Ratio.	5

Gate Restrictor Plate	6
--	----------

Adjustment.	6
----------------------------	----------

Plumbing Diagram (Bc Models).	9
--	----------

Plumbing Diagram (B Models).	10
---	-----------

Troubleshooting.	11
---------------------------------	-----------

Blown Fuse Or Circuit Breaker.	11
Gate Does Not Open. Agitator Does Not Turn	11
Gate Does Not Open.or Is Sluggish Agitator Turns	11
Ice Dispenses Continuously	11
Slushy Ice. Water In Hopper	11
Beverages Do Not Dispense	11
Beverages Too Sweet	11
Beverage Not Sweet Enough	11
Beverages Not Cold (Unitswith Built-in Cold Plate)	11
Flavor Syrups Do Not Dispense	12
Flavor Dispenses For More Than 1 Sec	12
Flavor Dispenses More Than .5 Oz	12

LIST OF FIGURES

Figure 1. Adjust Water-to-syrup Ratio	5
Figure 2. Gate Restrictor Plate	6
Figure 3. Mounting Template	7
Figure 4. Drip Tray Drain Assembly	8
Figure 5. Plumbing Diagram (Bc Model)	9
Figure 6. Plumbing Diagram (B Model)	10
Figure 7. Wiring Diagram (120 V Unit)	13
Figure 8. Wiring Schematic (120v Unit)	14
Figure 9. Wiring Diagram (220--240 V Unit)	15
Figure 10. Wiring Schematic (220--240 V Unit)	16

SAFETY INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

Safety Overview

- Read and follow **ALL SAFETY INSTRUCTIONS** in this manual and any warning/caution labels on the unit (decals, labels or laminated cards).
- Read and understand ALL applicable OSHA (Occupational Safety and Health Administration) safety regulations before operating this unit.

Recognition

<i>Recognize Safety Alerts</i>
 <i>This is the safety alert symbol. When you see it in this manual or on the unit, be alert to the potential of personal injury or damage to the unit.</i>

DIFFERENT TYPES OF ALERTS



DANGER:

Indicates an immediate hazardous situation which if not avoided **WILL** result in serious injury, death or equipment damage.



WARNING:

Indicates a potentially hazardous situation which, if not avoided, **COULD** result in serious injury, death, or equipment damage.



CAUTION:

Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury or equipment damage.

SAFETY TIPS

- Carefully read and follow all safety messages in this manual and safety signs on the unit.
- Keep safety signs in good condition and replace missing or damaged items.
- Learn how to operate the unit and how to use the controls properly.
- **Do not** let anyone operate the unit without proper training. This appliance is **not** intended for use by very young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
- Keep your unit in proper working condition and do not allow unauthorized modifications to the unit.

QUALIFIED SERVICE PERSONNEL



WARNING:

Only trained and certified electrical, plumbing and refrigeration technicians should service this unit. **ALL WIRING AND PLUMBING MUST CONFORM TO NATIONAL AND LOCAL CODES. FAILURE TO COMPLY COULD RESULT IN SERIOUS INJURY, DEATH OR EQUIPMENT DAMAGE.**

SAFETY PRECAUTIONS

This unit has been specifically designed to provide protection against personal injury. To ensure continued protection observe the following:



WARNING:

Disconnect power to the unit before servicing following all lock out/tag out procedures established by the user. Verify all of the power is off to the unit before any work is performed.

Failure to disconnect the power could result in serious injury, death or equipment damage.



CAUTION:

Always be sure to keep area around the unit clean and free of clutter. Failure to keep this area clean may result in injury or equipment damage.

SHIPPING AND STORAGE



CAUTION:

Before shipping, storing, or relocating the unit, the unit must be sanitized and all sanitizing solution must be drained from the system. A freezing ambient environment will cause residual sanitizing solution or water remaining inside the unit to freeze resulting in damage to internal components.

CO₂ (CARBON DIOXIDE) WARNING



DANGER:

CO₂ displaces oxygen. Strict attention **MUST** be observed in the prevention of CO₂ gas leaks in the entire CO₂ and soft drink system. If a CO₂ gas leak is suspected, particularly in a small area, **IMMEDIATELY** ventilate the contaminated area before attempting to repair the leak. Personnel exposed to high concentrations of CO₂ gas experience tremors which are followed rapidly by loss of consciousness and **DEATH**.

MOUNTING IN OR ON A COUNTER



WARNING:

When installing the unit in or on a counter top, the counter must be able to support a weight in excess of **390 lbs.** to insure adequate support for the unit. **FAILURE TO COMPLY COULD RESULT IN SERIOUS INJURY, DEATH OR EQUIPMENT DAMAGE.**

NOTE: Many units incorporate the use of additional equipment such as icemakers. When any addition equipment is used you must check with the equipment manufacturer to determine the additional weight the counter will need to support to ensure a safe installation.



DESCRIPTION

The “DURAFLEX” series of ice dispensers solves your ice and beverage service needs in a sanitary, space saving, economical way. Designed to be manually filled with ice from any remote ice-making source, these dispensers will dispense cubes (up to 1-1/4 inch in size), cubelets, and hard-chipped or cracked ice. In addition, several flavors of post-mix beverages. “BC” units include beverage faucets and a cold plate and are designed to be supplied direct from syrup tanks and carbonator, with no additional cooling required.

IMPORTANT: For dispensing compressed-style ice, Kit # 02394 Ice Diverter must be installed on the dispenser (see INSTALLATION INSTRUCTIONS on page 2)

SPECIFICATIONS

Model Descriptions:	ED150 - B (Beverage Faucet) BC (Beverage Faucets and Coldplate) Z (No Drip)
Ice Storage:	150 lbs
Maximum number of Faucets Available	6
Built-in Cold Plate:	On BC models only
Electrical:	120/1/60, 3 Amps Total Unit Draw 220-240/1/50/60 Hz, 2.5 Amps Total Unit Draw
Dimensions ED 150:	22” Wide X 30” Deep X 35-5/8” High (With Lid Removed 34” High) Z model = 22” Wide X 23-1/16” Deep X 35-5/8” High.

INSTALLATION INSTRUCTIONS

INSTALLATION

WARNING: **TO THE INSTALLER.**

It is the responsibility of the Installer to ensure that the water supply to the dispensing equipment is provided with protection against backflow by an air gap as defined in ANSI/ASME A112. 1.2-1979; or an approved vacuum breaker or other such method as proved effective by test and must comply with all federal state and local codes, failure to comply could result in serious injury, death or damage to the equipment.

Water pipe connections and fixtures directly connected to a potable water supply shall be sized, installed, and maintained according to Federal, State, and Local laws.

1. Locate the dispenser indoors on a level counter top.

A. LEG OPTION

Unpack the four (4) legs and install them into the threaded holes provided in the bottom of the unit. The installer must provide flexibility in the product and utility supply to permit shifting the position of the dispenser sufficiently to clean the area beneath it.

B. COUNTER MOUNTING

The ice dispenser must be sealed to the counter. The template drawing (see Figure 3) indicates where openings can be cut in the counter. Locate the desired position for the dispenser, then mark the outline dimensions on the counter using the template drawings. Cut openings in counter.

Apply a continuous bead of *NSF International* (NSF) silastic sealant (Dow 732 or equal) approximately 1/4--inch inside of the unit outline dimensions and around all openings. Then, position the unit on the counter within the outline dimensions. All excess sealant must be wiped away immediately.

2. The beverage tubes, drain tube and power cord are routed through the large opening in the bottom of the unit. See the MOUNTING TEMPLATE (Figure 1) for locating the required clearance opening in the counter for these utility lines.
3. DRIP TRAY DRAIN ASSEMBLY (see Figure 2): Route the drain tube to an open drain with the end of the tube above the "flood" level of the drain. Use the tubing, fittings, clamps, and insulation provided with the Dispenser to assemble the drain. The completed drain line *must* pitch continuously downward and contain no "traps" or improper drainage will result.
4. Connect the beverage system product tubes as indicated in the Beverage System Schematic. This work should be done by a qualified service person.

NOTE: See applicable Plumbing Diagram (see Figure 5 or 6) or Decal on the lower front panel of the unit for the location of syrup and water connections.

5. Clean the hopper interior (see CLEANING INSTRUCTIONS in Owner's Manual).

WARNING:

This unit must be grounded to avoid possible fatal electrical shock or serious injury to the operator. The unit power cord is equipped with a three prong plug. If a Three-hole (grounded) outlet is not available and use an approved method to ground the unit. Failure to comply could result in serious injury, death or damage to the equipment.

6. Connect the power cord to a 120 volt, 60 cycle, 3-wire grounded receptacle. For 220--240 volt International units, a 3--wire power cord is provided. An adapter plug for the particular country will need to be provided by the Installer.

7. Maximum and minimum ambient temperature rating for correct operation is 40 to 105 F
8. The dispenser is not designed for a wash down environment and must not be placed in an area where a water jet could be used.
9. The unit has to be placed in a horizontal position.
10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

ADJUST WATER -TO-SYRUP RATIO




Figure 1

1. Remove valve cover and install syrup separator over the diffuser and through the nozzle.
2. Hold cup under valve and dispense beverage for a specific time (i.e. 2 seconds)
3. NOTE: water and syrup must be cold before checking ratios.
4. Adjust carbonated water flow to the desired rate (such as 90 to 100 ml (3 to 3.75 oz.) per second). Turn the flow adjuster 1/4 of a turn at a time and recheck the flow. To increase reading turn clockwise.
5. Set a syrup flow adjuster to get the desired ratio.
6. Test the valve and adjust until a consistent ratio is delivered three consecutive times.
7. Repeat procedure for other valves.

GATE RESTRICTOR PLATE

**CAUTION:**

Disconnect power to dispenser before installing, removing or adjusting restrictor. See safety section of this manual.




Figure 2. GATE RESTRICTOR PLATE

ADJUSTMENT

This plate may be adjusted as shown to reduce or increase the dispensing rate of ice, especially desirable when using glasses or other containers with small openings. Adjustment can be made by sliding up or down with nuts loosened, to obtain the desired amount of restriction.




Figure 3. Drip Tray Drain Assembly

PLUMBING DIAGRAM (BC MODLES)




Figure 4. Plumbing Diagram (BC Model)

PLUMBING DIAGRAM (B MODELS)




Figure 5. Plumbing Diagram (B Model)

TROUBLESHOOTING

IMPORTANT: Only qualified personnel should service internal components or electrical wiring.



WARNING:

If repairs are to be made to a product system, remove quick disconnects from the applicable product tank, then relieve the system pressure before proceeding. If repairs are to be made to the CO2 system, stop dispensing, shut off the CO2 supply, then relieve the system pressure before proceeding. If repairs are to be made to the refrigeration system, make sure electrical power is disconnected from the unit.

Should your unit fail to operate properly, check that there is power to the unit and that the hopper contains ice. If the unit does not dispense, check the following chart under the appropriate symptoms to aid in locating the defect.

Trouble	Probable Cause
BLOWN FUSE OR CIRCUIT BREAKER.	A. Short circuit in wiring. B. Defective gate solenoid. C. Defective agitator motor.
GATE DOES NOT OPEN. AGITATOR DOES NOT TURN.	A. No power. B. Bent depressor plate (does not actuate switch). C. Defective dispensing switch.
GATE DOES NOT OPEN OR IS SLUGGISH. AGITATOR TURNS.	A. Defective gate solenoid B. Excessive pressure against gate slide. C. Defective Rectifier.
ICE DISPENSES CONTINUOUSLY.	A. Stuck or bent depressor plate (does not release switch). B. Defective dispensing switch. C. Improper switch installation.
SLUSHY ICE. WATER IN HOPPER.	A. Blocked drain. B. Unit not level. C. Poor ice quality due to water quality or ice maker problems. D. Improper use of flaked ice.
BEVERAGES DO NOT DISPENSE.	A. No 24 volt power to faucets. B. No CO2 pressure.
BEVERAGES TOO SWEET.	A. Carbonator not working. B. No CO2 pressure in carbonator. C. Faucet brix requires adjusting.
BEVERAGE NOT SWEET ENOUGH	A. Empty syrup tank B. Faucet brix requires adjusting.
BEVERAGES NOT COLD (UNITS WITH BUILT-IN COLD PLATE).	A. Unit standing with no ice in hopper -- no ice in cold plate cabinet.



Trouble	Probable Cause
FLAVOR SYRUPS DO NOT DISPENSE	A. No 24 volt power to PC board. B. No CO2 pressure. C. Empty syrup tank. D. Kinked tubing. E. Clogged inner nozzle. F. Defective PC board. G. Defective harness from keypad. H. Defective Flow control. I. Defective solenoid harness. J. Defective keypad.
FLAVOR DISPENSES FOR MORE THAN 1 SEC	A. Dip switch settings on control board incorrect. B. PC board defective. C. Defective flow control.
FLAVOR DISPENSES MORE THAN .5 OZ	A. Dip switch settings on control board incorrect. B. Flow control incorrectly set. C. PC board defective. D. Defective flow control.

Contact your local syrup or beverage equipment distributor for additional information and troubleshooting of beverage system.

SERVICE INFORMATION

DANGER!

ELECTRIC SHOCK HAZARD. DISCONNECT POWER BEFORE SERVICING UNIT.

DISPENSE SWITCH

TO HINGE

GRN

Q.C. CONNECTOR

TO BEVERAGE FAUCET

OPTIONAL KEY SWITCH

ICE LEVEL SIGNAL OPTION

TO 24V TRANSFORMER

BLUE

WHT

BLK

YELLOW

OPTIONAL BEVERAGE TRANSFORMER

FLAVOR SOLENOIDS

1 2 3 4

DOOR SENSING (WATER-S)

PCB BOARD

OPTIONAL LIGHT STARTER

OPTIONAL BALLAST

OPTIONAL SOCKET

OPTIONAL SOCKET

MOTOR START CAPACITOR

OPTIONAL SOCKET

AGITATION

J10-2

J9-1

J9-2

J9-3

J9-4

J9-5

J9-6

J9-7

J9-8

J9-9

J9-10

J9-11

J9-12

J9-13

J9-14

J9-15

J9-16

J9-17

J9-18

J9-19

J9-20

J9-21

J9-22

J9-23

J9-24

J9-25

J9-26

J9-27

J9-28

J9-29

J9-30

J9-31

J9-32

J9-33

J9-34

J9-35

J9-36

J9-37

J9-38

J9-39

J9-40

J9-41

J9-42

J9-43

J9-44

J9-45

J9-46

J9-47

J9-48

J9-49

J9-50

J9-51

J9-52

J9-53

J9-54

J9-55

J9-56

J9-57

J9-58

J9-59

J9-60

J9-61

J9-62

J9-63

J9-64

J9-65

J9-66

J9-67

J9-68

J9-69

J9-70

J9-71

J9-72

J9-73

J9-74

J9-75

J9-76

J9-77

J9-78

J9-79

J9-80

J9-81

J9-82

J9-83

J9-84

J9-85

J9-86

J9-87

J9-88

J9-89

J9-90

J9-91

J9-92

J9-93

J9-94

J9-95

J9-96

J9-97

J9-98

J9-99

J9-100

J9-101

J9-102

J9-103

J9-104

J9-105

J9-106

J9-107

J9-108

J9-109

J9-110

J9-111

J9-112

J9-113

J9-114

J9-115

J9-116

J9-117

J9-118

J9-119

J9-120

J9-121

J9-122

J9-123

J9-124

J9-125

J9-126

J9-127

J9-128

J9-129

J9-130

J9-131

J9-132

J9-133

J9-134

J9-135

J9-136

J9-137

J9-138

J9-139

J9-140

J9-141

J9-142

J9-143

J9-144

J9-145

J9-146

J9-147

J9-148

J9-149

J9-150

J9-151

J9-152

J9-153

J9-154

J9-155

J9-156

J9-157

J9-158

J9-159

J9-160

J9-161

J9-162

J9-163

J9-164

J9-165

J9-166

J9-167

J9-168

J9-169

J9-170

J9-171

J9-172

J9-173

J9-174

J9-175

J9-176

J9-177

J9-178

J9-179

J9-180

J9-181

J9-182

J9-183

J9-184

J9-185

J9-186

J9-187

J9-188

J9-189

J9-190

J9-191

J9-192

J9-193

J9-194

J9-195

J9-196

J9-197

J9-198

J9-199

J9-200

J9-201

J9-202

J9-203

J9-204

J9-205

J9-206

J9-207

J9-208

J9-209

J9-210

J9-211

J9-212

J9-213

J9-214

J9-215

J9-216

J9-217

J9-218

J9-219

J9-220

J9-221

J9-222

J9-223

J9-224

J9-225

J9-226

J9-227

J9-228

J9-229

J9-230

J9-231

J9-232

J9-233

J9-234

J9-235

J9-236

J9-237

J9-238

J9-239

J9-240

J9-241

J9-242

J9-243

J9-244

J9-245

J9-246

J9-247

J9-248

J9-249

J9-250

J9-251

J9-252

J9-253

J9-254

J9-255

J9-256

J9-257

J9-258

J9-259

J9-260

J9-261

J9-262

J9-263

J9-264

J9-265

J9-266

J9-267

J9-268

J9-269

J9-270

J9-271

J9-272

J9-273

J9-274

J9-275

J9-276

J9-277

J9-278

J9-279

J9-280

J9-281

J9-282

J9-283

J9-284

J9-285

J9-286

J9-287

J9-288

J9-289

J9-290

J9-291

J9-292

J9-293

J9-294

J9-295

J9-296

J9-297

J9-298

J9-299

J9-300

J9-301

J9-302

J9-303

J9-304

J9-305

J9-306

J9-307

J9-308

J9-309

J9-310

J9-311

J9-312

J9-313

J9-314

J9-315

J9-316

J9-317

J9-318

J9-319

J9-320

J9-321

J9-322

J9-323

J9-324

J9-325

J9-326

J9-327

J9-328

J9-329

J9-330

J9-331

J9-332

J9-333

J9-334

J9-335

J9-336

J9-337

J9-338

J9-339

J9-340

J9-341

J9-342

J9-343

J9-344

J9-345

J9-346

J9-347

J

© 2004-2010, IMI Cornelius Inc.

WIRING SCHEMATIC (120 V UNIT)




Figure 7. Wiring Schematic (120V Unit)

Wiring Diagram Details:

- Power Input:** L (Blue), N (Yellow), G (Green/White) enter through a **POWER FILTER**. A **DISPENSE SWITCH** is connected to the ground line.
- Control Section:** Includes a **PCB BOARD** with connections for **FLAVOR SOLENOIDS** (1-4), **FLAVOR OPTION** (WHT, BLK, BRN), **KEYPAD** (1-4), **ESD**, and **WATER-H**. A **TO BEVERAGES FAUCET** line is also shown.
- Motor Section:** Features a **MOTOR CAPACITOR** connected to the motor's start and run windings. The motor is labeled **ACW MOTOR**.
- Solenoid Section:** Includes a **SOLENOID** connected to a **TO SOLID POUNDING PLATE** line.
- Optional Components:**
 - OPTIONAL TRANSFORMER:** Connected to the power lines.
 - OPTIONAL BALLAST:** Connected to the power lines.
 - OPTIONAL LIGHT SOCKET:** Connected to the power lines.
 - OPTIONAL LIGHT STARTER:** Connected to the power lines.
 - OPTIONAL KEY SWITCH:** Connected to the power lines.
 - ICE LEVEL SIGNAL OPTION:** Connected to the power lines.
 - TO 24V TRANSFORMER:** Connected to the power lines.
- Wiring Labels:** Various color-coded wires are labeled throughout the diagram, including BLK, BRN, WHT, BLU, YEL, GRN, GRN/YEL, LT BLU, and PINK.

© 2004-2010, IMI Cornelius Inc.

WIRING SCHEMATIC (220-240 V UNIT)




Figure 9. Wiring Schematic (220--240 V Unit)

IMI Cornelius Inc.
www.cornelius.com