

# LAN Control Utility User Manual

## Contents

1. Introduction .....	2
1.1. Preparing to use network features .....	2
1.2. Functions and features .....	2
1.3. Operation environment .....	2
2. Setup .....	4
2.1. Installation of “ProjectorView Global+” .....	4
2.2. When deleting “ProjectorView Global+” (Uninstallation) .....	5
3. Main screen .....	6
3.1. System settings .....	8
4. Projector registration .....	9
4.1. Connection.....	9
4.2. Registration of projector to “ProjectorView Global+” .....	11
4.3. When changing the projector IP settings .....	13
4.4. When changing projector settings.....	14
4.5. When deleting projector registration .....	14
5. Operation of projector .....	15
5.1. Operation of projector by remote controller .....	15
5.2. Confirmation of projector status.....	16
6. Schedule setting.....	17
6.1. Creation of projector group .....	17
6.2. When changing schedule setting .....	18
6.3. When deleting group.....	19
7. E-mail setting.....	20
7.1. Connection with E-mail server.....	20
7.2. E-mail setting .....	20
7.3. Sending test E-mail.....	20
8. Web UI.....	21
8.1. Main functions .....	21
8.2. Starting Web UI.....	21
9. Visual PA2 (Visual PA2 enabled projectors only).....	25
9.1. Starting Visual PA2 .....	25
9.2. Saving messages entered and settings specified in Visual PA2.....	26
9.3. Loading saved data in Visual PA2 .....	26
9.4. Deleting data from Visual PA2 .....	26
9.5. Configuring the Schedule function of Visual PA2.....	27
10. ProjectorView (ProjectorView enabled projectors only).....	28
10.1. Starting ProjectorView .....	28
11. Telnet setup (Telnet enabled projectors only) .....	29
11.1. Displaying the Telnet setting screen.....	29
12. Others.....	30
12.1. Troubleshooting .....	30
12.2. Supported projectors.....	30

# 1. Introduction

---

## 1.1. Preparing to use network features

This projector is equipped with the network function.

Before using the network function, perform the following 2 preparation steps.

- Installing the ProjectorView Global+
- Configuring the projector IP address, network password, and network certification settings

The projector IP address, network password, and network certification settings can be configured in the projector menu. For more information, see the section describing network settings provided in the projector's User Manual.

### <Note>

- It is recommended that you assign an IP address of the projector to the fixed IP address and set DHCP Function to Off.
- Set the IP addresses, subnet masks, and default gateways of the projectors and PC correctly. For details, contact your network administrator.
- Be sure to make a note of the IP addresses and default gateways you set. If you forget the setting values, you may not be able to detect the projectors again.

## 1.2. Functions and features

### ProjectorView Global+

- 200 units of projectors can be remote-controlled at the maximum.
- Settings such as the IP address of the projector can be configured.
- You can register multiple projectors in a group and control them collectively.
- Various conditions of connected projectors can be monitored.
- Schedule of the power supply ON/OFF can be set every group.
- Schedule of the power supply ON/OFF can be set every day.
- When the communication with the projector monitored by the theft detector is disrupted, warning E-mail is issued to the designated address.
- Message can be displayed on the screen of the operating projector. (Visual PA2 enabled projectors only)
- The projector is capable of reading aloud on-screen messages. (Text Speech enabled projectors only)

### Web UI

- Each projector can be controlled and monitored separately using a Web browser.
- When an error or warning occurs with the projector, you can check its details.

## 1.3. Operation environment

- Supported OS  
Windows XP, Windows Vista and Windows 7 (Operation of the projector isn't guaranteed in a 64-bit version of any operating system.)
- CPU  
Higher than the minimum specifications for the above operating systems to work
- Memory  
More than the minimum specifications for the above operating systems to work
- Free HDD space  
32 MB or more (recommended)
- Web browser (When using Web UI)  
Internet Explorer Ver. 8.0 and Ver. 9.0 (recommended)  
(To use this function, install Adobe Flash Player on your computer. Download Adobe Flash Player from the website of Adobe Systems Incorporated.)

## **1. Introduction**

---

Microsoft® and Windows® are the registered trademark or trademark of Microsoft Corporation in the United States and other countries.

(The official name of Windows is Microsoft Windows Operating System.)

Adobe, Flash, and Adobe Flash Player are trademarks or registered trademarks of Adobe Systems Incorporated.

Crestron and RoomView are registered trademarks of Crestron Electronics, Inc.

Other company names and product names described in this document are the registered trademark or trademark of the respective holders.

Furthermore, “®” mark and “TM” mark are omitted in this document.

- Windows XP is referred to as Microsoft Windows XP Home Edition/Professional.
- Windows Vista is referred to as Microsoft Windows Vista Home Basic/Home Premium/Business/Enterprise/Ultimate.
- Windows 7 is referred to as Microsoft Windows 7 Home Basic/Home Premium/Professional/Enterprise/Ultimate.

## 2. Setup


### 2.1. Installation of “ProjectorView Global+”

Before starting installation, be sure to read “ReadMe.txt” contained in the CD-ROM.

Copy “ProjectorView Global+v3\_2.msi” contained in the Tools folder of CD-ROM to the hard disk of your personal computer.

**(1) Double click “ProjectorView Global+v3\_2.msi”, and start up the installer of “ProjectorView Global+”.**


**(2) The setup window is displayed. Click [Next].**



**(3) Select the folder to be installed, and click [Next].**


**<Note>**

- When installing “ProjectorView Global+” to Windows Vista or Windows 7, do not change the installation destination folder.




**(4) Click [Next].**

- Installation is started.



## 2. Setup

(5) When the installation has been completed, click [Close].



### 2.2. When deleting “ProjectorView Global+” (Uninstallation)

<Note>

- When uninstalling “ProjectorView Global+”, “ProjectorView Global+” should be ended in advance. If the application continues operating, uninstallation can not be performed normally.


(1) Double click “ProjectorView Global+v3\_2.msi”, and start up the installer of “ProjectorView Global+”.



(2) Select “Remove ProjectorView Global+”, and click [Finish].


- The uninstallation is started.

(3) When the uninstallation has been completed, click [Close].



- Logs and setting files are not automatically deleted. Delete them manually.

## 3. Main screen



### ① Menu bar

#### Configuration

You can specify the following settings:

- Add New Group: You can create a new group.
- Edit Schedule Setting: You can edit schedule settings set for existing groups.
- Search Projector: Automatically searches available projectors.
- Assign IP: You can configure IP settings of the projector.
- Edit Projector Setting: You can edit projector settings.
- Edit E-mail Setting: You can configure E-mail settings used for this application.
- Search Projector Setting: You can specify a search range for communication with the projector via a router.
- System Configuration: You can configure system settings of this application.

#### Help

The version information is displayed.

### ② Tool bar

#### ProjectorView

You can control each projector separately using a Web browser. (ProjectorView enabled projectors only.) In case of an error in the projector, the details of the error are displayed. For details, see page 28.

#### Telnet

You can make various settings using Telnet. (Telnet enabled projectors only.) You can set the password, ProjectorView display language, LAN control, and PJLink certification. For details, see page 29.

#### Visual PA2

You can display a line of any text on the projector screen (Visual PA2 enabled projectors only). For details, see page 25.

#### Remote Controller

Remote Controller window can be displayed to operate the projector. You can turn on/off the power, and select the input source.

#### Refresh Status

The current status of Power, Input Source, AV Mute, and Lamp Time 1/2 (Low) of the projectors being displayed in the projector list can be reacquired.

#### Select All

All projectors currently displayed on the projector list can be set to selected/non selected state.

#### Exit

You can exit "ProjectorView Global+". However, you cannot exit the application during the automatic projector search and the projector status refreshing. Even during the projector status acquisition, you can exit the application forcefully by clicking the  button at the upper right corner of the main screen. In this case, Windows warning message is displayed.

### 3. Main screen

---

- ③ **Group Name**                      Group of the projector can be selected. When you select “All”, all the registered projectors are displayed. Newly created group(s) are added to the list. When you select your choice of group, all projectors that belong to the selected group are displayed.
- ④ **Status tag**                        Property and status of the projector can be indicated. When clicking each tag button (except the MAC address), the list can be rearranged (sorted).
- ⑤ **Projector list display column**  
List of the projector which belongs to the selected group can be displayed. Status of the projector can also be displayed. The display color changes as follows depending on the condition of the projector:
- |                            |  |
|----------------------------|--|
| Black:                     | In normal condition  |
| Red:                       | In abnormal condition (→ Check the abnormal condition by ProjectorView. When the communication fails, see “12.1. Troubleshooting.”)                |
| Black (yellow background): | Warning about the lamp lifetime  |
| White (red background):    | The communication with the projector monitored by the theft detector has been disrupted. (→ Check the condition. There is a possibility of theft.) |
| Gray:                      | In communication inoperable condition  |
- ⑥ **Error Message**                    Error messages detected in communicating with the projector can be displayed.
- ⑦ **Operation status display column**  
Operation status of “ProjectorView Global+” can be indicated. Operation status during communication processing by remote-controlling and schedule can be indicated.


### 3. Main screen

---

#### 3.1. System settings

(1) Select “System Configuration” from “Configuration” of the menu bar on the main screen.

- “System Configuration” window is displayed. (Default settings are shown in the following example.)



---

Item	Description
Language	You can select the user interface language, Japanese or English.
Refresh Status Cycle	You can set the cycle to obtain the projector status. Select an integer value with no decimal part from 1 to 60 minutes.

---

(2) Change the settings as needed and click [Save].

- To update the settings you changed, it is necessary to restart “ProjectorView Global+”.

## 4. Projector registration

### 4.1. Connection

Connect the controller PC and the projector, which have installed “ProjectorView Global+”, to a commercially available LAN cable or wireless LAN adapter.


When connecting multiple projectors, use a commercially available hub.

- A LAN terminal or 802.11b/g/n wireless LAN adapter is required for the controller PC.
- Use a LAN cable compatible with Category 5 and 100BASE-T.  
Both crossover and straight-through cables can be used.  
(In the case of connection examples 5 and 6, see the instruction manual of the router.)


#### <Note>

- The LAN function may be unavailable depending on the standby mode setting of the projector. To enable the LAN function, change the setting referring to the User Manual of your projector.
- Some USB wireless adapters cannot be used for your projector depending on the specifications.

#### Connection example 1



#### Connection example 2




#### Connection example 3




## 4. Projector registration


### Connection example 4



### Connection example 5



### Connection example 6



## 4. Projector registration

---

### 4.2. Registration of projector to “ProjectorView Global+”

The procedures to register projectors vary among the foregoing connection examples.

- In connection examples 1 to 4 (where projectors are installed within the same local network), the projectors within such network are automatically detected and registered. For details, see procedure A below.
- In connection examples 5 and 6 (where projectors are installed via a router), specify the range of the projectors' IP addresses and then carry out automatic projector search within the range to register projectors. For details, see procedure B below.
- Up to 200 units of projectors can be registered at the maximum.
- Projectors that have just been registered by the automatic projector search aren't belonging to any group. When the projectors you registered aren't displayed on the projector list on the main screen, select “All” from the group select pull-down menu.

#### **Procedure A - For connection examples 1 to 4 (where projectors are installed within the same local network)**

##### **(1) Start up “ProjectorView Global+”.**

##### **(2) Select “Search Projector” from “Configuration” of the menu bar on the main screen.**

- The projectors connected to LAN are searched automatically.
- Some projectors may require you to enter the password when establishing projector connections for the first time. If the projector password is changed, you need to enter that new password.

##### **<Note>**

- Note that a different IP address may be assigned every time you start the projectors. If a connection cannot be established, execute “Search Projector”.
- If you change the IP address in the projector menu after the projectors have been detected, execute “Search Projector” again.
- If several projectors with the same IP address are registered, delete the ones which are not connected to the network from “Edit Projector Setting”.

## 4. Projector registration


### Procedure B - Connection examples 5 and 6 (where projectors are installed via a router)

To automatically detect projectors connected via a router, specify a range of IP addresses to search that particular IP address using “Search Projector Setting”.

(1) Start up “ProjectorView Global+”.

(2) Select “Search Projector Setting” from “Configuration” of the menu bar.

- “Search Projector Setting” window is displayed.



Item	Description
① Start IP Address	Specify the IP address that is the start of the search range. (You cannot specify an IP address that contains a range other than 1 to 254 for the first and last octets and a range other than 0 to 255 for the second and third octets.)
② End IP Address	Specify the last octet of the IP address that is the end of the search range. (You cannot specify a value that contains a number other than 1 to 254. In addition, you cannot specify a value that is smaller than the last octet of the search start IP address specified in step ①.)
③ Search Projector	The settings you made are saved and then the automatic projector search is performed.

(3) Specify the projector search range by IP address (① and ②).

- Up to 16 search ranges can be set. (Settings can be configured for each line of the search range.)

(4) To save the settings, click [Save]. To continue the projector search, click [Search Projector].

- When you click [Save], the search ranges you specify are saved and the “Search Projector Setting” window is closed.
- When you don’t want to save the search ranges, click [Cancel] to close the “Search Projector Setting” window.
- After saving the settings, by selecting “Configuration” on the menu bar and then selecting “Search Projector”, you can perform automatic projector search within the search ranges you saved.
- Some projectors may require you to enter the password when establishing projector connections for the first time. Authentication is automatically performed from the second time onwards unless projectors are deleted from the list.

## 4. Projector registration

### <Note>

- If you want to connect a projector via a router after automatically detecting it, you need to specify a search range of IP addresses that includes the projector's IP address in advance.
- Note that a different IP address may be assigned every time you start the projectors. If a connection cannot be established, specify the projector search range and execute "Search Projector" again.
- If you change the IP address in the projector menu after the projectors have been detected, execute "Search Projector" again.
- If several projectors with the same IP address are registered, delete the ones which are not connected to the network from "Edit Projector Setting".


### 4.3. When changing the projector IP settings

You can change the projector IP settings.

**(1) Select the projector which you like to change from the projector list on the main screen.**

**(2) Select "Assign IP" from "Configuration" of the menu bar on the main screen.**

- "Assign IP" window is displayed.



**(3) To automatically assign an IP address, select [Auto] and then select DHCP. To manually assign an IP address, select [Manual] and enter values for IP Address, Subnet Mask, and Default Gateway.**

Item	Description
DHCP	Obtain an IP address via a DHCP server.
IP Address	Enter an IP address.
Subnet Mask	Enter the subnet mask.
Default Gateway	Enter the default gateway address.

### <Note>

- Even when you change the projector IP settings in the "Assign IP" window, settings of DHCP Function, Start IP Address, and End IP Address in the projector menu are not changed.
- An error dialog for theft detection may be displayed after the IP settings have been changed.


## 4. Projector registration

### 4.4. When changing projector settings

(1) Select the projector which you like to change from the projector list on the main screen.

(2) Select “Edit Projector Setting” from “Configuration” of the menu bar.

- “Edit Projector Setting” window is displayed.




(3) Set the Projector Name and its group and the theft detector.

Item	Description
Projector Name	Enter the projector name within 64 characters in one-byte alphanumeric symbol.
MAC Address	The MAC address is displayed. The displayed address cannot be changed.
IP Address	The IP address is displayed. The displayed address cannot be changed. When it is required to change the IP address, use [Assign IP].
Group Name	From the pull-down menu, select the group to which the projector is belonging. (A new group can be created by clicking [Add New Group]. → See “6.1. Creation of projector group”.)
Theft Check	Turn on or off the theft detector.

#### <Note>

In right-click menu also, the setting of the projector can be changed. (Multiple projectors can be selected.)

- Add to New Group : Addition to a newly created group
- Add to Existing Group : Change of the belonging group
- Theft Check Setting : Change of theft detector setting (ON/OFF)



### 4.5. When deleting projector registration

(1) Select the projector which you like to delete from the projector list on the main screen.

(2) Select “Edit Projector Setting” from “Configuration” of the menu bar.

- “Edit Projector Setting” window is displayed.

(3) Click [Delete].

- The selected projector is deleted.

# 5. Operation of projector

## 5.1. Operation of projector by remote controller


Group or single unit of projector can be operated.

**(1) Select the projector which you like to operate from the projector list on the main screen.**

- When selecting more than one projector simultaneously, select while pressing the Ctrl key.

**(2) Click [Remote Controller] of the tool bar on the main screen or when you like to operate a certain projector, double click the projector on the projector list on the main screen.**

- “Remote Controller” window is displayed.



**(3) Operate the projector by selecting each operating button on the window.**

Command	Button	Description
Power	Power ON	Turn on the power supply of the projector.
	Power OFF	Turn off the power supply of the projector.
Input Source	COMPUTER 1	Change the input signal to COMPUTER 1.
	COMPUTER 2	Change the input signal to COMPUTER 2.
	VIDEO	Change the input signal to VIDEO.
	S-VIDEO	Change the input signal to S-VIDEO.
	COMPONENT	Change the input signal to COMPONENT.
	DIGITAL 1 *1	Change the input signal to DIGITAL 1 *1.
	DIGITAL 2 *1	Change the input signal to DIGITAL 2 *1.
	DIGITAL 3 *1	Change the input signal to DIGITAL 3 *1.
	STORAGE 1	Change the input signal to PC Less Presentation.
	STORAGE 2	Change the input signal to USB Display.
NETWORK	Change the input signal to LAN Display.	
Exit		Close the Remote Controller window.

\*1 DIGITAL 1-3 are displayed with HDMI (HDMI 1/HDMI 2), DVI-D or SDI by a connected projector.


**<Note>**

- The next operation can not be performed until the previous operation has been completed.
- The operation can not be performed during re-obtaining (refreshing) the projector status.
- Available input sources vary depending on the type of projectors. You cannot select input sources that aren't supported by the projector.

## 5. Operation of projector

### 5.2. Confirmation of projector status

The status of the projector is displayed on the projector list on the main screen.



Item	Description
Check	Theft detector setting (ON/OFF)
No.	Projector list registration number
Projector Name	Projector name set in the application
MAC Address	MAC address of the projector
IP Address	IP address of the projector
Power	Power supply status of the projector (ON/OFF)
Input Source *1	Input signal of the projector (COMPUTER 1/COMPUTER 2/VIDEO/S-VIDEO/HDMI (HDMI1/HDMI2)/DVI-D/SDI/PC Less Presentation/USB Display/LAN Display/COMPONENT)
AV Mute	Mute status of the projector (ON/OFF)
Lamp 1/2 Time (Low)	Lamp illuminating time (HHHH:MM) In the case of the projector equipped with two lamps, illuminating time for the lamp 1 is displayed in the left side and illuminating time for the lamp 2 is displayed in the right side.
Group Name	The belonging group of projector

\*1 HDMI and DVI-D are displayed with DIGITAL 1 or DIGITAL 2 by a connected projector.

#### <Note>

- The default cycle of the automatic re-acquisition is 10 minutes. To change this cycle, see “3.1. System settings.”
- The status of Input Source and AV Mute will not be obtained under the following conditions:
  - when the projector is powered off
  - during warm-up or cool-down.
- When multiple projectors are connected, it may take time to acquire the status. During acquiring the status, the status bar at the lower part of the main screen becomes “Getting status...”, and it becomes “Done” when the acquisition has been completed.

## 6. Schedule setting

### 6.1. Creation of projector group


Multiple projectors can be controlled and batched by sorting groups.

Also, each group can set each time of the power supply ON/OFF every day.

Since the schedule of the power supply ON/OFF is performed by each group, the projector which you like to operate at the same schedule should be integrated into the same group.

When Power ON and Power OFF are enabled, their time settings are indicated on the schedule list.

**[Example]** When setting the schedule for the group “group 1” to turn the power supply ON at 8:00 on Monday, turning OFF at 18:00 on the same day, ON at 8:40 on Thursday, and OFF at 17:00 on Friday.



(1) Select “Add New Group” from “Configuration” of the menu bar.

- “Add New Group” window is displayed.

(2) Input the group name to be created in the “Group Name” column (within 16 characters in one-byte alphanumeric symbol).

(3) Select the day of the week to be set for the time of the power supply ON/OFF.

(4) Only when setting the time of the power supply ON, set the time in the “Power ON” column, and put a check mark in the “Enable” box.

(5) Only when setting the time of power supply OFF, set the time in the “Power OFF” column, and put a check mark in the “Enable” box.

(6) When there are more than one day of the week to be set for the power supply ON/OFF schedule, repeat the procedure (3) to (5).

(7) Click [Add].


## 6. Schedule setting

### <Note>

- The power supply ON and the power supply OFF can not be selected at the same time of the same day of the week.
- The Schedule Setting will be executed while “ProjectorView Global+” is in operation.
- Depending on usage conditions, such as when there are so many projectors that you need to control, the time to be executed by the power supply control may deviate from the setting time of the schedule.
- When utilizing the Network Time Protocol (NTP) function on the Internet, the schedule operation may not be executed because the setting time of the schedule jumps over.
- When the automatic time adjustment by summer time is valid, the schedule operation may not be executed because the time is automatically adjusted before and after switching over.


### 6.2. When changing schedule setting

(1) Select a group which you like to change from the Group select pull-down menu on the main screen.



(2) Select “Edit Schedule Setting” from “Configuration” of the menu bar.

- “Edit Schedule Setting” window is displayed.



(3) Change the contents which you like to correct, and click [Save].

- Corrected contents are reflected.

## **6. Schedule setting**

---

### **6.3. When deleting group**

**(1) Select the group which you like to delete from the Group select pull-down menu on the main screen.**

**(2) Select “Edit Schedule Setting” from “Configuration” of the menu bar.**

- “Edit Schedule Setting” window is displayed.

**(3) Click [Delete].**

- The selected group is deleted.

**<Note>**

- When deleting a group, the projector which has belonged to the relevant group will not belong to any group. Set a new group to belong again on “Edit Projector Setting” window.

# 7. E-mail setting

When the communication with the projector monitored by the theft detector is disrupted, a warning E-mail can be sent to the designated address, enabling to serve for early detection of the projector theft. The E-mail setting can not be set at every projector and every group. The same setting should be set for all projectors.

## 7.1. Connection with E-mail server

Connect the E-mail server to the network to which the controller PC and the projector are connected that “ProjectorView Global+” is operating.

## 7.2. E-mail setting


Designate the address of the E-mail server and the address of the destination to be sent.

**<Note>**

- As for the network environment, confirm to the network administrator.

**(1) Select “Edit E-mail Setting” from “Configuration” of the menu bar on the main screen.**

- “Edit E-mail Setting” window is displayed.



**(2) Input the setting item for the network environment, and click [Save].**

Item	Description
E-mail Server (SMTP)	Enter the IP address of the E-mail server (Example: 192.168.7.230), or input the server name (Example: mail.example.com).
Destination E-mail Address	Enter the destination E-mail address using up to 64 single-byte characters. (Up to 3 places can be designated at the maximum.)

## 7.3. Sending test E-mail

After completing the setting of the each item on the E-mail Setting window, a test E-mail can be sent to confirm whether the E-mail is correctly delivered to the destination. When clicking [Test E-mail] at the upper right on the Email Setting window, the test E-mail is issued. Confirm whether the E-mail is correctly delivered to the destination address.

**<Note>**

- The E-mail function will be executed while “ProjectorView Global+” is in operation.
- If the test E-mail is not correctly received, confirm the address of the E-mail server and the destination, and the connection status of the network. For details, make an inquiry to the network administrator.
- The E-mail may possibly not be delivered depending on the certification function of the E-mail server. For details, make an inquiry to the network administrator.
- When the communication with the projector monitored by the theft detector is disrupted, a theft check error dialog is displayed.

However, the projector list isn't updated at the same time because it takes some time to update the list.

## 8. Web UI

Web UI is a tool to control and monitor the projector using a Web browser.

### 8.1. Main functions

- Projector control (You can control the projector using the computer screen in the same way as using the remote control.)
- Projector status display (projector name, lamp mode, lamp operation time, error/warning, etc.)

### 8.2. Starting Web UI

(1) Enter the projector's IP address (e.g. <http://192.168.0.30>) in the address bar of the browser and then press the Enter key.




#### <Note>

- You can connect only one Web UI to one projector.

#### ■ Control screen

You can perform the following controls by clicking the buttons and tabs displayed on the screen.



- ① **Power:** Turns on or off the power.
- AV Mute:** Mutes the video and audio temporarily. Clicking this button again will disable the mute.
- Vol +/-:** Adjusts the audio volume.
- ② **Source List:** The source you click is displayed. To see hidden sources, click ▲ or ▼ to scroll the list.

## 8. Web UI

---

- ③ **Freeze:** Pauses the displayed video. Clicking this button again will resume the normal video display.
- Contrast:** Adjusts the contrast of the video.
- Brightness:** Adjusts the brightness of the video.
- Color:** Adjusts the color density of the video.
- Sharpness:** Adjusts the sharpness of the video.
- Magnify:** Magnifies some part of the image. Clicking the  button will zoom in the image without changing the projection size. Clicking the  button will zoom out the area that has been magnified by the  button. You can select the area to be magnified by pressing the , ,  or  button.
- , : Scroll the button bar to display hidden buttons.
- ④ **Menu:** Displays the Main Menu.
- Enter:** Acts in the same way as the ENTER button on the remote control.
- Auto Position:** Automatically optimizes the settings of the video signal supplied from the computer.
- , , , : Act in the same way as the , , , and  buttons on the remote control.
- ⑤ **Log Out:** Logs out from the control screen. (Available only when the User Password has been set.)
- Tools:** Displays the Web UI Tools screen where you can configure the settings of the currently connected projector.
- Info:** Displays the Web UI Info screen that shows the information of the currently connected projector.
- Help:** Displays the Help Desk screen. You can send/receive messages to/from the administrator who uses Crestron RoomView.

## 8. Web UI

### ■ Web UI Tools screen

When you click [Tools] on the control screen, the following screen will appear. You can configure the settings of the currently connected projector using this screen. You can go back to the control screen by clicking [Exit].

The screenshot shows the 'Web UI Tools' screen with a navigation bar at the top containing 'Tools', 'Info', and 'Help'. The main content area is divided into four sections, each highlighted with a red box and a numbered callout:

- ① Crestron Control:** Contains input fields for 'IP Address', 'IP ID', and 'Port', and a 'Send' button.
- ② Projector:** Contains input fields for 'Projector Name', 'Location', and 'Projector Model', and a 'Send' button. Below these are read-only fields for 'DHCP' (checked), 'IP Address' (169.254.202.189), 'Subnet Mask' (255.255.0.0), and 'Default Gateway' (169.254.202.189).
- ③ User Password:** Contains an 'Enabled' checkbox, 'New Password' and 'Confirm' input fields, and a 'Send' button.
- ④ Admin Password:** Contains an 'Enabled' checkbox, 'New Password' and 'Confirm' input fields, and a 'Send' button.

An 'Exit' button is located at the bottom center of the screen. The Crestron logo and 'Expansion Options' are visible at the bottom of the interface.

#### ① Crestron Control

You can configure the settings of Crestron controller.

#### ② Projector

You can configure the following settings of the projector.

**Projector Name:** You can give any name to the projector. (Up to 15 alphanumeric characters.)

**Location:** You can give any name to the location where the projector is installed. (Up to 32 alphanumeric characters.)

**Send:** Click this button to accept your settings.

The settings stored in the projector are displayed.

**Projector Model:** Shows the projector's model name.

**DHCP:** When the DHCP setting is On, the [Enabled] checkbox is selected.

**IP Address:** Shows the IP address.

**Subnet Mask:** Shows the subnet mask.

**Default Gateway:** Shows the default gateway.

#### ③ User Password

To require entry of the password to display the control screen on the computer, select the [Enabled] checkbox. When this checkbox is selected, you can configure the following settings.

**New Password:** Enter a password to display the control screen. (Up to 26 alphanumeric characters.)

**Confirm:** Enter the same password as that you entered in the [New Password] box. If the passwords don't coincide with each other, an error message appears.

**Send:** Click this button to accept your settings.

#### ④ Admin Password

To require entry of the password to display the Web UI Tools screen, select the [Enabled] checkbox. When this checkbox is selected, you can configure the following settings.

**New Password:** Enter a password to display the Tools screen. (Up to 26 alphanumeric characters.)


**Confirm:** Enter the same password as that you entered in the [New Password] box. If the passwords don't coincide with each other, an error message appears.

**Send:** Click this button to accept your settings.

## 8. Web UI

### ■ Web UI Info screen

When you click [Info] on the control screen, the following screen will appear. This screen shows the information and status of the currently connected projector. You can go back to the control screen by clicking [Exit].



#### ① Projector Information

The following information of the projector is displayed.

- Projector Name:** Shows the projector's name.
- Location:** Shows the name of the location where the projector is installed.
- Mac Address:** Shows the MAC address.
- Resolution:** Shows the resolution of the video signal being projected.
- Lamp Time:** Shows the lamp operation time as converted into that in the Low lamp mode.

#### <Note>

- When the projector's lamp mode is set to Standard, the lamp operation time shown on this screen may be longer than the actual lamp operation time.

**Projector Model:** Shows the projector's model name.

#### ② Projector Status

The following information on the projector's status is displayed.

- Power Status:** Shows the projector's power status.
- Input Source:** Shows the name of the source currently selected.
- Lamp Mode:** Shows the lamp mode currently selected.
- Error Status:** Shows the following information if an error occurs in the projector.

Message in the [Error Status] box	Error description
3: Fan Error	The fan has an error.
3: Lamp Strike Failure	The lamp has failed to illuminate.
1: Lamp replacement recommended	The lamp life has ended.
3: Lamp replacement required	The lamp life will end soon.
3: Projector Overheating	The projector is overheated.
2: Temperature Warning	The projector is about to be overheated.
3: Lamp Cover Opened	The lamp cover is open.
4: Abnormal State Detected	The projector has an error.

#### <Note>

- When the projector is in the normal status, the [Error Status] box is blank.

## 9. Visual PA2 (Visual PA2 enabled projectors only)

Visual PA2 is a feature to display messages on the projector screen.

It can be used for all active Visual PA2 enabled projectors.

Additionally, the projector is capable of reading aloud on-screen messages using the Text Speech function. Note that some projectors may not have this function. See your projector User Manual for more information.


Visual PA2 is not available when using the Telnet enabled projectors listed on page 30.

This feature operates by referencing the information displayed in the projector list. You need to click [Refresh Status] to update the list before using this feature.

### 9.1. Starting Visual PA2

(1) Click [Visual PA2] in the tool bar on the main screen.

- “Visual PA2” window is displayed.



Select to set Schedule On or Off. When you click Edit, the Visual PA2 Schedule window is displayed. (See page 27.)

(2) Specify Text, Frame, Location, and Text Speech, enter text, and then click [Send].

- Alphanumerical characters, space, and symbols including ! " # \$ % & ( ) + , - / : ; < = > ? @ [ ] can be used.

(3) Click [Stop] to stop displaying the message on the projector screen.

<Note>

- If you exit Visual PA2 while the message is being displayed on the projector screen, a communication error may occur, and an error window may appear. If this happens, restart Visual PA2 and click [Stop].

## 9. Visual PA2 (Visual PA2 enabled projectors only)


### 9.2. Saving messages entered and settings specified in Visual PA2

You can save messages entered in Textbox, as well as settings specified for Text, Frame, Location, and Text Speech.

These must be saved before you activate the Schedule function in the Visual PA2 window.

**(1) Enter text in Textbox, specify settings for Text, Frame, Location, and Text Speech, and then click [Save].**

- “Save Data” window is displayed.




**(2) Enter the Data name in Save Data name and click [Save].**

- Up to 20 data can be saved.

### 9.3. Loading saved data in Visual PA2

**(1) Click [Load].**

- “Load Data” window is displayed.



**(2) Select the data you want to load and click [Load].**

### 9.4. Deleting data from Visual PA2

**(1) Click [Load].**

- “Load Data” window is displayed.

**(2) Select the data you want to delete and click [Delete].**


## 9. Visual PA2 (Visual PA2 enabled projectors only)

### 9.5. Configuring the Schedule function of Visual PA2

By using the Visual PA2's Schedule function, your intended messages can be displayed on the screen at a set time.

#### (1) Click [Edit] in the Schedule area.

- "Visual PA2 Schedule" window is displayed. (The window below shows the example when the schedules have been entered in three rows.)



Item	Description
① Enable	Enables the Schedule function for a particular day or period in each row.
② Day	From the pull-down menu, selects the day or period during which the Schedule function is enabled. (You can select your choice from Sun, Mon, Tue, Wed, Thu, Fri, Sat, Mon-Fri, Mon-Sat, Sat-Sun, and Everyday.)
③ Turn-on Time	From the pull-down menu, sets the start time in the Schedule function.
④ Period	From the pull-down menu, sets time period during which a message is displayed.
⑤ Data Name	From the pull-down menu, selects the message to be displayed on the screen when the Schedule function is enabled. (More than one message should be saved in advance. See "9.2. Saving messages entered and settings specified in Visual PA2" on page 26.)
⑥ Clear	Clears all entries from the selected row.
⑦ Exit	Saves changes and closes the window.

#### (2) Configure settings (② through ⑤) and check/uncheck the checkboxes for ①.

- Up to ten schedules can be configured, using the four rows in the table. (You can configure a schedule for each row.)
- By default, when no schedule is entered, the table has only one row. A new row is automatically added when you enter the items for ②, ③, ④, and ⑤ in the first row. In this manner, up to ten rows are automatically added to the table.

#### (3) Click [Exit] to close the window.

##### <Note>

- Once a schedule has been configured, it is executed automatically even if the Visual PA2 window is not displayed.
- If you send messages manually from Visual PA2 when a schedule is being executed, these messages have higher priority over that schedule. In addition, when the settings of a schedule currently being executed are reconfigured, the Visual PA2 window will close automatically.
- More than one schedule cannot be configured at the same time on the same day.
- The Schedule Setting will be executed while "ProjectorView Global+" is in operation.
- Depending on usage conditions, such as when there are so many projectors to control, time lapses may occur between the start time of Visual PA2 and the start time of a schedule.
- When Network Time Protocol (NTP) is used to automatically synchronize with an Internet time server, the start time of a pre-configured schedule may not match the clock of the projector, and the schedule may not be executed.
- When the automatic time adjustment by summer time is valid, the schedule operation may not be executed because the time is automatically adjusted before and after switching over.

## 10. ProjectorView (ProjectorView enabled projectors only)

---

ProjectorView is a web-browser based remote control and monitoring tool for network projectors. ProjectorView is not available when using other than the projectors listed on page 30. For more information on ProjectorView, see the LAN Control Utility manual that comes with the projector.


### 10.1. Starting ProjectorView

**(1) Select the projector that you want to operate from the list of projectors on the main screen.**

- Start ProjectorView for one projector at a time. You cannot concurrently use ProjectorView for multiple projectors.

**(2) Click [ProjectorView] in the tool bar on the main screen.**

- The Web browser launches automatically. The password entry window is then displayed.



**<Note>**

- You can start ProjectorView by manually typing the projector IP address in your web browser's address bar.
- If you are using a proxy server, do not enable proxy settings when accessing the projector IP address.
- Up to three ProjectorView units can be used to control a single projector.

**(3) Enter the password and click [OK]. (The default password is "admin".)**

- "ProjectorView" main window is displayed.

**<Note>**

- The connection will turn off in five minutes after the password entry window is displayed. You cannot enter the password then. If this happens, restart the ProjectorView.

# 11. Telnet setup (Telnet enabled projectors only)

You can set the password, ProjectorView display language, LAN control, and PJLink certification by running Telnet on the projector screen.

Telnet is not available when using other than the projectors listed on page 30.

For more information on Telnet, see the LAN Control Utility manual that comes with the projector.

## <Note>

- By default, Telnet is disabled on Windows Vista or Windows 7. To enable Telnet, go to Control Panel and select [Programs and Features]. In the left column, select [Turn Windows features on or off] and then check the box next to telnet.


## 11.1. Displaying the Telnet setting screen

(1) Select the projector that you want to configure on Telnet from the list of projectors on the main screen.

- Run Telnet on one projector at a time. Multiple projectors cannot be set simultaneously.

(2) Click [Telnet] in the toolbar on the main screen.

- A command prompt starts.
- An error message appears if the selected projector is not Telnet enabled.




(3) Press the [Enter] key when the above screen appears.

## <Note>

- Press the [Enter] key within five seconds. If not, the connection is terminated and the [Enter] key is not recognized. If this happens, exit the command prompt and start it again.

(4) Setup menus appear.



# 12. Others

## 12.1. Troubleshooting

- **The projector can not be recognized.**

The projector may not be recognized automatically due to the setting of fire wall. In such case, the communication of "ProjectorView Global+" should be registered as an exception to the fire wall. For the setting of the fire wall, see the manual of the software that configures the fire wall.

- **Operation by the remote controller can not be properly performed.**

The operation may not be performed until the last operation has been completed. In such case, wait for a while and perform the operation again. In addition, confirm whether the network setting such as IP address is correct.

- **Application becomes "No reply".**

Since it may take time for processing of the automatic status acquisition, the application can not be operated during that time, and "No reply" may be displayed. Wait for a while until the processing has been ended.

- **Application cannot be operated sometimes.**

The application cannot be operated during the acquisition of the projector status. When the main power of the projector is off or projectors not actually connected are registered, the projector status acquisition may take longer time to complete because it waits until time out. In this case, you can reduce the acquisition time by deleting unnecessary registered projectors.

- **Projectors cannot be controlled. Projector status isn't displayed.**

Restart the application. If the problem persists, try "Network Initialization" in the projector menu. In that case, you need to make settings of the projector again, because they are reset to the default values.

## 12.2. Supported projectors

- "ProjectorView" is available in the following types of projectors.

XD2000U, XD1000U, WD2000, XL550U, XL650U, HL650U, WL639U, XL1550U, XL2550U, WL2650U, HL2750U, MH2850U, FL7000U, WL6700U, XL6600U, XL6500U, FL7000U(BL), FL7000LU, WL6700LU, XL6600LU, XL6500LU, HD8000, FL6900U, XD3200U, WD3300U, XD221U, XD221U-ST, XD2000U(K), WD2000(K), XL550U(K), XL650U(K), HL650U(K), WL639U(K), XL1550U(K), XL2550U(K), WL2650U(K), FL7000U(K), WL6700U(K), XL6600U(K), XL6500U(K), XD221U(K), XD250U, XD280U, XD250U-ST, XD600U, WD620U, FD630U, XD3200U, XD3500U, WD3300U, XD8000U, XD8100U, WD8200U, UD8350U, UD8400U, XD8000LU, XD8100LU, WD8200LU, UD8350LU, UD8400LU, XD250U(K), XD280U(K), XD250U-ST(K), XD600U(K), WD620U(K), FD630U(K), HC7800D, HC7800DW, FD730U

- "Telnet" is available in the following types of projectors.

XD2000U, XD1000U, WD2000, XL550U, XL650U, HL650U, WL639U, XL1550U, XL2550U, WL2650U, HL2750U, MH2850U, FL7000U, WL6700U, XL6600U, XL6500U, FL7000U(BL), FL7000LU, WL6700LU, XL6600LU, XL6500LU, HD8000, FL6900U, XD3200U, WD3300U, XD3500U, XD221U, XD221U-ST, XD2000U(K), WD2000(K), XL550U(K), XL650U(K), HL650U(K), WL639U(K), XL1550U(K), XL2550U(K), WL2650U(K), FL7000U(K), WL6700U(K), XL6600U(K), XL6500U(K), XD221U(K)