



OM-1591

169 258B

December 1999

---

**Processes**




Air Plasma Cutting  
and Gouging

---

**Description**

Air-Cooled Arc Plasma Cutting Torches

# ICE-50, ICE-70, ICE-100, ICE-70M, And ICE-100M



**OWNER'S MANUAL**



Visit our website at  
[www.MillerWelds.com](http://www.MillerWelds.com)

# From Miller to You

*Thank you and congratulations* on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.



Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite. We've

made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide which exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.

Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at [www.MillerWelds.com](http://www.MillerWelds.com) on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.

*Miller offers a Technical Manual which provides more detailed service and parts information for your unit. To obtain a Technical Manual, contact your local distributor. Your distributor can also supply you with Welding Process Manuals such as SMAW, GTAW, GMAW, and GMAW-P.*



# TABLE OF CONTENTS

<b>SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING</b> .....	<b>1</b>
1-1. Symbol Usage .....	1
1-2. Plasma Arc Cutting Hazards .....	1
1-3. Additional Symbols For Installation, Operation, And Maintenance .....	2
1-4. Principal Safety Standards .....	3
1-5. EMF Information .....	4
<b>SECTION 2 – SPECIFICATIONS</b> .....	<b>5</b>
2-1. Duty Cycle .....	6
<b>SECTION 3 – INSTALLATION</b> .....	<b>7</b>
3-1. Installing 50 Ampere Torch .....	7
3-2. Installing 70 Or 100 Ampere Torch .....	8
3-3. Remote Control Connections For Machine-Held Torches .....	9
<b>SECTION 4 – OPERATING THE TORCH</b> .....	<b>10</b>
<b>SECTION 5 – MAINTENANCE &amp; TROUBLESHOOTING</b> .....	<b>13</b>
5-1. Routine Maintenance .....	13
5-2. Checking/Replacing Retaining Cup, Tip, And Electrode .....	14
5-3. Troubleshooting .....	15
<b>SECTION 6 – PARTS LIST</b> .....	<b>16</b>



# SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

pom\_nd\_9/98

## 1-1. Symbol Usage



Means Warning! Watch Out! There are possible hazards with this procedure! The possible hazards are shown in the adjoining symbols.

▲ Marks a special safety message.

☞ Means "Note"; not safety related.




This group of symbols means Warning! Watch Out! possible ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

## 1-2. Plasma Arc Cutting Hazards

▲ The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-4. Read and follow all Safety Standards.

▲ Only qualified persons should install, operate, maintain, and repair this unit.

▲ During operation, keep everybody, especially children, away.



### CUTTING can cause fire or explosion.

Hot metal and sparks blow out from the cutting arc. The flying sparks and hot metal, hot workpiece, and hot equipment can cause fires and burns. Check and be sure the area is safe before doing any cutting.

- Protect yourself and others from flying sparks and hot metal.
- Do not cut where flying sparks can strike flammable material.
- Remove all flammables within 35 ft (10.7 m) of the cutting arc. If this is not possible, tightly cover them with approved covers.
- Be alert that sparks and hot materials from cutting can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that cutting on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not cut on closed containers such as tanks or drums.
- Connect work cable to the work as close to the cutting area as practical to prevent cutting current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
- Never cut containers with potentially flammable materials inside – they must be emptied and properly cleaned first.
- Do not cut in atmospheres containing explosive dust or vapors.
- Do not cut pressurized cylinders, pipes, or vessels.
- Do not cut containers that have held combustibles.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Do not locate unit on or over combustible surfaces.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any cutting.



### ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The torch and work circuit are electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. Plasma arc cutting requires

higher voltages than welding to start and maintain the arc (200 to 400 volts dc are common), but also uses torches designed with safety interlock systems which turn off the machine when the shield cup is loosened or if tip touches electrode inside the nozzle. Incorrectly installed or improperly grounded equipment is a hazard.


- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not touch torch parts if in contact with the work or ground.
- Turn off power before checking, cleaning, or changing torch parts.
- Disconnect input power before installing or servicing this equipment. Lockout/tagout input power according to OSHA CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet – always verify the supply ground.
- When making input connections, attach proper grounding conductor first.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Inspect and replace any worn or damaged torch cable leads.
- Do not wrap torch cable around your body.
- Ground the workpiece to a good electrical (earth) ground if required by codes.
- Use only well-maintained equipment. Repair or replace damaged parts at once.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Do not bypass or try to defeat the safety interlock systems.
- Use only torch(es) specified in Owner's Manual.
- Keep away from torch tip and pilot arc when trigger is pressed.
- Clamp work cable with good metal-to-metal contact to workpiece (not piece that will fall away) or worktable as near the cut as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.



### ELECTRIC SHOCK can kill.


**SIGNIFICANT DC VOLTAGE** exists on internal parts of inverter power sources AFTER the removal of input power.

- Turn Off unit, disconnect input power, check voltage on input capacitors, and be sure it is near zero (0) volts before touching any parts. Check capacitors according to instructions in Maintenance Section of Owner's Manual or Technical Manual before touching any parts.



### EXPLODING PARTS can injure.


- On inverter power sources, failed parts can explode or cause other parts to explode when power is applied. Always wear a face shield and long sleeves when servicing inverters.



### FLYING SPARKS can cause injury.

Sparks and hot metal blow out from the cutting arc. Chipping and grinding cause flying metal.

- Wear approved face shield or safety goggles with side shields.
- Wear proper body protection to protect skin.
- Wear flame-resistant ear plugs or ear muffs to prevent sparks from entering ears.




### ARC RAYS can burn eyes and skin.

Arc rays from the cutting process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin.

- Wear face protection (helmet or shield) with correct shade of filter to protect your face and eyes when cutting or watching. ANSI Z49.1 (see Safety Standards) suggests a No. 9 shade (with No. 8 as minimum) for all cutting currents less than 300 amperes. Z49.1 adds that lighter filter shades may be used when the arc is hidden by the workpiece. As this is normally the case with low current cutting, the shades suggested in Table 1 are provided for the operator's convenience.
- Wear approved safety glasses with side shields under your helmet or shield.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather and wool) and foot protection.

Table 1. Eye Protection For Plasma Arc Cutting

Current Level In Amperes	Minimum Shade Number	
Below 20		#4
20 – 40		#5
40 – 60		#6
60 – 80		#8



### NOISE can damage hearing.

Prolonged noise from some cutting applications can damage hearing if levels exceed limits specified by OSHA (see Safety Standards).

- Use approved ear plugs or ear muffs if noise level is high.
- Warn others nearby about noise hazard.




### FUMES AND GASES can be hazardous.

Cutting produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.


- If inside, ventilate the area and/or use exhaust at the arc to remove cutting fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instruction for metals to be cut, coatings, and cleaners.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Fumes from cutting and oxygen depletion can alter air quality causing injury or death. Be sure the breathing air is safe.
- Do not cut in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not cut on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the cutting area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes when cut.
- Do not cut containers with toxic or reactive materials inside or containers that have held toxic or reactive materials – they must be emptied and properly cleaned first.



### PLASMA ARC can cause injury.

The heat from the plasma arc can cause serious burns. The force of the arc adds greatly to the burn hazard. The intensely hot and powerful arc can quickly cut through gloves and tissue.

- Keep away from the torch tip.
- Do not grip material near the cutting path.
- The pilot arc can cause burns – keep away from torch tip when trigger is pressed.
- Wear proper flame-retardant clothing covering all exposed body areas.
- Point torch away from your body and toward work when pressing the torch trigger – pilot arc comes on immediately.
- Turn off power source and disconnect input power before disassembling torch or changing torch parts.
- Use only torch(es) specified in the Owner's Manual.



### CYLINDERS can explode if damaged.

Gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of metalworking processes, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flame, sparks, and arcs.
- Install and secure cylinders in an upright position by chaining them to a stationary support or equipment cylinder rack to prevent falling or tipping.
- Keep cylinders away from any cutting or other electrical circuits.
- Never allow electrical contact between a plasma arc torch and a cylinder.
- Never cut on a pressurized cylinder – explosion will result.
- Use only correct gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.

### 1-3. Additional Symbols For Installation, Operation, And Maintenance




#### **HOT PARTS can cause severe burns.**

- Do not touch hot parts bare handed.
- Allow cooling period before working on torch.




#### **MOVING PARTS can cause injury.**

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.




#### **FLYING METAL can injure eyes.**

- Wear safety glasses with side shields or face shield.



#### **MAGNETIC FIELDS can affect pacemakers.**

- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near plasma arc cutting operations.



#### **OVERUSE can cause OVERHEATING.**


- Allow cooling period; follow rated duty cycle.
- Reduce amperage (thickness) or reduce duty cycle before starting to cut again.



#### **EXPLODING HYDROGEN hazard.**

- When cutting aluminum underwater or with the water touching the underside of the aluminum, free hydrogen gas may collect under the work-piece.

- See your cutting engineer and water table instructions for help.



#### **FALLING UNIT can cause injury.**


- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift unit.

- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.




#### **FIRE OR EXPLOSION hazard.**

- Do not locate unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




#### **STATIC (ESD) can damage PC boards.**

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



#### **H.F. RADIATION can cause interference.**

- High frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



#### **ARC CUTTING can cause interference.**

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- To reduce possible interference, keep cables as short as possible, close together, and down low, such as on the floor.
- Locate cutting operation 100 meters from any sensitive electronic equipment.
- Be sure this cutting power source is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the machine, using shielded cables, using line filters, or shielding the work area.

## 1-4. Principal Safety Standards

*Safety in Welding and Cutting*, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126

*Safety and Health Standards*, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

*Recommended Practices for Plasma Arc Cutting*, American Welding Society Standard AWS C5.2, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126

*Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances*, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126

*National Electrical Code*, NFPA Standard 70, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1, from Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

*Code for Safety in Welding and Cutting*, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.

*Safe Practices For Occupation And Educational Eye And Face Protection*, ANSI Standard Z87.1, from American National Standards Institute, 1430 Broadway, New York, NY 10018.

*Cutting And Welding Processes*, NFPA Standard 51B, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

## 1-5. EMF Information

Considerations About Welding Or Cutting And The Effects Of Low Frequency Electric And Magnetic Fields

Welding or cutting current, as it flows through the welding or cutting cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep cutting power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the cut as possible.

### **About Pacemakers:**

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.



# SECTION 2 – SPECIFICATIONS

Table 2-1. Cutting Torch

Specification	Description		
Cooling Method	Air		
Overall Dimensions	See Figure 2-1		
Cable Length	30 Or 50 ft (9.1 Or 15.2 m)		
Plasma Gas	Air Or Nitrogen		
	ICE-50	ICE-70 And 70M	ICE-100 And 100M
Plasma Gas Flow/Pressure	4.7 CFM (135 L/min) At 60 PSI (413 kPa)	7 CFM (198 L/min) At 70 PSI (483 kPa)	7 CFM (198 L/min) At 70 PSI (483 kPa)
Ampere Rating	Low Range: 35 Amperes At 100% Duty Cycle; High Range: 55 Amperes At 60% Duty Cycle (See Section 2-1)	70 Amperes At 100% Duty Cycle (See Section 2-1)	100 Amperes At 80% Duty Cycle (See Section 2-1)
Cutting Capacity	Up To 5/8 in (16 mm) Mild Steel And Stainless; Up To 3/8 in (10 mm) Aluminum	1 in (25 mm) Mild Steel, Stainless, And Aluminum	1-1/4 in (32 mm) Mild Steel, Stainless, And Aluminum
Gear Rack Pitch (Machine Torches Only)	Not Applicable	32	32
Weight	Net: 13-1/2 lb (6.1 kg)	Net: 10-1/2 lb (4.7 kg)	Net: 10-1/2 lb (4.7 kg)




Figure 2-1. Overall Dimensions

## 2-1. Duty Cycle





Figure 2-2. Duty Cycle


# SECTION 3 – INSTALLATION

## 3-1. Installing ICE-50 Torch



Side View

Tools Needed:



Turn Off power source and remove input power. Remove left side panel.

1 Access Holes

Insert cables through access holes.

2 Work Cable

3 Work (+) Output Terminal

4 Torch Cable

5 Pilot/Air Safety Cable

6 Pilot (+) Output Terminal

7 Torch/Air Output Cable

8 Torch (-) And Gas/Air Output Connector

Connect cables as shown.

9 Terminal Strip 1T

10 Torch Switch Leads



Connect one lead to each terminal of 1T.

Reinstall side panel.

ST-800 783 / ST-800 784 / ST-800 713

Figure 3-1. Installing ICE-50 Torch Into Power Source

### 3-2. Installing ICE-70, 70M, ICE-100, And 100M Torches



Turn Off power source and remove input power. Remove left side panel.

1 Access Holes

Insert cables through access holes as shown.

2 Work Cable (Supplied With Power Source)

3 Torch Cable

4 Torch (-) And Gas/Air Output Connector

5 Pilot Cable

6 Pilot (+) Output Terminal

Connect cables as shown.

7 Terminal Strip 1T

8 Connection Label

9 Torch Switch Leads


For hand-held torches, refer to label to connect leads. Reinstall side panel.

10 Nut

11 Hose Clamp

For machine-held torches, tighten nut and clamp to secure cables.

Machine torches require a custom-supplied external switch or remote pendant control connected between terminals 3 and 4 (refer to its Owner's Manual).



Ref. ST-159 466-C / ST-800 702-B / ST-800 713

Figure 3-2. Installing ICE-70, 70M, ICE-100, And 100M Torches Into Power Source

### 3-3. Remote Control Connections For Machine-Held Torches











Figure 3-3. Remote Control Connections For Machine-Held Torches

# SECTION 4 – OPERATING THE TORCH

 <b>WARNING</b>			
	<b>ELECTRIC SHOCK can kill.</b> <ul style="list-style-type: none"> <li>Always wear dry insulating gloves.</li> <li>Insulate yourself from work and ground.</li> <li>Do not touch live electrical parts.</li> <li>Keep all panels and covers securely in place.</li> </ul>		<b>CUTTING can cause fire or explosion.</b> <ul style="list-style-type: none"> <li>Do not cut near flammable material.</li> <li>Provide protection from flying sparks.</li> <li>Watch for fire; keep extinguisher nearby.</li> <li>Do not locate unit over combustible surfaces.</li> <li>Do not cut on closed containers.</li> <li>Allow work and equipment to cool before handling.</li> </ul>
	<b>FUMES AND GASES can be hazardous to your health.</b> <ul style="list-style-type: none"> <li>Keep your head out of the fumes.</li> <li>Ventilate area, or use breathing device.</li> <li>Read Material Safety Data Sheets (MSDSs) and manufacturer's instructions for material cut.</li> </ul>		<b>MOVING PARTS can cause injury.</b> <ul style="list-style-type: none"> <li>Keep away from moving parts.</li> <li>Keep all doors, panels, covers, and guards closed and securely in place.</li> </ul>
	<b>ARC RAYS can burn eyes and skin; NOISE can damage hearing.</b> <ul style="list-style-type: none"> <li>Wear face protection with correct shade of filter.</li> <li>Wear correct eye, ear, and body protection.</li> </ul>	See Safety Precautions at beginning of manual for basic cutting safety information. <span style="float: right;">swarn6.1* 10/91</span>	



Wear the following while cutting:

- 1 Dry, Insulating Gloves
- 2 Safety Glasses With Side Shields
- 3 Welding Helmet
- 4 Face Shield

Wear either helmet or face shield with correct shade of filter (See ANSI Z49.1).

- 5 Ear Muffs

Wear approved ear muffs or ear plugs if noise exposure exceeds OSHA limits.

sb3.1\* 1/94

**Figure 4-1. Safety Equipment**

# ⚠ CAUTION

## TIP AND ELECTRODE WEAR BEYOND RECOMMENDED VALUES or OPERATION WITHOUT TIP OR ELECTRODE can damage torch.

- Inspect retaining cup, tip, and electrode before cutting or whenever cutting speed has been significantly reduced (see Section 5-2).
- Do not operate torch without a tip or electrode in place.

## INCORRECT PIERCING can damage torch.

- When piercing (starting a cut away from metal edge) use a slight standoff distance and hold torch at about 10° angle to prevent sparks from reflecting back at torch.

## HITTING TORCH ON A HARD SURFACE to remove spatter can damage torch.


- Do not clean torch by hitting it against a hard surface.
- Hitting hard surfaces can damage torch parts and stop proper operation.

## INCORRECT STANDOFF DISTANCE can damage torch.


- For non-shielded cutting, always use a 1/8 in (3 mm) standoff distance between torch tip and workpiece.
- For 50 ampere torch, always use standoff guide when cutting with power source Range switch in High Range.

## HAVING PILOT ARC TURN ON AND OFF REPEATEDLY, such as during the cutting of chain fence, will shorten tip, electrode, and torch life.

- Put a continuous piece of sheet metal under the fence to prevent pilot arc from cycling on and off.
- Avoid constant starting and restarting of the arc.



### EXAMPLE Of Cutting Operation



ST-161 698-A

Figure 4-2. Sequence Of Plasma Arc Cutting (PAC)


# ⚠ CAUTION

## HITTING TORCH ON A HARD SURFACE to remove spatter can damage torch.


- Do not clean torch by hitting it against a hard surface.
- Hitting hard surfaces can damage torch parts and stop proper operation.

## TIP AND ELECTRODE WEAR BEYOND RECOMMENDED VALUES or OPERATION WITHOUT TIP OR ELECTRODE can damage torch.

- Inspect retaining cup, tip, and electrode before cutting or whenever cutting speed has been significantly reduced.
- Do not operate torch without a tip or electrode in place.
- Use correct standoff distance.
- Do not cut with gouging tip.



### EXAMPLE Of Gouging Operation



Ref. ST-162 317-A / Ref. ST-161 876-B

**Figure 4-3. Sequence Of Plasma Arc Gouging (PAG)**



# SECTION 5 – MAINTENANCE & TROUBLESHOOTING

## 5-1. Routine Maintenance

					<b>▲ Turn Off power source and disconnect input power before maintaining.</b>
--	--	--	--	--	---

**▲ Turn Off all power before maintaining.**

<p><b>Each Use</b></p> <table border="1"> <tr> <td></td> <td>See Section 5-2</td> <td></td> <td>Check Tip Electrode, And Retaining Cup</td> </tr> <tr> <td></td> <td>Power Source Manual</td> <td></td> <td>Check Gas/Air Pressure At Power Source</td> </tr> </table>			See Section 5-2		Check Tip Electrode, And Retaining Cup		Power Source Manual		Check Gas/Air Pressure At Power Source		<p><b>3 Months</b></p> <table border="1"> <tr> <td></td> <td>Tape Torn Outer Covering</td> </tr> <tr> <td></td> <td>Clean And Tighten Torch Connections</td> </tr> <tr> <td></td> <td>Replace Cracked Parts</td> </tr> <tr> <td></td> <td>Torch Body</td> </tr> <tr> <td></td> <td>Gas/Air Hose</td> </tr> <tr> <td></td> <td>Torch Cable</td> </tr> </table>			Tape Torn Outer Covering		Clean And Tighten Torch Connections		Replace Cracked Parts		Torch Body		Gas/Air Hose		Torch Cable
	See Section 5-2		Check Tip Electrode, And Retaining Cup																					
	Power Source Manual		Check Gas/Air Pressure At Power Source																					
	Tape Torn Outer Covering																							
	Clean And Tighten Torch Connections																							
	Replace Cracked Parts																							
	Torch Body																							
	Gas/Air Hose																							
	Torch Cable																							
<p><b>Every Week</b></p> <table border="1"> <tr> <td></td> <td>Power Source Manual</td> <td></td> <td>Check Retaining Cup Shutdown System</td> </tr> </table>			Power Source Manual		Check Retaining Cup Shutdown System																			
	Power Source Manual		Check Retaining Cup Shutdown System																					

Ref. ST-800 713

Figure 5-1. Maintenance Schedule

## 5-2. Checking/Replacing Retaining Cup, Tip, And Electrode

### CAUTION

#### OVERTIGHTENING will strip threads.

- Do not overtighten electrode, tip, and retaining cup during assembly.
- Do not cross-thread parts causing stripping.
- Use care during torch assembly and parts replacement.

#### TIP AND ELECTRODE WEAR BEYOND RECOMMENDED VALUES or OPERATION WITHOUT TIP OR ELECTRODE can damage torch.

- Inspect retaining cup, tip, and electrode before cutting or whenever cutting speed has been significantly reduced.
- Do not operate torch without a tip or electrode in place.
- Be sure to use genuine replacement parts.
- A good practice is to replace both the tip and electrode at the same time.




Figure 5-2. Checking/Replacing Retaining Cup, Tip, And Electrode

### 5-3. Troubleshooting

**Table 5-1. Cutting Trouble**



Trouble	Remedy	Section
Power source Torch-To-Tip Short trouble light On; no cutting output.	Check tip and electrode for a short. See also power source Owner's Manual.	5-2
	Check torch connections on power source terminal 1T. See power source Owner's Manual.	3-1, 3-2
Power source Gas/Air Or Shield Cup trouble light On; no cutting output.	Check o-ring, and lubricate if needed with supplied grease.	Figure 6-3, Figure 6-4
	Check for clean and sufficient gas/air supply pressure. See power source Owner's Manual.	--
Sparks come out top of cut, or cut is not clean.	Torch travel speed too fast; reduce travel speed.	Figure 4-2
	Check torch tip and electrode, and replace if necessary.	5-2
	Metal being cut is too thick; increase power source output control setting. See power source Owner's Manual.	--
	Be sure work clamp is securely attached. See power source Owner's Manual.	--
Arc goes out while cutting.	Make sure torch tip is not touching metal while cutting (above 40 amperes only).	Figure 4-2
	Check torch tip and electrode, and replace if necessary.	5-2
	Be sure work clamp is securely attached. See power source Owner's Manual.	--
Arc goes on and off while cutting.	Torch travel speed is too slow; increase travel speed.	Figure 4-2
	Check torch tip and electrode, and replace if necessary.	5-2
	Be sure work clamp is securely attached. See power source Owner's Manual.	--

# SECTION 6 – PARTS LIST

See Figure 6-3, Figure 6-4, or Figure 6-5 for additional torch consumables and parts.




Figure 6-1. Torch, ICE-50/70/100

Item No.	Part No.	Description	Quantity
<b>Figure 6-1. Torch, ICE-50/70/100</b>			
1	171 258	TORCH, main body (ICE-50 model)	1
1	171 257	TORCH, main body (ICE-70/-100 models)	1
2	171 246	HANDLE	1
3	171 248	PUSHBUTTON, switch	1
	171 255	SPLICE, 22-18 butt N-insul connector	2
4	171 263	LEAD INSULATOR, 5/8PVC 3.5 in long (ICE-50 model)	1
4	171 252	TEFLON TUBE, 11/16 ID x .030W x 3.5 in long (ICE-70/-100 models)	1
5	171 260	LEAD INSULATOR, 7/16PVC 3 in long (ICE-50 model)	1
5	171 251	TEFLON TUBE, 9/16 ID x .030W x 2.5 in long (ICE-70/-100 models)	1
6	171 259	BOOT, (ICE-50 model)	1
6	171 247	BOOT (ICE-70/-100 models)	1
7	171 256	HANDLE SCREW, No. 6 x 3/4ph	5
8	171 264	LEADS, 30ft (ICE-50 model) (consisting of)	1
9	180 504	LEADS, trigger	1
10	180 507	LEADS, pilot	1
11	180 506	LEADS, torch	1
8	171 253	LEADS, 30ft (ICE-70/-100 models) (consisting of)	1
9	180 504	LEADS, trigger	1
10	180 500	LEADS, pilot	1
11	180 501	LEADS, torch	1
8	171 265	LEADS, 50ft (ICE-50 model) (consisting of)	1
9	180 505	LEADS, trigger	1
10	180 509	LEADS, pilot	1
11	180 508	LEADS, torch	1
8	171 254	LEADS, 50ft (ICE-70/-100 models) (consisting of)	1
9	180 505	LEADS, trigger	1
10	180 498	LEADS, pilot	1
11	180 499	LEADS, torch	1

See Figure 6-6 or Figure 6-7 for additional torch consumables and parts.





Figure 6-2. Torch, ICE-70M/100M

ST-800 951-A


Item No.	Part No.	Description	Quantity
<b>Figure 6-2. Torch, ICE-70M/100M</b>			
... 1	171 245	.. TORCH, main body	1
... 2	171 241	.. TORCH ASSEMBLY, rack and sleeve (consisting of)	1
... 3	185 999	.. TORCH POSITION SLEEVE	1
... 4	186 000	.. COLLAR, brass	1
... 5	186 001	.. LOCKING RING	1
... 6	171 242	.. LEADS, 50ft (ICE-100M model) (consisting of)	1
... 7	180 498	.. LEADS, pilot	1
... 8	180 499	.. LEADS, torch	1
... 6	171 243	.. LEADS, 30ft (ICE-70M model) (consisting of)	1
... 7	180 500	.. LEADS, pilot	1
... 8	180 501	.. LEADS, torch	1
... 9	010 860	.. CLAMP, hose .750-1.750clp dia	1
... 10	170 993	.. COLLAR, brass	1
... 11	170 825	.. WASHER, shldr 1.251 ID x 1.750 OD x .125thk	1
... 12	010 907	.. NUT, 1.000-11	1
... 13	171 244	.. BLACK PVC, 5/8 ID x 3.5 long	1


 Torch is shipped with shielded cutting parts installed. Hand-held model shown.


Select correct consumables and parts for process being used as shown.

Apply a thin film of supplied grease (169 231) to O-ring before installing onto torch.

Always use standoff guide when cutting with power source Range switch in High Range. Install as shown. Standoff guide not required for Low Range cutting.




 The word "front" on swirl rings must face away from torch body.



Ref. S-170 648-C


**Figure 6-3. Consumables And Parts Supplied With ICE-50 Torch**

 Torch is shipped with shielded cutting parts installed.

Select correct consumables and parts for process being used as shown.

Apply a thin film of supplied grease (169 231) to O-ring before installing onto torch.

**Set air pressure to 70 PSI.**




Tools Needed:



(Supplied 170 488)

Ref. 170 650-D


**Figure 6-4. Consumables And Parts Supplied With ICE-70 Torch**

 Torch is shipped with shielded cutting parts installed.

Select correct consumables and parts for process being used as shown.

Apply a thin film of supplied grease (169 231) to O-ring before installing onto torch.

Set air pressure to 70 PSI.



Tools Needed:




(Supplied 170 488)

Ref. 170 652-C

Figure 6-5. Consumables And Parts Supplied With ICE-100 Torch




 Torch is shipped with shielded cutting parts installed.

Select correct consumables and parts for process being used as shown.

Apply a thin film of supplied grease (169 231) to O-ring before installing onto torch.

**Set air pressure to 70 PSI.**

**Grease    Wrench**  
**169231    170488**




Tools Needed:



(Supplied 170 488)

Ref. 170 657-C

**Figure 6-6. Consumables And Parts Supplied With ICE-70M Torch**


 Torch is shipped with shielded cutting parts installed.


Select correct consumables and parts for process being used as shown.

Apply a thin film of supplied grease (169 231) to O-ring before installing onto torch.

**Set air pressure to 70 PSI.**

**Grease    Wrench**  
**169231    170488**

 The word "front" on swirl rings must face away from torch body.



Tools Needed:



(Supplied 170 488)

Ref. 170 658-C

**Figure 6-7. Consumables And Parts Supplied With ICE-100M Torch**

# TRUE BLUE® WARRANTY

Effective January 1, 2000

(Equipment with a serial number preface of "LA" or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

## Warranty Questions?

Call  
1-800-4-A-MILLER  
for your local  
Miller distributor.

Your distributor also gives  
you ...

### Service

You always get the fast,  
reliable response you  
need. Most replacement  
parts can be in your  
hands in 24 hours.

### Support

Need fast answers to the  
tough welding questions?  
Contact your distributor.  
The expertise of the  
distributor and Miller is  
there to help you, every  
step of the way.

**LIMITED WARRANTY** – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor or eighteen months after the equipment is sent to an International distributor.

1. 5 Years Parts – 3 Years Labor
  - \* Original main power rectifiers
  - \* Inverters (input and output rectifiers only)
2. 3 Years — Parts and Labor
  - \* Transformer/Rectifier Power Sources
  - \* Plasma Arc Cutting Power Sources
  - \* Semi-Automatic and Automatic Wire Feeders
  - \* Inverter Power Supplies
  - \* Intelligig
  - \* Engine Driven Welding Generators  
**(NOTE: Engines are warranted separately by the engine manufacturer.)**
3. 1 Year — Parts and Labor
  - \* DS-2 Wire Feeder
  - \* Motor Driven Guns (w/exception of Spoolmate 185 & Spoolmate 250)
  - \* Process Controllers
  - \* Positioners and Controllers
  - \* Automatic Motion Devices
  - \* RFCS Foot Controls
  - \* Induction Heating Power Sources
  - \* Water Coolant Systems
  - \* HF Units
  - \* Grids
  - \* Maxstar 140
  - \* Spot Welders
  - \* Load Banks
  - \* Miller Cyclomatic Equipment
  - \* Running Gear/Trailers
  - \* Plasma Cutting Torches (except APT & SAF Models)
  - \* Field Options  
**(NOTE: Field options are covered under True Blue® for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)**
4. 6 Months — Batteries
5. 90 Days — Parts
  - \* MIG Guns/TIG Torches
  - \* Induction Heating Coils and Blankets

- \* APT, ZIPCUT & PLAZCUT Model Plasma Cutting Torches
- \* Remote Controls
- \* Accessory Kits
- \* Replacement Parts (No labor)
- \* Spoolmate 185 & Spoolmate 250
- \* Canvas Covers

Miller's True Blue® Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear.**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.





# Owner's Record

Please complete and retain with your personal records.

---

Model Name Serial/Style Number

---

Purchase Date (Date which equipment was delivered to original customer.)

---

Distributor

---

Address

---

City

---

State Zip

---



## For Service

**Call 1-800-4-A-Miller or see our website at [www.MillerWelds.com](http://www.MillerWelds.com) to locate a DISTRIBUTOR or SERVICE AGENCY near you.**

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

- Welding Supplies and Consumables
- Options and Accessories
- Personal Safety Equipment
- Service and Repair
- Replacement Parts
- Training (Schools, Videos, Books)
- Technical Manuals (Servicing Information and Parts)
- Circuit Diagrams
- Welding Process Handbooks

Contact the Delivering Carrier for:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

### Miller Electric Mfg. Co.

An Illinois Tool Works Company  
1635 West Spencer Street  
Appleton, WI 54914 USA

### International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended  
USA & Canada FAX: 920-735-4134  
International FAX: 920-735-4125

### European Headquarters – United Kingdom

Phone: 44 (0) 1204-593493  
FAX: 44 (0) 1204-598066

[www.MillerWelds.com](http://www.MillerWelds.com)

