



| EWT 1066 TDW | |
|---------------------|--|
| EWT 1266 TDW | |

EN WASHING MACHINE USER MANUAL

CONTENTS

| 1. | SAFETY INFORMATION | . 3 |
|-----|-----------------------|-----|
| 2. | SAFETY INSTRUCTIONS | . 4 |
| 3. | PRODUCT DESCRIPTION | . 5 |
| 4. | CONTROL PANEL | . 5 |
| 5. | WASHING PROGRAMMES | . 6 |
| 6. | CONSUMPTION VALUES | . 8 |
| 7. | OPTIONS | . 9 |
| 8. | BEFORE FIRST USE | 11 |
| 9. | DAILY USE | 11 |
| 10. | HINTS AND TIPS | 14 |
| 11. | CARE AND CLEANING | 15 |
| 12. | TROUBLESHOOTING | 17 |
| 13. | TECHNICAL INFORMATION | 19 |
| 14. | ENVIRONMENT CONCERNS | 19 |

WE'RE THINKING OF YOU

Thank you for purchasing an Electrolux appliance. You've chosen a product that brings with it decades of professional experience and innovation. Ingenious and stylish, it has been designed with you in mind. So whenever you use it, you can be safe in the knowledge that you'll get great results every time.

Welcome to Electrolux.

Visit our website for:



Get usage advice, brochures, trouble shooter, service information: www.electrolux.com



Register your product for better service:

www.electrolux.com/productregistration



Buy Accessories, Consumables and Original spare parts for your appliance: www.electrolux.com/shop

CUSTOMER CARE AND SERVICE

We recommend the use of original spare parts.

When contacting Service, ensure that you have the following data available.

The information can be found on the rating plate. Model, PNC, Serial Number.

(!) Warning / Caution-Safety information



(i) General information and tips



Environmental information

Subject to change without notice.

1. SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible if an incorrect installation and use causes injuries and damages. Always keep the instructions with the appliance for future reference.

1.1 Children and vulnerable people safety



WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8
 years and above and persons with reduced physical,
 sensory or mental capabilities or lack of experience and
 knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way
 and understand the hazards involved.
- Do not let children play with the appliance.
- Keep all packaging away from children.
- Keep all detergents away from children.
- Keep children and pets away from the appliance door when it is open.
- If the appliance has a child safety device, we recommend you activate it.
- Cleaning and user maintenance shall not be made by children without supervision.

1.2 General Safety

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Do not change the specification of this appliance.
- Obey the maximum load volume of 6 kg (refer to the "Programme chart" chapter).

2. <u>(1</u>)

SAFETY INSTRUCTIONS

2.1 Installation

- Remove all the packaging and the transit bolts.
- Keep the transit bolts. When you move the appliance again you must block the drum.
- Do not install or use a damaged appliance.
- Do not install or use the appliance where the temperature is less than 0 °C or where it is exposed to the weather.
- Obey the installation instruction supplied with the appliance.
- Make sure that the floor where you install the appliance is flat, stable, heat resistant and clean.
- Do not install the appliance where the appliance door can not be fully opened.
- Always be careful when you move the appliance because it is heavy. Always wear safety gloves.
- Make sure that there is air circulation between the appliance and the floor.
- Adjust the feet to have the necessary space between the appliance and the carpet.

Electrical connection



WARNING!

Risk of fire and electrical shock.

- The appliance must be earthed.
- Make sure that the electrical information on the rating plate agrees with the power supply. If not, contact an electrician.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable.
 Should the appliance power supply cable need to be replaced, this must be carried out by our Service Centre.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.

- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Do not touch the mains cable or the mains plug with wet hands.
- This appliance complies with the E.E.C. Directives.

Water connection

- Make sure not to cause damage to the water hoses.
- The appliance is to be connected to the water mains using the new supplied hose-sets. Old hose sets must not be reused.
- Before you connect the appliance to new pipes or pipes not used for a long time. let the water flow until it is clean.
- The first time you use the appliance, make sure that there is no leakage.

2.2 Use



WARNING!

Risk of injury, electrical shock, fire, burns or damage to the appliance.

- Use this appliance in a household only.
- Do not change the specification of this appliance.
- Obey the safety instructions on the detergent packaging.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Make sure that you remove all metal objects from the laundry.
- Do not put a container to collect possible water leakage under the appliance.
 Contact the Service to ensure which accessories can be used.

2.3 Care and Cleaning



WARNING!

Risk of injury or damage to the appliance.

 Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.


- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal obiects.
- 2.4 Disposal
- <u>(1)</u>

WARNING!

Risk of injury or suffocation.


- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Remove the door catch to prevent children and pets to get closed in the appliance.

3. PRODUCT DESCRIPTION



- Control panel
- 2 Lid
- 3 Lid handle
- 4 Feet for the appliance level
- 5 Rating plate

4. CONTROL PANEL




1 On Off button (1)

2 Programme knob

- 3 Spin reduction touchpad 6
- 4 Temperature touchpad
- 5 Display
- 6 Prewash touchpad
- 7 Delay start touchpad 🖰

- 8 Extra rinse touchpad
- 9 Easy iron touchpad =
- 10 Start pause touchpad 🕥
- 11 Time Manager touchpads − ⊕ +

4.1 Display



- A) The Temperature area:
 - : Temperature indicator
 - _ _: Cold water indicator
- B) (: Time Manager indicator.
- C) The time area:
 - 125: the programme duration
 - 2 h : the delay start
 - [2 ☐: the alarm codes
 - $\[\[\[\] \]$ $\[\]$ the message of error
 - ☐: Programme is completed.
- **D)** : the child safety lock indicator.

- E) Washing indicators:
 - | II | : the washing phase
 - : the rinses phase
 - (6): the spin phase
 - 📥 : Extra rinse permanent option.
- F) The spin area:
 - IBBB: the Spin speed indicator
 - _ _ : the No Spin indicator
 - | : the Rinse Hold indicator
 - dB: the Extra Silent indicator.
- G) : the Door locked indicator

5. WASHING PROGRAMMES

| Programme Temperature range | Type of load and soil Maximum load, Maximum spin |
|---------------------------------|---|
| ♥ Cottons 90°C — Cold | White cotton and coloured cotton. Normal soil and light soil. 6 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Cottons Eco 1) 60 °C - 40 °C | White cotton and colour-fast cotton. Normal soil. 6 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |

| Programme Temperature range | Type of load and soil Maximum load, Maximum spin |
|--------------------------------|---|
| Synthetics 60 °C - Cold | Synthetic items or mixed fabric items. Normal soil. 2,5 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Delicates 40 °C - Cold | Delicate fabrics as acrylics, viscose, polyester items. Normal soil. 2,5 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Wool/Handwash 40 °C − Cold | Machine washable wool, hand washable wool and delicate fabrics with «hand washing» care symbol. 1 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Jeans 60 °C - Cold | Items in denim and jersey. Also for items in dark colours. 3 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Rinse | To rinse and spin the laundry. All fabrics. 6 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Spin/Drain | To spin the laundry and to drain the water in the drum. All fabrics. 6 kg, 1000 rpm (EWT 1066TDW), 1200 rpm (EWT 1266TDW) |
| Solution Lingerie 40 °C − Cold | Special programme for very delicate items, as lingerie, bras and underwear etc. 1 kg, 800 rpm |
| Silk 30 °C | Special programme for silk and mixed synthetic items. 1 kg, 800 rpm |
| Curtains 40 °C - Cold | Special programme for curtains. The prewash phase activates automatically. ²⁾ 2 kg, 800 rpm |
| Duvet 60 °C - 30 °C | Special programme for one synthetic blanket, duvet, bedspread and so on. 2 kg, 800 rpm |
| Sports 30 °C | Synthetic and delicate items. Light soil or items or items to refresh. 2,5 kg, 800 rpm |
| 5 Shirts 30 °C | Washing cycle to wash 5 slightly soiled shirts. 800 rpm |

¹⁾ Standard programmes for the Energy Label consumption values

According to regulation 1061/2010, the "Cottons Eco 60 °C" and "Cottons Eco 40 °C" are respectively the "standard 60 °C cotton programme" and the "standard 40 °C cotton

8 www.electrolux.com

programme". They are the most efficient programmes in terms of combined energy and water consumptions for washing normally soiled cotton laundry.

The water temperature of the washing phase may differ from the temperature declared for the selected programme.

2) Do not use any detergent for prewash phase.

Programme options compatibility

| Programme | 6 - | | - 🗆 | dB | | | =5 | <u></u> |
|---------------------------|-----|---|-----|----|---|---|----|---------|
| \$ | • | • | • | • | • | • | • | • |
| ⇔ Eco | • | • | • | | • | • | - | • |
| \triangle | • | • | • | • | • | • | | - |
| ** | • | • | • | | • | • | | - |
| | • | • | • | • | | • | | |
| | • | • | • | | • | • | | - |
| | • | • | • | | | • | | - |
| (G [T] 1) | • | • | | | - | | | |
| \$ | • | • | - | | | • | | |
| B \$ \$ \$ \$ | • | • | | | | • | | |
| | • | • | • | | | • | | - |
| 圓 | • | | | | | | | |
| [] | • | • | | | | • | | |
| | • | • | | | | • | | |

¹⁾ If you set No Spin option the only drain phase is available.

6. CONSUMPTION VALUES

The data of this table are approximate. Different causes can change the data: the quantity and type of laundry, the water and ambient temperature.

| Pro- grammes | Load (kg) | Energy consump- tion (kWh) | Water con- sumption (litre) | Approxi- mate pro- gramme duration (mi- nutes) | Remaining moisture (%)1) EWT 1066TD W | Remaining moisture (%)1) EWT 1266TD W |
|-------------------------------|--------------|----------------------------------|--------------------------------------|--|---------------------------------------|---------------------------------------|
| Cottons 60 °C | 6 | 1.20 | 56 | 150 | 60 | 53 |
| Cottons 40 °C | 6 | 0.70 | 54 | 150 | 60 | 53 |
| Synthetics 40 °C | 2,5 | 0.50 | 46 | 105 | 37 | 35 |
| Delicates 40 °C | 2,5 | 0.55 | 46 | 90 | 37 | 35 |
| Wool/Hand wash 30 °C | 1 | 0.36 | 50 | 65 | 32 | 30 |
| Standard co | otton pr | ogrammes | | | | |
| Standard 60 °C cot- ton | 6 | 1.03 | 48 | 224 | 60 | 53 |
| Standard 60 °C cot- ton | 3 | 0.78 | 41 | 150 | 60 | 53 |
| Standard 40 °C cot- ton | 3 | 0.60 | 42 | 138 | 60 | 53 |

¹⁾ At the end of spin phase.

| Off Mode (W) | Left On Mode (W) |
|--------------|------------------|
| 0.75 | 0.75 |

The information given in the charts above are in compliance with the EU Commision regulation 2015/2010 implementing directive 2009/125/EC.

7. OPTIONS

7.1 Temperature

Set this option to change the default temperature.

Indicator $_{-}$ = cold water.

The display shows the set temperature.

7.2 Spin 6

With this option you can decrease the default spin speed.

The display shows the indicator of the set speed.

Additional spin options:

No Spin

- · Set this option to remove all spin pha-
- Set it for very delicate fabrics.
- The rinse phase uses more water for some washing programmes.
- The display shows the indicator _ _ _ _

Rinse Hold

- Set this option to prevent the laundry creases.
- The washing programme stops with the water in the drum. The drum turns reqularly to prevent the laundry creases.
- The door stays locked. You must drain the water to unlock the door.
- The display shows the indicator I
- i

To drain the water refer to 'At the end of the programme'.

Extra Silent

- · Set this option to remove all spin phases and to perform a silent washing.
- The rinse phase uses more water for some washing programmes.
- The washing programme stops with the water in the drum. The drum turns reaularly to prevent the laundry creases.
- The door stavs locked. You must drain the water to unlock the door.
- The display shows the indicator dB.
- i

To drain the water refer to 'At the end of the programme'.

7.3 Prewash | | |

With this option you can add a prewash phase to a washing programme. Use this option for heavy soil. When you set this option the programme duration increases.

The related indicator comes on.

7.4 Delay Start (2)

With this option you can delay the start of a programme from 30 minutes to 20 hours.

The display shows the related indicator.

7.5 Extra Rinse

With this option you can add some rinses to a washing programme.

Use this option for persons allergic to detergents and in areas where the water is

The related indicator comes on.

7.6 Easy Iron =/

The appliances carefully washes and spins the laundry to prevent the creases. The appliance decreases the spin speed, uses more water and adapt the programme duration to the type of laundry. The related indicator comes on.

7.7 Time Manager - 🕒 +

When you set a washing programme, the display shows the default duration. Press — or + to decrease or increase the programme duration.

The Time Manager is available only with the programmes in the table.

| (L) Indicator | \Diamond | \triangle | *** | ⊜ Eco | \square | B |
|---------------|-------------|-------------|------------|------------|-------------|------------|
| 1) | • | • | | | • | |
| ①, | - | - | - | | - | • |
| (C) | - | - | | | - | |
| () | • | • | • | - | - | • |
| (D) | - | - | | | - | |
| (1) | = 2) | = 2) | - | | = 2) | • |
| (1) | - | - | | | • | |
| | | | 2) | 2) | | 2) |
| 1) | | | | | | |

- Shortest: to fresh the laundry.
- 2) Programme default duration.
- 3) Longest: Increasing the programme duration gradually decreases the energy consumption. The optimized heating

phase saves energy and the longer duration maintains the same washing results (specially for normal soil).

7.8 Child Lock 🗔

With this option you can prevent that the children play with the control panel.

 To activate/deactivate the option, press at the same time until the indicator comes on/goes off.

You can activate this option:

 After you press ▷||, the options and the programme knob are locked. Before you press ▷ | : the appliance cannot start.

7.9 Acoustic signals

The acoustic signals operate when:

- The programme is completed.
- The appliance has a malfunction.

To **deactivate/activate** the acoustic signals, press = and $\stackrel{\leftarrow}{\Longrightarrow}$ at the same time for 6 seconds.



If you deactivate the acoustic signals, they continue operate when the appliance has a malfunction.

8. BEFORE FIRST USE

- 1. Put a small quantity of detergent in the compartment for washing phase.
- 2. Set and start a programme for cotton at the highest temperature without


laundry. This removes all possible dirt from the drum and the tub.

9. DAILY USE

Open the water tap.

 Connect the mains plug to the mains socket.

9.1 Loading the laundry



- 1. Open the appliance lid.
- **2.** Push the button A. The drum opens automatically.
- Put the laundry in the drum, one item at a time. Shake the items before you put them in the appliance. Make sure not to put too much laundry in the drum.
- 4. Close the drum and the lid.




CAUTION!

Before you close the lid of your appliance, make sure that you close the drum correctly.

9.2 Using detergent and additives

Measure out the detergent and the fabric conditioner.



The detergent compartment for the prewash phase.

III The detergent compartment for the washing phase.

Liquid additives compartment (fabric conditioner, starch).

The mark M is the maximum level for the quantity liquid additives.

9.3 Activating the appliance

Press the On/Off button to activate or deactivate the appliance. A tune sounds when the appliance is activated.

9.4 Setting a programme

- 1. Turn the programme knob and set the programme:
 - The related programme indicator comes on.
 - The indicator of the |>|| flashes.
 - The display shows the level of the Time Manager, the programme duration and the indicators of the programme phases
- 2. If necessary, change the temperature, the spin speed, the cycle duration, or add available options. When you activate an option, the indicator of the set option comes on.



If you set something incorrect, the display shows the message Err.

9.5 Starting a programme without delay start

Press the |>||:

- The indicator of the |>|| stops to flash and stays on.
- The indicator | | | start to flash on the display.
- The programme starts, the lid is locked and the display shows the indicator ---
- The drain pump can operate for a short time when the appliance fills water.

\mathbf{i}

After approximately 15 minutes from the start of the programme:

- The appliance adjusts automatically the programme duration agree with the laundry load.
- The display shows the new value.

9.6 Starting a programme with delay start

- Press (2) again and again until the display shows the delay you want to set. The related indicator comes on the display.
- Press ▷II:
 - The appliance starts the countdown.
 - When the countdown is completed. the programme starts automatically.



You can cancel or change the set of the delay start before you press \square

To cancel the delay start:

- Press |>|| to set the appliance to pause.
- 2. Press (1) until the display shows [] '. Press |> | again to start the programme immediately.

9.7 Interrupting a programme and changing the options

You can change only some options before they operate.

- 1. Press . The indicator flashes.
- 2. Change the options.
- Press |> || again. The programme continues.

9.8 Cancelling a programme

- Press the button for some seconds to cancel the programme and to deactivate the appliance.
- Press the same button again to activate the appliance. Now, you can set a new washing programme.
- \mathbf{i}

The appliance does not drain the water.

9.9 Opening the lid

While a programme or the delay start operates, the appliance lid is locked and the display shows the indicator — 1.



CAUTION!

If the temperature and level of the water in the drum are too high, you cannot open the lid.

Open the appliance lid when the delay start operates:

- 1. Press | to pause the appliance.
- 2. Wait until the lid lock indicator goes off.
- 3. You can open the lid.
- **4.** Close the lid and press the **|** again. The delay start continues to operate.

Open the appliance lid when the programme operates:

- 1. Press the ① button for some seconds to deactivate the appliance.
- Wait for some minutes and then open carefully the appliance lid.
- **3.** Close the lid and set the programme again.

9.10 At the end of the programme

- The appliance stops automatically.
- The acoustic signal operates (if it is activated).
- In the display a \square comes on.
- The lid lock indicator goes off.
- Remove the laundry from the appliance. Make sure that the drum is empty.
- Close the water tap.

- Press the button of for some seconds to deactivate the appliance.
- Keep the lid ajar, to prevent the mildew and odours.

The washing programme is completed, but there is water in the drum:

- The drum turns regularly to prevent the creases in the laundry.
- The lid lock indicator is on. The lid stays locked.
- You must drain the water to open the lid.

To drain the water:

- If necessary, decrease the spin speed. If you set _ _ _ , the appliance only drains.
- 2. Press | . The appliance drains the water and spins.
- When the programme is completed and the lid lock indicator — goes off. you can open the lid.
- Press the button of for some seconds to deactivate the appliance.



The appliance drains and spins automatically after approximately 18 hours (except for Wool programme).

9.11 AUTO Stand-by option

The AUTO Stand-by option automatically deactivates the appliance to decrease the energy consumption when:

You do not use the appliance for 5 minutes before you press ▷||.

Press the button () to activate the appliance again.

 After 5 minutes from the end of the washing programme

Press the button () to activate the appliance again.

The display shows the end of the last set programme.

Turn the programme knob to set a new cycle.

10. HINTS AND TIPS

10.1 The laundry load

- Divide the laundry in: white, coloured, synthetics, delicates and wool.
- Obey the washing instructions that are on the laundry care labels.
- Do not wash together white and coloured items.
- Some coloured items can discolour with the first wash. We recommend that you wash them separately for the first times.
- Button up pillowcases, close zippers, hooks and poppers. Tie up belts.
- Empty the pockets and unfold the items.
- Turn inside out multilayered fabrics, wool and items with painted illustrations.
- Remove hard stains.
- Wash with a special detergent heavy soil stains.
- Be careful with the curtains. Remove the hooks or put the curtains in a washing bag or pillowcase.
- Do not wash in the appliance :
 - Laundry without hems or with cuts
 - Underwired bras.
 - Use a washing bag to wash small items
- A very small load can cause balance problems with the spin phase. If this occurs, adjust manually the items in the tub and start the spin phase again.

10.2 Stubborn stains

For some stains, water and detergent is not sufficient.

We recommend that you remove these stains before you put the items in the appliance.

Special stain removers are available. Use the special stain remover that is applicable to the type of stain and fabric.

10.3 Detergents and additives

- Only use detergents and additives specially made for washing machines.
- Do not mix different types of deteraents.
- To help the environment, do not use more than the correct quantity of detergent.
- Obey the instructions that you find on the on packaging of these products.
- Use the correct products for the type and colour of the fabric, the programme temperature and the level of soil.
- If your appliance has not the detergent dispenser with the flap device, add the liquid detergents with a dosing ball.

10.4 Ecological hints

- Set a programme without the prewash phase to wash laundry with normal soil.
- Always start a washing programme with the maximum load of laundry.
- If necessary, use a stain remover when you set a programme with a low temperature.
- To use the correct quantity of the detergent, check the water hardness of your domestic system

10.5 Water hardness

If the water hardness in your area is high or moderate, we recommend that you use a water softener for washing machines. In areas where the water hardness is soft it is not necessary to use a water softener. To know the water hardness in your area, contact your local water authority. Use the correct quantity of the water softener. Obey the instructions that you find on the packaging of the product.

11. CARE AND CLEANING



WARNING!

Before maintenance, disconnect the appliance from the mains supply.

11.1 External cleaning

Clean the appliance only with soap and warm water. Fully dry all the surfaces.



CAUTION!

Do not use alcohol, solvents or chemical products.

11.2 Descaling

If the water hardness in your area is high or moderate, we recommend that you use a water softener for washing machines. Regularly examine the drum to prevent limescale and rust particles. To remove rust particles use only special products for washing machine. Do this separately from the laundry wash.




Always obey the instructions that you find on the packaging of the product.


11.3 Maintenance wash


With the low temperature programmes it is possible that some detergent stays in the drum. Make regularly a maintenance wash. To do this:

- Remove the laundry from the drum.
- Set the cotton programme with the highest temperature with a small quantity of detergent.

11.4 Cleaning the detergent dispenser









11.5 Cleaning the drain filter




WARNING!


Do not clean the drain filter if the water in the appliance is hot.





11.6 Cleaning the inlet hose and the valve filter







11.7 Frost precautions

If the appliance is installed in an area where the temperature can be less than 0

°C, remove the remaining water from the inlet hose and the drain pump.



Do this procedure also when you want to do the emergency drain.

- **1.** Disconnect the mains plug from the mains socket.
- **2.** Close the water tap and disconnect the water inlet hose.
- **3.** Disconnect the drain hose from a sink or spigot
- 4. Put the ends of the drain and inlet hose in a container. Let the water flow out of the hoses
- **5.** Set the Drain programme and let it operate until the end of the cycle.

- Turn the programme knob to Stop to disconnect the appliance from the power supply.
- 7. Disconnect the appliance.



WARNING!

Make sure that the temperature is more than 0 °C before you use the appliance again.

The manufacturer is not responsible for damages caused by low temperatures.

12. TROUBLESHOOTING

The start of the appliance does not occur or it stops during operation.

First try to find a solution to the problem (refer to the table). If not, contact the service centre.

With some problems, the acoustic signals operate and the display shows an alarm code:

- *£10* The appliance does not fill with water.
- **£2**[] The appliance does not drain the water.

- E\(\frac{1}{0} \) The appliance door is open or not closed correctly. Please check the door!
- **EHI** The mains supply is unstable. Wait until the mains supply is stable.



WARNING!

Deactivate the appliance before you do the checks.

| Problem | Possible solution | |
|---|---|--|
| The programme does not start. | Make sure that the mains plug is connected to the mains socket. | |
| | Make sure that the appliance lid is closed. | |
| | Make sure that there is not a damaged fuse in the fuse box. | |
| | Make sure that the Start/Pause has been pressed. | |
| | If the delay start is set, cancel the setting or wait for the end of countdown. | |
| | Deactivate the Child Lock function if it is on. | |
| The appliance does not fill with water. | Make sure that the water tap is open. | |
| | Make sure that the pressure of the water supply is not too low. For this information, contact your local water authority. | |
| | Make sure that the water tap is not clogged. | |
| | Make sure that the filter of the inlet hose and the filter of the valve are not clogged. Refer to "Care and cleaning". | |
| | Make sure that the inlet hose has no kinks or bends. | |

| Problem | Possible solution | | | |
|--|---|---|--|--|
| | Use special products to remove the stubborn stains before you wash the laundry. | | | |
| | Make sure that you set the correct temperature. | | | |
| | Decrease the laundry load. | | | |
| You cannot set an option. | Make sure that you press only the wanted touchbutton(s). | | | |
| After the check, activate the appliance. The programme continues from the point of interruption. If the problem occurs again, contact the Service. | | If the display shows other alarm codes. Deactivate and activate the appliance. If the problem continues, contact the Service. | | |

13. TECHNICAL INFORMATION

| Dimensions | Width / Height / Depth | 400 / 850 / 600 mm | |
|--|---------------------------------|--|--|
| | Total depth | 600 mm | |
| Electrical connection: | Voltage 23 Overall power 220 | | |
| | Fuse | 10 A | |
| | Frequency | 50 Hz | |
| Level of protection agains and moisture ensured by cept where the low voltag tection against moisture | IPX4 | | |
| Water supply pressure | Minimum | 0,5 bar (0,05 MPa) | |
| | Maximum | 8 bar (0,8 MPa) | |
| Water supply 1) | Nater supply 1) | | |
| Maximum load | Cotton | 6 kg | |
| Spin speed | Maximum | 1000 rpm (EWT 1066TDW) 1200 rpm (EWT 1266TDW) | |
| | | | |

¹⁾ Connect the water inlet hose to a water tap with a 3/4" thread.

14. ENVIRONMENT CONCERNS

Recycle the materials with the symbol \bigcirc . Put the packaging in applicable containers to recycle it.

Help protect the environment and human health and to recycle waste of electrical

and electronic appliances. Do not dispose appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.













