

Operator manual

Simrad SH80

High frequency fishery sonar



www.simrad.com

MAXIMIZING YOUR PERFORMANCE AT SEA

SIMRAD
A KONGSBERG Company

SH80
High frequency fishery sonar
Operator manual

WARNING

The sonar must never be powered up when the ship is in dry dock. The transducer will be damaged if it transmits in open air. To prevent inadvertent use of the sonar, pull out the mains plug on the Sonar Processor Unit whenever the vessel is in dry dock.

About this document

Rev	Date	Written by	Checked by	Approved by
Rev.C	11.02.05	RBr	SØJ	OBG
Updated for software version 1.2.X				

© 2005 Simrad AS

ISBN 82-8066-007-0

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or otherwise copied without prior permission from Simrad AS.

The information contained in this document is subject to change without prior notice. Simrad AS shall not be liable for errors contained herein, or for incidental or consequential damages in connection with the furnishing, performance, or use of this document.

Simrad AS
Strandpromenaden 50
Box 111
N-3191 Horten

Telephone: +47 33 03 40 00
Facsimile: +47 33 04 29 87

www.simrad.com

SIMRAD
A KONGSBERG Company

MAXIMIZING YOUR PERFORMANCE AT SEA

Sections

1. System description

This chapter provides a brief introduction to the SH80, and defines the main units. Refer to page 1.

2. Display modes

This chapter defines the available operational display modes. Refer to page 13.

3. Sonar Operating Panel

The main functions of the SH80 is controlled by a dedicated keyboard; the operating panel. The controls and functions of this unit is described. Refer to page 23.

4. Operation

This chapter provides the basic knowledge on how to operate the SH80 sonar. Refer to page 36.

5. Menu description

Operation of the SH80 sonar is also menu based. and the menus will automatically adjust to your current operational modes. This chapter explains all the menus, and refers directly to the relevant parameters. Refer to page 56.

6. Parameters

All the operational functions of the SH80 sonar are controlled by the parameters accessed from the menu system. In this chapter, all the parameters are described and explained. They are listed in alphabetical order. Refer to page 83.

7. Maintenance

This chapter explains how to perform the on-board maintenance on the SH80 sonar. Refer to page 150.

SYSTEM DESCRIPTION	1
Introduction	1
System overview	2
Main units	2
Wheelhouse units	2
Sonar room units	3
System diagram	4
Options	6
General	6
Multiple-frequency	6
Scientific output	6
Functional description	7
Introduction	7
Functional principles	7
Stabilization system	9
Reception	9
Transmission	10
Peripheral equipment	12
DISPLAY MODES	13
Introduction	13
Bow Up	14
North Up	15
True Motion	16
180°/Audio	17
270°/Vertical	18
Bow Up / Vertical	19
True Motion/Vertical	20
Dual 1	21
Dual 2	22
SONAR OPERATING PANEL	23
Introduction	23
Main switch	24
Symbol	25
Mode	27
Gain	28
Range	29
Cursor	30
Train	32

Tilt	34
Various	35
OPERATION	36
Introduction	36
Maintaining the sonar	37
Maintenance procedures	37
Important when docking the vessel	37
Start and stop procedures	38
Start procedure	38
Stop procedure	39
Dry-docking safety measures	40
Menu operation	41
Introduction	41
Screen presentations	42
Menu structure	44
Menu buttons	45
Selecting a new parameter value	46
Stored parameters	48
Visual aids	49
Common information on the display	49
Moving the boundary lines	49
Cosmetics	50
Installation of options	53
On-line help	55
MENU DESCRIPTIONS	56
Introduction	56
Active menus	57
Overview	57
Horizontal	58
Vertical	59
Display	60
Setup	61
Objects	62
Temporary menus	63
Cosmetics	64
Store/Recall	65
System test	66
Sort Modes	68

Pop-up menus	69
View pop-up	70
Object pop-up	72
View menus	74
GeoView	75
VerticalView	76
CatchView	77
Messages	78
Message categories	78
Warnings	79
Operator alarms	80
System alarms	81
Errors	82
PARAMETERS	83
About parameter dialogues and help	83
Alphabetical list	84
About	85
Beam	86
Bearing (Horizontal)	88
Bearing (Display)	90
Bearing (Vertical)	91
Colour Threshold	92
Colours	93
Data Source	94
Dead Reckoning	95
Default Setting	96
Direction Indicator	97
Edit Gear (Purse)	98
Edit Gear (Trawl)	99
Edit School	101
External Synchronization	102
Fish Alarm	103
Frequency	104
Gain	105
Gear	106
Heading	107
Inspect Object	108
Language	109
Menu	110

Message Bar	111
Mode	112
Mode Buttons	113
Movements	114
Noise Level	115
Palette	116
Panel Backlight	117
PP Filter	118
Pulse Form	119
Range	121
Range (Catch View)	122
RCG (Reverberation Controlled Gain)	123
Recall	124
Recall Mode	124
Ruler	125
Scale	126
School	127
Scientific Output (Option)	128
Search Sector	129
Search Step	130
Slant Range/True Range	131
Speed	132
Stabilizer	133
Status	134
Store	135
Store Mode	135
Target Track	136
Tilt	137
Time and Date	138
Track History	139
Track Window	140
Transducer	141
TVG (Time Variable Gain)	142
Tx Power	143
Units	144
User Setting	145
Wind Direction	146
Wind Speed	147
Zoom	148
Zoom Scale	149

ON-BOARD MAINTENANCE	150
Introduction	150
Preventive maintenance schedule	151
Wheelhouse units	152
Cleaning	152
Dust filter	152
Transceiver Unit	154
Dust filter	154
Replacing fuses	154
Hull unit	156
General	156
Hull unit familiarization	157
Docking the vessel	158
Cleaning the transducer	160
Hoist motor overload protection	161
Emergency hoisting and lowering	162
Lubrication of the Hull Unit	163

SYSTEM DESCRIPTION

Introduction

The Simrad SH80 sonar is an omnidirectional high frequency sonar, designed for all sized fishing vessels, both purse seiners and trawlers. The standard frequency is 116 kHz (multiple frequencies as option), and the beam can be electronically tilted from +10 to –60 degrees.

Great emphasis has been placed on giving the best possible presentations on a high resolution colour display. The processor unit is controlled by Microsoft's Windows XP® operating system, which result in a flexible choice of display modes for a large range of user applications.

The signal processing and beamforming is performed in a fast digital signal processing system using the full dynamic range of the signals. In addition to the traditional single frequency transceiver system, the SH80 sonar contains an advanced frequency modulated filter system (FM).

The cylindrical multi-element transducer allows the omni-directional sonar beam to be tilted electronically down to -60 degrees. This allows you to automatically track schools of fish, and to observe the whole water volume around the vessel. A stabilization system is included for electronic pitch and roll compensation.

Topics

- *System overview, page 2*
- *System diagram, page 4*
- *Options, page 6*
- *Functional description, page 7*
- *Peripheral equipment, page 12*

Important notice

Windows, Windows NT and Windows XP® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

System overview

Main units

The Simrad SH80 sonar consists of the following units:

- Wheelhouse units:
 - Display monitor
 - Sonar Operating Panel
 - Sonar Processor Unit
 - Sonar Interface Unit
- Sonar room units:
 - Transceiver Unit
 - Hull Unit

Wheelhouse units

The **Display Monitor** is a high-resolution colour LCD (Liquid Crystal Display). In addition to the sonar picture, the monitor can also display the user menu for the interactive operation. In order to ease the situation comprehension, certain colours have been chosen to better the distinction between the various elements in the scene.

The **Operating Panel** contains all necessary control functions for operating the sonar. The controls are arranged in function groups, which gives a clear and easy operation. Note that all sonar operation also may be made from the trackball, or from an optional standard mouse.

The **Sonar Processor Unit** contains a ruggedized computer, which runs the **Microsoft Windows XP®** operating system. The software has been modified by Simrad to suit the SH80 sonar requirements. The unit holds a CD R/WR unit to be used for future software upgrades.

The **Sonar Interface Unit** provides interface for all auxiliary equipment; log, gyro, GPS, echo sounder, trawl systems, purse seine systems etc. One signal cable is used for the communication with the Transceiver Unit in the sonar room.

Note that SH80 sonars shipped before August 2003 use a different Sonar Processor Unit; the **APC10**. These sonars do not have the Sonar Interface Unit fitted. All interfaces to peripheral equipment are then handled by the APC10.

Sonar room units

The **Transceiver Unit** is located in the sonar room, close to the Hull Unit. One signal cable is used for communication with the Sonar Interface Unit in the wheelhouse. The transceiver performs the signal processing and the digital beamforming of the 240 transmitters and 480 receiver channels, which are located on the eight identical transceiver boards.

The **Hull Unit** is designed to be lowered 1.0 meters below the ship's hull. The transducer can also be lowered to any selectable middle position. Note that in case of voltage failure, the Hull Unit can be manually raised or lowered by means of a hand crank.

The cylindrical 480-elements **transducer** allows the sonar beam to give full 360 degrees coverage of the water volume down to -60 degrees.

The sensor for the electronic stabilization of the sonar beams is housed in the Motor Control Unit, which is mounted on the Hull Unit.

Warning:

If the transducer hits larger objects or bottom, the transducer shaft may be bent, or in worst case it can be broken off. A broken transducer shaft will cause water leakage in the top of the shaft. To prevent larger leakages in such a case, do not raise the transducer shaft to the upper position. To prevent serious damages it is therefore of great importance to have a good pump and warning system in the sonar room.

Related topics

→ *System diagram, page 4*

System diagram

A simplified SH80 system diagram is shown.

(A) = Colour display

(B) = Operating Panel

(C) = Sonar Processor Unit

(D) = Sonar Interface Unit


(E) = Multiple interface lines to peripheral equipment

(F) = Transceiver Unit

(G) = Hull Unit

(1) = Wheelhouse

(2) = Sonar room



(CD15015B)

Options

General

The standard SH80 sonar is a single 116 kHz version with beam stabilization.

The beam stabilization was an optional function until 1 January 2003. After that date, the function was included with the standard sonar delivery.

The options described below are pre-programmed into the standard software version, and a code word is required to make the actual option available. Simrad offers a 1 month free test period for certain options. Note that the Scientific Output function is not available for such a test period.

For a permanent installation of a chosen option, a new code word will be released from Simrad when the option is ordered.

Multiple-frequency

In addition to the standard 116 kHz frequency, a multiple frequency option is available. In this multiple frequency version you can select between 13 frequencies from 110 to 122 kHz in 1 kHz steps.

Scientific output

The Scientific Output is designed for research purposes. When activated, the following data are available on an Ethernet (LAN) output:

- Beam data
- Target data
- Own ship data
- Gear data

The scientific output option may also include software for a Scientific Data Logger.

Note that this option is not available for a free test period.

Related topics

→ *Code words, procedure, page 53*

Functional description

Introduction


The basic principles of the SH80 sonar are unique because of the 240 transmitter and 480 receiver channels with their transducer elements spread around on the cylindrical transducer array.

The transmission, reception and data processing are under computer control, and the powerful capabilities of the sonar are the results of sophisticated digital signal processing software and state of the art hardware.

Functional principles

When the **Omni** beam is tilted, the total beam picture can be compared with folding an umbrella, which means that all beams in 360 degrees around the vessel have the same tilt angle.

*Omni beam
principle*



The beam can be tilted from +10 up to -60 degrees down.


In addition to seeing the target from above, it is also possible to see the target from the side, by using the vertical slice presentation. In this case the beam covers a continuous vertical beam from 0 to -60 degrees in one transmission.

This vertical slice, which is presented by the white audio line in the horizontal picture, can be selected to any bearing by the manual training control. The combination of the **Omni** mode and the vertical slice will give an optimal visualization of the catch situation.

60 degrees vertical slice



Omni/Vertical combination




In addition to the **Omni** picture, the vertical slice is especially useful for visualizing the vertical distribution of a school of fish. In that way, it is not necessary to go over the target to see the distribution on the echo sounder, which often results in a spreading of the school.

Stabilization system

When the beam stabilizer is activated, both horizontal and vertical beams will be stabilized electronically for roll and pitch movements up to ± 20 degrees. The beam direction will then change continuously according to the vessel's movements, and secure an optimal contact with the targets even in rough seas.

Stabilization system



Reception

A great effort has been made to reduce unwanted noise to get a clean and stable echo presentation. To achieve this goal the sonar receiver has the following filtering possibilities:

FM Correlation filter

In addition to the traditional single frequency transmitting method, the SH80 sonar is equipped with an FM correlation mode.

In FM mode each transmission pulse contains up to four different frequencies, and the receiver makes a spectrum analysis and compares the received echoes with the transmitted frequency code. This provides a filtering effect, which efficiently reduces interference, noise and reverberation. In addition to giving a clean and stable echo presentation, this will normally also increase the sonar's detection range.

Frequency selection (Option)

The optional multiple frequency selection can be used for suppression of interference from other sonars.

However, the sound absorption in salt water increases with the frequency, thus giving the lower frequencies a longer detection range.

RCG (Reverberation Controlled Gain)

The RCG filter senses the noise level (reverberation, propeller noise, etc.), and adjusts the gain individually for each of the 64 receiver beams in order to eliminate noise on the display. The strength of the filter can be selected in the menu. With maximum strength is selected, the RCG will effectively reduce the bottom in shallow water, while variations on the bottom will be displayed.

Note that scattered fish can be perceived as reverberation. The RCG filter must therefore be used with care if scattered schools are to be detected.

PP Filter

The SH80 sonar is equipped with a ping-to-ping filter to give a clean and steady presentation by reducing the interference and noise. This filter compares the echoes from a selected amount of transmissions (pings), and an echo has to be present in the selected amount of pings in order to be presented on the display.

Note that in rough seas, when the beam easily can miss the target in several pings, the PP filter must be used with care.

TVG (Time Variable Gain)

The TVG function controls the gain of the receiver so that a school with a given size and density is presented with approximately the same strength on the display, inside the regulated TVG range. This can also be seen as a filter, because it reduces the noise close to the vessel.

The regulated strength of the TVG can be selected in the menu.

Transmission

The transmitting is controlled by the signal processor in the Transceiver Unit. The parameters you have chosen are used.

There are 240 separate transmitters in the unit distributed on eight transceiver circuit boards. Each transmitter is individually addressed and controlled from the signal processor. The controlled parameters include power output and time delay for each transducer element in order to form a beam with the selected tilt angle.

When the stabilisation system is active, the tilt angle for each beam will automatically be corrected relative to the vessel's pitch and roll movements.

Related topics

→ *Frequency options, page 6*

Peripheral equipment

The SH80 sonar requires connection to a speed log and a course gyro. An inaccurate log or gyro input will cause inaccurate indication of the vessel and target movements.

In addition to log and gyro, the following peripheral equipment can be connected to the sonar.

- A (D)GPS may be connected to the SH80 sonar to establish the vessels position and provide cursor and marker latitude and longitude.
- Simrad echo sounders (EQ, ES and EK Series) provides a bottom plot on the catch data page.
- Simrad PI32 and PI44 Catch Monitoring systems provide the net depth in digits and bars on the catch data presentation.
- Simrad trawl instrumentation; FS 900, FS 3300 or ITI
 - FS 900 and FS 3300: The trawl will be displayed in correct depth.
 - ITI: The trawl will be displayed in correct size, depth, distance and bearing.
- A Current meter system will indicate the current speed and direction for up to three different depths in the sonar picture.
- A radio buoy system (GPS type) will provide the geographical position of the buoy(s) in the sonar picture.

For connection of any of this peripheral equipment, contact your local dealer.

DISPLAY MODES

Introduction

This chapter describes the SH80 display modes. The various modes represent the graphical presentation of sonar data. Several display modes are available to present the best possible presentations as well as flexible choices for a large range of user applications.

Topics

- *Bow Up, page 14*
- *North Up, page 15*
- *True Motion, page 16*
- *180°/ Audio, page 17*
- *270°/ Vertical, page 18*
- *Bow Up / Vertical, page 19*
- *True Motion / Vertical, page 20*
- *Dual 1, page 21*
- *Dual 2, page 22*

Display mode selection is made on the second menu button in the main menu. The four first display modes shown can also easily be selected with the four **Mode** buttons on the Sonar Operating Panel.

Note that the descriptive order of the display modes in this chapter has been chosen only to simplify the descriptions. In operational conditions, the order of the display modes depends on the selected gear (seine net, bottom trawl or pelagic trawl). This is because different initial display modes are used for easy selection by the four **Mode** buttons on the Sonar Operating Panel. The order of these display modes can easily be changed in the **Sort Mode** menu.


All the display modes in the following chapters are shown without echoes.

Related topics

- *Mode buttons, page 27*
- *Sort Modes, page 68*

Bow Up

When **Bow Up** mode is selected, the vessel symbol is stationary on the screen with the bow pointing upwards. The echo presentation covers 360 degrees around the vessel, and all echoes are updated for every ping. The distance from the vessel symbol to the outer echo ring is equal to the selected range.




The movement of the echoes across the screen are controlled by a combination of the vessel's course and speed and the target's own movements.

Related topics

→ *Cosmetics, page 50*

North Up

When the **North Up** mode is selected, true north is always up on the screen. The vessel symbol is stationary with the bow pointing in the vessel's course direction. The movement of the echoes across the screen are controlled by a combination of the vessel's course and speed and the target's own movements.




Related topics

→ *Cosmetics, page 50*

True Motion

When the **True Motion** mode is selected, the picture is locked to a geographical position, where the vessel moves around the screen according to its present course and speed. All echoes are always presented in their correct position relative to the vessel, and their movements on the screen will be a true representation of the movements of the targets through the water.




When the vessel symbol reaches the edge of the screen, it will automatically be moved back to the centre, or to a position determined by the **Off Centre** button. This position is reset to the screen centre whenever the mode is changed. When you select **Target Track**, the target will automatically be moved to the screen centre.

Related topics

→ *Cosmetics, page 50*

180° / Audio

When the **180°/Audio** mode is selected, the upper half of the screen shows a 180 degrees bow-up presentation, while the lower part is used for a recording of the audio channel.



The audio channel is shown with a continuous white line in the horizontal picture, and it can be trained in any direction. The recorded echoes are a direct replica of the echoes under the white audio line. As the audio channel is recorded over a period of time, this mode is especially useful for detection of weak echoes mixed with reverberation or noise.


The information recorded by the audio channel is always stored in the computer, even if another mode is selected. That means that this recording will always be presented when selecting the **180°/Audio** mode. Note that the vessel symbol can be moved to any position in the horizontal view with the cursor and **Off Centre** button.

Related topics

→ *Cosmetics, page 50*

270° / Vertical

The **270°/Vertical** mode is specially designed for purse seining. The vertical half slice is displayed in the lower left corner for normal setting with the net on the starboard side. If the net is set on the port side, the 60 degrees vertical slice will be displayed in the lower right hand corner.




With this presentation, it is easy to keep the best contact with a school in both the vertical and horizontal presentation, and to determine its size distribution. The position of the school relative to the bottom is another important information provided by this presentation. The **Catch data** presentation for purse seining is shown on the right hand side. It shows all the net data relative to the target and the bottom, as well as all available target data.

Related topics

→ *Cosmetics, page 50*

Bow Up / Vertical

When the **Bow Up / Vertical** mode is selected, the picture is divided into three sections; where the left side is a **bow-up** presentation similar to the bow-up presentation previously described.




The upper part on the right hand side is a **catch data** presentation, while the lower part is a 60 degree **vertical slice** presentation.

Related topics

→ *Cosmetics, page 50*

True Motion/Vertical

When the **True Motion/Vertical** mode is selected, the picture is divided into three sections; where the left side is a **True motion** presentation similar to the true motion presentation previously described.




The upper part on the right-hand side is a **Catch data** presentation, while the lower part is a 60 degrees **Vertical slice** presentation.

Related topics

→ *Cosmetics, page 50*

Dual 1

The **Dual 1** mode is a kind of “two sonars in one” operation, where each presentation is updated for every second transmission. All settings can be set individually for each of the two presentations. This makes the dual mode especially useful for optimizing settings by directly comparing the two presentations.



To optimize the horizontal settings, use the **Horizontal** menu to try different settings in the upper picture. These settings are automatically transferred to the other modes.


The dual operation may also be used for other user applications, where different range, tilt, frequency and other parameters can be selected.

Related topics

→ *Cosmetics, page 50*

Dual 2

The **Dual 2** mode is very similar to the **Dual 1** mode previously described, but the “two sonars” are presented next to each other. All settings can still be set individually for each of the two presentations.



Related topics


→ *Cosmetics, page 50*

SONAR OPERATING PANEL

Introduction

You may enter operational commands directly on the **Sonar Operating Panel**. Sonar functions may also be accessed and activated using the menu field on the display and the trackball on the operating panel.

Frequently used functions are directly accessed by the designated control buttons. These are grouped according to their purpose.




Sonar Operating Panel

A thorough understanding of system functions and controls is necessary to optimize overall performance. Sonar conditions vary, sometimes drastically, and it is not possible to identify settings that will provide the best data at all times. Careful study of the information in this manual is highly recommended, preferably while exploring the sonar's various functions. System operation is a dynamic activity requiring regular adjustments and fine tuning to achieve the best possible results under varying environmental conditions.

Main switch

Main switch functions control power to the sonar, hoisting and lowering of the transducer and indicates the transducer's current position.



Power

Pressing **Power** for approximately two seconds powers up the sonar. The adjacent green LED blinks while the Sonar Control Unit boots up, and remains illuminated once the system is operational.

Before the sonar can be powered down, the transducer must be in the **Up** position. Pressing the **Power** button for approximately two seconds secures power to the unit which is confirmed by the adjacent green LED being extinguished.

Up

Raises the transducer to its upper position. The adjacent green LED blinks while the transducer is raised and remains illuminated once it is housed safely inside the hull of the vessel. The green blinking LED will also be accompanied by an audible signal.

Middle

Raises or lowers the transducer to its middle position.

The physical location of the middle position can be defined in the **Transducer** parameter dialogue.

Down


Lowers the transducer to its lower position. The adjacent green LED blinks while the transducer is lowered and remains illuminated when lower position is reached. The green blinking LED will also be accompanied by an audible signal.

Related topics

→ *Transducer, page 141*

Symbol

The **Symbol** functions provide on-screen graphic references for targets, own ship and fishing gear.



(A) Target marker

To mark a target, move the cursor over it and press the button. A triangular symbol with a corresponding number will appear on the screen over the target.

Position data for the defined markers are displayed in the **Objects** menu.

Note that the system continues to track the markers even when outside the sonar range.

The **Target marker** function can also be used for manual target tracking as the system is designed to calculate the speed (S), course (C) and distance (D) between the last two chosen targets.

The **Target marker** data is displayed in white figures for three minutes in the lower right hand corner of the horizontal presentation. This function is also an effective method for determining the distance between two selected points on the screen.

(B) Own ship marker

The “own ship” button produces a square symbol on the screen at the vessel’s current location when the button is pressed. The own ship marker’s position data is displayed in the **Objects** menu.

(C) Circle marker

This marker may be used to estimate the size of a school of fish or as an indication of the size of the purse seine. To activate the function, move the cursor to the desired position and press the button. A circular symbol will appear on the screen at the chosen location. The size of the symbol is equal to that of the purse seine selected.

(D) Gear symbol

The gear symbol may be either a purse seine circle or a trawl symbol depending on the parameter chosen by the **Gear** button in the **Setup** menu. The selected gear symbol will be displayed in yellow.

Seine circle

This is a useful aid in planning the shooting of the purse seine. It is used as follows:

1. Press the **Gear** button.
 - The purse seine circle will appear on the forward end of the ship symbol on the corresponding side of the vessel selected in the **Setup** menu. The circle will follow the vessel's movements.
2. At the moment the seine is shot, press the **Gear** button again.
 - The purse seine circle will remain stationary and indicate the ideal path for setting the seine. Three square symbols on the ship's course line indicate the: shooting, one half, and the end of the seine positions. Three different nets can be pre-programmed in the **Gear** menu.
3. Press the **Gear** button to delete the **Purse Seine** circle.

Trawl symbol


This is a useful aid in providing an overview of the trawl operation.

Trawl data can be set manually using the menu or automatically by interfacing the Simrad **FS** trawl sonar or **ITI** trawl monitoring system with the sonar.

- In the manual mode the trawl symbol will be displayed with the selected size, depth and distance.
- When the FS900 or FS3000 trawl sonar is connected, the trawl symbol will automatically be displayed with the correct depth in the vertical modes.
- When the ITI trawl system is connected, the trawl symbol will be displayed with the correct distance, bearing and depth. If required, the trawl opening, ambient water temperature, and trawl-filling indicator may also be displayed.

Mode

The four **Mode** buttons can be used to select either the four favourite display modes or user settings. To set up the buttons to choose modes or settings, select **Mode Buttons** in the **Display** menu.



Depending on the selection you make in the **Mode Buttons** menu, you have two options:


- To select a mode, use the **Mode** button on the top of the menu, or press one of the four **Mode** buttons. Frequently used operational modes that are task specific to particular phases of the fishing operation can be pre-defined in the **Sort modes** menu. For example, *Mode 1* may be used for the search phase, *Mode 2* for the evaluation phase, *Mode 3* for the catch phase, and *Mode 4* for dual operation.
- To select a user setting, you can select **User Settings** on the the **Setup** menu, or you can use one of the four **Mode** buttons. The different user settings are created and maintained in the **User Setting** parameter dialogue. To choose user setting assignment to the four buttons, sort the list of users alphabetically.

Related topics

- *Sort Modes, page 68*
- *Display Modes, page 13*
- *User Settings, page 145*
- *Mode Buttons, page 113*

Gain

Gain controls are specified as either horizontal or vertical.



Horizontal gain


The two upper buttons control receiver gain effecting the horizontal presentation of the sonar. The level of gain selected is display in the **Horizontal** menu and on top of the tilt indicator in the upper left-hand side of the display. It has 51 selectable values numbered from 0 to 50 and may be changed in steps of 1 dB.

Vertical gain

The two lower buttons control receiver gain effecting the vertical presentation of the sonar. The level of gain selected is display in the **Vertical** menu. It has 51 selectable values numbered from 0 to 50 and may be changed in steps of 1 dB.

Range

Range controls are specified as either horizontal or vertical.



Horizontal range


The two upper buttons control the horizontal range. The range selected is displayed in the **Horizontal** menu, and on top of the tilt indicator in the upper left corner of the display.

Vertical range

The two lower buttons control the vertical range. The range selected is displayed in the **Vertical** menu.

Cursor

The cursor is used for on-screen cursor orientation and menu operation.



Menu

The **Menu** button is used for selection between **Menu** or **Full Screen** presentations. When the main menu is displayed, the echo presentation will be reduced correspondingly. In full screen presentation, the full dimension of the screen is used for the echo presentation.

When the full screen echo presentation is displayed, the cursor may be used to activate the menu field by moving it to the left or right extremes of the screen. Moving the cursor outside the menu field will hide the menu.

Select

The **Select** button is used to execute a selection. This corresponds to the left button on a standard mouse.

View

The **View** button activates the **View** pop-up menu for the selected display window. This button corresponds to the middle button on a standard mouse.

Object

The **Object** button activates the **Object** pop-up menu for the selected display window. This button corresponds to the right button on a standard mouse.

Trackball

The trackball controls the cursor. The cursor changes appearance in relation to its location on the screen:


- An **Orange** cursor in the echo field.
- An **arrow** in the menu field.
- A **negative or positive sign** at each end of the menu buttons. The negative or positive sign indicates the direction in which the corresponding parameter values will be changed when the **Select** button is pressed.

Related topics

- *Menu and full screen presentations, page 41*
- *View pop-up menu, page 70*
- *Object pop-up menu, page 72*
- *Menu buttons, page 45*

Train

The audio channel is displayed as a continuous white line. It can be trained either manually or automatically. The bearing angle is displayed in the upper right-hand corner of the display, indicated relative to the bow.



Manual

In the **Manual** mode the train left (arrow) or train right (arrow) buttons are used to direct the audio line to the desired bearing.

Auto search

In the **Auto Search** mode the sonar will automatically search within pre-set sector limits with the selected audio line designating the centre of the search. The search sector is displayed on the bearing card with two white angular symbols.

- The search sector is adjusted by pressing and holding the **Auto Search** button and simultaneously pressing the train left (arrow) or train right (arrow) buttons .
- The **Automatic Search** function is overridden when either the train left (arrow) or train right (arrow) buttons are pressed and will continue once released. The present bearing at the moment either button is released will become the centre of the search.

Position track

The **Position Track** function is only available when both a course gyro and a speed log are interfaced with the sonar system.

To track a fixed position, place the cursor over the desired location and press the **Position Track** button. A geographically fixed circle will appear on the display, and its position will automatically be tracked by the system with respect to the bearing and tilt angle.

When the **Auto Tilt** function is activated in the **Position Track** mode the tilt search centre is automatically adjusted with regard to the distance to the tracked position.

Target track

To track a target, place the cursor over the desired location and press the **Target Track** button. A circle will appear on the display and its position automatically tracked by the system using the strongest echo centred in the "window" represented by two lines on the audio line. The "window's" size may be selected by the **Track Window** button in the **Setup** menu.

The vector originating from the target's centre indicates its course and speed. The length of the vector increases relative to the target's speed. One knot is represented by a small mark on the vector. A course line can also be displayed showing the target's track.

Target tracking symbols and data are displayed with a light violet colour. In addition to the information on the **Catch data** page, the speed, course and distance for some modes are found in the lower left hand corner of the screen.

In **Manual tilt** mode, the tilt angle will automatically be adjusted with respect to the distance to the tracked target.

When the **Auto Tilt** function is activated in the **Target Track** mode, the tilt search centre is automatically adjusted with regard to the distance to the tracked position.

Note:


Manual training overrides the Target Tracking function.

Tilt

Manual tilt

In **Manual mode** the transducer may be tilted within the systems limits by pressing the **Tilt up** (arrow) or **Tilt down** (arrow) buttons. Pressing either button once changes the tilt angle in steps of 1 degree. Pressing and holding either button continuously changes the tilt angle until pressure is removed.

In the **Position** and **Target Tracking** modes, the tilt angle will automatically be adjusted to compensate for the distance to the tracked position.



Auto tilt

In the **Auto Tilt** mode the selected tilt angle forms the centre of the tilt search. The selected tilt limits are displayed on the tilt indicator by yellow lines and corresponding numerical values for both the upper and lower limits.

The centre of the tilt search sector is adjusted by pressing the **Tilt up** (arrow) or **Tilt down** (arrow) buttons. Sector limits are adjusted by pressing and holding the **Auto** button and simultaneously pressing the **Tilt up** (arrow) or **Tilt down** (arrow) buttons.

Tilt search sector limits can be incremented in steps of 1 degree to 10 degrees according to the value selected in the **Tilt** menu.

The **Auto Tilt** function responds differently with regard to the training mode selected as follows:


- **Manual training mode:** The transducer automatically changes the tilt angle after each transmission in steps within the selected limits.
- **Auto search training mode:** The transducer automatically changes the tilt angle after each complete search is performed.
- **Position and Target Tracking modes:** The tilt angle's search centre will automatically be adjusted with regard to the distance to the position being tracked. The transducer will tilt automatically in steps after each transmission.

Note:

If the stabilization system is activated, the beamformer will automatically adjust the tilt angle with regard to the vessel's motion (even if manual tilt is selected). The change in the tilt angle for the beamformer will not be shown on the tilt indicator.

Various

The buttons grouped under various are **Zoom**, **Record**, **Mute** and **Off Centre**.



Mute

The **Mute** button is not used on the SH80 sonar.

Record

The record function is used for storing either a sequence or single display picture. Sequential or single storage options are preset in the **Store/Recall** menu (available from the **Setup** menu).

If sequential store mode is selected, **Record** is used for starting and stopping the storage. If single shot storage is selected a new picture is storage each time the button is pressed.

Zoom

The zoom function magnifies an area of the display by positioning the cursor in its centre and pressing the **Zoom** button. The **Zoom** button works as a toggle switch for on/off of the zoom function.

Off centre

The **Off Centre** function moves the **Own vessel** symbol to the cursor's position on the display. This adjusts the presentation to fill the screen accordingly.

Related topics

→ *Store/Recall menu, page 65*

OPERATION

Introduction

All operation of the sonar is normally made from the Sonar Operating Panel. Optionally, a standard mouse or trackball may be connected, and the sonar can then be operated by means of the menu system alone.

This section contains a detailed description of the start and stop procedures, the principles of the menu operation, and other operational procedures for the daily use of the SH80. In order to obtain the necessary understanding of the sonar design, refer to the *System description* chapter. The various presentation formats are described in the *Display mode* chapter.

Topics

- *Maintaining the sonar, page 37*
 - *Start and stop procedure, page 38*
 - *Menu operation, page 41*
 - *Visual aids, page 49*
 - *Cosmetics, page 50*
 - *Installation of options, page 53*
 - *On-line help, page 55*
-

Note:

Remember that the SH80 transducer in its lower position reaches 1,0 meter below the vessel's hull. Maximum vessel speed in that position is 20 knots!

Related topics

- *System description, page 1*
- *Display modes, page 13*
- *Sonar Operating Panel, page 23*

Maintaining the sonar

Maintenance procedures

To ensure the best possible reliability of the SH80 sonar, it is important to follow the maintenance procedures described in the *Maintenance* chapter.

A preventive maintenance schedule is provided. It is very important that you follow this schedule, and that you log the actions thoroughly. Refer to the information in the *Maintenance* chapter.

Important when docking the vessel

Caution:

When docking the vessel, disconnect the mains plug on the Sonar Processor Unit to prevent inadvertent use of the sonar. The transducer can be damaged if allowed to transmit in air.

Note:

Refer to the information in the Maintenance chapter!

Related topics

- *Maintenance, page 150*
- *Preventive maintenance schedule, page 151*
- *Dry-docking safety measures, page 40*


Start and stop procedures

Note:

Before you start the sonar, check that the water depth is sufficient, and that the vessel's speed is within the maximum speed specified with the transducer lowered.


Start procedure

Observe the following procedure to power up the sonar.



1. Press the **Power** button on the monitor to power up the display monitor.
2. Press and hold the red **Power** button on the Sonar Operating Panel for approximately two seconds to start the sonar.
 - The green LED next to the button indicates that the sonar starts loading the program. After approximately one and a half minutes the sonar picture will be displayed.
3. Press the **Down** button to move the transducer to the lower position.
 - The green LED next to the button will flash, and an audible signal indicates that the transducer moves downwards.
 - Observe that the **TX Power: Off** button in the **Horizontal** menu starts to flash. In order to prevent inadvertent start of the transmitter, the transmit power is automatically switched off when you power up the sonar.
 - When the bottom position has been reached, the LED will illuminate continuously, the audible signal stops, and the top button in the **Status** parameter dialogue shows: **Transducer: DOWN**.
4. Set **TX Power** to **On** in the **Horizontal** menu.


This completes the normal start-up procedure.



Disconnected mains

In case of power failure, or if the mains plug on the Sonar Processor Unit has been disconnected, the sonar must be started by pressing the start switch **S101**. This switch is located behind the small front panel on the Sonar Processor Unit.

The location of the S101 switch on the front of the Sonar Processor Unit.



Design change

On sonars shipped from Simrad before August 2003, the **APC10** Sonar Processor Unit is used. This unit is also equipped with an “on/off” switch behind a front panel. It has also an additional “master on/off” switch on its rear panel. Instead of disconnecting the mains plug, this switch can be set to “off”.

Stop procedure

1. Press the **Up** button on the Sonar Operating Panel to hoist the transducer to the upper position.
 - The green LED next to the button will flash, and an audible signal indicates that the transducer is hoisted. When the upper position has been reached, the LED will illuminate continuously, the audible signal stops, and the upper button in the **Status** menu shows: **Transducer: UP.**
2. Press and hold the **Power** button approximately two seconds to switch off the sonar.
3. Check that the green LED next to the **On/off** button extinguishes.
4. Press the **Power** button on the display monitor to switch it off.

Warning:

If the sonar is switched off uncontrolled with the transducer lowered, the transducer must be raised by means of the hoist/lower switch in the Motor Control Unit, or with the hand crank.

Procedures for emergency hoisting are provided in the *Maintenance* chapter.

Dry-docking safety measures

To prevent inadvertent use of the sonar when dry-docking etc., disconnect the mains plug for the Sonar Processor Unit.

Warning:

Transmitting in air will damage the transducer!

Related topics

- *Sonar Operating Panel, Main switch. page 24*
- *Manual hoisting and lowering, page 162*
- *Status, page 134*

Menu operation

Introduction

The menu system on the SH80 sonar is designed to allow for easy and fast access to the parameters.

The menu can be removed from the screen.

Some of the parameters (for example **Range**, **Gain** and **Tilt**) can be controlled both from the button on the menu and from buttons on the Sonar Operating Panel. The parameter values shown on the menu buttons will then change according to the setting made on the panel.

It is also possible to operate the sonar with a standard computer mouse.


Screen presentations

The menu can be set up for permanent display, or available only when required for parameter alterations. The **Menu** button on the Sonar Operating Panel is used to select **Menu** or **Full Screen** presentation.

Menu presentation

In **Menu** presentation, the menu is always shown on the right hand side of the display, and the size of the echo area will be reduced.

Typical screen presentation with the menu on the right hand side




Full screen

When **Full Screen** is selected, the echo presentation is extended to cover the entire display.


Once the menu has been disabled, observe the following procedure to recall it for temporary use.

1. Use the trackball, and move the cursor to the outmost left- or right hand side on the display.
2. Observe the menu appear on top of the echo area, and that the remaining echo area is not re-scaled.
3. Move the cursor outside the menu, and observe that it disappears.

*Full screen
presentation with
the menu hidden
from view*




*Full screen
presentation with
temporary menu*



Menu structure

The menu field on the sonar display contains several different buttons, tabs and parameter dialogues.



(A) Sonar type: The upper “button” indicates the sonar in operation. You can not press this button.

(B) Mode selection: The second button is used to display the current mode. You can press this button to select a different mode.

(C) Tabs: These selections on the right hand side of the menu allows you to choose between the menus applicable for the current operational mode. The menu field will provide different tabs for each display mode. In order to select a new menu, move the cursor to the tab, and press **Select**.

(D) Active menu: The next field contains the main menu. Depending on operational mode and the menu properties, this menu can contain a number of buttons or other information.

(E) Menu button: Each menu button allows you to define the parameters for the specific function.

(F) Parameter dialogue: When a menu button is pushed, the applicable dialogue with a selection of parameters appears at the bottom of the menu.

All the tabs, menus and submenus are explained in chapter *Menu*.


Related topics

- *Menu buttons*, page 45
- *Menus overview*, page 56

Menu buttons

Each menu contains several **buttons**. Each button shows both the function and the current parameter. The majority of the buttons in each menu field have three functions.

- You can select a lower parameter value.
- You can select a higher parameter value.
- You can open the applicable dialogue.




(A) Decrease: Position the cursor on the left side the button. Observe the arrow symbol change to a **minus sign**: Decrease the parameter by pressing the **Select** button.

(B) Increase: Position the cursor on the right side the button. Observe the arrow symbol change to a **plus sign**: Increase the parameter by pressing the **Select** button.

(C) Dialogue: Position the cursor on the centre of the menu button. Observe the arrow symbol change to a **menu symbol**. Open the parameter dialogue by pressing the **Select** button. The dialogue appears in the lower part of the menu field, providing an overview of the available options.

Selecting a new parameter value

The menu system is operated by the trackball and the **Select** button on the Sonar Operating Panel.





When you have gained more experience, and have become more familiar with the available options, you will select the parameters directly from the “smart” buttons. Use the trackball to move the cursor, and position it over the button.

First method:

1. Use the trackball to move the cursor to the right or left side of the button. Observe that the cursor symbol changes.
2. Increase or decrease the option by pressing the **Select** button (A).

Second method:

1. Use the trackball to move the cursor to the middle of the button (B). Observe that the cursor symbol changes to a small menu icon.
2. Click the **Select** button (A) on the Sonar Operating Panel. Observe the parameter dialogue appearing at the bottom of the menu (C).
3. Use the trackball to move the cursor, and press the **Select** button on the Sonar Operating Panel to choose the new setting (D).
4. Press **Close** (E) to close the parameter dialogue.



The parameter value shown in the button is operational even without closing the parameter dialogue. This makes it easy to test the effect of each parameter setting. Note that the transceiver related parameters will first be in operation in the next ping.

Stored parameters

Default settings

The parameter settings identified with an asterisk (*), indicates the normal setting known to perform well under normal conditions. If you get “lost“ in the parameter settings, the **Default settings** function will bring up these normal parameters.

The **Default setting** function is available on the **Setup** menu, and a dedicated parameter dialogue is used.

User settings

The **User setting** function allows you to store chosen parameter settings for various types of fisheries, or your favourite individual settings. The saved settings can easily be retrieved into the operational sonar.

The **User setting** function is available on the **Setup** menu, and a dedicated parameter dialogue is used.

Parameter memory

The SH80 sonar is equipped with a battery powered memory. This function will cause the sonar to remember all the selected parameter settings, even when the sonar is switched off.

Related topics


- *Default Settings, page 96*
- *User Settings, page 145*

Visual aids

Common information on the display

In nearly all display modes, the following information is provided.

- The **Tilt indicator** is displayed in the upper left corner. The selected range and gain is shown on top of this indicator.
- The orange text in the upper right hand corner of the echo area shows the bearing, distance and depth of the cursor.
- If a GPS is connected to the sonar, the geographical latitude and longitude for the cursor location will also be displayed.



(A) *Tilt indicator*

(B) *Selected range and gain, and current user setting (if used)*

(C) *Geographical position*

(D) *Bearing, distance and depth of the cursor*

Moving the boundary lines


In most display modes with multiple views, the size of each view can easily be modified by moving the boundary line between the views.

Locate the cursor on the boundary line, press and hold **Select** and move the cursor with the **Select** button depressed. When the button is released, the boundary line will be located at the new cursor position.

Cosmetics

The choices in the **Cosmetics** menu allows you to enable or disable a range of visual aids in the sonar picture.

*Sonar display with
Bearing Card (A)
Wind Marker (B)
and Distance Rings
(C) enabled*




(A) The **Bearing Card** shows the current bearing relative to the vessel. The markers are shown as short white lines for every 10th degree along the outer circle of the sonar view.

(B) The **Wind Marker** is shown as an arrow drawn from the **Compass Card** pointing towards the centre of the display. If a wind sensor is connected to the sonar, it will automatically show the current wind direction. Otherwise, the wind direction may be entered manually. The arrow has a fixed length, it is not scaled according to the current wind speed.

(C) The **Distance Rings** are shown as dotted rings, each with a range readout on the left hand side of the display centre.

Sonar display with Variable Range Marker (D), Compass Card (E) and Vertical Ring (F) enabled. The Vertical Ring reflects the vertical range setting.




(D) The **VRM** (Variable Range Marker) consists of an adjustable range ring with range readout. It can be used for any type of distance marking relative to the vessel. To adjust the marker, locate the cursor on the marker ring, press **Select** and move the cursor with the **Select** button depressed. When the button is released, the variable range marker radius will be moved to the new cursor position.

(E) The **Compass Card** is shown as short yellow lines for every 10th degree along the outermost circle of the sonar view. A triangle symbol indicates each 45th degree. It has labels indicating North, East, South and West. It is updated when the heading of own ship has changed more than 1 degree, if the display mode is **Bow up**.

(F) The **Vertical Ring** shows the selected range of the vertical slice as a full circle in the horizontal presentation. This is an indication of which distance a target should be presented in the vertical view. The **Vertical Ring** will only be visible in those modes that support a vertical slice. In other modes, the button will give no response.

Sonar display with Vertical Depth dividers (G), Track history with Minute Markers (H) and Bow Marker (I) enabled.



(G) The **Depth dividers** are horizontal dotted lines used to visualize the depth steps in the vertical slices.

(H) The **Minute markers** are shown as small circles on the track history of the ship.

(I) The **Bow Marker** is heading marker. It is a dotted line drawn from the bow of your own ship in the same direction as the vessel's current heading.

Related topics

- *Track History, page 139*
- *Wind Direction, page 146*
- *Cosmetics, page 64*

Installation of options

The following options can be installed on the SH80 sonar:

- Triple- or multiple-frequency
- Scientific output

Note that all options are pre-programmed into the standard sonar version, and that Simrad offer a 1 month free test period for certain options. When ordering a permanent option installation, a code word will be released from Simrad.

For a free test, or permanent option installation, use the following procedure:

1. Select the **Setup** menu.
2. Press the **Test** button to activate the **System test** menu.
3. Press the **Installation Menu** button.
4. Observe that the installation menu bar is shown on the top of the screen.

Installation I/O Setup OwnShip Environment Options

5. Press **Options** on the menu bar.
6. Select **Install Options** to activate the **Install options** parameter dialogue.

The following parameters are available in the **Install options** dialogue.

HWID - This field displays the unique 12-character Hardware Identification code. This code is different for each SH80 sonar. Simrad uses this code to generate the 32-characters code word used for a permanent option installation.

Try - A number of buttons, where each will start the 1 month free test period for the chosen option.

Note:

If any time or date adjustments are made during the test period, the option will be closed.

Add License String - This button is used for permanent installation of the chosen option. When you press the button, this will activate the **On-Screen Keyboard** used to type the required 32-character code word.



Procedure:

1. Press **Add License string**.
2. Place the cursor in the text field.
3. Type the code word.
4. Check that the 32 characters is entered correctly into the text field
5. Press the **Apply License String** button.
6. Restart the sonar.
7. Check if the actual option is opened and operable.

Related topics

→ *System description, Options, page 6.*

On-line help

The SH80 sonar is equipped with a comprehensive on-line help system. It is available from all the parameter dialogues and menus by pressing the **Help** button.

Help is provided in two levels: **On-line** and **Free**.

Once pressed, the first Help text will appear in the bottom of the menu. This is the **On-line** text. It is short, context sensitive, and designed not to interrupt the operation of the sonar. To close the **Help** dialogue, press the **Close** button.

To access more detailed information, press the **Free** button. This will open the complete interactive manual. It contains the same information as the printed *Operator manual*, but the information is accessed using the menu on the left hand side and interactive links throughout the document.

Press **Free** in the bottom left corner to return to the small **On-line** dialogue, or **Close** to exit the interactive manual.

Note that if you press **Close**, the large interactive manual will automatically reappear the next time you press a **Help** button.

MENU DESCRIPTIONS

Introduction

This section provides a detailed description of the complete menu system for the SH80 sonar, and contains the chapters listed below. For an explanation of how to operate the menu system, refer to the section *Menu operation*.

The SH80 comprises a large number of different menus on several levels. Menus are selected by pressing their respective tabs on the right side, and the appearance of menus and tabs depends on the chosen operation mode and the current settings. The menu types are organised as follows:

- **Active menus** - relevant for each of the display modes, available at all times selectable by the appropriate tab.
- **Temporary menus** - “sub-menus” activated by a button in one of the **Active** menus.
- **Pop-up menus** - activated by the **View** and **Object** buttons on the Sonar Operating Panel, or the middle and right mouse button (provided a mouse is installed).
- **View menus** - activated in the **View** pop-up menu.
- **Messages** - presents system messages.

Topics

- *Active menus, page 57*
- *Temporary menus, page 63*
- *Pop-up menus, page 69*
- *View menus, page 74*
- *Messages, page 78*

The chapter *Menu structure* gives a description of the menu system configuration with references to more detailed descriptions of all the menu. Any selections you do in the menus will bring up the parameters available for the chosen setting. The *Alphabetical list of parameters* is a useful aid to find a description of a particular parameter of all available parameters incorporated in the SH80 sonar system.

Related topics

- *Menu operation, page 41*
- *Menu structure, page 44*
- *Alphabetical list of parameters, page 84*

Active menus

Overview

The **Active menus** are those relevant for the different operational modes. The menus are shown with vertical selector tabs on the right hand side, and each menu can easily be selected using the trackball and the **Select** button on the Sonar Operating Panel. All menus have access to on-line help through a **Help** button.

Topics

- *Horizontal, page 58*
- *Vertical, page 59*
- *Display, page 60*
- *Setup, page 61*
- *Objects, page 62*

Horizontal

The **Horizontal** menu is used to control the horizontal presentations. The parameters chosen are present in all display modes. When a horizontal parameter setting is selected and defined in one mode, the chosen settings will automatically be applied to all modes.

Range: 500 m	Horizontal
Tilt: +00°	
Bearing: 000°	
Gain: * 30	
Pulse Form: *AUTO	
TX Power: OFF	
Beam: *NARROW	
Frequency: * 116 kHz	
TVG: *AUTO	
RCG: *MEDIUM	
PP Filter: *MEDIUM	
Noise Level 0.0 dB	
Help...	

Parameters

- *Range, page 121*
- *Tilt, page 137*
- *Bearing, page 88*
- *Gain, page 105*
- *Pulse Form, page 119*
- *Tx Power, page 143*
- *Beam, page 86*
- *Frequency, page 104*
- *TVG (Time Variable Gain), page 142*
- *RCG (Reverberation Controlled Gain), page 123*
- *PP Filter, page 118*
- *Noise Level, page 115*

The **Help** button opens the on-line help.

The **Horizontal 2** menu is identical to the **Horizontal** menu. It is used during Dual mode operations.

Vertical

The **Vertical** menu is only shown in modes with a vertical slice function. All relevant settings, except the **TX Power**, can be selected separately for the vertical modes independent of the horizontal settings. When any vertical setting is selected and defined in one mode, the setting will be applied to all vertical modes.

Range: 500 m	
Bearing: 000 °	
Gain: * 30	
Pulse Form: *AUTO	
TX Power: OFF	
Frequency: * 116 kHz	
TVG: *AUTO	
RCG: *STRONG	
PP Filter: *MEDIUM	
Help...	

Parameters

- *Range, page 121*
- *Bearing (Vertical), page 91*
- *Gain, page 105*
- *Pulse Form, page 119*
- *Tx Power, page 143*
- *Frequency, page 104*
- *TVG (Time Variable Gain), page 142*
- *RCG (Reverberation Controlled Gain), page 123*
- *PP Filter, page 118*

The **Help** button opens the on-line help.

Display

The **Display** menu is shown in all display modes, and provides access to parameters controlling the visual presentation of the sonar views. Some of the choices on the menu are simple on/off buttons.



Parameters

Full Screen - Replica of the **Menu** button on the Sonar Operating Panel.

Audio Mute - Replica of the **Mute** button on the Sonar Operating Panel.

Resolution - Select 16 or 64 colours in the display presentation. The chosen resolution is shown in the colour bar below the button.

- *Palette, page 116*
- *Colour Threshold, page 92*
- *Colours, page 93*
- *Panel backlight, page 117*
- *Mode buttons, page 113*
- *Language, page 109*
- *Units, page 144*
- *Cosmetics, page 64*
- *Bearing, page 90*
- *Menu, page 110*

The **Help** button opens the on-line help.

Setup

The **Setup** menu is shown in all display modes, and gives access to parameters controlling the processing and algorithms in the sonar system. It also provides access to specific system parameters and functions such as **Test** and **Store/Recall**.



Parameters

- *Store/Recall, page 65*
- *Test, page 66*
- *Gear, page 106*
- *School, page 127*
- *Dead reckoning, page 95*
- *Stabilizer, page 133*
- *Movements, page 114*
- *Track Window, page 140*
- *Wind direction, page 146*
- *Wind speed, page 147*
- *Sort Modes, page 68*
- *External Sync, page 102*
- *Scientific Output, page 128*
- *Fish Alarm, page 103*
- *User Setting, page 145*
- *Default Setting, page 96*

The **Help** button opens the on-line help.

Note that the **Wind speed** button will disappear from this menu if the **Scientific Output** option is installed.

Objects

The **Objects** menu is shown in all display modes, and displays the range (**R**), bearing (**B**) and depth (**D**) to all selected objects.

ID	R[m]	B[°]	D[m]
AT 1	1002	061	0
Ci	891	082	0
M 1	563	049	0
OS	44	180	0
PT	660	031	0

Objects

Delete

Delete All

Help...

The identification (ID) abbreviations for the different objects are:

AT - Automatic Target Track Marker

Ci - Circle Marker

M - Target Marker

OS - Own Ship Marker

PT - Position Track Marker

F - Radio buoy marker (if a GPS buoy system is connected)

The number behind the ID abbreviation refers to the same number on the object in the sonar presentation. The **P** after the Automatic Target Track Marker indicates the priority level where the audio channel is locked to the target.

When selecting an object in the list, a list with all the available object data will be shown below the **Objects** menu.

When selecting a **Target Marker**, **Automatic Target Track Marker** or a **Radio Buoy Marker** in the list, a dotted bearing line from the vessel to the marker will be presented.

To delete an object, select the relevant marker in the list, and press the **Delete** button in the lower part of the menu. Pressing the **Delete All** button will delete all objects.

The parameters for each marker are shown in the **Inspect Object** parameter dialogue.

Related topics

→ *Inspect Object*, page 108

Temporary menus


The **Temporary** menus are those selected from the active menus. They are also shown with vertical tabs on the right side of the menu, and can easily be selected by the trackball and the **Select** button. The **Temporary** menus must however be removed manually using the **Close** button in the bottom of menu. All **Temporary** menus have access to on-line help through a **Help** button.

Topics

- *Cosmetics, page 64*
- *Store/Recall, page 65*
- *Test, page 66*
- *Sort Modes, page 68*

Cosmetics

The **Cosmetics** menu is activated by pressing the **Cosmetics** button in the **Display** menu. It provides access to various parameters controlling the appearance of the sonar picture. All the functions - except **Track history** - are on/off buttons.



Parameters

- *Slant Range / True Range, page 131*
- *Bearing Card, page 50*
- *Compass Card, page 51*
- *Distance Rings, page 50*
- *VRM (Variable Range Marker), page 51*
- *Bow Marker, page 52*
- *Track History, page 139*
- *Minute Marker, page 52*
- *Wind Marker, page 50*
- *Vertical Ring, page 51*
- *Depth dividers, page 52*

The **Close** button closes this menu. The **Help** button opens the on-line help.

Store/Recall

The **Store/Recall** menu is activated by the **Store/Recall** button in the **Setup** menu.

The **Store/Recall** menu is used to store single display pictures or a sequence of pictures. The stored pictures can easily be recalled for evaluation or comparing schools.

Parameters

Store - This is the “record” button to start the storage sequence.

Delete - Deletes the highlighted display picture.


Rename - Provides an on-screen keyboard to rename the stored picture.

Print - Allows you to print the stored picture to the default printer (if any).

The following other parameters are available:

- *Store, page 135*
- *Store Mode, page 135*
- *Recall, page 124*
- *Recall Mode, page 124*

The **Close** button closes this menu. The **Help** button opens the on-line help.



System test

The **System test** menu is activated by the **Test** button in the **Setup** menu.

The **System test** menu provides several test routines available to perform operational and functional tests. These tests are designed only to be carried out by qualified service engineers.



Parameters

Test Configuration - This function is only to be activated by qualified service engineers.

Test Function - This function is only to be activated by qualified service engineers.

Toggle TxPower - This function is only to be activated by qualified service engineers.

Test Beam - This function is only to be activated by qualified service engineers.

Echo Level - This button provides a readout of the current noise in the waters surrounding the vessel. This noise is caused by air bubbles, water flow and mechanical disturbances from hull and engine. In order to obtain the best possible sonar result, the noise level readout should be as close to 0.0 dB as possible.

Roll - This is not a button, it is a readout from the sensor of the actual roll value at the time of the last transmission.

Pitch - This is not a button, it is a readout from the sensor of the actual pitch value at the time of the last transmission.

TRU Temp- This button provides a readout of the current temperature inside the Transceiver Unit. If the temperature rises to an unacceptable level, an alarm will be given.

Interpolation - This is a built-in software function that may give a more realistic presentation of the echos.

Message bar - This button opens the **Message bar** parameter dialogue, which allows you to monitor operational messages from the sonar.

Installation menu - This button opens the **Installation menu** on the top of the display. This menu is used during installtion of the sonar, and information about this is provided in the *Installation manual*.

About - This button provides access to a small information dialogue providing the current software version.


The **Close** button closes this menu. The **Help** button opens the on-line help.

Related topics

- *Message bar, page 111*
- *About, page 85*

Sort Modes

The **Sort Modes** menu is activated by the **Sort Modes** button in the **Setup** menu.



The **Sort Modes** menu is used to select the display modes to be activated by the four **Mode** buttons on the Sonar Operating Panel. The four upper display modes in this menu will always be the four modes selectable by the four **Mode** buttons in the order they are sorted.

In order to sort the modes, select the actual mode and use the **Move Up** and **Move Down** buttons to place it in the wanted position.

When the modes are organized in the requested order, press the **Apply** button to store the information.

Related topics

- *Mode buttons, Operator Panel, page 27*
- *Mode buttons, page 113*

Pop-up menus

The **pop-up menus** are accessed using the **View** and **Object** buttons on the Sonar Operating Panel, or the middle and right mouse buttons if an optional mouse is installed. Each button will present a small menu, and it appears at the cursor's current location. To make a selection, use the trackball and the **Select** button, or the mouse.

Topics

- *View, page 70*
- *Object, page 72*

Related topics


- *View and Object buttons, page 30*

View pop-up

The **View** pop-up menu is accessed using the **View** button over the trackball on the Sonar Operating Panel or the middle mouse button if an optional mouse is installed.



When activating the pop-up menu in the **Catch Data** view, it will display the following reduced menu.



Parameters

Set New Display Centre - When this function is selected, the new display centre is moved to the cursor's position where the **View** menu was activated.

Ship To Centre - When this function is selected, the own ship symbol is moved to the centre of the view.

Zoom - The zoom function magnifies an area of the display by positioning the cursor in its centre and pressing the **Zoom** button. The zoom button works as a toggle switch for on/off of the zoom function.

Erase Echoes - When this function is selected, all echoes displayed on the sonar view will be deleted.

Synchronize - This function is not operational on the SH80 sonar. For synchronization to external equipment, refer to the **Setup** menu.

Make Same Size - When this function is selected, window areas tiled vertically will acquire the same width.

Grey scale data - This command changes the display from a colour presentation to a black-and-white. The number of shades of grey and the number of different colours used will be the same. The **Grey scale data** command can be selected for singular sonar views independent of each other.

View Menu - When this function is selected menus will be displayed according to the view in which the cursor is situated. Several different **View** menus are available.

Related topics

- *View menus, page 74*
- *Setup menu, page 61*
- *View button, page 30*

Object pop-up


The **Object** pop-up menu is accessed using the **Object** button over the trackball on the Sonar Operating Panel, or the right mouse button if an optional mouse is installed.



This pop-up menu is mainly used when you operate the sonar from an optional mouse, as most of the functions on it can be selected directly on the Sonar Operating Panel. Note that the cursor related selections in the **Object** pop-up menu use the cursor position where the pop-up menu was activated.

Activating the **Object** pop-up menu whilst positioning the cursor over a defined object on the display, it will display the following additional parameters.

- Inspect <object>
- Delete <object>
- Make <object> priority target



Parameters

Basic functions - These choices provide the same functions as their respective buttons on the Sonar Operating Panel.

- Target Track
- Position Track
- Set Marker
- New Own Ship Marker
- Circle Marker
- Gear Symbol

New ruler - When this function is selected, a straight line is drawn from the current cursor position (where the **Object** pop-up menu was selected) to another selectable position. The ruler will display range and bearing between the two points. To remove the ruler, click on it with the right mouse button, and select **Remove ruler** from the **Object** pop-up menu.

Inspect ruler - If you click on an existing ruler, the **Ruler** parameter dialogue will appear under the menu. This dialogue will provide information about the selected ruler, and it allows you to remove the ruler with a **Delete** button.

Inspect <object> - When this function is selected, the object parameters are displayed at the bottom of the menu in the **Inspect Object** parameter dialogue.

Delete <object> - When this function is selected, the object will be removed. This is the same function as provided by the **Objects** menu.

Make <object> Priority Target - This function can be used to give priority to an “old” target tracking symbol, which locks the audio channel on the target.

Related topics

- *Ruler, page 125*
- *Inspect Object, page 108*
- *Object button, page 30*

View menus

The **View** menus are activated from the **View** pop-up menu, which again is accessed using the **View** button on the Sonar Operating Panel or the middle mouse button. The **View** menus are shown with vertical tabs on the right hand side, and the menus can easily be closed using the **Close** button in the lower part of each menu. All menus have access to on-line help through a **Help** button.

Topics

- *Geo View, page 75*
- *Vertical View, page 76*
- *Catch View, page 77*


Related topics

- *View pop-up menu, page 70*
- *View button, page 30*

GeoView

The **GeoView** menu is activated by pressing the **View** button on the Sonar Operating Panel or the middle mouse button in any horizontal view, and then selecting **View menu** in the **View** pop-up.

The **GeoView** menu provides control of selected parameters related to the current data displayed in the horizontal view; **Scale** and **Target track**. It also provides you with a button to reposition the vessel symbol.



Parameters

Ship to centre - Moves the ship symbol to the centre of the view.

→ *Scale, page 126*

→ *Target Track, page 136*

The **Close** button closes this menu. The **Help** button opens the on-line help.

The **GeoView2** menu is also available. This is identical to the **GeoView** menu, and used during dual mode operations.

Related topics


→ *View pop-up menu, page 70*

→ *View button, page 30*

VerticalView

The **VerticalView** menu is activated by pressing the **View** button on the Sonar Operating Panel or the middle mouse button while positioning the cursor in any of the vertical views, and then selecting **View menu** in the **View** pop-up.

The **VerticalView** menu provides control of selected parameters related to the current data displayed in the vertical view; **Zoom**, **Zoom Scale** and **Data Source**.



Parameters

- *Zoom, page 148*
- *Zoom Scale, page 149*
- *Data Source, page 94*
- *Direction Indicator, 97*

Note that **Direction Indicator** is only available when **Indicator** is selected in the **Data Source** menu.

The **Close** button closes this menu. The **Help** button opens the on-line help.

Related topics


- *View pop-up menu, page 70*
- *View button, page 30*

CatchView

The **CatchView** menu is activated by pressing the **View** button on the Sonar Operating Panel or the middle mouse button while the cursor is located in the **Catch** view, and then selecting **View menu** in the **View** pop-up.

The **Catch** view is only available in the *270°/Vertical*, *True Motion/Vertical* and *Bow up/Vertical* display modes, and you may need to hide the menu to see it.

The **CatchView** menu provides control of selected parameters related to the current data displayed in the **Catch** view.



Parameters

→ *Range, page 122*

The **Close** button closes this menu. The **Help** button opens the on-line help.

Related topics

→ *View pop-up menu, page 70*

→ *View button, page 30*

Messages

Message categories

When necessary, the sonar will provide you (or your service engineer) with operational and technical messages. These messages are sorted into four categories; *Warnings*, *Operator alarms*, *System alarms* and *Errors*.

In order to access the messages, the **Message bar** must be enabled. This function can be set to activate itself when necessary. The **Message Bar** is located at the bottom of the display, and it contains four buttons, one for each category of messages. These buttons give an overview of the number of unread messages currently in the system. Each of the four buttons gives access to a dialogue where each message can be read, acknowledged and deleted. When no messages are present, the four buttons are grey. When one or more unread messages exists, the **Warning** and **Operational Alarm** buttons are yellow, while the **System Alarm** and **Error** buttons are red.



Topics

- *Warnings, page 79*
- *Operator alarms, page 80*
- *System alarms, page 81*
- *Errors, page 82*

Related topics


- *Message Bar, page 111*

Warnings

The **Warnings** menu is activated from the **Warnings** button in the **Message bar**.

The **Warnings** menu displays the warning messages issued by the sonar. Each warning is identified with time of issue and a heading. Additional information is found in the small text field below the message list. The top of the message list with the most recent messages is always displayed when the dialogue is opened. Acknowledged messages are displayed in grey.

Use the trackball and select individual messages with the **Select** button on the Sonar Operating Panel.



Parameters

Ack(knowledge) - Press this button to acknowledge the selected message.

Delete - Press this button to delete the selected message.

The **Close** button closes the menu. The **Help** button opens the on-line help.

Related topics


- *Message Bar, page 111*
- *Trackball and Select button, page 30*

Operator alarms

The **Operator alarms** dialogue is activated from the **Op.Alarms** button in the **Message bar**.

The **Operator alarms** menu displays the alarms issued by the sonar. Each alarm message is identified with time of issue and a heading. Additional information is found in the small text field below the message list. The top of the message list with the most recent messages is always displayed when the menu is opened. Acknowledged messages are displayed in grey.

Use the trackball and select individual messages with the **Select** button on the Sonar Operating Panel.



Operator Alarm parameters

Ack(knowledge) - Press this button to acknowledge the selected message.

Delete - Press this button to delete the selected message.

The **Close** button closes the dialogue. The **Help** button opens the on-line help.

Related topics


- *Message Bar, page 111*
- *Trackball and Select button, page 30*

System alarms

The **System alarms** dialogue is activated from the **Sys.Alarms** button in the **Message bar**.

The **System alarms** dialogue displays the alarms issued by the sonar. Each alarm message is identified with time of issue and a heading. Additional information is found in the small text field below the message list. The top of the message list with the most recent messages is always displayed when the dialogue is opened. Acknowledged messages are displayed in grey.

Use the trackball and select individual messages with the **Select** button on the Sonar Operating Panel.



Parameters

Ack(knowledge) - Press this button to acknowledge the selected message.

Delete - Press this button to delete the selected message.

The **Close** button closes the dialogue. The **Help** button opens the on-line help.

Related topics


- *Message Bar, page 111*
- *Trackball and Select button, page 30*

Errors

The **Errors** dialogue is activated from the **Errors** button in the **Message bar**.

The **Errors** menu displays the alarms issued by the sonar. Each error message is identified with time of issue and a heading. Additional information is found in the small text field below the message list. The top of the message list with the most recent messages is always displayed when the menu is opened. Acknowledged messages are displayed in grey.

Use the trackball and select individual messages with the **Select** button on the Sonar Operating Panel.



Parameters

Ack(knowledge) - Press this button to acknowledge the selected message.

Delete - Press this button to delete the selected message.

The **Close** button closes the dialogue. The **Help** button opens the on-line help.

Related topics

- *Message Bar, page 111*
- *Trackball and Select button, page 30*

PARAMETERS

About parameter dialogues and help

This chapter describes all the parameter dialogues accessed from the menu system.

When a parameter is selected, the available choices are shown in the dialogue below the menu. The setting is then made using the available buttons or lists. Several levels are frequently used to select the parameters.

Note that:

1. In many cases you will not need to open the parameter dialogue, as you can control the settings directly on the menu button.
2. The parameter is selected and activated by the sonar once it is highlighted in the dialogue. The operational changes can thus be investigated from within the dialogue without closing it.
3. The **Close** button will always close the dialogue.
4. The **Help** button will always provide short-form context sensitive help. This help text will appear on top of the parameter dialogue, and you need to press **Close** to return.

In the **Help** window, you can also press **Free** to access to full interactive manual. This may not be available in all modes, as it will block the view of the sonar echoes.

Once the interactive manual has been accessed, you need to press **Free** to reduce the large help window back to short-form presentation. If you press **Close** in the interactive manual, the manual will automatically appear next time you press **Help** in a parameter dialogue.

The menu settings marked with an asterisk, indicate the normal setting which perform well under normal conditions. If one got lost in the menu settings, a **Default Settings** function will bring up these normal settings.

After experience, when the contents of the menus are better known, the increase/decrease function on the actual menu button can be used directly without selecting the submenu.

Alphabetical list

The following is an overview of available parameters incorporated in the SH80 sonar system.

- *About, page 85*
- *Beam, page 86*
- *Bearing, page 88*
- *Bearing (Display), page 90*
- *Bearing (Vertical), page 91*
- *Colour Threshold, page 92*
- *Colours, page 93*
- *Data Source, page 94*
- *Date and time, page 138*
- *Dead Reckoning, page 95*
- *Default setting, page 96*
- *Direction Indicator, page 97*
- *Edit gear (Purse), page 98*
- *Edit gear (Trawl), page 99*
- *Edit school, page 101*
- *External synchronisation, page 102*
- *Fish alarm, page 103*
- *Frequency, page 104*
- *Gain, page 105*
- *Gear, page 106*
- *Heading, page 107*
- *Inspect object, page 108*
- *Language, page 109*
- *Menu, page 110*
- *Message Bar, page 111*
- *Mode, page 112*
- *Mode buttons, page 113*
- *Movements, page 114*
- *Noise Level, page 115*
- *Palette, page 116*
- *Panel backlight, page 117*
- *PP Filter, page 118*
- *Pulse Form, page 119*
- *Range, page 121*
- *Range (CatchView), page 122*
- *RCG, page 123*
- *Recall, page 124*
- *Recall Mode, page 124*
- *Ruler, page 125*
- *Scale, page 126*
- *School Data, page 127*
- *Scientific Output, page 128*
- *Search Sector, page 129*
- *Search Step, page 130*
- *Slant Range, page 131*
- *Speed, page 132*
- *Stabilizer, page 133*
- *Status, page 134*
- *Store, page 135*
- *Store Mode, page 135*
- *Target Track, page 136*
- *Tilt, page 137*
- *Time and date, page 138*
- *Track History, page 139*
- *Track Window, page 140*
- *Transducer, page 141*
- *True range, page 131*
- *TVG, page 142*
- *Tx Power, page 143*
- *Units, page 144*
- *User Setting, page 145*
- *Wind Direction, page 146*
- *Wind Speed, page 147*
- *Zoom, page 148*
- *Zoom Scale, page 149*

About


The **About** parameter dialogue is accessed from the **System test** menu.



The **About** dialogue is only used to provide information about the current software version. In addition, the **Versions** button opens a small text document with detailed version information. This information is not intended for operational use.

Beam

The **Beam** parameters are accessed from the **Horizontal** menu.




The **Beam** command enables you to select the vertical beam width in the horizontal presentation. The beam selection can be made manually, or controlled automatically by the selected range.

The **Wide** beam is designed to be used with shorter ranges in order to obtain a larger vertical coverage. This makes the sonar less “tilt dependent” in the catching phase.

The **Normal** beam is designed to be used for the medium ranges.

The **Narrow** beam is provided for the longer ranges. The focused narrow beam has the highest source level, which increases the detection range.



(A) = Wide (B) = Normal (C) = Narrow

In the **Auto** mode, the beam will change automatically defined by the range selections made by the **Wide** and **Normal** buttons.


The following buttons can be used.

Wide - This button is used to select the upper range for the wide beam width in **Auto** mode. For ranges higher than this selection, the beam will automatically switch to **Normal** or **Narrow**, depending on the current selection for the **Normal** button.

Normal – This button is used to select the upper range for the normal beam width in **Auto** mode. For ranges higher than this selection, the beam will automatically switch to **Narrow**, which is indicated by a grey and unoperable **Narrow** button.

Bearing (Horizontal)

The **Bearing** parameters are accessed from the **Horizontal** menu.



The **Bearing** of the audio channel is normally controlled from the Sonar Operating Panel. The selected bearing is shown with a continuous white line pointing out from the transducer position. This line can be trained manually or automatically in any position. The angle readout on the bearing button can be selected to be ± 180 degrees relative to the bow, or absolute (relative north).

Left/Right arrow

Click to train the audio channel one degree. The current bearing is shown above. Click **Absolute** or **Relative** to set the readout to show an absolute value (relative to north) or show the bearing ± 180 degrees relative to the bow.

Search Step

This button opens a new parameter dialogue, which allows you to select the search step angle. This value defines how many degrees the search beam shall move for each transmission in the **Auto Search** mode.

Search Sector

This button opens a new parameter dialogue to select the active audio search sector. This sector can be adjusted between 22 and 360 degrees directly with the increase/decrease button function, or by the two buttons in the **Search Sector** dialogue. The search sector limits are shown on the outer part of the echo circle with two white angular symbols.

Absolute/Relative

Click **Absolute** to set bearing of the audio channel to be relative to true north. Click **Relative** to set the bearing to be relative to the vessel's bow.

Manual/Auto

In **Manual** mode, the audio channel can be trained continuously in either direction by pressing the two arrow buttons in the **Train** field on the Sonar Operating Panel. In **Auto** mode, the sonar will automatically perform search within the selected **Search Sector** using the steps defined.

More information about the **Auto Search** program are provided in the *Sonar Operating Panel* description.

Related topics

- *Auto Search, page 32*
- *Search Step, page 130*
- *Search Sector, page 129*

Bearing (Display)

The **Bearing** button is located in the **Display** menu.

This is simply a selector switch. Click on the button to select **True north** or **Relative ship**. Certain bearing data will change their values accordingly.

Bearing: True North

Bearing: Relative Ship

The following bearing data will change when you switch between the two settings:

- Cursor bearing
- Markers bearing in the **Objects** menu
- Target positions in the catch data views


Note that there are no indication on any of these readouts to identify them as relative or true.

All other bearing data remain permanent, and will not change when you select relative or true bearing.

- Wind direction - always relative to true north
- Audio line - always relative to the ship's heading
- Ship's current heading - always relative to true north
- Target's current heading - always relative to true north

Bearing (Vertical)

The **Bearing (Vertical)** parameter is accessed from the **Vertical** menu.



This dialogue allows you to train the audio channel bearing manually. The **Bearing** of the audio channel is normally controlled with the **Train** buttons on the Sonar Operating Panel. The bearing of the vertical slice, which is presented by the white audio line in the horizontal picture, may also be trained by the **Bearing** button in the **Horizontal** menu.

The following options are available:

- (minus button) - Train left.

+ (plus button) - Train right.


More information about the **Train** control is provided in the *Sonar Operating Panel* chapter.

Related topics

→ *Train control, page 32*

Colour Threshold

The **Colour Threshold** button is located on the **Display** menu.




The **Colour Threshold** function is used to reduce the number of echo colours on the display.

The strength of the echoes is indicated with a scale of 16 or 64 colours. A weak echo has a cold colour (blue), medium echoes have warmer colours (green, yellow) and strong echoes are shown with the warmest colours (orange, red). If desired, the number of colours may be reduced. When you do this, the sonar will start with the colour indicating the weakest echoes. Therefore, by reducing colours, the maximum detection range will be reduced, because all echoes will normally appear as weak echoes at long ranges.

Colours

The **Colours** button is located in the **Display** menu.



The colour strength of the echo presentation can be selected with three different colour scales. Under normal conditions, the **Normal** colours will give the best dynamic in the echo presentation, while **Strong** colours are preferred for weaker echoes.

Do not confuse this parameter with the **Colour Threshold** setting.


Related topics

→ *Colour Threshold, page 92*

Data Source

The **Data Source** button is located in the **Vertical View** menu.

The **Vertical View** menu is activated by pressing the **View** button on the Sonar Operating Panel (or the middle mouse button) while positioning the cursor in any of the vertical views, and then selecting **View menu** on the **View** pop-up menu.



The **Data Source** parameter is used to select the bearing source of the vertical views.

Audio - The vertical slice will follow the trainable audio channel.

Indicator - The bearing of the vertical slice can be adjusted independent of the Audio channel.

In addition, the vertical slice may be selected to three fixed settings: **Forward**, **Aft**, or **Athwart**.

Dead Reckoning

Dead Reckoning is accessed from the **Setup** menu.

Dead Reckoning is used to improve the position of the historical track line from the vessel, relative to the actual position of the drifting fishing gear.

Dead Reckoning: OFF

When **OFF**, the vessel movement and track line will be calculated from the GPS data, which then will be relative to the bottom.


Dead Reckoning: ON

When **ON**, the gyro and speed log are used to positioning the vessel relative to the water.

In order to get correct dead reckoning, a doppler speed log must be connected to the sonar.

Default Setting

Default Setting is accessed from the **Setup** menu.




This function makes it possible to delete all the parameters currently saved in the sonar's memory, and re-install those defined by Simrad instead; the factory default settings. These default settings are identified with an asterisk in the different parameter dialogues and menus, and will perform well under normal conditions.

Direction Indicator

The **Direction Indicator** is accessed from the **Vertical View** menu when **Data Source** is set to **Indicator**.

The **Vertical View** menu is activated by pressing the **View** button on the Sonar Operating Panel (or the middle mouse button) while positioning the cursor in any of the vertical views, and then selecting **View menu** on the **View** pop-up menu.




This feature allows you to train the vertical slices independent of the audio channel. The **Direction Indicator** is shown in the horizontal presentation as a yellow dotted line.

Related topics

→ *Data Source, page 94*

Edit Gear (Purse)

The **Gear** parameter dialogue is accessed on the **Setup** menu. Each of the available options in the **Gear** dialogue can be edited using the **Edit** button. When a purse has been selected, this parameter dialogue is provided.



Net Configuration: Medium Purse		
Depth: 200 m		
Length: 1000 m		
Throw Side: Starboard		
Close		Help...

These parameters allows you to define the depth and the length of your purse seine, as well as which side of the vessel it is positioned.

Depth

This function allows you to enter the depth of your purse seine. When the **Gear** symbol is selected, the depth of the purse seine will be shown on all vertical views.

Length

This function allows you to enter the length of your purse seine. When the **Gear** symbol is selected, the seine circle will be shown in correct size. A dedicated parameter dialogue is used to make this setting.

Throw Side


This function is used to position the seine circle on the port or starboard side of the vessel. A dedicated parameter dialogue is used to make this setting.

Related topics

- *Gear, page 106*
- *Sonar Operating Panel; Gear, page 25*

Edit Gear (Trawl)

The **Gear** parameter dialogue is accessed on the **Setup** menu. Each of the available options in the **Gear** dialogue can be edited using the **Edit** button. When a trawl has been selected, this parameter dialogue is provided.



Trawl Configuration: Trawl3	
L Bottom Trawl	
Distance A: 0 m	
Depth A: 0 m	
Height A: 10 m	
Width A: 100 m	
Length: 150 m	
Close	Help...

These parameters allows you to monitor or define the distance and depth of your trawl, as well as the height and width of your trawl opening. If you use the Simrad ITI system, these parameters will be provided automatically.

Distance

A dedicated parameter dialogue is provided to define the distance to the trawl. The setting is made automatically if you click the **Auto** button, provided that a Simrad trawl system is connected to the sonar. If you click **Manual**, you can define the setting in steps of 10 meters.

Depth

A dedicated parameter dialogue is provided to define the depth of the trawl. The setting is made automatically if you click the **Auto** button, provided that a Simrad trawl system is connected to the sonar. If you click **Manual**, you can define the setting in steps of 10 meters.

Height

A dedicated parameter dialogue is provided to define the height of the trawl opening. The setting is made automatically if you click the **Auto** button, provided that a Simrad trawl system is connected to the sonar. If you click **Manual**, you can define the setting in steps of 1 meter.

Width

A dedicated parameter dialogue is provided to define the width of the trawl opening. The setting is made automatically if you click the **Auto** button, provided that a Simrad trawl system is connected to the sonar. If you click **Manual**, you can define the setting in steps of 10 meters.

Length


A dedicated parameter dialogue is provided to define the length of the trawl symbol on the sonar display.

Related topics

→ *Gear, page 106*

Edit School

The **Edit School** parameter dialogue is accessed from the **School** button in the **Setup** menu. In the **School** dialogue, select species and press **Edit**. The top button displays the fish species selected in the **School** dialogue.




The **Edit School** dialogue displays the species of fish and its presently selected density. The density for the school volume estimation is based on kg/m² school area. The default value is 25 kg/m² for all species, and you may adjust this figure individually in the **Density** parameter dialogue accessed by the **Density** button.

Related topics

→ *School*; page 127

External Synchronization

The **External Sync** button is located in the **Setup** menu.



The **External synchronization** function makes it possible to eliminate interference from other Simrad sonars on board the vessel. If the sonars are connected together, you can use these settings to synchronise their transmissions.

Sync mode

A dedicated parameter dialogue opens. It allows you to select one of the three synchronization modes; **None**, **Slave** or **Master**.


- **None** disconnects the SH80 from the synchronisation system. The sonar will then operate completely on its own.
- **Slave** connects the SH80 as a slave to an external system. The external system will then instruct the SH80 to when it can transmit.
- **Master** allows the SH80 to be in control. The sonar will then instruct the external system on when it can transmit.

Delay

Select the delay between the SH80 transmission and the transmission of the external system, or vice versa. A dedicated dialogue is provided to make the selection.

Fish Alarm

The **Fish Alarm** button is located in the **Setup** menu.



The **Fish Alarm** function makes it possible to set up the sonar to warn you when a school of fish are detected inside the selected sector. The selected sector is displayed with white dashed lines in the horizontal sonar picture.

Fish alarm

This is an on/off switch used to activate or deactivate the fish alarm function.

Start range

This button opens a dedicated dialogue in which you can select the range for the alarm sector to start; the inner radius. The start range can be selected between 0 and 7900 meters.

End range

This button opens a dedicated dialogue in which you can select the range for the alarm sector to end; the outer radius. The end range can be selected between 100 and 8000 meters.

Width

This button opens a dedicated dialogue in which you can select the width of the alarm sector. The sector width can be set between 10 and 360 degrees.

Alarm Threshold


This button opens a dedicated dialogue in which you can select at which echo level the alarm shall be activated. The chosen echo level is shown with the white pointer in the echo colour bar just below the **Alarm Threshold** button.

The **Close** button closes this menu. The **Help** button opens the on-line help.

Frequency

The **Frequency** parameters can be called from the **Horizontal** and **Vertical** menus.

Note that this parameter dialogue is optional, it will only be available if the triple or multiple frequency option has been installed on the sonar.




The **Frequency** parameter dialogue is used to select the transmitter and receiver frequency. In addition to the standard frequency, an optional multiple frequency version is available.

If multiple frequencies are installed, they are mainly intended for suppression of interference from other hydroacoustic equipment. However, the sound absorption in salt water decreases with the frequency, thus giving lower frequencies a longer range. If only the standard frequency is installed, Simrad offers a one-month free test period for the multiple frequencies.

Gain

The **Gain** is accessed from the **Horizontal** and **Vertical** menus.




The **Gain** is normally selected from the Sonar Operating Panel. It has 51 values, these are numbered from 0 to 50. The receiver gain is changed 1 dB per step. In addition to the readout on the **Gain** button, the horizontal gain is normally repeated over the tilt indicator in the upper left hand corner on the display. The default value is 30 dB.

Related topics

→ *Sonar Operating Panel; Gain, page 25*

Gear

The **Gear** button is located in the **Setup** menu.



The **Gear** parameter dialogue is used to select the type of fishing gear, and to get the right size and position of the gear on the display.


By using **Edit...** it is possible to program the system for three different purse seines, three different bottom trawls, and three different pelagic trawls.

Related topics

- *Edit Gear (Purse), page 98*
- *Edit gear (Trawl), page 99*

Heading

The **Heading** parameter is accessed by pressing the **Hdg** (Heading) button in the **Status** dialogue at the bottom of the menus.



The **Heading** readout is a repetition of the connected course gyro input. Manual heading input may be used if signals from external sensors are missing. By selecting **Manual**, the + and - buttons can be used to alter the heading value.

Important: This readout must not be used for navigation.

Inspect Object

The **Inspect Object** parameters are either accessed when you select a target marker in the **Objects** menu, or when you place the cursor on the marker and pushes the **Select** button on the Sonar Operating Panel.



M 1	
	↓ 0 m
→ 330 m	B: 056°
S:	C:
00° 0.123 N	000° 0.147 E
A:	V:
Delete	Set Priority
Close	Help...

The **Inspect object** parameter dialogue displays the current parameters for the chosen object. Note that every parameter may not be applicable for all marker categories.

The following parameters are shown:

- Depth
- Distance
- Bearing (B)
- Speed (S)
- Course (CO)
- Geographical position
- Area (A)
- Volume (V)

The **Delete** and **Set Priority** buttons allow you to remove an object, or to change its status to “priority”.

Delete - This button allows you to delete the chosen target

Set priority - This button sets the current target marker to the “priority” marker. The marker is then identified with a “P”.

Related topics

→ *Sonar Operating Panel; Select, page 30*

Language


The **Language** button is located on the **Display** menu.



The **Language** parameter dialogue is used to select the language on the menus.

Menu

The **Menu** button is located in the **Display** menu.




The **Menu** parameter is used to select different levels of complexity of the menu system.

- For simplified use, select the **Short** menu system. Only the most important parameters will then be shown in the menus.
- For normal operation, select **Normal**. This setting is recommended for most users after some experience with the sonar.
- For advanced use, select **Full**. All parameters in the menus will be shown.

Message Bar

The **Message Bar** button is located in the **System test** menu. This menu is accessed by pressing the **Test...** button on the **Setup** menu.



The sonar automatically issues messages when a disturbance occur. The messages are grouped into four categories; **Errors**, **System alarms**, **Operational alarms** and **Warnings**. The **Message Bar** parameter dialogue is used to select at which level warnings and alarms shall be presented.



The **Message Bar** is located at the bottom of the display, and it contains four buttons, one for each category of messages. These buttons give an overview of the number of unread messages currently in the system. Each of the four buttons gives access to a menu where each message can be read, acknowledged and deleted. When no messages are present, the four buttons are grey. When one or more unread messages exists, the **Warning** and **Operational Alarm** buttons are yellow, while the **System Alarm** and **Error** buttons are red.


When no messages are present, the four buttons are grey. When one or more unread messages exists, the **Warning** and **Operational Alarm** buttons are yellow, while the **System Alarm** and **Error** buttons are red.

Related topics

- *Warnings, page 79*
- *Operator alarms, page 80*
- *System alarms, page 81*
- *Errors, page 82*

Mode

The **Mode** button is located on the top of every menu.



The **Mode** parameter dialogue is used to select display mode. It will automatically provide a selection between the modes currently available on the sonar.

The various display modes are described in the *Display Modes* chapter.

The modes can also be selected with the four **Mode** buttons on the Sonar Operating Panel. The various modes to activate using those four buttons are controlled by the **Sort Modes** menu.

Related topics

- *Display Modes, page 13*
- *Sort Modes menu, page 68*
- *Sonar Operating Panel; Modes, page 27*

Mode Buttons

The **Mode Buttons** button is located in the **Display** menu.

This is simply a selector switch. Click on the button to select **Mode** or **User**, and by this defining the operational function of the four **Mode** buttons on the Sonar Operating Panel.



Mode Buttons: **MODE**

Mode: The four **Mode** buttons on the Sonar Operating Panel can be used to select from your favourite modes.



Mode Buttons: **USER**


User: The four **Mode** buttons on the Sonar Operating Panel can be used to select between four favourite user settings.

Related topics

- *Sort Modes, page 68*
- *User settings, page 145*
- *Mode buttons, page 27*

Movements

The **Movements** button is located in the **Setup** menu.



The **Movements** function makes it possible to estimate the position of a tracked school at a given time (from one to ten minutes). Estimate school position is presented by a violet dot. When selecting 0, the movement estimation is switched Off.

Noise Level


The **Noise Level** button is located in the **Horizontal** menu.



The **Noise level** button provides a readout of the current noise in the waters surrounding the vessel. It is only used for test purposes. This noise is caused by water flow, mechanical disturbances from hull and engine, and even from other electric or electronic systems on the vessel. In order to obtain the best possible sonar result, the noise level readout must be as low as possible, and you should read a value close to 47 dB.

Palette


The **Palette** button is located in the **Display** menu.



The **Palette** parameter dialogue is used to select background colours and day/night brightness of the display.

Panel Backlight


The **Panel Backlight** button is located in the **Display** menu.



The **Panel Backlight** controls the illumination on the keyboard on the Sonar Operating Panel in 8 steps (0 – 7). Note that the Panel Backlight can only be manually operated. The **Auto** button is added for future expansion.

PP Filter


The **PP Filter** can be accessed from the **Horizontal** and **Vertical** menus.



The **PP Filter** (Ping-to Ping filter) reduces unwanted noise and echoes from the screen. The filter has three different strengths. As the ping-to-ping filter compares the echoes from the last 2 (**Weak**), 4 (**Medium**) or 8 (**Strong**) pings, it will take this selected amounts of pings to make a stable presentation when changing most of the sonar functions. The filtering routine takes the vessel's movements into consideration when comparing the echoes from ping to ping.

Pulse Form

The **Pulse Form** is accessed from the **Horizontal** and **Vertical** menus.



The **Pulse Form** parameter dialogue is used to select the form of the transmitter pulse. This could either be CW (Continuous Wave) with different pulse lengths, or FM (Frequency Modulation) with different pulse lengths and number of frequencies.

Range (meters)	CW Pulse length (ms)			AUTO mode (ms)	FM Pulse length(ms)		
	Short	Normal	Long		Short	Normal	Long
50	0.4	0.8	1.2	FM 6.4	3.2	6.4	6.4
75	0.6	1.2	2.0	FM 6.4	3.2	6.4	6.4
100	0.8	1.5	2.5	FM 6.4	3.2	6.4	6.4
150	1.2	2.5	4.0	FM 6.4	3.2	6.4	6.4
200	1.5	3.0	5.0	FM 12.8	3.2	12.8	12.8
300	2.3	4.5	8.0	FM 12.8	3.2	12.8	12.8
400	3.0	6.0	10	FM 25.6	3.2	12.8	25.6
500	3.8	7.5	13	FM 25.6	3.2	12.8	25.6
600	4.5	9.0	15	FM 25.6	3.2	12.8	25.6
750	6.0	12.0	20	CW 20	3.2	12.8	25.6
1000	7.5	15.0	30	CW 30	3.2	12.8	25.6
1200	9.0	18.0	30	CW 30	3.2	12.8	25.6
1500	11.3	22.5	30	CW 30	3.2	12.8	25.6
2000	15.0	30.0	30	CW 30	3.2	12.8	25.6

CW (Continuous Wave)

The frequency of the transmitter pulse is here constant, equal to the selected frequency (if the optional multiple frequencies are installed).

There is a selection between three different pulse lengths: **Short**, **Normal** and **Long**. In addition the pulse length will change automatically in accordance with the selected range. The table shows the different pulse lengths given in milliseconds (ms).

Auto

In **Auto** mode, the transmitter pulse is made with a combination of FM and CW to give an optimal echo presentation for all ranges. This combination is designed from operational experience, and will change automatically between **FM Long** in the shorter ranges, and **CW Long** in the longer ranges. The table shows the mode and pulse lengths (ms) which are used for the different ranges.

FM (Frequency Modulation)

In the FM mode, the transmitter pulse is frequency modulated. This provides a stable echo presentation and greater ability of detection as noise and reverberation are reduced.


There is a selection between these different FM modes:

- **FM Short** - Transmits one-frequency pulse with a total pulse length of 3.2 ms for all ranges.
- **FM Normal** - Transmits one-frequency pulses with a total pulse length of 6.4 ms up to the ranges of 150 meters, and two-frequency pulses with a total pulse length of 12.8 ms for the longer ranges.
- **FM Long** - Transmits one-frequency pulses with a total pulse length of 6.4 ms up to the ranges of 300 meters, and four-frequency pulses with a total pulse length of 25.6 ms for the longer ranges.

The selected number of frequencies are transmitted in one ping, and the receiver undertakes a spectrum analysis to compare the received echoes with the transmitter's frequency code. This provides a filtering effect, where only "own echoes" are displayed, and noise and other echoes are reduced. The table on the previous page shows the maximum FM mode for all ranges.

Range

The **Range** parameter can be accessed from the button in the **Horizontal** and **Vertical** menus.



Horizontal and vertical range is normally selected using the SH80 Sonar Operating Panel. You can also control these settings directly on the **Range** button. The available choices are listed in this dialogue.

The **Range** buttons are described in the *Sonar Operating Panel* chapter.

Available ranges (in meters) are:

50, 75, 100, 150, 200, 300, 400, 500, 600, 750, 1000, 1200, 1500 and 2000.

In addition to the readout on the menu, the current horizontal range is normally displayed over the tilt indicator in the upper, left-hand corner of the display.

The following options are available in the **Range** parameter dialogue:

Manual - Allows you to change the range manually.

Auto - Enables automatic range selection during position- and target tracking. This allows for optimal tracking.

To maintain a steady display during seine setting, the lower automatic range is set to 450 meters. Changing the range or pressing the **Manual** buttons will stop the automatic ranging function.

The SH80 sonar is designed to work with various horizontal range units such as meter, nautical mile, US survey feet or yards. This choice can be made by pressing the **Units** button in the **Display** menu.


Related topics

→ *Sonar Operating Panel; Range, page 29*

Range (Catch View)

The **Range (Catch View)** button is located in the **Catch View** menu.

The **CatchView** menu is activated by pressing the **View** button on The Sonar Operating Panel (or the middle mouse button), while the cursor is located in the **Catch** view, and then selecting **View menu** on the **View** pop-up menu.



The **Range** in the **CatchView** may be selected manually or automatically.

In **Manual**, the range scale can be selected from the list in the dialogue.


In **Auto**, the **CatchView** range will automatically follow the range selected in the **Vertical** view.

Related topics

→ *Sonar Operating Panel; View, page 25*

RCG (Reverberation Controlled Gain)

The **RCG** button is located in the **Horizontal** and **Vertical** menus.



The **RCG** (Reverberation Controlled Gain) regulates the receiver gain individually for each of the 64 receiving beams.

In **Weak** and **Medium** selections, signals with small variations, like propeller noise, surface and bottom reverberations will be removed, while signals with fast variations, like target echoes or bottom echoes, will not be removed. In **Strong**, a special filter removes the bottom, while echoes on the bottom will be presented.

Note that scattered fish can be perceived as reverberation. The RCG function should therefore be used with care if scattered schools are to be detected.

Recall

The **Recall** button is located in the **Store/Recall** menu, which is accessed from the **Setup** menu.


The **Recall** button is used to retrieve the previously stored display information. You can select which storage image you wish to see by selecting it from the list of temporary or permanent files, or start a playback sequence. When a playback sequence is finished, the last picture of the sequence will remain “frozen” on the display.

The recalled image is clearly identified with the word “Recall”.

To exit the recall mode, press the **Object** button on the Sonar Operating Panel or the right mouse button.

Recall Mode

The **Recall Mode** button is located in the **Store/Recall** menu, which is accessed from the **Setup** menu.



The **Recall Mode** menu is used to select the replay function of the **Record** button on the Sonar Operating Panel and the **Recall** button in the **Store/Recall** menu.

The **Record** button is described in the *Sonar Operating Panel* chapter.

Related topics

→ *Sonar Operating Panel; Record, page 35*

Ruler

To create a ruler, open the **Object** pop-up menu by clicking **Object** on the Sonar Operating Panel (or the right mouse button), and select **New ruler** in the **Object** pop-up menu.

To open the **Ruler** dialogue, click on the ruler with the **Select** button.

Ruler	
L: 694 m	Di: 149°
S:	C:
A:	V:
Delete	Set Priority
Close	Help...

The **Ruler** dialogue provides information about the currently selected ruler, its length and angle. The same information is also provided next to the ruler on the display.

The **Delete** button allows you to remove the ruler from the display.


Related topics

- *Object pop-up menu, page 72*
- *Sonar Operating Panel; Select, page 30*

Scale

The **Scale** button is located in the **Geo View** menu.


The **GeoView** menu is activated by pressing the **View** button on the Sonar Operating Panel or the middle mouse button in any horizontal view, and then selecting **View menu** in the **View** pop-up menu.



The **Scale** of the horizontal presentations may be selected between 25% and 200%, where 100% is the default scale.

School

The **School** button is located in the **Setup** menu.




The **School** parameter is used to obtain information of the volume estimation of a school in the automatic target tracking program. Four types of known fish species plus **Own school** can be selected. Assumed density can be adjusted according to experience by use of the **Edit School** button.

Related topics

→ *Edit School; page 101*

Scientific Output (Option)

The **Scientific Output** button is located in the **Setup** menu.




The **Scientific Output** functionality is designed to be used when the sonar is used for scientific purposes. When enabled, the sonar will provide special information on an ethernet port.

The data provided by the the Scientific Output function can be enabled or disabled using the following buttons:

- **Target Data** - consists of all the actual target track data for all targets which are in automatically target track mode.
- **Equipment Data** - consists of all gear parameter data for the selected gear, both data which are manually selected, and data which are automatically transferred from the ITI trawl system or the PI32 net system.
- **Ownship Data** - consists of the vessels position, speed, and heading.
- **Raw Data** - consists of the start ping telegram, the actual beam data, and the end of ping data.

Search Sector

The **Search Sector** is accessed from the **Bearing** parameter dialogue, which in turn is opened from the **Horizontal** menu.




The **Search Sector** parameter dialogue is used to define the size (in degrees) of the search sector, in which the audio beam will travel back and forth when the **Auto Search** mode is enabled.

Related topics

- *Bearing, page 88*
- *Auto Search, page 32*

Search Step

The **Search Step** is accessed from the **Bearing** parameter dialogue, which in turn is opened from the **Horizontal** menu.



The **Search Step** parameter dialogue is used to define the size of each step (in degrees) the audio beam will travel between each transmission. This function is used when the **Auto Search** mode is enabled.

Related topics

- *Bearing, page 88*
- *Auto Search, page 32*

Slant Range/True Range


The **Slant Range/True Range** button is located in the **Cosmetics** menu, which in turn is accessed from the **Display** menu.

True Range

In the **True Range** presentation the echo distance is the distance which the vessel must sail in order to come on top of the target.

Slant Range


In the **Slant Range** presentation the distance to the target is measured along the tilt angle.



(A) = True range, (B) = Slant range, (C) = Tilt angle

Speed

The **Speed** parameter is accessed by pressing the **Spd** (Speed) button in the **Status** dialogue at the bottom of the menu.



The **Speed** readout is a repetition of the connected speed input source, which can be a separate speed log input or data from the connected (D)GPS. In case of a fault in the speed data, the speed can be set manually by pressing **Manual** and using the + and - buttons to alter the speed value.

Stabilizer


The **Stabilizer** button is located in the **Setup** menu.

Stabilizer: OFF

Stabilizer: ON

When the stabilizer is active, the transducer beam will be stabilized electronically for roll and pitch. The beam direction will change continuously according to the vessel's movements, and thus be compensated whenever the vessel is out of trim. The beam angle will always be maintained as if referred to a "flat" water surface. When the stabilizer is used, this will also allow you to use the **PP Filter** in rough seas. This filter will give a cleaner and more stable echo presentation.


The first example in the figure (top vessel **A**) indicates the sonar beam without stabilization, while the bottom vessel (**B**) indicates the stable sonar beam with the stabilization in operation.



Status

The **Status** dialogue is the default view displayed in the lower, right hand corner of the screen.

The **Status** dialogue can not be closed, but if an other parameter is selected it will be overwritten. The dialogue contains a transducer position indicator, as well as readouts of current time, date, latitude, longitude, heading and speed.



Related topics

- *Transducer, page 141*
- *Time and Date, page 138*
- *Heading, page 107*
- *Speed, page 132*

Store


The **Store** button is located in the **Store/Recall** menu, which is accessed from the **Setup** menu.

The **Store** button is used to store display information. This may be a sequence loop or single display pictures, as selected in the **Store mode** dialogue.

If a sequence loop storage is selected, the **Store** button is used for start and stop of the storage. If single picture storage is selected, a new picture storage is made each time the **Store** button is pressed.

Store Mode

The **Store Mode** button is located in the **Store/Recall** menu, which is accessed from the **Setup** menu.



The **Store Mode** dialogue is used to select the storage function of the **Record** button on the Sonar Operating Panel and the **Store** button in the **Store/Recall** menu. The storage can be selected to contain single shots, or different ping- or time sequences.


Related topics

→ *Sonar Operating Panel; Record, page 35*

Target Track

The **Target Track** button is located in the **GeoView** menu.


The **GeoView** menu is activated by pressing the **View** button on the Sonar Operating Panel or the middle mouse button in any horizontal view, and then selecting **View menu** in the **View** pop-up menu.



Target Track lines shows the movement history of targets as a line after the respective symbols. They are shown as straight line segments drawn between each position fix, with optional minute markers to be added for each minute along the line.

Tilt

The **Tilt** parameters are accessed from the **Horizontal** menu.



The **Tilt** is normally controlled from the Sonar Operating Panel. The transducer can be tilted electronically from +10 degrees up to -60 degrees down. In addition to the readout on the **Tilt** button, the tilt angle is normally repeated on the tilt indicator in the upper left corner of the display, and in the vertical modes; directly in the vertical slice.

Arrows

Manual tilt up/down.

Tilt Step

This button opens a new dialogue to select the tilt steps in the **Auto tilt** mode. It can be set from 1 to 10 degrees directly with the increase/decrease function on the **Tilt Step** button, or by the - and + buttons in the **Tilt step** parameter dialogue.

Tilt Sector

This button opens a new dialogue to select the active tilt sector in the **Auto tilt** mode. It can be set from 2 to 70 degrees directly with the increase/decrease function on the **Tilt Sector** button, or by the - and + buttons in the **Tilt Sector** dialogue.

Manual

In manual mode, the transducer may be tilted within the limits by pressing the “tilt down” or “tilt up” button.

Auto

In **Auto Tilt** mode, the transducer will automatically change tilt angle for each transmission. The change of the tilt angle is selected by the **Tilt Step** button, and the total tilt sector is selected by the **Tilt Sector** button. The centre of the auto tilt search can be adjusted with the - (tilt down) or + (tilt up) buttons. The tilt sector limits will be shown on the tilt indicator with yellow lines and digits. Note that the auto tilt is working differently when one of the automatic training programs are activated (Auto search, Position track or Target track).


The **Tilt** buttons and the **Auto Tilt** programs are described in the *Sonar Operator Panel* chapter.

Related topics

→ *Sonar Operating Panel; Tilt, page 34*

Time and Date

The **Time and Date** dialogue box is accessed by pressing the **Time** or **Date** buttons in the default **Status** dialogue at the bottom of the menu. Time and date are battery powered and stored in the memory when the sonar is switched off.




The **Date/Time properties** dialogue box is provided by the sonar's operating system, and it is used to change time, date and time zone settings.

- **Time adjustment** - Use the cursor and select the actual digit. Then use the two arrow buttons in the spin box to adjust.
- **Date adjustment** - Use the spin boxes and the calendar to change month, year and date.
- **Time zone** - Use the list box to select your geographical position for the correct time zone.

Note that if time and date adjustments are made during the 1 month free option test period, the actual option will be closed.

Track History

The **Track History** is accessed from the **Cosmetics** menu.




The **Track History** lines show the movement history of your own ship as a line after the vessel symbol. When this function is active, the length (in time) of the history lines can be set.

It is possible to place minute markers on the history line. To activate this, press the **Minute Marker** button ("on/off switch") on the **Cosmetics** menu. These markers are shown as small circles on the history line.

Track Window


The **Track Window** parameter is accessed from the **Setup** menu.



The **Track Window** command enables you to adjust the track window size. A larger track window will enable the system to track a large target more easily, but the system will be more susceptible to background noise. Smaller targets may be ignored if there is a lot of noise in the area, as the system will track the strongest echo within the track window.

Transducer

The **Transducer** button is located in the **Status** dialogue at the bottom of the menus.




The **Transducer** position is normally selected from the Sonar Operating Panel, and in addition to the LED indicators on the panel, the transducer position will be indicated in the **Status** dialogue.

The **Off**, **Up**, **Middle** and **Down** controls in the **Transducer** dialogue correspond to their respective buttons on the Sonar Operating Panel and makes it possible to make the selections by the trackball.

The **Middle position** button allows you to define the vertical location of the transducer when **Middle** is selected.

TVG (Time Variable Gain)

The **TVG** button is located in the **Horizontal** and **Vertical** menus.




The **TVG** controls the gain in the signal amplifier. The gain is weakest just after the ping, and increases in accordance with time (and therefore range).

In addition to **Off** and **Auto**, the TVG can be selected with six different curve slopes, each having different gain regulations. The **Auto** line in the menu is marked with an asterisk to indicate the theoretically correct setting for the different range settings.

With this setting, the gain is adjusted in such way that a school of fish with a certain size and density will be presented with approximately the same strength on the screen in any position inside the regulated TVG range.

Tx Power


The **Tx Power** button is accessed from the **Horizontal** and **Vertical** menus.



The **TX Power** is used to switch transmitter output power on or off. Note that the TX Power parameter is common for all the menus. Thus, if the Tx Power is changed in one menu, it will automatically also be changed in all other menus.

Units

The **Units** button is located on the **Display** menu. When activated, it opens the **Engineering Units** parameter dialogue.



This parameter dialogue is used to set up the various units used by the sonar to display all measurements. Separate units are available for Range, Equipment, Depth, Speed, Position and Temperature. When any of these buttons are pressed, dedicated parameter dialogues are provided to make the selection.

The following units are available:

Range: Meters, Nautical mile, Feet, Yards

Equipment: Meter, Fathoms, Feet

Depth: Meter, Fathoms, Feet


Speed: m/s, knots, km/h

Position: Geographical

Temperature: Celcius, Fahrenheit

User Setting

User Setting is accessed from the **Setup** menu.



The **User Setting** is used to store the parameter settings for different type of fisheries, or individual user related settings. The stored settings can easily be loaded back into the operative menus using the **Mode** buttons on the Sonar Operating Panel.

Load Selected Setting

Use this option to retrieve the previously stored setting. Click on the chosen setting in the dialogue to highlight it, and then click this button to retrieve it.

Save Current Settings

Use this option to save all the currently used parameter settings. You will always save your current setting as a “new user”. By default the setting will be named **User N**, and “N” is simply the next available number.

Delete

Click to select one of the settings in the dialogue, then click this button to delete it.

Rename

This option provides an on-screen keyboard to rename the stored user setting. Click on a setting to select it, then click this button. Enter the new name using the on-screen keyboard.

Select users


Using the four **Mode** buttons on the Sonar Operating Panel, you can select the four top users on the list. The list of users is sorted alphabetically, and you can rename the users and thus control which **Mode** button to recall which user.

Related topics

→ *Mode buttons, page 27*

Wind Direction

The **Wind Direction** button is located in the **Setup** menu.



The wind marker is show in the outer area of the echo presentation as a white arrow. This arrow can be manually adjusted for indication of the wind or current direction, or automatically show the wind direction if a wind sensor is connected.

Wind Speed

The **Wind Speed** button is located in the **Setup** menu.


A rectangular button with a light gray background and rounded corners. The text "Wind Speed: 0 m/s" is displayed in a medium gray, sans-serif font, centered within the button.

Wind Speed: 0 m/s

The **Wind Speed** is not used as a parameter in the sonar. It is only a readout if a wind sensor is connected.

Zoom


The **Zoom** button is located in the **Vertical View** menu.



The **Zoom** function is used to zoom in on the vertical view around the trawl symbol or the bottom. To zoom in on the bottom, an external echo sounder must be connected to the sonar.

Zoom Scale

The **Zoom** button is located in the **Vertical View** menu.



The **Zoom Scale** is used for scaling the zoom around the bottom.

ON-BOARD MAINTENANCE

Introduction

This section deals with maintenance work that may be carried out by the user. In addition to cleaning the cabinets and dust filters, you should inspect the sonar room at least once a week. The ventilation and heating system, as well as the bilge pump arrangement should then be checked to be in good working order.

For location and replacing of fuses, refer to the chapter for the unit in question.

Major repairs and complete overhaul of the sonar must be left to an authorized Simrad service engineer.

Topics

- *Preventive maintenance schedule, page 151*
- *Wheelhouse units, page 152*
- *Transceiver unit, page 154*
- *Hull unit, page 156*

Preventive maintenance schedule

Observe the following schedule for preventive maintenance on the SH80 sonar system. Use this information to create a preventive maintenance log, and make sure that every maintenance action is logged accurately.

Note:

It is very important that the preventive maintenance is carried out correctly as at the specified intervals. All guarantee is voided unless this schedule is followed.

Every three months

1. Inspect the dust filters on the Sonar Processor Unit. Clean the filters, or replace if required.
2. Inspect the dust filters on the Transceiver Unit. Clean the filters, or replace if required.
3. Carry out all the necessary lubrication of the hull unit.

Every time the ship is in dock

1. Perform a close visual inspection of the sonar trunk and the transducer.
2. If required, clean the trunk and the transducer surface for marine growth.
3. If the hull unit has been dismantled for service or repairs, replace all zinc anodes.

Related topics

- *Wheelhouse units, page 152*
- *Transceiver unit, page 154*
- *Cleaning the transducer, page 160*
- *Lubrication, page 163*

Wheelhouse units

Cleaning

The units must be kept clean and dry. Remove salt water residue with a soft cloth moistened in fresh water. Do not use strong solvents.

Note:

The display screen must be handled with care to avoid damage to the anti-glare filter coating. Use a soft cloth without any strong solvents when cleaning it.

Dust filter


To avoid overheating, the dust filter(s) must be inspected, and if necessary, cleaned once every third month.

Due to design changes, your sonar may be equipped with either of the following computers.

APC10 Sonar Processor Unit

The dust filter on the APC10 is located on the air inlet on the rear side of the Sonar Processor Unit.

*Rear side of the
APC10 Sonar
Processor Unit*




The filter is accessible by unscrewing the four screws which fasten the filter grid. The filter should be vacuum cleaned, or washed in soap and water. If washed, the filter must be dried thoroughly before being reinstalled.

MC70 Sonar Processor Unit

The two dust filters on the MC70 are located on the air inlets on the front side of the Sonar Processor Unit.

*The dust filters on the MC70
Sonar Processor Unit*



The filter is accessible by simply pulling off the filter grid. Each filter should be vacuum cleaned, or washed in soap and water. If washed, the filter must be dried thoroughly before being reinstalled.

Transceiver Unit

Dust filter


There is a dust filter in the bottom of the Transceiver Unit. To avoid overheating, this must be inspected, and if necessary, cleaned once every third month.

The dust filter is accessible from the outside of the Transceiver Unit, by unscrewing the eight finger nuts in the bottom of the unit. The filter should be vacuum cleaned, or washed in soap and water. If washed, the filter must be dried thoroughly before being reinstalled.

Replacing fuses


The Transceiver Unit is fused with two 8A slow blow main fuses (*F205* and *F206*) located on the front of the Power Control Unit.

*SH80 Transceiver Unit
fuse locations.
(A) = Dust filter*



If one of the fuses are blown, the lamp *L203* should be lit, while lamp *L204* should be extinguished. If lamp *L203* is not lit, check the fuses on the ship's main power system.

*The SH80 Transceiver Unit
power supply system*



In addition, two 5A slow blow fuses are located on the front of the Triple Power (*F201* and *F202*) and the HV-Power Unit (*F203* and *F204*).

Note that due to a design change, some SH80 Transceivers have been installed using a HV Power Unit with a different front plate design.

Hull unit

General

The sonar hull unit must be under continuous watch as a part of the vessel's machinery. As the hull unit may be exposed to severe strain because of pitching and vibrations, it must be inspected regularly for loose parts.


In addition to lubrication, check for signs of corrosion. If required, clean the corroded areas and paint over with a high quality protective paint.

Topics

- *Hull unit familiarization, page 157*
- *Precautions when docking the vessel, page 158*
- *Cleaning the transducer, page 160*
- *Hoist motor overload protection, page 161*
- *Emergency hoisting and lowering, page 162*
- *Lubrication, page 163*

Hull unit familiarization

Observe the illustration below for the identification of the main parts.



- A) Upper limit switch S304
- B) Transducer cable
- C) Transducer shaft
- D) Lower limit switch S305
- E) Pressure release plug (on rear side)
- F) Air bleeding plug
- G) Hoist motor
- H) Motor Control Unit
- I) Gantry
- J) Mounting flange
- K) Installation trunk
- L) Transducer


Docking the vessel

When docking the vessel, great care must be taken not to damage the sonar trunk and protecting blister.

Warning:

The sonar must never be powered up when the ship is in dry dock. The transducer will be damaged if it transmits in open air. To prevent inadvertent use of the sonar, disconnect the mains plug on the Sonar Processor Unit whenever the vessel is in dry dock.

The location of S302 in the Motor Control Unit



On vessels which have been in dock, the Hull Unit must be thoroughly examined, and the hoist/lower functions must be checked out and observed while operating the *Hoist/Lower Switch* (**S302** in the Motor Control Unit). The hoist/lower motor will automatically stop when the transducer shaft reaches the upper or lower limit switch.

Remember to set the hoisting/lowering switch back to **Remote** for normal operation.

Cleaning the transducer

The transducer normally needs little attention. However, the transducer face should be inspected and cleaned whenever the vessel is in dock.

To lower the transducer when in dock, use the hoist/lower switch *S302* in the Motor Control Unit (mounted on the gantry). Set the switch to **STOP** to position the transducer at any vertical location.

Do not use strong solvents, but a normal synthetic soap and water. Marine growth must be carefully removed with fine-grade sandpaper or emery paper.

Note:


The transducer surface must not be painted.

Hoist motor overload protection

To prevent the hoist/lower motor from overload, an overload circuit breaker **S301** is located in the Motor Control Unit. This may automatically be switched off during hoisting if the vessel's speed is too high, or if the transducer shaft has been bent.

To reset the motor overload switch, open the Motor Control Unit, locate the switch **S301** and press the button marked **1**.

The location of S301 in the Motor Control Unit



Emergency hoisting and lowering

In case of a failure or an emergency in the normal hoist/lower operation controlled from the Sonar Operating Panel, the transducer may be hoisted and lowered from the Sonar Room.

Local control switch S302

If the 3-phase voltage for the hoist/lower motor and the +24 Vdc stand-by voltage from the Transceiver Unit are available, the transducer can be hoisted or lowered by means of switch S302 in the Motor Control Unit. The motor will automatically stop when the transducer shaft reaches the upper or lower limit switch.

Remember to set the switch back to **Remote** position when finished.

Hoist/lower contactors K301 and K302

If the 3-phase voltage for the hoist/lower motor is available, the transducer can be hoisted and lowered by operating the hoist (K301) and lower (K302) contactors in the Motor Control Unit by activating the small switch handle on the front of the contactor.

Warning:

The switches must be released before the transducer shaft reaches upper or lower position, as this operation overrides the two limit switches.


Manual hoist and lower operation

If the 3-phase voltage is not available, the transducer must be hoisted and lowered by means of the hand crank. Observe the following procedure.

1. Locate the motor overload switch S301 in the Motor Control Unit, and press the red button marked **0**.
2. Locate the hand crank in the Motor Control Unit.
3. Remove the plastic plug on the top cover of the Hull Unit, and mount the hand crank onto the stub shaft through the hole in the top cover.
4. Use the hand crank to hoist and lower the transducer.
5. Remove the hand crank from the stub shaft, and mount it in its storage position in the Motor Control Unit.
6. Press the black button marked **1** on the motor overload switch S301.

Lubrication of the Hull Unit

From the factory, the Hull Unit is lubricated with the types of oil or grease as specified below. However, if of equal quality, other types may be used. The following number refer to the lubrication points on the illustration to the left.



(1) The ball bearing on the top of the hoist/lower screw must be lubricated with normal ball bearing grease.

(2) The hoisting spindle should be lubricated with *Tonna Slideway Oils S68*.

(3) Topping up the shaft sleeve through the grease nipple is only required if the shaft is dry of lubrication, or if water tends to force its way up along the shaft. The shaft sleeve is filled with *Esso Cazar K1*.

Warning: When you top up the shaft sleeve with oil, you must open the pressure release plug to avoid damage to the shaft bearings.

(A) = Pressure release plug

(B) = Air bleeding cock

© 2005 Simrad AS
ISBN 82-8066-007-0

Simrad AS
Strandpromenaden 50
Box 111
N-3191 Horten

Telephone: +47 33 03 40 00
Facsimile: +47 33 04 29 87

www.simrad.com

MAXIMIZING YOUR PERFORMANCE AT SEA

SIMRAD
A KONGSBERG Company