

Use and maintenance manual

MTU

Diesel Engine

12V 2000 G23/43/63/83

16V 2000 G23/43/63/83

18V 2000 G63/83

Réf. constructeur : M015560/00E

Réf. GPAO : 33522055801

Printed in Germany

© 2003 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller seiner Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten.

Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen.

Änderungen bleiben vorbehalten.

Printed in Germany

© 2003 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Imprimé en Allemagne

© 2003 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2003 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2003 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego od utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm ed alla memorizzazione od all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

1 Safety

Safety, accident prevention and environmental protection instructions

2 Product Summary

Engine layout, technical data

3 Operation

Task descriptions

4 Maintenance and Servicing

Maintenance schedule

5 Troubleshooting

Malfunctions, causes, measures

6 Task Description

Inspection and maintenance tasks

7 Annex

Abbreviations

Index

Wichtig - Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations concernant la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separen la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).


Staccare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão "Participação da colocação em serviço", preenché-lo e devolvé-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.

| | |
|--|--|
| | <div data-bbox="1278 1406 1461 1630" style="border: 1px solid black; width: 115px; height: 100px; margin-bottom: 20px;"></div> <p>Postcard</p> <p>MTU Friedrichshafen GmbH Department SCSD 88040 Friedrichshafen GERMANY</p> |
|--|--|



Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



| | | |
|---|--|---|
| Motornr.: Engine No.: No du moteur: No de motor: Motore N.: No. do motor: | Auftragsnr.: MTU works order No.: No de commande: No de pedido: N. commessa: No. do pedido: | Inbetriebnahmemeldung Commissioning Note |
| Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor: | Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço: | Notice de mise en service Aviso de puesta en servicio |
| Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em: | Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de bugue / Constructor: Tipo di Barca / Costruttore Tipo de embarcação/estaleiro naval: | Avviso di messa in servizio Participação da colocação em serviço |
| Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço: | | |
| Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações: | | |

Amendment Service!

Any changes in contents will be sent to you in the form of an amendment,
provided you complete the reverse of this receipt card and return it to us.

| | |
|--|--|
| | <div data-bbox="1278 1406 1461 1630" style="border: 1px solid black; width: 115px; height: 100px; margin: 0 auto;"></div> <p data-bbox="1042 1787 1139 1809">Postcard</p> <p data-bbox="1042 1877 1414 2056">MTU Friedrichshafen GmbH Department SCT 88040 Friedrichshafen GERMANY</p> |
|--|--|



Please mark all filed amendments here.



| No. | Date | Name |
|-----|------|------|
| 1. | | |
| 2. | | |
| 3. | | |
| 4. | | |
| 5. | | |
| 6. | | |
| 7. | | |
| 8. | | |
| 9. | | |
| 10. | | |
| 11. | | |
| 12. | | |
| 13. | | |
| 14. | | |
| 15. | | |
| 16. | | |

Please use block capitals!



| | | |
|--|---------------|-----|
| Receipt | Amendment No. | 1. |
| | | 2. |
| | | 3. |
| | | 4. |
| Publication number: M015560/00E | | 5. |
| | | 6. |
| Name | | 7. |
| Manufacturer | | 8. |
| Department | | 9. |
| | | 10. |
| Fax Telephone..... | | 11. |
| Street | | 12. |
| | | 13. |
| Postal box number | | 14. |
| (Postal code) City | | 15. |
| Country | | 16. |

| | | |
|----------|---|--------|
| 1 | Safety | |
| 1.1 | General conditions | 1 – 01 |
| 1.2 | Personnel and organizational requirements | 1 – 02 |
| 1.3 | Transport | 1 – 03 |
| 1.4 | Safety precautions when working on the engine | 1 – 04 |
| 1.5 | Auxiliary materials, fire prevention and environmental protection | 1 – 07 |
| 1.6 | Standards for warning notices in the publication | 1 – 09 |

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

1.2 Personnel and organizational requirements

Personnel

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

Organization

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

Working clothes and protective equipment

Wear proper work clothing for all work.


Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).

1.3 Transport

Transport



Lift the engine only with the lifting eyes provided.

Use only the transport and lifting equipment approved by MTU.

Take note of the engine center of gravity.

The engine must only be transported in installation position, max. permissible diagonal pull 10° .

In the case of special packaging with aluminum foil, suspend the engine on the lifting eyes of the transport pallet or transport with equipment for heavy loads (forklift truck).

Prior to transporting the engine, it is imperative to install transportation locking devices for crankshaft and engine mounts.

Secure the engine against tilting during transport. The engine must be especially secured against slipping or tilting when going up or down inclines and ramps.

Setting the engine down after transport

Place the engine only on an even, firm surface.

Ensure appropriate consistency and load-bearing capacity of the ground or support surface.

Never place an engine on the oil pan, unless expressly authorized by MTU on a case-to-case basis to do so.

1.4 Safety precautions when working on the engine

Engine operation

When the engine is running, always wear ear protectors.

Ensure that the engine room is well ventilated.

Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable bonding agent.

Exhaust gases from combustion engines are poisonous. Inhalation of poisonous exhaust gases is a health hazard. The exhaust pipework must be free of leaks and discharge the gases to atmosphere.

During engine operation, do not touch battery terminals, generator terminals or cables.

Inadequate protection of electrical components can lead to electric shocks and serious injuries.

When the engine is running, never release coolant, oil, fuel, compressed-air or hydraulic lines.

Maintenance and repair

Compliance with maintenance and repair specifications is an important safety factor.

Unless expressly permitted, no maintenance or repair work must be carried out with the engine running. Secure the engine against inadvertent starting. With electric starter, disconnect the battery. With pneumatic starter, close main shut-off valve of compressed-air system and release pressure from compressed-air supply line. Attach sign "Do not operate" in operating area or to control equipment. Persons not involved must keep clear.

Never attempt to rectify faults or carry out repairs if you do not have the necessary experience or special tools required. Maintenance and repair work must only be carried out by authorized, qualified personnel.

Use only proper, calibrated tools.

Do not work on engines or components which are only held by lifting equipment or crane.

Always support these components in accordance with regulations on suitable frames or stands before beginning any maintenance or repair work.

Before barring the engine, make sure that nobody is standing in the danger zone. After working on the engine, check that all guards have been reinstalled and that all tools and loose components have been removed from the engine.

Fluids emerging under high pressure can penetrate clothing and skin and may cause serious injury. Before starting work, relieve pressure in systems and H.P. lines which are to be opened.

Never bend a fuel line and do not install bent lines. Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

During maintenance and repair work, take care not to damage the fuel lines. To tighten the connections when installing the lines, use the correct tightening torque and ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection lines and pressurized oil lines have sufficient distance to other components to avoid contact with them. Do not place fuel or oil lines near hot components, except when necessary for design reasons during installation.

Elastomers (e.g. "Viton" sealing rings) are stable under normal operating conditions. When subjected to fire or temperatures above 300 °C the material degenerates, giving off hydrogen fluoride gas. The resulting acid leads to serious burning if it contacts the skin. Do not touch elastomeric seals if they have carbonized or resinous appearance. Wear protective gloves!

Take care with hot fluids in lines, pipes and chambers ⇒ Risk of injury!

Note cooling period for components which are heated for installation or removal ⇒ Risk of injury!

Do not touch hot components of the compressor and the exhaust system ⇒ Risk of injury!

Take special care when removing ventilation or plugs from engine. In order to avoid discharge of highly pressurized liquids, hold a cloth over the screw or plug. It is even more dangerous if the engine has recently been shut down, as the liquids can still be hot.

Take special care when draining hot fluids. ⇒ Risk of injury!

When draining, collect fluids in a suitable container, mop up any spilt fluids or wipe or soak them with a suitable bonding agent.

When changing the engine oil or working on the fuel system, ensure that the engine room is adequately ventilated.

When working high on the engine, always use suitable ladders and work platforms. Make sure components are placed on stable surfaces.

In order to prevent back injuries when lifting heavy components adults, depending on age and sex, should only lift weights between max. 10 kg and 30 kg, therefore:

- Use lifting gear or seek assistance.

- Ensure that all chains, hooks, slings, etc. are tested and authorized, are sufficiently strong and that hooks are correctly positioned. Lifting eyes must not be unevenly loaded.

Welding work

Never carry out welding work on the engine or engine-mounted units.

Never use the engine as a ground connection. (This prevents the welding current passing through the engine and causing scoring or burning at bearings, sliding surfaces and tooth flanks, which can lead to pitting or other material damage).

Never position the welding power supply cable adjacent to, or crossing MTU plant wiring harnesses. (The welding current could be induced in the cable harnesses and could possibly damage the electrical plant).

The welding unit ground connection must not be more than 60 cm from the weld point.

If components (e.g. exhaust manifold) are to be welded, they must be removed from the engine.

It is not necessary to remove the connector and the connections when carrying out welding operation on MTU electronics if the master switch for power supply is switched from "ON" to "OFF" and the wire is disconnected from the negative and positive poles on the battery.

Hydraulic installation and removal

Only the hydraulic installation and removal equipment specified in the work schedule and in the assembly instructions must be used.

The max. permissible push-on pressure specified for the equipment must not be exceeded.

The H.P. lines for hydraulic installation and removal are tested with 3800 bar.

Do not attempt to bend or apply force to lines.

Before starting work, pay attention to the following:

- Vent the hydraulic installation/removal tool, the pumps and the lines at the relevant points for the system to be used (e.g. open vent plugs, pump until bubble-free air emerges, close vent plugs).
- For hydraulic installation, screw on the tool with the piston retracted.
- For hydraulic removal, screw on the tool with the piston extended.

For a hydraulic installation/removal tool with central expansion pressure supply, screw spindle into shaft end until correct sealing is achieved.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed. As long as the system is under pressure, there is the risk that the component to be installed/removed may be suddenly released from the pressure connection.

Before use, the tools must be checked at regular intervals (crack test).

Working on electrical/electronic assemblies

Authorization must be obtained from the superior prior to commencing maintenance and repair work and switching off parts of the electronic system required for this.

Prior to working on assemblies, the power of the appropriate areas must be switched off. Any measures requiring power supply are expressly defined as such at the appropriate place in the manual.

Gases released from the battery are explosive. Avoid sparks and naked flames. Do not allow battery acids to come in contact with skin or clothing. Wear protective goggles. Do not place tools on the battery. Before connecting the cable to the battery, check battery polarity. Battery pole reversal may lead to injury through the sudden discharge of acid or bursting of the battery body.

Do not damage wiring during removal work and when reinstalling wiring and ensure that during operation it is not damaged by contact with sharp objects, by rubbing against other component or by a hot surface.

Do not secure wiring to fluid-carrying lines.

On completion of the maintenance and repair work, any cables which have become loose must be correctly connected and secured.

Always tighten connectors with connector pliers.

On completion of all repair work, the component and system must be subjected to a function check. Separate testing of the repaired component without system integration is insufficient.

If wires are installed beside mechanical components and there is a risk of chafing, use cable clamps to properly support the wires.

For this purpose, no cable binders must be used as, during maintenance and / or repair work, the binders can be removed but not installed a second time.

Spare parts shall be properly stored prior to replacement, i.e. particularly protected against moisture. Defective electronic components and assemblies must be suitably packed when dispatched for repair, i.e. particularly protected against moisture and impact and wrapped in antistatic foil if necessary.

Working with laser equipment

When working with laser equipment, always wear special laser-protection goggles.

Laser equipment can generate extremely intensive, concentrated radiation by the effect of stimulated emission in the range of visible light or in the infrared or ultraviolet spectral range. The photochemical, thermal and optomechanical effects of the laser can cause damage. The main danger is irreparable damage to the eyes.

Laser equipment must be fitted with the protective devices necessary for safe operation according to type and application.

For conducting light-beam procedures and measurement work, only the following laser devices must be used:

- Laser devices of classes 1, 2 or 3A,
- Laser devices of class 3B, which have maximum output in the visible wavelength range (400 to 700 nm), a maximum output of 5 mW, and in which the beam axis and surface are designed to prevent any risk to the eyes.

Operation of electrical equipment

When operating electrical equipment, certain components of this equipment are live.

Noncompliance with the warning instructions given for this equipment may result in serious injury or damage to property.

1.5 Auxiliary materials, fire prevention and environmental protection

Fire prevention

Rectify any fuel or oil leaks immediately; even splashes of oil or fuel on hot components can cause fires - therefore always keep the engine in a clean condition. Do not leave cloths soaked with fluids and lubricants lying around on the engine. Do not store combustible fluids near the engine.

Do not weld pipes and components carrying oil or fuel. Before welding, clean with an inflammable fluid.

When starting the engine with a foreign power source, connect the ground lead last and remove it first.

To avoid sparks in the vicinity of the battery, connect the ground lead from the foreign power source to the ground lead of the engine or to the ground terminal of the starter.

Always keep suitable fire-fighting equipment (fire extinguishers) at hand and familiarize yourself with their use.

Noise

Noise can lead to an increased risk of accident if acoustic signals, warning shouts or noises indicating danger are drowned.

At all workplaces with a sound pressure level over 85 dB (A), always wear ear protectors (protective wadding, plugs or capsules).

Environmental protection

Dispose of used fluids, lubricants and filters in accordance with local regulations.

Manipulation of the injection control system can influence the engine performance and exhaust emissions. As a result, compliance with environmental regulations may no longer be guaranteed.

Only fuels of the specified quality required to achieve emission limits must be used.

In Germany, the VAWs (= regulations governing the use of materials that may affect water quality) is applicable, which means work must only be carried out by authorized specialist companies (MTU is such a company).

Auxiliary materials

Use only fluids and lubricants that have been tested and approved by MTU.

Fluids and lubricants must be kept in suitable, properly designated containers. When using fluids, lubricants and other chemical substances, follow the safety instructions applicable to the product. Take care when handling hot, chilled or caustic materials. When using inflammable materials, avoid sparks and do not smoke.

Lead

- When working with lead or lead-containing pastes, avoid direct contact to the skin and do not inhale lead vapors.
- Adopt suitable measures to avoid the formation of lead dust!
- Switch on fume extraction system.
- After coming into contact with lead or lead-containing materials, wash hands!

Acids and alkaline solutions

- When working with acids and alkalis, wear protective goggles or face mask, gloves and protective clothing.
- Immediately remove clothing wetted by acids and alkalis!
- Rinse injuries with plenty of water!
- Rinse eyes immediately with eyedrops or clean tap water.

Paints

- When painting in other than spray booths equipped with extractors, ensure good ventilation. Make sure that adjacent work areas are not affected.
- No naked flame!
- No smoking.
- Observe fire prevention regulations!
- It is absolutely necessary to wear masks providing protection against paint and solvent fumes.

Liquid oxygen

- Liquid oxygen is highly inflammable.
- Liquid oxygen should only be stored in small quantities and in regulation containers (without fixed seals)!
- Do not bring liquid oxygen in contact with the body (hands), as this causes frostbite and possibly the loss of tissue.
- No smoking, no naked flame, risk of explosion! Excessive oxygen in the air leads to explosive combustion.

- Do not store combustible substances, e.g. oils and greases, within 5 m of the working area!
- Under no circumstances should clothing be oily or greasy.
- Do not allow vapors to penetrate clothing! Oxygen enrichment in fabric can cause working clothes to ignite suddenly!
- After working with liquid oxygen, do not smoke until clothing is free of vapors!
- Avoid all knocks and jars to the containers, fixtures or workpieces.

Liquid nitrogen

- Store liquid nitrogen only in small quantities and always in regulation containers without fixed covers.
- Do not bring liquid nitrogen in contact with the body (eyes, hands), as this causes frostbite and numbing.
- Wear protective clothing, including gloves and closed shoes, and protective goggles!
- Ensure that the room is well ventilated. Nitrogen concentration exceeding 88% of breathing air leads to suffocation.
- Avoid all knocks and jars to the containers, fixtures or workpieces.

Compressed air

Compressed air is air compressed at excess pressure and is stored in tanks from which it can be extracted.

The pressure at which the air is kept can be read off at pressure gauges which must be connected to the compressed air tanks and the compressed air lines.

When working with compressed air, safety precautions must be constantly observed:

- Pay special attention to the pressure level in the compressed air network and pressure vessel!
- Connecting devices and equipment must either be designed for this pressure or, if the permitted pressure for the connecting elements is lower than the pressure required, a pressure reducing valve and safety valve (set to permitted pressure) must form an intermediate connection. Hose coupling and connections must be securely attached!
- Always wear protective goggles when blowing off tools or extracting chips!
- The snout of the air nozzle is provided with a protective disc (e.g. rubber disc), which prevents air-borne particles being reflected and thereby prevents injury to eyes.
- First shut off compressed air lines before compressed air equipment is disconnected from the supply line or before equipment or tool is to be replaced!
- Unauthorized use of compressed air, e.g. forcing flammable liquids (danger class A1, A11 and B) out of containers, results in a risk of explosion!
- Forcing compressed air into thin-walled containers (e.g. containers made of tin, plastic and glass) for drying purposes or to check for leaks, results in a risk of explosion!
- Do not blow dirty clothing with compressed air when being worn on the body.




Used oil

Used oil may contain health-threatening combustion residues.

Rub barrier cream into hands!

Wash hands after contact with used oil.

1.6 Standards for warning notices in the publication

| | |
|---|---|
|  DANGER | In the event of immediate danger. Consequences: Death or serious injury. . |
|  WARNING | In the event of possibly dangerous situations. Consequences: Death or serious injury. . |
|  CAUTION | In the event of dangerous situations. Consequences: Slight injury or material damage. . |

Note: This Publication contains especially emphasized safety instructions in accordance with the American standard ANSI Z535, which begin with one of the above signal words according to the degree of danger:

Warning notices

1. Read and become acquainted with all cautions and symbols before operating or repairing this product.
2. Pass on all safety instructions to your operating, maintenance, repair and transport personnel!


2 Product Summary

| | |
|---|---------------|
| 2.1 Engine Layout | 2 – 01 |
| 2.1.1 Engine layout | 2 – 01 |
| 2.2 Engine Side and Cylinder Designations | 2 – 03 |
| 2.2.1 Engine side and cylinder designations | 2 – 03 |
| 2.3 Main Engine Dimensions | 2 – 04 |
| 2.3.1 Main engine dimensions | 2 – 04 |
| 2.4 Engine Data | 2 – 05 |
| 2.4.1 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized fuel consumption | 2 – 05 |
| 2.4.2 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 10 |
| 2.4.3 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized fuel consumption | 2 – 15 |
| 2.4.4 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (TA-Luft) | 2 – 20 |
| 2.4.5 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 25 |
| 2.4.6 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Air-cooled charge air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 29 |
| 2.4.7 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized fuel consumption | 2 – 37 |
| 2.4.8 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 42 |
| 2.4.9 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized fuel consumption | 2 – 47 |
| 2.4.10 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (TA-Luft) | 2 – 52 |
| 2.4.11 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 57 |
| 2.4.12 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Water-cooled charge-air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 61 |
| 2.4.13 Firing order | 2 – 69 |
| 2.4.14 Final compression pressure | 2 – 70 |

2.1 Engine Layout

2.1.1 Engine layout

Illustration is applicable to 8/12/16/18V 2000 Gxy engines



- | | | |
|-------------------------------|-----------------------------|--|
| 010 Crankcase and attachments | 100 Exhaust turbocharger | 210 Electric power supply, engine-related |
| 020 Gear train | 110 Intercooler | 230 Mounting system |
| 030 Running gear | 120 Air intake / air supply | 250 Drive systems, drive end and free end (couplings) |
| 040 Cylinder head | 140 Exhaust system | 500 Monitoring and control systems, general electric devices |
| 050 Valve gear | 170 Starting equipment | |
| 070 HP fuel system | 180 Lube oil system | |
| 080 LP fuel system | 200 Cooling system | |

Engine model designation

Key to the engine model designations 812/16/18V 2000 Gxy

| | |
|------------|----------------------------------|
| 8/12/16/18 | Number of cylinders |
| V | Cylinder configuration: V engine |
| 2000 | Series |
| G | Application |
| X | Application segment (2, 4, 6, 8) |
| Y | Design index (0,1, 2,...) |

2.2 Engine Side and Cylinder Designations


2.2.1 Engine side and cylinder designations

Engine sides are always designated as viewed from the driving end (KS).

The cylinders of the left engine side are designated "A" and those of the right side "B" (as per DIN ISO 1204).

The cylinders of each bank are numbered consecutively, starting with No. 1 at the driving end.

The numbering of engine components is also from the driving end, starting with No. 1.




00000146c

- | | |
|------------------|--------------------|
| 1 KGS = Free end | 3 KS = Driving end |
| 2 Right side | 4 Left side |

2.3 Main Engine Dimensions

2.3.1 Main engine dimensions

Main engine dimensions



| Engine model | 12V 2000 Gxy | 16V 2000 Gxy | 18V 2000 Gxy |
|--------------|-----------------|-----------------|-----------------|
| Length (A) | approx. 2020 mm | approx. 2365 mm | approx. 2400 mm |
| Width (B) | approx. 1580 mm | approx. 1580 mm | approx. 1580 mm |
| Height (C) | approx. 1690 mm | approx. 1925 mm | approx. 1605 mm |

2.4 Engine Data

2.4.1 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized fuel consumption

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3D | 3D | 3D | 3D | 3D |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|------------------------------|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Fuel stop power ISO 3046 FSP | A | kW | 625 | 680 | 805 | 895 | 985 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before cylinder FSP | R | bar ABS | 2.7 | 2.9 | 2.7 | 3.0 | 3.0 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- | --- | --- |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 90 | 110 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 2490 | 3100 | 3100 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced FSP (sound power level LW, ISO 6798) | R | db(A) | 125 | 126 | 125 | 127 | 127 |
| Engine surface noise with attenuated FSP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 120 | 121 | 121 | 121 | 122 |

2.4.2 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G43 | 12 V 2000G83 | 16 V 2000G43 | 16 V 2000G83 | 18 V 2000G83 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3D | 3D | 3D | 3D | 3D |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|------------------------------|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1800 | 1800 | 1800 | 1800 | 1800 |
| Fuel stop power ISO 3046 FSP | A | kW | 735 | 835 | 1000 | 1115 | 1250 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 14 | 14 | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before cylinder FSP | R | bar ABS | 3.1 | 3.4 | 3.2 | 3.3 | 3.3 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- | --- | --- |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.5 | 6.5 | 6.0 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.8 | 7.8 | 7.0 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 5.5 | 5.5 | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 5.0 | 5.0 | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|------|------|------|------|------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----|-----|-----|-----|-----|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 200 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----|-----|-----|-----|-----|
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 90 | 110 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 2490 | 3100 | 3100 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced FSP (sound power level LW, ISO 6798) | R | db(A) | 129 | 129 | 128 | N | 130 |
| Engine surface noise with attenuated FSP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | N | N | N | N | 123 |

2.4.3 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized fuel consumption

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 565 | 625 | 720 | 805 | 895 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.5 | 2.7 | 2.5 | 2.7 | 2.8 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- | --- | --- |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 90 | 110 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 2490 | 3100 | 3100 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 123 | 125 | 124 | 125 | 127 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 119 | 119 | 120 | 121 | 122 |

2.4.4 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (TA-Luft)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 565 | 625 | 720 | 805 | 895 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.8 | 3.1 | 2.8 | 3.1 | 3.2 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- | --- | --- |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 90 | 110 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 2490 | 3100 | 3100 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 127 | 128 | 126 | 125 | 127 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 120 | 121 | 121 | 121 | 122 |

2.4.5 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G83 | 16 V 2000G83 | 18 V 2000G83 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|-----|------|------|------|
| Engine rated speed | A | rpm | 1800 | 1800 | 1800 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 695 | 925 | 1040 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|------|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | |
|--|--|---------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X |
| Cooling system: conditioned water | | | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X |
| Number of cylinders | | | 12 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 31.84 | 35.82 |
| Compression ratio | | | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | |
|---|---|---------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 3.0 | 3.1 | 3.0 |

COOLING SYSTEM (HT circuit)

| | | | | | |
|--|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| | | | | | |
|--|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- |

LUBE OIL SYSTEM

| | | | | | |
|---|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Lube oil operating temperature before engine,from | R | °C | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.5 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| | | | | | |
|---|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| | | | | | |
|---|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 |

CAPACITIES

| | | | | | |
|--|---|-------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| | | | | | |
|---|---|----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 3100 | 3500 |

ACOUSTICS

| | | | | | |
|--|---|-------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 129 | 128 | N |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | N | N | N |

2.4.6 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Air-cooled charge air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G63 | 16 V 2000G63 | 18 V 2000G63 | 12 V 2000G83 * | 16 V 2000G83 * | 18 V 2000G83 * |
|--------------------------------|--|------|-----------------|-----------------|-----------------|----------------------|----------------------|----------------------|
| Application group | | | 3A | 3A | 3A | 3A | 3A | 3A |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | --- | --- | --- | --- | --- | --- |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|------|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1800 | 1800 | 1800 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 515 | 655 | 720 | 625 | 835 | 900 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|------|----|----|----|-----|-----|-----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 30 | 30 | 30 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 50 | 50 | 50 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 50 | 50 | 50 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 100 | 100 | 100 |

MODEL-RELATED DATA (basic design)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|--|---------|-----|-----|-----|-----|-----|-----|
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X | X |
| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 | 150 |

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|--|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 31.84 | 35.82 | 23.88 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.4 | 2.3 | 2.4 | 2.8 | 2.9 | 2.9 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Pressure loss in the external cooling system, max. permissible | L | bar | --- | --- | --- | --- | --- | --- |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | N | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 5.5 | 6.0 | 6.5 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 6.5 | 8.0 | 7.8 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.5 | 4.4 | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 4.0 | 3.9 | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 90 | 110 | 120 | 90 | 110 | 120 |
| Intercooler coolant capacity | R | liter | --- | --- | --- | --- | --- | --- |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 102 | 130 | 77 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 99 | 114 | 74 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 69 | 87 | 50 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 92 | 110 | 67 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2490 | 3100 | 3500 | 2570 | 3150 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 123 | 123 | 125 | 126 | 126 | 126 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 118 | 119 | 122 | N | N | 122 |

2.4.7 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized fuel consumption

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3D | 3D | 3D | 3D | 3D |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 1000 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|------------------------------|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Fuel stop power ISO 3046 FSP | A | kW | 625 | 680 | 805 | 895 | 985 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before cylinder FSP | R | bar ABS | 2.7 | 2.9 | 2.7 | 3.0 | 3.0 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 110 | 130 | 130 | 140 |
| Intercooler coolant capacity | R | liter | 20 | 20 | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 2570 | 3150 | 3150 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced FSP (sound power level LW, ISO 6798) | R | db(A) | 125 | 126 | 125 | 127 | 127 |
| Engine surface noise with attenuated FSP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 117 | 118 | 120 | 120 | 122 |

2.4.8 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G43 | 12 V 2000G83 | 16 V 2000G43 | 16 V 2000G83 | 18 V 2000G83 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3D | 3D | 3D | 3D | 3D |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|------------------------------|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1800 | 1800 | 1800 | 1800 | 1800 |
| Fuel stop power ISO 3046 FSP | A | kW | 735 | 835 | 1007 | 1115 | 1250 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|------|-----|-----|-----|-----|-----|
| Intake air depression (new filter) (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Intake air depression (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |
| Exhaust backpressure (design) | A | mbar | 50 | 50 | 50 | 50 | 50 |
| Exhaust backpressure (limit value) | L | mbar | 100 | 100 | 100 | 100 | 100 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 14 | 14 | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before cylinder FSP | R | bar ABS | 3.2 | 3.5 | 3.2 | 3.5 | 3.3 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.5 | 6.5 | 6.0 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.8 | 7.8 | 7.0 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 5.5 | 5.5 | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 5.0 | 5.0 | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 110 | 130 | 130 | 140 |
| Intercooler coolant capacity | R | liter | 20 | 20 | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 2570 | 3150 | 3180 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced FSP (sound power level LW, ISO 6798) | R | db(A) | 129 | 129 | 128 | N | N |
| Engine surface noise with attenuated FSP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 119 | 119 | 121 | N | N |

2.4.9 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized fuel consumption

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 565 | 625 | 720 | 805 | 895 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.5 | 2.7 | 2.5 | 2.7 | 2.8 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 110 | 130 | 130 | 140 |
| Intercooler coolant capacity | R | liter | --- | 20 | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 2570 | 3150 | 3150 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 123 | 125 | 124 | 125 | 127 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 116 | 117 | 118 | 120 | 124 |

2.4.10 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (TA-Luft)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G23 | 12 V 2000G63 | 16 V 2000G23 | 16 V 2000G63 | 18 V 2000G63 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1500 | 1500 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 565 | 625 | 720 | 805 | 895 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|------|----|----|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | | | |
|--|--|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X |
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 23.88 | 31.84 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 16 | 16 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | | | |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.8 | 3.1 | 2.8 | 3.1 | 3.2 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 6.2 | 5.5 | 5.5 | 6.0 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.5 | 6.5 | 6.5 | 8.0 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.4 | 4.5 | 4.5 | 4.4 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 3.9 | 4.0 | 4.0 | 3.9 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 110 | 130 | 130 | 140 |
| Intercooler coolant capacity | R | liter | 20 | 20 | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 77 | 102 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 74 | 99 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 50 | 69 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 67 | 92 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 2570 | 3150 | 3150 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 12 | 16 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 127 | 126 | 126 | 128 | 127 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 116 | 117 | 119 | 120 | 123 |

2.4.11 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G83 | 16 V 2000G83 | 18 V 2000G83 |
|--------------------------------|--|------|-----------------|-----------------|-----------------|
| Application group | | | 3B | 3B | 3B |
| Intake air temperature | | °C | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|-----|------|------|------|
| Engine rated speed | A | rpm | 1800 | 1800 | 1800 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 695 | 925 | 1040 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|------|----|----|----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 |

MODEL-RELATED DATA (basic design)

| | | | | | |
|--|--|---------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X |
| Cooling system: conditioned water | | | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X |
| Number of cylinders | | | 12 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 |
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 31.84 | 35.82 |
| Compression ratio | | | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| | | | | | |
|---|---|---------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 3.0 | 3.0 | 3.0 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.5 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| | | | | | |
|---|---|-----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 |

CAPACITIES

| | | | | | |
|--|---|-------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 130 | 140 |
| Intercooler coolant capacity | R | liter | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| | | | | | |
|---|---|----|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 3150 | 3500 |

ACOUSTICS

| | | | | | |
|--|---|-------|-----------|-----------|-----------|
| Number of cylinders | | | 12 | 16 | 18 |
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 129 | 128 | N |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 119 | 121 | N |

2.4.12 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Water-cooled charge-air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1)

Explanation:

DL Ref. value: Continuous power (CP)

BL Ref. value: Fuel stop power (FSP)

A Design value

G Guaranteed value

R Guideline value

L Limit value, up to which the engine can be operated, without change (e.g. of power setting)

N Not yet defined value

- Not applicable

X Applicable

Reference Conditions

| Engine model | | | 12 V 2000G63 | 16 V 2000G63 | 18 V 2000G63 | 12 V 2000G83 * | 16 V 2000G83 * | 18 V 2000G83 * |
|--------------------------------|--|------|-----------------|-----------------|-----------------|----------------------|----------------------|----------------------|
| Application group | | | 3A | 3A | 3A | 3A | 3A | 3A |
| Intake air temperature | | °C | 25 | 25 | 25 | 25 | 25 | 25 |
| Charge-air coolant temperature | | °C | 55 | 55 | 55 | 55 | 55 | 55 |
| Raw-water inlet temperature | | °C | --- | --- | --- | --- | --- | --- |
| Barometric pressure | | mbar | 1000 | 1000 | 1000 | 1000 | 1000 | 1000 |
| Site altitude above sea level | | m | 100 | 100 | 100 | 100 | 100 | 100 |

POWER-RELATED DATA (power ratings are net brake power to ISO 3046)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|------|------|------|------|------|------|
| Engine rated speed | A | rpm | 1500 | 1500 | 1500 | 1800 | 1800 | 1800 |
| Continuous power ISO 3046 (10% overload CP cap., design power DIN 6280, ISO 8528) | A | kW | 515 | 655 | 720 | 625 | 835 | 900 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|------|----|----|----|-----|-----|-----|
| Intake air depression (new filter) (design) | A | mbar | 15 | 15 | 15 | 30 | 30 | 30 |
| Intake air depression (limit value) | L | mbar | 30 | 30 | 30 | 50 | 50 | 50 |
| Exhaust backpressure (design) | A | mbar | 30 | 30 | 30 | 50 | 50 | 50 |
| Exhaust backpressure (limit value) | L | mbar | 50 | 50 | 50 | 100 | 100 | 100 |

MODEL-RELATED DATA (basic design)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|--|---------|-----|-----|-----|-----|-----|-----|
| Engine with exhaust turbocharging (ETC) and charge air cooling (CAC) | | | X | X | X | X | X | X |
| Exhaust piping, non-cooled | | | X | X | X | X | X | X |
| Working method: four-cycle, diesel, single-acting | | | X | X | X | X | X | X |
| Combustion method: direct fuel injection | | | X | X | X | X | X | X |
| Cooling system: conditioned water | | | X | X | X | X | X | X |
| Direction of rotation: c.c.w. (facing driving end) | | | X | X | X | X | X | X |
| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
| Cylinder configuration: V angle | | degrees | 90 | 90 | 90 | 90 | 90 | 90 |
| Bore | | mm | 130 | 130 | 130 | 130 | 130 | 130 |
| Stroke | | mm | 150 | 150 | 150 | 150 | 150 | 150 |

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|--|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Displacement, cylinder | | liter | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 | 1.99 |
| Displacement, total | | liter | 23.88 | 31.84 | 35.82 | 23.88 | 31.84 | 35.82 |
| Compression ratio | | | 16 | 16 | 16 | 14 | 14 | 14 |
| Cylinder heads: single-cylinder | | | X | X | X | X | X | X |
| Cylinder liners: wet, replaceable | | | X | X | X | X | X | X |
| Number of inlet valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 | 2 |
| Number of exhaust valves, per cylinder | | | 2 | 2 | 2 | 2 | 2 | 2 |
| Standard flywheel housing flange (engine main PTO) | | SAE | 0 | 0 | 0 | 0 | 0 | 0 |
| Flywheel interface | | DISC | 18" | 18" | 18" | 18" | 18" | 18" |

COMBUSTION AIR / EXHAUST GAS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| Charge air pressure before CP cylinder (abs.) | R | bar ABS | 2.4 | 2.3 | 2.4 | 2.8 | 2.9 | 2.9 |

COOLING SYSTEM (HT circuit)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature (at engine outlet to cooling equipment) | A | °C | 95 | 95 | 95 | 95 | 95 | 95 |
| Coolant temperature after engine, alarm | R | °C | 97 | 97 | 97 | 97 | 97 | 97 |
| Coolant temperature after engine, shutdown | L | °C | 102 | 102 | 102 | 102 | 102 | 102 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

COOLING SYSTEM (LT circuit)

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Coolant temperature before intercooler (at engine inlet from cooling equipment) | A | °C | 55 | 55 | 55 | 55 | 55 | 55 |
| Coolant antifreeze content, max. permissible | L | % | 50 | 50 | 50 | 50 | 50 | 50 |
| Pressure loss in the external cooling system, max. permissible | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

LUBE OIL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Lube oil operating temperature before engine, from | R | °C | 88 | 88 | 88 | 88 | 88 | 88 |
| Lube oil operating temp. before engine, to | R | °C | 98 | 98 | 98 | 98 | 98 | 98 |
| Lube oil temperature before engine, alarm | R | °C | 103 | 103 | 103 | 103 | 103 | 103 |
| Lube oil temperature before engine, shutdown | L | °C | --- | N | --- | --- | --- | --- |
| Lube oil operating press. bef. engine, from | R | bar | 6.2 | 5.5 | 6.0 | 6.5 | 6.0 | 6.5 |
| Lube oil operating press. bef. engine, to | R | bar | 7.5 | 6.5 | 8.0 | 7.8 | 7.0 | 8.5 |
| Lube oil pressure before engine, alarm | R | bar | 4.4 | 4.5 | 4.4 | 5.5 | 5.5 | 5.5 |
| Lube oil pressure before engine, shutdown | L | bar | 3.9 | 4.0 | 3.9 | 5.0 | 5.0 | 5.0 |

FUEL SYSTEM

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Fuel pressure at supply connection to engine (when engine is starting), min. admissible | L | bar | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 | -0.3 |
| Fuel pressure at supply connection to engine (when engine is starting), max. admissible | L | bar | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 | +0.5 |

GENERAL OPERATING DATA

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-----|-----------|-----------|-----------|-----------|-----------|-----------|
| Cold start capability: air temperature (w/o start aid, w/o preheating) (case A) | R | °C | 0** | 0** | 0** | 0** | 0** | 0** |
| Coolant preheating: preheating temperature (min.) | R | °C | 32 | 32 | 32 | 32 | 32 | 32 |
| Firing speed, from | R | rpm | 100 | 100 | 100 | 100 | 100 | 100 |
| Firing speed, to | R | rpm | 120 | 120 | 120 | 120 | 120 | 120 |

CAPACITIES

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Engine coolant capacity (without cooling equipment) | R | liter | 110 | 130 | 140 | 110 | 130 | 140 |
| Intercooler coolant capacity | R | liter | 20 | 20 | 20 | 20 | 20 | 20 |
| Engine oil capacity , initial filling (standard-oil system) (Option: max. operating inclinations) | R | liter | 77 | 102 | 130 | 77 | 102 | 130 |
| Oil change quantity, max. (standard oil system) | R | liter | N | N | N | N | N | N |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations) | R | liter | 74 | 99 | 114 | 74 | 99 | 114 |
| Oil pan capacity, dipstick mark min. (standard oil system) (Option: max. operating inclinations) | L | liter | 50 | 69 | 87 | 50 | 69 | 87 |
| Oil pan capacity, dipstick mark max. (standard oil system) (Option: max. operating inclinations) | L | liter | 67 | 92 | 110 | 67 | 92 | 110 |

WEIGHTS / MAIN DIMENSIONS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|---|---|----|-----------|-----------|-----------|-----------|-----------|-----------|
| Engine weight, dry (basic engine configuration acc. to scope of supply specification) | R | kg | 2570 | 3150 | 3500 | 2570 | 3180 | 3500 |

ACOUSTICS

| Number of cylinders | | | 12 | 16 | 18 | 12 | 16 | 18 |
|--|---|-------|-----------|-----------|-----------|-----------|-----------|-----------|
| Exhaust noise, unsilenced CP (sound power level LW, ISO 6798) | R | db(A) | 123 | 123 | 125 | 126 | 126 | 126 |
| Engine surface noise with attenuated CP intake noise (filter) (sound power level LW, ISO 6798) | R | db(A) | 116 | 119 | 120 | 118 | 119 | N |

2.4.13 Firing order

Firing order

| | |
|------|---|
| 12 V | A1-B2-A5-B4-A3-B1-A6-B5-A2-B3-A4-B6 |
| 16 V | A1-B5-A3-A5-B2-B8-A2-A8-B3-A7-B4-B6-A4-A6-B1-B7 |
| 18 V | A1-B6-A3-B4-A5-B2-A7-B1-A9-B3-A8-B5-A6-B7-A4-B9-A2-B8 |

2.4.14 Final compression pressure

Final compression pressure

| | |
|---------------------------------------|------------------|
| Final compression pressure at 120 rpm | 30 bar to 36 bar |
|---------------------------------------|------------------|

3 Operation

| | | |
|------------|---|---------------|
| 3.1 | Putting the engine into operation after extended out-of-service periods (>3 months) . . . | 3 – 01 |
| 3.2 | Putting the engine into operation after scheduled out-of-service-period | 3 – 02 |
| 3.3 | Starting the engine in manual mode | 3 – 03 |
| 3.4 | Emergency start (override mode) | 3 – 04 |
| 3.5 | Operational checks | 3 – 05 |
| 3.6 | Stopping the engine in manual mode | 3 – 06 |
| 3.7 | Emergency stop | 3 – 07 |
| 3.8 | After stopping the engine – engine remains ready for operation | 3 – 08 |
| 3.9 | After stopping the engine – putting the engine out of service | 3 – 09 |

3.1 Putting the engine into operation after extended out-of-service periods (>3 months)

Preconditions

- Engine is stopped and starting disabled.
- MTU Fluids and Lubricants Specification (A001061/..) is available.

Putting the engine into operation after extended out-of-service-periods (>3 months)

| Item | Task |
|---------------------------------|--|
| Engine | Depreserve (→ MTU Fluids and Lubricants Specification A001061/..). |
| Lube oil system | Check oil level (→ Page 6 – 41); |
| Fuel prefilter | Prime (→ Page 6 – 32). |
| Fuel prefilter, pressure gauge | Align adjustable pointer with position of pressure indicator (→ Page 6 – 27). |
| Fuel system | Vent (→ Page 6 – 23). |
| Cooling system | If engine is out of service for more than one year, change engine coolant (→ Page 6 – 45); Change charge-air coolant (→ Page 6 – 51). |
| Cooling system | Check engine coolant level (→ Page 6 – 46); Check charge-air coolant level (→ Page 6 – 52). |
| Cooling system | Preheat coolant with preheating unit. |
| ECU | Check plug-in connections (→ Page 6 – 65). |
| Monitoring equipment | Carry out lamp test (see manufacturer's documentation). |
| Engine/generator control system | Switch ON; Select operating mode, e.g. MANUAL OPERATION, AUTOMATIC OPERATION. |

3.2 Putting the engine into operation after scheduled out-of-service-period

Preconditions

- Engine is stopped and starting disabled.


Putting the engine into operation

| Item | Task |
|---------------------------------|--|
| Lube oil system | Check oil level (→ Page 6 – 41); |
| Cooling system | Check engine coolant level (→ Page 6 – 46); Check charge-air coolant level (→ Page 6 – 52). |
| Cooling system | Preheat coolant with preheating unit. |
| Fuel prefilter | Drain (→ Page 6 – 28). |
| Monitoring equipment | Carry out lamp test (see manufacturer's documentation). |
| Engine/generator control system | Switch ON; Select operating mode, e.g. MANUAL OPERATION, AUTOMATIC OPERATION. |

3.3 Starting the engine in manual mode

Preconditions

- Generator is not connected to network.
- External start interlock is not activated.

| | |
|--|--|
|  DANGER | Unguarded rotating and moving engine components. Risk of serious injury — danger to life! <ul style="list-style-type: none"> • Before barring or starting the engine, ensure that nobody is in the danger zone. |
|--|--|

| | |
|---|---|
|  WARNING | Engine noise above 85 dB (A). Risk of damage to hearing! <ul style="list-style-type: none"> • Wear ear protectors. |
|---|---|

Preparation

| Item | Task |
|--|------------------------|
| Operating mode selector switch (if provided) | Change to manual mode. |
| Preheating pump (if provided) | Switch ON. |

Starting the engine

| Item | Task |
|---|---|
| Switching cabinet, control panel etc. (depending on manufacturer) | If coolant temperature is <ul style="list-style-type: none"> • > 40 °C (with preheating pump), or • > 10 °C (60 Hz generator, without preheating pump), or • > 5 °C (50 Hz generator, without preheating pump): Press start button. <ul style="list-style-type: none"> • Automatic starting procedure is performed; • Tachometer indicates increasing crankshaft speed; • After the starting procedure is completed, engine is running at rated speed. |

Connecting the generator to network, running the engine to reach operating temperature

| Item | Task |
|---|---|
| Switching cabinet, control panel etc. (depending on manufacturer) | Close the generator circuit breaker. |
| Engine | Run engine at 10 to 15 % of rated power to reach operating temperature. Apply full load only after engine has reached operating temperature (coolant temperature approx. 75 °C). |

3.4 Emergency start (override mode)



Safety functions and engine shutdown alarms will be disregarded.
Serious damage to plant!

- Initiate emergency start only in emergency situations.

Preparation

| Item | Task |
|--|------------------------|
| Operating mode selector switch (if provided) | Change to manual mode. |

Emergency start

| Item | Task |
|---|--|
| Switching cabinet, control panel etc. (depending on manufacturer) | Actuate switch/button for override input of ECU. |
| Switching cabinet, control panel etc. (depending on manufacturer) | Press start button. <ul style="list-style-type: none"> • Automatic starting procedure is performed; All safety functions are deactivated and engine shutdown alarms disregarded; • Tachometer indicates increasing crankshaft speed; • After the starting procedure is completed, engine is running at rated speed. |

Connecting the generator to network

| Item | Task |
|---|--|
| Switching cabinet, control panel etc. (depending on manufacturer) | If generator is not connected to network: Close the generator circuit breaker. |
| Engine | Run at rated power. |

3.5 Operational checks



Unguarded rotating and moving engine components.
Risk of serious injury – danger to life!
 • Take special care when working on a running engine.



Engine noise above 85 dB (A).
Risk of damage to hearing!
 • Wear ear protectors.

Operational checks

| Item | Task |
|--|---|
| Control and display panels | Check indicated operating parameters (speed, temperatures, pressures). |
| Engine under load Engine at nominal speed | Check engine/plant and all pipework visually for leaks, rectify any leaks with the engine stopped. Check for abnormal running noises and vibrations. |
| Fuel prefilter | Check if indicated differential pressure is within the limit (→ Page 6 – 27). |
| Exhaust system | Check exhaust color (→ Page 5 – 01). |
| Intercooler | Check condensate drain(s) for water discharge and obstruction (→ Page 6 – 34). |
| Air filter | Check signal ring position of service indicator (→ Page 6 – 37); Replace air filter (→ Page 6 – 35), if the signal ring is completely visible in the service indicator control window. |
| Coolant pump | Check relief bore (→ Page 6 – 47). |
| Compressed-air system (if installed) | Check operating pressure at pressure gauge. Fill compressed-air tank to maximum pressure; Drain condensate from compressed-air tank, pressure drop must not exceed 1 bar. |

3.6 Stopping the engine in manual mode

Preconditions

- Generator is not connected to network.
- Engine is running in manual mode.



Stopping the engine when it is running at full load causes extreme stress to the engine.

Risk of overheating, damage to components!

- Before stopping the engine, operate it at idle speed until operating temperatures decrease and stable values are indicated.

Preparation

| Item | Task |
|--------|--|
| Engine | After the generator circuit breaker has been opened, allow the engine to cool down by running it idle for approx. 5 minutes. |

Stopping the engine

| Item | Task |
|---|---|
| Switching cabinet, control panel etc. (depending on manufacturer) | Press stop button. <ul style="list-style-type: none"> • Automatic stopping procedure is performed; • Engine is stopped. |

After stopping the engine

| Item | Task |
|--------------|--|
| Cooling pump | Operate for approx. 5 minutes after engine stop. |

3.7 Emergency stop



An emergency stop causes extreme stress to the engine.
Risk of overheating, damage to components!

- Initiate emergency stop only in emergency situations.

Emergency stop from LOP

| Item | Task |
|-----------------------|--|
| EMERGENCY STOP button | Press. <ul style="list-style-type: none"> • Engine is stopped by switching off power supply to ECU; • Signalization (e.g. by horn, flashing lamp) is released. |

After emergency stop from LOP

| Item | Task |
|---|---|
| Switching cabinet, control panel etc. (depending on manufacturer) | Press button for alarm acknowledgement. <ul style="list-style-type: none"> • Audible and visual signalization stops. |

3.8 After stopping the engine – engine remains ready for operation

After stopping the engine

| Item | Task |
|---------------------------------|--|
| Engine/generator control system | Select operating mode, e.g. MANUAL OPERATION, AUTOMATIC OPERATION. |

3.9 After stopping the engine – putting the engine out of service

Preconditions

- MTU Fluids and Lubricants Specification (A001061/..) is available.

After stopping the engine

| Item | Task |
|---------------------------------|--|
| Cooling system | Drain engine coolant (→ Page 6 – 44); Drain charge-air coolant (→ Page 6 – 50) if: <ul style="list-style-type: none"> • freezing temperatures are expected and the engine is to remain out of service for an extended period and coolant has no antifreeze additive; • the engine room is not heated; • the coolant is not maintained at a suitable temperature; • the antifreeze concentration is insufficient for the engine-room temperature; • antifreeze concentration is 50% and engine-room temperature is below -40°C. |
| Engine/generator control system | Switch OFF. |
| Air intake and exhaust system | If the engine is to remain out of service for more than 1 week, seal the engine's air and exhaust sides. If the engine is to remain out of service for more than 1 month, carry out preservation (→ MTU Fluids and Lubricants Specification A001061/..). |

4 Maintenance

| | |
|--|---------------|
| 4.1 Maintenance and Servicing | 4 – 01 |
| 4.1.1 Maintenance and servicing | 4 – 01 |
| 4.2 Maintenance Schedule – Application Group 3D | 4 – 02 |
| 4.2.1 Maintenance schedule | 4 – 02 |
| 4.3 Maintenance Schedule – Application Group 3B | 4 – 05 |
| 4.3.1 Maintenance schedule | 4 – 05 |
| 4.4 Maintenance Schedule – Application Group 3B TAL | 4 – 08 |
| 4.4.1 Maintenance schedule | 4 – 08 |
| 4.5 Maintenance Schedule – Application Group 3A | 4 – 11 |
| 4.5.1 Maintenance schedule | 4 – 11 |

4.1 Maintenance and Servicing

4.1.1 Maintenance and servicing

Preface

Low operating and maintenance costs as well as operational reliability and availability depend on maintenance and servicing being carried out in compliance with MTU's specifications and instructions.

The overall system, of which the engine is an integral part, must be maintained in such a way as to ensure trouble-free engine operation. For this purpose always:

- ensure that sufficient fuel of specified quality is available
- that the combustion air is dry and clean

Preventive maintenance instructions:

- Special care should be taken to keep the machinery plant in a clean and serviceable condition at all times to facilitate detection of possible leaks and prevent subsequent damage.
- Protect rubber and synthetic parts from oil and fuel, never treat with organic detergents, only wipe with dry cloth.
- Always replace all seals and gaskets. Our Service partner will always be available should assistance be required.

MTU maintenance concept

The MTU maintenance concept is a preventive maintenance concept.

Preventive maintenance permits advance operational planning and increases availability. The maintenance schedule refers to the specified load profile. The time intervals at which the maintenance work is to be carried out, and the relevant checks and tasks involved, are average results based on operational experience and therefore represent guidelines only. Specific operating conditions may require modifications to the Maintenance Schedule. Exchange parts (reliabilt[®]) are available for components to be replaced.

Note

The maintenance task matrix covers all tasks up to a major overhaul. After a major overhaul, the maintenance tasks must continue to be performed in accordance with the specified schedule.

The specification of fluids and lubricants, guidelines for maintenance and change intervals as well as a list of approved fluids and lubricants are provided in the MTU Fluids and Lubricants Specification A001061. Use only fluids and lubricants which comply with the MTU Fluids and Lubricants Specification.

The user/customer must perform the following additional maintenance tasks:

- Fuel prefilter:

Maintenance depends on fuel quality (purity). The filter elements of the fuel prefilter must be replaced every 2 years at the latest.

- Battery:

Maintenance depends on load and ambient conditions of the batteries. The specifications of the battery manufacturer are binding.

Out-of-service periods

If the engine is to remain out of service for more than 1 month, carry out engine preservation procedures according to the Fluids and Lubricants Specification, MTU Publication No. A001061.

4.2 Maintenance Schedule – Application Group 3D

4.2.1 Maintenance schedule

Application group

3D Standby operation, load factor: < 85%

Load profile

| | | |
|------------------------------|------|-----|
| Load factor | 100% | 85% |
| Corresponding operating time | 5% | 95% |

Maintenance schedule matrix

| | Engine oil filter | Belt drive | Coolant cooler | Fuel filter | Valve gear | Air filter | Fuel injectors | Fuel injection pumps | Combustion chambers |
|-------------------|-------------------|------------|----------------|-------------|------------|------------|----------------|----------------------|---------------------|
| Maintenance level | W2 | W2 | W3 | W3 | W3 | W4 | W4 | W4 | W4 |
| Time limit, years | 2 | 2 | 1 | 2 | - | 3 | - | - | 4 |
| Operating hours | | | | | | | | | |
| Daily | | | | | | | | | |
| 500 | | | X | X | X | | | | |
| 1000 | | | X | X | X | | | | |
| 1500 | | | X | X | X | | | | |
| 2000 | | | X | X | X | | | | |
| 2500 | | | X | X | X | | | | |
| 3000 | | X | X | X | X | X | X | | X |
| 3500 | | | X | X | X | | | | |
| 4000 | | | X | X | X | | | | |
| 4500 | | | X | X | X | | | | |
| 5000 | | | X | X | X | | | | |
| 5500 | | | X | X | X | | | | |
| 6000 | | X | X | X | X | X | X | X | X |

Maintenance tasks

| Maintenance level | Interval (hours/years) | Item | Maintenance tasks |
|--------------------------|-------------------------------|----------------------|---|
| W2 | 0 / 2 | Engine oil filter | Replace when changing the oil or when the interval/years is reached, at the latest (→ Page 6 – 42). |
| W2 | 3000 / 2 | Belt drive | Check drive belt condition and tension, replace if necessary: <ul style="list-style-type: none"> • Battery-charging generator drive (→ Page 6 – 56) • Ventilator drive (→ Page 6 – 57). |
| W3 | 500 / - | Valve gear | Check valve clearance (→ Page 6 – 10). |
| W3 | 500 / 1 | Coolant cooler | Check cooler elements for external contamination (see manufacturer's documentation). |
| W3 | 500 / 2 | Fuel filter | Replace fuel filter or fuel filter element (→ Page 6 – 32). |
| W4 | 3000 / - | Fuel injectors | Replace injectors (→ Page 6 – 18). |
| W4 | 3000 / 3 | Air filter | Replace air filter (→ Page 6 – 35). |
| W4 | 3000 / 4 | Combustion chambers | Perform endoscopic examination (→ Page 6 – 04). |
| W4 | 6000 / - | Fuel injection pumps | Replace fuel injection pumps (→ Page 6 – 14). |

4.3 Maintenance Schedule – Application Group 3B

4.3.1 Maintenance schedule

Application group

3B Continuous operation with variable load, load factor: < 75%

Load profile

| | | | |
|------------------------------|------|------|-----|
| Load factor | 110% | 100% | 70% |
| Corresponding operating time | 1% | 9% | 90% |

Maintenance schedule matrix

| | Engine oil filter | Belt drive | Coolant cooler | Fuel filter | Valve gear | Air filter | Fuel injectors | Fuel injection pumps | Combustion chambers |
|-------------------|-------------------|------------|----------------|-------------|------------|------------|----------------|----------------------|---------------------|
| Maintenance level | W2 | W2 | W3 | W3 | W3 | W4 | W4 | W4 | W4 |
| Time limit, years | 2 | 2 | 1 | 2 | - | 3 | - | - | 4 |
| Operating hours | | | | | | | | | |
| Daily | | | | | | | | | |
| 500 | | | X | X | X | | | | |
| 1000 | | | X | X | X | | | | |
| 1500 | | | X | X | X | | | | |
| 2000 | | | X | X | X | | | | |
| 2500 | | | X | X | X | | | | |
| 3000 | | X | X | X | X | X | X | | X |
| 3500 | | | X | X | X | | | | |
| 4000 | | | X | X | X | | | | |
| 4500 | | | X | X | X | | | | |
| 5000 | | | X | X | X | | | | |
| 5500 | | | X | X | X | | | | |
| 6000 | | X | X | X | X | X | X | X | X |

Maintenance tasks

| Maintenance level | Interval (hours/years) | Item | Maintenance tasks |
|--------------------------|-------------------------------|----------------------|---|
| W2 | 0 / 2 | Engine oil filter | Replace when changing the oil or when the interval/years is reached, at the latest (→ Page 6 – 42). |
| W2 | 3000 / 2 | Belt drive | Check drive belt condition and tension, replace if necessary: <ul style="list-style-type: none"> • Battery-charging generator drive (→ Page 6 – 56) • Ventilator drive (→ Page 6 – 57). |
| W3 | 500 / - | Valve gear | Check valve clearance (→ Page 6 – 10). |
| W3 | 500 / 1 | Coolant cooler | Check cooler elements for external contamination (see manufacturer's documentation). |
| W3 | 500 / 2 | Fuel filter | Replace fuel filter or fuel filter element (→ Page 6 – 32). |
| W4 | 3000 / - | Fuel injectors | Replace injectors (→ Page 6 – 18). |
| W4 | 3000 / 3 | Air filter | Replace air filter (→ Page 6 – 35). |
| W4 | 3000 / 4 | Combustion chambers | Perform endoscopic examination (→ Page 6 – 04). |
| W4 | 6000 / - | Fuel injection pumps | Replace fuel injection pumps (→ Page 6 – 14). |

4.4 Maintenance Schedule – Application Group 3B TAL

4.4.1 Maintenance schedule

Application group

3B Continuous operation with variable load, load factor: < 75%

Load profile

| | | | |
|------------------------------|------|------|-----|
| Load factor | 110% | 100% | 70% |
| Corresponding operating time | 1% | 9% | 90% |

Maintenance schedule matrix

| | Engine oil filter | Engine oil | Belt drive | Coolant cooler | Fuel filter | Valve gear | Air filter | Fuel injectors | Fuel injection pumps | Combustion chambers |
|-------------------|-------------------|------------|------------|----------------|-------------|------------|------------|----------------|----------------------|---------------------|
| Maintenance level | W2 | W2 | W2 | W3 | W3 | W3 | W4 | W4 | W4 | W4 |
| Time limit, years | 2 | - | 2 | 1 | 2 | - | 3 | - | - | 4 |
| Operating hours | | | | | | | | | | |
| Daily | X | | | | | | | | | |
| 250 | | X | | | | | | | | |
| 500 | | X | | X | X | X | | | | |
| 750 | | X | | | | | | | | |
| 1000 | | X | | X | X | X | | | | |
| 1250 | | X | | | | | | | | |
| 1500 | | X | | X | X | X | | | | |
| 1750 | | X | | | | | | | | |
| 2000 | | X | | X | X | X | | | | |

| | Engine oil filter | Engine oil | Belt drive | Coolant cooler | Fuel filter | Valve gear | Air filter | Fuel injectors | Fuel injection pumps | Combustion chambers |
|------|-------------------|------------|------------|----------------|-------------|------------|------------|----------------|----------------------|---------------------|
| 2250 | | X | | | | | | | | |
| 2500 | | X | | X | X | X | | | | |
| 2750 | | X | | | | | | | | |
| 3000 | | X | X | X | X | X | X | X | | X |
| 3250 | | X | | | | | | | | |
| 3500 | | X | | X | X | X | | | | |
| 3750 | | X | | | | | | | | |
| 4000 | | X | | X | X | X | | | | |
| 4250 | | X | | | | | | | | |
| 4500 | | X | | X | X | X | | | | |
| 4750 | | X | | | | | | | | |
| 5000 | | X | | X | X | X | | | | |
| 5250 | | X | | | | | | | | |
| 5500 | | X | | X | X | X | | | | |
| 5750 | | X | | | | | | | | |
| 6000 | | X | X | X | X | X | X | X | X | X |

Maintenance tasks

| Maintenance level | Interval (hours/years) | Item | Maintenance tasks |
|--------------------------|-------------------------------|----------------------|---|
| W2 | 1 / 2 | Engine oil filter | Replace when changing the oil or when the interval/years is reached, at the latest (→ Page 6 – 42). |
| W2 | 250 / - | Engine oil | Change engine oil (→ Page 6 – 39). |
| W2 | 3000 / 2 | Belt drive | Check drive belt condition and tension, replace if necessary: <ul style="list-style-type: none"> • Battery-charging generator drive (→ Page 6 – 56) • Ventilator drive (→ Page 6 – 57). |
| W3 | 500 / - | Valve gear | Check valve clearance (→ Page 6 – 10). |
| W3 | 500 / 1 | Coolant cooler | Check cooler elements for external contamination (see manufacturer's documentation). |
| W3 | 500 / 2 | Fuel filter | Replace fuel filter or fuel filter element (→ Page 6 – 32). |
| W4 | 3000 / - | Fuel injectors | Replace injectors (→ Page 6 – 18). |
| W4 | 3000 / 3 | Air filter | Replace air filter (→ Page 6 – 14). |
| W4 | 3000 / 4 | Combustion chambers | Perform endoscopic examination (→ Page 6 – 04). |
| W4 | 6000 / - | Fuel injection pumps | Replace fuel injection pumps (→ Page 6 – 14). |

4.5 Maintenance Schedule – Application Group 3A

4.5.1 Maintenance schedule

Application group

3A Continuous operation, unrestricted, load factor: 100%

Load profile

| | | |
|------------------------------|------|------|
| Load factor | 110% | 100% |
| Corresponding operating time | 1% | 99% |

Maintenance schedule matrix

| | Engine oil filter | Belt drive | Coolant cooler | Fuel filter | Valve gear | Air filter | Fuel injectors | Fuel injection pumps | Combustion chambers |
|-------------------|-------------------|------------|----------------|-------------|------------|------------|----------------|----------------------|---------------------|
| Maintenance level | W2 | W2 | W3 | W3 | W3 | W4 | W4 | W4 | W4 |
| Time limit, years | 2 | 2 | 1 | 2 | - | 3 | - | - | 4 |
| Operating hours | | | | | | | | | |
| Daily | | | | | | | | | |
| 500 | | | | X | | | | | |
| 1000 | | | X | X | X | | | | |
| 1500 | | | | X | | | | | |
| 2000 | | | X | X | X | | | | |
| 2500 | | | | X | | | | | |
| 3000 | | X | X | X | X | X | X | | X |
| 3500 | | | | X | | | | | |
| 4000 | | | X | X | X | | | | |
| 4500 | | | | X | | | | | |
| 5000 | | | X | X | X | | | | |
| 5500 | | | | X | | | | | |
| 6000 | | X | X | X | X | X | X | X | X |

Maintenance tasks

| Maintenance level | Interval (hours/years) | Item | Maintenance tasks |
|--------------------------|-------------------------------|----------------------|---|
| W2 | 0 / 2 | Engine oil filter | Replace when changing the oil or when the interval/years is reached, at the latest (→ Page 6 – 42). |
| W2 | 3000 / 2 | Belt drive | Check drive belt condition and tension, replace if necessary: <ul style="list-style-type: none"> • Battery-charging generator drive (→ Page 6 – 56) • Ventilator drive (→ Page 6 – 57). |
| W3 | 500 / 2 | Fuel filter | Replace fuel filter or fuel filter element (→ Page 6 – 32). |
| W3 | 1000 / - | Valve gear | Check valve clearance (→ Page 6 – 10). |
| W3 | 1000 / 1 | Coolant cooler | Check cooler elements for external contamination (see manufacturer's documentation). |
| W4 | 3000 / - | Fuel injectors | Replace injectors (→ Page 6 – 18). |
| W4 | 3000 / 3 | Air filter | Replace air filter (→ Page 6 – 35). |
| W4 | 3000 / 4 | Combustion chambers | Perform endoscopic examination (→ Page 6 – 04). |
| W4 | 6000 / - | Fuel injection pumps | Replace fuel injection pumps (→ Page 6 – 14). |

5 Troubleshooting

5.1 Troubleshooting **5 – 01**

5.2 ECU alarms **5 – 04**

5.1 Troubleshooting

Engine does not turn when starter is actuated

| Component | Probable Cause | Task |
|---------------------------------|---|---|
| Battery | Low or defective | Charge or replace (see manufacturer's documentation). |
| | Cable connections defective | Check if cable connections are properly secured (see manufacturer's documentation). |
| Starter | Engine wiring or starter defective | Check if cable connections are properly secured, contact Service. |
| Engine wiring | Defective | Check (→ Page 6 – 62). |
| Engine/generator control system | Secure seating of assemblies or connectors not provided | Perform visual inspection (see manufacturer's documentation). |
| ECU | Plug-in connections are loose | Check plug-in connections (→ Page 6 – 65). |
| Engine | Running gear blocked (engine cannot be barred manually) | Contact Service. |

Engine turns but does not fire

| Component | Probable Cause | Task |
|---------------|--|---|
| Starter | Poor rotation by starter: Battery low or defective | Charge or replace battery (see manufacturer's documentation). |
| Engine wiring | Defective | Check (→ Page 6 – 62). |
| Fuel system | Not vented | Vent fuel system (→ Page 6 – 23). |
| ECU | Defective | Contact Service. |

Engine fires unevenly

| Component | Probable Cause | Task |
|--------------------------|--------------------------|-----------------------------------|
| Fuel injection equipment | Injector defective | Replace (→ Page 6 – 18). |
| | Injection pump defective | Replace (→ Page 6 – 15). |
| Engine wiring | Defective | Check (→ Page 6 – 62). |
| Fuel system | Not vented | Vent fuel system (→ Page 6 – 23). |
| ECU | Defective | Contact Service. |

Engine does not reach nominal speed

| Component | Probable Cause | Task |
|--------------------------|--------------------------|--|
| Fuel supply | Fuel prefilter clogged | Replace (→ Page 6 – 32). |
| | Fuel filter clogged | Replace (→ Page 6 – 25). |
| Air supply | Air filter clogged | Check signal ring position of service indicator (→ Page 6 – 37). |
| Fuel injection equipment | Injector defective | Replace (→ Page 6 – 18). |
| | Injection pump defective | Replace (→ Page 6 – 15). |
| Engine wiring | Defective | Check (→ Page 6 – 62). |
| Engine | Overloaded | Contact Service. |

Engine speed not steady

| Component | Probable Cause | Task |
|--------------------------|--------------------------|-----------------------------------|
| Fuel injection equipment | Injector defective | Replace (→ Page 6 – 18). |
| | Injection pump defective | Replace (→ Page 6 – 15). |
| Speed sensor | Defective | Contact Service. |
| Fuel system | Not vented | Vent fuel system (→ Page 6 – 23). |
| ECU | Defective | Contact Service. |

Charge-air temperature too high

| Component | Probable Cause | Task |
|-------------|---------------------------------|--|
| Coolant | Incorrect coolant concentration | Check (MTU test kit). |
| Intercooler | Contaminated | Contact Service. |
| Engine room | Air-intake temperature too high | Check fans and air supply / ventilation ducts. |

Charge air pressure too low

| Component | Probable Cause | Task |
|----------------------|--------------------|--|
| Air supply | Air filter clogged | Check signal ring position of service indicator (→ Page 6 – 37). |
| Intercooler | Contaminated | Contact Service. |
| Exhaust turbocharger | Defective | Contact Service. |

Coolant leaks on intercooler

| Component | Probable Cause | Task |
|-------------|----------------------------------|------------------|
| Intercooler | Leaking, major coolant discharge | Contact Service. |

Exhaust gas black

| Component | Probable Cause | Task |
|--------------------------|--------------------------|--|
| Air supply | Air filter clogged | Check signal ring position of service indicator (→ Page 6 – 37). |
| Fuel injection equipment | Injector defective | Replace (→ Page 6 – 18). |
| | Injection pump defective | Replace (→ Page 6 – 15). |
| Engine | Overloaded | Contact Service. |

Exhaust gas blue

| Component | Probable Cause | Task |
|---|--|-----------------------------------|
| Engine oil | Too much oil in engine | Drain engine oil (→ Page 6 – 39). |
| | Oil separator of crankcase breather contaminated | Replace (→ Page 6 – 08). |
| Exhaust turbocharger, cylinder head, piston rings, cylinder liner | Defective | Contact Service. |


Exhaust gas white

| Component | Probable Cause | Task |
|-------------|------------------------------|---|
| Engine | Not at operating temperature | Run engine to reach operating temperature. |
| Fuel system | Water in fuel | Check fuel system on fuel prefilter. Drain fuel prefilter (→ Page 6 – 28). |
| Intercooler | Leaking | Contact Service. |

5.2 ECU alarms

The ECU generates alarms which are indicated in different ways depending on the equipment configuration:

- as four-digit code on a PIM
- as alarm text on a display
- as four-digit code on a dialog PC



The four-digit code consists of one letter and three figures:

- The letter encodes when the fault occurred the last time:
 - A = currently present
 - B = within the last operating hour
 - C = one to four operating hours ago
 - D = four to twelve operating hours ago
 Alarms that occurred more than twelve hours ago are deleted automatically.
- The three figures encode the fault itself as listed in the table below.

Alarms can also be caused by defective sensors / actuators. If troubleshooting in accordance with the following table is not successful, contact Service to have the sensors / actuators checked and, if required, replaced.

| Fault code | Alarm text | Meaning | Task |
|------------|-------------------|--|--|
| 005 | L1 T-CHARGE AIR | Charge-air temperature too high (1st limit) | Reduce power. |
| 006 | L2 T-CHARGE AIR | Charge-air temperature too high (2nd limit) | Reduce power. |
| 009 | L1 T-INTER-COOLER | Charge-air coolant temperature too high (1st limit) | Reduce power. |
| 015 | L1 P-LUBE OIL | Lube-oil pressure too low (1st limit) | Check engine-oil level and top up, if required; (→ Page 6 – 41); |
| 016 | L2 P-LUBE OIL | Lube-oil pressure too low (2nd limit) automatic engine shutdown | 1. Check engine-oil level and top up, if required; (→ Page 6 – 41); 2. Try to re-start the engine (→ Page 3 – 03). 3. Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------|--|--|
| 023 | L1 COOLANT LEVEL | Engine coolant level too low | Check coolant level and top up, if required (→ Page 6 – 46) . |
| 024 | L2 COOLANT LEVEL | Engine coolant level too low | Check coolant level and top up, if required (→ Page 6 – 46) . |
| 030 | ENGINE OVERSPEED | Engine overspeed; automatic engine shutdown | <ol style="list-style-type: none"> 1. Acknowledge alarm. 2. Try to re-start the engine (→ Page 3 – 03). 3. Contact Service. |
| 044 | L1 LEVEL INTERCOOLER | Charge-air coolant level too low (1st limit) | Check coolant level and top up, if required (→ Page 6 – 52) . |
| 045 | L2 LEVEL INTERCOOLER | Charge-air coolant level too low (2nd limit) | <ol style="list-style-type: none"> 1. Check coolant level and top up, if required (→ Page 6 – 52) . 2. If fault occurs repeatedly: Contact Service. |
| 051 | L1 T-LUBE OIL | Lube-oil temperature too high (1st limit) | Reduce power. |
| 052 | L2 T-LUBE OIL | Lube-oil temperature too high (2nd limit) | <ol style="list-style-type: none"> 1. Reduce power. 2. If fault occurs repeatedly: Contact Service. |
| 065 | L1 P-FUEL | Fuel supply pressure too low (1st limit) | <ol style="list-style-type: none"> 1. Check fuel lines for leaks; repair defective lines. 2. Clean fuel prefilter (→ Page 6 – 26). 3. Flush fuel prefilter (→ Page 6 – 30). 4. Replace filter element of fuel prefilter (→ Page 6 – 32). 5. Replace filter element of fuel prefilter (→ Page 6 – 25). 6. If fault is not rectified: Contact Service. |
| 066 | L2 P-FUEL | Fuel supply pressure too low (2nd limit) | <ol style="list-style-type: none"> 1. Check fuel lines for leaks; repair defective lines. 2. Clean fuel prefilter (→ Page 6 – 26). 3. Flush fuel prefilter (→ Page 6 – 30). 4. Replace filter element of fuel prefilter (→ Page 6 – 32). 5. Replace filter element of fuel prefilter (→ Page 6 – 25). 6. If fault is not rectified: Contact Service. |
| 067 | L1 T-COOLANT | Coolant temperature too high (1st limit); warning | Reduce power. |
| 068 | L2 T-COOLANT | Coolant temperature too high (2nd limit); automatic engine shutdown | <ol style="list-style-type: none"> 1. Allow the engine to cool down. 2. Check coolant cooler (elements etc.) and clean contaminated parts (see manufacturer's documentation). 3. Re-start the engine (→ Page 3 – 03). 4. If fault occurs repeatedly: Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------------|--|---|
| 069 | L1 T-EXTERN 1 | Violation of first limit for external temperature channel 1 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 070 | L2 T-EXTERN 1 | Violation of second limit for external temperature channel 1 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 071 | L1 T-EXTERN 2 | Violation of first limit for external temperature channel 2 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 072 | L2 T-EXTERN 2 | Violation of second limit for external temperature channel 2 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 073 | L1 P-EXTERN 1 | Violation of first limit for external pressure channel 1 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 074 | L2 P-EXTERN 1 | Violation of second limit for external pressure channel 1 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 075 | L1 P-EXTERN 2 | Violation of first limit for external pressure channel 2 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 076 | L2 P-EXTERN 2 | Violation of second limit for external pressure channel 2 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 077 | LIM EXT.COOLANT LEV. | Alarm from external coolant level monitoring | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 078 | LIM INTERCOOLER LEV. | Alarm from external charge-air coolant level monitoring | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 079 | L Bin-EXTERN 3 | Alarm from external binary channel 3 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 080 | L Bin-EXTERN 4 | Alarm from external binary channel 4 | (Depending on the corresponding measuring point, which is read via CAN bus) |
| 081 | RAIL LEAKAGE | HP fuel system leaking, system contains air | Contact Service. |
| 082 | RAIL PRESSURE HIGH | Pressure in HP fuel system exceeds specified value; Solenoid valve of HP fuel control block jamming or wiring to solenoid valve defective | Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------|---|---|
| 083 | RAIL PRESSURE LOW | Pressure in HP fuel system lower than the specified value; HP fuel control block defective or system leaking NOTE: With very large generators having a run-out time of more than > 20 sec this alarm is not a relevant fault. | Contact Service. |
| 089 | ENGINE SPEED LOW | Engine speed lower than 200 rpm; automatic engine shutdown | Re-start the engine (→ Page 3 – 03). |
| 090 | IDLE SPEED LOW | Idle speed not reached within a specified period; Termination of starting procedure. | Note further alarms. |
| 091 | RUN UP SPEED LOW | Run-up speed not reached within a specified period; Termination of starting procedure. | Note further alarms. |
| 092 | START SPEED LOW | Starter speed not reached within a specified period; Termination of starting procedure. | Note further alarms. |
| 093 | PREHEAT TEMP. LIMIT2 | Coolant preheating temperature too low during starting (2nd limit) Termination of starting procedure (depending on project design) | Check preheating pump / preheating system (see manufacturer's documentation). |
| 094 | PREHEAT TEMP. LIMIT1 | Coolant preheating temperature too low during starting (1st limit) | Check preheating pump / preheating system (see manufacturer's documentation). |
| 100 | EDM NOT VALID | Check sum error of measuring-point data in EDM | If fault occurs repeatedly: Contact Service. |
| 101 | IDM NOT VALID | Check sum error of measuring-point data in IDM | If fault occurs repeatedly: Contact Service. |
| 102 | INVALID FUEL CONS. 1 | Check sum error of accumulated fuel consumption data in EDM (redundant data record 1) | If fault occurs repeatedly: Contact Service. |
| 103 | INVALID FUEL CONS. 2 | Check sum error of accumulated fuel consumption data in EDM (redundant data record 2) | If fault occurs repeatedly: Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|------------|-------------------------|---|--|
| 104 | OP HOURS1 NOT VALID | Check sum error of hour meter data in EDM | If fault occurs repeatedly: Contact Service. |
| 105 | OP HOURS2 NOT VALID | Check sum error of hour meter data in IDM | If fault occurs repeatedly: Contact Service. |
| 106 | ERR REC1 NOT VALID | Check sum error of fault memory in EDM (redundant data record 1) | If fault occurs repeatedly: Contact Service. |
| 107 | ERR REC2 NOT VALID | Check sum error of fault memory in EDM (redundant data record 2) | If fault occurs repeatedly: Contact Service. |
| 118 | L1 SUPPLY VOLT. LOW | Supply voltage too low (1st limit) | Check ECU supply voltage. |
| 119 | L2 SUPPLY VOLT. LOW | Supply voltage too low (2nd limit) | Check ECU supply voltage. |
| 120 | L1 SUPPLY VOLT. HIGH | Supply voltage too high(1st limit) | Check ECU supply voltage. |
| 121 | L2 SUPPLY VOLT. HIGH | Supply voltage too high (2nd limit); automatic engine shutdown (depending on project design) | Check ECU supply voltage. If engine was stopped: Start engine (→ Page 3 – 03). |
| 122 | L1 T-ELECTRONIC | Temperature in ECU housing too high (1st limit) | 1. Improve engine room ventilation. 2. Reduce engine power. |
| 134 | 15V POS ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 136 | 15V NEG ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 137 | L1 5V BUFFER TEST | Power supply for pressure sensors defective. | 1. Disconnect connectors X2 and X3 from ECU. If alarm does not disappear: Contact Service. 2. Check wiring (pressure sensors). 3. Contact Service. |
| 138 | SENSORPOW- ERDEFECT | Power supply for pressure sensors defective. | 1. Disconnect connectors X2 and X3 from ECU. If alarm does not disappear: Contact Service. 2. Check wiring (pressure sensors). 3. Contact Service. |
| 139 | L1 TE BUFFER TEST | Internal electronic fault (temperature sensors) | Contact Service. |
| 140 | TE BUF. ECU DEFECT | Internal electronic fault (temperature sensors) | Contact Service. |
| 142 | BANK1 ECU DEFECT | Internal electronic fault; Engine does not start | Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------|--|---|
| 144 | BANK2 ECU DEFECT | Internal electronic fault; Engine does not start | Contact Service. |
| 145 | 15V_GOOD ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 146 | L1 AD-TEST1 SUPPLY | A/D-converter supply voltage too low | Contact Service. |
| 147 | AD-TEST1 ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 148 | L1 AD-TEST2 SUPPLY | A/D-converter supply voltage too low | Contact Service. |
| 149 | AD-TEST2 ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 150 | L1 AD-TEST3 SUPPLY | A/D-converter supply voltage too low | Contact Service. |
| 151 | AD-TEST3 ECU DEFECT | Electronic equipment defective; automatic engine shutdown | Contact Service. |
| 170 | MI MODULE FAIL | Module in maintenance predictor either defective or missing | Contact Service. |
| 171 | MI NOT ACTIVE | Maintenance predictor no more activated | Contact Service. |
| 173 | MODULE WRITE LIMIT | EEPROM write limit reached | Contact Service. |
| 180 | CAN1 NODE LOST | At least one device not detected on Default CAN bus | 1. Check wiring (CAN bus). 2. Contact Service. |
| 181 | CAN2 NODE LOST | At least one device not detected on Redundant CAN bus | 1. Check wiring (CAN bus). 2. Contact Service. |
| 182 | CAN WRONG PARAMETERS | Consistency error in CAN parameters | Contact Service. |
| 183 | CAN NO PU-DATA | Error during loading of CAN project design data into ECU. | Contact Service. |
| 184 | CAN PU-DATA EE-FAIL | Error during project design data download in EEPROMs | Contact Service. |
| 185 | CAN LESS MAILBOXES | Error during CAN initialization. | Contact Service. |
| 186 | CAN1 BUS OFF | Severe fault on Default CAN bus; automatic change-over to Redundant CAN bus | Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------|--|---|
| 187 | CAN1 ERROR PASSIVE | Light fault on Default CAN bus (e.g.shortage overload) | (none) |
| 188 | CAN2 BUS OFF | Severe fault on Redundant CAN bus; automatic change-over to Default CAN bus | Contact Service. |
| 189 | CAN2 ERROR PASSIVE | Light fault on Redundant CAN bus (e.g.short-time overload) | (none) |
| 201 | SD T-COOLANT | Sensor defect (coolant temperature) | 1. Check wiring. 2. Contact Service. |
| 202 | SD T-FUEL | Sensor defect (Fuel temperature) | 1. Check wiring. 2. Contact Service. |
| 203 | SD T-CHARGE AIR | Sensor defect (charge-air temperature) | 1. Check wiring. 2. Contact Service. |
| 205 | SD T-COOLANT INTERC. | Sensor defect (charge-air coolant temperature) | 1. Check wiring. 2. Contact Service. |
| 208 | SD P-CHARGE AIR | Sensor defect (charge-air pressure) | 1. Check wiring. 2. Contact Service. |
| 211 | SD P-LUBE OIL | Sensor defect (lube oil pressure) | 1. Check wiring. 2. Contact Service. |
| 215 | SD P-RAIL FUEL | Sensor defect (common rail pressure); HP controller in emergency mode | 1. Check wiring. 2. Contact Service. |
| 216 | SD T-LUBE OIL | Sensor defect (lube oil temperature) | 1. Check wiring. 2. Contact Service. |
| 220 | SD COOLANT LEVEL | Sensor defect (coolant level) | 1. Check wiring. 2. Contact Service. |
| 223 | SD LEVEL INTERCOOLER | Sensor defect (charge-air coolant level) | 1. Check wiring. 2. Contact Service. |
| 229 | SD ENG.SPEED SENSORS | Sensor defect (crankshaft speed) and sensor defect (camshaft speed) | 1. Check wiring. 2. Contact Service. |
| 230 | SD CRANKSHAFT SPEED | Sensor defect (crankshaft speed) | 1. Check wiring. 2. Contact Service. |
| 231 | SD CAMSHAFT SPEED | Sensor defect (camshaft speed) | 1. Check wiring. 2. Contact Service. |
| 240 | SD P-FUEL | Sensor defect (fuel pressure) | 1. Check wiring. 2. Contact Service. |
| 245 | SD POWER SUPPLY | Sensor defect (ECU operating voltage) | Contact Service. |
| 246 | SD T-ELECTRONIC | Sensor defect (temperature in ECU) | Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|----------------------|---|--|
| 250 | SD CAN SPEED DEMAND | Sensor defect (CAN nominal speed demand) | 1. Check speed transmitter. 2. Check wiring (CAN bus). 3. Contact Service. |
| 266 | SD SPEED DEMAND AN. | Sensor defect (analog nominal speed demand) | 1. Check speed transmitter. 2. Check wiring. 3. Contact Service. |
| 267 | SD SP.DEM.TEST BENCH | Sensor defect (analog speed demand); NOTE: Only used in test-stand operation. | 1. Check speed transmitter. 2. Check wiring. 3. Contact Service. |
| 270 | SD SPEED DEMAND F11 | Sensor defect (frequency input for speed demand); | 1. Check speed transmitter. 2. Check wiring. 3. Contact Service. |
| 271 | SD T-EXTERN 1 | External device defective (CAN T-EXTERN 1) | Contact Service. |
| 272 | SD T-EXTERN 2 | External device defective (CAN T-EXTERN 2) | Contact Service. |
| 273 | SD P-EXTERN 1 | External device defective (CAN P-EXTERN 1) | Contact Service. |
| 274 | SD P-EXTERN 2 | External device defective (CAN P-EXTERN 2) | Contact Service. |
| 275 | SD EXT.COOLANT LEVEL | External coolant-level monitoring defective (CAN) | Contact Service. |
| 276 | SD INTERCOOLER LEVEL | External charge-air coolant-level monitoring defective (CAN) | Contact Service. |
| 277 | SD BIN-EXTERN 3 | External device defective (CAN BIN-EXTERN 3) | Contact Service. |
| 278 | SD BIN-EXTERN 4 | External device defective (CAN BIN-EXTERN 4) | Contact Service. |
| 301 | TIMING CYLINDER A1 | Injection timing fault cylinder A1 | If fault occurs repeatedly: Contact Service. |
| 302 | TIMING CYLINDER A2 | Injection timing fault cylinder A2 | If fault occurs repeatedly: Contact Service. |
| 303 | TIMING CYLINDER A3 | Injection timing fault cylinder A3 | If fault occurs repeatedly: Contact Service. |
| 304 | TIMING CYLINDER A4 | Injection timing fault cylinder A4 | If fault occurs repeatedly: Contact Service. |
| 305 | TIMING CYLINDER A5 | Injection timing fault cylinder A5 | If fault occurs repeatedly: Contact Service. |
| 306 | TIMING CYLINDER A6 | Injection timing fault cylinder A6 | If fault occurs repeatedly: Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|------------------------|--|--|
| 307 | TIMING CYLINDER A7 | Injection timing fault cylinder A7 | If fault occurs repeatedly: Contact Service. |
| 308 | TIMING CYLINDER A8 | Injection timing fault cylinder A8 | If fault occurs repeatedly: Contact Service. |
| 309 | TIMING CYLINDER A9 | Injection timing fault cylinder A9 | If fault occurs repeatedly: Contact Service. |
| 310 | TIMING CYLINDER A10 | Injection timing fault cylinder A10 | If fault occurs repeatedly: Contact Service. |
| 311 | TIMING CYLINDER B1 | Injection timing fault cylinder B1 | If fault occurs repeatedly: Contact Service. |
| 312 | TIMING CYLINDER B2 | Injection timing fault cylinder B2 | If fault occurs repeatedly: Contact Service. |
| 313 | TIMING CYLINDER B3 | Injection timing fault cylinder B3 | If fault occurs repeatedly: Contact Service. |
| 314 | TIMING CYLINDER B4 | Injection timing fault cylinder B4 | If fault occurs repeatedly: Contact Service. |
| 315 | TIMING CYLINDER B5 | Injection timing fault cylinder B5 | If fault occurs repeatedly: Contact Service. |
| 316 | TIMING CYLINDER B6 | Injection timing fault cylinder B6 | If fault occurs repeatedly: Contact Service. |
| 317 | TIMING CYLINDER B7 | Injection timing fault cylinder B7 | If fault occurs repeatedly: Contact Service. |
| 318 | TIMING CYLINDER B8 | Injection timing fault cylinder B8 | If fault occurs repeatedly: Contact Service. |
| 319 | TIMING CYLINDER B9 | Injection timing fault cylinder B9 | If fault occurs repeatedly: Contact Service. |
| 320 | TIMING CYLINDER B10 | Injection timing fault cylinder B10 | If fault occurs repeatedly: Contact Service. |
| 321 | WIRING CYLINDER A1 | Faulty wiring to solenoid valve cylinder A1; Misfiring | 1. Check wiring. 2. Contact Service. |
| 322 | WIRING CYLINDER A2 | Faulty wiring to solenoid valve cylinder A2; Misfiring | 1. Check wiring. 2. Contact Service. |
| 323 | WIRING CYLINDER A3 | Faulty wiring to solenoid valve cylinder A3; Misfiring | 1. Check wiring. 2. Contact Service. |
| 324 | WIRING CYLINDER A4 | Faulty wiring to solenoid valve cylinder A4; Misfiring | 1. Check wiring. 2. Contact Service. |
| 325 | WIRING CYLINDER A5 | Faulty wiring to solenoid valve cylinder A5; Misfiring | 1. Check wiring. 2. Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|------------------------|---|---|
| 326 | WIRING CYLINDER A6 | Faulty wiring to solenoid valve cylinder A6; Misfiring | 1. Check wiring. 2. Contact Service. |
| 327 | WIRING CYLINDER A7 | Faulty wiring to solenoid valve cylinder A7; Misfiring | 1. Check wiring. 2. Contact Service. |
| 328 | WIRING CYLINDER A8 | Faulty wiring to solenoid valve cylinder A8; Misfiring | 1. Check wiring. 2. Contact Service. |
| 329 | WIRING CYLINDER A9 | Faulty wiring to solenoid valve cylinder A9; Misfiring | 1. Check wiring. 2. Contact Service. |
| 330 | WIRING CYLINDER A10 | Faulty wiring to solenoid valve cylinder A10; Misfiring | 1. Check wiring. 2. Contact Service. |
| 331 | WIRING CYLINDER B1 | Faulty wiring to solenoid valve cylinder B1; Misfiring | 1. Check wiring. 2. Contact Service. |
| 332 | WIRING CYLINDER B2 | Faulty wiring to solenoid valve cylinder B2; Misfiring | 1. Check wiring. 2. Contact Service. |
| 333 | WIRING CYLINDER B3 | Faulty wiring to solenoid valve cylinder B3; Misfiring | 1. Check wiring. 2. Contact Service. |
| 334 | WIRING CYLINDER B4 | Faulty wiring to solenoid valve cylinder B4; Misfiring | 1. Check wiring. 2. Contact Service. |
| 335 | WIRING CYLINDER B5 | Faulty wiring to solenoid valve cylinder B5; Misfiring | 1. Check wiring. 2. Contact Service. |
| 336 | WIRING CYLINDER B6 | Faulty wiring to solenoid valve cylinder B6; Misfiring | 1. Check wiring. 2. Contact Service. |
| 337 | WIRING CYLINDER B7 | Faulty wiring to solenoid valve cylinder B7; Misfiring | 1. Check wiring. 2. Contact Service. |
| 338 | WIRING CYLINDER B8 | Faulty wiring to solenoid valve cylinder B8; Misfiring | 1. Check wiring. 2. Contact Service. |
| 339 | WIRING CYLINDER B9 | Faulty wiring to solenoid valve cylinder B9; Misfiring | 1. Check wiring. 2. Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|------------------------|---|---|
| 340 | WIRING CYLINDER B10 | Faulty wiring to solenoid valve cylinder B10; Misfiring | 1. Check wiring. 2. Contact Service. |
| 341 | OPEN_LOAD CYL. A1 | Disconnection in wiring to solenoid valve cylinder A1; Misfiring | 1. Check wiring. 2. Contact Service. |
| 342 | OPEN_LOAD CYL. A2 | Disconnection in wiring to solenoid valve cylinder A2; Misfiring | 1. Check wiring. 2. Contact Service. |
| 343 | OPEN_LOAD CYL. A3 | Disconnection in wiring to solenoid valve cylinder A3; Misfiring | 1. Check wiring. 2. Contact Service. |
| 344 | OPEN_LOAD CYL. A4 | Disconnection in wiring to solenoid valve cylinder A4; Misfiring | 1. Check wiring. 2. Contact Service. |
| 345 | OPEN_LOAD CYL. A5 | Disconnection in wiring to solenoid valve cylinder A5; Misfiring | 1. Check wiring. 2. Contact Service. |
| 346 | OPEN_LOAD CYL. A6 | Disconnection in wiring to solenoid valve cylinder A6; Misfiring | 1. Check wiring. 2. Contact Service. |
| 347 | OPEN_LOAD CYL. A7 | Disconnection in wiring to solenoid valve cylinder A7; Misfiring | 1. Check wiring. 2. Contact Service. |
| 348 | OPEN_LOAD CYL. A8 | Disconnection in wiring to solenoid valve cylinder A8; Misfiring | 1. Check wiring. 2. Contact Service. |
| 349 | OPEN_LOAD CYL. A9 | Disconnection in wiring to solenoid valve cylinder A9; Misfiring | 1. Check wiring. 2. Contact Service. |
| 350 | OPEN_LOAD CYL. A10 | Disconnection in wiring to solenoid valve cylinder A10; Misfiring | 1. Check wiring. 2. Contact Service. |
| 351 | OPEN_LOAD CYL. B1 | Disconnection in wiring to solenoid valve cylinder B1; Misfiring | 1. Check wiring. 2. Contact Service. |
| 352 | OPEN_LOAD CYL. B2 | Disconnection in wiring to solenoid valve cylinder B2; Misfiring | 1. Check wiring. 2. Contact Service. |
| 353 | OPEN_LOAD CYL. B3 | Disconnection in wiring to solenoid valve cylinder B3; Misfiring | 1. Check wiring. 2. Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|------------------------|--|---|
| 354 | OPEN_LOAD CYL. B4 | Disconnection in wiring to solenoid valve cylinder B4; Misfiring | 1. Check wiring. 2. Contact Service. |
| 355 | OPEN_LOAD CYL. B5 | Disconnection in wiring to solenoid valve cylinder B5; Misfiring | 1. Check wiring. 2. Contact Service. |
| 356 | OPEN_LOAD CYL. B6 | Disconnection in wiring to solenoid valve cylinder B6; Misfiring | 1. Check wiring. 2. Contact Service. |
| 357 | OPEN_LOAD CYL. B7 | Disconnection in wiring to solenoid valve cylinder B7; Misfiring | 1. Check wiring. 2. Contact Service. |
| 358 | OPEN_LOAD CYL. B8 | Disconnection in wiring to solenoid valve cylinder B8; Misfiring | 1. Check wiring. 2. Contact Service. |
| 359 | OPEN_LOAD CYL. B9 | Disconnection in wiring to solenoid valve cylinder B9; Misfiring | 1. Check wiring. 2. Contact Service. |
| 360 | OPEN_LOAD CYL. B10 | Disconnection in wiring to solenoid valve cylinder B10; Misfiring | 1. Check wiring. 2. Contact Service. |
| 361 | POWER STAGE FAIL 1 | Defect in ECU (solenoid valve power stage) | Contact Service. |
| 362 | POWER STAGE FAIL 2 | Defect in ECU (solenoid valve power stage) | Contact Service. |
| 363 | STOP POWER STAGE 1 | Solenoid valve or wiring or ECU defective automatic engine shutdown | 1. Check wiring. 2. Try to re-start the engine (→ Page 3 – 03). 3. Contact Service. |
| 364 | STOP POWER STAGE 2 | Solenoid valve or wiring or ECU defective automatic engine shutdown | 1. Check wiring. 2. Try to re-start the engine (→ Page 3 – 03). 3. Contact Service. |
| 365 | STOP MV-WIRING | Solenoid-valve wiring faulty; automatic engine shutdown | 1. Check wiring. 2. Try to re-start the engine (→ Page 3 – 03). 3. Contact Service. |
| 381 | TRAN.OUT1 PLANT DEF | Binary transistor output plant 1 defective | Contact Service. |
| 382 | TRAN.OUT2 PLANT DEF | Binary transistor output plant 2 defective | Contact Service. |
| 383 | TRAN.OUT3 PLANT DEF | Binary transistor output plant 3 defective | Contact Service. |
| 384 | TRAN.OUT4 PLANT DEF | Binary transistor output plant 4 defective | Contact Service. |

| Fault code | Alarm text | Meaning | Task |
|-------------------|------------------------|---|------------------|
| 385 | TRAN.OUT5 PLANT DEF | Binary transistor output plant 5 defective | Contact Service. |
| 386 | TRAN.OUT6 PLANT DEF | Binary transistor output plant 6 defective | Contact Service. |

6 Task Description

| | |
|--|---------------|
| 6.1 Engine | 6 – 01 |
| 6.1.1 Engine – Barring manually | 6 – 01 |
| 6.1.2 Engine – barring with starting system | 6 – 02 |
| 6.1.3 Engine test run | 6 – 03 |
| 6.2 Cylinder Liner | 6 – 04 |
| 6.2.1 Cylinder-liner endoscopic examination | 6 – 04 |
| 6.2.2 Instructions and comments on endoscopic and visual examination of cylinder liner | 6 – 06 |
| 6.3 Crankcase Breather | 6 – 08 |
| 6.3.1 Crankcase breather – oil separator replacement and diaphragm check | 6 – 08 |
| 6.4 Valve Gear | 6 – 10 |
| 6.4.1 Valve clearance – Check and adjustment | 6 – 10 |
| 6.4.2 Cylinder-head cover – Removal and installation | 6 – 13 |
| 6.5 Injection Pump / HP Pump | 6 – 14 |
| 6.5.1 Injection pump replacement | 6 – 14 |
| 6.5.2 Injection pump removal and installation | 6 – 15 |
| 6.6 Fuel Injector | 6 – 18 |
| 6.6.1 Injector replacement | 6 – 18 |
| 6.6.2 Injector removal and installation | 6 – 19 |
| 6.7 Fuel System (Low Pressure) | 6 – 22 |
| 6.7.1 Fuel – Draining | 6 – 22 |
| 6.7.2 Fuel system – Venting | 6 – 23 |
| 6.8 Fuel Filter | 6 – 25 |
| 6.8.1 Fuel filter – Replacement | 6 – 25 |
| 6.8.2 Fuel prefilter cleaning | 6 – 26 |
| 6.8.3 Fuel prefilter – differential pressure check and adjustment of gauge | 6 – 27 |
| 6.8.4 Fuel prefilter – draining | 6 – 28 |
| 6.8.5 Fuel prefilter – flushing | 6 – 30 |
| 6.8.6 Fuel prefilter – filter element replacement | 6 – 32 |
| 6.9 Charge-Air Cooling, General, Left Side | 6 – 34 |
| 6.9.1 Intercooler – Checking condensate drains for coolant discharge and obstructions | 6 – 34 |
| 6.10 Air Filter | 6 – 35 |
| 6.10.1 Air filter replacement | 6 – 35 |
| 6.10.2 Air filter removal and installation | 6 – 36 |
| 6.11 Air Intake | 6 – 37 |
| 6.11.1 Service indicator – signal ring position check | 6 – 37 |
| 6.12 Starting System | 6 – 38 |
| 6.12.1 Air starter – manual operation | 6 – 38 |
| 6.13 Lube Oil System | 6 – 39 |
| 6.13.1 Engine oil change | 6 – 39 |
| 6.13.2 Engine oil level check | 6 – 41 |

| | |
|---|---------------|
| 6.14 Oil Filtration / Cooling | 6 – 42 |
| 6.14.1 Engine oil filter – Replacement | 6 – 42 |
| 6.15 Cooling System, General, HT Circuit | 6 – 43 |
| 6.15.1 Engine coolant filling | 6 – 43 |
| 6.15.2 Engine coolant – Draining | 6 – 44 |
| 6.15.3 Engine coolant change | 6 – 45 |
| 6.15.4 Engine coolant-level check | 6 – 46 |
| 6.15.5 Cooling pump - Relief bore check | 6 – 47 |
| 6.16 Cooling System, LT Circuit | 6 – 48 |
| 6.16.1 Charge-air coolant filling | 6 – 48 |
| 6.16.2 Charge-air coolant – Draining | 6 – 50 |
| 6.16.3 Charge-air coolant change | 6 – 51 |
| 6.16.4 Charge-air coolant level check | 6 – 52 |
| 6.17 Battery-Charging Generator | 6 – 53 |
| 6.17.1 Battery-charging generator drive – Drive-belt check and adjustment | 6 – 53 |
| 6.17.2 Battery-charging generator drive – drive belt condition check | 6 – 55 |
| 6.17.3 Battery-charging generator drive – Drive belt replacement | 6 – 56 |
| 6.18 Ventilator Drive | 6 – 57 |
| 6.18.1 Ventilator drive – Drive-belt check and adjustment | 6 – 57 |
| 6.18.2 Ventilator drive – Drive belt replacement | 6 – 60 |
| 6.19 Engine Mounts | 6 – 61 |
| 6.19.1 Engine mounts – Resilient elements check | 6 – 61 |
| 6.20 General Wiring, Engine / Gearbox / Plant | 6 – 62 |
| 6.20.1 Engine wiring check | 6 – 62 |
| 6.21 Engine Governor (Electronic) Control System | 6 – 63 |
| 6.21.1 ECU – Removal and installation | 6 – 63 |
| 6.21.2 ECU and connectors cleaning | 6 – 64 |
| 6.21.3 ECU – checking plug-in connections | 6 – 65 |

6.1 Engine

6.1.1 Engine – Barring manually

Preconditions

- Engine is stopped and starting disabled.

Special tools


| Designation / Use | Part No. | Qty. |
|---------------------------------|----------|------|
| Barring tool for 12V engines | | |
| Barring tool for 16/18V engines | | |



Unguarded rotating and moving engine components.

Risk of serious injury - danger to life!

- Before barring or starting the engine, ensure that nobody is in the danger zone.
- After working on the engine, check that all protective devices have been reinstalled and all tools removed from the engine.



Engine – Barring manually

1. Remove cover from flywheel housing.
2. Install barring tool (arrow) on flywheel housing.
3. Rotate crankshaft in engine direction of rotation. Apart from the normal compression resistance, there should be no abnormal resistance.
Result: If the resistance exceeds the normal compression resistance, contact Service.
4. For barring-tool removal follow reverse sequence of working steps.

6.1.2 Engine – barring with starting system

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Connector pliers | | |




DANGER

Unguarded rotating and moving engine components.

Risk of serious injury - danger to life!

- Before barring or starting the engine, ensure that nobody is in the danger zone.
- After working on the engine, check that all protective devices have been reinstalled and all tools removed from the engine.



Barring engine with starting system

1. Disengage the bayonet ring-nut (4) of connector X4 with connector pliers (2) and withdraw connector (3) from ECU.
2. Bar engine in unloaded condition: Press START button.
3. Let the crankshaft rotate until oil pressure is indicated.
4. Engine start is automatically interrupted when specified starting period is expired. If necessary, re-start the engine after approx. 20 seconds.
5. Plug connector X4 (3) and use connector pliers (2) to secure the bayonet ring (4) by turning it clockwise until it latches into place.

6.1.3 Engine test run



DANGER

Unguarded rotating and moving engine components.

Risk of serious injury — danger to life!

- Before barring or starting the engine, ensure that nobody is in the danger zone.



WARNING

Engine noise above 85 dB (A).

Risk of damage to hearing!

- Wear ear protectors.

Engine test run

1. Start engine (→ Page 3 – 03).
2. Perform test run at not below 1/3 load and at least until steady-state temperature is reached.
3. Carry out operational checks (→ Page 3 – 05).
4. Stop engine (→ Page 3 – 06).

6.2 Cylinder Liner

6.2.1 Cylinder-liner endoscopic examination

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|--------------------------------------|----------|------|
| Rigid endoscope, max. diameter: 7 mm | | |

Preparatory steps

1. Remove cylinder-head cover (→ Page 6 – 13).
2. Remove injector (→ Page 6 – 19).

Bringing the piston to BDC position

1. Use the barring tool to rotate the crankshaft until the crank pin of the cylinder to be inspected is at BDC position.
2. Insert the endoscope through the cylinder-head injector bore into the combustion chamber.

| Findings | Task |
|---|--|
| <ul style="list-style-type: none"> • Thin carbon deposits around the carbon-residue control ring • Light, localized additive deposits on upper surface • Polished spots on lower edge • Ring of oil deposits in the area between the positions of the upper piston-ring and the lower edge of the carbon-residue control ring • Start of traces left by upper piston ring • Bright surface round circumference • Even honing pattern without complaint • Start of traces left by lower cooling-oil bores • Wear pattern appears to be darker | No measures necessary. |
| <ul style="list-style-type: none"> • Oxidation discoloration of even or uneven intensity. • Start and end of discolored areas have no clear edges and do not extend over the whole stroke length • Discolored areas become lighter in upper part of cooling bore; rest of circumference without complaint • Piston-ring set without complaint | Further endoscope check necessary during maintenance work. |
| <ul style="list-style-type: none"> • In addition to bright discolorations (which are not critical for engine operation), evidently darker "black zones" all over the running surface, beginning at upper-piston-ring TDC position • Overheating discoloration in piston stroke direction with damaged honing pattern • Piston rings show overheating discoloration | Cylinder liner must be replaced. Contact Service. |

Cylinder-liner endoscopic examination

1. Assess findings of endoscopic examination using the above table.
2. For description of findings on cylinder liner surface use the specified terms (→ Page 6 – 06).
3. Depending on the findings:
 - Do not take any measures, or
 - Conduct endoscopic examination of another liner in the course of maintenance work; or
 - Contact Service: Cylinder liner must be replaced.

Final steps

1. Install injector (→ Page 6 – 19).
2. Install cylinder-head cover (→ Page 6 – 13).

6.2.2 Instructions and comments on endoscopic and visual examination of cylinder liner

Terms used for endoscopic examination

Use the terms listed below to describe the condition of the cylinder-liner surface in the endoscopic examination report.

| | |
|--------------------------|--|
| Minor dirt scores | Light scoring can take place during the assembly of a new engine (honing products, particles, broken-off burrs). Removed cylinders clearly show such scoring on the running surface under endoscope magnification. Cannot be felt with the fingernail. Findings not critical. |
| Single scores | Clearly visible scores from hard particles. They usually start in the TDC area and cross through the hone pattern in the stroke direction. Findings not critical. |
| Scored area | These areas consist of scorings next to one another of different length and depth. In most cases, they are found at the 6–o'clock and 12–o'clock positions (inlet/exhaust) along the transverse engine axis. Findings not critical. |
| Smoothened area | Smoothened areas are on the running surface but almost the whole honing pattern is still visible. Smoothened areas appear brighter and more brilliant than the surrounding running surface. Findings not critical. |
| Polished area | Polished areas are on the running surface and show local removal of the honing pattern. Grooves from honing process are not visible any more. |
| Discoloration | This is caused by oxidation (surface discoloration through oil or fuel) and temperature differences around the liner. It appears rather darker within the honed structure in contrast to the bright metallic running surface. The honing pattern is undisturbed. Discolorations extend in stroke direction and may be interrupted. Findings not critical. |
| Corrosion fields / spots | Corrosion fields / spots result from water (condensed water) with the valves in the overlap (open) position. They are clearly visible due to the dark color of the honing groove bottom. This corrosion is not critical unless there are corrosion pittings. |
| Black lines | Black lines are a step towards to heat discoloration. They are visible as a clear discoloration from TDC to BDC in the running surface and the start of localized damage to the honing pattern. Cylinders with a number of black lines around the running surface have limited service life and should be replaced. |
| Discolorations (Heat) | These are caused by a disturbance in the liner / ring tribosystem. Usually they run over the whole ring-travel area (TDC/BDC), starting at the first TDC-ring and becoming more visible towards the second TDC-ring . The honing pattern is usually not visible any more and has a clearly defined (straight) edge to the undisturbed surface. The damaged surface is usually discolored. The circumferential length varies. Liners with heat discoloration starting in the TDC-ring 1 have to be replaced. |
| Corrosion | Corrosion traces have irregular circumferential length and depth. They can be caused by either the piston skirt or crown. The material deposit on the liner (smear) shows heavy discoloration and heavy scoring. Replace liner. |

Evaluation of findings and further measures

The findings in the start phase of oxidation discoloration and heat discoloration are similar. A definite opinion can first be made after a careful inspection and reference to the above criteria. To avoid unnecessary disassembly work, it is recommended that another inspection be carried out after further operation of the engine.

6.3 Crankcase Breather

6.3.1 Crankcase breather – oil separator replacement and diaphragm check

Preconditions


- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Torque wrench | | |


Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Filter element | | |
| Diaphragm | | |
| O-ring | | |



Oil separator replacement

1. Remove cover (2) with O-ring (3).
2. Remove filter element (1) from housing (4).
3. Insert new filter element into housing (4) observing correct installation position, and fit cover (2) with new sealing ring.
4. Tighten screws of cover (2) to 6 Nm + 2 Nm.
5. Replace filter elements of further oil separators in the same way.



Diaphragm check

1. Remove cover (5).
2. Take off spring (6), seal (4) and diaphragm (3).
3. Check diaphragm (3) for damage.
4. Replace diaphragm if damaged.
5. Mount diaphragm (3) on housing (2).
6. Install new seal (4) and spring (6) together with cover (5).
7. Tighten screws of cover (5) to 6 Nm + 2 Nm.
8. Check diaphragms in further oil separators in the same way.

6.4 Valve Gear


6.4.1 Valve clearance – Check and adjustment

Preconditions

- Engine is stopped and starting disabled.
- Engine coolant temperature is max. 40 °C.
- Valves are closed.


Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Feeler gauge | | |



Preparatory steps


1. Remove cylinder-head cover (→ Page 6 – 13).
2. Use barring tool to bar engine manually in engine direction of rotation (→ Page 6 – 01), until the markings are aligned.



- 1 Cylinder A1 is in firing TDC
- 2 Cylinder A1 is in overlap TDC
- I Inlet valve
- X Exhaust valve

Adjusting valve clearance in two crankshaft positions

1. Check TDC position of piston in cylinder A1:
 - If the rocker arms are not under load on cylinder A, the piston is in firing TDC.
 - If the rocker arms are under load on cylinder A, the piston is in overlap TDC.
2. Check valve clearance with cold engine:
 - Inlet = 0.4 mm;
 - Exhaust = 0.6 mm;
3. Check all valve clearances in two crankshaft positions (firing and overlap TDC for cylinder A1) as per diagram.
4. Use feeler gauge to determine the distance between valve bridge and rocker arm.
5. If the deviation from the reference value exceeds 0.1 mm, adjust valve clearance.



Valve clearance adjustment

1. Loosen locknut (1) and unscrew adjusting screw (2) by a few threads.
2. Insert feeler gauge between valve bridge and rocker arm.
3. Readjust adjusting screw (2) so that the feeler gauge just passes through the gap.
4. Tighten locknut (1) to 50 Nm, holding adjusting screw (2) firmly.
5. Check if the feeler gauge just passes through between valve bridge and rocker arm.
Result: If not, adjust valve clearance.

Final steps

1. Remove barring tool.
2. Install cylinder-head cover (→ Page 6 – 13).
3. Install cover.

6.4.2 Cylinder-head cover – Removal and installation

Preconditions

- Engine is stopped and starting disabled.

Special tools


| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Torque wrench | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Gasket | | |

Preparatory steps

1. On cylinder-head covers with crankcase breather: Loosen clamps.
2. Slide rubber sleeves onto the pipe.



Cylinder-head cover – Removal and installation

1. Remove screws.
2. Remove cylinder-head cover with gasket from cylinder head.
3. Clean mating faces.
4. Check condition of gasket in cylinder-head cover.
5. Replace damaged gasket(s).
6. Place cylinder-head covers onto crankcase and tighten screws to 20 Nm.

Final steps

1. Slide rubber sleeves onto the relevant pipe connection.
2. Tighten all clamps.

6.5 Injection Pump / HP Pump

6.5.1 Injection pump replacement

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Injection pump | | |

Remove injection pump and install new one (→ Page 6 – 15).

6.5.2 Injection pump removal and installation

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Barring tool | | |

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Petroleum jelly | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |
| Sealing ring | | |



Unguarded rotating and moving engine components.

Risk of serious injury — danger to life!


- Before barring the engine, ensure that nobody is in the danger zone.



Fuels are combustible.


Risk of fire and explosion!

- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



Preparatory steps

1. Shut off fuel supply line before fuel filter.
2. Remove engine control system (→ Page 6 – 63).
3. Drain fuel (→ Page 6 – 22).
4. Remove charge-air manifold and all seals.




Injection pump removal

1. Mark installation position of injection pump.
2. Disconnect wiring (1) from injection pump.
3. Remove fuel line (2).
4. Remove injection pump securing screws.

Note: Never try to prise loose a jammed injection pump at the solenoid valve or the intermediate plate.

5. Pull out injection pump, if required, press out carefully at the recess of the injection pump head.
6. Remove sealing rings from injection pump.
7. Cover installation bore.




Injection pump installation


1. Remove all blanking plugs and covers.
2. Clean mating face of injection pump and roller.

Note: Sealing rings are identified by different item numbers, pay attention to correct installation position!

3. Coat new sealing rings (1) and (2) with petroleum jelly and set them onto injection pump.
4. Coat roller (arrow) with engine oil.
5. Clean sealing face and installation bore on crankcase.
6. Use barring tool (→ Page 6–01) to align camshaft pump cams with base circle.



7. Install injection pump, observing marked installation position.
8. Tighten injection pump to 60 Nm + 12 Nm.
9. Install fuel line (2).
10. Tighten locknuts of the fuel line (2) to 20 Nm + 5 Nm.
11. Install injection pump wiring (1).
12. Tighten screws to 1.0 Nm +/- 0.2 Nm.

**Final steps**

1. Remove barring tool (→ Page 6–01).
2. Clean mating faces on cylinder head and charge-air manifold.
3. Check gaskets for damage and replace them, if required.
4. Set gasket onto cylinder head.
5. Install charge-air manifold.
6. Install engine control system (→ Page 6–63).
7. Open fuel supply line before fuel filter.
8. Vent fuel system (→ Page 6–23).

6.6 Fuel Injector

6.6.1 Injector replacement

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Injector | | |

Remove injector and install new one (→ Page 6 – 19).

6.6.2 Injector removal and installation

Preconditions

- Engine is stopped and starting disabled.

Special tools



| Designation / Use | Part No. | Qty. |
|---------------------|----------|------|
| Impact extractor | | |
| Fuel suction device | | |
| Torque wrench | | |

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Petroleum jelly | | |


Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |
| Sealing ring | | |

| | |
|---|---|
|  WARNING | Fuels are combustible. Risk of fire and explosion! <ul style="list-style-type: none"> • Avoid naked flames, electrical sparks and ignition sources. • Do not smoke. |
|  WARNING | Compressed air. Risk of injury! <ul style="list-style-type: none"> • Do not direct compressed-air jet at persons. • Wear protective goggles / safety mask and ear protectors. |


Preparatory steps

1. Remove cylinder head cover (→ Page 6 – 13).
2. Drain fuel (→ Page 6 – 22).




Injector removal


1. Remove leak-off-fuel lines.
2. Remove fuel line (3).
3. Remove thrust screw (2).
4. Pull off pressure pipe neck (1).
5. Extract fuel from the exposed bores using the suction device.
6. Seal all connections with appropriate plugs.



7. Remove screw (2).
8. Take off clamp (1).




9. Screw extractor into injector.
10. Remove injector using the impact extractor.
11. Remove sealing ring using a self-made hook.



Injector installation

1. Prior to installation, remove all plugs.
2. Clean sealing surface on cylinder head and protective sleeve.
3. Coat new sealing ring (1) with petroleum jelly and fit onto injector.
4. Coat new sealing ring (2) with petroleum jelly and fit onto injector.
5. Press injector into cylinder head by hand.
Result:
 - The pin must be at 11-o'clock position to the longitudinal axis of the engine.
 - The pin must be engaged in the groove of the clamp (4).
6. Install clamp (4) with screw (5), positioning it correctly.
Result: Forked clamp end must engage in the cover recess.
7. Check injector for correct seating.
8. Tighten clamp screw (5) to 50 Nm.
9. Blow out fuel line (3) and pressure pipe neck (1) with compressed air.
10. Coat new O-ring with petroleum jelly and fit on pressure pipe neck (1).
11. Coat sealing cone of pressure pipe neck with engine oil.
12. Insert pressure pipe neck into cylinder head until the sealing ring is in contact with cylinder head, do not press in yet!
13. Press pressure pipe neck (1) into cylinder head by hand.
14. Screw thrust screw (2) into cylinder head by a few threads.
15. Tighten thrust screw (2) to 40 Nm + 5 Nm.
16. Install fuel line (3).
17. Tighten union nut on injection pump to 30 Nm + 5 Nm.
18. Tighten union nut on pressure pipe neck to 20 Nm + 5 Nm.
19. Install leak-off-fuel lines.



Final steps

1. Install cylinder head cover (→ Page 6 – 13).
2. Vent fuel system (→ Page 6 – 23).

6.7 Fuel System (Low Pressure)

6.7.1 Fuel – Draining

Preconditions


- Engine is stopped and starting disabled.



Fuels are combustible.


Risk of fire and explosion!

- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



Fuel – Draining

1. Loosen nut (arrow) on banjo union.



2. Remove fuel line from non-return valve.
3. Unscrew non-return valve on end piece (arrow) and drain fuel into a suitable container.
4. When the fuel flow has stopped, install non-return valve with new sealing ring and tighten.
5. Install fuel line.
6. Tighten nut on banjo union.

6.7.2 Fuel system – Venting

Preconditions

- Engine is stopped and starting disabled.




WARNING

Fuels are combustible.

Risk of fire and explosion!


- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



08000030a


Fuel system – Venting

1. Unlock fuel priming pump, unscrew handle.




08000060a

2. Loosen nut (arrow) on banjo union.
3. Operate the pump with the handle until fuel without bubbles comes out of the vent plugs.
4. Tighten nut on banjo union.



5. Loosen banjo screw (arrow).
6. Operate the pump with the handle until fuel without bubbles comes out of the nipple.
7. Tighten banjo screw.



8. Loosen union nut of fuel return line.
9. Loosen non-return valve (arrow).
10. Operate the pump with the handle until fuel without bubbles comes out of the nipple.
11. Tighten non-return valve.
12. Tighten union nut of fuel return line.
13. Lock fuel priming pump, screw in handle.

6.8 Fuel Filter

6.8.1 Fuel filter – Replacement

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Strap wrench | | |

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel | | |

Spare parts


| Designation / Use | Part No. | Qty. |
|--------------------|----------|------|
| Easy-change filter | | |



Fuels are combustible.

Risk of fire and explosion!

- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



Fuel filter – Replacement

1. Remove easy-change filter using the strap wrench.
2. Clean the sealing surface on the bracket.
3. Fill the new easy-change filter with clean fuel.
4. Install and tighten new filter by hand.
5. Vent fuel system (→ Page 6 – 23).

6.8.2 Fuel prefilter cleaning

Preconditions

- Engine is stopped and starting disabled.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |




WARNING

Fuels are combustible.

Risk of fire and explosion!

- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



Fuel prefilter cleaning

1. Shut off fuel supply.
2. Remove nuts from filter head.
3. Take off filter housing and drain fuel into appropriate container.
4. Remove filter-element securing nut and remove filter element by pulling it downwards.
5. Wash filter element in clean fuel using a smooth brush.
6. Wash filter housing with clean fuel.
7. Insert filter element into filter housing and secure with nut.
8. Place new sealing ring into groove in filter head.
9. Fit cover with seal and secure it with nuts crosswise.
10. Open fuel supply.

6.8.3 Fuel prefilter – differential pressure check and adjustment of gauge



Unguarded rotating and moving engine components.

Risk of serious injury – danger to life!


- Take special care when working on a running engine.



Engine noise above 85 dB (A).

Risk of damage to hearing!

- Wear ear protectors.



Setting adjustable pointer of differential pressure gauge

1. After installation of a new filter element, align adjustable pointer (2) with pressure-indicating pointer (3) of pressure gauge (1).
2. Verify that differential pressure is within the limit.

Fuel prefilter – checking differential pressure

1. With the engine running at full load or rated power, read off pressure at gauge (1).
2. If differential pressure as indicated between position of adjustable pointer (2) and pressure-indicating pointer (3) of pressure gauge is ≥ 0.3 bar, flush filter element of the cut-in filter (→ Page 6 – 30).

6.8.4 Fuel prefilter – draining

Preconditions

- Engine is stopped and starting disabled.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Gasket | | |




WARNING

Fuels are combustible.

Risk of fire and explosion!


- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



- I Left filter cut in
II Right filter cut in

Fuel prefilter – draining

1. Cut out the filter to be drained.



2. Open vent plug (5) of the filter to be drained.
3. Unlock drain cock (6) by pressing toggle and open it.
4. Drain water and contaminants from the filter until pure fuel emerges.
5. Close drain cock (6).
6. Remove screws securing the cover and take off cover (2).
7. Fill filter housing with clean fuel.
8. Place new gasket in cover (2).
9. Fit cover with gasket and secure it with screws.
10. Cut the cut-out filter in again.
11. When fuel emerges from system, close vent plug (5).

6.8.5 Fuel prefilter – flushing

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Gasket | | |



Unguarded rotating and moving engine components.

Risk of serious injury – danger to life!

- Take special care when working on a running engine.



Fuels are combustible.

Risk of fire and explosion!


- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



Engine noise above 85 dB (A).

Risk of damage to hearing!


- Wear ear protectors.



Fuel prefilter – flushing

1. Cut out the contaminated filter.

- I Left filter cut in
II Right filter cut in



2. Open vent plug (5) of the filter to be flushed.
3. Unlock drain cock (6) by pressing toggle, open it and drain fuel.
Result: Fuel flows from filtered side back to the unfiltered side, flushing the filter deposits downwards out of the filter.
4. Close vent plug (5) and drain cock (6).

Fuel prefilter – filling fuel

1. Stop engine (→ Page 3 – 06) and disable engine start.
2. Remove screws securing the cover and take off cover (2).
3. Fill filter housing with clean fuel.
4. Place new gasket in cover (2).
5. Fit cover with gasket and secure it with screws.
6. Check differential pressure (→ Page 6 – 27).

Result: If flushing did not lead to an improvement of the differential pressure, replace filter element (→ Page 6 – 32).

6.8.6 Fuel prefilter – filter element replacement

Preconditions

- Engine is stopped and starting disabled.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Filter element | | |
| Gasket | | |




WARNING

Fuels are combustible.

Risk of fire and explosion!


- Avoid naked flames, electrical sparks and ignition sources.
- Do not smoke.



- I Left filter cut in
II Right filter cut in

Fuel prefilter – filter element replacement

1. Cut out the contaminated filter.



2. Open vent plug (5) of the contaminated filter.
3. Unlock drain cock (6) by pressing toggle and open it.
4. Drain water and contaminants from the filter.
5. Close drain cock (6).
6. Remove screws securing the cover and take off cover (2).
7. Remove spring (4) and filter element (3).
8. Insert new filter element (3) and spring (4).
9. Fill filter housing with clean fuel.
10. Place new gasket in cover (2).
11. Fit cover with gasket and secure it with screws.
12. Cut the cut-out filter in again.
13. Close vent plug (5) when fuel emerges.
14. Align adjustable pointer of differential pressure gauge with pressure-indicating pointer.
(→ Page 6 – 27).

6.9 Charge-Air Cooling, General, Left Side

6.9.1 Intercooler – Checking condensate drains for coolant discharge and obstructions

Preconditions

- Engine is stopped and starting disabled.

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |



WARNING

Compressed air.

Risk of injury!

- Do not direct compressed-air jet at persons.
- Wear protective goggles / safety mask and ear protectors.

Intercooler – Checking condensate drains for coolant discharge and obstructions

1. Remove plug screw(s) from charge-air manifold.
2. Check drain bore(s) for air discharge. If no air emerges:
3. Clean drain bore(s) and blow out with compressed air.
4. If a large amount of coolant is continuously discharged, the intercooler is leaking. Contact Service.
5. Install plug screw(s) with new sealing ring and tighten.

Emergency measures prior to engine start with a leaking intercooler

1. Remove injectors (→ Page 6 – 19).
2. Bar engine manually (→ Page 6 – 01).
3. Bar engine with starting system to blow out combustion chambers (→ Page 6 – 02).
4. Install injectors (→ Page 6 – 19).

6.10 Air Filter

6.10.1 Air filter replacement

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Air filter | | |


Remove air filter and install new one (→ Page 6 – 36).

Reset signal ring of service indicator (→ Page 6 – 37).

6.10.2 Air filter removal and installation

Preconditions

- Engine is stopped and starting disabled.



Air filter removal and installation


1. Loosen clamp (2).
2. Remove air filter (3) and clamp (2) from flange of intake housing (1).
3. Verify that there are no objects in the flange of the intake housing (1) and clean it.
4. Place new air filter (3) with clamp (2) onto intake housing (1).
5. Tighten clamp (2).

6.11 Air Intake

6.11.1 Service indicator – signal ring position check

Preconditions

- Engine is stopped and starting disabled.



Signal ring position check

1. If the signal ring is completely visible in the control window (2), replace air filter (→ Page 6 – 35).
2. After installation of new filter, press reset button (1).

Result: Engaged piston with signal ring moves back to initial position.

6.12 Starting System

6.12.1 Air starter – manual operation



Unguarded rotating and moving engine components.

Risk of serious injury — danger to life!


- Before barring or starting the engine, ensure that nobody is in the danger zone.



Engine noise above 85 dB (A).

Risk of damage to hearing!

- Wear ear protectors.



Air starter – manual operation

1. Press pushbutton for manual start and hold it.
2. Allow compressed air to enter the air starter until the engine fires evenly.
3. Release pushbutton.

6.13 Lube Oil System

6.13.1 Engine oil change

Preconditions

- Engine is stopped and starting disabled.
- Engine is at operating temperature.
- MTU Fluids and Lubricants Specification (A001061/..) is available.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil | | |

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |



WARNING

Hot engine oil.

Engine oil can contain combustion residues which are harmful to health.

Risk of injury and scalding!


- Wear protective clothing, gloves, and goggles / safety mask.
- Avoid contact with skin.
- Do not inhale oil vapor.

Oil change without semirotary hand pump: Draining oil at drain plug on oil pan

1. Provide a suitable container in which to collect the oil.
2. Remove drain plug and drain oil.
3. Install drain plug with new sealing ring.
4. Replace engine oil filter (→ Page 6 – 42).

Oil change using semirotary hand pump: Oil extraction

1. Provide a suitable container in which to collect the oil.
2. Extract all oil from oil pan using the hand pump.
3. Replace engine oil filter (→ Page 6 – 42).


**Engine oil system filling**

1. Determine amount of engine oil required for oil change (→ Product Summary - Technical Data).
2. Open cover of filler neck.
3. Pour oil in at filler neck up to "max." mark at oil dipstick.
4. Close cover of filler neck.
5. Check oil level (→ Page 6 – 41).
6. After oil change and oil filter replacement, bar engine with starting system (→ Page 6 – 02).

6.13.2 Engine oil level check

Preconditions

- Engine is stopped and starting disabled.



Oil level check prior to engine start

1. Withdraw dipstick from guide tube and wipe it.
2. Insert dipstick into guide tube to stop, withdraw after approx. 10 seconds and check oil level.
3. Oil level must be between "min." and "max." marks.
4. If necessary, top up to "max." mark (→ Page 6 – 39).
5. Insert dipstick into guide tube to stop.

Oil level check after the engine is stopped

1. 5 minutes after stopping the engine, remove oil dipstick from the guide tube and wipe it.
2. Insert dipstick into guide tube to stop, withdraw after approx. 10 seconds and check oil level.
3. Oil level must be between "min." and "max." marks.
4. If necessary, top up to "max." mark (→ Page 6 – 39).
5. Insert dipstick into guide tube to stop.

6.14 Oil Filtration / Cooling

6.14.1 Engine oil filter – Replacement

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Strap wrench | | |

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil | | |


Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Oil filter | | |



WARNING

- Hot engine oil.
Engine oil can contain combustion residues which are harmful to health.
- Risk of injury and scalding!**
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.



Engine oil filter – Replacement

1. Remove oil filter using the strap wrench.
2. Clean the sealing surface of the filter head.
3. Check condition of the new sealing ring and coat it with oil.
4. Install and tighten new oil filter by hand.
5. Replace further oil filters in the same way.
6. After each oil change and filter replacement, bar the engine using the starting device (→ Page 6 – 02).
7. Check oil level (→ Page 6 – 41).

6.15 Cooling System, General, HT Circuit

6.15.1 Engine coolant filling

Preconditions

- Engine is stopped and starting disabled.
- MTU Fluids and Lubricants Specification (A001061/..) is available.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine coolant | | |



Coolant is hot and under pressure.

Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.



Cold coolant in hot engine can cause thermal stress.

Formation of cracks in components!

- Fill / top up coolant only into cold engine.



Preparatory steps

1. Turn breather valve on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.

Engine coolant filling

1. Fill coolant through filler neck on expansion tank or through filling line until coolant level reaches lower edge of cast-in eye or marking plate.
2. Check proper condition of breather valve and clean sealing faces, if required.
3. Set breather valve onto filler neck and close it.

Final steps

1. Start the engine and operate it at idle speed for some minutes.
2. Check coolant level (→ Page 6 – 46) and top up, if required.

6.15.2 Engine coolant – Draining

Preconditions

- Engine is stopped and starting disabled.





Coolant is hot and under pressure.

Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

Preparatory steps

1. Provide an appropriate container to drain the coolant into.
2. Switch off preheating unit.



Engine coolant – Draining

1. Turn breather valve of filler neck on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Draw off precipitated corrosion inhibitor oil from the expansion tank through filler neck.
4. Open drain cocks or drain plugs and drain coolant at the following points:
 - At the preheating unit;
 - At the HT coolant pump;
 - On the crankcase, right side.
5. Draining of residual coolant:
 - On crankcase, left side;
 - On oil heat exchanger.
6. Seal all open drain points.
7. Set breather valve onto filler neck and close it.

6.15.3 Engine coolant change

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant | | |

Drain engine coolant (→ Page 6 – 44).

Fill engine coolant system (→ Page 6 – 43).

6.15.4 Engine coolant-level check

Preconditions


- Engine is stopped and starting disabled.
- MTU Fluids and Lubricants Specification (A001061/..) is available.



Coolant is hot and under pressure.

Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.



20000063a

Coolant-level check at filler neck:

1. Turn breather valve of filler neck on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Check coolant level (coolant must be visible at the lower edge of the cast-in eye).



01400308a

Coolant-level check at external cooler:

1. Check coolant level (coolant must be visible at marking plate).
2. If required, top up with treated engine coolant (→ Page 6 – 43).
3. Check proper condition of breather valve, clean sealing faces if required.
4. Fit breather valve onto filler neck and close it.

Coolant-level check by means of level sensor:

1. Switch engine control system ON and check display (coolant level is automatically monitored by the engine control system).
2. If required, top up with treated engine coolant (→ Page 6 – 43).

6.15.5 Cooling pump - Relief bore check



Unguarded rotating and moving engine components.

Risk of serious injury – danger to life!


- Take special care when working on a running engine.



Engine noise above 85 dB (A).

Risk of damage to hearing!

- Wear ear protectors.



Cooling pump - Relief bore check

1. Check relief bore for oil and water discharge.
2. Stop engine (→ Page 3–06) and disable engine start.
3. Clean the relief bore with a wire if it is dirty.
 - Permissible coolant discharge: up to 10 drops/hour;
 - Permissible coolant discharge: up to 5 drops/hour;
4. If coolant discharge exceeds the specified limits, contact Service.

6.16 Cooling System, LT Circuit

6.16.1 Charge-air coolant filling

Preconditions

- Engine is stopped and starting disabled.
- MTU Fluids and Lubricants Specification (A001061/..) is available.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant | | |

Spare parts


| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |



Engine noise above 85 dB (A).
Risk of damage to hearing!
 • Wear ear protectors.



Cold coolant in hot engine can cause thermal stress.
Formation of cracks in components!
 • Fill / top up coolant only into cold engine.



Preparatory steps

1. Turn breather valve on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Remove plug screw from filling point on coolant line to intercooler.

Charge-air coolant filling

1. Fill treated coolant through filling line or through filler neck of coolant expansion tank until coolant level reaches marking plate.
2. Install plug screws of filling points with new sealing rings.
3. Check proper condition of breather valve and clean sealing faces, if required.
4. Set breather valve onto filler neck and close it.

Final steps

1. Start the engine and operate it at idle speed for some minutes.
2. Check coolant level (→ Page 6 – 52).

6.16.2 Charge-air coolant – Draining

Preconditions

- Engine is stopped and starting disabled.

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Sealing ring | | |




WARNING

Coolant is hot and under pressure.

Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.



Charge-air coolant – Draining

1. Provide an appropriate container to drain the coolant into.
2. Turn breather valve of filler neck on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
3. Continue to turn breather valve counterclockwise and remove.
4. Draw off precipitated corrosion inhibitor oil from the expansion tank through filler neck.
5. Open drain plugs and drain coolant at the following points:
 - at the LT cooling pump;
 - at the coolant line (customer's equipment).
6. Draining of residual coolant:
 - at charge-air cooler.
7. Screw in drain plugs with new sealing rings.
8. Fit breather valve onto filler neck and close it.

6.16.3 Charge-air coolant change

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant | | |

Drain charge-air coolant system (→ Page 6 – 50).

Fill charge-air coolant system (→ Page 6 – 48).

6.16.4 Charge-air coolant level check

Preconditions


- Engine is stopped and starting disabled.
- MTU Fluids and Lubricants Specification (A001061/..) is available.



Coolant is hot and under pressure.

Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.



Charge-air coolant level check at filler neck:

1. Turn breather valve of filler neck on coolant expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Check coolant level (coolant must be visible at marking plate).
4. If required, top up with treated coolant (→ Page 6 – 48).
5. Check proper condition of breather valve, clean sealing faces if required.
6. Fit breather valve onto filler neck and close it.

Charge-air coolant level check by means of level sensor:

1. Switch engine control system ON and check display (coolant level is automatically monitored by the engine control system).
2. If required, top up with treated coolant (→ Page 6 – 48).

6.17 Battery-Charging Generator


6.17.1 Battery-charging generator drive – Drive-belt check and adjustment

Preconditions

- Engine is stopped and starting disabled.


Special tools

| Designation / Use | Part No. | Qty. |
|---------------------|----------|------|
| Belt-tension tester | | |




Belt condition check

1. Remove guard cover.
2. Check belt for contamination by oil, cracks, wear, and signs of overheating.
3. Replace drive belt:
 - If belt is oily;
 - If belt shows signs of overheating;
 - If ribs are broken around the entire circumference (A);
 - If ribs are broken around the entire circumference and material is broken off in some places (B). (→ Page 6 – 56)
4. Install guard cover.



Belt tension check

1. Remove guard cover.
2. Place belt-tension tester onto drive belt midway between the belt pulleys.
3. Press button uniformly down on drive-belt surface until spring disengagement can be heard and felt.
4. Do not press any further, otherwise the reading is not exact.
5. Take off belt-tension tester without changing the position of the indication arm.
6. Read off measuring value at the intersection of indication arm and "KG" scale.
 - Specified belt tension for new drive belt: 450 N –50 N
 - Specified belt tension for used drive belt: 350 N –50 N
7. If the measured value deviates from the specified belt tension, readjust belt tension.
8. Install guard cover.




Belt tension adjustment

1. Loosen securing screws (2 and 3).
2. Tension ribbed drive belt with tensioning nut (1) and check belt tension
3. Tighten securing screw (2).
 - Tightening torque: 40 Nm +4 Nm
4. Tighten securing screw (3).
5. Check drive belt tension.
6. Install guard cover.

6.17.2 Battery-charging generator drive – drive belt condition check

Preconditions

- Engine is stopped and starting disabled.



Belt condition check

1. Remove guard cover.
2. Check belt for contamination by oil, cracks, wear, and signs of overheating.
3. Replace drive belt:
 - If belt is oily;
 - If belt shows signs of overheating;
 - If ribs are broken around the entire circumference (A);
 - If ribs are broken around the entire circumference and material is broken off in some places (B) (→ Page 6 – 56).
4. Install guard cover.


6.17.3 Battery-charging generator drive – Drive belt replacement

Preconditions

- Engine is stopped and starting disabled.

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Ribbed belt | | |



Battery-charging generator drive – Drive belt replacement

1. Remove guard cover.
2. Remove ventilator drive belt (applicable only to TD cooling). (→ Page 6–60)
3. Loosen securing screws (2 and 3).
4. Release tensioning screw (1) until the ribbed belt can be removed.
5. Check belt pulleys for cleanliness, remove dirt, if any.
6. Fit new drive belt.
7. Tension drive belt with tensioning nut (1) and check belt tension (→ Page 6–53).
8. Tighten securing screw (2).
 - Tightening torque: 40 Nm +4 Nm
9. Tighten securing screw (3).
10. Install ventilator drive belt (→ Page 6–60)
11. Install guard cover.

6.18 Ventilator Drive

6.18.1 Ventilator drive – Drive-belt check and adjustment

Preconditions

- Engine is stopped and starting disabled.

Special tools


| Designation / Use | Part No. | Qty. |
|---------------------|----------|------|
| Belt-tension tester | | |

Preparatory steps

1. Remove screws from guard cover.
2. Remove guard cover.


Belt condition check

1. Remove guard cover.
2. Check V-belt for contamination by oil, cracks, wear, chunking and signs of overheating.
3. Replace V-belt:
 - If belt is oily;
 - If belt shows signs of overheating;
 - If belt shows cracks;
 - If belt is worn;
 - If belt is chunked (→ Page 6 – 60).




Belt-tension check on 12/16V engines:

1. Place belt-tension tester onto V-belt midway between the belt pulleys (arrow).
2. Press button uniformly against V-belt surface until spring disengagement can be heard and felt.
3. Take off belt-tension tester without changing the position of the indication arm.
4. Read off measured value at the intersection of indication arm and "KG" scale.
 - Specified belt tension for new V-belt: 660 N
 - Specified belt tension for used V-belt: 510 N
5. If the measured value deviates from the specified belt tension, readjust belt tension.




Belt-tension check on 18V engines:

1. Place belt-tension tester onto V-belt midway between the belt pulleys (arrow).
2. Press button uniformly against V-belt surface until spring disengagement can be heard and felt.
3. Take off belt-tension tester without changing the position of the indication arm.
4. Read off measured value at the intersection of indication arm and "KG" scale.
 - Specified belt tension for new drive belt: 670 N —50 N
 - Specified belt tension for used drive belt: 570 N —50 N
5. If the measured value deviates from the specified belt tension, readjust belt tension.



Belt-tension adjustment on 12/16V engines:

1. Loosen securing screws (3).
2. Release locknut (2).
3. Screw in tensioning screw (1) to set specified belt tension.
4. Tighten locknut.
5. Check V-belt tension.
6. Tighten securing screws with torque wrench.
 - Tightening torque: 100 Nm



Belt-tension adjustment on 18V engines:

1. Loosen securing screws (1 and 4).
- Note:** On engines for 50 Hz generators, bolt (3) must be in position (A). On all other engines, it must be in position (B).
2. Screw in tensioning screw (2) to tension V-belt.
3. Check V-belt tension.
4. Tighten securing screws (1 and 4) with torque wrench.
 - Tightening torque: 69 Nm
5. Check V-belt tension.

Final steps

1. Install guard cover.
2. Fit screws and tighten.

6.18.2 Ventilator drive – Drive belt replacement

Preconditions


- Engine is stopped and starting disabled.

Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| V-belt | | |

Preparatory steps

1. Remove guard cover from cooler.
2. Remove ventilator.




Drive belt replacement on 12V/16V engines:

1. Loosen securing screws (3).
2. Release locknut (2).
3. Screw out tensioning screw (1) until V-belts can be removed.
4. Check belt pulley on ventilator bearing pedestal and crankshaft for contamination, clean if necessary.

Note: V-belts must only be fitted in the grooves as a set and without applying any force.

5. Fit new set of drive belts.
6. To check V-belt tension, the ventilator bearing pedestal must rest against the gearcase.
7. Adjust and check V-belt tension (→ Page 6 – 57).



Drive belt replacement on 18V engines:

1. Loosen securing screws (1 and 4).
2. Unscrew tensioning screw (2) with bolt (3) until the V-belts can be removed.
3. Check belt pulley on ventilator bearing pedestal and crankshaft for contamination, clean if necessary.

Note: V-belts must only be fitted in the grooves as a set and without applying any force.

4. Fit new set of drive belts.
5. To check V-belt tension, the ventilator bearing pedestal must rest against the gearcase.
6. Adjust and check V-belt tension (→ Page 6 – 57).

Final steps


1. Install ventilator.
2. Install guard cover.

6.19 Engine Mounts

6.19.1 Engine mounts – Resilient elements check

Preconditions

- Engine is stopped and starting disabled.
- Engine is filled with coolant and engine oil.



Engine mounts – Resilient elements check

1. Wipe rubber surface with dry cloth, do not use organic detergents.
2. Check resilient elements for crack formation and deformation by visual inspection.
3. Have cracked elements replaced, contact Service.

Setting dimension check

1. Measure setting dimension:
 - Dimension (a) = 55 mm.
2. If dimension (a) is less than 55 mm, resilient elements must be replaced. Contact Service.

6.20 General Wiring, Engine / Gearbox / Plant

6.20.1 Engine wiring check

Preconditions

- Engine is stopped and starting disabled.

Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Isopropyl alcohol | | |

Engine wiring check

1. Check securing screws of cable clamps on the engine and tighten loose screw connections.
2. Make certain that cables are securely seated in clamps and cannot move freely.
3. Check cable binders for secure seating, tighten loose cable binders.
4. Replace defective cable binders.
5. Inspect electrical components visually for damage:
 - connector housings;
 - contacts;
 - connector sockets;
 - cables and terminals;
 - plug-in contacts.
6. If conductors are damaged, contact Service.
7. Clean dirty connector housings, sockets and contacts with isopropyl alcohol.

6.21 Engine Governor (Electronic) Control System


6.21.1 ECU – Removal and installation

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|----------------------------------|----------|------|
| Connector pliers | | |
| Covering caps for Cannon sockets | | |



ECU – Removal

1. Note or mark assignment of cables to connector sockets.
2. Use connector pliers (2) to disengage the bayonet union nuts (4) of the connectors (3) by turning them counterclockwise.
3. Withdraw all connectors.
4. Close connector sockets with appropriate covering caps (1).
5. Disconnect grounding strip from ECU grounding pin .
6. Unscrew corresponding screws and remove ECU.

ECU – Installation

1. Follow reverse sequence of operations as described for removal. Ensure correct assignment of connectors to sockets.
2. Use connector pliers to turn the bayonet union nuts of the connectors clockwise until they lock into place.

6.21.2 ECU and connectors cleaning

Preconditions


- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Connector pliers | | |


Material

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Isopropyl alcohol | | |



ECU and connectors cleaning

1. Remove coarse dirt from housing surface using a cloth moistened with isopropyl alcohol.
2. Remove dirt from surface of connectors (1), connector sockets and shrink sleeves (2) using a cloth moistened with isopropyl alcohol.
3. Check legibility of cable labels. Clean or replace illegible labels.



Cleaning severely contaminated connectors on ECU

1. Use connector pliers (2) to disengage bayonet union nut (4) and withdraw connector (3).
2. Clean connector housings, connector socket housings (1) and all contacts with isopropyl alcohol.
3. When connectors, sockets and all contacts are dry: Install connectors and check plug-in connection on ECU (→ Page 6 – 65).


6.21.3 ECU – checking plug-in connections

Preconditions

- Engine is stopped and starting disabled.

Special tools

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Connector pliers | | |



ECU – checking plug-in connections

1. Use connector pliers (3) to make certain that all plug-in connections of ECU are securely seated.
2. Tighten loose bayonet union nuts (2) with connector pliers (3) by turning them clockwise until they lock into place.
3. Ensure that unassigned connector sockets are protected with covering caps.

7 Annex

7.1 Abbreviations **7-01**

7.2 Index **7-03**

7.1 Abbreviations

| Abbrevia- tion | Meaning | Explanation |
|-------------------|---|--|
| ANSI | American National Standards Institute | |
| ATL | Abgasturbolader | Turbocharger |
| BR | Baureihe | Engine Series |
| CAN | Controller Area Network | |
| DIN | Deutsches Institut für Normung e. V. | German Standardization Organization, at the same time identifier of German standards (DIN = "Deutsche Industrie-Norm") |
| DL | Default Lost | Alarm: Default CAN bus failure |
| ECU | Engine Control Unit | |
| EDM | Engine Data Module | |
| EEPROM | Electrically Erasable and Programmable Read-Only Memory | |
| EMU | Engine Monitoring Unit | |
| FLS | Fluids and Lubricants Specification | MTU Publication No. A01061/.. |
| HI | High | Alarm: Measured value exceeds 1st maximum limit |
| HIHI | High High | Alarm: Measured value exceeds 2nd maximum limit |
| HT | High Temperature | |
| IDM | Interface Data Module | |
| ISO | International Organization for Standardization | |
| KGS | Kraftgegenseite | Engine free end in accordance with DIN ISO 1204 |
| KS | Kraftseite | Engine driving end in accordance with DIN ISO 1204 |
| LED | Light Emitting Diode | |
| LO | Low | Alarm: Measured value lower than 1st minimum limit |
| LOLO | Low Low | Alarm: Measured value lower than 2nd minimum limit |
| OT | Oberer Totpunkt | Top dead center (TDC) |
| P-xyz | Pressure-xyz | Pressure measuring point xyz |
| PAN | Panel | |
| PIM | Peripheral Interface Module | |
| RL | Redundancy Lost | Alarm: Redundant CAN bus failure |
| SAE | Society of Automotive Engineers | U.S. standardization organization |
| SD | Sensor Defect | Alarm: Sensor failure |
| SS | Safety System | Alarm initiated by safety system |

| Abbrevia- tion | Meaning | Explanation |
|---------------------------|-----------------------|---------------------------------|
| SPC | Spare Parts Catalog | |
| T-xyz | Temperature-xyz | Temperature measuring point xyz |
| TC | Tools Catalog | |
| TD | Transmitter Deviation | |
| UT | Unterer Totpunkt | Bottom dead center (BDC) |

7.2 Index

| | |
|--|--------|
| 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized fuel consumption | 2 – 15 |
| 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized fuel consumption | 2 – 47 |
| 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Air-cooled charge air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 29 |
| 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Water-cooled charge-air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 61 |
| 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 10 |
| 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized fuel consumption | 2 – 05 |
| 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 42 |
| 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized fuel consumption | 2 – 37 |
| 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 25 |
| 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (TA-Luft) | 2 – 20 |
| 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 57 |
| 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (TA-Luft) | 2 – 52 |

A

| | |
|--|--------|
| Abbreviations | 7 – 01 |
| After stopping the engine – engine remains ready for operation | 3 – 08 |
| After stopping the engine – putting the engine out of service | 3 – 09 |
| Air Filter | 6 – 35 |
| Air filter removal and installation | 6 – 36 |

| | |
|---|--------|
| Air filter replacement | 6 – 35 |
| Air filter removal and installation | 6 – 36 |
| Air filter replacement | 6 – 35 |
| Air Intake | 6 – 37 |
| Service indicator – signal ring position check | 6 – 37 |
| Air starter – manual operation | 6 – 38 |
| Auxiliary materials, fire prevention and environmental protection | 1 – 07 |

B

| | |
|--|--------|
| Battery-Charging Generator | 6 – 53 |
| Battery-charging generator drive – drive belt condition check | 6 – 55 |
| Battery-charging generator drive – Drive belt replacement | 6 – 56 |
| Battery-charging generator drive – Drive-belt check and adjustment | 6 – 53 |
| Battery-charging generator drive – drive belt condition check | 6 – 55 |
| Battery-charging generator drive – Drive belt replacement | 6 – 56 |
| Battery-charging generator drive – Drive-belt check and adjustment | 6 – 53 |

C

| | |
|---|--------|
| Charge-air coolant – Draining | 6 – 50 |
| Charge-air coolant change | 6 – 51 |
| Charge-air coolant filling | 6 – 48 |
| Charge-air coolant level check | 6 – 52 |
| Charge-Air Cooling, General, Left Side | 6 – 34 |
| Intercooler – Checking condensate drains for coolant discharge and obstructions | 6 – 34 |
| Cooling pump - Relief bore check | 6 – 47 |
| Cooling System, General, HT Circuit | 6 – 43 |
| Cooling pump - Relief bore check | 6 – 47 |
| Engine coolant – Draining | 6 – 44 |
| Engine coolant change | 6 – 45 |
| Engine coolant filling | 6 – 43 |
| Engine coolant-level check | 6 – 46 |
| Cooling System, LT Circuit | 6 – 48 |
| Charge-air coolant – Draining | 6 – 50 |
| Charge-air coolant change | 6 – 51 |
| Charge-air coolant filling | 6 – 48 |
| Charge-air coolant level check | 6 – 52 |
| Crankcase Breather | 6 – 08 |
| Crankcase breather – oil separator replacement and diaphragm check | 6 – 08 |
| Crankcase breather – oil separator replacement and diaphragm check | 6 – 08 |

| | | | |
|--|--------|--|--------|
| Cylinder Liner | 6 – 04 | 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 42 |
| Cylinder-liner endoscopic examination | 6 – 04 | 12/16/18V 2000 Standby operation: Application Group 3D, Water-cooled charge-air, Optimized fuel consumption | 2 – 37 |
| Instructions and comments on endoscopic and visual examination of cylinder liner | 6 – 06 | 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 25 |
| Cylinder-head cover – Removal and installation | 6 – 13 | 12/16/18V Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized exhaust emission (TA-Luft) | 2 – 20 |
| Cylinder-liner endoscopic examination | 6 – 04 | 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 57 |
| | | 12/16/18V Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized exhaust emission (TA-Luft) | 2 – 52 |
| | | Final compression pressure | 2 – 70 |
| | | Firing order | 2 – 69 |
| | | Engine Governor (Electronic) Control System | 6 – 63 |
| | | ECU – checking plug-in connections | 6 – 65 |
| | | ECU – Removal and installation | 6 – 63 |
| | | ECU and connectors cleaning | 6 – 64 |
| | | Engine layout | 2 – 01 |
| | | Engine Layout | 2 – 01 |
| | | Engine layout | 2 – 01 |
| | | Engine Mounts | 6 – 61 |
| | | Engine mounts – Resilient elements check | 6 – 61 |
| | | Engine mounts – Resilient elements check | 6 – 61 |
| | | Engine oil change | 6 – 39 |
| | | Engine oil filter – Replacement | 6 – 42 |
| | | Engine oil level check | 6 – 41 |
| | | Engine side and cylinder designations | 2 – 03 |
| | | Engine Side and Cylinder Designations | 2 – 03 |
| | | Engine side and cylinder designations | 2 – 03 |
| | | Engine test run | 6 – 03 |
| | | Engine wiring check | 6 – 62 |
| | | F | |
| | | Final compression pressure | 2 – 70 |
| | | Firing order | 2 – 69 |
| | | Fuel – Draining | 6 – 22 |
| E | | | |
| ECU – checking plug-in connections | 6 – 65 | | |
| ECU – Removal and installation | 6 – 63 | | |
| ECU alarms | 5 – 04 | | |
| ECU and connectors cleaning | 6 – 64 | | |
| Emergency start (override mode) | 3 – 04 | | |
| Emergency stop | 3 – 07 | | |
| Engine | 6 – 01 | | |
| Engine – Barring manually | 6 – 01 | | |
| Engine – barring with starting system | 6 – 02 | | |
| Engine test run | 6 – 03 | | |
| Engine – Barring manually | 6 – 01 | | |
| Engine – barring with starting system | 6 – 02 | | |
| Engine coolant – Draining | 6 – 44 | | |
| Engine coolant change | 6 – 45 | | |
| Engine coolant filling | 6 – 43 | | |
| Engine coolant-level check | 6 – 46 | | |
| Engine Data | 2 – 05 | | |
| 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Air-cooled charge air, Optimized fuel consumption | 2 – 15 | | |
| 12/16/18V 2000 Continuous operation with variable load: Application group 3B, Water-cooled charge-air, Optimized fuel consumption | 2 – 47 | | |
| 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Air-cooled charge air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 29 | | |
| 12/16/18V 2000 Continuous operation, unrestricted: Application group 3B, Water-cooled charge-air, Optimized fuel consumption, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 61 | | |
| 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized exhaust emission (EPA 40 CFR89 / Tier 1) | 2 – 10 | | |
| 12/16/18V 2000 Standby operation: Application Group 3D, Air-cooled charge air, Optimized fuel consumption | 2 – 05 | | |

- | | | | |
|--|--------|---|--------------------------------|
| Fuel Filter | 6 – 25 | Main Engine Dimensions | 2 – 04 |
| Fuel filter – Replacement | 6 – 25 | Main engine dimensions | 2 – 04 |
| Fuel prefilter – differential pressure check and adjustment of gauge | 6 – 27 | Maintenance and servicing | 4 – 01 |
| Fuel prefilter – draining | 6 – 28 | Maintenance and Servicing | 4 – 01 |
| Fuel prefilter – filter element replacement | 6 – 32 | Maintenance and servicing | 4 – 01 |
| Fuel prefilter – flushing | 6 – 30 | Maintenance schedule | 4 – 02, 4 – 05, 4 – 08, 4 – 11 |
| Fuel prefilter cleaning | 6 – 26 | Maintenance Schedule – Application Group | |
| Fuel filter – Replacement | 6 – 25 | 3A | 4 – 11 |
| Fuel Injector | 6 – 18 | Maintenance schedule | 4 – 11 |
| Injector removal and installation | 6 – 19 | Maintenance Schedule – Application Group | |
| Injector replacement | 6 – 18 | 3B | 4 – 05 |
| Fuel prefilter – differential pressure check and adjustment of gauge | 6 – 27 | Maintenance schedule | 4 – 05 |
| Fuel prefilter – draining | 6 – 28 | Maintenance Schedule – Application Group 3B | |
| Fuel prefilter – filter element replacement | 6 – 32 | TAL | 4 – 08 |
| Fuel prefilter – flushing | 6 – 30 | Maintenance schedule | 4 – 08 |
| Fuel prefilter cleaning | 6 – 26 | Maintenance Schedule – Application Group | |
| Fuel system – Venting | 6 – 23 | 3D | 4 – 02 |
| Fuel System (Low Pressure) | 6 – 22 | Maintenance schedule | 4 – 02 |
| Fuel – Draining | 6 – 22 | | |
| Fuel system – Venting | 6 – 23 | | |
| | | O | |
| | | Oil Filtration / Cooling | 6 – 42 |
| | | Engine oil filter – Replacement | 6 – 42 |
| | | Operational checks | 3 – 05 |
| | | | |
| | | P | |
| | | Personnel and organizational requirements | 1 – 02 |
| | | Putting the engine into operation after extended out-of-service periods (>3 months) | 3 – 01 |
| | | Putting the engine into operation after scheduled out-of-service-period | 3 – 02 |
| | | | |
| | | S | |
| | | Safety precautions when working on the engine | 1 – 04 |
| | | Service indicator – signal ring position check | 6 – 37 |
| | | Standards for warning notices in the publication | 1 – 09 |
| | | Starting System | 6 – 38 |
| | | Air starter – manual operation | 6 – 38 |
| | | Starting the engine in manual mode | 3 – 03 |
| | | Stopping the engine in manual mode | 3 – 06 |
| | | | |
| | | T | |
| | | Transport | 1 – 03 |
| | | Troubleshooting | 5 – 01 |
| | | | |
| | | V | |
| | | Valve clearance – Check and adjustment | 6 – 10 |
-
- | | |
|--|--------|
| G | |
| General conditions | 1 – 01 |
| General Wiring, Engine / Gearbox / Plant | 6 – 62 |
| Engine wiring check | 6 – 62 |
| | |
| I | |
| Index | 7 – 03 |
| Injection Pump / HP Pump | 6 – 14 |
| Injection pump removal and installation | 6 – 15 |
| Injection pump replacement | 6 – 14 |
| Injection pump removal and installation | 6 – 15 |
| Injection pump replacement | 6 – 14 |
| Injector removal and installation | 6 – 19 |
| Injector replacement | 6 – 18 |
| Instructions and comments on endoscopic and visual examination of cylinder liner | 6 – 06 |
| Intercooler – Checking condensate drains for coolant discharge and obstructions | 6 – 34 |
| | |
| L | |
| Lube Oil System | 6 – 39 |
| Engine oil change | 6 – 39 |
| Engine oil level check | 6 – 41 |
| | |
| M | |
| Main engine dimensions | 2 – 04 |

| | | | |
|---|--------|---|--------|
| Valve Gear | 6 – 10 | Ventilator drive – Drive-belt check and adjustment | 6 – 57 |
| Cylinder-head cover – Removal and installation | 6 – 13 | Ventilator drive – Drive belt replacement | 6 – 60 |
| Valve clearance – Check and adjustment | 6 – 10 | Ventilator drive – Drive-belt check and adjustment | 6 – 57 |
| Ventilator Drive | 6 – 57 | | |
| Ventilator drive – Drive belt replacement | 6 – 60 | | |