



# **YFM50S**

## **SERVICE MANUAL**

---

EBS00001

**YFM50S  
SERVICE MANUAL  
©2003 by Yamaha Motor Corporation, U.S.A.  
First Edition, April 2003  
All rights reserved.  
Any reproduction or unauthorized use  
without the written permission of  
Yamaha Motor Corporation, U.S.A.  
is expressly prohibited.  
Printed in U.S.A.  
LIT-11616-17-13**

## NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

**NOTE:**

Designs and specifications are subject to change without notice.

## IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person checking or repairing the machine.

**CAUTION:**

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

**NOTE:**

A NOTE provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

## MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “symbols”)

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.



2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

























## EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.





① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ CARB 	⑥ DRIV 	
⑦ CHAS 	⑧ ELEC 	
⑨ TRBL SHTG 	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	⑰ 
⑱ 	⑲ 	⑳ 
㉑ 	㉒ 	㉓ 
㉔ 	㉕ New	

EBS00005

## SYMBOLS

The following symbols are not relevant to every machine.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Carburetor
- ⑥ Drive train
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Symbols ⑩ to ⑰ indicate the following.

- ⑩ Serviceable with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Electrical data ( $\Omega$ , V, A)










Symbols ⑱ to ㉓ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑱ Apply engine oil
- ⑲ Apply gear oil
- ⑳ Apply molybdenum disulfide oil
- ㉑ Apply wheel bearing grease
- ㉒ Apply lithium-soap-based grease
- ㉓ Apply molybdenum disulfide grease

Symbols ㉔ to ㉕ in the exploded diagrams indicate where to apply a locking agent ㉔ and when to install a new part ㉕.

- ㉔ Apply the locking agent (LOCTITE®)
- ㉕ Replace

# TABLE OF CONTENTS

GENERAL INFORMATION		
	GEN INFO	<b>1</b>
SPECIFICATIONS		
	SPEC	<b>2</b>
PERIODIC CHECKS AND ADJUSTMENTS		
	CHK ADJ	<b>3</b>
ENGINE		
	ENG	<b>4</b>
CARBURETOR		
	CARB	<b>5</b>
DRIVE TRAIN		
	DRIV	<b>6</b>
CHASSIS		
	CHAS	<b>7</b>
ELECTRICAL		
	ELEC	<b>8</b>
TROUBLESHOOTING		
	TRBL SHTG	<b>9</b>

---

# CONTENTS

## CHAPTER 1 GENERAL INFORMATION

<b>MACHINE IDENTIFICATION</b> .....	1-1
VEHICLE IDENTIFICATION NUMBER .....	1-1
MODEL LABEL.....	1-1
<b>IMPORTANT INFORMATION</b> .....	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY.....	1-2
REPLACEMENT PARTS.....	1-2
GASKETS, OIL SEALS AND O-RINGS .....	1-2
LOCK WASHERS/PLATES AND COTTER PINS .....	1-3
BEARINGS AND OIL SEALS .....	1-3
CIRCLIPS .....	1-3
CHECKING THE CONNECTIONS.....	1-4
<b>SPECIAL TOOLS</b> .....	1-5

## CHAPTER 2 SPECIFICATIONS

<b>GENERAL SPECIFICATIONS</b> .....	2-1
<b>ENGINE SPECIFICATIONS</b> .....	2-4
<b>CHASSIS SPECIFICATIONS</b> .....	2-11
<b>ELECTRICAL SPECIFICATIONS</b> .....	2-12
<b>TIGHTENING TORQUES</b> .....	2-14
ENGINE TIGHTENING TORQUES.....	2-14
CHASSIS TIGHTENING TORQUES .....	2-15
<b>HOW TO USE THE CONVERSION TABLE</b> .....	2-17
<b>GENERAL TIGHTENING TORQUE SPECIFICATIONS</b> .....	2-17
<b>LUBRICATION POINTS AND LUBRICANT TYPES</b> .....	2-18
ENGINE.....	2-18

---

<b>OIL FLOW DIAGRAMS</b> .....	2-20
<b>CABLE ROUTING</b> .....	2-22

## **CHAPTER 3**

### **PERIODIC CHECKS AND ADJUSTMENTS**

<b>INTRODUCTION</b> .....	3-1
<b>PERIODIC MAINTENANCE/LUBRICATION</b> .....	3-1
<b>SEAT, FENDERS AND FUEL TANK</b> .....	3-2
SEAT AND FRONT PANEL .....	3-2
FRONT FENDER .....	3-3
REAR FENDER AND FOOTREST BOARDS .....	3-4
FUEL TANK.....	3-6
<b>ENGINE</b> .....	3-7
ADJUSTING THE TIMING CHAIN TENSIONER .....	3-7
ADJUSTING THE VALVE CLEARANCE .....	3-8
ADJUSTING THE ENGINE IDLING SPEED .....	3-10
ADJUSTING THE THROTTLE LEVER FREE PLAY .....	3-11
ADJUSTING THE SPEED LIMITER.....	3-12
CHECKING THE SPARK PLUG .....	3-13
CHECKING THE IGNITION TIMING.....	3-14
MEASURING THE COMPRESSION PRESSURE.....	3-15
CHECKING THE ENGINE OIL LEVEL.....	3-17
CHANGING THE ENGINE OIL .....	3-18
CLEANING THE AIR FILTER ELEMENT.....	3-19
CLEANING THE SPARK ARRESTER .....	3-20
<b>CHASSIS</b> .....	3-22
CHECKING THE FRONT AND REAR BRAKE SHOES.....	3-22
ADJUSTING THE FRONT BRAKE .....	3-22
ADJUSTING THE REAR BRAKE.....	3-23
CHECKING THE FINAL GEAR OIL LEVEL .....	3-24
CHANGING THE FINAL GEAR OIL.....	3-24
CHECKING THE SWINGARM DUST BOOT .....	3-25
CHECKING THE STEERING SYSTEM .....	3-26
ADJUSTING THE TOE-IN.....	3-27
CHECKING THE FRONT AND REAR SHOCK ABSORBERS .....	3-28
CHECKING THE TIRES.....	3-29
CHECKING THE WHEELS .....	3-31
CHECKING AND LUBRICATING THE CABLES .....	3-32
LUBRICATING THE LEVERS, STEERING SHAFT AND STEERING KNUCKLES .....	3-32

---

<b>ELECTRICAL SYSTEM.....</b>	<b>3-33</b>
CHECKING AND CHARGING THE BATTERY .....	3-33
CHECKING THE FUSE .....	3-37

## CHAPTER 4

### ENGINE

<b>ENGINE .....</b>	<b>4-1</b>
EXHAUST PIPE/MUFFLER, BREATHER HOSE AND LEADS .....	4-1
ENGINE MOUNTING BOLTS .....	4-2
REMOVING THE ENGINE .....	4-4
INSTALLING THE ENGINE.....	4-4
 <b>CYLINDER HEAD.....</b>	 <b>4-5</b>
REMOVING THE CYLINDER HEAD.....	4-7
CHECKING THE CAMSHAFT SPROCKET .....	4-8
CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER.....	4-8
CHECKING THE TIMING CHAIN GUIDES .....	4-8
CHECKING THE TIMING CHAIN TENSIONER ASSEMBLY .....	4-8
CHECKING THE CYLINDER HEAD .....	4-9
INSTALLING THE CYLINDER HEAD .....	4-10
 <b>CAMSHAFT, ROCKER ARMS AND VALVES.....</b>	 <b>4-12</b>
REMOVING THE ROCKER ARMS AND CAMSHAFT.....	4-14
REMOVING THE VALVES AND VALVE SPRINGS .....	4-14
CHECKING THE CAMSHAFT.....	4-15
CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS .....	4-15
CHECKING THE VALVES AND VALVE SPRINGS .....	4-17
INSTALLING THE VALVES AND VALVE SPRINGS .....	4-21
INSTALLING THE CAMSHAFT AND ROCKER ARMS .....	4-22
 <b>CYLINDER AND PISTON.....</b>	 <b>4-23</b>
REMOVING THE PISTON .....	4-24
CHECKING THE CYLINDER AND PISTON .....	4-24
CHECKING THE PISTON RINGS.....	4-26
CHECKING THE PISTON PIN .....	4-27
INSTALLING THE PISTON .....	4-28
INSTALLING THE CYLINDER .....	4-29
 <b>C.D.I. MAGNETO.....</b>	 <b>4-30</b>
REMOVING THE C.D.I. MAGNETO ROTOR .....	4-31
CHECKING THE PICKUP COIL/STATOR ASSEMBLY.....	4-31
INSTALLING THE C.D.I. MAGNETO ROTOR .....	4-32
INSTALLING THE SHIFT LEVER .....	4-32

---

<b>CLUTCH</b> .....	4-33
REMOVING THE CLUTCH .....	4-35
REMOVING THE PRIMARY DRIVE GEAR .....	4-35
CHECKING THE FRICTION PLATES.....	4-35
CHECKING THE CLUTCH PLATES .....	4-36
CHECKING THE CLUTCH SPRINGS.....	4-36
CHECKING THE CLUTCH HOUSING .....	4-36
CHECKING THE CLUTCH BOSS.....	4-37
CHECKING THE PRESSURE PLATE .....	4-37
CHECKING THE CLUTCH BALLS.....	4-37
CHECKING THE PRIMARY DRIVE GEARS .....	4-37
INSTALLING THE PRIMARY DRIVE GEAR.....	4-38
INSTALLING THE CLUTCH.....	4-38
<b>STARTER CLUTCH AND OIL PUMP</b> .....	4-42
CHECKING THE STARTER CLUTCH .....	4-44
CHECKING THE OIL PUMP .....	4-45
<b>SHIFT SHAFT</b> .....	4-47
CHECKING THE SHIFT SHAFT .....	4-48
CHECKING THE STOPPER LEVER .....	4-48
INSTALLING THE STOPPER LEVER .....	4-48
INSTALLING THE SHIFT SHAFT .....	4-48
<b>CRANKCASE</b> .....	4-49
CRANKCASE BEARINGS.....	4-50
SEPARATING THE CRANKCASE .....	4-51
CHECKING THE TIMING CHAIN.....	4-51
CHECKING THE BEARINGS AND OIL SEALS.....	4-52
CHECKING THE CRANKCASE .....	4-52
INSTALLING THE BEARINGS.....	4-52
ASSEMBLING THE CRANKCASE.....	4-53
<b>CRANKSHAFT</b> .....	4-54
CHECKING THE CRANKSHAFT .....	4-55
INSTALLING THE CRANKSHAFT .....	4-55
<b>TRANSMISSION</b> .....	4-56
REMOVING THE TRANSMISSION .....	4-57
CHECKING THE SHIFT FORK .....	4-57
CHECKING THE SHIFT DRUM .....	4-58
CHECKING THE TRANSMISSION .....	4-58
INSTALLING THE TRANSMISSION .....	4-59
<b>MIDDLE GEAR</b> .....	4-60
REMOVING THE MIDDLE DRIVEN SHAFT .....	4-61
CHECKING THE PINION GEARS .....	4-62
SELECTING MIDDLE DRIVEN GEAR SHIMS .....	4-63
INSTALLING THE MIDDLE DRIVEN SHAFT .....	4-64
MEASURING THE MIDDLE GEAR BACKLASH.....	4-66

---

## **CHAPTER 5**

### **CARBURETOR**

<b>CARBURETOR</b> .....	5-1
DISASSEMBLING THE CARBURETOR.....	5-4
CHECKING THE CARBURETOR .....	5-4
ASSEMBLING THE CARBURETOR.....	5-6
INSTALLING THE CARBURETOR .....	5-6
MEASURING AND ADJUSTING THE FUEL LEVEL .....	5-7

## **CHAPTER 6**

### **DRIVE TRAIN**

<b>TROUBLESHOOTING</b> .....	6-1
CHECKING NOISES .....	6-2
TROUBLESHOOTING CHART .....	6-4
 <b>REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT</b> .....	6-5
REAR AXLE/FINAL DRIVE ASSEMBLY .....	6-7
REMOVING THE NUTS .....	6-8
REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY .....	6-8
DISASSEMBLING THE REAR AXLE HOUSING .....	6-9
DISASSEMBLING THE FINAL GEAR CASE .....	6-9
CHECKING THE REAR AXLE .....	6-10
CHECKING THE DRIVE SHAFT.....	6-10
CHECKING THE REAR AXLE HOUSING AND FINAL DRIVE ASSEMBLY .....	6-10
ASSEMBLING THE FINAL GEAR CASE .....	6-11
ASSEMBLING THE REAR AXLE HOUSING .....	6-11
INSTALLING THE REAR AXLE/FINAL DRIVE ASSEMBLY .....	6-12
INSTALLING THE NUTS.....	6-13

## **CHAPTER 7**

### **CHASSIS**

<b>FRONT AND REAR WHEELS</b> .....	7-1
FRONT WHEELS .....	7-1
REAR WHEELS .....	7-2
CHECKING THE WHEELS .....	7-3
CHECKING THE FRONT WHEEL HUBS .....	7-3
CHECKING THE REAR WHEEL HUBS.....	7-4
INSTALLING THE WHEEL HUBS.....	7-4
INSTALLING THE WHEELS .....	7-5

---

<b>FRONT AND REAR BRAKES.....</b>	<b>7-6</b>
FRONT BRAKE .....	7-6
REAR BRAKE .....	7-7
REMOVING THE BRAKES .....	7-9
CHECKING THE BRAKE SHOE PLATES .....	7-9
CHECKING THE BRAKE SHOES.....	7-9
CHECKING THE BRAKE DRUMS .....	7-10
INSTALLING THE FRONT BRAKES .....	7-11
INSTALLING THE REAR BRAKE .....	7-12
<b>STEERING SYSTEM.....</b>	<b>7-14</b>
HANDLEBAR.....	7-14
REMOVING THE HANDLEBAR GRIPS.....	7-16
REMOVING THE REAR BRAKE SWITCH .....	7-16
CHECKING THE HANDLEBAR .....	7-16
INSTALLING THE HANDLEBAR .....	7-17
INSTALLING THE HANDLEBAR GRIPS .....	7-17
INSTALLING THE REAR BRAKE LEVER .....	7-18
INSTALLING THE FRONT BRAKE LEVER ASSEMBLY.....	7-18
STEERING STEM .....	7-19
REMOVING THE STEERING STEM .....	7-20
CHECKING THE STEERING STEM .....	7-20
INSTALLING THE STEERING STEM .....	7-20
INSTALLING THE LOCK WASHER.....	7-20
TIE-RODS AND STEERING KNUCKLES .....	7-21
REMOVING THE TIE-RODS.....	7-22
CHECKING THE TIE-RODS .....	7-22
CHECKING THE STEERING KNUCKLES.....	7-22
INSTALLING THE TIE-RODS .....	7-23
<b>FRONT SHOCK ABSORBER ASSEMBLIES AND FRONT SWINGARM ...</b>	<b>7-24</b>
REMOVING THE FRONT SWINGARM .....	7-25
CHECKING THE FRONT SWINGARM .....	7-25
CHECKING THE FRONT SHOCK ABSORBER ASSEMBLIES .....	7-25
<b>REAR SHOCK ABSORBER AND REAR SWINGARM .....</b>	<b>7-26</b>
REMOVING THE REAR SWINGARM.....	7-27
CHECKING THE REAR SHOCK ABSORBER.....	7-27
CHECKING THE REAR SWINGARM .....	7-28
CHECKING THE DUST BOOT .....	7-28
INSTALLING THE LOCK WASHER.....	7-28



---

## **CHAPTER 8**

### **ELECTRICAL**

<b>ELECTRICAL COMPONENTS.....</b>	<b>8-1</b>
<b>CHECKING SWITCH CONTINUITY .....</b>	<b>8-2</b>
<b>CHECKING THE SWITCHES.....</b>	<b>8-3</b>
<b>CHECKING THE BULBS AND BULB SOCKETS .....</b>	<b>8-4</b>
TYPES OF BULBS .....	8-4
CHECKING THE CONDITION OF THE BULBS .....	8-4
CHECKING THE CONDITION OF THE BULB SOCKETS .....	8-6
<b>IGNITION SYSTEM .....</b>	<b>8-7</b>
CIRCUIT DIAGRAM .....	8-7
TROUBLESHOOTING .....	8-8
<b>ELECTRIC STARTING SYSTEM.....</b>	<b>8-12</b>
CIRCUIT DIAGRAM .....	8-12
STARTING CIRCUIT OPERATION.....	8-13
TROUBLESHOOTING .....	8-14
<b>STARTER MOTOR.....</b>	<b>8-18</b>
CHECKING THE STARTER MOTOR .....	8-19
ASSEMBLING THE STARTER MOTOR.....	8-20
<b>CHARGING SYSTEM.....</b>	<b>8-21</b>
CIRCUIT DIAGRAM .....	8-21
TROUBLESHOOTING .....	8-22
<b>SIGNAL SYSTEM.....</b>	<b>8-24</b>
CIRCUIT DIAGRAM .....	8-24
TROUBLESHOOTING .....	8-25
CHECKING THE SIGNALING SYSTEM .....	8-26


## **CHAPTER 9**

### **TROUBLESHOOTING**

<b>STARTING FAILURE/HARD STARTING .....</b>	<b>9-1</b>
FUEL SYSTEM.....	9-1
ELECTRICAL SYSTEM.....	9-1
COMPRESSION SYSTEM.....	9-2

---

<b>POOR IDLE SPEED PERFORMANCE .....</b>	<b>9-2</b>
POOR IDLE SPEED PERFORMANCE .....	9-2
 <b>POOR MEDIUM AND HIGH-SPEED PERFORMANCE .....</b>	 <b>9-2</b>
POOR MEDIUM AND HIGH-SPEED PERFORMANCE .....	9-2
 <b>FAULTY DRIVE TRAIN .....</b>	 <b>9-3</b>
 <b>FAULTY GEAR SHIFTING .....</b>	 <b>9-4</b>
HARD SHIFTING .....	9-4
SHIFT LEVER DOES NOT MOVE .....	9-4
JUMPS OUT GEAR .....	9-4
 <b>CLUTCH SLIPPING/Dragging .....</b>	 <b>9-4</b>
CLUTCH SLIPPING .....	9-4
CLUTCH DRAGGING .....	9-4
 <b>OVERHEATING .....</b>	 <b>9-4</b>
OVERHEATING .....	9-4
 <b>FAULTY BRAKE .....</b>	 <b>9-5</b>
POOR BRAKING EFFECT .....	9-5
 <b>SHOCK ABSORBER MALFUNCTION .....</b>	 <b>9-5</b>
MALFUNCTION .....	9-5
 <b>UNSTABLE HANDLING .....</b>	 <b>9-5</b>
UNSTABLE HANDLING .....	9-5




EBS00009

## GENERAL INFORMATION MACHINE IDENTIFICATION

EBS00010

### VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the left side of the frame.



EBS00011

### MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.

EBS00013

### **IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DISASSEMBLY**

1. Before removal and disassembly remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.  
Refer to "SPECIAL TOOLS".
3. When disassembling always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

1

EBS00014


### **REPLACEMENT PARTS**

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EBS00015

### **GASKETS, OIL SEALS AND O-RINGS**


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly properly oil all mating parts and bearings, and lubricate the oil seal lips with grease.



EBS00016

## LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EBS00017


## BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

### CAUTION:

**Do not spin the bearing with compressed air because this will damage the bearing surfaces.**



① Bearing




EBS00018

## CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



EBS00019

## CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

### 1. Disconnect:


- lead
- coupler
- connector

### 2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.



### 3. Check:

- all connections

Loose connection → Connect properly.

### NOTE:


If the pin ① on the terminal is flattened, bend it up.

### 4. Connect:

- lead
- coupler
- connector

### NOTE:

Make sure all connections are tight.



### 5. Check:


- continuity (with the pocket tester)



**Pocket tester**  
P/N. YU-03112-C, 90890-03112

### NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.



EBS00021

**SPECIAL TOOLS**

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.








When placing an order, refer to the list provided below to avoid any mistakes.












For US and CDN

P/N. YM-, YU-, YS-, YK-, ACC-









Except for US and CDN

P/N. 90890-

Tool No.	Tool name/Function	Illustration
Bolt 90890-01085 Weight 90890-01084 Set YU-01083-A	Slide hammer bolt (M8)/weight/set  These tools are used to remove the rocker arm shaft.	
90890-01189 YM-01189	Flywheel puller  This tool is needed to remove the rotor.	
90890-01304 YU-01304	Piston pin puller set  This tool is used to remove the piston pin.	
90890-01311 YM-08035	Tappet adjusting tool (3 mm)  This tool is necessary for adjusting the valve clearance.	 
90890-01312 YM-01312-A	Fuel level gauge  This gauge is used to measure the fuel level in the float chamber.	
90890-01388	Damper rod holder (27 mm)  This tool is needed to loosen and tighten the middle driven pinion gear bearing retainer.	

Tool No.	Tool name/Function	Illustration	
90890-01422 YM-37132	Axle nut wrench (36 mm)  This tool is needed to loosen or tighten the rear axle nut.		
90890-01430 YM-38404	Ring nut wrench  This tool is needed to loosen and tighten the final gear case bearing retainer.		
90890-01467 YM-01467	Gear lash measurement tool  This tool is used to measure the middle gear backlash.		
90890-01701 YS-01880-A	Sheave holder  This tool is needed to hold the rotor when removing or installing the rotor nut.		
Gauge 90890-03081 YU-33223 Adapter 90890-04082	Compression gauge Adapter  These tools are needed to measure engine compression.		
90890-03112 YU-03112-C	Pocket tester  This instrument is needed for checking the electrical system.		
90890-03113	Engine tachometer  This tool is needed for observing engine rpm.		
90890-03141 YM-33277-A	Timing light  This tool is necessary for checking ignition timing.		



Tool No.	Tool name/Function	Illustration
Compressor 90890-04019 YM-04019 Attachment 90890-04108 YM-04108	Valve spring compressor Valve spring compressor attachment  This tool is needed to remove and install the valve assemblies.	
Holder 90890-04062 YM-04062 Attachment 90890-04096	Universal joint holder Universal joint holder attachment  This tool is needed when removing or installing the universal joint yoke nut.	
90890-04097 YM-04097	Valve guide remover (5 mm)  This tool is needed to remove and install the valve guide.	
90890-04098 YM-04098	Valve guide installer (5 mm)  This tool is needed to install the valve guide.	
90890-04099	Valve guide reamer (5 mm)  This tool is needed to rebore the new valve guide.	
90890-04100	Clutch holder  This tool is needed to hold the clutch boss when removing or installing the clutch boss nut.	
90890-04129 YM-04129	Pinion gear fix clamp  This tool is used to hold the drive axle/middle drive pinion gear assembly.	
90890-06754	Ignition checker  This instrument is necessary for checking the ignition system components.	



Tool No.	Tool name/Function	Illustration
Bond 90890-85505 Sealant ACC-11001-05-01	Yamaha bond No. 1215 Sealant (Quick Gasket®)  This sealant (bond) is used on crankcase mating surfaces, etc.	
YM-01363	27-mm hexagon wrench  This tool is needed to loosen and tighten the middle driven pinion gear bearing retainer.	
YM-34487	Dynamic spark tester  This instrument is necessary for checking the ignition system components.	
YU-8036-B	Inductive self-powered tachometer  This tool is needed for observing engine rpm.	



EBS01001

## SPECIFICATIONS

## GENERAL SPECIFICATIONS

Item	Standard
<b>Model code</b>	5YF1
<b>Dimensions</b>	
Overall length	1,537 mm (60.5 in)
Overall width	825 mm (32.5 in)
Overall height	915 mm (36.0 in)
Seat height	618 mm (24.3 in)
Wheelbase	1,030 mm (40.6 in)
Minimum ground clearance	70 mm (2.76 in)
Minimum turning radius	2,300 mm (90.6 in)
<b>Basic weight</b>	
With oil and full fuel tank	115 kg (253 lb)
<b>Engine</b>	
Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	49 cm <sup>3</sup>
Bore × stroke	39.0 × 41.4 mm (1.54 × 1.63 in)
Compression ratio	10.0 : 1
Standard compression pressure (at sea level)	1,200 kPa (12.0 kg/cm <sup>2</sup> , 170.6 psi) at 1,000 r/min
Starting system	Electric starter
<b>Lubrication system</b>	Wet sump
<b>Oil type or grade</b>	
Engine oil	API service SE, SF, SG type or higher
<p>The chart shows three horizontal bars representing different oil grades and their applicable temperature ranges. The top bar is for YAMALUBE 4 (20W40) or SAE 20W40, ranging from 0°F to 130°F. The middle bar is for YAMALUBE 4 (10W30) or SAE 10W30, ranging from -10°F to 110°F. The bottom bar is for SAE 5W30, ranging from -20°F to 0°F. The temperature scales are in both Fahrenheit (top) and Celsius (bottom).</p>	
Final gear oil	SAE 80API "GL-4" Hypoid gear oil
<b>Oil capacity</b>	
Engine oil	
Periodic oil change	0.80 L (0.70 Imp qt, 0.85 US qt)
Total amount	0.95 L (0.84 Imp qt, 1.00 US qt)
Final gear case oil	
Total amount	0.12 L (0.11 Imp qt, 0.13 US qt)
<b>Air filter</b>	Wet type element



Item		Standard
<b>Fuel</b>		
Type		Unleaded gasoline only
Fuel tank capacity		6.8 L (1.50 Imp gal, 1.80 US gal)
Fuel reserve amount		0.9 L (0.20 Imp gal, 0.24 US gal)
<b>Carburetor</b>		
Type/quantity		VM16SH/1
Manufacturer		MIKUNI
<b>Spark plug</b>		
Type/manufacturer		CR7HS/NGK
Spark plug gap		0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
<b>Clutch type</b>		Wet, multiple-disc automatic
<b>Transmission</b>		
Primary reduction system		Spur gear
Primary reduction ratio		65/20 (3.250)
Secondary reduction system		Shaft drive
Secondary reduction ratio		19/18 × 34/10 (3.588)
Operation		Left hand operation
Gear ratio		
1st gear		38/14 (2.714)
<b>Chassis</b>		
Frame type		Steel tube frame
Caster angle		1.0°
Camber angle		2.0°
Kingpin angle		10°
Trail		3.4 mm (0.13 in)
Tread (STD)	front	630 mm (24.80 in)
	rear	665 mm (26.18 in)
Toe-in		0 ~ 10 mm (0 ~ 0.39 in)
<b>Tire</b>		
Type		Tubeless
Size	front	AT16 × 7-7
	rear	AT16 × 8-7
Manufacturer	front	DUNLOP
	rear	DUNLOP
Type	front	KT145
	rear	KT145
<b>Tire pressure (cold tire)</b>		
Maximum load*		40 kg (88 lb)
Off-road riding	front	17 ~ 23 kPa (0.17 ~ 0.23 kgf/cm <sup>2</sup> , 2.5 ~ 3.3 psi)
	rear	17 ~ 23 kPa (0.17 ~ 0.23 kgf/cm <sup>2</sup> , 2.5 ~ 3.3 psi)
*Load in total weight of rider accessories		

# GENERAL SPECIFICATIONS

**SPEC**






Item		Standard
<b>Brake</b>		
Front brake	type operation	Drum brake Right hand operation
Rear brake	type operation	Drum brake Left hand operation
<b>Suspension</b>		
Front suspension		Leading arm
Rear suspension		Swingarm
<b>Shock absorber</b>		
Front shock absorber		Coil spring/oil damper
Rear shock absorber		Coil spring/oil damper
<b>Wheel travel</b>		
Front wheel travel		57 mm (2.24 in)
Rear wheel travel		56 mm (2.20 in)
<b>Electrical</b>		
Ignition system		C.D.I.
Generator system		A.C. magneto
Battery type		12N7D-3B
Battery capacity		12 V 7 AH
<b>Bulb wattage × quantity</b>		
Neutral indicator light		12 V 1.7 W × 1







EBS01002



## ENGINE SPECIFICATIONS

Item	Standard	Limit
<b>Cylinder head</b> Warp limit * 	----	0.05 mm (0.002 in)
<b>Cylinder</b> Bore size Taper limit Maximum out-of-round	39.000 ~ 39.005 mm (1.5354 ~ 1.5356 in) ---- ----	39.105 mm (1.5396 in) 0.05 mm (0.002 in) 0.01 mm (0.0004 in)
<b>Camshaft</b> Drive method Cam dimensions  Intake “A” “B” Exhaust “A” “B” Camshaft runout limit 	Chain drive (Left)  25.300 ~ 25.310 mm (0.9961 ~ 0.9965 in) 20.994 ~ 21.094 mm (0.8265 ~ 0.8305 in) 25.301 ~ 25.311 mm (0.9961 ~ 0.9965 in) 21.021 ~ 21.121 mm (0.8276 ~ 0.8315 in) ----	----  25.200 mm (0.9921 in) 20.894 mm (0.8226 in) 25.201 mm (0.9922 in) 20.921 mm (0.8237 in) 0.03 mm (0.0012 in)
<b>Timing chain</b> Timing chain type/No. of links Timing chain adjustment method	Bush chain/82 Manual	---- ----






Item		Standard	Limit
<b>Rocker arm/rocker arm shaft</b>			
Rocker arm inside diameter		10.000 ~ 10.015 mm (0.3937 ~ 0.3943 in)	----
Rocker arm shaft outside diameter		9.981 ~ 9.991 mm (0.3930 ~ 0.3933 in)	----
Rocker-arm-to-rocker-arm-shaft clearance		0.009 ~ 0.034 mm (0.0004 ~ 0.0013 in)	0.08 mm (0.0031 in)
<b>Valve, valve seat, valve guide</b>			
Valve clearance (cold)	IN	0.05 ~ 0.10 mm (0.002 ~ 0.004 in)	----
	EX	0.075 ~ 0.125 mm (0.003 ~ 0.005 in)	----
Valve dimensions			
			
Head Diameter	Face Width	Seat Width	Margin Thickness
“A” head diameter	IN	19.9 ~ 20.1 mm (0.7835 ~ 0.7913 in)	----
	EX	16.7 ~ 16.9 mm (0.6575 ~ 0.6654 in)	----
“B” face width	IN	1.10 ~ 2.30 mm (0.0433 ~ 0.0906 in)	----
	EX	1.30 ~ 2.40 mm (0.0512 ~ 0.0945 in)	----
“C” seat width	IN	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
	EX	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
“D” margin thickness	IN	0.5 ~ 0.9 mm (0.0197 ~ 0.0354 in)	1.6 mm (0.0630 in)
	EX	0.6 ~ 1.0 mm (0.0236 ~ 0.0394 in)	1.6 mm (0.0630 in)
Stem outside diameter	IN	4.975 ~ 4.990 mm (0.1959 ~ 0.1965 in)	4.950 mm (0.1949 in)
	EX	4.960 ~ 4.975 mm (0.1953 ~ 0.1959 in)	4.953 mm (0.1950 in)
Guide inside diameter	IN	5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in)	5.030 mm (0.1980 in)
	EX	5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in)	5.030 mm (0.1980 in)





Item		Standard	Limit
Stem-to-guide clearance	IN	0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)	0.08 mm (0.0031 in)
	EX	0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in)	0.10 mm (0.0039 in)
Stem runout limit		----	0.02 mm (0.0008 in)
			
Valve seat width	IN	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
	EX	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
<b>Valve spring</b>			
Free length	IN	32.00 mm (1.26 in)	30.40 mm (1.20 in)
	EX	32.00 mm (1.26 in)	30.40 mm (1.20 in)
Compressed pressure (installed)	IN	136 ~ 158 N at 24.6 mm (13.87 ~ 16.11 kg, 30.57 ~ 35.52 lb at 0.97 in)	----
	EX	136 ~ 158 N at 24.6 mm (13.87 ~ 16.11 kg, 30.57 ~ 35.52 lb at 0.97 in)	----
Tilt limit *	IN		2.5°/1.4 mm (2.5°/0.06 in)
	EX		2.5°/1.4 mm (2.5°/0.06 in)
			
Direction of winding (top view)	IN	Clockwise	----
	EX	Clockwise	----





Item	Standard	Limit
<b>Piston</b>		
Piston to cylinder clearance	0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in)	0.15 mm (0.0059 in)
Piston size "D"	38.960 ~ 38.975 mm (1.5339 ~ 1.5344 in)	----
		
Measuring point "H"	5.0 mm (0.20 in)	----
Oversize	2nd 4th	----
	39.5 mm (1.56 in)	----
	40.0 mm (1.57 in)	----
Piston off-set	0.5 mm (0.02 in)	----
Piston off-set direction	Intake side	----
Piston pin bore inside diameter	13.002 ~ 13.013 mm (0.5119 ~ 0.5123 in)	13.043 mm (0.5135 in)
Piston pin outside diameter	12.996 ~ 13.000 mm (0.5117 ~ 0.5118 in)	12.976 mm (0.5109 in)
<b>Piston rings</b>		
Top ring		
		
Type	Barrel	----
Dimensions (B × T)	1.0 × 1.7 mm (0.0394 × 0.0669 in)	----
End gap (installed)	0.08 ~ 0.20 mm (0.0031 ~ 0.0079 in)	0.45 mm (0.0177 in)
Side clearance (installed)	0.030 ~ 0.065 mm (0.0012 ~ 0.0026 in)	0.12 mm (0.0047 in)
2nd ring		
		
Type	Taper	----
Dimensions (B × T)	1.0 × 1.7 mm (0.0394 × 0.0669 in)	----
End gap (installed)	0.05 ~ 0.20 mm (0.0020 ~ 0.0079 in)	0.55 mm (0.0217 in)
Side clearance	0.020 ~ 0.055 mm (0.0008 ~ 0.0022 in)	0.12 mm (0.0047 in)



Item	Standard	Limit
<b>Oil ring</b>  Dimensions (B × T) End gap (installed)	 2.0 × 2.0 mm (0.0787 × 0.0787 in) 0.20 ~ 0.70 mm (0.0079 ~ 0.0276 in)	 ---- ----
<b>Crankshaft</b>  Crank width "A" Runout limit C1 C2 Big end side clearance "D" Big end radial clearance "E" Small end free play "F"	 40.20 ~ 40.25 mm (1.5827 ~ 1.5846 in) ---- ---- 0.10 ~ 0.40 mm (0.0039 ~ 0.0157 in) 0.004 ~ 0.019 mm (0.0002 ~ 0.0007 in) 0.80 ~ 1.00 mm (0.0315 ~ 0.0394 in)	 ---- 0.05 mm (0.0020 in) 0.04 mm (0.0016 in) 0.50 mm (0.0197 in) ---- 1.50 mm (0.0591 in)
<b>Clutch</b> Friction plate 1 (with black color marking) Thickness Quantity Friction plate 2 Thickness Quantity	 2.92 ~ 3.08 mm (0.115 ~ 0.121 in) 4 2.92 ~ 3.08 mm (0.115 ~ 0.121 in) 1	 2.90 mm (0.114 in) ---- 2.90 mm (0.114 in) ----






Item	Standard	Limit
Clutch plate 1		
Thickness	1.4 mm (0.055 in)	----
Quantity	1	----
Maximum warpage	----	0.06 mm (0.002 in)
Clutch plate 2		
Thickness	1.2 ~ 1.6 mm (0.047 ~ 0.063 in)	----
Quantity	3	----
Maximum warpage	----	0.06 mm (0.002 in)
Clutch spring		
Free length	31.9 mm (1.26 in)	30.3 mm (1.19 in)
Quantity	8	----
Automatic centrifugal clutch		
Clutch-in revolution	2,300 ~ 2,500 r/min	----
Clutch-stall revolution	3,000 ~ 3,200 r/min	----
<b>Transmission</b>		
Main axle deflection limit	----	0.08 mm (0.0031 in)
Drive axle deflection limit	----	0.08 mm (0.0031 in)
<b>Shifter</b>		
Shifter type	Shift drum and guide bar	----
<b>Carburetors</b>		
I. D. mark	5YF1 00	----
Main jet (M.J)	#72.5	----
Air jet (A.J)	1.2	----
Jet needle (J.N)	3PZ13-2	----
Needle jet (N.J)	D-8M	----
Cutaway (C.A)	3	----
Pilot outlet (P.O)	0.7	----
Pilot jet (P.J)	#15	----
Valve seat size (V.S)	1.2	----
Fuel level (F.L)	4.0 ~ 5.0 mm (0.16 ~ 0.20 in)	----
	Below the float chamber mating surface	
Engine idle speed	1,750 ~ 1,850 r/min	----
Intake vacuum	30 kPa (225 mmHg, 8.9 inHg)	----



Item	Standard	Limit
<b>Oil pump</b>		
Oil pump type	Trochoid	----
Inner-rotor-to-outer-rotor-tip clearance	0.05 ~ 0.07 mm (0.002 ~ 0.003 in)	0.15 mm (0.006 in)
Outer-rotor-to-oil-pump-housing clearance	0.013 ~ 0.036 mm (0.0005 ~ 0.0014 in)	0.106 mm (0.0042 in)
Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance	0.06 ~ 0.10 mm (0.0024 ~ 0.0039 in)	0.17 mm (0.0067 in)
<b>Shaft drive</b>		
Middle gear backlash	0.17 ~ 0.31 mm (0.007 ~ 0.012 in)	----
Final gear backlash	0.17 ~ 0.31 mm (0.007 ~ 0.012 in)	----

**Lubrication chart**

 : Pressure feed  
 : Splashed scavenge





EBS01003

## CHASSIS SPECIFICATIONS

Item		Standard	Limit
<b>Front suspension</b>			
Shock absorber travel		60 mm (2.36 in)	----
Optional spring		No	----
<b>Rear suspension</b>			
Shock absorber travel		58 mm (2.28 in)	----
Optional spring		No	----
<b>Front wheel</b>			
Type		Panel wheel	----
Rim size		7 × 5.5 AT	----
Rim material		Steel	----
Rim runout limit	radial	----	2.0 mm (0.08 in)
	lateral	----	2.0 mm (0.08 in)
<b>Rear wheel</b>			
Type		Panel wheel	----
Rim size		7 × 6.5 AT	----
Rim material		Steel	----
Rim runout limit	radial	----	2.0 mm (0.08 in)
	lateral	----	2.0 mm (0.08 in)
<b>Front drum brake</b>			
Type		Leading, trailing	----
Brake drum inside diameter		110.0 mm (4.33 in)	110.5 mm (4.35 mm)
Lining thickness		4.0 mm (0.16 in)	2.0 mm (0.08 in)
Shoe spring free length		54.0 mm (2.13 in)	----
<b>Rear drum brake</b>			
Type		Leading, trailing	----
Brake drum inside diameter		130.0 mm (5.12 in)	130.5 mm (5.14 in)
Lining thickness		4.0 mm (0.16 in)	2.0 mm (0.08 in)
Shoe spring free length		36.5 mm (1.44 in)	----
<b>Brake lever and brake pedal</b>			
Brake lever free play (pivot)	front	10 ~ 12 mm (0.39 ~ 0.47 in)	----
	rear	7 ~ 10 mm (0.28 ~ 0.39 in)	----
Throttle lever free play		1.5 ~ 5.0 mm (0.06 ~ 0.20 in)	----



EBS01004

## ELECTRICAL SPECIFICATIONS

Item	Standard	Limit
<b>Voltage</b>	12 V	----
<b>Ignition system</b>		
Ignition timing (B.T.D.C.)	10°/1,700 r/min	----
Advanced timing (B.T.D.C.)	30°/5,000 r/min	----
Advancer type	Electrical (analogue)	----
<b>C.D.I.</b>		
Magneto model/manufacturer	F2FM/YAMAHA	----
Pickup coil resistance/color	264 ~ 396 $\Omega$ at 20 °C (68 °F)/ White/Red—White/Blue	----
Source coil resistance/color	304 ~ 456 $\Omega$ at 20 °C (68 °F)/ Black/Red—Green/White	----
C.D.I. unit model/manufacturer	5YF/YAMAHA	----
<b>Ignition coil</b>		
Model/manufacturer	2JN/YAMAHA	----
Minimum spark gap	6 mm (0.24 in)	----
Primary winding resistance	0.18 ~ 0.28 $\Omega$ at 20 °C (68 °F)	----
Secondary winding resistance	6.32 ~ 9.48 k $\Omega$ at 20 °C (68 °F)	----
<b>Spark plug cap</b>		
Type	Resin	----
Resistance	10 k $\Omega$	----
<b>Charging system</b>		
Type	A.C. magneto	----
Model/manufacturer	F2FM/YAMAHA	----
Nominal output	14 V 45 W at 5,000 r/min	----
Charging coil resistance/color	0.72 ~ 1.08 $\Omega$ at 20 °C (68 °F)/ White—Black	----
Lighting coil resistance	0.32 ~ 0.48 $\Omega$ at 20 °C (68 °F)/ Yellow/Red—Black	----
<b>Rectifier/regulator</b>		
Regulator type	Semi conductor-short circuit	----
No-load regulated voltage (DC)	14.0 ~ 15.0 V	----
No-load regulated voltage (AC)	13.0 ~ 14.0 V	----
Model/manufacturer	SH704-12/SHINDENGEN	----
Capacity (DC)	5 A	----
Capacity (AC)	8 A	----
Withstand voltage	200 V	----




Item	Standard	Limit
<b>Electric starter system</b>		
Type	Constant mesh	----
Starter motor		
Model/manufacturer	ADB4A5/DENSO	----
Output	0.2 kW	----
Armature coil resistance	0.029 ~ 0.035 $\Omega$ at 20 °C (68 °F)	----
Brush overall length	6.0 mm (0.24 in)	3.5 mm (0.14 in)
Spring force	3.24 ~ 4.22 N (330 ~ 430 gf, 11.66 ~ 15.19 oz)	----
Commutator diameter	16.5 mm (0.65 in)	15.5 mm (0.61 in)
Mica undercut	1 mm (0.04 in)	----
Starter relay		
Model/manufacturer	MS5E-661/JIDECO	----
Amperage rating	100 A	----
Coil winding resistance	4.18 ~ 4.62 $\Omega$ at 20 °C (68 °F)	----
<b>Starting circuit cut-off relay</b>		
Model/manufacturer	ACA12115-3/MATSUSHITA	----
Coil resistance	72 ~ 88 $\Omega$ at 20 °C (68 °F)	----
Diode	Yes	----
<b>Circuit breakers</b>		
Type	Fuse	----
Amperage for individual circuit		
Main fuse	5 A $\times$ 1	----
Reserve	5 A $\times$ 1	----



EBS01005

## TIGHTENING TORQUES

### ENGINE TIGHTENING TORQUES

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Cylinder head (exhaust pipe)	Stud bolt	M6	2	7	0.7	5.1	
Intake and exhaust tappet cover	—	M45	2	18	1.8	13	
Camshaft sprocket cover	Screw	M6	2	7	0.7	5.1	
Cylinder head	Nut	M6	4	12	1.2	8.7	
	Bolt	M6	2	10	1.0	7.2	
Spark plug	—	M10	1	13	1.3	9.4	
C.D.I. magneto rotor	Nut	M10	1	40	4.0	29	
Valve adjuster	Nut	M5	2	7	0.7	5.1	
Camshaft sprocket	Bolt	M8	1	20	2.0	14	
Timing chain tensioner	—	M18	1	18	1.8	13	
Timing chain tension adjuster locknut	Nut	M6	1	7	0.7	5.1	
Oil pump	Screw	M6	2	7	0.7	5.1	
Engine oil drain bolt	Bolt	M12	1	20	2.0	14	
Intake manifold	Screw	M6	2	7	0.7	5.1	
Carburetor	Screw	M6	2	7	0.7	5.1	
Exhaust pipe	Nut	M6	2	10	1.0	7.2	
Muffler	Bolt	M8	2	25	2.5	18	
Spark arrester	Screw	M6	2	8	0.8	5.8	
Muffler purging bolt	Bolt	M6	1	10	1.0	7.2	
Crankcase	Screw	M6	9	7	0.7	5.1	
Crankcase (cylinder head)	Stud bolt	M6	4	10	1.0	7.2	
Main axle bearing retainer	Screw	M6	2	8	0.8	5.8	
Drive axle/middle drive pinion gear assembly plate	Bolt	M6	3	10	1.0	7.2	
Clutch cover	Screw	M6	3	7	0.7	5.1	
C.D.I. magneto cover	Screw	M6	9	7	0.7	5.1	
Starter clutch	Screw	M6	3	10	1.0	7.2	
Primary drive gear	Nut	M12	1	50	5.0	36	
Clutch boss	Nut	M14	1	60	6.0	43	
Push plate	Screw	M6	4	8	0.8	5.8	
Middle driven shaft bearing retainer	—	M42	1	60	6.0	43	
Universal joint yoke	Nut	M12	1	90	9.0	65	
Middle driven shaft bearing housing	Bolt	M6	3	10	1.0	7.2	
Shift drum retainer	Screw	M6	2	8	0.8	5.8	
Shift shaft spring stopper	Bolt	M8	1	25	2.5	18	
Shift drum stopper lever	Bolt	M6	1	10	1.0	7.2	
Shift lever	Bolt	M6	1	10	1.0	7.2	
Stator assembly	Screw	M6	2	7	0.7	5.1	
Starter motor	Bolt	M6	2	10	1.0	7.2	



# TIGHTENING TORQUES

**SPEC**



Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Neutral switch	—	M10	1	20	2.0	14	
Spark arrester tailpipe	Screw	M6	2	8	0.8	5.8	
Purging bolt	Bolt	M6	1	10	1.0	7.2	

EBS01006

## CHASSIS TIGHTENING TORQUES

Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Engine and frame	M8	33	3.3	24	
Rear swingarm and frame	M12	85	8.5	61	
Rear swingarm and swingarm guard	M8	23	2.3	17	
Rear shock absorber and frame	M10	45	4.5	32	
Rear shock absorber and rear axle housing	M10	45	4.5	32	
Front swingarm and frame	M12	60	6.0	43	
Front shock absorber and frame	M10	45	4.5	32	
Front shock absorber and front swingarm	M12	45	4.5	32	
Steering knuckle and front swingarm	M10	30	3.0	22	
Steering knuckle and tie-rod ball joint	M10	40	4.0	29	
Steering stem and tie-rod ball joint	M10	40	4.0	29	
Tie-rod locknut	M10	15	1.5	11	
Steering stem and frame	M10	35	3.5	25	
Steering stem bushing and frame	M8	23	2.3	17	
Handlebar holder and steering stem	M8	20	2.0	14	
Throttle lever and housing	M8	8	0.8	5.8	
Front wheel and brake drum	M8	28	2.8	20	
Front axle and brake drum	M14	70	7.0	50	
Front brake camshaft and camshaft lever	M6	9	0.9	6.5	
Rear brake camshaft and camshaft lever	M6	9	0.9	6.5	
Rear axle and nut	M28				See NOTE.
Rear wheel and wheel hub	M8	28	2.8	20	
Rear axle and wheel hub	M12	70	7.0	50	
Rear brake drum boss and brake drum	M8	21	2.1	15	
Rear axle housing and rear swingarm	M10	40	4.0	29	
Footrest board bracket and frame	M12	85	8.5	61	
Front bumper and frame	M8	23	2.3	17	
Front bumper and dummy headlight	M6	7	0.7	5.1	
Front bumper and front fender	M6	7	0.7	5.1	
Front fender and frame	M6	7	0.7	5.1	
Front fender stay and frame	M6	7	0.7	5.1	
Footrest board and bracket	M6	7	0.7	5.1	
Rear fender and frame	M6	7	0.7	5.1	
Rear swingarm and final gear case	M8	20	2.0	14	
Final gear case and rear axle housing	M6	20	2.0	14	



# TIGHTENING TORQUES

**SPEC**



Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Final gear oil drain plug	M14	23	2.3	17	
Final gear case bearing retainer	M55	80	8.0	58	
Final drive pinion gear and bearing	M20	12	1.2	8.7	
Rear axle housing bearing retainer	M58	110	11.0	80	

## NOTE:

1. Before tightening the nuts, apply locking agent (LOCTITE®) to rear axle threads.
2. Tighten the inside nut to 110 Nm (11.0 m · kg, 80 ft · lb).
3. Tighten the outside nut to 130 Nm (13.0 m · kg, 94 ft · lb) while holding the inside nut.
4. Loosen the inside nut to 160 Nm (16.0 m · kg, 115 ft · lb) while holding the outside nut.

# HOW TO USE THE CONVERSION TABLE/ GENERAL TIGHTENING TORQUE SPECIFICATIONS



EBS00022

## HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER		IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in


## CONVERSION TABLE

METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Torque	m · kg	7.233	ft · lb
	m · kg	86.794	in · lb
	cm · kg	0.0723	ft · lb
	cm · kg	0.8679	in · lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/h	0.6214	mph
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm <sup>3</sup> )	0.03527	oz (Imp liq.)
	cc (cm <sup>3</sup> )	0.06102	cu · in
	lt (liter)	0.8799	qt (Imp liq.)
	lt (liter)	0.2199	gal (Imp liq.)
Misc.	kg/mm	55.997	lb/in
	kg/cm <sup>2</sup>	14.2234	psi (lb/in <sup>2</sup> )
	Centigrade (°C)	9/5+32	Fahrenheit (°F)

EBS00023

## GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Distance between flats

B: Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m · kg	ft · lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



EBS00024

## LUBRICATION POINTS AND LUBRICANT TYPES

### ENGINE

Lubrication points	Lubricant
Oil seal lips	
Bearings	
O-rings	
Tappet cover thread	
Crankshaft pin	
Connecting rod (bearing)	
Crankshaft, oil seal	
Piston, piston ring	
Piston pin	
Valve stem	
Valve stem end	
Rocker arm	
Rocker arm shaft	
Camshaft lobe	
Camshaft sprocket	
Timing chain tensioner	
Intake side timing chain guide	
Oil pump assembly	
Starter idle gear shaft	
Starter wheel gear	
Primary driven gear, spacer	
Clutch push rod, oil seal	
Drive axle, 1st wheel gear	
Drive axle dog splines	
Drive axle dog shift fork groove	
Middle drive/driven pinion gear	
Shift drum	
Shift fork guide bar, O-ring	
Shift shaft	
Shift shaft washer	
Middle driven pinion gear, universal joint yoke, drive shaft, coupling gear, final drive pinion gear splines	
Final drive pinion gear, ring gear	
Crankcase mating surface	Sealant (Quick Gasket®) Yamaha Bond No.1215

## LUBRICATION POINTS AND LUBRICANT TYPES

**SPEC**


Lubrication points	Lubricant
Final gear case and rear axle housing mating surface	Sealant (Quick Gasket®) Yamaha Bond No.1215



EBS00026



**OIL FLOW DIAGRAMS**

- ① Camshaft
- ② Crankshaft
- ③ Main axle
- ④ Drive axle





- ① Oil pump
- ② Oil strainer






EBS00028

## CABLE ROUTING


- |                                  |                                       |                              |
|----------------------------------|---------------------------------------|------------------------------|
| ① Rear brake cable               | ⑩ Wire harness                        | ⑮ Left front brake cable     |
| ② Throttle cable                 | ⑪ Negative battery lead               | ⑯ Engine stop switch (frame) |
| ③ Fuel tank breather hose        | ⑫ Rectifier/regulator                 |                              |
| ④ Carburetor air vent hose       | ⑬ Engine stop switch lead (frame end) |                              |
| ⑤ Final gear case breather hose  | ⑭ Battery breather hose               |                              |
| ⑥ Crankcase breather hose        | ⑮ Starter motor lead                  |                              |
| ⑦ Starter relay                  | ⑯ Fuel overflow hose                  |                              |
| ⑧ Starting circuit cut-off relay | ⑰ Right front brake cable             |                              |
| ⑨ Positive battery lead          |                                       |                              |








- [A] Route the rear brake cable to the right of the steering stem.
- [B] Pass the carburetor air vent hose through the hole on the left side of the steering stem bracket and then insert the hose between the bracket and frame. Make sure that there is no slack or bends in the hose. Do not route the hose over the throttle cable.
- [C] Route the final gear case breather hose and crankcase breather hose to the right of the ignition coil.
- [D] Align the white tape of the wire harness with the bracket.
- [E] 200 mm (7.87 in)
- [F] To starter motor
- [G] Fasten the engine stop switch lead (frame end) to the frame with a plastic band.
- [H] Pass the final gear case breather hose through the hose guide.
- [I] Pass the battery breather hose through the hole.






- J** Fasten the carburetor air vent hose with a plastic band. Be sure to not pinch the hose. Install the plastic band with the buckle facing backward and the end inward.
- K** Route the cables under the frame.
- L** 45°






- ① Rear brake cable
- ② Wire harness
- ③ Ignition coil
- ④ Handlebar switch lead
- ⑤ Rear brake switch lead
- ⑥ Neutral indicator light lead
- ⑦ Main switch
- ⑧ C.D.I. unit
- ⑨ Fuel hose
- ⑩ Crankcase breather hose
- ⑪ Final gear case breather hose

- ⑫ Fuel tank breather hose
- ⑬ Throttle cable
- ⑭ Front brake cables






- A** 80 mm (3.15 in)
- B** Fasten the rear brake cable, wire harness, crankcase breather hose, and final gear case breather hose with a plastic band. Be sure to not pinch the hoses.
- C** Route the final gear case breather hose and crankcase breather hose over the wire harness. Fasten the hoses with a plastic band. Be sure to not pinch the hoses. Pass the ends of the hoses between the frame and bracket.
- D** Fasten the rear brake cable and wire harness near the ignition coil with a plastic locking tie.
- E** Do not fasten the main switch lead.
- F** Fasten the crankcase breather hose and final gear case breather hose with a plastic band.
- G** Face the coupler release tabs backward.
- H** Forward






- ① Rear brake switch
- ② Rear brake cable
- ③ Left front brake cable
- ④ Right front brake cable
- ⑤ Throttle cable
- ⑥ Fuel tank breather hose
- ⑦ Negative battery lead
- ⑧ Main fuse
- ⑨ Positive battery lead
- ⑩ Handlebar switch






- [A] Fasten the negative battery lead with the plastic holder.
- [B] To starter motor
- [C] Pass the leads through the hole.
- [D] To wire harness
- [E] To starter relay
- [F] Fasten the handlebar switch lead and rear brake switch lead with a plastic band.
- [G] Connect the negative battery lead to the battery so that the lead is routed to the side of the battery.
- [H] Connect the positive battery lead to the battery so that the lead contacts the battery case.





- ① Throttle cable
- ② Fuel tank breather hose
- ③ Rear brake cable
- ④ Handlebar switch lead
- ⑤ Rear brake switch lead
- ⑥ Air filter joint
- ⑦ Neutral indicator light lead
- ⑧ Right front brake cable
- ⑨ Left front brake cable

- Ⓐ Route the front brake cables to the left of the steering stem. Route the left front brake cable to the right of the air filter joint. Route the right front brake cable to the left of the air filter joint.



EBS00029

## PERIODIC CHECKS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable machine operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to machines already in service as well as to new machines that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EBS00030

### PERIODIC MAINTENANCE/LUBRICATION

ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
<b>Valves*</b>	<ul style="list-style-type: none"> <li>Check valve clearance.</li> <li>Adjust if necessary.</li> </ul>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Cam chain*</b>	<ul style="list-style-type: none"> <li>Check chain tension.</li> <li>Adjust if necessary.</li> </ul>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Spark plug</b>	<ul style="list-style-type: none"> <li>Check condition.</li> <li>Adjust gap and clean.</li> <li>Replace if necessary.</li> </ul>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Air filter element</b>	<ul style="list-style-type: none"> <li>Clean.</li> <li>Replace if necessary.</li> </ul>	Every 20 ~ 40 hours (more often in wet or dusty areas)				
<b>Carburetor*</b>	<ul style="list-style-type: none"> <li>Check idle speed/choke lever operation.</li> <li>Adjust if necessary.</li> </ul>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Crankcase breather system*</b>	<ul style="list-style-type: none"> <li>Check breather hose for cracks or damage.</li> <li>Replace if necessary.</li> </ul>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Exhaust system*</b>	<ul style="list-style-type: none"> <li>Check for leakage.</li> <li>Tighten if necessary.</li> <li>Replace gasket if necessary.</li> </ul>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Spark arrester</b>	<ul style="list-style-type: none"> <li>Clean.</li> </ul>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Fuel line*</b>	<ul style="list-style-type: none"> <li>Check fuel hose for cracks or damage.</li> <li>Replace if necessary.</li> </ul>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Engine oil</b>	<ul style="list-style-type: none"> <li>Replace (warm engine before draining).</li> </ul>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Final gear oil</b>	<ul style="list-style-type: none"> <li>Check oil level/oil leakage.</li> <li>Replace every 12 months.</li> </ul>	<input type="radio"/>				<input type="radio"/>
<b>Brakes*</b>	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Adjust if necessary.</li> </ul>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Wheels*</b>	<ul style="list-style-type: none"> <li>Check balance/damage/runout.</li> <li>Replace if necessary.</li> </ul>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Wheel bearings*</b>	<ul style="list-style-type: none"> <li>Check bearing assemblies for looseness/damage.</li> <li>Replace if damaged.</li> </ul>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Steering system*</b>	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Repair if damaged.</li> <li>Check toe-in.</li> <li>Adjust if necessary.</li> </ul>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Knuckle shafts/steering shaft*</b>	<ul style="list-style-type: none"> <li>Lubricate every 6 months with Lithium-soap-based grease.</li> </ul>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Fittings and fasteners*</b>	<ul style="list-style-type: none"> <li>Check all chassis fittings and fasteners.</li> <li>Correct if necessary.</li> </ul>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Battery*</b>	<ul style="list-style-type: none"> <li>Check specific gravity.</li> <li>Check breather hose for correct routing.</li> <li>Correct if necessary.</li> </ul>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

\* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

EBS00032



**Indicates a potential hazard that could result in serious injury or death.**






EBS00033

## SEAT, FENDERS AND FUEL TANK


## SEAT AND FRONT PANEL



Order	Job/Part	Q'ty	Remarks
1	<b>Removing the seat and front panel</b> Seat	1	Remove the parts in the order listed. <b>NOTE:</b> _____ Pull back the seat lock lever, than pull up on the rear of the seat.
2	Front panel	1	
3	Fuel tank breather hose	1	
4	Handlebar cover	1	<b>NOTE:</b> _____ When installing the handlebar cover, pass the fuel tank breather hose through the hole in the handlebar cover.
5	Neutral indicator light connectors	2	Disconnect. For installation, reverse the removal procedure.

EBS00037

FRONT FENDER




Order	Job/Part	Q'ty	Remarks
	<b>Removing the front fender</b>		
	Seat and front panel		Remove the parts in the order listed. Refer to "SEAT AND FRONT PANEL".
1	Fuel tank top panel	1	
2	Air cleaner joint clamp screw	1	Loosen.
3	Main switch	1	
4	Front fender	1	
			For installation, reverse the removal procedure.




EBS00039

## REAR FENDER AND FOOTREST BOARDS




Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear fender and footrest boards</b>		Remove the parts in the order listed.
	Seat		Refer to "SEAT AND FRONT PANEL".
	Front fender		Refer to "FRONT FENDER".
1	Battery band	1	
2	Main fuse	1	
3	Negative battery lead	1	Disconnect.
			<b>CAUTION:</b> <u>First disconnect the negative lead, then disconnect the positive lead.</u>
4	Positive battery lead	1	Disconnect.
5	Battery breather hose	1	Disconnect.



Order	Job/Part	Q'ty	Remarks
6	Battery	1	For installation, reverse the removal procedure.
7	Footrest board	2	
8	Rear fender	1	

EBS00042

FUEL TANK




Order	Job/Part	Q'ty	Remarks
1	<b>Removing the fuel tank</b> Seat and front panel Front fender Fuel hose	1	Remove the parts in the order listed. Refer to "SEAT AND FRONT PANEL". Refer to "FRONT FENDER". Disconnect. <b>NOTE:</b> _____ Before disconnecting the fuel hose, turn the fuel cock to "OFF". _____
2	Fuel tank	1	For installation, reverse the removal pro- cedure.






# ADJUSTING THE VALVE CLEARANCE

**CHK  
ADJ**




## NOTE:

- When the piston is at the Top Dead Center (TDC) on the compression stroke, there should be clearance between the valve stem tips and their respective adjusting screws.
- Be sure to align the alignment mark ③ on the camshaft sprocket with the alignment mark ④ on the cylinder head.
- If there is no clearance, rotate the crankshaft counterclockwise one turn.



- Measure the valve clearance using a thickness gauge ⑤.



## 3. Adjust:

- valve clearance



- Loosen the locknut ①.
- Insert a thickness gauge ② between the adjuster end and the valve end.
- Turn the adjuster ③ clockwise or counterclockwise with the tappet adjusting tool ④ until the proper clearance is obtained.




**Tappet adjusting tool (3 mm)  
P/N. YM-08035, 90890-01311**

- Hold the adjuster to prevent it from moving and then tighten the locknut.



**Locknut  
7 Nm (0.7 m · kg, 5.1 ft · lb)**



- Measure the valve clearance.
- If the clearance is incorrect, repeat the above steps until the proper clearance is obtained.









6. Adjust:
- throttle lever free play
- Refer to "ADJUSTING THE THROTTLE LEVER FREE PLAY".



**Throttle lever free play**  
1.5 ~ 5.0 mm (0.06 ~ 0.20 in)



EBS00052

## ADJUSTING THE THROTTLE LEVER FREE PLAY

### NOTE:

Engine idling speed should be adjusted properly before adjusting the throttle lever free play.

1. Measure:
- throttle lever free play ①
- Out of specification → Adjust.



**Throttle lever free play**  
1.5 ~ 5.0 mm (0.06 ~ 0.20 in)

2. Adjust:
- throttle lever free play



- Pull back the adjuster cover ①.
- Loosen the locknut ② on the carburetor side.
- Turn the adjuster ③ in or out until the correct free play is obtained.

Turning in	Free play is increased.
Turning out	Free play is decreased.

- Tighten the locknut ②.
- Push in the adjuster cover ①.



### WARNING

After adjusting the free play, turn the handlebar to the right and left to make sure that the engine idling speed does not increase.






EBS00057


## CHECKING THE SPARK PLUG

1. Remove:
  - spark plug
2. Check:
  - spark plug type
 Incorrect → Change.

**Standard spark plug  
CR7HS/NGK**



3. Check:
  - electrode ①  
Wear/damage → Replace.
  - insulator ②  
Abnormal color → Replace.  
Normal color is a medium-to-light tan color.
4. Clean:
  - spark plug  
(with a spark plug cleaner or wire brush)



5. Measure:
  - spark plug gap ③  
Use a wire gauge or thickness gauge.  
Out of specification → Regap.



**Spark plug gap**  
**0.6 ~ 0.7 mm (0.024 ~ 0.028 in)**

6. Tighten:
  - spark plug

**13 Nm (1.3 m · kg, 9.4 ft · lb)**

### NOTE:

Before installing a spark plug, clean the gasket surface and plug surface.



EBS00061

## MEASURING THE COMPRESSION PRESSURE

### NOTE:

Insufficient compression pressure will result in a loss of performance.

#### 1. Measure:

- valve clearance

Out of specification → Adjust.

Refer to “ADJUSTING THE VALVE CLEARANCE”.

#### 2. Start the engine, warm it up for several minutes, and then turn it off.

#### 3. Disconnect:


- spark plug cap

#### 4. Remove:

- spark plug

### CAUTION:

Before removing a spark plug, use compressed air to blow away any dirt accumulated in the spark plug well to prevent it from falling into the cylinder.



#### 5. Attach:

- adapter
- compression gauge ①



**Compression gauge**  
P/N. YU-33223, 90890-03081  
**Adapter**  
P/N. 90890-04082

#### 6. Measure:

- compression pressure

Out of specification → Refer to steps (c) and (d).



**Compression pressure (at sea level)**

**Minimum**

1,040 kPa  
(10.4 kg/cm<sup>2</sup>, 147.9 psi)

**Standard**

1,200 kPa  
(12.0 kg/cm<sup>2</sup>, 170.6 psi)


**Maximum**

1,340 kPa  
(13.4 kg/cm<sup>2</sup>, 190.5 psi)











EBS00068

## CHANGING THE ENGINE OIL

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place a container under the engine oil drain bolt.
3. Remove:
  - dipstick ①
  - engine oil drain bolt ② (along with the gasket)
4. Drain:
  - engine oil (completely from the crankcase)
5. Check:
  - engine oil drain bolt gasket
 Damage → Replace.



6. Install:
  - engine oil drain bolt ① (along with the gasket)

 **20 Nm (2.0 m · kg, 1.4 ft · lb)**

7. Fill:
  - crankcase (with the specified amount of the recommended engine oil)



### Quantity

#### Total amount

**0.95 L (0.84 Imp qt, 1.00 US qt)**

#### Periodic oil change

**0.80 L (0.70 Imp qt, 0.85 US qt)**



8. Install:
  - dipstick
9. Start the engine, warm it up for several minutes, and then turn it off.
10. Check:
  - engine (for engine oil leaks)
11. Check:
  - engine oil level
 Refer to "CHECKING THE ENGINE OIL LEVEL".





## CLEANING THE SPARK ARRESTER

CHK  
ADJ



- c. Tap the tailpipe lightly with a soft-face hammer or suitable tool, then use a wire brush to remove any carbon deposits from the spark arrester portion of the tailpipe and the inner contact surfaces of the muffler.
- d. Insert the tailpipe into the muffler and align the screw holes.
- e. Insert the screw and tighten it.



**Screw**  
**8 Nm (0.8 m · kg, 5.8 ft · lb)**

- f. Remove the purging bolt ③.
- g. Start the engine and rev it up approximately twenty times while momentarily creating exhaust system back pressure by blocking the end of the muffler with a shop towel.
- h. Stop the engine and allow the exhaust pipe to cool.
- i. Install the purging bolt ③ and tighten it.




**Bolt**  
**10 Nm (1.0 m · kg, 7.2 ft · lb)**







## CHECKING THE FINAL GEAR OIL LEVEL/ CHANGING THE FINAL GEAR OIL



EBS00101

### CHECKING THE FINAL GEAR OIL LEVEL

1. Place the machine on a level surface.
2. Remove:
  - dipstick ①
3. Check:
  - final gear oil level

Oil level should be between the maximum ① and minimum ② marks.

Oil level low → Add oil to the proper level.




**Recommended oil**  
**SAE80 API “GL-4” Hypoid gear oil**

### CAUTION:

**Take care not allow foreign material to enter the final gear case.**

4. Install:
  - dipstick



EBS00102

### CHANGING THE FINAL GEAR OIL

1. Place the machine on a level surface.
2. Place a receptacle under the final gear case.
3. Remove:
  - dipstick ①
  - final gear oil drain plug ②
4. Drain:
  - final gear oil
5. Install:
  - final gear oil drain plug

**23 Nm (2.3 m · kg, 17 ft · lb)**

### NOTE:

Check the gasket (drain plug). If it is damaged, replace it with a new one.

6. Fill:
- final gear case




**Total amount**  
0.12 L (0.11 Imp qt, 0.13 US qt)  
**Recommended oil**  
SAE80 API “GL-4” Hypoid gear oil

**CAUTION:**

**Take care not to allow foreign material to enter the final gear case.**

7. Check:
- final gear oil level  
Refer to “CHECKING THE FINAL GEAR OIL LEVEL”.
8. Install:
- dipstick





EBS00105

**CHECKING THE SWINGARM DUST BOOT**

1. Remove:
- C.D.I. magneto cover  
Refer to “C.D.I. MAGNETO” in chapter 4.
2. Check:
- dust boot ①  
Damage → Replace.  
Refer to “REAR SHOCK ABSORBER AND REAR SWINGARM” in chapter 7.
3. Install:
- C.D.I. magneto cover  
Refer to “C.D.I. MAGNETO” in chapter 4.







EBS00107

## CHECKING THE STEERING SYSTEM

1. Place the machine on a level surface.
2. Check:
  - steering shaft bushings and bearings  
Move the handlebar up and down, and/or back and forth.  
Excessive play → Replace the steering shaft bushings and or bearings.  
Refer to “STEERING SYSTEM” in chapter 7.
3. Check:
  - tie-rod ends  
Turn the handlebar to the left and/or right until it stops completely, then slightly move the handlebar from left to right.  
Tie-rod end has any vertical play → Replace the tie-rod end(s).  
Refer to “STEERING SYSTEM” in chapter 7.
4. Raise the front end of the machine so that there is no weight on the front wheels.



5. Check:
    - knuckles and/or wheel bearings  
Move the wheels laterally back and forth.  
Excessive free play → Replace the following parts.
- 1) Wheel bearings
  - 2) Bushings ①
  - 3) Thrust covers ②
  - 4) Knuckle shafts ③
  - 5) Spacers ④
  - 6) Cotter pins ⑤
- Refer to “FRONT AND REAR WHEELS” and “STEERING SYSTEM” in chapter 7.





EBS00114

## CHECKING THE TIRES

**⚠ WARNING**

This model is equipped with low pressure tires. It is important that they be inflated correctly and maintained at the proper pressures.


• **TIRE CHARACTERISTICS**

- 1) Tire characteristics influence the handling of ATVs. The tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. If other tire combinations are used, they can adversely affect your machine's handling characteristics and are therefore not recommended.

	Manufacturer	Size	Type
Front	DUNLOP	AT16× 7-7	KT145
Rear	DUNLOP	AT16× 8-7	KT145

• **TIRE PRESSURE**

- 1) Recommended tire pressure  
Front 20 kPa (0.20 kgf/cm<sup>2</sup>, 2.9 psi)  
Rear 20 kPa (0.20 kgf/cm<sup>2</sup>, 2.9 psi)
- 2) Tire pressure below the minimum specification could cause the tire to dislodge from the rim under severe riding conditions.  
The following are minimums:  
Front 17 kPa (0.17 kgf/cm<sup>2</sup>, 2.5 psi)  
Rear 17 kPa (0.17 kgf/cm<sup>2</sup>, 2.5 psi)
- 3) Use no more than  
Front 250 kPa (2.5 kgf/cm<sup>2</sup>, 36 psi)  
Rear 250 kPa (2.5 kgf/cm<sup>2</sup>, 36 psi)  
when seating the tire beads. Higher pressures may cause the tire to burst. Inflate the tires slowly and carefully. Fast inflation could cause the tire to burst.
- **MAXIMUM LOADING LIMIT**  
Vehicle load limits: 40 kg (88 lb)  
\*Total weight of the cargo, trailer hitch vertical load, rider, and accessories.



## 1. Measure:

- tire pressure

Out of specification → Adjust.

## NOTE:

- The low-pressure tire gauge ① is included as standard equipment.
- If dust or the like is stuck to this gauge, it will not provide the correct readings. Therefore, take two measurements of the tire's pressure and use the second reading.


Cold tire pressure	Front	Rear
<b>Standard</b>	20 kPa (0.20 kgf/cm <sup>2</sup> , 2.9 psi)	20 kPa (0.20 kgf/cm <sup>2</sup> , 2.9 psi)
<b>Minimum</b>	17 kPa (0.17 kgf/cm <sup>2</sup> , 2.5 psi)	17 kPa (0.17 kgf/cm <sup>2</sup> , 2.5 psi)
<b>Maximum</b>	23 kPa (0.23 kgf/cm <sup>2</sup> , 3.3 psi)	23 kPa (0.23 kgf/cm <sup>2</sup> , 3.3 psi)

## WARNING

Uneven or improper tire pressure may adversely affect the handling of this machine and may cause loss of control.

- Maintain proper tire pressures.
- Set tire pressures when the tires are cold.
- Tire pressures must be equal in both front tires and equal in both rear tires.

## CHECKING THE TIRES/ CHECKING THE WHEELS



### 2. Check:

- tire surfaces


Wear/damage → Replace.



**Tire wear limit <sup>a</sup>**  
**Front and rear: 3 mm (0.12 in)**

### **WARNING**

It is dangerous to ride with a worn-out tire.  
When tire wear is out of specification,  
replace the tire immediately.



EBS00116

## CHECKING THE WHEELS

### 1. Check:

- wheel ①

Damage/bends → Replace.

### **NOTE:**

Always balance the wheel when a tire or wheel  
has been changed or replaced.

### **WARNING**

- Never attempt even small repairs to the wheel.
- Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

EBS00117

## CHECKING AND LUBRICATING THE CABLES

### **WARNING**

A damaged cable sheath may cause corrosion and interfere with the cable movement. An unsafe condition may result so replace a damaged cable as soon as possible.

1. Check:
  - cable sheath  
Damage → Replace.
2. Check:
  - cable operation  
Unsmooth operation → Lubricate or replace.



**Recommended lubricant**  
**Lithium-soap-base grease**

### **NOTE:**

Hold the cable end up and apply several drops of lubricant to the cable.

EBS00118

## LUBRICATING THE LEVERS, STEERING SHAFT AND STEERING KNUCKLES

Lubricate the pivoting point and metal-to-metal moving parts of the levers, steering shaft and steering knuckles.



**Recommended lubricant**  
**Lithium-soap-base grease**



EBS00119

## ELECTRICAL SYSTEM

### CHECKING AND CHARGING THE BATTERY

#### WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:


- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

#### FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin — Wash with water.
- Eyes — Flush with water for 15 minutes and get immediate medical attention.

#### INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.



#### 1. Remove:

- seat
- battery band

Refer to "SEAT, FENDERS AND FUEL TANK".


#### 2. Disconnect:

- battery leads (from the battery terminals)
- battery breather hose

#### CAUTION:

First, disconnect the negative battery lead ①, and then the positive lead ②.





3. Remove:

- battery

4. Check:


- electrolyte level

The electrolyte level should be between the minimum level mark (a) and the maximum level mark (b).

Below the minimum level mark → Add distilled water to the proper level.

## CAUTION:

Add only distilled water. Tap water contains minerals which are harmful to the battery.




5. Check:

- specific gravity

Less than 1.280 → Recharge the battery.



**Specific gravity**  
1.280 at 20 °C (68 °F)



6. Charge:

- battery



**Battery charging amperage and time**  
7 amps/10 hrs

## ⚠ WARNING

Do not quick charge a battery.

## CAUTION:

- Loosen the battery sealing caps.
- Make sure the battery breather hose and battery vent are free of obstructions.
- To ensure maximum performance, always charge a new battery before using it.




- Do not use a high-rate battery charger. They force a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
  - If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
  - When charging a battery, be sure to remove it from the machine. (If charging has to be done with the battery mounted on the machine, disconnect the negative lead from the battery terminal.)
  - To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
  - Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
  - Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
  - If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
- 

**NOTE:** \_\_\_\_\_

Replace the battery whenever:

- battery voltage does not rise to specification or bubbles fail to rise during charging,
  - sulfation of one or more battery cells occurs (as indicated by the battery plates turning white or material accumulating in the bottom of the battery cell),
  - specific gravity readings after a long, slow charge indicate that one battery cell's charge is lower than the rest,
  - warpage or buckling of the battery plates or insulators is evident.
-




7. Check:
  - battery breather hose and battery vent  
Obstruction → Clean.  
Damage → Replace.
8. Install:
  - battery
9. Connect:
  - battery breather hose ①

## CAUTION:

When checking the battery, make sure the battery breather hose is properly installed and routed correctly. If the battery breather hose is positioned so as to allow electrolyte or hydrogen gas from the battery to contact the frame, the machine and its finish may be damaged.

## NOTE:

Refer to “CABLE ROUTING” in chapter 2.



10. Check:
  - battery terminals  
Dirt → Clean with a wire brush.  
Loose connection → Connect properly.
11. Connect:
  - battery leads  
(to the battery terminals)

## CAUTION:

First, connect the positive battery lead ①, and then the negative battery lead ②.

12. Lubricate:
  - battery terminals

	<b>Recommended lubricant</b> <b>Dielectric grease</b>
-------------------------------------------------------------------------------------	----------------------------------------------------------

13. Install:
  - battery band
  - seat  
Refer to “SEAT, FENDERS AND FUEL TANK”.



- | Items   | Amperage rating | Q'ty |
|---------|-----------------|------|
| Main    | 5 A             | 1    |
| Reserve | 5 A             | 1    |

**Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the ignition systems to malfunction and could possibly cause a fire.**

Refer to "SEAT, FENDERS AND FUEL TANK".




EBS00198

# ENGINE

## ENGINE

### EXHAUST PIPE/MUFFLER, BREATHER HOSE AND LEADS




4

Order	Job/Part	Q'ty	Remarks
	<b>Removing the exhaust pipe/muffler, breather hose and leads</b>		Remove the parts in the order listed.
	Rear fender		Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
1	Exhaust pipe/muffler	1	
2	Exhaust pipe gasket	1	
3	Spark plug lead	1	
4	C.D.I. magneto coupler	2	
5	Crankcase breather hose	1	
			For installation, reverse the removal procedure.




EBS00205

## ENGINE MOUNTING BOLTS




Order	Job/Part	Q'ty	Remarks
	<b>Removing the engine mounting bolts</b>		Remove the parts in the order listed.
	Carburetor		Refer to "CARBURETOR" in chapter 5.
	Starter motor		Refer to "ELECTRIC STARTING SYSTEM" in chapter 8.
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO".
1	Metal clamp	2	
2	Lower engine mounting nut/bolt	1/1	<b>CAUTION:</b> _____ <b>Install all of the bolts/nuts and then tighten them to full torque specifications.</b> _____ Refer to "INSTALLING THE ENGINE".



Order	Job/Part	Q'ty	Remarks
3	Upper engine mounting nut/bolt	1/1	Refer to "INSTALLING THE ENGINE".
4	Engine assembly	1	
5	Dust boot	1	Refer to "REMOVING THE ENGINE" and "INSTALLING THE ENGINE". For installation, reverse the removal procedure.






## REMOVING THE ENGINE

1. Remove:
  - metal clamps

### NOTE:

After removing the metal clamps, slide the dust boot ① towards the swingarm.




EBS00207

## INSTALLING THE ENGINE

1. Install:
  - dust boot ①

### NOTE:

Before mounting the engine assembly, install the dust boot onto the middle driven gear bearing housing.



2. Install:
  - upper engine mounting bolt/nut ①
  - lower engine mounting bolt/nut ②

### NOTE:

Do not fully tighten the bolts and nuts.

3. Tighten:
  - upper engine mounting nut ①

33 Nm (3.3 m · kg, 24 ft · lb)


- lower engine mounting nut ②

33 Nm (3.3 m · kg, 24 ft · lb)




EBS00218




## CYLINDER HEAD



Order	Job/Part	Q'ty	Remarks
	<b>Removing the cylinder head</b>		
	Carburetor assembly		Remove the parts in the order listed.
	Exhaust pipe/muffler		Refer to "CARBURETOR" in chapter 5.
	C.D.I. magneto cover		Refer to "ENGINE".
			Refer to "C.D.I. MAGNETO".
1	Spark plug lead	1	
2	Spark plug	1	
3	Camshaft sprocket cover	1	
4	Intake tappet cover	1	
5	Exhaust tappet cover	1	
6	Timing chain tension adjuster	1	
7	Timing chain tensioner assembly	1	Refer to "REMOVING THE CYLINDER HEAD" and "INSTALLING THE CYLINDER HEAD".
8	Camshaft sprocket	1	
9	Cylinder head	1	
10	Intake side timing chain guide	1	



Order	Job/Part	Q'ty	Remarks
11	Exhaust side timing chain guide	1	For installation, reverse the removal procedure.
12	Cylinder head gasket	1	
13	Dowel pin	2	



EBS00220

**REMOVING THE CYLINDER HEAD****1. Align:**

- "T" mark on the rotor  
(with the stationary pointer on the crankcase)



- Turn the crankshaft counterclockwise with a wrench.
- Align the "T" mark ① on the rotor with the stationary pointer ② on the crankcase.  
When the "T" mark is aligned with the stationary pointer, the piston is at Top Dead Center (TDC).

**NOTE:**

TDC on compression stroke check:

- Both rocker arms must have a valve clearance when the camshaft sprocket alignment mark ③ is aligned with the cylinder head alignment mark ④.
- If not, give the crankshaft one counterclockwise turn to meet the above condition.

**2. Loosen:**

- camshaft sprocket bolt ①  
Use the sheave holder ② to hold the rotor.

**NOTE:**

Do not allow the sheave holder to touch the projection on the rotor.




**Sheave holder**  
**P/N. YS-01880-A, 90890-01701**

**3. Remove:**

- timing chain tension adjuster
- timing chain tensioner assembly
- camshaft sprocket

**NOTE:**


- Fasten a safety wire to the timing chain to prevent it from falling into the crankcase.
- When removing the camshaft sprocket, it is not necessary to separate the timing chain.



4. Remove:
- bolts
  - nuts
  - cylinder head ①

**NOTE:**

Working in a crisscross pattern, loosen each nut 1/4 of a turn.




EBS00224


**CHECKING THE CAMSHAFT SPROCKET**

1. Check:
- camshaft sprocket  
Wear/damage → Replace the camshaft sprocket and timing chain as a set.

- ① 1/4 of a tooth
- ② Correct
- ③ Roller
- ④ Sprocket

**CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER**


1. Check:
- tappet covers ①
  - camshaft sprocket cover ②
  - O-rings  
Cracks/damage → Replace.



EBS00226

**CHECKING THE TIMING CHAIN GUIDES**

1. Check:
- intake side timing chain guide ①
  - exhaust side timing chain guide ②  
Wear/damage → Replace.



EBS00228

**CHECKING THE TIMING CHAIN TENSIONER ASSEMBLY**


1. Check:
- chain tensioner assembly  
Wear/damage → Replace.








- i. If the marks are aligned, temporarily tighten the camshaft sprocket bolt. If the marks are not aligned, change the meshing position of the camshaft sprocket and timing chain.



3. Install:
- timing chain tensioner assembly
  - timing chain tension adjuster

	<b>18 Nm (1.8 m · kg, 13 ft · lb)</b>
-------------------------------------------------------------------------------------	---------------------------------------

**NOTE:**


- Align the timing chain tensioner rod groove ① with the timing chain tensioner straight plug projection ②.
- The flat surface ③ of the timing chain tensioner rod should face towards the adjuster threaded hole ④.

**⚠ WARNING**

**Always use a new gasket.**


4. Adjust:
- timing chain tensioner
- Refer to “ADJUSTING THE TIMING CHAIN TENSIONER” in chapter 3.

5. Tighten:
- camshaft sprocket bolt ①

 **20 Nm (2.0 m · kg, 14 ft · lb)**

**NOTE:**

- Use the sheave holder ② to hold the rotor.
- Do not allow the sheave holder to touch the projection on the rotor.



**Sheave holder**  
**P/N. YS-01880-A, 90890-01701**


6. Check:
- camshaft sprocket alignment mark
  - rotor "T" mark
- Out of alignment → Adjust.






EBS00235

## CAMSHAFT, ROCKER ARMS AND VALVES



Order	Job/Part	Q'ty	Remarks
	<b>Removing the camshaft, rocker arms and valves</b>		Remove the parts in the order listed.
	Cylinder head		Refer to "CYLINDER HEAD".
1	Intake manifold	1	
2	Rocker arm shaft	2	Refer to "REMOVING THE ROCKER ARMS AND CAMSHAFT" and "INSTALLING THE CAMSHAFT AND ROCKER ARMS".
3	Rocker arm	2	
4	Adjuster	2	
5	Camshaft	1	
6	Valve cotter	4	Refer to "REMOVING THE VALVES AND VALVE SPRINGS" and "INSTALLING THE VALVES AND VALVE SPRINGS".
7	Valve spring retainer	2	
8	Valve spring	2	
9	Intake valve	1	
10	Exhaust valve	1	
11	Valve stem seal	2	
12	Valve spring seat	2	





Order	Job/Part	Q'ty	Remarks
13	Valve guide	2	For installation, reverse the removal procedure.



EBS00237

## REMOVING THE ROCKER ARMS AND CAMSHAFT

1. Loosen:
  - locknuts
  - adjusters
2. Remove:
  - intake rocker arm shaft
  - exhaust rocker arm shaft
  - intake rocker arm
  - exhaust rocker arm



### NOTE:

Remove the rocker arm shafts with the slide hammer bolt ① and weight ②.



**Slide hammer set**  
**P/N. YU-01083-A**  
**Slide hammer bolt (M8)**  
**P/N. 90890-01085**  
**Weight**  
**P/N. 90890-01084**

3. Remove:
  - camshaft ①

### NOTE:


Screw a M8 bolt ② into the threaded end of the camshaft and then pull out the camshaft.


EBS00238

## REMOVING THE VALVES AND VALVE SPRINGS

1. Check:
  - valve sealing  
 Leakage at the valve seat → Check the valve face, valve seat and valve seat width. Refer to “CHECKING THE VALVES AND VALVE SPRINGS”.

- a. Pour a clean solvent ① into the intake and exhaust ports.
- b. Check that the valve seals properly.  
 There should be no leakage at the valve seat ②.







2. Remove:
  - valve cotters

## NOTE:

Attach a valve spring compressor ① and attachment ② between the valve spring retainer and the cylinder head to remove the valve cotters.



**Valve spring compressor**  
 P/N. YM-04019, 90890-04019  
**Valve spring compressor attachment**  
 P/N. YM-04108, 90890-04108



EBS00223

## CHECKING THE CAMSHAFT

1. Check:
  - cam lobes  
 Pitting/scratches/blue discoloration → Replace.
2. Measure:
  - cam lobe dimensions ① and ②  
 Out of specification → Replace.



## Camshaft lobe limit

### Intake

- ① 25.200 mm (0.9921 in)
- ② 20.894 mm (0.8226 in)

### Exhaust

- ① 25.201 mm (0.9922 in)
- ② 20.921 mm (0.8237 in)

EBS00239

## CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS

The following procedure applies to all of the rocker arms and rocker arm shafts.

1. Check:
  - rocker arm  
 Damage/wear → Replace.



2. Check:

- rocker arm shaft

Blue discoloration/excessive wear/pitting/scratches → Replace or check the lubrication system.

3. Check:


- camshaft lobe

Excessive wear → Replace the camshaft.

4. Measure:

- rocker arm inside diameter ①

Out of specification → Replace.




**Rocker arm inside diameter**  
10.000 ~ 10.015 mm  
(0.3937 ~ 0.3943 in)

5. Measure:

- rocker arm shaft outside diameter ②

Out of specification → Replace.



**Rocker arm shaft outside diameter**  
9.981 ~ 9.991 mm  
(0.3930 ~ 0.3933 in)

6. Calculate:

- rocker-arm-to-rocker-arm-shaft clearance






**NOTE:**

Calculate the clearance by subtracting the rocker arm shaft outside diameter from the rocker arm inside diameter.

Above 0.08 mm (0.0031 in) → Replace the defective part(s).



**Rocker-arm-to-rocker-arm-shaft clearance**  
0.009 ~ 0.034 mm  
(0.0004 ~ 0.0013 in)  
<Limit>: 0.08 mm (0.0031 in)



EBS00240

## CHECKING THE VALVES AND VALVE SPRINGS

### 1. Measure:

- stem-to-guide clearance

**Stem-to-guide clearance =**  
**valve guide inside diameter (a) –**  
**valve stem diameter (b)**

Out of specification → Replace the valve guide.



### Stem-to-guide clearance

#### Intake

0.010 ~ 0.037 mm

(0.0004 ~ 0.0015 in)

<Limit>: 0.08 mm (0.0031 in)

#### Exhaust

0.025 ~ 0.052 mm

(0.0010 ~ 0.0020 in)

<Limit>: 0.10 mm (0.0039 in)

### 2. Replace:

- valve guide



### NOTE:

To ease guide removal, installation and to maintain correct fit, heat the cylinder head to 100 °C (212 °F) in an oven.

- Remove the valve guide using a valve guide remover ①.
- Install the new valve guide using a valve guide remover ① and valve guide installer ②.
- After installing the valve guide, bore the valve guide using a valve guide reamer ③ to obtain proper stem-to-guide clearance.



**Valve guide remover (5 mm)**

**P/N. YM-04097, 90890-04097**

**Valve guide installer (5 mm)**

**P/N. YM-04098, 90890-04098**

**Valve guide reamer (5 mm)**

**P/N. 90890-04099**

### NOTE:

After replacing the valve guide reface the valve seat.





3. Check:

- valve face

Pitting/wear → Grind the face.


- valve stem end

Mushroom shape or diameter larger than the body of the stem → Replace.

4. Measure:

- margin thickness (a)

Out of specification → Replace.



**Margin thickness**

**Intake**

0.5 ~ 0.9 mm

(0.0197 ~ 0.0354 in)


<Limit>: 1.6 mm (0.0630 in)

**Exhaust**

0.6 ~ 1.0 mm

(0.0236 ~ 0.0394 in)

<Limit>: 1.6 mm (0.0630 in)



5. Measure:

- runout (valve stem)

Out of specification → Replace.



**Runout limit**

0.02 mm (0.0008 in)

**NOTE:**

- When installing a new valve always replace the guide.
- If the valve is removed or replaced always replace the oil seal.

6. Eliminate:

- carbon deposits

(from the valve face and valve seat)



7. Check:

- valve seats

Pitting/wear → Reface the valve seat.







- b. Apply molybdenum disulfide oil to the valve stem.
- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the compound.

**NOTE:**


For best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.

- e. Apply a fine lapping compound to the valve face and repeat the above steps.

**NOTE:**

After every lapping operation be sure to clean off all of the compound from the valve face and valve seat.

- f. Apply Mechanic's blueing dye (Dykem) to the valve face.
- g. Install the valve into the cylinder head.
- h. Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- i. Measure the valve seat width again. If the valve seat width is out of specification, reface and relap the valve seat.




10.Measure:

- valve spring free length ①
- Out of specification → Replace.



**Valve spring free length**  
**32 mm (1.26 in)**  
**<Limit>: 30.4 mm (1.20 in)**




11.Measure:

- compressed spring force ①
- Out of specification → Replace.

② Installed length



**Compressed spring force**  
**136 ~ 158 N at 24.6 mm**  
**(13.87 ~ 16.11 kg,**  
**30.57 ~ 35.52 lb at 0.97 in)**



12. Measure:

- spring tilt ①


Out of specification → Replace.



**Spring tilt limit**

**Inner**

**2.5°/1.4 mm (2.5°/0.06 in)**



EBS00241

## INSTALLING THE VALVES AND VALVE SPRINGS

1. Apply:

- molybdenum disulfide oil  
(onto the valve stem and valve stem seal)


2. Install:

- valve spring seats
- valve stem seals **New**
- valves
- valve springs
- valve spring retainers

**NOTE:**

Install the valve springs with the larger pitch ① facing upwards.

② Smaller pitch



3. Install:

- valve cotters

**NOTE:**

Install the valve cotters while compressing the valve spring with the valve spring compressor ① and attachment ②.




**Valve spring compressor**

**P/N. YM-04019, 90890-04019**

**Valve spring compressor attachment**



**P/N. YM-04108, 90890-04108**



4. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a piece of wood.

**CAUTION:**

Hitting the valve tip with excessive force could damage the valve.



EBS00243

**INSTALLING THE CAMSHAFT AND  
ROCKER ARMS**

1. Install:

- camshaft ①

**NOTE:**

Install the camshaft groove ② facing down.

2. Apply:

- engine oil  
(onto the rocker arm shafts)

3. Install:

- rocker arms ①
- rocker arm shafts


**NOTE:**

Use a slide hammer bolt ② to install the rocker arm shaft.



EBS00245

## CYLINDER AND PISTON



Order	Job/Part	Q'ty	Remarks
	<b>Removing the cylinder and piston</b>		Remove the parts in the order listed.
	Cylinder head		Refer to "CYLINDER HEAD".
1	Cylinder	1	Refer to "INSTALLING THE CYLINDER".
2	Cylinder gasket	1	
3	Dowel pin	2	
4	Piston pin clip	2	
5	Piston pin	1	Refer to "REMOVING THE PISTON" and "INSTALLING THE PISTON".
6	Piston	1	
7	Piston ring set	1	
			For installation, reverse the removal procedure.






<b>Cylinder bore “C”</b>	<b>39.000 ~ 39.005 mm (1.5354 ~ 1.5356 in)</b>
<b>Taper limit “T”</b>	<b>0.05 mm (0.002 in)</b>
<b>Out-of-round “R”</b>	<b>0.01 mm (0.0004 in)</b>


**“C” = maximum of  $D_1 \sim D_2$**

**“T” = maximum of  $D_1$  or  $D_2$  – maximum of  $D_5$  or  $D_6$**

**“R” = maximum of D<sub>1</sub>, D<sub>3</sub> or D<sub>5</sub> –  
minimum of D<sub>2</sub>, D<sub>4</sub> or D<sub>6</sub>**


- b. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.
  - c. Measure piston skirt diameter "P" with the micrometer.
- ④ 5 mm (0.20 in) from the bottom edge of the piston



		<b>Piston size “P”</b>
	<b>Standard</b>	<b>38.960 ~ 38.975 mm (1.5339 ~ 1.5344 in)</b>


- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

**Piston-to-cylinder clearance =**  
Cylinder bore “C” –  
Piston skirt diameter “P”

 **Piston-to-cylinder clearance**  
0.025 ~ 0.045 mm  
(0.0010 ~ 0.0018 in)  
<Limit>: 0.15 mm (0.0059 in)

- f. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.

[illegible]



EBS00250

**CHECKING THE PISTON RINGS**

## 1. Measure:

- piston ring side clearance

Out of specification → Replace the piston and piston rings as a set.

**NOTE:**

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

**Piston ring side clearance****Top ring**

0.030 ~ 0.065 mm

(0.0012 ~ 0.0026 in)


&lt;Limit&gt;: 0.12 mm (0.0047 in)

**2nd ring**

0.020 ~ 0.055 mm

(0.0008 ~ 0.0022 in)

&lt;Limit&gt;: 0.12 mm (0.0047 in)



## 2. Install:

- piston ring  
(into the cylinder)

**NOTE:**

Level the piston ring into the cylinder with the piston crown.

## 3. Measure:

- piston ring end gap

Out of specification → Replace the piston ring.

**NOTE:**

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

**Piston ring end gap****Top ring**

0.08 ~ 0.20 mm

(0.0031 ~ 0.0079 in)

&lt;Limit&gt;: 0.45 mm (0.0177 in)

**2nd ring**

0.05 ~ 0.20 mm

(0.0020 ~ 0.0079 in)

&lt;Limit&gt;: 0.55 mm (0.0217 in)

**Oil ring**

0.20 ~ 0.70 mm

(0.0079 ~ 0.0276 in)




EBS00251

**CHECKING THE PISTON PIN**

## 1. Check:

- piston pin

Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.



## 2. Measure:

- piston pin outside diameter (a)


Out of specification → Replace the piston pin.

**Piston pin outside diameter**

**12.996 ~ 13.000 mm**

**(0.5117 ~ 0.5118 in)**

**<Limit>: 12.976 mm (0.5109 in)**



## 3. Measure:

- piston pin bore diameter (b)

Out of specification → Replace the piston.

**Piston pin bore diameter**

**13.002 ~ 13.013 mm**

**(0.5119 ~ 0.5123 in)**

**<Limit>: 13.043 mm (0.5135 in)**

## 4. Calculate:

- piston-pin-to-piston-pin-bore clearance

Out of specification → Replace the piston pin and piston as a set.

**Piston-pin-to-piston-pin-bore clearance =**

**Piston pin bore diameter (b) –**

**Piston pin outside diameter (a)**




**Piston-pin-to-piston clearance**

**0.002 ~ 0.017 mm**

**(0.00008 ~ 0.00067 in)**

**<Limit>: 0.067 mm (0.00264 in)**





EBS00252

**INSTALLING THE PISTON****1. Install:**

- piston rings  
(onto the piston)

**NOTE:**

- Be sure to install the piston rings so that the manufacturer's marks or numbers are located on the upper side of the rings.
- Lubricate the piston and piston rings liberally with engine oil.

**2. Position:**

- top ring
- 2nd ring
- oil ring

Offset the piston ring end gaps as shown.

① Top ring end

② Upper oil ring rail end

③ Expander end

④ Lower oil ring rail end

⑤ 2nd ring end

⑥ 20 mm (0.79 in)

**3. Install:**

- piston ①
- piston pin ②
- piston pin clips ③ **New**

**NOTE:**


- Apply engine oil onto the piston pin, piston rings and piston.
- Be sure that the arrow mark ① on the piston points to the exhaust side of the engine.
- Before installing the piston pin clips, cover the crankcase with a clean rag to prevent the piston pin clips from falling into the crankcase.

**4. Lubricate:**

- piston
- piston rings
- cylinder

**NOTE:**

Apply a liberal coating of engine oil.



EBS00253

**INSTALLING THE CYLINDER**

1. Install:

- cylinder

**NOTE:**

Install the cylinder with one hand while compressing the piston rings with the other hand.


**CAUTION:**

- Be careful not to damage the timing chain damper during installation.
- Pass the timing chain through the timing chain cavity.




EBS00256

## C.D.I. MAGNETO



Order	Job/Part	Q'ty	Remarks
	<b>Removing the C.D.I. magneto</b>		
	Rear fender		Remove the parts in the order listed.
			Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
1	Shift lever	1	Refer to "INSTALLING THE SHIFT LEVER".
2	C.D.I. magneto cover	1	Refer to "REMOVING THE C.D.I. MAGNETO ROTOR" and "INSTALLING THE C.D.I. MAGNETO ROTOR".
3	C.D.I. magneto cover gasket	1	
4	Dowel pin	2	
5	C.D.I. magneto rotor	1	
6	Woodruff key	1	
7	Pickup coil/stator assembly	1	
8	Neutral switch	1	For installation, reverse the removal procedure.



EBS00259

**REMOVING THE C.D.I. MAGNETO ROTOR**

## 1. Remove:


- C.D.I. magneto rotor nut
- washer

**NOTE:**

- While holding the C.D.I. magneto rotor ① with the sheave holder ②, loosen the rotor nut.
- Do not allow the sheave holder to touch the projection on the rotor.



**Sheave holder**  
P/N. YS-01880-A, 90890-01701



## 2. Remove:


- C.D.I. magneto rotor ①
- woodruff key

**NOTE:**

Use the flywheel puller ②.



**Flywheel puller**  
P/N. YM-01189, 90890-01189



EBS00262

**CHECKING THE PICKUP COIL/STATOR ASSEMBLY**

## 1. Check:

- pickup coil/stator assembly
- Damage → Replace.




EBS00268

**INSTALLING THE C.D.I. MAGNETO ROTOR****1. Install:**

- woodruff key
- C.D.I. magneto rotor

**NOTE:**

- Before installing the rotor, clean the outside of the crankshaft and the inside of the rotor.
- After installing the rotor, check that the rotor rotates smoothly. If not, reinstall the key and rotor.

**2. Tighten:**


- C.D.I. magneto rotor nut

**40 Nm (4.0 m · kg, 29 ft · lb)**
**NOTE:**

- While holding the C.D.I. magneto rotor ① with the sheave holder ②, tighten the C.D.I. magneto rotor nut.
- Do not allow the sheave holder to touch the projection on the rotor.



**Sheave holder**  
P/N. YS-01880-A, 90890-01701

**INSTALLING THE SHIFT LEVER****1. Install:**

- shift lever


**NOTE:**

Temporarily install the left footrest board, and then install the shift lever and align it with the mark ① on the left footrest board.




EBS00291


## CLUTCH



Order	Job/Part	Q'ty	Remarks
	<b>Removing the clutch</b>		
	Engine oil		Remove the parts in the order listed. Drain. Refer to "CHANGING THE ENGINE OIL" in chapter 3.
1	C.D.I. magneto cover	1	Refer to "C.D.I. MAGNETO".
	Clutch cover	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH".
2	Clutch cover gasket	1	
3	Dowel pin	2	
4	Push plate	1	
5	Circlip	1	
6	Pressure plate	1	
7	Push rod	1	
8	Friction plate 1 (with black color marking)	4	Refer to "INSTALLING THE CLUTCH".



Order	Job/Part	Q'ty	Remarks
9	Clutch plate 1	1	Refer to "INSTALLING THE CLUTCH".
10	Clutch plate 2	3	
11	Friction plate 2	1	
12	Thrust weight plate	1	
13	Clutch ball	12	
14	Thrust plate	1	
15	Clutch boss	1	
16	Clutch boss one-way cam	1	
17	Primary driven gear/clutch housing	1	
18	Spacer	1	Refer to "REMOVING THE PRIMARY DRIVE GEAR" and "INSTALLING THE PRIMARY DRIVE GEAR". For installation, reverse the removal procedure.
19	Primary drive gear	1	



EBS00297

**REMOVING THE CLUTCH**

1. Remove:
  - clutch cover

**NOTE:**

Loosen each screw 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the screws are fully loosened, remove them.



2. Loosen:
  - clutch boss nut ①

**NOTE:**

While holding the clutch boss ② with the clutch holder ③, loosen the clutch boss nut.



**Clutch holder**  
**P/N. 90890-04100**




EBS00298

**REMOVING THE PRIMARY DRIVE GEAR**

1. Loosen:
  - primary drive gear nut ①

**NOTE:**

Place an aluminum plate ② between the teeth of the primary driven gear/clutch housing ③ and primary drive gear ④.



EBS00300

**CHECKING THE FRICTION PLATES**

The following procedure applies to all of the friction plates.

1. Check:
  - friction plate  
Damage/wear → Replace the friction plates as a set.
2. Measure:
  - friction plate thickness  
Out of specification → Replace the friction plates as a set.


**NOTE:**

Measure the friction plate at four places.



**Friction plate thickness**  
**2.92 ~ 3.08 mm (0.115 ~ 0.121 in)**  
**<Limit>: 2.90 mm (0.114 in)**





EBS00301

**CHECKING THE CLUTCH PLATES**

The following procedure applies to all of the clutch plates.

## 1. Check:

- clutch plate

Damage → Replace the clutch plates as a set.

## 2. Measure:

- clutch plate warpage


(with a surface plate and thickness gauge

①)

Out of specification → Replace the clutch plates as a set.



**Clutch plate warpage limit**  
**0.06 mm (0.002 in)**



EBS00302

**CHECKING THE CLUTCH SPRINGS**

The following procedure applies to all of the clutch springs.

## 1. Check:

- clutch spring

Damage → Replace the clutch springs as a set.


## 2. Measure:

- clutch spring free length ②

Out of specification → Replace the clutch springs as a set.



**Clutch spring free length**  
**31.9 mm (1.26 in)**  
**<Limit>: 30.3 mm (1.19 in)**



EBS00303

**CHECKING THE CLUTCH HOUSING**

## 1. Check:

- clutch housing dogs


Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

- clutch housing bearing

Damage/pitting/wear → Replace.

**NOTE:**

Pitting on the clutch housing dogs will cause erratic clutch operation.



EBS00304

**CHECKING THE CLUTCH BOSS**


## 1. Check:

- clutch boss splines
- clutch boss cam groove
- clutch boss one-way cam

Damage/pitting/wear → Replace the clutch boss and clutch boss one-way cam as a set.

**NOTE:**

Pitting on the clutch boss splines will cause erratic clutch operation.



EBS00305

**CHECKING THE PRESSURE PLATE**

## 1. Check:

- pressure plate


Cracks/damage → Replace.

**CHECKING THE CLUTCH BALLS**

## 1. Check:

- clutch ball

Pitting/damage/wear → Replace the clutch balls as a set.



EBS00307


**CHECKING THE PRIMARY DRIVE GEARS**

## 1. Check:

- primary drive gear ①
- primary driven gear ②

Damage/wear → Replace the primary drive gear and clutch housing as a set.

Excessive noise during operation → Replace the primary drive gear and clutch housing as a set.



EBS00310


**INSTALLING THE PRIMARY DRIVE GEAR**

1. Tighten:

- primary drive gear nut ①

**50 Nm (5.0 m · kg, 36 ft · lb)**
**NOTE:**

Place an aluminum plate ② between the teeth of the primary driven gear/clutch housing ③ and primary drive gear ④.


**Sheave holder****P/N. YS-01880-A, 90890-01701****INSTALLING THE CLUTCH**

1. Install:

- clutch balls

**NOTE:**

Install the clutch balls ① on the primary driven gear/clutch housing as shown.




2. Install:

- thrust weight plate
- clutch boss one-way cam
- clutch boss

**NOTE:**

Align section ① of the clutch boss one-way cam with section ② of the clutch boss and then install the primary driven gear/clutch housing.






5. Install:
- clutch housing ①

**NOTE:**


Make sure that the primary driven gear teeth and primary drive gear teeth mesh correctly.



6. Install:
- clutch boss one-way cam ①
  - clutch boss ②

**NOTE:**

Align section (a) of the clutch boss one-way cam with section (b) of the clutch boss and then install the primary driven gear/clutch housing.



7. Tighten:
- clutch boss nut ①


60 Nm (6.0 m · kg, 43 ft · lb)

**NOTE:**

While holding the clutch boss ② with the clutch holder ③, tighten the clutch boss nut.





**Clutch holder**  
**P/N. 90890-04100**



8. Install:
- clutch balls

**NOTE:**

Install the clutch balls on the primary driven gear/clutch housing as shown.



## 9. Install:

- thrust weight plate ①
- friction plate 2 ②
- clutch plates 2 ③
- friction plates 1 ④
- clutch plate 1 ⑤
- pressure plate ⑥

Ⓐ silver section

**NOTE:**

Install the clutch plates and friction plates alternately on the clutch boss, starting and ending with a friction plate.

**CAUTION:**

- The friction plate 2 ② must be placed between the thrust weight plate and the third clutch plate 2.
- The clutch plate 1 ⑤ must be placed between the first and second friction plate 1.

## 10. Install:

- clutch cover

7 Nm (0.7 m · kg, 5.1 ft · lb)


**NOTE:**

Tighten the screws in stage, using a crisscross pattern.



EBS00315


## STARTER CLUTCH AND OIL PUMP



Order	Job/Part	Q'ty	Remarks
	<b>Removing the starter clutch and oil pump</b>		Remove the parts in the order listed.
	Clutch assembly		Refer to "CLUTCH".
1	Starter idle gear assembly	1	
2	Starter wheel gear	1	
3	Starter clutch assembly	1	
4	Spacer	1	
5	Oil pump drive gear	1	
6	Oil pump driven gear	1	
7	Oil pump assembly	1	
8	Oil pump gasket	1	
9	Oil strainer	1	
			For installation, reverse the removal procedure.




EBS00316




Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the oil pump</b>		
①	Oil pump housing cover	1	Remove the parts in the order listed.
②	Oil pump shaft	1	
③	Inner rotor	1	
④	Outer rotor	1	
⑤	Oil pump housing	1	
			For assembly, reverse the disassembly procedure.








4. Check:
  - starter idle gear teeth ①
  - starter wheel gear teeth ②
 Burrs/clips/roughness/wear → Replace.
5. Check:
  - starter wheel gear contacting surface ②
 Damage/pitting/wear → Replace.




EBS00330

## CHECKING THE OIL PUMP

1. Check:
  - oil pump drive gear ①
  - oil pump driven gear ②
  - oil pump housing ③
  - oil pump housing cover ④
 Cracks/wear/damage → Replace.
2. Clean:
  - oil strainer ①
 Damage → Replace.





## 3. Measure:

- inner-rotor-to-outer-rotor-tip clearance (a)
- outer-rotor-to-oil-pump-housing clearance (b)
- oil-pump-housing-to-inner-rotor-and-outer-rotor clearance (c)

Out of specification → Replace the oil pump.

- ① Inner rotor
- ② Outer rotor
- ③ Oil pump housing



### Inner-rotor-to-outer-rotor-tip clearance

0.05 ~ 0.07 mm  
(0.002 ~ 0.003 in)

<Limit>: 0.15 mm (0.006 in)

### Outer-rotor-to-oil-pump-housing clearance


0.013 ~ 0.036 mm  
(0.0005 ~ 0.0014 in)

<Limit>: 0.106 mm (0.0042 in)

### Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance

0.06 ~ 0.10 mm  
(0.0024 ~ 0.0039 in)

<Limit>: 0.17 mm (0.0067 in)




## 4. Check:

- oil pump operation


Rough movement → Repeat steps #1 and #3 or replace the defective parts.



## SHIFT SHAFT




Order	Job/Part	Q'ty	Remarks
	<b>Removing the shift shaft</b>		
	Clutch assembly		Remove the parts in the order listed. Refer to "CLUTCH".
1	Shift shaft	1	
2	Stopper lever	1	
3	Dowel pin	5	
			For installation, reverse the removal procedure.



EBS01018

### CHECKING THE SHIFT SHAFT


1. Check:
  - shift shaft ①  
Bends/damage/wear → Replace.
  - shift shaft spring ②  
Damage/wear → Replace.



EBS01019

### CHECKING THE STOPPER LEVER

1. Check:
  - stopper lever ①  
Bends/damage → Replace.
  - stopper lever spring ②  
Roller turns roughly → Replace the stopper lever.




### INSTALLING THE STOPPER LEVER

1. Install:
  - stopper lever ①

#### NOTE:

Hook the hooked end of the stopper lever spring onto the stopper lever and catch the straight end of the stopper lever spring onto the crankcase.



### INSTALLING THE SHIFT SHAFT

1. Install:
  - shift shaft ①


#### NOTE:

- Install the end of the shift shaft spring onto the shift shaft spring stopper ②.
- Make sure that the arm section of the shift shaft contacts the dowel pins on the shift drum ③.



EBS00319

## CRANKCASE




Order	Job/Part	Q'ty	Remarks
	<b>Removing the timing chain and separating the crankcase</b>		Remove the parts in the order listed.
	Engine		Refer to "ENGINE".
	Cylinder head		Refer to "CYLINDER HEAD".
	Cylinder and piston		Refer to "CYLINDER AND PISTON".
	C.D.I. magneto		Refer to "C.D.I. MAGNETO".
	Clutch		Refer to "CLUTCH".
	Starter clutch and oil pump		Refer to "STARTER CLUTCH AND OIL PUMP".
	Shift shaft		Refer to "SHIFT SHAFT".
1	Timing chain	1	Refer to "SEPARATING THE CRANKCASE" and "ASSEMBLING THE CRANKCASE".
2	Shift drum retainer	1	
3	Right crankcase	1	
4	Dowel pin	2	
5	Left crankcase	1	
			For installation, reverse the removal procedure.



EBS00321


## CRANKCASE BEARINGS



Order	Job/Part	Q'ty	Remarks
	<b>Removing the crankcase bearings</b>		
	Crankshaft		Remove the parts in the order listed.
	Transmission		Refer to "CRANKSHAFT".
	Middle driven pinion gear		Refer to "TRANSMISSION".
1	Bearing retainer	1	Refer to "MIDDLE GEAR".
2	Bearing	6	Refer to "INSTALLING THE BEARINGS".
			For installation, reverse the removal procedure.







EBS00339


### CHECKING THE BEARINGS AND OIL SEALS

1. Check:
  - bearings  
Clean and lubricate, then rotate the inner race with a finger.  
Roughness → Replace.
2. Check:
  - oil seals  
Damage/wear → Replace.

EBS00338

### CHECKING THE CRANKCASE

1. Thoroughly wash the case halves in a mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Check:
  - crankcase  
Cracks/damage → Replace.
  - oil delivery passages  
Clogged → Blow out with compressed air.




### INSTALLING THE BEARINGS

1. Install:
  - left main axle bearing ①

#### NOTE:

Press the left main axle bearing into the left crankcase ②, as shown in the illustration.

- ① 34.0 ~ 34.5 mm (1.34 ~ 1.36 in)  
 ② Crankcase mating surface



EBS00341

## ASSEMBLING THE CRANKCASE

### 1. Apply:

- sealant (Quick Gasket®) or Yamaha bond No. 1215 ①  
(to the mating surfaces of both case halves)




**Sealant (Quick Gasket®)**  
P/N. ACC-11001-05-01  
**Yamaha bond No. 1215**  
P/N. 90890-85505

### 2. Install:

- dowel pin
3. Fit the right crankcase onto the left case.  
Tap lightly on the case with a soft hammer.

### CAUTION:

**Before installing and torquing the crankcase holding screws, be sure to check whether the transmission is functioning properly by manually rotating the shift drum in both directions.**



### 4. Install:

- gaskets ① **New**
- crankcase screws

### 5. Tighten:

- crankcase screws

**7 Nm (0.7 m · kg, 5.1 ft · lb)**

② Screw:  $\ell = 45 \text{ mm}$

③ Screw:  $\ell = 60 \text{ mm}$

④ Screw:  $\ell = 75 \text{ mm}$

### NOTE:

Tighten the screws in stages, using a criss-cross pattern.

### 6. Apply:


- 4-stroke engine oil  
(to the crankshaft pin, bearing and oil delivery hole)

### 7. Check:


- crankshaft and transmission operation  
Unsmooth operation → Repair.



EBS00326

**CRANKSHAFT**

Order	Job/Part	Q'ty	Remarks
1	<b>Removing the crankshaft</b>	1	Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
	Crankshaft		
			Refer to "INSTALLING THE CRANK-SHAFT".
			For installation, reverse the removal procedure.



EBS00361

## CHECKING THE CRANKSHAFT

### 1. Measure:

- crank width Ⓐ

Out of specification → Replace the crankshaft.



**Crank width**  
40.20 ~ 40.25 mm  
(1.5827 ~ 1.5846 in)

### 2. Measure:

- side clearance Ⓓ

Out of specification → Replace the crankshaft.



**Big end side clearance**  
0.10 ~ 0.40 mm  
(0.0039 ~ 0.0157 in)  
<Limit>: 0.50 mm (0.0197 in)

### 3. Measure:

- runout Ⓒ

Out of specification → Replace the crankshaft.



**Runout limit**  
C1: 0.05 mm (0.0020 in)  
C2: 0.04 mm (0.0016 in)

### 4. Measure:

- small end free play Ⓕ

Out of specification → Replace the big end bearing, crankshaft pin, connecting rod and/or side washer as a set.



**Small end free play**  
**Standard**  
0.80 ~ 1.00 mm  
(0.0315 ~ 0.0394 in)  
<Limit>: 1.50 mm (0.0591 in)

EBS00362

## INSTALLING THE CRANKSHAFT

### 1. Install:

- crankshaft


### CAUTION:

Apply engine oil to each bearing to protect the crankshaft against scratches and to make installation easier.




EBS00345

## TRANSMISSION



Order	Job/Part	Q'ty	Remarks
	<b>Removing the transmission</b>		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
1	Main axle/1st pinion gear	1	Refer to "REMOVING THE TRANSMISSION" and "INSTALLING THE TRANSMISSION".
2	Shift fork guide bar	1	
3	Shift fork	1	
4	Drive axle/middle drive pinion gear assembly	1	
5	Shift drum	1	
6	1st wheel gear	1	
7	Drive axle dog gear	1	
8	Middle drive gear shim	1	
			For installation, reverse the removal procedure.




## REMOVING THE TRANSMISSION

### 1. Remove:

- shift fork guide bar ①
- shift fork ②
- drive axle/middle drive pinion gear assembly ③
- shift drum ④

### NOTE:

Remove the shift fork guide bar, shift fork, drive axle/middle drive gear assembly, and shift drum from the crankcase together.




EBS00350

## CHECKING THE SHIFT FORK

### 1. Check:

- shift fork cam follower ①
- shift fork pawl ②

Bends/damage/scoring/wear → Replace the shift fork.



I1520401

### 2. Check:


- shift fork guide bar

Roll the shift fork guide bar on a flat surface.

Bends → Replace.

### ⚠ WARNING

Do not attempt to straighten a bent shift fork guide bar.




I1520101

### 3. Check:

- shift fork movement

(along the shift fork guide bar)

Rough movement → Replace the shift fork and shift fork guide bar as a set.




EBS01103

**CHECKING THE SHIFT DRUM**

## 1. Check:

- shift drum grooves  
Damage/scratches/wear → Replace the shift drum assembly.
- shift drum segment ①  
Damage/wear → Replace the shift drum assembly.



I1650702

EBS00354


**CHECKING THE TRANSMISSION**

## 1. Measure:

- main axle runout  
(with a centering device and dial gauge ①)  
Out of specification → Replace the main axle.



**Main axle runout limit**  
**0.08 mm (0.0031 in)**




## 2. Measure:

- drive axle runout  
(with a centering device and dial gauge ①)  
Out of specification → Replace the drive axle.



**Drive axle runout limit**  
**0.08 mm (0.0031 in)**



I1650401

## 3. Check:

- transmission gears  
Blue discoloration/pitting/wear → Replace the defective gear(s).
- transmission gear dogs  
Cracks/damage/rounded edges → Replace the defective gear(s).

## 4. Check:


- transmission gear engagement  
(each pinion gear to its respective wheel gear)  
Incorrect → Reassemble the transmission axle assemblies.

## 5. Check:

- transmission gear movement  
Rough movement → Replace the defective part(s).

## 6. Check:

- circlips  
Bends/damage/looseness → Replace.




EBS00357

**INSTALLING THE TRANSMISSION****1. Install:**

- shift drum ①
- drive axle/middle drive pinion gear assembly ②
- shift fork ③
- shift fork guide bar ④

**NOTE:**

- The embossed marks on the shift fork should face towards the left of the engine.
- Be sure to install the forked section ① of the drive axle/middle drive gear assembly around the shift fork guide bar when installing the transmission.

**2. Check:**

- transmission  
Rough movement → Repair.

**NOTE:**


- Oil each gear and bearing thoroughly.
- Before assembling the crankcase, be sure that the transmission is in neutral and that the gears turn freely.





EBS00363

## MIDDLE GEAR





Order	Job/Part	Q'ty	Remarks
	<b>Removing the middle gear</b>		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE". Refer to "TRANSMISSION".
	Drive axle/middle drive pinion gear assembly		
1	Middle drive gear shim	1	
2	Middle driven gear shim		Refer to "SELECTING MIDDLE DRIVEN GEAR SHIMS".
3	Bearing	4	
4	Universal joint	1	
5	Universal joint yoke	2	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT".
6	Middle driven shaft (with driven pinion gear)	1	
7	Bearing retainer	1	
8	Bearing housing	1	
			For installation, reverse the removal procedure.











## 3. Install:

- universal joint



- Install the yoke into the universal joint.
- Apply wheel bearing grease to the bearings.
- Install the bearing ① onto the yoke.

**CAUTION:**

**Check each bearing. The needles can easily fall out of their races. Slide the yoke back and forth on the bearings; the yoke will not go all the way onto a bearing if a needle is out of place.**

- Press each bearing into the universal joint using a suitable socket.

**NOTE:**

The bearing must be inserted far enough into the universal joint so that the circlip can be installed.

- Install the circlips into the groove of each yoke.





EBS00376

## MEASURING THE MIDDLE GEAR BACKLASH


### 1. Measure:

- middle gear lash



#### Middle gear lash

0.17 ~ 0.31 mm (0.007 ~ 0.012 in)



- Temporarily install the drive axle/middle drive pinion gear assembly and middle driven pinion gear.
- Attach the pinion gear fix clamp ① to the drive axle/middle drive pinion gear assembly.




#### Pinion gear fix clamp

P/N. YM-04129, 90890-04129

### NOTE:

Tighten the bolt on one corner of the pinion gear fix clamp as shown to secure the pinion gear fix clamp.



- Attach the gear lash measurement tool ② and dial gauge ③.



#### Gear lash measurement tool

P/N. YM-01467, 90890-01467

② 25.2 mm (0.99 in)

- Measure the gear lash while rotating the middle driven shaft back and forth.

### NOTE:

Measure the gear lash at 4 positions. Rotate the middle driven gear 90° each time.


- If the gear lash is incorrect, adjust the gear lash by middle driven gear shim(s).



EBS00141

CARBURETOR

CARBURETOR




5

Order	Job/Part	Q'ty	Remarks
	<b>Removing the carburetor</b>		Remove the parts in the order listed.
1	Fuel overflow hose	1	Refer to "INSTALLING THE CARBURETOR".
2	Carburetor air vent hose	1	
3	Fuel hose	1	
4	Carburetor assembly	1	
5	Carburetor top cover	1	
6	Throttle cable	1	
7	Spring	1	
8	Piston valve	1	
9	Jet needle set	1	
			For installation, reverse the removal procedure.






EBS00144




Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the carburetor</b>		Remove the parts in the order listed. <b>NOTE:</b> Before disassembling the carburetor, make sure to note the number of times the pilot screw is turned out from the seated position to its set position.
①	Throttle stop screw	1	
②	Float chamber	1	
③	Pilot jet	1	
④	Main jet	1	
⑤	Needle jet	1	
⑥	Float pin	1	




Order	Job/Part	Q'ty	Remarks
⑦	Float	1	Refer to "ASSEMBLING THE CARBURETOR".
⑧	Needle valve	1	For assembly, reverse the disassembly procedure.






4. Check:
- piston valve ①  
Scratches/wear/damage → Replace.



5. Check:
- carburetor top cover ①
  - spring ②  
Cracks/damage → Replace.



6. Check:
- jet needle ①
  - main jet ②
  - needle jet ③
  - pilot jet ④
  - throttle stop screw ⑤  
Bends/wear/damage → Replace.  
Blockage → Blow out the jets with compressed air.
7. Check:
- piston valve movement  
Sticks → Replace the piston valve.  
Insert the piston valve into the carburetor body, and check for free movement.
8. Check:
- choke valve movement  
Sticks → Replace.




EBS00150

**ASSEMBLING THE CARBURETOR****NOTE:** \_\_\_\_\_

Before assembling the carburetor, make sure to turn out the pilot air screw the same number of times, as noted before disassembly, from the seated position to the set position.

**CAUTION:** \_\_\_\_\_

- Before reassembling, wash all of the parts in a clean petroleum based solvent.
- Always use a new gasket.

**INSTALLING THE CARBURETOR****1. Install:**

- jet needle set
- piston valve
- spring
- throttle cable

**NOTE:** \_\_\_\_\_

Align the slit ① of the throttle valve with the tab ② of the carburetor body.





## DRIVE TRAIN

### TROUBLESHOOTING

The following conditions may indicate damaged shaft drive components:

Symptoms	Possible Causes
<ol style="list-style-type: none"><li>1. A pronounced hesitation or “jerky” movement during acceleration deceleration or sustained speed. (This must not be confused with engine surging or transmission characteristics.)</li><li>2. A “rolling rumble” noticeable at low speed; a high-pitched whine; a “clunk” from a shaft drive component or area.</li><li>3. A locked-up condition of the shaft drive train mechanism, no power transmitted from the engine to the rear wheels.</li></ol>	<ol style="list-style-type: none"><li>A. Bearing damage.</li><li>B. Improper gear lash.</li><li>C. Gear tooth damage.</li><li>D. Broken drive shaft.</li><li>E. Broken gear teeth.</li><li>F. Seizure due to lack of lubrication.</li><li>G. Small foreign objects lodged between the moving parts.</li></ol>

**NOTE:**

Areas A, B, and C above may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal machine operating noise. If there is reason to believe these components are damaged, remove the components and check them.










EBS00157

**TROUBLESHOOTING CHART**

When basic condition “a” and “b” exist, check the following points:




# REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT




EBS00178

## REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT




Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear axle/final drive assembly and drive shaft</b>		Remove the parts in the order listed.
	Rear wheels		Refer to "FRONT AND REAR WHEELS" in chapter 7.
	Brake drum cover		Refer to "FRONT AND REAR BRAKES" in chapter 7.
	Final gear oil		Drain. Refer to "CHANGING THE FINAL GEAR OIL" in chapter 3.
1	Nut	1	Refer to "REMOVING THE NUTS" and "INSTALLING THE NUTS".
2	Nut	1	
3	Final gear case breather hose	1	
4	Bolt/nut	1/1	
5	Swingarm guard	1	




Order	Job/Part	Q'ty	Remarks
6	Rear axle/final drive assembly	1	Refer to "REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY" and "INSTALLING THE REAR AXLE/FINAL DRIVE ASSEMBLY". For installation, reverse the removal procedure.
7	Drive shaft	1	
8	Coupling gear	1	

EBS00179

## REAR AXLE/FINAL DRIVE ASSEMBLY



Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the rear axle/final drive assembly</b>		Remove the parts in the order listed.
1	Rear axle housing	1	Refer to "DISASSEMBLING THE REAR AXLE HOUSING" and "ASSEMBLING THE REAR AXLE HOUSING".
2	Rear axle housing bearing retainer	1	
3	Spacer	1	Refer to "DISASSEMBLING THE FINAL GEAR CASE" and "ASSEMBLING THE FINAL GEAR CASE".
4	Final gear case bearing retainer	1	
5	Spacer	1	
6	Final drive pinion gear	1	
7	Rear axle (with final drive ring gear)	1	
8	Final gear case	1	For assembly, reverse the disassembly procedure.



## REMOVING THE NUTS

1. Place the machine on a level surface.
2. Loosen:
  - nuts ①

### NOTE:


- Apply the rear brake lever so that the rear axle does not turn, when loosening the nuts.
- Use an axle nut wrench (36 mm).



**Axle nut wrench (36 mm)**  
P/N. YM-37132, 90890-01422

3. Elevate the rear wheels by placing the suitable stand under the frame.
4. Remove:
  - rear wheels
  - wheel hubs
  - nuts
5. Remove:
  - rear brake assembly

Refer to "FRONT AND REAR BRAKES" in chapter 7.





## REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY

1. Remove:
  - rear axle/final drive assembly ①

### NOTE:

Remove the rear axle/final drive assembly as an assembly after removing each bolt and nut.





EBS00181

## DISASSEMBLING THE REAR AXLE HOUSING

1. Remove:
  - rear axle housing bearing retainer

**NOTE:**

Use a ring nut wrench ①.



**Ring nut wrench**  
P/N. YM-38404, 90890-01430


EBS00181

## DISASSEMBLING THE FINAL GEAR CASE

1. Remove:
  - rear axle  
(with final drive ring gear)

**CAUTION:**

**Never directly tap the axle end with a hammer, since this will result in damage to the axle thread and spline.**



2. Remove:
  - final gear case bearing retainer


**NOTE:**

Use a ring nut wrench ①.



**Ring nut wrench**  
P/N. YM-38404, 90890-01430

3. Remove:
  - final drive pinion gear assembly  
With a soft hammer, lightly tap on the final drive pinion gear end.



EBS00190

## CHECKING THE REAR AXLE

### 1. Check:


- rear axle runout ①  
Out of specification → Replace.

### ⚠ WARNING

**Do not attempt to straighten a bent axle.**



**Rear axle runout limit  
1.5 mm (0.06 in)**




EBS00191

## CHECKING THE DRIVE SHAFT

### 1. Check:

- drive shaft splines ①
- coupling gear splines ②  
Wear/damage → Replace.



EBS00192

## CHECKING THE REAR AXLE HOUSING AND FINAL DRIVE ASSEMBLY

### 1. Check:

- final gear case ①
- rear axle housing ②  
Cracks/damage → Replace.

### 2. Check:

- gear teeth  
Pitting/galling/wear → Replace the drive pinion gear and ring gear as a set.


- oil seals
- O-rings  
Damage → Replace.

### 3. Check:

- bearings  
Damage → Replace.



# REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT



EBS00195

## ASSEMBLING THE FINAL GEAR CASE

### 1. Install:


- final drive pinion gear assembly
- spacer ①
- bearing
- final gear case bearing retainer

80 Nm (8.0 m · kg, 58 ft · lb)

Use a ring nut wrench ②.

### CAUTION:

Always use a new bearing.



**Ring nut wrench**  
P/N. YM-38404, 90890-01430

### 2. Install:


- oil seal ①
- dust seal ②

### NOTE:

Install the oil seal and dust seal as shown.

① 6 ~ 6.5 mm (0.24 ~ 0.26 in)

② 1 ~ 2 mm (0.04 ~ 0.08 in)



EBS00195

## ASSEMBLING THE REAR AXLE HOUSING

### 1. Install:


- rear axle housing bearing retainer

110 Nm (11.0 m · kg, 80 ft · lb)

Use a bearing retainer wrench ①.

### CAUTION:

Always use a new bearing.



**Ring nut wrench**  
P/N. YM-38404, 90890-01430

### 2. Install:

- bearing ①

### NOTE:

Install the bearing as shown.

① 0.5 mm (0.02 in)

② rear axle housing bearing retainer








EBS00378

## CHASSIS

## FRONT AND REAR WHEELS

## FRONT WHEELS




Order	Job/Part	Q'ty	Remarks
	<b>Removing the front wheels</b>		<p>Remove the parts in the order listed. Place the machine on a level surface.</p> <p><b>⚠ WARNING</b> _____  <b>Securely support the machine so there is no danger of it falling over.</b></p> <p>_____</p> <p>The following procedure applies to both of the front wheels.</p> <p>1 Cotter pin 1 Refer to "INSTALLING THE WHEEL HUBS".</p> <p>2 Axle nut 1 Refer to "INSTALLING THE WHEELS".</p> <p>3 Front wheel 1</p> <p>4 Front brake drum 1</p> <p>For installation, reverse the removal procedure.</p>



EBS00379

### REAR WHEELS



Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear wheels</b>		<p>Remove the parts in the order listed. Place the machine on a level surface.</p> <p><b>! WARNING</b> _____  <b>Securely support the machine so there is no danger of it falling over.</b></p> <p>_____</p> <p>The following procedure applies to both of the rear wheels.</p> <p>Refer to "INSTALLING THE WHEEL HUBS".</p> <p>Refer to "INSTALLING THE WHEELS".</p> <p>For installation, reverse the removal procedure.</p>
1	Cotter pin	1	
2	Axle nut	1	
3	Rear wheel	1	
4	Rear wheel hub	1	






**⚠ WARNING**

**Eye protection is recommended when using striking tools.**

- c. To install the wheel bearings, reverse the above sequence. Use a socket that matches outside diameter of bearing outer race to drive in bearing.

**CAUTION:**

**Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.**




EBS00384

## CHECKING THE REAR WHEEL HUBS

The following procedure applies to both of the rear wheel hubs.

1. Check:
  - rear wheel hub ①  
Cracks/damage → Replace.
  - wheel hub splines ②  
Wear/damage → Replace.



EBS00390


## INSTALLING THE WHEEL HUBS

The following procedure applies to both of the front and rear wheel hubs.

1. Install:
- axle nut ①
  - cotter pin ②
-  **70 Nm (7.0 m · kg, 50 ft · lb)**
- New**

**NOTE:**

Do not loosen the axle nut after torquing it. If the axle nut groove is not aligned with the cotter pin hole, align the groove with the hole by tightening the axle nut.



EBS00391

## INSTALLING THE WHEELS


The following procedure applies to both of the front and rear wheels.

1. Install:

- wheel

### NOTE:

The arrow mark ① on the tire must point in the direction of rotation **a** of the wheel.



**A** Front wheel

**B** Rear wheel

2. Tighten:

- nuts


28 Nm (2.8 m · kg, 20 ft · lb)




EBS00437


## FRONT AND REAR BRAKES

### FRONT BRAKE



Order	Job/Part	Q'ty	Remarks
	<b>Removing the front brakes</b>		
	Front wheels		Remove the parts in the order listed. Refer to "FRONT AND REAR WHEELS". The following procedure applies to both of the front brakes.
1	Brake shoe	2	Refer to "INSTALLING THE FRONT BRAKES".
2	Front brake cable (drum side)	1	
3	Brake shoe plate	1	Refer to "REMOVING THE BRAKES" and "INSTALLING THE FRONT BRAKES".
4	Brake camshaft lever	1	
5	Brake shoe wear indicator	1	
6	Brake camshaft	1	
7	Left front brake cable (lever side)	1	
8	Right front brake cable (lever side)	1	
9	Front brake lever	1	For installation, reverse the removal procedure.





Order	Job/Part	Q'ty	Remarks
12	Rear brake cable (lever side)	1	For installation, reverse the removal procedure.
13	Rear brake switch	1	
14	Rear brake lever	1	



## REMOVING THE BRAKES

The following procedure applies to each brake.

### 1. Remove:

- brake camshaft lever
- brake shoe wear indicator
- brake camshaft

### NOTE:

When removing the brake camshaft lever, mark the position on the brake camshaft lever where it is aligned with the punch mark in the brake camshaft.


EBS00439

## CHECKING THE BRAKE SHOE PLATES

The following procedure applies to each brake.

### 1. Check:

- brake shoe plate
- pivot pin
- brake camshaft
- Bends/cracks/damage → Replace.
- dust seal
- Wear/damage → Replace.



EBS00440

## CHECKING THE BRAKE SHOES


The following procedure applies to each brake.

### 1. Check:

- brake shoes ①
- brake shoe springs ②
- Cracks/damage → Replace as a set.

### NOTE:

When replacing the brake shoes, replace the brake shoe springs at the same time.




## 2. Check:

- brake shoe lining surface  
Glazed areas → Remove.  
Use coarse sandpaper.

## NOTE:

After using sandpaper, wipe off the polished particles with a cloth.



## 3. Measure:

- brake shoe lining thickness (a)  
Out of specification → Replace.


① Measuring points

## NOTE:

Replace the brake shoes as a set if either is found to be worn to the wear limit.



**Brake lining thickness**  
**4.0 mm (0.16 in)**  
**<Limit>: 2.0 mm (0.08 in)**



EBS00441

## CHECKING THE BRAKE DRUMS

The following procedure applies to each brake.

## 1. Measure:


- brake drum inside diameter (a)  
Out of specification → Replace.



**Rear brake drum inside diameter**  
**Front: 110.0 mm (4.33 in)**  
**<Limit>: 110.5 mm (4.35 in)**  
**Rear: 130.0 mm (5.12 in)**  
**<Limit>: 130.5 mm (5.14 in)**

**A** Front brake drum

**B** Rear brake drum



2. Check:
  - brake drum inner surface
 Oil/scratches → Remove.

Oil	Use a rag soaked in lacquer thinner or solvent.
Scratches	Use an emery cloth (light and even polishing).

- [A] Front brake drum  
[B] Rear brake drum

EBS00442

## INSTALLING THE FRONT BRAKES

The following procedure applies to both of the front brakes.

Reverse the “Removal” procedure.

Note the following points.



1. Lubricate:
  - brake camshaft
  - pivot pin



**Lithium-soap-based grease**

### CAUTION:

**During installation, lightly grease the brake camshaft and the pivot pin. Wipe off the excess grease.**




2. Install:
  - brake camshaft ①
  - brake shoe wear indicator ②
  - brake camshaft lever

**9 Nm (0.9 m · kg, 6.5 ft · lb)**

### NOTE:

- Install the brake camshaft so its punch mark (a) is positioned as shown.
- Align the projection on the brake shoe wear indicator with the notch in the brake camshaft.
- Align the punch mark in the brake camshaft with the mark on the brake camshaft lever.

- [A] Left side  
[B] Right side



3. Install:
  - brake shoe plate ①

**NOTE:**

When installing the brake shoe plate, align the groove ① of the brake shoe plate with the projection ② of the steering knuckle.

4. Install:
  - front brake cable (drum side)
  - brake shoes

**NOTE:**

Check that the brake shoes are properly positioned.

5. Check:
  - brake camshaft operation  
Unsmooth operation → Repair.
6. Adjust:
  - front brake  
Refer to “ADJUSTING THE FRONT BRAKE” in chapter 3.

EBS00442

## INSTALLING THE REAR BRAKE

Reverse the “Removal” procedure.  
Note the following points.


1. Lubricate:
  - brake camshaft
  - pivot pin



Lithium-soap-based grease

**CAUTION:**

During installation, lightly grease the brake camshaft and the pivot pin. Wipe off the excess grease.



## 2. Install:

- brake camshaft ①
- brake shoe wear indicator plate ②
- brake camshaft lever

**9 Nm (0.9 m · kg, 6.5 ft · lb)**

## NOTE:


- Install the brake camshaft so its punch mark ③ is positioned as shown.
- Align the projection on the brake shoe wear indicator with the notch in the brake camshaft.
- Align the punch mark in the brake camshaft with the mark on the brake camshaft lever.

## 3. Install:

- rear brake cable (drum side)
- brake shoes

## NOTE:

Check that the brake shoes are properly positioned.



## 4. Install:

- brake drum boss
- brake drum
- lock washers ① **New**

## NOTE:

Bend the tabs of each lock washer along a flat side of each nut.

## 5. Check:

- brake camshaft operation  
Unsmooth operation → Repair.

## 6. Adjust:

- rear brake  
Refer to “ADJUSTING THE REAR BRAKE” in chapter 3.







EBS00444

## STEERING SYSTEM


### HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the handlebar</b>		
	Handlebar cover		Remove the parts in the order listed.
1	Handlebar grip	2	Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
2	Front brake cable	2	Refer to "REMOVING THE HANDLEBAR GRIPS" and "INSTALLING THE HANDLEBAR GRIPS".
3	Front brake lever assembly	1	Refer to "INSTALLING THE FRONT BRAKE LEVER ASSEMBLY".
4	Handlebar switch	1	Refer to "INSTALLING THE REAR BRAKE LEVER".
5	Rear brake cable	1	
6	Rear brake switch	1	
7	Rear brake lever	1	
8	Plastic band	1	



Order	Job/Part	Q'ty	Remarks
9	Upper handlebar holder	2	Refer to "INSTALLING THE HANDLE-BAR".
10	Handlebar	1	
11	Lower handlebar holder	1	
			For installation, reverse the removal procedure.



EBS00447


**REMOVING THE HANDLEBAR GRIPS**

1. Remove:

- handlebar grips ①

**NOTE:**

Blow compressed air between the handlebar and handlebar grip, and gradually push the grip off the handlebar.



EBS00445


**REMOVING THE REAR BRAKE SWITCH**

1. Remove:

- rear brake switch ①

**NOTE:**

Push the fastener when removing the rear brake switch out of the rear brake lever holder.



EBS00448

**CHECKING THE HANDLEBAR**


1. Check:

- handlebar ①

Bends/cracks/damage → Replace.

**⚠ WARNING**

Do not attempt to straighten a bent handlebar as this may dangerously weaken the handlebar.



EBS00449

**INSTALLING THE HANDLEBAR**

## 1. Install:


- lower handlebar holder
- handlebar
- upper handlebar holders

**20 Nm (2.0 m · kg, 14 ft · lb)**
**NOTE:**

- Install the handlebar within 15° from the horizontal line shown in the illustration.
- The upper handlebar holders should be installed with the punched mark ① forward ②.

**CAUTION:**

First tighten the bolt ③ on the front side of the handlebar holder, and then tighten the bolt ④ on the rear side.



EBS00450





**INSTALLING THE HANDLEBAR GRIPS**

## 1. Install:

- handlebar grips

**NOTE:**

- Before installing the handlebar grips, temporarily install the rear brake lever and front brake lever assembly on the handlebar.
- Before applying the adhesive, wipe off grease or oil on the handlebar surface with a lacquer thinner.



EBS00451

**INSTALLING THE REAR BRAKE LEVER****1. Install:**

- rear brake lever ①
- handlebar switch ②

**NOTE:**

- Install the rear brake lever within 10° from the horizontal line shown in the illustration.
- After installing the rear brake lever, make sure the rear brake lever ①, handlebar switch ②, and handlebar grip ③ are in the positions shown in the illustration.

**2. Adjust:**

- rear brake  
Refer to “ADJUSTING THE REAR BRAKE” in chapter 3.

EBS00452

**INSTALLING THE FRONT BRAKE LEVER ASSEMBLY****1. Install:**

- front brake lever assembly ①

**NOTE:**

- Install the front brake lever assembly within 10° from the horizontal line shown in the illustration.
- After installing the front brake lever assembly, make sure that the clearance ① between the front brake lever assembly ① and handlebar grip ② is 9 mm (0.35 in).


**2. Adjust:**

- front brake  
Refer to “ADJUSTING THE FRONT BRAKE” in chapter 3.




EBS00454

## STEERING STEM



Order	Job/Part	Q'ty	Remarks
	<b>Removing the steering stem</b>		
	Front fender		Remove the parts in the order listed. Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
	Handlebar		Refer to "HANDLEBAR".
1	Lock washer	1	Refer to "INSTALLING THE LOCK WASHER".
2	Steering stem bushing	2	
3	Spacer	2	
4	Oil seal	2	
5	Steering stem	1	Refer to "REMOVING THE STEERING STEM" and "INSTALLING THE STEERING STEM". For installation, reverse the removal procedure.




EBS00455

**REMOVING THE STEERING STEM**

1. Remove:
  - steering stem

**NOTE:**

When loosening each tie-rod end nut ①, hold the tie-rod ball joint with a 14-mm wrench ②.




EBS00456

**CHECKING THE STEERING STEM**


1. Check:
  - steering stem
 Bends → Replace.

**⚠ WARNING**

Do not attempt to straighten a bent stem; this may dangerously weaken the stem.



2. Check:
  - steering stem bushings ①
 Wear/damage → Replace.

**INSTALLING THE STEERING STEM**

1. Tighten:
  - steering stem nut ①


35 Nm (3.5 m · kg, 25 ft · lb)

- tie-rod end nut ②

40 Nm (4.0 m · kg, 29 ft · lb)

**NOTE:**

When tightening each tie-rod end nut ②, hold the tie-rod ball joint with a 14-mm wrench ③.



EBS00459

**INSTALLING THE LOCK WASHER**

1. Install:
  - lock washer ① **New**


**NOTE:**

Bend a lock washer tab along a flat side of each bolt.




EBS00460

## TIE-RODS AND STEERING KNUCKLES



Order	Job/Part	Q'ty	Remarks
	<b>Removing the tie-rods and steering knuckles</b>		Remove the parts in the order listed.
	Front brakes		Refer to "FRONT AND REAR BRAKES". The following procedure applies to both of the tie-rods and steering knuckles.
1	Tie-rod	1	Refer to "REMOVING THE TIE-RODS" and "INSTALLING THE TIE-RODS".
2	Steering knuckle	1	
3	Thrust cover	2	
4	Spacer	1	
5	Bushing	2	
			For installation, reverse the removal procedure.





EBS00461

**REMOVING THE TIE-RODS**


The following procedure applies to both of the tie-rods.

## 1. Remove:

- tie-rod ①

**NOTE:**

When removing the tie-rod, hold each tie-rod ball joint with a 14-mm wrench ② and then loosen the tie-rod end nut.



EBS00462

**CHECKING THE TIE-RODS**


The following procedure applies to both of the tie-rods.

## 1. Check:

- tie-rod free play and movement  
Free play → Replace the tie-rod end.  
Turns roughly → Replace the tie-rod end.

## 2. Check:

- tie-rod  
Bends/damage → Replace.





EBS00464

**CHECKING THE STEERING KNUCKLES**

The following procedure applies to both of the steering knuckles.

## 1. Check:

- steering knuckle  
Damage/pitting → Replace.




EBS00465

**INSTALLING THE TIE-RODS**

The following procedure applies to both of the tie-rods.

**1. Install:**

- tie-rod

 **15 Nm (1.5 m · kg, 11 ft · lb)****NOTE:**

- The tie-rod side which must be installed on the inside has grooves ①.
- When installing the tie-rod, hold each tie-rod ball joint with a 14-mm wrench ② and then tighten the tie-rod end nut.


**2. Adjust:**

- toe-in

Refer to “ADJUSTING THE TOE-IN” in chapter 3.

EBS00468

## FRONT SHOCK ABSORBER ASSEMBLIES AND FRONT SWINGARM




Order	Job/Part	Q'ty	Remarks
	<b>Removing the front shock absorber assemblies and front swingarm</b>		Remove the parts in the order listed.
1	Steering knuckles	2	Refer to "STEERING SYSTEM".
2	Front shock absorber	1	Refer to "REMOVING THE FRONT SWINGARM".
	Front swingarm		For installation, reverse the removal procedure.






EBS00476

## REAR SHOCK ABSORBER AND REAR SWINGARM



Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear shock absorber and swingarm</b>		Remove the parts in the order listed.
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO" in chapter 4.
	Rear axle/final drive assembly		Refer to "REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT" in chapter 6.
1	Rear shock absorber	1	
2	Pivot shaft	1	
3	Lock washer	1	Refer to "INSTALLING THE LOCK WASHER".
4	Rear swingarm	1	Refer to "REMOVING THE REAR SWINGARM".
5	Metal clamp	2	
6	Dust boot	1	
			For installation, reverse the removal procedure.






EBS00479

## CHECKING THE REAR SWINGARM


1. Check:
  - rear swingarm  
Bends/cracks/damage → Replace.
2. Check:
  - bushings  
Wear/damage → Replace.



EBS00481

## CHECKING THE DUST BOOT

1. Check:
  - dust boot ①  
Damage → Replace.



## INSTALLING THE LOCK WASHER

1. Install:
  - lock washer ① **New**

### NOTE:

Insert the small tab of the lock washer in the groove on the swingarm, and then bend the other lock washer tab along a flat side of the pivot shaft head.




EBS00500




## ELECTRICAL

## ELECTRICAL COMPONENTS

- |                              |                                  |                 |
|------------------------------|----------------------------------|-----------------|
| ① Main switch                | ⑧ Rectifier/regulator            | ⑮ Ignition coil |
| ② Neutral indicator light    | ⑨ Diode                          | ⑯ C.D.I. unit   |
| ③ Rear brake switch          | ⑩ Starting circuit cut-off relay | ⑰ Wire harness  |
| ④ Handlebar switch           | ⑪ Starter relay                  |                 |
| ⑤ Battery                    | ⑫ Neutral switch                 |                 |
| ⑥ Main fuse                  | ⑬ Pickup coil/stator assembly    |                 |
| ⑦ Engine stop switch (frame) | ⑭ Starter motor                  |                 |







EBS01028

## CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

### CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester  
P/N. YU-03112-C, 90890-03112

### NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.


The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left. The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.

### NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between black and black/white when the switch is set to "OFF".  
There is continuity between red and brown when the switch is set to "ON".



EBS01029


## CHECKING THE SWITCHES


Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to “CHECKING SWITCH CONTINUITY”.

Damage/wear → Repair or replace.

Improperly connected → Properly connect.

Incorrect continuity reading → Replace the switch.





EBS01030



## CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.

Damage/wear → Repair or replace the bulb, bulb socket or both.

Improperly connected → Properly connect.

No continuity → Repair or replace the bulb, bulb socket or both.



### TYPES OF BULBS

The bulbs used on this machine are shown in the illustration on the left.

- Bulbs (a) and (b) are used for the headlights and usually use a bulb holder that must be detached before removing the bulb. The majority of these types of bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulbs (c) is used for turn signal and tail/brake lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs (d) and (e) are used for meter and indicator lights and can be removed from their respective socket by carefully pulling them out.

### CHECKING THE CONDITION OF THE BULBS


The following procedure applies to all of the bulbs.

1. Remove:
  - bulb









EBS01045

### TROUBLESHOOTING

**The ignition system fails to operate (no spark or intermittent spark).**

Check:

1. spark plug
2. ignition spark gap
3. spark plug cap resistance
4. ignition coil resistance
5. main switch
6. engine stop switches
7. pickup coil resistance
8. source coil resistance
9. wiring connections (of the entire ignition system)

#### NOTE:

- Before troubleshooting, remove the following part(s):
  1. seat
  2. front fender
  3. fuel tank
- Troubleshoot with the following special tool(s).



**Dynamic spark tester**  
**P/N. YM-34487**  
**Ignition checker**  
**P/N. 90890-06754**  
**Pocket tester**  
**P/N. YU-03112-C, 90890-03112**

EBS01032

#### 1. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.  
 Refer to "CHECKING THE SPARK PLUG" in chapter 3.



**Standard spark plug**  
**CR7HS (NGK)**  
**Spark plug gap**  
**0.6 ~ 0.7 mm (0.024 ~ 0.028 in)**

- Is the spark plug in good condition, is it of the correct type, and is its gap within specification?




YES



NO


**Re-gap or replace the spark plug.**



EBS01034

### 2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition dynamic spark tester ① as shown.
- ② Spark plug cap
- ③ Spark plug
- Set the main switch to "ON".
- Measure the ignition spark gap ④.
- Crank the engine by pushing the starter switch and gradually increase the spark gap until a misfire occurs.



**Minimum ignition spark gap**  
**6 mm (0.24 in)**

- Is there a spark and is the spark gap within specification?

NO


YES

The ignition system is OK.

EBS01036

### 3. Spark plug cap resistance

- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester (" $\Omega \times 1k$ " range) to the spark plug cap as shown.



- Measure the spark plug cap resistance.



**Spark plug cap resistance**  
**10 k $\Omega$  at 20 °C (68 °F)**


- Is the spark plug cap OK?

YES

NO

Replace the spark plug cap.






EBS01038

### 4. Ignition coil resistance

- Disconnect the ignition coil connectors from the ignition coil terminals.
- Connect the pocket tester ( $\Omega \times 1$ ) to the ignition coil as shown.

**Positive tester probe** → orange terminal  
**Negative tester probe** → ignition coil base




- Measure the primary coil resistance.



**Primary coil resistance**  
 0.18 ~ 0.28  $\Omega$  at 20 °C (68 °F)

- Connect the pocket tester ( $\Omega \times 1k$ ) to the ignition coil as shown.

**Positive tester probe** → orange terminal  
**Negative tester probe** → spark plug lead



- Measure the secondary coil resistance.



**Secondary coil resistance**  
 6.32 ~ 9.48 k $\Omega$  at 20 °C (68 °F)

- Is the ignition coil OK?

YES

NO

Replace the ignition coil.

EBS01041

### 5. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

YES

NO

Replace the main switch.

EBS01042


### 6. Engine stop switches

- Check the engine stop switches for continuity. Refer to "CHECKING THE SWITCHES".
- Are the engine stop switches OK?

YES

NO

Replace the handle-bar switch or engine stop switch (frame).




EBS01040

### 7. Pickup coil resistance

- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 100$ ) to the pickup coil terminal as shown.

**Positive tester probe** → **white/red terminal ①**  
**Negative tester probe** → **white/blue terminal ②**



- Measure the pickup coil resistance.



**Pickup coil resistance**  
 264 ~ 396  $\Omega$  at 20 °C (68 °F)  
 (between white/red and white/blue)

- Is the pickup coil OK?

YES

NO


Replace the pickup coil/stator assembly.

EBS01099

### 8. Source coil resistance

- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 100$ ) to the source coil terminal.

**Positive tester probe** → **black/red terminal ①**  
**Negative tester probe** → **green/white terminal ②**



- Measure the source coil resistance.



**Source coil resistance**  
 304 ~ 456  $\Omega$  at 20 °C (68 °F)  
 (black/red and green/white)

YES

NO

Replace the pickup coil/stator assembly.

EBS01047

### 9. Wiring

- Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?


YES

NO

Replace the C.D.I. unit.

Properly connect or repair the ignition system's wiring.






EBS00507

**STARTING CIRCUIT OPERATION**

The starting circuit on this model consists of the starter motor, starter relay, starting circuit cut-off relay, rear brake switch and neutral switch. If the main switch is on and the engine stop switch is in the RUN position, the starter motor can be operated only if:


- The transmission is in neutral (the neutral switch is closed).
- or
- You pull in the rear brake lever (the rear brake switch is ON).



- ① Main fuse
- ② Battery
- ③ Starter relay
- ④ Starter motor
- ⑤ Starting circuit cut-off relay
- ⑥ Diode
- ⑦ Rear brake switch
- ⑧ Start switch
- ⑨ Neutral switch

[A] TO MAIN SWITCH

[B] FROM MAIN SWITCH



EBS01050

**TROUBLESHOOTING****The starter motor fails to turn.**

Check:

1. main fuse
2. battery
3. starter motor
4. starting circuit cut-off relay
5. starter relay
6. main switch
7. neutral switch
8. rear brake switch
9. start switch
10. diode
11. wiring connections  
(of the entire starting system)

**NOTE:**

- Before troubleshooting, remove the following part(s):
  1. seat
  2. front fender
  3. rear fender
  4. C.D.I. magneto cover
- Troubleshoot with the following special tool(s).



**Pocket tester**  
P/N. YU-03112-C, 90890-03112

EBS01043

**1. Main fuse**

- Check the main fuse for continuity. Refer to "CHECKING THE FUSE" in chapter 3.
- Is the main fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

**2. Battery**

- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



**Specific gravity**  
**1.280 at 20 °C (68 °F)**

- Is the battery OK?

↓ YES


↓ NO

- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EBS01051

**3. Starter motor**

- Connect the positive battery terminal ① and starter motor lead ② with a jumper lead ③.

**! WARNING**


- A wire that is used as a jumper lead must have at least the same capacity or more as that of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore make sure nothing flammable is in the vicinity.

- Does the starter motor turn?

↓ YES

↓ NO

Repair or replace the starter motor.




EBS01053

## 4. Starting circuit cut-off relay

**First step:**

- Disconnect the starting circuit cut-off relay coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$ ) and battery (12 V) to the starting circuit cut-off relay coupler as shown.


**Positive battery terminal** → red/white ①**Negative battery terminal** → black/yellow ②**Positive tester probe** → red/white ①**Negative tester probe** → blue/white ③

- Does the starting circuit cut-off relay have continuity between red/white and blue/white?

**Second step:**

- Connect the pocket tester ( $\Omega \times 1$ ) to the starting circuit cut-off relay coupler as shown.
- Measure the starting circuit cut-off relay for continuity as follows.

<b>Positive tester probe</b> → sky blue ④	<b>Continuity</b>
<b>Negative tester probe</b> → black/yellow ⑤	
<b>Positive tester probe</b> → black/yellow ⑤	<b>No continuity</b>
<b>Negative tester probe</b> → sky blue ④	

**NOTE:**


When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the testing readings correct?

↓ YES

↓ NO

Replace the starting circuit cut-off relay.



EBS01054

## 5. Starter relay


- Disconnect the starter relay coupler from the coupler.
- Connect the pocket tester ( $\Omega \times 1$ ) and battery (12 V) to the starter relay coupler as shown.

Positive battery terminal → blue/white ①

Negative battery terminal → red/white ②

Positive tester probe → red ③

Negative tester probe → black ④



- Does the starter relay have continuity between red and black?

YES

NO

Replace the starter relay.

EBS01041

## 6. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

YES

NO

Replace the main switch.

EBS01046

## 7. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

YES

NO

Replace the neutral switch.

## 8. Rear brake switch

- Check the rear brake switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the rear brake switch OK?

YES

NO

Replace the rear brake switch.

EBS01057


## 9. Start switch

- Check the start switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the start switch OK?

YES

NO

Replace the handle-bar switch.




EBS01060

## 10. Diode

- Remove the diode from the coupler.
- Connect the pocket tester ( $\Omega \times 1$ ) to the diode terminals as shown.
- Check the diode for continuity as follows.

Positive tester probe → green/yellow ①	Continuity
Negative tester probe → black/yellow ②	

Positive tester probe → black/yellow ②	No continuity
Negative tester probe → green/yellow ①	

**NOTE:**

When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the testing readings correct?

↓ YES

↓ NO

Replace the diode.

EBS01059

## 11. Wiring

- Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the starting system's wiring properly connected and without defects?


↓ YES

The starting system circuit is OK.

↓ NO


Properly connect or repair the starting system's wiring.









EBS01061

## STARTER MOTOR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the starter motor</b>		Remove the parts in the order listed.
1	Starter motor lead	1	
2	Ground lead	1	
3	Starter motor	1	
			For installation, reverse the removal procedure.
	<b>Disassembling the starter motor</b>		Remove the parts in the order listed.
①	Yoke	1	Refer to "ASSEMBLING THE STARTER MOTOR".
②	Armature coil	1	
③	Brush	1	
④	Bracket	1	
			For assembly, reverse the disassembly procedure.



EBS01064

## CHECKING THE STARTER MOTOR

1. Check:
  - commutator  
Dirt → Clean with 600-grit sandpaper.
2. Measure:
  - commutator diameter (a)  
Out of specification → Replace the starter motor.



**Commutator wear limit  
15.5 mm (0.61 in)**

- ### 3. Measure:
- mica undercut Ⓐ  
Out of specification → Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



**Mica undercut  
1 mm (0.04 in)**

**NOTE:**

The mica of the commutator must be undercut to ensure proper operation of the commutator.

4. Measure:
- armature assembly resistances (commutator and insulation)
- Out of specification → Replace the starter motor.

- a. Measure the armature assembly resistances with the pocket tester.





**Pocket tester**  
**P/N. YU-03112-C, 90890-03112**



**Armature coil**  
**Commutator resistance ①**  
 0.029 ~ 0.035 Ω at 20 °C (68 °F)  
**Insulation resistance ②**  
 Above 1 MΩ at 20 °C (68 °F)

- b. If any resistance is out of specification, replace the starter motor.



5. Measure:

- brush length ①

Out of specification → Replace the brushes as a set.



**Brush length wear limit**  
3.5 mm (0.14 in)

6. Measure:

- brush spring force

Out of specification → Replace the brush springs as a set.



**Brush spring force**  
3.24 ~ 4.22 N  
(320 ~ 430 gf, 11.66 ~ 15.19 oz)

7. Check:


- gear teeth

Damage/wear → Replace the gear.

8. Check:

- bearing
- oil seal
- O-rings

Damage/wear → Replace the defective part(s).



EBS00515

### ASSEMBLING THE STARTER MOTOR

1. Install:

- bracket
- brush
- armature coil
- yoke


**NOTE:**


Align the projection ① on the yoke with the slot ② on the bracket.



EBS00516

# CHARGING SYSTEM CIRCUIT DIAGRAM





EBS01065

**TROUBLESHOOTING****The battery is not being charged.**

Check:

1. main fuse
2. battery
3. charging voltage
4. charging coil resistance
5. wiring connections  
(of the entire charging system)

**NOTE:**

- Before troubleshooting, remove the following part(s):
  1. seat
  2. rear fender
- Troubleshoot with the following special tool(s).

**Inductive self-powered tachometer**

**P/N. YU-8036-B**  
**Engine tachometer**  
**P/N. 90890-03113**  
**Pocket tester**  
**P/N. YU-03112-C, 90890-03112**

EBS01043

**1. Main fuse**

- Check the main fuse for continuity.  
Refer to “CHECKING THE FUSE” in chapter 3.
- Is the main fuse OK?



YES



NO

Replace the fuse.

EBS01044

**2. Battery**

- Check the condition of the battery.  
Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3.



**Specific gravity**  
**1.280 at 20 °C (68 °F)**

- Is the battery OK?



YES



NO

- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.



EBS01066

## 3. Charging voltage


- Connect the engine tachometer to the spark plug lead.
- Connect the pocket tester (DC 20 V) to the battery as shown.

Positive tester probe →

positive battery terminal

Negative tester probe →

negative battery terminal



- Start the engine and let it run at approximately 5,000 r/min.
- Measure the charging voltage.



**Charging voltage**  
14 V at 5,000 r/min

**NOTE:**

Make sure the battery is fully charged.

- Is the charging voltage within specification?

NO

YES

The charging circuit  
is OK.


EBS01100

## 4. Charging coil resistance

- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$ ) to the charging coils.

Positive tester probe → white terminal ①

Negative tester probe → black terminal ②



- Measure the charging coil resistance.



**Charging coil resistance**  
0.72 ~ 1.08  $\Omega$  at 20 °C (68 °F)  
(between white and black)

YES

NO

Replace the rectifier/  
regulator.

Replace the pickup  
coil/stator assembly.

EBS01059

## 5. Wiring


- Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the charging system's wiring properly connected and without defects?

YES

NO

The charging system  
circuit is OK.


Properly connect or  
repair the charging  
system's wiring.




EBS00521

# SIGNAL SYSTEM

## CIRCUIT DIAGRAM





EBS01073

## TROUBLESHOOTING

**If the neutral indicator light fails to come on.**

Check:

1. main fuse
2. battery
3. main switch
4. wiring connections  
(of the entire signaling system)

### NOTE:

- Before troubleshooting, remove the following part(s):
  1. seat
  2. front fender
  3. C.D.I. magneto cover
- Troubleshoot with the following special tool(s).



**Pocket tester**  
P/N. YU-03112-C, 90890-03112

EBS01043

### 1. Main fuse

- Check the main fuse for continuity. Refer to “CHECKING THE FUSE” in chapter 3.
- Is the main fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

### 2. Battery

- Check the condition of the battery. Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3.



**Specific gravity**  
1.280 at 20 °C (68 °F)

- Is the battery OK?

↓ YES

↓ NO

- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EBS01041

### 3. Main switch

- Check the main switch for continuity. Refer to “CHECKING THE SWITCHES”.
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EBS01074

### 4. Wiring

- Check the entire signal system’s wiring. Refer to “CIRCUIT DIAGRAM”.
- Is the signaling system’s wiring properly connected and without defects?


↓ YES

↓ NO

Check the condition of each of the signaling system’s circuits. Refer to “CHECKING THE SIGNALING SYSTEM”.

Properly connect or repair the signaling system’s wiring.





EBS01075

**CHECKING THE SIGNALING SYSTEM**

EBS01077

1. The neutral indicator light fails to come on.

**1. Neutral indicator light bulb and socket**

- Check the neutral indicator light bulb and socket for continuity.  
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the neutral indicator light bulb and socket OK?

↓ YES

↓ NO

Replace the neutral indicator light bulb, socket or both.

**2. Neutral switch**

- Check the neutral switch for continuity.  
Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

↓ YES

↓ NO


Replace the neutral switch.

**3. Voltage**

- Connect the pocket tester (DC 20 V) to the neutral indicator light connectors (wire harness side) as shown.

**Positive tester probe** → brown ①

**Negative tester probe** → sky blue ②



- Set the main switch to "ON".
- Measure the voltage (DC 12 V).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.

The wiring circuit from the main switch to the neutral indicator light connectors is faulty and must be repaired.

## TROUBLESHOOTING

**NOTE:**

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for check, adjustment and replacement of parts.

### STARTING FAILURE/HARD STARTING

**FUEL SYSTEM****Fuel tank**

- Empty
- Clogged fuel filter
- Clogged fuel strainer
- Clogged fuel breather hose
- Deteriorated or contaminated fuel

**Fuel cock**

- Clogged fuel hose

**Carburetor**

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Deformed float
- Worn needle valve
- Improperly sealed valve seat
- Improperly adjusted fuel level
- Improperly set pilot jet

**Air filter**

- Clogged air filter element

**ELECTRICAL SYSTEM****Spark plug**

- Improper plug gap
- Worn electrodes
- Wire between terminals broken
- Improper heat range
- Faulty spark plug cap

**Ignition coil**

- Broken or shorted primary/secondary
- Faulty spark plug lead
- Broken body

**C.D.I. system**

- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty source coil
- Broken woodruff key

**Switches and wiring**

- Faulty main switch
- Faulty engine stop switch
- Broken or shorted wiring
- Faulty neutral switch
- Faulty start switch

**Starter motor**

- Faulty starter motor
- Faulty starter relay
- Faulty starter circuit cut-off relay

**Battery**

- Faulty battery

## **COMPRESSION SYSTEM**

### **Cylinder and cylinder head**

- Loose spark plug
- Loose cylinder head or cylinder
- Broken cylinder head gasket
- Broken cylinder gasket
- Worn, damaged or seized cylinder

### **Valve, camshaft and crankshaft**

- Improperly sealed valve
- Improperly contacted valve and valve seat
- Improper valve timing
- Broken valve spring
- Seized camshaft
- Seized crankshaft

### **Piston and piston rings**

- Improperly installed piston ring
- Worn, fatigued or broken piston ring
- Seized piston ring
- Seized or damaged piston

### **Crankcase and crankshaft**

- Improperly seated crankcase
- Seized crankshaft

### **Valve train**

- Improperly adjusted valve clearance
- Improperly adjusted valve timing

EBS00538

## **POOR IDLE SPEED PERFORMANCE**

### **POOR IDLE SPEED PERFORMANCE**

#### **Carburetor**

- Loose pilot jet
- Clogged pilot jet
- Clogged pilot air jet
- Improperly adjusted idle speed (throttle stop screw)
- Improper throttle cable play
- Flooded carburetor

#### **Electrical system**

- Faulty battery
- Faulty spark plug
- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty source coil
- Faulty ignition coil

#### **Valve train**

- Improperly adjusted valve clearance

#### **Air filter**

- Clogged air filter element

EBS00539

## **POOR MEDIUM AND HIGH-SPEED PERFORMANCE**

### **POOR MEDIUM AND HIGH-SPEED PERFORMANCE**

Refer to “STARTING FAILURE/HARD STARTING” and “POOR IDLE SPEED PERFORMANCE—Valve train”.

#### **Carburetor**

- Improper jet needle clip position
- Improperly adjusted fuel level
- Clogged or loose main jet
- Deteriorated or contaminated fuel

#### **Air filter**

- Clogged air filter element

EBS00540

## FAULTY DRIVE TRAIN

The following conditions may indicate damaged shaft drive components:

Symptoms	Possible Causes
<ol style="list-style-type: none"> <li>1. A pronounced hesitation or “jerky” movement during acceleration, deceleration, or sustained speed. (This must not be confused with engine surging or transmission characteristics.)</li> <li>2. A “rolling rumble” noticeable at low speed; a high-pitched whine; a “clunk” from a shaft drive component or area.</li> <li>3. A locked-up condition of the shaft drive mechanism, no power transmitted from the engine to the rear wheels.</li> </ol>	<ol style="list-style-type: none"> <li>A. Bearing damage.</li> <li>B. Improper gear lash.</li> <li>C. Gear tooth damage.</li> <li>D. Broken drive shaft.</li> <li>E. Broken gear teeth.</li> <li>F. Seizure due to lack of lubrication.</li> <li>G. Small foreign objects lodged between the moving parts.</li> </ol>

### NOTE:

Areas A, B, and C above may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal machine operating noise. If there is reason to believe these components are damaged, remove the components and check them.

EBS00541

## **FAULTY GEAR SHIFTING**

### **HARD SHIFTING**

Refer to “CLUTCH SLIPPING/Dragging—CLUTCH Dragging”.

#### **SHIFT LEVER DOES NOT MOVE**

##### **Shift shaft**

- Bent shift shaft

##### **Shift cam, shift forks**

- Groove jammed with impurities
- Seized shift fork
- Bent shift fork guide bar

##### **Transmission**

- Seized transmission gear
- Jammed impurities
- Incorrectly assembled transmission

#### **JUMPS OUT GEAR**

##### **Shift shaft**

- Improperly adjusted shift shaft position
- Improperly returned stopper lever

##### **Shift forks**

- Worn shift fork

##### **Shift drum**

- Improper thrust play
- Worn shift drum groove

##### **Transmission**

- Worn gear dog

EBS00545

## **CLUTCH SLIPPING/Dragging**

### **CLUTCH SLIPPING**

##### **Clutch**

- Loose clutch spring
- Fatigued clutch spring
- Worn friction plate
- Worn clutch plate
- Incorrectly assembled clutch

##### **Engine oil**

- Low oil level
- Improper quality (low viscosity)
- Deterioration

### **CLUTCH Dragging**

##### **Clutch**

- Warped pressure plate
- Unevenly tensioned clutch springs
- Loose clutch boss nut
- Bent clutch plate
- Swollen friction plate
- Broken clutch boss

##### **Engine oil**

- High oil level
- Improper quality (high viscosity)
- Deterioration

EBS00546

## **OVERHEATING**

### **OVERHEATING**

##### **Ignition system**

- Improper spark plug gap
- Improper spark plug heat range
- Faulty C.D.I. unit

##### **Fuel system**

- Improper carburetor main jet (improper setting)
- Improper fuel level
- Clogged air filter element

##### **Compression system**

- Heavy carbon build-up

##### **Engine oil**

- Improper oil level
- Improper oil viscosity
- Inferior oil quality

##### **Brake**

- Brake drag

EBS00549

## **FAULTY BRAKE**

### **POOR BRAKING EFFECT**

#### **Front and rear drum brake**

- Worn brake shoe lining
- Worn brake drum
- Oily or greasy brake shoe lining
- Oily or greasy brake drum
- Improperly adjusted brake lever free play
- Improper brake cam lever position
- Improper brake shoe position
- Fatigued/damaged return spring
- Broken brake cable

EBS00551

## **SHOCK ABSORBER MALFUNCTION**

### **MALFUNCTION**

- Bent or damaged damper rod
- Damaged oil seal lip
- Fatigued shock absorber spring

EBS00552

## **UNSTABLE HANDLING**

### **UNSTABLE HANDLING**

#### **Handlebar**

- Improperly installed or bent

#### **Steering**

- Incorrect toe-in
- Bent steering stem
- Improperly installed steering stem
- Damaged bearing or bearing race
- Bent tie rods
- Deformed steering knuckles

#### **Tires**

- Uneven tire pressures on both sides
- Incorrect tire pressure
- Uneven tire wear

#### **Wheels**

- Deformed wheel
- Loose bearing
- Bent or loose wheel axle
- Excessive wheel runout

#### **Frame**

- Bent
- Damaged frame

#### **Swingarm**


- Worn bearing or bushing
- Bent or damaged



YAMAHA MOTOR CO., LTD.  
2500 SHINGAI IWATA SHIZUOKA JAPAN

PRINTED IN U.S.A.

YFM50S WIRING DIAGRAM



- ① C.D.I. magneto
- ② Neutral switch
- ③ Main switch
- ④ Rectifier/regulator
- ⑤ Main fuse
- ⑥ Positive battery lead
- ⑦ Battery
- ⑧ Negative battery lead
- ⑨ Starter relay
- ⑩ Starter motor
- ⑪ Starting circuit cut-off relay
- ⑫ C.D.I. unit
- ⑬ Ignition coil
- ⑭ Spark plug
- ⑮ Diode
- ⑯ Rear brake switch
- ⑰ Engine stop switch (frame)
- ⑱ Handlebar switch
- ⑲ Start switch
- ⑳ Engine stop switch (handlebar)
- ㉑ Neutral indicator light

COLOR CODE

- B ..... Black
- Br ..... Brown
- O ..... Orange
- R ..... Red
- Sb ..... Sky blue
- W ..... White
- Y ..... Yellow
- B/R ..... Black/Red
- B/W ..... Black/White
- B/Y ..... Black/Yellow
- G/W ..... Green/White
- G/Y ..... Green/Yellow
- L/W ..... Blue/White
- R/W ..... Red/White
- W/L ..... White/Blue
- W/R ..... White/Red
- Y/R ..... Yellow/Red