

## **Pressure Washers** and Accessories

# **EQUALIZER 3200** (PN 9490A-E)

## Operators Manual and Parts Lists

Delco Pressure Washers LIT-EQ3200-DEL

## INTRODUCTION

Thank you for selecting a high pressure power washer from Delco Pressure Washers.

Your pressure washer has been manufactured using the most advanced components in the pressure industry.

When operated properly, our equipment has been designed and manufactured to give you years of trouble free, reliable use, with a minimal amount of regular maintenance.

Your pressure washer is mechanical, as with all mechanical equipment it requires proper installation, operation and maintenance as outlined in this manual.

The Operators Manual has been written for your benefit. For your safety and the safety of others, we recommend you and all operators read and understand the contents.

Should you experience any difficulty with your Delco pressure washer, please contact your nearest Delco Distributor immediately.

We are aware of your investment in an Delco pressure washer, therefore, our prime concern is that you become one of our "satisfied" owners. Please feel free to send us your comments and ideas.

### THANK YOU!!!

## PRESSURE WASHER LIMITED WARRANTY

- 1. **DELCO**<sup>®</sup> **Cleaning Systems, LLC** warrants its products for a period of one year from the date of purchase, against defects in material and/or workmanship. The warranty covers parts and labor, but excludes transportation.
- 2. Normal wear and tear items such as valves, seals, etc., are warranted for the initial 30 days following purchase by the end-user.
- 3. The high-pressure hose and accessories (trigger gun, extension/lance/wand and cleaning nozzles) are warranted for the initial 30 days following purchase by the end-user.
- 4. The burner coil on all **DELCO**<sup>®</sup> **Cleaning Systems, LLC**, hot water pressure washers and steam cleaners is warranted for five (5) years, excluding abuse due to leaving unit in unheated building, causing coil to freeze and burst.
- 5. Parts repaired or replaced under this warranty (except wear items) are warranted for the balance of the original warranty period or ninety (90) days, whichever is longer. Defective parts replaced under this warranty are the property of **DELCO® Cleaning Systems, LLC**.
- 6. All warranty service will be performed by a trained technician employed by an Phoenix Cleaning Systems, LLC distributor/dealer. Servicing distributor/dealer will abide by the **DELCO**<sup>®</sup> **Cleaning Systems**, **LLC**, Service Center Warranty Policy.
- 7. Warranty does not cover damage caused by freezing, abuse or chemicals. Abuse includes but is not limited to unauthorized repair, alterations carried out by any entity or individuals other than **DELCO**<sup>®</sup> **Cleaning Systems, LLC**, authorized service personnel, damage caused by contaminants in the water supply or operation in a manner which conflicts with instructions found in the Owners Manual.
- 8. **DELCO**<sup>®</sup> **Cleaning Systems, LLC**, and its distributors/dealers disclaim responsibility for any loss of time, use of equipment, loss of income, or any incidental or consequential damages.
- 9. Settlement of any warranty claim will be at the sole discretion of **DELCO**® **Cleaning Systems**, **LLC**.

## Thank You for Purchasing our Products!

Effective January, 2005, and supersedes all other warranties.



#### **IMPORTANT:**

Please read the following instructions before installing and operating this equipment.

#### **DANGER**

THIS EQUIPMENT CAN BE HAZARDOUS TO OPERATOR SAFETY AND ONLY AUTHORIZED PERSONNEL WHO HAVE READ AND UNDERSTAND THE INSTALLATION AND OPERATION MANUAL SHOULD

BE PERMITTED TO OPERATE THIS EQUIPMENT. DO NOT LEAVE WAND UNATTENDED WHILE EQUIPMENT IS RUNNING.

Failure to follow all cautionary warnings and procedures may result in serious or fatal injury and/or property damage including, but not limited to: fire, severe burns, concussion from explosion, electrocution, scalding, penetration by pressurized water, chemical reaction, asphyxiation, cuts, contusions, laceration, and loss of body parts and/or life.

#### DO'S

- ALWAYS WEAR SAFETY GLASSES, GOGGLES or FULL FACE SHIELD; GLOVES, and when spraying acids WEAR RAIN GEAR. NEVER RUN ACIDS THROUGH THE PUMP ON THIS EQUIPMENT.
- 2. USE ONLY THE SAME SIZE NOZZLE SUPPLIED WITH THIS EQUIPMENT.
- 3. CHECK YOUR BATTERY FOR WATER LEVELS AND MAINTAIN A GOOD CHARGE.
- 4. USE 3/4" (inch) x 50' (foot) GARDEN HOSE FOR WATER SUPPLY-.
- 5. USE A CLEAN FUEL CAN FOR REFUELING UNIT.
- 6. USE CLEAN DIESEL FUEL OR KEROSENE. NO ADDITIVES. Fill fuel tank each evening. This will help minimize condensation in fuel tank, and prolong fuel pump life.
- 7. Always follow chemical manufacturer's recommendations in use of chemicals with this equipment. Immediately after using chemical solutions through this equipment, flush thoroughly with clear water.
- 8. Disconnect all electrical power before performing any maintenance on this equipment.
- 9. Make sure positive is always positive and negative is always negative to keep from shorting out.
- 10. When storing this equipment in freezing weather conditions, this equipment must be drained thoroughly; and the plumbing system charged with a 50% solution of permanent type antifreeze. Antifreeze should be used when the equipment is not in service for prolonged periods or is being transported in freezing weather. NOTE: Antifreeze must be flushed out of equipment thoroughly before any cleaning project begins. Failure to do so could result in damage to paint or chemical attack on painted surfaces.
- 11. Use a water softener on your water system if it is high in mineral content (HARDNESS). Failure to do so will result in lime build-up in plumbing systems.
- 12. Use only manufacturer approved components when replacing parts on this equipment. Failure to do so may create operating conditions that are hazardous to personal health, safety, and will void the warranty.
- 13. Use only recommended oil in pump.

14. Always cool down coil.

#### **DO NOT'S**

## DO NOT - UNDER ANY CIRCUMSTANCES - POINT THE HIGH PRESSURE NOZZLE AT YOURSELF, OTHER PEOPLE, OR ANIMALS!

- 1. **DO NOT** use an undersized discharge nozzle.
- DO NOT disconnect the pressure hoses or wand while the equipment is HOT, PRESSURIZED or RUNNING.
- 3. **DO NOT** operate this equipment without sufficient water supply to the pump.
- 4. **DO NOT** operate this equipment without proper ventilation or in a closed space.
- 5. **DO NOT** use any type of fuel other than # 2 diesel, kerosene or # 1 home heating oil.
- 6. **DO NOT** leave wand unattended while equipment is running.
- 7. **DO NOT** point the stream of water from nozzle toward any person or animal (including the operator).
- 8. **DO NOT** touch exhaust stack, metal wand and hose on **HOT WATER UNIT**. *THEY GET VERY*
- 9. **DO NOT** obstruct the exhaust stack.
- 10. DO NOT run engine or burner within 25 feet of flammable materials or dust.
- 11. **DO NOT** use this equipment around or near explosive environment of any kind. (Gas, paint, solvents, etc.)
- 12. **DO NOT** screw the pop-off valve all the way in to prevent leaking or dripping.
- 13. **DO NOT** adjust the unloader-regulator valve (on trigger control units) to a pressure in excess of 200 PSI of equipments motor or pump rating.
- 14. **DO NOT** secure trigger gun in the open position (ON). Operate ONLY with your hand during operation to prevent injury.
- 15. **DO NOT** allow air into the water system through soap valve or loose fittings.
- 16. **DO NOT** operate the machine if the water pressure drops or is low.
- 17. **DO NOT** continue to operate this machine if burner fails to shut off when trigger is released (closed).
- 18. **DO NOT** continue to operate this machine if burner fails to light.
- 19. **DO NOT** smoke or operate this machine while filling or emptying fuel tank(s), or connecting/disconnecting tanks and fittings.
- 20. **DO NOT** operate this machine if coil becomes clogged or soothed.
- 21. **DO NOT** alter machine from manufacturer's design.
- 22. **DO NOT** attempt to pull beyond normal length.
- 23. **DO NOT** attempt to service this machine without first disconnecting the electrical service. Failure to do so may cause severe or *fatal electrical shock*.
- 24. DO NOT BY-PASS ANY SAFETY DEVICE ON THIS MACHINE!

## INSTALLATION

#### 1. LOCATION

Avoid operating units in small areas or near exhaust fans. Adequate oxygen is needed for combustion or dangerous carbon monoxide will result. Stationary units should be installed in accordance with local plumbing and heating codes.

#### 2. FUEL SUPPLY


Oil Fired Units: Fill fuel tank with clean kerosene, No. 1 home heating fuel, or diesel fuel (without anti-gel additives.)

#### 3. VENTING THE UNITS -

If the unit is to be used in an enclosed area it must be vented out.

The Draft Regulator (on oil-fired units) and chimney must be same size as the stack on the cleaner unit. Poor draft will cause the unit to soot-up and not operate efficiently. When installing the machine so the stack will be as straight as possible, protruding through the roof at a sufficient height to eliminate down-draft and to comply with local codes.

Always disconnect the battery when servicing your cleaner.



## **OPERATING THE MACHINE**

#### PRE-OPERATING INSTRUCTIONS

- 1. Connect the swivel end of the discharge hose to the cleaning gun.
- 2. Attach the hose to the machine outlet.
- 3. Check the fuel level in the fuel tank. Add fuel if required. It is best to keep fuel tank full during nonworking conditions.
- 4. Attach an ordinary garden hose to the float tank inlet. Turn on the water supply and let the float tank fill.
- 5. Place the end of the soap line into your soap solution container.

#### **OPERATING INSTRUCTIONS**

**NOTE:** On initial start up, or if machine has not been operated for several days, it is advisable to remove the nozzle from the cleaning gun and flush out any foreign material. Open the water supply. Turn on the engine and let the unit run until clear water flows through the cleaning gun.

- 1. Turn on the water supply.
- 2. Add fuel if required. Check oil levels in pump and engine before starting.
- 3. Install the nozzle tip into the cleaning gun.
- 4. Close the soap valve. (turn fully clockwise)
- 5. Securely hold the cleaning gun and turn the switch to position 1(pump).
- 6. The recommended method of cleaning is:
- A. Wet entire surface and remove the loose dirt with water only,
- B. Turn on the soap by opening the soap valve (turn the handle counterclockwise). NOTE: The operating pressure of the machine will drop to nearly zero until the soap line is primed.
- C. Cover the entire surface to be cleaned with soap/water solution by applying from the bottom up. Allow the soap to stay on surface four to five minutes.
- D. Close the soap valve and wash at high pressure with water only from the top down.

**NOTE:** Soap will flush from the coil and discharge hose within a minute or two of operation.

E. For hot water washing, turn the switch to position 2 (burner). **CAUTION:** If there is a sudden loss of pressure while washing with hot water, turn the burner off immediately and attempt to locate the problem while running cold water only. Failure to turn the burner off could cause excessive temperature and pressure build-up in the heating coil.

#### SHUT DOWN INSTRUCTIONS

- 1. If the burner is on turn control switch to position 1(pump).
- 2. Run water through the pump until cool water flows from the cleaning gun. Failure to do this could result in increased coil scaling.
- 3. Turn the control switch to off.
- 4. Turn off the water supply.
- 5. If the machine will be exposed to freezing temperatures, see winterizing procedure.

#### THINGS TO CHECK DAILY

- 1. Check oil level in pump.
- 2. Fill fuel tank at the end of each day's use to prevent condensation build-up in fuel system.
- 3. Fill soap container.
- 4. Check oil level in engine.

#### **THINGS TO CHECK WEEKLY**

- 1. Check and clean water float tank and pump inlet screen.
- 2. Check all hoses for leaks and damage. Repair or replace as needed.
- 3. Check pressure nozzle for wear. Replace if needed.
- 4. Check all nuts and bolts. Tighten as needed (DO NOT OVER TIGHTEN.)
- 5. Check all water connections for leaks. Tighten if loose.
- Check belts and pulleys for wear and tightness. (DO NOT CHECK WHILE MACHINE IS RUNNING.)

## MAINTENANCE OF COMPONENTS

#### **PUMPS**

- 1. Refer to pump section in this manual for your model of equipment.
- 2. Change pump oil after the first 25 hours of use. Subsequent changes should be every 250 hours or 3 months, whichever comes first.
  - A. Disconnect power supply.
  - B. Remove drain plug on pump and drain oil.
  - C. If the oil has water in it, it is important to flush out the pump with oil before refilling pump with the proper oil.
- 3. Refilling: Replace drain plug and fill slowly to the dot in the center of sight glass, or the proper level on dip stick. Do not over fill.
- 4. Use high quality 30 wt. non-detergent oil.


#### **OIL BURNERS**

- 1. BLOWER FAN: Clean blower fan in burner housing once a year or as often as needed. Dirt and deposits will reduce air delivery and affect combustion.
- 2. FUEL NOZZLE: Keep tip free of surface deposits wiping with a clean, solvent saturated, cloth rag. The nozzle should be changed once a year for maximum heating and emission control.
- 3. FUEL FILTER: Clean or replace every 400 hours or 3 months, whichever comes first (or as needed). This will help prolong fuel pump life and burner efficiency.

#### **DESCRIPTION**

#### **Racor Water Separator**

- 4. FUEL TANK: Drain one pint of fuel from bottom of fuel tank every 50 hours of use or every two weeks, whichever comes first. Check for water or contaminates in fuel. If any are present, drain and flush fuel tank then refill with clean fuel. This will prolong fuel pump life and burner efficiency.
- 5. ELECTRODES: Clean off carbon deposits on electrodes. To adjust electrodes refer to figure and these instructions:
- A. TO REMOVE THE GUN ASSEMBLY: Disconnect the oil line at the burner fan housing. Remove gun holding nut on outside of housing. Loosen transformer hold-down screw and swing open transformer on hinges. Gun assembly can now be removed by turning 1/4 turn and lifting out and pulling down through this opening.




**ELECTRODE ADJUSTMENTS - 12V BURNERS** 

B. SPACING OF ELECTRODES: The electrodes should be spaced 1/8 inch apart, 5/16 inch above the top of fuel nozzle and 1/4 inch from the center of fuel nozzle tip, to the electrodes.

- 6. FUEL PUMP: To bleed air out of fuel pump, open air bleed valve on side of fuel pump. Turn machine and burner ON. When fuel looks clear (NOT FOAMING), close air bleeding valve. Air is out of fuel lines and fuel pump.
- A. To check fuel pressure, plumb a 200 PSI gauge into the port marked gauge. DO NOT USE BLEED VALVE PORT TO CHECK FUEL PUMP PRESSURE.
- B. To adjust fuel pressure, insert a small flat screwdriver into pressure regulator slot and turn clockwise to increase pressure and counter clockwise to decrease pressure. One full turn is about 10 PSI. Use a pressure gauge. normal operating pressure is 140 PSI. DO NOT EXCEED 150 PSI.
  - C. Service the fuel pump once every 50 hours or 3 months by cleaning the fuel strainer screen.

    A clogged strainer or fuel filter will cause fuel pump starvation and dry the fuel pump up.

    The ONLY lubrication the fuel pump has is the fuel that runs through it. KEEP IT CLEAN for longer fuel pump life.



#### **WINTERIZING**

- 1. Shut off and disconnect the water supply.
- 2. Drain float tank.
- 3. Install antifreeze kit (available through local dealer.)
- 4. Remove nozzle from wand, and insert pick up hose and soap line into a bucket of 50% solution of antifreeze. Pump antifreeze through machine. Open and close trigger gun a few times to winterize unloader system. When antifreeze flows from the wand, shut the pump off. Disconnect antifreeze kit.

**NOTE: BEFORE** attempting to wash ANY painted surface, pump anti-freeze out of machine into a clean bucket and save for next use.

#### **DE-SOOTING COIL**

Poor grades of fuel oil or inadequate combustion air will cause heavy soot build up on the outside surface of the heating coil. This will insulate the coil and restrict air flow through the coil, further aggravating the soot build up.

To clean off soot, add Red Devil Soot Remover, using manufactures mixing instructions, or remove coil and clean thoroughly, or Call a Factory Authorized DELCO Dealer.

#### **DE-LIMING OR DE-SCALING OF COIL**

In hard water areas, or when using the wrong kind of soap, lime build-up inside the coil pipe will occur. Lime build-up will decrease the water temperature, water flow may eventually plug the coil.

It is recommended that a low pressure auxiliary pump be used if de-liming or de-scaling is needed. To install low pressure auxiliary pump.

- 1. Disconnect high pressure hose that goes between high pressure pump and coil inlet.
- 2. Connect about four feet of hose with screen to suction side of a low pressure auxiliary pump.
- 3. Connect a discharge hose between the low pressure auxiliary pump discharge side and the inlet.
- 4. Disconnect high pressure discharge hose from coil outlet.
- 5. Connect another 5-6 feet of hose to the coil outlet and run to a 5 gallon bucket.
- 6. Stick low pressure auxiliary pump suction hose w/screen into 5 gallon bucket.
- 7. Mix 2 gallons of water with 1 container of Coil Doctor.
- 8. Turn on pump and circulate the acid mixture through the coil system for about 40 minutes or until discharge solution stops foaming.

After cleaning, remove low pressure auxiliary pump assembly and connect all plumbing. Remove pressure tip from end of wand. Turn on pressure washer and run clean water through machine for about 5 minutes. This flushes out the coil and neutralizes any remaining acid. Replace pressure tip.

OR, call your Factory Authorized DELCO® Distributor.

#### **WARNING:**


COIL DOCTOR IS ACID AND IS HARMFUL TO SKIN AND EYES. ALWAYS FOLLOW MANUFACTURERS LABEL DIRECTIONS.

## **DIAGNOSIS AND MAINTENANCE**

PROBLEM	PROBABLE CAUSE	SOLUTION
Low Pressure	Worn nozzle	Replace nozzle of proper size.
	Belt slippage.	Tighten or replace; use correct belt.
	Air leak in inlet plumbing.	Use PTFE liquid or tape.
	Pressure gauge inoperative or not	Check pressure with new gauge and replace as needed.
	registering accurately.  Relief valve stuck partially plugged or	Class and recent relief value to queter processes and correct by
	improperly adjusted.	Clean and reset relief valve to system pressure and correct by- pass. Check supply tank for contamination.
	Worn seat or valves.	Clean or replace with valve kit.
	Inlet suction strainer clogged or improperly sized.	Use adequate size for inlet pump connection and fluid being pumped. Clean frequently.
	Worn seals. Abrasives in pumped fluid, severe cavitation; inadequate water supply, stressful inlet conditions.	Install and maintain proper filter, check line size and flow available to pump. Install a C.A.T.
	Fouled or dirty inlet or discharge valves.	Clean inlet and discharge valve assemblies.
	Worn inlet or discharge valves.	Replace with valve kit.
	Leaky discharge hose.	Replace hose. Check connections.
Pulsation, pump runs extremely rough, pressure low.	Faulty Pulsation Dampener	Check precharge (should be 30-50%) of system pressure or replace as needed.
	Restricted inlet or air entering inlet plumbing.	Check filters and clean as needed. Check fittings and use PTFE liquid or tape for air tight connection.
	Stuck inlet or discharge valve	Clean or replace valve. Check supply tank for contamination.
Water leakage from under the manifold	Worn seals	Replace with seal kit, check inlet pressure and system temperature, use Thermo Valve in by- inlet pressure regulator in inlet line.
Oil leak between crankcase and pumping section *Slight leakage.	Worn crankcase seals	Replace crankcase seals
Oil leaking in area of crankshaft	Worn crankshaft seal Bad bearing	Replace damaged seals. Replace bearing.
Excessive play in the end of the crankshaft.	Worn bearing	Replace bearing.
Water in crankcase inside of the crankcase	Humid air condensing into water	Change oil every 3 months or 500 hours intervals using premium grade 10W30 Non-detergent hydraulic oil, (other approved oil every month or 200 hours.)
	Leaking of crankcase seals or seals installed backward	Replace seals. Follow proper installation procedure. Contact Cat Pumps supplier for crankcase servicing.
Oil leaking at the rear portion of the crankcase	Damaged or improperly installed oil gauge, crankcase cover, or drain plug o-ring	Replace oil gauge, crankcase cover or drain plug o-ring. Thread in oil gauge and drain plug hand tight to avoid extruding o-ring.
Loud knocking noise in pump	Pulley loose on crankshaft	Check key and tighten screw
pump	Worn bearing, connecting rod or crankshaft.	Consult Cat Pumps supplier for crankcase servicing.
	Stressful inlet conditions.	Install C.A.T.
Frequent or premature failure of the packing	Cracked or scored plungers Abrasive material in the fluid being pumped Check supply tank for contamination.	Replace plungers Install proper filtration on pump inlet plumbing.
	Excessive pressure and/or temperature of fluid being pumped.	Check pressure and fluid inlet temperature; be sure they are within specified range.
	Over pressure of inlet or discharge	Reduce pressure per specifications.
	Running pump dry.	DO NOT RUN PUMP WITHOUT WATER!
Strong surging at the inlet and low pressure at the discharge side.	Foreign particles in the inlet or discharge valve or worn inlet or discharge valves.	Check for smooth surfaces on inlet and discharge valve seats.  Replace with kit if pitted or worn. Check supply tank for contamination, Install and regularly clean filter. Do not pump abrasive fluids.

Notes:	

### **TT 2028 PUMP COMPONENT LOCATOR**



#### **Recommended Grades of Pump Oil:**

DELCO Pump Oil is recommended as your first choice. This oil contains de-oxidizer, anti-wear, and rust inhibitor additives. A high quality SAE #30 non-detergent oil can be used in place of DELCO Pump Oil, but should be changed more often. Pump Capacity: 11.2 Fluid Ounces

## **TT 2028 PUMP PARTS LIST**

		114	2020 PUIVIP PARTS LIST
Ref. No.	Qty.	Part No.	Description
1	1	IP 700-02	CRANKCASE
2	2	IP 700-04	PLUG
3	1	IP 700-06	O-RING
4	1	IP 700-08	PROTECTOR
5	3	IP 700-10	OIL SEAL
6	1	IP 700-12	PLUG
7	1	IP 700-14	MANIFOLD
8	8	IP 700-16	WASHER
9	8	IP 700-18	SCREW
10	6	IP 700-20	O-RING
11	6	IP 700-22	VALVE SEAT
12	6	IP 700-24	VALVE PLATE
13	6	IP 700-26	SPRING
14	6	IP 700-28	VALVE CAGE
15	6	PF 026-01	O-RING
16	6	IP 700-32	VALVE CAP
17	6	IP 100-23	VALVE ASSEMBLY
18	3	IP 100-28	HEAD RING
19	3	IP 100-24	PACKING
20	3	IP 700-40	PACKING RETAINER
21	3	IP 700-42	O-RING
22	3	IP 700-44	O-RING
23	1	IP 700-46	SIGHT GAUGE
24	1	IP 700-49	NEEDLE BEARING
25	1	IP 700-50	OIL DIP STICK
26	3	IP 700-52	NUT
27	3	IP 700-54	WASHER
28	3	IP 700-56	PLUNGER
29	3	IP 700-58	O-RING
30	3	IP 700-60	BACK-UP RING
31	3	IP 700-62	FLINGER WASHER
32	3	IP 700-64	CONNECTING ROD PIN
33	1	IP 700-66	CRANKCASE COVER
34	4	IP 700-68	SCREW
35	1	IP 700-00	COVER GASKET
36	3	IP 700-70	CONNECTING ROD END
37	3	IP 700-72	CONNECTING ROD END
49	4	IP 700-74	SCREW
50	4	IP 700-76	WASHER
		IP 700-78	
51 52	4	IP 700-80	FLANGE SCREW
53		IP 700-82	
	4		WASHER
54 55	1	IP 700-86	SPACER
55 56	1	IP 700-88	O-RING
56 57	1	IP 700-90	OIL SEAL
57	1	IP 700-92	SNAP RING
58	1	IP 700-95	BEARING
59	1	IP 700-97	CRANKSHAFT

## TT 2028 Repair Kits

### RK 371-01 Valve Repair Kit

Ref. No.	Qty	Part #	Description
15	6	PF 026-01	O-RING
17	6	IP 100-23	VALVE ASSEMBLY


#### RK 733-02 Plunger Repair Kit

Ref. #	Qty	Part #	Description
18	3	IP 100-28	HEAD RING
19	3	IP 100-24	PACKING
20	3	IP 700-40	PACKING RETAINER
21	3	IP 700-42	O-RING
22	3	IP 700-44	O-RING

#### RK 733-03 V-Packing Kit

Ref. #	Qty	Part #	Description
18	3	IP 100-28	HEAD RING
19	3	IP 100-24	PACKING
21	3	IP 700-42	O-RING
22	3	IP 700-44	O-RING

## **UV-7500-2 UNLOADER COMPONENT LOCATOR**




#### UNLOADER VALVE COMPONENT PARTS LIST

		Designation, Denominación, Désignation,	
Pos. Ref.	Part No.	Bezeichnung	UV7500-2
1	CP-540081	Adjusting Cap	1
		Tapón de Protección de Ajuste	
		Bouchon de Protection de Ajustage Intstellung Schutzkappe	
2	CP-32094		1
2	CP-32094	Spring Muelle	'
		Ressort	
		Feder	
3	CP-107672	Spring Retainer	1
		Retenedor de Muelle	
		Retenue de la Ressort	
		Federplatte	
4	CP-45694	Piston Stem, M5	1
		Vástago de Émbolo, M5	
		Tige de Poussoir, M5 Kolbenschaft, M5	
5*	CP-20184	Back-Up Ring	1
Ü	01 20104	Anillo Antiextrusion	'
		Bague Anti-Extrusion	
		Stuetzring	
6*	CP-14190	O-Ring	1
		O-Anillo	
		O-Anneau	
_		O-Ring	<u>.</u>
7	CP-170673	Piston Retainer Retenedor de Émbolo	1
		Retenue d'Poussoir	
		Kolbensprengring	
8*	CP-13969	O-Ring	1
		O-Anillo	
		O-Anneau	
		O-Ring	
9*	CP-14759	O-Ring	1
		O-Anillo	
		O-Anneau O-Ring	
10*	CP-107675	Back-Up Ring	1
10	CF-10/0/3	Anillo Antiextrusion	'
		Bague Anti-Extrusion	
		Stuetzring	
11	CP-45696	Valve & Ball Assembly	1
		Ensamblaje de Válvula & de Bola	
		Ensemble de Soupape & de Bille	
4.0	OD 107555	Ventil & Kugel Anordnung	
12	CP-107680-2	Valve Seat	1
		Asiento de Válvula Siège de Soupape	
		Ventilsitz	
		· Ormone	1

#### **UNLOADER VALVE COMPONENT PARTS LIST**


Pos. Ref.	Part No.	Designation, Denominación, Désignation, Bezeichnung	UV7500-2
13*	CP-13963	O-Ring Empaque-O O-Anneau O-Ring	1
14*	CP-13969	O-Ring Empaque-O O-Anneau O-Ring	1
15	8000743	Check Valve with O-Ring Válvula de Regulación con O-Anillo Robinet de Réglage avec O-Anneau Drosselventil mit O-Ring	1
16	CP-45924	Spring Muelle/Resorte Ressort Feder	1
17*	CP-13969	O-Ring Empaque-O O-Anneau O-Ring	1
18	CP-45695	Bypass Fitting, 3/8 in NPT Conexión de Derivación, 3/8 in NPT Raccord de Dérivation, 3/8 in NPT Nebenschlußabdichtung, 3/8 in NPT	1
19	CP-107681	Dicharge Fitting, 3/8 in NPT Conexión de Descarga, 3/8 in NPT Raccord de Décharge, 3/8 in NPT Abflußabdichtung, 3/8 in NPT	1
20	CP-32097	O-Ring Kit Includes: *5, *6, *8, *9, *10, *13, *14 & *17 Conjunto de O-Anillo Trousse de O-Anneau O-Ring-Satz	1

## **BURNER (Beckett 12V) COMPONENT LOCATOR & PARTS LIST**




Ref.No.	Part No.	Qty.	Description		
1	29601A	1	Air Shutter		
2	29602A	1	Air Band		
3	29603A	1	Escutcheon Plate		
4	29604A	1	Gasket, Square Plate		
5	29605A	1	Air Tube Flange Assembly		
6	193871	1	Flange Gasket		
7	45027A	1	Motor		
8	962139	1	Mounting Screws 1/4" - 20NC x 5/8		
9	29606A	1	Blower Wheel (R.W.B. only)		
10	29609A	1	Coupling		
11	197216	1	Fuel Unit		
12	962219	4	Mounting Screws 1/4" - 20 NC x 7/8"		
13	193107	1	Pump Nozzle Port Fitting		
14	29612A	1	Connector Tube Assembly		
15	48415A**	1	Ignition Transformer Assembly with Interrupted Ignition		
16	29641A	1	Nozzle Line Electrode Asm.		
17	47000A	1	Oil Valve		
18	51454A	1	Brushes, Replaceable Motor		
19	962626	2	Mounting Screws 10 - 24NC x 5/16		
20	NI	1	Transformer Gasket		

## EQUALIZER 4300 / 3200 ELECTRICAL SCHEMATIC (12VDC)




## **GUNVALVE AND HOSE ASSEMBLY COMPONENT LOCATOR**



## GUNVALVE AND HOSE ASSEMBLY COMPONENT LOCATOR PARTS LIST

Ref. No.	Qty.	Part No.	Description
1	1	QC-251-22	O-Ring / O-Anillo
2	1	QC-250-51	Female Socket, ¼ / Ancla Hembra, ¼
3	1	GE-600-36	Extension Tube, 3 ft / Tubo de Extensión, 3 ft
4	1	GC-590-40	Spray Gun / Pistola Aerografica
5	2	QC-381-22	O-Ring / O-Anillo
6	1	192278	Quick Coupling Socket, 3/8 / Manguito de Acomplamiento Rápido, 3/8
7	1	DH-477-50	Hose, 3/8 x 50 ft, 3000 PSI / Tubo Flexible, 3/8 x 50 ft, 3000 psi
8	1	QC-380-43	Female Plug, 3/8 / Tapón Hembra, 3/8
9	1	192276	Male Socket, 3/8 / Ancla Macho, 3/8
10	1	DH-166-50	Hose, 3/8 x 50 ft, 4000 PSI / Tubo Flexible, 3/8 x 50 ft, 4000 psi
11	1	197055	Male Plug, 3/8 / Tapón Macho, 3/8
12	1	DH-499-50HP	Hose Assembly / Ensamblaje de Tubo Flexible

## **GC 590-40 GUNVALVE COMPONENT LOCATOR**



## GC 590-40 GUNVALVE COMPONENT LOCATOR PARTS LIST

Ref. No.	Qty.	Part No.	Description
1	1	GC-765-14	Housing (Right) / Carcasa (Derecho)
2	1	8001660	Housing (Left) / Carcasa (Izquierdo)
3	1	GC-765-75	Trigger / Gatillo
4	1	GC-764-44	Pin / Pasador
5	1	8002258	Valve Body / Cuerpo de la Valvula
6*	1	GC-765-22	Trigger Cam / Leva de Gatillo
8*	1	GC-764-20	O-Ring / Empaque-O
9*	1	GC-764-18	Control Bolt / Tornillo de Control
10	1	8001661	Trigger Lock / Cerrojo del Gatillo
11	1	GC-764-41	Cap / Funda - Tapa
12*	1	GC-764-38	Valve Spring / Muelle de Válvula
13*	1	GC-764-36	Valve Ball / Válvula de Bola
14*	1	GC-764-32	Valve Seat / Asiento de la Válvula
15*	2	GC-764-30	O-Ring / Empaque-O
16	7	GC-765-16	Self-Tapping Screw / Tornillo de Rosca Cortante
17*	1	GC-765-30	Spring / Muelle
18	1	GC-765-53	Discharge Tube Assembly / Ensamblaje de Tubo de Descarga
19*		8000650	Inlet Tube / Tubo de Entrada
20*	1	8000168	Inlet Fitting / Conexión de Admisión
21	1	GC-764-50	Pin / Pasador
22	1	GC-765-54	Inlet Tube Assembly Includes: *19 & *20
			Ensamblage de Tubo de Entrada
23	1	RK-775-75	Gunvalve Repair Kit Includes: *6, *8, *9, *12 - *15 & *17
			Conjunto de Reparacion de Pistola Aerografica



1111 E. Lake Francis Dr. • Siloam Springs, AR 72761 • 1-800-BUY-DELCO