

COMPLETE MANUAL



Model	Chameleon CTM-15X Modem
Revision	Firmware 1.3.0 Revision D

3066 Beta Avenue Burnaby, B.C. V5G 4K4
Phone: 604.294.4465
Fax: 604.294.4471
support@cypress.bc.ca

Revision Control

Description	Revision	Date
New 1.3.0 title, modified message 98, added agpspde, gpsdata, gpsinput , gpsparam commands, Modem Operation revisions, revised swipereport, added swipemode, revised pendantreport , mode, ppp, tenetport, telnetpswd, and confupgrade commands; ULCP report messages, updated landhcp, removed landns	A	15-Jan-2010
Report Messages 16, 82, 119-122, 255; added freeconsole command and updated pad and modbusgw commands, Message Type 30, added wpanpensrv, rpanicreport, panicreportack, and reportscripts command. Added gpstime, networktime, ntpserver, ntpstime and timesync commands	B	01-Apr-2010
Revised ppp command, added modemmode, modemmodedhcp, and clientmac, added padclientport and revised padmode; added repfiledelivery, repfilename, repfilezip and sshkey commands, updated cmd apply and associated command reference pages, updated Operating Your Modem section	C	30-Aug-2010
Added usepeerdns command, edited repfilezip command, edited Message Type 30, added power cycle to obdsp command, added nmeamode command, revised gpsrmc command, revised report messages 16 and 82, added wlanenable command, revices agpspde and modemmode commands, revised mip command, removed ctmsts, added padpfc, revised padfwdc, edited modbusadd, added gpspos	D	17-Mar-2011
Removed wlanenable command, edited gpsrep, iorep and reptype commands, removed factory command, added dnscheck command, updated Message Type 3	D	25-Oct-2011

Table of Contents

Revision Control	2
Table of Contents	3
1 Notice	8
1.1 Safety & hazards	8
1.2 Regulatory restrictions	8
1.3 Electromagnetic Interference (EMI) – United States FCC Information	8
1.4 Electromagnetic Interference (EMI) – Canada Information	9
1.5 Trademarks	9
2 Activating Your Modem	9
2.1 Gather Account Information	9
2.1.1 CDMA/EV-DO devices	9
2.1.2 GSM/GPRS/HSPA devices	10
2.2 Embedded Web Page Activation	10
2.2.1 Automatic Activation via Modem Embedded Web Browser	10
2.2.2 Manual Activation via Modem Embedded Web Browser	11
2.3 Command Line Activation	11
2.3.1 Automatic Activation (OTASP)	11
2.3.2 Manual Activation	12
3 Installing Your Modem	12
1. Mounting	12
3.1 Connecting the Power Cable	14
3.2 Connecting the Ethernet Cable	14
3.3 Mounting and Attaching the Cell Antenna	14
3.4 Mounting and Attaching the GPS Antenna	15
3.5 Serial Data Cable Connection	15
3.6 Connecting to the I/O Port	15
3.6.1 Output Connection	16
3.6.2 Input Connection	16
4 Operating Your Modem	17
4.1 Automatic Power Control	17
4.2 Power Consumption	18

4.3	Device Reset	18
4.4	LED Indicators	19
4.5	Making a Wireless Network Connection	20
4.6	GPS Operation	20
5	Connecting to a CTM-15X Modem Locally	21
5.1	Ethernet.....	21
5.2	Telnet.....	21
5.3	Browser.....	23
5.4	Serial	23
6	Connecting to a CTM-15X Modem Remotely	24
7	List of Commands	26
7.1.1	A.....	26
7.1.2	B.....	26
7.1.3	C.....	26
7.1.4	D.....	26
7.1.5	E.....	26
7.1.6	F.....	27
7.1.7	G.....	27
7.1.8	I.....	27
7.1.9	L.....	28
7.1.10	M.....	28
7.1.11	N.....	28
7.1.12	O.....	28
7.1.13	P.....	29
7.1.14	R.....	29
7.1.15	S.....	30
7.1.16	T.....	30
7.1.17	U.....	31
7.1.18	V.....	31
7.1.19	W.....	31
8	Command Reference	32
8.1.1	“A” Commands.....	32
8.1.2	“B” Commands.....	34
8.1.3	“C” Commands.....	35

8.1.4	“D” Commands.....	39
8.1.5	“E” Commands	46
8.1.6	“F” Commands.....	48
8.1.7	“G” Commands.....	51
8.1.8	“I” Commands	64
8.1.9	“L” Commands.....	72
8.1.10	“M” Commands.....	75
8.1.11	“N” Commands.....	86
8.1.12	“O” Commands.....	89
8.1.13	“P” Commands	95
8.1.14	“R” Commands	115
8.1.15	“S” Commands.....	128
8.1.16	“T” Commands	140
8.1.17	“U” Commands.....	142
8.1.18	“V” Commands.....	145
8.1.19	“W” Commands.....	148
9	Report Messages	151
9.1	Message Type 03, PMID	152
9.2	Message Type 16, \$GPGLL.....	153
9.3	Message Type 20, PIND	154
9.4	Message Type 21 to 26, PINA	154
9.5	Message Type 30, PCTM.....	155
9.6	Message Type 31, PDATA	156
9.7	Message Type 40, ID=.....	156
9.8	Message Type 80, \$GPGGA	157
9.9	Message Type 82, GPRMC.....	157
9.10	Message Type 84, \$GPGSA.....	158
9.11	Message Type 85, ULCP binary position message with GPS coordinates	159
9.12	Message Type 88, ULCP message with Acceleration/Deceleration and GPS information	159
9.13	Message Type 89, ULCP binary format, Modem ID/Firmware, Revision/Odometer value	160
9.14	Message Type 90, ULCP binary format, Odometer value	160
9.15	Message Type 92, ULCP binary format, Wireless Link TX/RX Data Count with Modem ID.....	161
9.16	Message Type 98, ULCP binary format, Digital Inputs plus GPS data	161
9.17	Message Type 100, Trimble proprietary TAIP PV message	162

9.18	Message Type 101, Trimble Proprietary LN message	163
9.19	Message Type 112, ULCP binary format, Digital input and Output states, Modem ID and GPS data	163
9.20	Message Type 114, \$PGPS.....	164
9.21	Message Type 115, \$PKML.....	165
9.22	Message Type 116, \$PPWR	166
9.23	Message Type 117, \$PRFI	166
9.24	Message Type 117, \$PRFI	166
9.25	Message Type 118, \$GPGSV	167
9.26	Message Type 119, \$POBDA.....	168
9.27	Message Type 120, \$POBDB.....	168
9.28	Message Type 121, \$POBDC.....	168
9.29	Message Type 122, \$POBDD	169
9.30	Message Type 136, \$PACCEL.....	169
9.31	Message Type 137, \$PODO	170
9.32	Message Type 255, ULCP binary format, Custom Message	170
10	Email Message Format	171
11	MODBUS Messages	172
11.1	Read Digital Outputs.....	172
11.2	Set Digital Output	173
11.3	Read Digital Inputs.....	173
11.4	Read Analog Inputs.....	174
11.5	Error response	175
11.6	MODBUS TCP Messages	175
12	ULCP Remote Configuration Messages	176
12.1	ULCP Message Format.....	177
12.2	ULCP Remote Configuration Messages	177
12.2.1	Set Digital Outputs.....	177
12.2.2	Execute Application-Specific Script	178
12.2.3	NMEA GGA Query.....	178
12.2.4	NMEA RMC Query	178
12.2.5	ULCP Binary Position Query.....	179
12.2.6	Wireless Link Data Count Query.....	179
12.2.7	Time Based Reporting.....	179

12.2.8	Delta Position Based Reporting	180
12.2.9	Download Script Files	181
12.2.10	Trigger Reports	182
12.3	Examples.....	183
13	Technical Specifications.....	184
13.1	FCC/IC Approvals	184
13.2	Temperature.....	184
13.3	Humidity	184
13.4	Vibration	184
13.5	Shock.....	185
13.6	Sealing.....	185
13.7	Material	185
13.8	Power Supply	185
13.9	Host Connectivity	185
13.10	I/O.....	185
13.11	RF.....	186
13.11.1	CDMA/EV-DO.....	186
13.11.2	GSM/GPRS/HSPA.....	186
13.12	GPS.....	186
13.13	Physical.....	186
14	Technical Support.....	187

I Notice

Due to the nature of wireless communication the reception or transmission of data can never be guaranteed. Data may be delayed, corrupted or never received. Data transfer problems are rare with well-constructed and configured wireless networks used in conjunction with devices such as the CTM-15X wireless data device. Cypress Solutions Inc. accepts no responsibility for damages of any kind including but not limited to personal injury, death, or loss of property due to the delay or loss of data resulting from the use of the CTM-15X wireless data device.

I.1 Safety & hazards

Wireless transmitters can cause interference with some critical operation equipment. For this reason it is required that the RF portion of the CTM-15X Series wireless data device be turned off when in the vicinity of blasting operations, medical equipment, life support equipment, or any other equipment that is susceptible to radio interference. The CTM-15X series wireless data device must be turned off when on-board or in the vicinity of any aircraft. The FAA prohibits the use of wireless transmitter equipment at any time during aircraft flight.

I.2 Regulatory restrictions

CAUTION: Any modifications to the CTM-15X series wireless data device not expressly authorized by Cypress Solutions Inc. may cause its regulatory approval status to become invalidated, thereby voiding your authority to use the product.

The CTM-15X series wireless data device contains a wireless device approved under FCC CFR 47 part 2.1091 and Industry Canada RSS-102 rules for operation as a mobile or fixed device with its specified antenna of gain $\leq 6\text{dBi}$ and from which a separation distance of at least 20cm (8") must be maintained from all persons at all times and during all modes of operation. The antenna used must not be co-located or operated in conjunction with any other antenna or transmitter. These rules are in place to prevent any possible hazard due to personal exposure to electromagnetic radiation.

The CTM-15X series devices are designed to operate with approved wireless cards installed. These cards will have their own FCC and Industry Canada approval ID numbers. Contact Cypress Solutions for a complete updated list of supported Wireless cards/modules.

I.3 Electromagnetic Interference (EMI) – United States FCC Information

This equipment has been tested and found to comply with limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful

interference to radio communication. However, there is no guarantee that harmful interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient or relocate the receiving antenna
- increase the separation between the equipment and receiver
- connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- consult the dealer or an experienced radio/TV technician for help

1.4 Electromagnetic Interference (EMI) – Canada Information

This digital apparatus does not exceed the class A limits for radio noise emissions from digital apparatus as set out in the interference causing equipment standard entitled “Digital Apparatus”, ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: “Appareils Numériques”, NMB-003 édictée par le Ministre des Communications.

1.5 Trademarks

All brand or product names, trademarks, logos, etc. used in this manual are owned by their respective companies.

2 Activating Your Modem

2.1 Gather Account Information

2.1.1 CDMA/EV-DO devices

For Sierra Wireless AC595/AC597/AC598/AC580 CDMA/EV-DO devices, the following information is typically required:

- Phone number (10-digit MDN)
- Lock code (6-digit CSL)
- User name (number@... format)
- Password
- Dial number (usually #777)

For all other manufacturer data devices and cards, network activation of the device must be done in a laptop prior to installing in the modem.

2.1.2 GSM/GPRS/HSPA devices

For GSM/GPRS/HSPA devices, the following information is required:

- An activated SIM card needs to be installed in the Modem or data card
- cmd factory gsm must be entered

Note: TRU-install™ must be disabled on devices that support the TRU-install™ feature prior to installation into the modem, or activation will not be successful

2.2 Embedded Web Page Activation

Note: Activation via the modem Embedded web browser is supported only on Sierra Wireless AC595, AC597 Express Card, AC597/8 USB and AC580 data devices with the TRU-install™ feature disabled. For all other devices, activate the device using a laptop

2.2.1 Automatic Activation via Modem Embedded Web Browser

On the **OTASP (Over-The-Air Service Provisioning)** page, click Initiate to start the OTASP processing, depending on the programming data on the modem card, one or more of the following messages will be displayed on the OTASP page's status window:

- SPL Unlocked
- Authentication key has been updated
- Shared secrets data has been exchanged
- New NAM parameters have been downloaded
- New MDM has been downloaded
- IMSI has been downloaded
- PRL has been downloaded

During updating, if any of the above data is unsuccessful, the "OTASP Timeout" message and the "OTASP Disconnected" message will be displayed. To retry the OTASP process, click Initiate to re-start. When the OTASP process is complete and the provisioning parameters have been committed the "OTASP Disconnected" message will be displayed.

Click Initiate and cycle the power on the modem.

2.2.2 Manual Activation via Modem Embedded Web Browser

On the Activate page, enter the Lock code (CSL), the Phone number (MDN), and the Mobile Identification Number (MIN).

CSL, **MDN** and **MIN** are all required to successfully activate the data device.

The MIN entry is provided to add support for the Wireless Number Portability (WNP).

If you were provided with a MIN from your service provider then enter the 10-digit number in the MIN field and enter the Lock code (CSL).

If you were not provided with a MIN then copy the 10-digit number for the MDN in the MIN field and enter the Lock code (CSL).

Click Submit and cycle the power on the modem.

2.3 Command Line Activation

Note 1: Command line activation can be via a local telnet session or console session via the modem serial interface

Note 2: Activation via the command line interface is supported only on Sierra Wireless AC595, AC597 Express Card, AC597/8 USB and AC580 data devices with the TRU-install™ feature disabled. For all other devices, activate the device using a laptop

There are two methods, **OTASP** is a single command entry and the simplest, if **OTASP** does not work follow the **Manual Activation** instructions.

2.3.1 Automatic Activation (OTASP)

At # prompt, type the command:

cmd otasp and press Enter.

This command is used to perform automatic wireless network activation and updates any required network related files that are embedded in the wireless modem. The modem responds with one or more of the following messages:

- SPL Unlocked
- Authentication key has been exchanged
- Shared secrets data has been updated
- New NAM parameters have been downloaded
- New MDM has been downloaded

- IMSI has been downloaded
- PRL has been downloaded

During updating, if any of the data is unsuccessful, the "OTASP Timeout" message and "OTASP Disconnected" message will be displayed. A progress message reading "OTASP Processing" will be displayed every 10 seconds. When the OTASP process has successfully completed and the provisioning parameters have been committed, a message "OTASP Disconnected" message will be displayed.

2.3.2 Manual Activation

At # prompt, type the following commands:

```
cmd spc pppppp where pppppp is the 6 digit lock code
cmd dir nnnnnnnnnn where nnnnnnnnnn is the 10 digit MDN phone number
cmd pwrmode 2 power cycle the modem
```

The MIN entry is provided to add support for Wireless Number Portability (WNP) and also needs to be set on the modem by entering the following commands:


If no MIN is provided use the MDN number provided.

```
cmd spc pppppp where pppppp is the 6 digit lock code
cmd dir + nnnnnnnnnn where nnnnnnnnnn is the 10 digit MIN number
cmd pwrmode 2 power cycle the modem
```

3 Installing Your Modem

I. Mounting

The CTM-15x is provided with a flexible mounting bracket that has eight 5mm mounting holes suitable for #10 screws. These may be used to screw or bolt the device to a suitable surface – take care not to over-tighten these screws and damage the bracket. Once this has been installed in the required location the modem clips into the 4 tabs of the bracket. The bracket can be used as drill guide template. There are a total of 8 mounting holes, (2, 4 hole patterns, 2 x 5.5 and 1.75 x 3.75)



The modem can be installed in any orientation, but it is suggested that the modem not be mounted with the interconnect face directed upwards as this can allow liquids to enter the modem.

The modem should be mounted in an area where it is free from excessive dust and liquids.

3.1 Connecting the Power Cable


The power cable has three wires:

Red +V supply (+9 to +36VDC)

Black 0V return

White Standby (+V for operation, Off for standby)

A 5 Amp “slow-blow” fuse is recommended in the +V supply line.



The operate/standby switch may, for example, be the accessory position on a vehicle ignition switch. In order to minimize the acquisition time of the GPS module in the CTM-15x at power on, it is recommended to keep the +V supply connected – this will provide the “keep-alive” power required by the GPS module to maintain its internal almanac.

3.2 Connecting the Ethernet Cable

Plug one end of a standard Ethernet patch cable into the CTM-15x Ethernet port, and the other end into the LAN device, PC or Ethernet peripheral. The Ethernet port is compatible with 10Base-T or 100Base-T connection types.

3.3 Mounting and Attaching the Cell Antenna

The antenna used with the CTM-15x must be a type suitable for operation on the network for which the modem is activated. For CDMA/EV-DO/GPRS/HSPA networks this is typically a dual band 800 Mhz and 1900 Mhz antenna.

For optimum performance the antenna should be mounted in a vertical orientation as high up as possible and with clear line of sight in all directions. For regulatory purposes it must be mounted in such a position as to maintain a separation distance from any person of at least 20cm (8”).

The modem antenna connector is a standard SMA female type that requires the antenna cable to use a male SMA connector. The CTM-15x can be provided with alternate antenna connector types – contact Cypress Solutions for details.

3.4 Mounting and Attaching the GPS Antenna

The GPS antenna used with the CTM-15x (with GPS) must be an active type with gain of at least 26dB and compatible with a 3.3 volt dc supply provided directly by the modem over the coax cable. The antenna installation should typically be on an upper horizontal surface of a vehicle with a clear 360 degree view of the sky.

The GPS antenna connector is a standard MCX type or SMA female depending on whether the CTM-15X modem is PC-CARD based or Express card/module/USB based. The CTM-15x can be provided with alternate antenna connector types – contact Cypress Solutions for details.

3.5 Serial Data Cable Connection

The serial data port is a standard DB9 female connector configured as Data Communication Equipment (DCE) and is wired as per the table below.

DB9 Pin	Signal	Name	Direction
1	DCD	Data Carrier Detect	CTM-15x to PC
2	RxD	Received Data (by DTE)	CTM-15x to PC
3	TxD	Transmitted Data (by DTE)	PC to CTM-15x
4	DTR	Data Terminal Ready	PC to CTM-15x
5	GND	Signal Ground	
6	DSR	Data Set Ready	CTM-15x to PC
7	RTS	Request To Send	PC to CTM-15x
8	CTS	Clear To Send	CTM-15x to PC
9	RI	Ring Indicator	CTM-15x to PC

Serial data ports on most computer equipment are configured as Data Terminal Equipment (DTE) with a DB9 male connector. A standard serial data cable will allow for direct connection of the CTM-15x to most computer and terminal equipment. In some cases it may be necessary to insert a “null modem” or “gender changer” in the serial data line in order to correctly connect between the devices.

3.6 Connecting to the I/O Port

The I/O port provides for the control of 4 external devices and for monitoring 6 external sensors. Connections are made via the 12 position connector.


OUT1	OUT3	OUT GND	IN1	IN3	IN5
1	3	5	7	9	11
2	4	6	8	10	12
OUT2	OUT4	GND	IN2	IN4	IN6

3.6.1 Output Connection

The 4 outputs are configured as “open drain” which means that they can be directly connected to energize external relays, lamps or other DC devices.

Maximum supply voltage is 36 volts, with a maximum load current of 500mA.

Recommended wire gauge for use with the connector is 16AWG. Note that the OUT GND connection is referenced to the modem’s supply ground.




3.6.2 Input Connection


The 6 inputs may be configured in the modem for monitoring a digital DC voltage state or an analog DC voltage.

For digital state monitoring the minimum input voltage is 0 volts while the maximum is 36 volts.

The threshold detection voltage is 2.5 volts with 1 volt of hysteresis. Note that the IN GND connection is referenced to the modem’s supply ground.



For analog voltage monitoring the measurement range is 0 to +10 volts with 10mV resolution. The input can withstand up to 36 volts. Note that the IN GND connection is referenced to the modem’s supply ground.



4 Operating Your Modem

4.1 Automatic Power Control

The supply voltage must be a minimum of 9VDC for the CTM-15X to operate. With the power applied it will power-up in its operating mode.

Note: In some vehicle operation, when starting the engine the vehicle supply voltage will dip below 9VDC momentarily. This will cause the modem to reset as the power dips below 9VDC. If continual operation is required, contact Cypress Solutions for an accessory power regulator that plugs in-line with the modem power supply. This power regulator will prevent unnecessary resets.

The CTM-15X Chameleon device has two power modes:

Mode	Description	Mode change event
Operation	In this mode the device is fully powered up and ready to receive or make network connections	The device will go back into shutdown mode when the ignition/standby signal is deactivated or upon expiry of the power ON timer as configured.
Shutdown	Only the modem's power management circuits are operating.	The device will go back into operation mode when the ignition/standby signal is activated, an input event occurs, or upon expiry of the power OFF timer as configured.

The CTM-15X can be configured to remain on for a defined period after the standby/ignition signal has been turned off. This enables the modem to continue sending position reports or be used for data operations even after the vehicle ignition has been switched off – e.g. for short duration driver breaks.

When in its power shutdown mode the modem may be configured to resume full operation by either the standby/ignition signal becoming active, an input event occurring, or the power OFF timer expiring.

4.2 Power Consumption

The power consumption of the CTM-15X modem will depend on its supply voltage, its current operating function and its RF environment.

The following table is provided to assist application integrators in defining the power requirements for their specific application.

Power Consumption	Weak RF signal(12V)	Strong RF signal(12V)	Weak RF signal(24V)	Strong RF signal(24V)
Shutdown Mode	1.5mA typical	1.5mA typical	2.0mA typical	2.0mA typical
Downloading (Receive data)	450mA max	350mA max	220mA max	195mA max
Uploading (Transmit data)	500mA max	390mA max	260mA max	210mA max

4.3 Device Reset

The CTM-15X modem may be manually reset via the front panel using a <1mm diameter (0.04”) wire tool (a standard paper clip). This can be used to cause the modem to reset its operation, or to enter its standby power mode.

Reset: Press and hold for 0.25 to 1 second

Shutdown: Press and hold for 2 to 5 seconds (the PWR LED will go off at the 2-second mark). Press again for more than 0.25 second to return to operating mode.



4.4 LED Indicators

There are five LED indicators on the CTM-15X top. These are used to show the status and operation of the device.

For Sierra Wireless HSPA, Sierra Wireless CDMA/EV-DO, and Kyocera Wireless CDMA/EV-DO data devices or modules:

LED	Description	Solid	Blinking	Off
PWR	Power status of the device	full operating mode and able to connect	device is in shutdown mode	the device has no power
CELL	status of the device on the wireless network	receiving a signal greater than or equal to -95dBm	receiving a signal less than -95dBm	device is not detecting a valid RF signal
TX/RX	data is being transmitted or received	N/A	Data is being transmitted or received	no data is being transmitted or received
GPS	status of the GPS module or external GPS device (only firmware version R1.3.0 or above)	GPS module or external GPS device (only firmware version R1.3.0 or above) has obtained a valid position fix	GPS module or external GPS device (only firmware version R1.3.0 or above) does not have a valid position fix	
3G	indicates the type of wireless data connection	EV-DO Rev A (typical downlink 450 to 800kbps)	EV-DO Rev 0 (typical downlink 400 to 700 kbps)	1xRTT (typical downlink 40 to 100 kbps)

For Novatel Wireless, Option or other Manufacturer devices:

LED	Description	Solid	Blinking	Off
PWR	Power status of the device	full operating mode and able to connect	device is in shutdown mode	the device has no power
CELL	status of the device on the wireless network	device is connected to the wireless network	N/A	device is not connected to the wireless network
TX/RX	data is being transmitted or received	N/A	Data is being transmitted or received	no data is being transmitted or received
GPS	status of the GPS module or external GPS device (only firmware version R1.3.0 or above)	GPS module or external GPS device (only firmware version R1.3.0 or above) has obtained a valid position fix	GPS module or external GPS device (only firmware version R1.3.0 or above) does not have a valid position fix	
3G	indicates the type of wireless data connection	N/A	N/A	N/A)

4.5 Making a Wireless Network Connection

The CTM-15X will attempt to connect to the wireless network whenever power is applied, when configured with `cmd mode 2` (default)

If no wireless network connection is available the IP address will be given as 0.0.0.0. This can be queried using `cmd ipadr` For Sierra Wireless RF devices, wireless signal strength information can be queried using `cmd rssi`. These values for both 1x and EV-DO are given in dBm with range typically -60dBm (very good) to -105dBm (weak).

With the wireless network connection active you may now open Windows® applications that will make use of this connection – this includes email, web browsers, and VPN connections.

4.6 GPS Operation

The GPS module in the CTM-15X will continuously track the unit's position whenever power is applied and the GPS antenna has a clear view of the sky. The time taken for the module to achieve a valid positional fix is determined by the previous state of the unit:

For a “cold” start (after all power is applied to the modem) the acquisition time typically will be less than 50 seconds.

For a “warm” start (standby power is maintained to the CTM-15x) the acquisition time will typically be less than 38 seconds.

For reacquisition (after the GPS module has temporarily lost signal) the time to acquire a valid position fix is typically less than 2 seconds.

The GPS information can be sent by the device as a message in any of the configured reports.

The GPS receiver uses the WGS-84 datum.

The CTM-15X (running firmware version R1.3.0 or above only) supports GPS data from a external GPS device connected to the modem via USB or serial port, or from a wireless module via A-GPS (Sierra Wireless devices only). When the CTM-15x has been configured to use an external GPS or an A-GPS device, the GPS LED will reflect the current status of the selected GPS device.

5 Connecting to a CTM-15X Modem Locally

The CTM-15X modem has 2 interface ports available for configuration:

- Ethernet
- Serial

5.1 Ethernet

The ethernet port supports a **telnet** session and an internet browser session.

Note: If your PC or Laptop is part of an existing network, you may have to disable/reconfigure your existing network settings.


5.2 Telnet

With the device powered up and connected directly to a PC with an Ethernet cable, access the command prompt:

Start/All Programs/Accessories/Command Prompt

Enter the command:


telnet 192.168.1.1 (this is the local IP address of the CTM-15x)



```
C:\ Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\fli>telnet 192.168.1.1
```

The CTM-15x will respond with its login prompt:




```
C:\ Telnet 192.168.1.1

Chameleon login:
```

At the login prompt, type in **admin** (default user name). At the password prompt type in **Chameleon** (default password, case sensitive).

A # prompt will be displayed indicating you now have access to the device command line interface:



```
C:\ Telnet 192.168.1.1

Chameleon login: admin
Password:
Cypress Solutions Inc.
CTM15x
http://www.cypress.bc.ca

#
```

5.3 Browser

Open an internet browser and enter the address:

<http://192.168.1.1>

The browser will redirect to a web page requiring a username and password.

At the login prompt, type in **admin** (default user name). At the password prompt type in **Chameleon** (default password, case sensitive).

After successful login you will have access to a web browser based configuration.

Notes:

- Not all device functionality is supported by the web browser interface. To access all device commands please use the command line interface.
- The embedded web server can only be used with a single client session at any time.
- Only 1 I/O input signal can be set from the embedded web page.
- Both GPS and IO report web pages are limited and cannot set all conditions, including minimum time between reports.

5.4 Serial


With the device powered up and connected directly to a PC or Laptop with a serial cable, start up a terminal emulation program such as Windows [HyperTerminal](#) or similar application.

Configure the terminal emulation program with the following parameters:

- Data rate: 115,200 baud
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: None

Note: The above settings are the device default settings; they can be configured using the cmd port command.

Press the Enter key to return the # prompt:



6 Connecting to a CTM-15X Modem Remotely

Please note:

- It is highly recommended to test all device configuration and operation before deploying devices to remote locations.
- Not all wireless networks offer "public" IP addresses that are remotely accessible, some are firewall protected to allow access from either the same IP pool only or restricted IP addresses. Contact your wireless network provider or administrator to determine what options are available.
- Some networks will force device IP addresses to change at regular intervals. Without proper configuration, this could cause a remote device to become inaccessible if the device IP address is not known. The CTM-15X can be configured to send a message when its IP address changes using this command: **cmd iocond**
- Embedded wireless radio modules must be activated before deploying to remote locations
- Incorrectly configuring the device could cause the device to become inaccessible, take care when issuing commands via a remote session.

There are 4 ways to configure a CTM-15X remotely:

- **Telnet** (most flexible, allows access to the complete repository of remote commands)
- **Device Embedded Web Page** (provides access to a limited sub-set of device commands, used typically for quick configuration of basic commands)
- **SMS** (Allows commands to be sent to the modem via SMS, this command only applies to devices with embedded Sierra Wireless CDMA/EV-DO revision A cards, USB modems or modules)
- **ULCP** (Allows configuration of digital outputs only using ULCP binary format)
- For telnet to work with a remote device cmd [rmttelnet 1](#) must be set.
For access to the Device embedded web page, cmd [rmtweb 1](#) must be set.

Telnet and Device Embedded Web Page Configuration

Follow the directions for **telnet** configuration listed in [How To Connect to a CTM-15X Modem - Locally](#) and substitute 192.168.1.1 with the known IP address of the remote device.

SMS configuration

No configuration of the CTM-15X is required for the modem to accept SMS commands.

The commands via SMS feature is supported **only** on CTM15x modems installed with Sierra Wireless cards and running firmware release R1.2.0. This feature is built into the firmware and no additional modem configuration is required to enable commands via SMS.

CTM-15X commands may be issued via a SMS text message sent from a mobile phone or from a cell phone carrier's web site for execution on the CTM15x modem upon receiving the SMS message. One or more commands may be included in the body of a SMS text message up to a maximum message size of 166 characters. The destination of such a SMS message is the phone number of the modem, which may be obtained by entering **cmd dir** from a Telnet or serial port console session.

Message format for CTM15x commands via SMS:

NNNN:<command> <parameters> ... NNNN:<command> <parameters> ... (up to 166 characters)

Where:

NNNN is the last 4 digits of the modem's ESN

<command> is the command to be executed. **cmd** should not be included in <command> and commands do not have to be separated by a linefeed (<CR><LF>)

<parameters> are the parameters for each command

Example: If the last 4 digits of the modem's ESN are 1234

Two commands separated by a space in SMS message

1234:gpsremip 2 123.456.78.900 1234:save

Three commands separated by <CR><LF> for each line of the SMS message:

1234:gpsremip 2 123.456.78.900

1234:gpsremport 2 15000

1234:save

ULCP configuration

ULCP configuration is performed by sending properly formatted binary messages to port **6100** of the remotely connected device.

See [ULCP Remote Configuration Messages](#) for message format.

7 List of Commands

7.1.1 A

[agpspde](#) (configure Assisted GPS (A-GPS) using cellular device location based features) (see pg. 32)

[apn](#) (set carrier access-point name) (see pg. 33)

[apply](#) (apply network / firewall and other system configuration changes) (see pg. 33)

7.1.2 B

[boomreport](#) (set the boom tracker report) (see pg. 34)

7.1.3 C

[cardlistclear](#) (erase approved ID list from modem) (see pg. 35)

[cardlistload](#) (load approved ID list for swipe card interface) (see pg. 35)

[cardlistsave](#) (save approved ID list to non-volatile RAM) (see pg. 36)

[cardlockload](#) (load a swipe card lock script to the modem) (see pg. 36)

[cardunlockload](#) (load a swipe card unlock script to the modem) (see pg. 37)

[clientmac](#) (set client mac address for modem mode with DHCP) (see pg. 37)

[confupgrade](#) (configures the modem for automatic configuration capability) (see pg. 37)

[ctm15x](#) (command for configuration of protected values) (see pg. 39)

7.1.4 D

[data](#) (query count of data transmitted/received over wireless link) (see pg. 39)

[datacond](#) (wireless link total data count trigger condition) (see pg. 40)

[datareport](#) (set the link data report(s)) (see pg. 41)

[dir](#) (set NAM phone number,MDN,MIN) (see pg. 41)

[dmz](#) (demilitarized zone (DMZ) feature) (see pg. 42)

[dnscheck](#) (check valid DNS) (see pg. 43)

[dout](#) (digital outputs) (see pg. 44)

[dyndns](#) (dynamic DNS) (see pg. 45)

7.1.5 E

[emailsrv](#) (set email server) (see pg. 46)

[enghours](#) (calculate engine hours) (see pg. 46)

[enghrmode](#) (used to configure enghours command) (see pg. 47)

[esn](#) (electronic serial number) (see pg. 47)

[ethernet](#) (Enable/Disable Ethernet services) (see pg. 48)

7.1.6 F

[firewall](#) (Firewall – Port forwarding) (see pg. 48)

[freeconsole](#) (kill serial console prompt) (see pg. 49)

[friends](#) (set firewall friends list) (see pg. 49)

7.1.7 G

[gpsaccel](#) (GPS report trigger for hard acceleration and deceleration events) (see pg. 51)

[gpsaddmes](#) (add GPS messages to a report) (see pg. 51)

[gpscond](#) (GPS report trigger conditions) (see pg. 52)

[gpsdata](#) (display status of GPS input devices) (see pg. 54)

[gpsdelmes](#) (delete GPS message) (see pg. 54)

[gpsemail](#) (GPS email address) (see pg. 55)

[gpsgga](#) (GPS GGA message) (see pg. 55)

[gpsinput](#) (GPS input device, internal on board GPS module, external GPS device or cellular based A-GPS)
(see pg. 56)

[gpslocport](#) (GPS local port) (see pg. 56)

[gpsmes](#) (GPS messages) (see pg. 57)

[gpsparam](#) (GPS port configuration and priority) (see pg. 57)

[gpspos](#) (GPS port configuration and priority) (see pg. 57)

[gpsremip](#) (set fixed GPS position) (see pg. 58)

[gpsremport](#) (GPS remote port) (see pg. 60)

[gpsrep](#) (GPS reporting) (see pg. 60)

[gpsrmc](#) (GPS RMC message) (see pg. 62)

[gpssms](#) (set destination of GPS SMS report) (see pg. 62)

[gpstime](#) (set priority of valid GPS as system time synchronization source) (see pg. 63)

7.1.8 I

[igncond](#) (ignition report trigger conditions) (see pg. 64)

[ignreport](#) (set ignition trigger report) (see pg. 64)

[input](#) (query input channels status) (see pg. 65)

[insetup](#) (input setup) (see pg. 65)

[ioaddmes](#) (add IO message) (see pg. 67)

[iocond](#) (IO report trigger conditions) (see pg. 67)

[iodelmes](#) (delete IO message) (see pg. 68)

[ioemail](#) (IO email address) (see pg. 68)

[iolocport](#) (IO local port) (see pg. 69)

[iomes](#) (IO messages) (see pg. 69)

[ioemip](#) (IO remote IP address) (see pg. 69)

[ioemport](#) (IO remote port) (see pg. 70)

[iorep](#) (IO reporting) (see pg. 70)

[iosms](#) (set destination of IO SMS report) (see pg. 71)

[ipadr](#) (IP address) (see pg. 72)

7.1.9 L

- [landhcp](#) (LAN DHCP server settings) (see pg. 72)
- [lanip](#) (IP address of modem on LAN) (see pg. 73)
- [lannetmask](#) (Netmask of modem on LAN) (see pg. 74)
- [lanrepip](#) (LAN IP address for local reporting) (see pg. 75)

7.1.10 M

- [mip](#) (mobile IP) (see pg. 75)
- [modbusadd](#) (add MODBUS TCP slave, serial slave or self slave, query MODBUS slave gateway list) (pg. 76)
- [modbusctm130](#) (enable backward compatibility with CTM13x MODBUS messages over-the-air) (pg. 79)
- [modbusdel](#) (delete MODBUS entry) (see pg. 79)
- [modbusgw](#) (manual MODBUS gateway initiation) (see pg. 80)
- [modbusidmap](#) (set up MODBUS ID to modem IP:port map) (see pg. 80)
- [modbusmode](#) (sets the MODBUS gateway mode) (see pg. 81)
- [modbusport](#) (sets the MODBUS port number) (see pg. 82)
- [mode](#) (sets connection mode) (see pg. 83)
- [modemdevice](#) (configure modem device port) (see pg. 84)
- [modemid](#) (assign modem ID) (see pg. 84)
- [modemmode](#) (enable Modem Mode or Half Bridge mode) (see pg. 84)
- [modemmodedhcp](#) (enable DHCP support with Modem Mode) (see pg. 86)

7.1.11 N

- [netwd](#) (network watchdog) (see pg. 86)
- [networktime](#) (set priority of cellular network time as system time synchronization source, Sierra Wireless data devices/modules only) (see pg. 87)
- [nmeamode](#) (set NMEA 0183 version for GPGLL and GPRMC sentences) (see pg. 88)
- [ntpserver](#) (set URL or IP of NTP server for system time synchronization) (see pg. 88)
- [ntptime](#) (set priority of NTP client as system time synchronization source) (see pg. 89)

7.1.12 O

- [obdcond](#) (OBD report trigger conditions) (see pg. 89)
- [obddata](#) (Display data obtained from OBDII transmitter) (see pg. 91)
- [obdreport](#) (Set report for OBD trigger) (see pg. 92)
- [obdsp](#) (Sets protocol used by OBDII transmitter) (see pg. 92)

[odometer](#) (GPS odometer) (see pg. 93)
[otasp](#) (Over-The-Air Service Provisioning) (see pg. 94)

7.1.13 P

[pad](#) (manual PAD initiation) (see pg. 95)
[padclientport](#) (see pg. 95)
[padecho](#) (PAD echo mode) (see pg. 95)
[padesc](#) (PAD escape sequence) (see pg. 97)
[padesc](#) (PAD escape guard time) (see pg. 97)
[padfwdc](#) (PAD forwarding character) (see pg. 98)
[padfwdl](#) (PAD forwarding length) (see pg. 99)
[padfwdt](#) (PAD forwarding time) (see pg. 100)
[padip](#) (PAD IP address) (see pg. 100)
[padmode](#) (PAD mode) (see pg. 101)
[padpfc](#) (PAD postfix character) (see pg. 102)
[padport](#) (PAD port number) (see pg. 102)
[padreset](#) (PAD reset) (see pg. 103)
[padsvct](#) (PAD server connection cut-off timer) (see pg. 104)
[panicreport](#) (set pendant panic report) (see pg. 105)
[panicreportack](#) (set modem to send pendant acknowledgment when panic report received) (see pg. 106)
[pendantreport](#) (set pendant report) (see pg. 106)
[ping](#) (pings a specific IP address) (see pg. 107)
[pobda-pobdd](#) (OBDII reports) (see pg. 108)
[port](#) (serial port settings) (see pg. 109)
[ppp](#) (Local Point to Point Protocol connection) (see pg. 109)
[pswd](#) (sets password used for wireless network access via simple IP) (see pg. 110)
[pupcond](#) (power up report trigger conditions) (see pg. 111)
[pupreport](#) (set power up report) (see pg. 111)
[pwrmode](#) (power mode) (see pg. 112)
[pwrsdwn](#) (power shutdown) (see pg. 112)
[pwrvcct](#) (supply voltage threshold) (see pg. 113)
[pwrwoe](#) (power wake on event) (see pg. 114)

7.1.14 R

[ratesel](#) (Rate select for selected data devices/modules only) (see pg. 115)
[ratetmr](#) (Rate Timer, Sierra Wireless CDMA/EVDO only ?) (see pg. 116)
[reppaddmes](#) (add messages to a report configuration, display report configuration messages) (see pg. 116)
[repedelmes](#) (delete messages from a report configuration) (see pg. 117)
[repemail](#) (configure report email address) (see pg. 118)
[repfiledelivery](#) (configure delivery parameters for file-based reporting) (see pg. 118)
[repfilename](#) (configure filename for file-based reporting) (see pg. 119)
[repfilezip](#) (configure compression of data files for file-based reporting) (see pg. 120)

[replcport](#) (configure report local port) (see pg. 120)
[reportscripts](#) (configure custom scripts to be triggered when reports are generated) (see pg. 121)
[repremip](#) (configure report remote IP address) (see pg. 122)
[reprempport](#) (configure report remote port) (see pg. 122)
[repsms](#) (configure report SMS address) (see pg. 123)
[reptype](#) (configure local and remote report types, store-and-forward) (see pg. 124)
[restore](#) (restores last saved configuration) (see pg. 125)
[rmttd](#) (reverse telnet connection) (see pg. 126)
[rmtssh](#) (remote ssh access) (see pg. 126)
[rmttelnet](#) (remote telnet) (see pg. 126)
[rmtweb](#) (Remote web access) (see pg. 127)
[rssi](#) (RF signal strength) (see pg. 128)

7.1.15 S

[saltreport](#) (set salt-spreader report) (see pg. 128)
[satbackup](#) (switch to backup satellite modem) (see pg. 129)
[save](#) (saves configuration) (see pg. 130)
[showconfig](#) (displays current configuration settings) (see pg. 130)
[showstate](#) (displays modem state) (see pg. 131)
[singlepc](#) (single pc mode) (see pg. 132)
[smssend](#) (send SMS message) (see pg. 133)
[smstext](#) (SMS text message) (see pg. 133)
[smsto](#) (send SMS to) (see pg. 133)
[smsview](#) (SMS message view) (see pg. 134)
[snfdelay](#) (Store and Forward delay period before SNF starts) (see pg. 134)
[snfflush](#) (Store and Forward Flush) (see pg. 135)
[snflog](#) (Store and Forward log) (see pg. 135)
[spc](#) (service provisioning code) (see pg. 135)
[speedth](#) (speed threshold for enabling RF module of the modem) (see pg. 136)
[sshkey](#) (generate a ssh key) (see pg. 137)
[sshport](#) (set modem ssh server port) (see pg. 137)
[sshtimeout](#) (ssh session idle timeout) (see pg. 137)
[swipemode](#) (set swipe-card interface) (see pg. 138)
[swipereport](#) (set swipe-card report) (see pg. 139)
[syslog](#) (system log) (see pg. 140)

7.1.16 T

[telnetport](#) (telnet port) (see pg. 140)
[telnetpswd](#) (password for telnet access) (see pg. 141)
[telnettimeout](#) (telnet timeout) (see pg. 141)
[timesync](#) (set period for system time synchronization) (see pg. 142)

7.1.17U

- [univwd](#) (configure universal watchdog) (see pg. 142)
- [univwdtimer](#) (set universal watchdog timer interval) (see pg. 143)
- [upgradefw](#) (upgrade firmware kernel image + root filesystem (rootfs)) (see pg. 143)
- [upgradesrv](#) (set authorized IP for remote admin) (see pg. 143)
- [usepeerdns](#) (enable/disable obtaining DNS nameserver IP addresses from carrier) (see pg. 144)
- [user](#) (sets username used for wireless network access via simple IP) (see pg. 145)

7.1.18V

- [vcc](#) (supply voltage) (see pg. 145)
- [vcccond](#) (supply voltage level report trigger conditions) (see pg. 146)
- [vccreport](#) (set supply voltage level report) (see pg. 147)
- [ver](#) (firmware version) (see pg. 147)

7.1.19W

- [wifiwd](#) (configures Wi-Fi Watchdog) (see pg. 148)
- [wpanacktype](#) (Man Down Pendant acknowledgement type) (see pg. 148)
- [wpanadddev](#) (WPAN accessory add device id, query device id) (see pg. 149)
- [wpandelall](#) (WPAN accessory delete all device ids) (see pg. 150)
- [wpandeldev](#) (WPAN accessory delete device id) (see pg. 150)
- [wpanpanid](#) (WPAN accessory set PAN id, query PAN id) (see pg. 150)
- [wpanpensrv](#) (WPAN server for remote access to Man Down Pendant devices) (see pg. 151)

8 Command Reference

Each command is entered as:

cmd <command> <parameters>

Use a space between all parameters (no commas or other characters).

Use ***cmd save*** to save modified values to non-volatile memory.

8.1.1 “A” Commands

agpspde

This command is used to configure Assisted GPS (A-GPS) parameters on supported wireless data cards/modules.

The cellular device chipset contains a GPS receiver. Position Determine Equipment (PDE) assists the cellular device to speed up satellite acquisition, the PDE sends satellite almanac and ephemeris information to the device.

Currently this feature only works on later model Sierra Wireless data devices that support A-GPS (USB598, USB597). When a later model Sierra Wireless data device is used with a modem configured in half bridge mode, A-GPS support is not available and must be disabled.

cmd agpspde ip port tm pc pl nl

where:

ip ip address for location processing (Range: 0.0.0.0 to 255.255.255.255)

port port id for location processing (Range: 0 to 65535)

tm transportation mechanism (Range: 0 to 1) **0 - TCP/IP(default)**, 1 - Data Burst

pc position calculation type, fix type (Range: 1 to 6) **1 - Standalone**, **2 - MS-based only**, **3 - MS-assisted only = A-GPS Only(default)**, **4 - Optimum speed**, **5 - Optimum accuracy**, **6 - Optimum data**

pl privacy level for location processing (Range: 0 to 2) **0 - low(default)**, 1 - medium, 2 - high

nl network access level for location processing (Range: 0 to 3) **0 - network access only**, **1 - no network access**, **2 - network access with demodulation(default)**, **3 - network access without demodulation**

Examples:

1. Set A-GPS parameters:

```
cmd agpspde 124.105.114.86 5412 0 3 0 2
```

2. Disable A-GPS feature:

```
cmd agpspde 0.0.0.0 0 0 1 0 1
```


A cmd save and a powercycle is required for this command to take effect.

[return to list of commands](#)

apn <name-of-apn>

This command configures the APN(Access Point Name) for a modem. This command is only applicable to GSM/GPRS/HSPA devices.

cmd apn will query current APN value

Examples:

1. Query current APN

```
cmd apn
cmd apn internet.com
OK
```

2. Set APN

```
cmd apn newapn.com
OK
```

[return to list of commands](#)

apply

This command applies changes to network and firewall settings. The command takes no arguments, and returns OK when complete.

cmd apply is required to make changes take effect after the following configuration commands:

- cmd dmz
- cmd friends
- cmd lanip
- cmd lannetmask
- cmd landhcp
- cmd rmtweb
- cmd rmttelnet
- cmd rmtssh
- cmd user

- cmd pswd
- cmd firewall
- cmd telnetport
- cmd ethernet

Examples:

1. Set the LAN subnet

```
cmd lanip 192.168.2.0
cmd lannetmask 255.255.255.0
cmd apply
OK
```

[return to list of commands](#)

8.1.2 “B” Commands

boomreport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command sets the report(s) to be used for boom-tracker triggered reports.

Where:

r = 0 disables the report

r = 1 to 999 report number

boomreport requires the modem to be listening for traffic from the WPAN gateway, this requires cmd mode 10 to be configured.

Examples:

1. Use report 2 for boom-tracker triggered reports.

```
cmd boomreport 2
OK
cmd boomreport
cmd boomreport 2 0 0 0 0 0 0 0
```

2. User report 1, 2 and 4 for boom-tracker triggered reports.

```
cmd boomreport 1 2 4
OK
cmd boomreport
cmd boomreport 1 2 4 0 0 0 0 0
OK
```

3. Disable boom-tracker triggered reports

```
cmd boomreport 0
OK
```

```
cmd boomreport
cmd boomreport 0 0 0 0 0 0 0 0
OK
```

A cmd save is required for this command to take effect.

See also: mode, repaddmes, repdelmes, repemail, replocport, repremip, repremport, repsms, reptype

[return to list of commands](#)

8.1.3 “C” Commands

cardlistclear

Removes list of approved swipe-card IDs from modem.

Example:

```
cmd cardlistclear
OK
```

See also: cardlistload, cardlistsave

[return to list of commands](#)

cardlistload (file-name url username passwd)

This command is used to load the approved ID list used with the swipe card interface from a remote location (FTP/HTTP server). The approved ID list file is copied to /var/config/approved.txt.

The command requires 4 parameters when accessing an FTP server or 2 parameters when accessing an HTTP server:

- **file-name** the name of the approved ID list to load onto the modem
- **url** the address of the FTP or HTTP server, can also be an IP address, prefixed by ftp:// or http:// respectively; if no prefix is specified (eg. cypress.bc.ca) then ftp:// is used
- **username** username to access FTP server (ignored when **url** is prefixed by http://)
- **passwd** password to access FTP server (ignored when **url** is prefixed by http://)

Examples:

cmd cardlistload new-approved.txt cypress.bc.ca guest guestpw where **new-approved.txt** is the approved ID list, **cypress.bc.ca** is the FTP server, **guest** is the username of the FTP server and **guestpw** is the password of the FTP server

cmd cardlistload new-approved.txt http://cypress.bc.ca where **new-approved.txt** is the approved ID list, and **cypress.bc.ca** is the HTTP server

After using this command, a **cmd save** is required to save the approved ID list.

See also: **cardlistclear**, **cardlistsave**, **mode**, **swipereport**

[return to list of commands](#)

cardlistsave

Store a list of approved swipe-card IDs for use by redboot loader swipe card reader application.

Note that a list of approved IDs must first be loaded to the modem using **cardlistload**.

Example:

```
cmd cardlistsave
OK
```

See also: **cardlistclear**, **cardlistload**

[return to list of commands](#)

cardlockload lock-script-file-name url username passwd

This command is used to load the custom lock script associated with the swipe card interface. The command requires 4 parameters when accessing an FTP server or 2 parameters when accessing an HTTP server:

- **lock-script-file-name** the name of the lock script file
- **url** the address of the FTP or HTTP server, can also be an IP address, prefixed by **ftp://** or **http://** respectively; if no prefix is specified (eg. **cypress.bc.ca**) then **ftp://** is used
- **username** username to access FTP server (ignored when **url** is prefixed by **http://**)
- **passwd** password to access FTP server (ignored when **url** is prefixed by **http://**)

Examples:

cmd cardlockload lock.sh cypress.bc.ca guest guestpw where **lock.sh** is the lock script, **cypress.bc.ca** is the FTP server, **guest** is the username of the FTP server and **guestpw** is the password of the FTP server

cmd cardlockload lock.sh http://cypress.bc.ca where **lock.sh** is the lock script, and **cypress.bc.ca** is the HTTP server

After using this command, a **cmd save** is required to save the lock script.

See also: **cardunlockload**, **mode**

[return to list of commands](#)

cardunlockload lock-script-file-name url username passwd

This command is used to load the custom unlock script associated with the swipe card interface. The command requires 4 parameters when accessing an FTP server or 2 parameters when accessing an HTTP server:

- **unlock-script-file-name** the name of the unlock script file
- **url** the address of the FTP or HTTP server, can also be an IP address, prefixed by ftp:// or http:// respectively; if no prefix is specified (eg. cypress.bc.ca) then ftp:// is used
- **username** username to access FTP server (ignored when **url** is prefixed by http://)
- **passwd** password to access FTP server (ignored when **url** is prefixed by http://)

Examples:

cmd cardunlockload unlock.sh cypress.bc.ca guest guestpw where **unlock.sh** is the unlock script, **cypress.bc.ca** is the FTP server, **guest** is the username of the FTP server and **guestpw** is the password of the FTP server

cmd cardunlockload unlock.sh http://cypress.bc.ca where **unlock.sh** is the unlock script, and **cypress.bc.ca** is the HTTP server

After using this command, a **cmd save** is required to save the unlock script.

See also: **cardlockload**, **mode**

[return to list of commands](#)

clientmac nn:nn:nn:nn:nn:nn

Use **clientmac** to set the MAC address of a client computer Ethernet interface, if using modem mode (half-bridge mode) and DHCP.

nn:nn:nn:nn:nn:nn 12-digit hexadecimal address

The **clientmac** address can be queried by using this command without parameters.

Examples:

cmd clientmac 00:a0:d1:69:b2:c8

OK

cmd clientmac

cmd clientmac 00:a0:d1:69:b2:c8

OK

See also: `modemmode`, `modemmodedhcp`

[return to list of commands](#)

confupgrade script-name url username passwd

Configures the modem for over-the-air configuration by means of a custom configuration script retrieved from a defined FTP or HTTP server.

The command requires 4 parameters when accessing an FTP server, 2 parameters when accessing an HTTP server, or 2 parameters when accessing scripts locally.

The script file is a text file containing modem commands used to configure a modem. The script file must have UNIX line endings.

For example:

```
cmd mode 2
cmd gpsrep 1 0 3
cmd gpscond 1 1 30
cmd gpsremip 1 123.123.123.123
cmd gpsremport 1 5005
.....
....
..
```

- **script-name** the name of the configuration script to fetch/run
- **url** can be **localhost**, or the address of the FTP or HTTP server, can also be an IP address, prefixed by `ftp://` or `http://` respectively; if no prefix is specified (eg. `cypress.bc.ca`) then `ftp://` is used
- **username** username to access FTP server (ignored when **url** is prefixed by `http://` or `localhost://`, or **url** is **localhost**)
- **passwd** password to access FTP server (ignored when **url** is prefixed by `http://` or `localhost://`, or **url** is **localhost**)

When **localhost** is specified as the **url**, the script file and its corresponding `.md5` file must be located in `/etc/config` on the modem. Likewise, when `localhost://tmp` is specified as the **url**, the script file and its corresponding `.md5` file must be located in `/tmp` on the modem.

Examples:

cmd confupgrade ctm15x-config.sh cypress.bc.ca guest guestpw where **ctm15x-config.sh** is the script file, **cypress.bc.ca** is the FTP server, **guest** is the username of the FTP server, and **guestpw** is the password of the FTP server

cmd confupgrade ctm15x-config.sh http://cypress.bc.ca where **ctm15x-config.sh** is the script file, and **cypress.bc.ca** is the HTTP server

cmd confupgrade action.sh localhost://tmp will execute the script **/tmp/action.sh** on the modem

cmd confupgrade action.sh localhost will execute the script **/etc/config/action.sh** on the modem

[return to list of commands](#)

ctm15x

This command is used to enable a reset of protected configuration values.

Current protected configuration commands are:

- cmd data
- cmd ethernet
- cmd enghours
- cmd odometer

cmd ctm15x must be run once prior to setting any of the above configuration values.

cmd ctm15x is volatile and cannot be saved, its state will be reset following a modem power cycle or reboot

See also: data, ethernet, enghours, odometer

[return to list of commands](#)

8.1.4 “D” Commands

data [0]

This command keeps track of the amount of data transmitted and received over the wireless data link. The total data transmitted and data received counts can only be reset by using the following command:

cmd data 0

0 Set to 0 to reset

The current amount of data transmitted and received can be queried using **cmd data** without parameters, the result is shown in megabytes (MB).

A **cmd factory** does not reset the wireless link count statistics of this command.

Examples:**1. Reset the link data count to 0**

```
cmd ctm15x
OK
cmd data 0
OK
```

2. Query the current link data count

```
cmd data
TX: 4 MB
RX: 2 MB
Total: 6 MB
OK
```

See also: [ctm15x](#), [datacond](#)

[return to list of commands](#)

datacond x

This command is used to set the condition that will trigger wireless link data count report(s). Report(s) are sent whenever the total amount of data transmitted and received is a multiple of a specified amount.

x = 0 disables the condition

x = 1 to 1999999 total data amount in MB used for periodic triggering

The default configuration upon **cmd factory** is **cmd datacond 10**.

Examples:

1. Set trigger when 5 MB total data has been transmitted and received (such as when 1 MB of data was transmitted, and 4 MB of data was received)

```
cmd datacond 5
OK
```

2. Query the current link data trigger condition

```
cmd datacond
cmd datacond 10
OK
```

See also: [data](#), [datareport](#)

[return to list of commands](#)

datareport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command sets the report(s) to be used for link data count triggered events. See data and datacond for information on configuring the link data reports.

Where:

r = 0 disables the report

r = 1 to 999 report number

Examples:

1. Use report 2 for link data count triggered reports.

```
cmd datareport 2
OK
cmd datareport
cmd datareport 2 0 0 0 0 0 0 0
```

2. User report 1, 2 and 4 for link data count triggered reports.

```
cmd datareport 1 2 4
OK
cmd datareport
cmd datareport 1 2 4 0 0 0 0 0
OK
```

3. Disable link data count triggered reports

```
cmd datareport 0
OK
cmd datareport
cmd datareport 0 0 0 0 0 0 0 0
OK
```

See also: datacond, repaddmes, repdelmes, repemail, replocport, repemip, repemport, repsms, reptype

[return to list of commands](#)

dir pppppppppp [qqqqqqqqqq]

This command sets the NAM (Number Assignment Module) value for the modem. It is a 10-digit phone number assigned to the modem by the service provider. Use the spc command to unlock the modem first. The NAM value may be queried by using the dir command without parameters.

This command also sets the MIN (Mobile Identification Number) value for the modem. It is a 10-digit number assigned to the modem by the service provider. Use the spc command to unlock the modem first.

pppppppppp 10-digit phone number (MDN) to be assigned to the modem or “+” if only MIN is to be assigned

Optional Parameter:

qqqqqqqqqq 10-digit phone number (MIN) to be assigned to the modem

Note: Previous firmware versions included `cmd min` for setting the MIN value of the modem. However, `cmd min` has been replaced by `cmd dir`. Using `cmd dir` as shown one of the examples below are the only ways to set the MIN value of the modem.

Examples:

1. Set the modem’s MDN and MIN

```
cmd dir 1234567890 0987654321
OK
```

2. Set the modem’s 10-digit number (MDN)

```
cmd dir 5551234567
OK
```

3. Set the modem’s 10-digit number (MIN)

```
cmd dir + 0987654321
OK
```

4. Query the modem’s currently assigned phone number (MDN)

```
cmd dir
cmd dir 6049998888
OK
```

A `cmd save` is required for this command to take effect.

http://en.wikipedia.org/wiki/Number_Assignment_Module

<http://en.wikipedia.org/wiki/MIN>

[return to list of commands](#)

dmz iii.iii.iii.iii

This command is used to set up the demilitarized zone (DMZ) feature of the modem that will let all packets go through the modem's firewall to a selected computer. Note that port forwarding rules configured via **cmd firewall** are honored first and if no match is found then traffic is forwarded to the DMZ device.

If any of the modem's remote configuration features are enabled (**cmd rmttelnet**, **cmd rmtssh** (R1.3.X and above), or **cmd rmtweb**), the DMZ feature will forward the enabled remote access (Telnet, SSH, or HTTP) traffic to the modem and forward all other traffic to the DMZ device.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 local IP address of device that all packets are forwarded to (default: 0.0.0.0, which disables the DMZ feature)

Examples:

1. Set up all traffic to be forwarded to a device at 192.168.1.20, except remote Web configuration (TCP port 80) traffic and remote SSH (TCP port 22) traffic that are forwarded to the modem

```
cmd rmtweb 1
OK
cmd rmtssh 1
OK
cmd dmz 192.168.1.20
OK
```

2. Set up all traffic to be forwarded to a device at 192.168.1.20 including remote Telnet (TCP port 23) traffic, remote SSH (TCP port 22) traffic, and remote Web configuration (TCP port 80) traffic

```
cmd dmz 192.168.1.20
OK
```

3. Disable the DMZ feature

```
cmd dmz 0.0.0.0
OK
```

4. Query the current DMZ configuration

```
cmd dmz
cmd dmz 192.168.1.20
OK
```

A **cmd apply** followed by a **cmd save** are required for this command to take effect.

[return to list of commands](#)

dnscheck x

This command is used to enable or disable the CTM-15X modem from checking for valid DNS IP addresses obtained from the carrier when it connects to the network. If the DNS IP addresses are invalid, the modem will disconnect the current network connection and reconnect.

After 5 reconnects have been attempted every 30 secs, and the modem still gets an invalid DNS, the modem will stop disconnecting and reconnecting the network connection.

x = 0 disable checking for valid DNS IP addresses from the carrier

x = 1 enable checking for valid DNS IP addresses from the carrier (default)

Examples:

1. Disable checking DNS IP addresses from the carrier.

```
cmd dnscheck 0
OK
```

A `cmd save` and a **power cycle** are required for this command to take effect.

[return to list of commands](#)

dout n x

This command is used to set the state of each of the all outputs. There are four outputs in total.

n = 1 to 4 output channel number

x = 0 sets output to off

x = 1 sets output to on

The current settings can be queried by using the `dout` command without parameters.

Examples:

1. Set output #2 ON

```
cmd dout 2 1
OK
```

2. Query the state of all four outputs

```
cmd dout
cmd dout 1 0
cmd dout 2 1
cmd dout 3 0
cmd dout 4 0
```

A `cmd save` is required for this command to take effect.

[return to list of commands](#)

dyndns text1 text2 text3

This command configures the modem to perform regular updates to the Dynamic Domain Name Service. This feature creates an alias from a dynamic IP address to a static hostname allowing the modem to be more easily accessed over the Internet for remote configuration or for end application. For this feature, the modem requires a **public IP address**. By default this feature is disabled - “,,”. This command requires a cmd save command and **power cycle** for the changes to take effect.

text1 user name for the DYNDNS service.

text2 user password for the DYNDNS service.

text3 domain (hostname) name for the DYNDNS

The current settings of the DYNDNS (Dynamic Domain Name Service) can be queried by using the dyndns command without parameters.

DYNDNS updates can be disabled by using **0** for the user name, **0** for the user password, and **0.0.0.0** for the hostname. Note that after disabling DYNDNS updates, the hostname will continue to point to the last IP address of the modem. For instructions on clearing the IP address associated with the hostname, please refer to DYNDNS documentation for details on using the offline hostname feature.

Examples:

1. Set the user name and password and the domain name

```
cmd dyndns cypressdemo cypress cypresscamera2.dyndns.org
OK
```

2. Disable DYNDNS updates

```
cmd dyndns 0 0 0.0.0.0
OK
```

3. Query the modem's setting for this setting

```
cmd dyndns
cmd dyndns cypressdemo cypress cypresscamera2.dyndns.org
OK
```

A cmd save is required for this command to take effect.

<http://en.wikipedia.org/wiki/Dyndns>

<http://www.dyndns.com/>

[return to list of commands](#)

8.1.5 “E” Commands

emailsrv a.a.a.a

This command is used to set the IP address of the SMTP email server that will be used by the modem for sending email reports.

The commands `gpsrep`, `ignreport`, and `reptype` are used to enable email reporting.

a.a.a.a = 0.0.0.0 to 255.255.255.255 IP address of the email server to be used for email reports. Default = 0.0.0.0 The current email server IP address can be queried by using the `emailsrv` without parameters.

Examples:

1. Set the email server IP address to 100.120.10.10

```
cmd emailsrv 100.120.10.10
OK
```

2. Query current email server

```
cmd emailsrv
cmd emailsrv 100.120.10.10
OK
```

A `cmd save` is required for this command to take effect.

[return to list of commands](#)

enghours n

Since total engine hours data is not available through standard OBD2 interface, Total engine hours must be calculated using other methods.

When a modem is installed in a vehicle and the current vehicle engine hours are known, the current engine hours will need to be programmed.

This can be done through the following command:

```
cmd enghours n
n Total engine hours in hours (0-999999.99).
```

The current value of engine hours can be queried using **cmd enghours** without parameters and is shown in hours.

The modem must be configured to enable engine hours counting using the `enghrmode` command.

Examples:

1. Set the engine hours to **2501**

```
cmd ctm15x
OK
cmd enghours 2501
OK
```

See also: ctm15x

[return to list of commands](#)

enghrmode n

cmd enghrmode n

where n:

- 0** Disabled (Default, Engine hours can still be obtained if vehicle has J1939 capability)
- 1** Use ignition input only
- 2** Use OBD2 input only
- 3** Use combination of ignition and OBD2 inputs

A cmd save is required for this command to take effect.

[return to list of commands](#)

esn

This command queries the 32 bit ESN (Electronic Serial Number) of the embedded wireless network access device.

The ESN is read only and cannot be altered.

Example:

1. Query the 11 digit ESN in decimal format

```
cmd esn
12345678901
OK
```

http://en.wikipedia.org/wiki/Electronic_Serial_Number

[return to list of commands](#)

ethernet x

This command is used to enable or disable the Ethernet services of the modem. Ethernet services are enabled by default whenever a `cmd factory` is issued.

x = 0 disable Ethernet services

x = 1 enable Ethernet services

Examples:

1. Disable Ethernet services

```
cmd ctm15x
OK
cmd ethernet 0
OK
```

A `cmd apply` followed by a `cmd save` are required for this command to take effect.

See also: `ctm15x`

[return to list of commands](#)

8.1.6 “F” Commands

firewall n eeee llll t iii.iii.iii.iii s

This command is used to setup the port forwarding configuration of the modem.

Up to 10 port forwarding configurations can be set.

The local IP address will default to 192.168.1.X, where X is extracted from iii.iii.iii.iii and 192.168.1 is extracted from the IP address in the LAN Configuration setting.

n = 1 to 10 port forwarding number

eeee = 0 to 65535 external port number to forward to

llll = 0 to 65535 local port number to forward to

t = 0 disable

t = 1 UDP

t = 2 TCP

t = 3 both UDP and TCP

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 local IP address to forward to

s = 0 disable forwarding

s = 1 enable forwarding

The current port forward settings can be queried by using `firewall` without parameters.

Note that LAN IP addresses used in port forwarding rules must match the LAN subnet as configured using `lanip`, `lanetmask`, and `lanrepip`.

Examples:

1. Set port forwarding #1 to forward data destined for port 8080 (same external & local port number), on both using UDP and TCP protocol to IP 192.168.1.20 and enabled

```
cmd firewall 1 8080 8080 3 192.168.1.20 1
OK
```

2. Set port forwarding #2 to forward data destined for external port 42375 and redirect it to local port 5001, on UDP protocol to IP 192.168.1.20 and enabled.

```
cmd firewall 2 42375 5001 1 192.168.1.20 1
OK
```

3. Query the current firewall configuration

```
cmd firewall
cmd firewall 1 8080 8080 3 192.168.1.20 1
OK
```

A `cmd apply` followed by a `cmd save` are required for this command to take effect.

[return to list of commands](#)

freeconsole

Kill the serial console shell process. This command must be done at first if you use **cmd pad** or **cmd modbusgw** from the SSH/Telnet console in mode 4 or 6.

Example:

1. Free the serial console port to use by pad or modbusgw mode.

```
// only from the SSH/Telnet session
cmd freeconsole
OK
```

```
cmd pad
or
cmd modbusgw
OK
```

The serial console is not available after this command. You may need to set **cmd port** to use serial console again.

[return to list of commands](#)

friends n x.x.x.x y.y.y.y

This command is used to setup the modem's firewall friends list, which is used to block incoming packets from an IP address that is not specifically enabled.

Use this to define a range of IP addresses whose traffic you wish to be accepted by the modem.

This feature controls access to the following modem features:

- MODBUS
- PAD
- ULCP
- Remote SSH access (R1.3.0 only)
- Remote Telnet access
- Remote Web access

Port forwarding configured via firewall and the DMZ feature configured via dmz are accessible by all IP addresses. The friends list feature does not control access to these features.

Modem access is verified in ascending order via the OR condition of all entries in the friends list.

n = 1 to 8 friends list number

x.x.x.x = 0.0.0.0 to 255.255.255.255 IP address/range to allow

y.y.y.y = 0.0.0.0 to 255.255.255.255 netmask of addresses to allow

By default, the friends list is disabled and all IP addresses are allowed to access the modem.

The current friends list can be queried by using friends without parameters. An empty friends list indicates that this feature is disabled.

Examples:

1. Allow only incoming requests from the IP address 1.2.3.4 to access the modem

```
cmd friends 1 1.2.3.4 255.255.255.255
OK
```

2. Allow only incoming requests from the 1.2.3.x subnet to access the modem

```
cmd friends 2 1.2.3.4 255.255.255.0
OK
```

3. Allow only incoming requests from the 1.2.3.x subnet to access the modem. This is equivalent to Example #2 above.

```
cmd friends 2 1.2.3.0 255.255.255.0
OK
```

4. Disable the friends list entry and allow all IP addresses to access the modem (default)

```
cmd friends 1 0.0.0.0 0.0.0.0
OK
```

A cmd apply followed by a cmd save are required for this command to take effect.

[return to list of commands](#)

8.1.7 “G” Commands

gpsaccel n a d

Sets the GPS report triggers for capturing hard acceleration and deceleration events.

Reports will be triggered if the instantaneous acceleration is greater than **a** or the instantaneous acceleration is less than **d**.

The default thresholds are 0 km/h/s for acceleration and 0 km/h/s for deceleration.

n = 1 to 8 GPS report number

a acceleration threshold in km/h/s

d deceleration threshold in km/h/s

Examples:

1. Send GPS report #7 whenever acceleration is greater than 10 km/h/s or deceleration is less than -10 km/h/s

```
cmd gpsaccel 7 10 -10
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

gpsaddmes n x [x2] [x3] [x4]

Adds messages to a GPS report. 4 messages can be included in a single report. Duplicate messages cannot be included in a report.

Messages will be sent in a report in the same order that they are added with this command.

ULCP header messages will be sent as individual UDP packets, NMEA format messages will be combined into a single packet.

n = 1 to 8 GPS report number

x message type to be added, valid message types must be used - see CTM-15X message list

Examples:

1. Adds message #16 – GPS NMEA GLL – to GPS report #4

```
cmd gpsaddmes 4 16
OK
```

2. Query messages for GPS report #4

```
cmd gpsaddmes 4
cmd gpsaddmes 4 16 80 82 0
OK
```

A `cmd save` is required for this command to take effect.

See also: `gpsrep`, `gpsdelmes`, `gpslocport`, `gpsremip`, `gpsremport`, `gpsemail`, `gpsms`

[return to list of commands](#)

gpscond *n b t* [*d*] [*ms Ms*] [*h hs*] [*mt*]

Sets the condition(s) that will trigger a GPS report.

The conditional operator is used to indicate how all following parameters will be used to determine if a report is triggered.

The **mt** parameter must be used at the end if all other optional parameters are entered.

The default condition for report #11 is 11 1 10 (these can be changed, the first three parameters are valid for report #11 ONLY).

n = 1 to 8 GPS report number

b = 0 conditional operator for all following parameters: **Off**

b = 1 conditional operator for all following parameters: **AND**

b = 2 conditional operator for all following parameters: **OR**

t = 0 timeout disabled

t = 1 to 65535 timeout in seconds

Optional parameters:

d = 0 to 65535 distance traveled threshold in meters

ms = 0 to 65535 low speed threshold in kph – use with *Ms*

Ms = 0 to 65535 high speed threshold in kph – use with *ms*

h = 0 to 359 heading change in degrees – use with *hs*

hs = 0 65535 minimum speed threshold to make heading measurement valid, in kph – use with *h*

mt = 0 to 65535 maximum reporting rate in seconds (minimum time between reports)

The current condition(s) for a report can be queried by using the **gpscond n** command. If *n* is blank, all GPS reports will be queried.

Examples:

1. Send report #1 every **60** seconds

```
cmd gpscond 1 1 60
OK
```

2. Send report #2 every **60** seconds **AND** distance is greater than **50** metres

```
cmd gpscond 2 1 60 50
OK
```

3. Send report #4 every **60** seconds **AND** the distance traveled is greater than **50** metres **AND** the speed is between **20kph** and **60kph**

```
cmd gpscond 4 1 60 50 20 60
OK
```

4. Send report #5 every **60** seconds **OR** when distance traveled is greater than **50** metres **OR** speed is greater than **60kph**, **OR** if the heading changes by more than **45** degrees, with a maximum report rate of one every **10** seconds

```
cmd gpscond 5 2 60 50 60 200 45 10 10
OK
```

5. Send report #6 only when distance traveled is greater than **0** metres **AND** the speed is between **0kph** and **5kph** **AND** with a maximum report rate of one every **7** seconds

```
cmd gpscond 6 1 0 0 0 5 0 0 7
OK
```

6. Query the conditions used to trigger all GPS reports

```
cmd gpscond
cmd gpscond 1 1 30 0 0 0 0 0 0
cmd gpscond 2 1 30 0 0 0 0 0 0
cmd gpscond 3 2 10 10 0 0 0 0 0
OK
```

7. Query the conditions used to trigger GPS report #4

```
cmd gpscond 4
cmd gpscond 4 1 0 0 0 5 0 0 7
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

gpsdata

Displays the current status of GPS input devices configured via `gpsinput` and corresponding GPS data. This command is read-only.

Example:

cmd gpsdata displays the status of currently configured GPS input devices and GPS data obtained from the devices

```
root@OpenWrt:~# cmd gpsinput 15
OK
root@OpenWrt:~# cmd gpsdata
GPS INPUT 1, CONNECTED, SELECTED
  $GPGGA,212403.00,4915.3923,N,12259.8040,W,1,5,04.5,+00010,M,,M,,0000*55
  $GPRMC,212403.00,A,4915.3923,N,12259.8040,W,000.0,180.0,051109,,*22
GPS INPUT 2, NOT CONNECTED
GPS INPUT 3, CONNECTED, NOT SELECTED
  $GPGGA,212318.00,4915.3916,N,12259.8031,W,1,6,02.8,+00032,M,,M,,0000*50
  $GPRMC,212318.00,A,4915.3916,N,12259.8031,W,000.0,000.0,051109,,*26
GPS INPUT 4, NOT CONNECTED
OK
```

See also: `gpsinput`, `gpsparam`

[return to list of commands](#)

gpsdelmes n x

This command is used to delete a message type (or all messages) from a GPS report.

n = 1 to 8 GPS report number

x message type to be deleted (0 to delete all messages)

Examples:

1. Delete message type #16 from GPS report #1

```
cmd gpsdelmes 1 16
OK
```

2. Delete all messages from GPS report #4

```
cmd gpsdelmes 4 0
OK
```

A `cmd save` is required for this command to take effect.

See also: `gpsrep`, `gpslocport`, `gpsremip`, `gpsremport`, `gpsemail`, `gpssms`

[return to list of commands](#)

gpsemail n <email address>

Sets the email address that the GPS report will be sent to (if configured for email using gpsrep).

Up to 8 email addresses may be configured – one for each of the 8 GPS reports. The default email address is blank.

Note that an email server is required – see emailsrv.

n = 1 to 8 GPS report number

<email address> = name@domain email address to which the report will be sent
(leave blank to clear the address)

The current email address configured for all GPS reports can be queried by using the gpsemail command without parameters.

Examples:

1. Set the destination email address for GPS report #1

```
cmd gpsemail 1 me@home.com
OK
```

2. Clear the email address for GPS report #1

```
cmd gpsemail 1
OK
```

3. Query the email address for all GPS reports

```
cmd gpsemail
cmd gpsemail 1 me@home.com
OK
```

A cmd save is required for this command to take effect.

See also: gpsrep, gpsdelmes, gpslocport, gpsremip, gpsremport, gpsaddmes, gpsms

[return to list of commands](#)

gpsgga

Displays the current GPS position in NMEA0183 format.
This command is a read only command.

Example:

1. Return a current GPS NMEA format GGA message

```
cmd gpsgga
$GPGGA,215619.00,4948.7174,N,11928.6175,W,0,5,01.9,++00380,M,,M,,0000*58
OK
```

[return to list of commands](#)

gpsinput m

This command defines what source to use for GPS data.

cmd gpsinput m

Where:

m=mode (bit mapped) default=0x01

m.0 - Input 1 = Use internal GPS module (TSIP)

m.1 - Input 2 = Use internal GPS module (NMEA)

m.2 - Input 3 = Use external GPS module (NMEA)

m.3 - Input 4 = Use A-GPS module (NMEA)

Example:

```
gpsinput 9
```

A cmd save and a powercycle is required for this command to take effect.

[return to list of commands](#)

gpslocport n xxxxx

Sets the port number of the local server that the GPS report will be sent to.

Up to 8 GPS reports may be configured.

The default port for report #11 is 6102.

n = 1 to 8 or 11 GPS report number

xxxxx = 0 to 65535 local port number in decimal

The current local port configuration for a GPS report can be queried by entering **gpslocport n**, where **n** is the port number.

If **n** is omitted, all reports will be queried.

Examples:

1. Send report #1 to local port 5005

```
cmd gpslocport 1 5005
OK
```

2. Query the local port setting of all GPS reports

```
cmd gpslocport
cmd gpslocport 1 5005
OK
```

A cmd save is required for this command to take effect.

See also: [gpsrep](#), [gpsdelmes](#), [gpsaddmes](#), [gpslocport](#), [gpsremip](#), [gpsemail](#), [gpssms](#)

[return to list of commands](#)

gpsmes

Displays all messages associated with each GPS report.

This command is read only.

Example:

cmd gpsmes displays all messages associated with each GPS report

[return to list of commands](#)

gpsparam

This command configures the parameters and priority of the port the modem will use for obtaining GPS information.

cmd gpsparam input priority port br db p sb fc

Where:

input - GPS input to configure 1-4

priority - Data Priority (0-3). 0=highest

port - Serial port to use. e.g. ttyS1 or ttyUSB14

br - baud rate (same as cmd port)

db - data bits (same as cmd port)

p - parity (same as cmd port)

sb - stop bits (same as cmd port)

fc - flow control (same as cmd port)

If all enabled ports are available and have valid GPS, the highest priority input is used.

Notes:

- This can feature can also be used for A-GPS since it is outputting NMEA data on a ttyUSB port.
- When GPS inputs are configured at the same priority, GPS data will be obtained from whichever GPS input has valid data first, in ascending order from GPS input 0 to GPS input 3.

Example:

```
cmd gpsparam 3 2 /dev/ttyUSB0 4800 8 n 1 0 configure the modem USB port for accepting GPS data
```

```
cmd gpsparam 3 2 /dev/ttyS0 4800 8 n 1 0 configure the modem external serial port for accepting GPS data
```

A `cmd save` and a `powercycle` is required for this command to take effect.

[return to list of commands](#)

gpspos `n ±xx.xxxxxx ±yyy.yyyyyy`

Set fixed GPS position mode. This sets the GPS coordinates used in modem reports to user-defined latitude and longitude values. When this setting is enabled, the GPS date and time used in modem reports is synchronized to the modem's system time.

This setting is used for monitoring modems used with fixed-site applications.

n = 0 Disable fixed GPS position mode. Use GPS position from GPS input device configured with `gpsinput`. (Default)

n = 1 Enable fixed GPS position mode. Use user-defined location.

`±xx.xxxxxx = -90.000000 <= ±xx.xxxxxx <= +90.000000` latitude in decimal format, where North=positive and South=negative

`±yyy.yyyyyy = -180.000000 <= ±yyy.yyyyyy <= +180.000000` longitude in decimal format where East=positive and West=negative

A `cmd save` and a `power cycle` are required for this command to take effect.

Notes:

`cmd gpspos 0` will disable the fixed GPS position mode but preserve the user-defined location

`cmd gpspos 0 0 0` will disable the fixed GPS position mode and clear the user-defined location

Example:

1. Enable fixed GPS position mode and set the user-defined location to (49.256553, -122.996733):

```
cmd gpspos 1 49.256553 -122.996733
OK
```

2. Disable fixed GPS position mode but preserve the user-defined location:

```
cmd gpspos 0
OK
```

3. Disable fixed GPS position mode and clear the user-defined location:

```
cmd gpspos 0 0 0
OK
```

See also: [gpsinput](#)

[return to list of commands](#)

gpsremip n iii.iii.iii.iii

Sets the IP address of the remote server that the GPS report will be sent to. Up to 8 GPS reports can be configured.

n = 1 to 8 or 11 GPS report number

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 remote IP address in decimal

The remote IP address of a report can be queried by using **gpsremip n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

1. Report #1 will be sent to remote IP address 123.10.1.101

```
cmd gpsremip 1 123.10.1.101
OK
```

2. Query the remote IP address setting of all GPS reports

```
cmd gpsremip
cmd gpsremip 1 123.10.1.101
cmd gpsremip 2 99.99.99.99
OK
```

A `cmd save` is required for this command to take effect.

See also: [gpsrep](#), [gpsdelmes](#), [gpslocport](#), [gpsaddmes](#), [gpsrempport](#), [gpsemail](#), [gpsmsms](#)

[return to list of commands](#)

gpsremport n xxxxx

Sets the IP port number of the remote server that the GPS report will be sent to.

Up to 8 GPS reports can be configured.

n = 1 to 8 or 11 GPS report number

xxxxx = 0 to 65535 remote port number in decimal

The current IP port configuration for a GPS report can be queried by using **gpsremport n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

1. Report #1 will be sent to port 5005 on remote IP address set by `gpsremip`

```
cmd gpsremport 1 5005
OK
```

2. Query the remote port setting of all GPS reports

```
cmd gpsremport
cmd gpsremport 1 7001
cmd gpsremport 2 4114
OK
```

A `cmd save` is required for this command to take effect.

See also: `gpsrep`, `gpsdelmes`, `gpsaddmes`, `gpsremip`, `gpsremport`, `gpsemail`, `gpssms`

[return to list of commands](#)

gpsrep n l r s

Sets the reporting type for each GPS report for the local and remote servers.

n = 1 to 8 or report 11 GPS report number

l = 0 disables local GPS report (default)

l = 1 asynchronous NMEA or ULCP messages over RS232

l = 2 asynchronous NMEA or ULCP messages with a ULCP header over RS232

l = 3 in-band NMEA or ULCP messages in a UDP Packet over Ethernet

l = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets over Ethernet
l = 5 in-band NMEA or ULCP messages in a TCP Packet over Ethernet
l = 6 file-based reports

r = 0 disables remote GPS report (default)
r = 3 in-band NMEA or ULCP messages in a UDP Packet
r = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets
r = 5 in-band NMEA or ULCP messages in a TCP Packet
r = 6 email reports
r = 7 SMS reports

s = 0 disables the store and forward of GPS reports
s = 1 enables the store and forward of GPS reports

Note: For **r = 7** (SMS reports), the total length of the report must not exceed 166 characters including <CR> and <LF>

The current report type configuration for a GPS report can be queried by using **gpsrep n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

1. Send GPS report #4 as a UDP packet over Ethernet and over the wireless link, do not store GPS reports

```
cmd gpsrep 4 3 3
OK
```

2. Send GPS report #2 as a UDP packet over Ethernet and as an SMS message to the SMS destination set using the **gpssms** command, and enable the store and forward of GPS reports

```
cmd gpsrep 2 3 7 1
OK
```

3. Queries the reporting method for all GPS reports

```
cmd gpsrep
cmd gpsrep 1 0 3 1
cmd gpsrep 2 3 3 0
cmd gpsrep 11 3 0 0
OK
```

A **cmd save** is required for this command to take effect.

See also: **gpsaddmes**, **gpsdelmes**, **gpslocport**, **gpsremip**, **gpsrempport**, **gpsemail**, **gpssms**

[return to list of commands](#)

gpsrmc

Displays the current GPS position in NMEA0183 format.
This command is a read only command.

Example:

1. Return a current GPS NMEA format RMC message

NMEA 0183 v2.0:

```
cmd nmeamode
cmd nmeamode 0
OK
cmd gpsrmc
$GPRMC,215812.00,V,4948.7177,N,11928.6161,W,000.0,000.0,280409,,,*38
OK
```

NMEA 0183 v3.0:

```
cmd nmeamode
cmd nmeamode 1
OK
cmd gpsrmc
$GPRMC,014418.00,A,4915.3868,N,12259.8017,W,000.8,318.0,221210,, ,A*4B
OK
```

[return to list of commands](#)

gpssms n pppppppppp or <email address>

Sets the destination of the GPS report that is sent as an SMS message.

Up to 8 GPS reports may be configured. The default SMS destination is blank.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

n = 1 to 8 GPS report number

pppppppppp phone number which the SMS report will be sent to. For long distance calls, a "1" needs to be added in front of the phone number.

(leave blank to clear the phone number)

<email address> email address which the SMS report will be sent to.

(leave blank to clear the address)

The current SMS destination configured for all GPS reports can be queried by using the **gpssms** command without parameters.

Examples:

1. Send GPS report #1 as an SMS message to the specified phone number

```
cmd gpssms 1 1234567890
OK
```

2. Send GPS report #2 as an SMS message to the specified email address

```
cmd gpssms 2 me@home.com
OK
```

3. Clear the SMS destination for GPS report #1

```
cmd gpssms 1
OK
```

4. Query the phone numbers or email addresses for all GPS SMS reports

```
cmd gpssms
cmd gpssms 1 1234567890
cmd gpssms 2 me@home.com
OK
```

A `cmd save` is required for this command to take effect.

See also: `gpsrep`, `gpsaddmes`, `gpsdelmes`, `gpslocport`, `gpsremip`, `gpsrempport`, `gpsemail`

[return to list of commands](#)

gpstime n

Set the priority of valid GPS as an external system time synchronization source.

n = 0 Disabled

n = 1-3 Priority relative to other external system time synchronization sources with 1 = highest (default: 1)

A `cmd save` and a **power cycle** are required for this command to take effect.

Example:

1. Set valid GPS as lowest priority relative to other external time synchronization sources:

```
cmd gpstime 3
OK
```

See also: `networktime`, `ntpserver`, `ntpstime`, `timesync`

[return to list of commands](#)

8.1.8 “I” Commands

igncond n a

Sets the condition(s) that would trigger an ignition report.

The state of the ignition is controlled by the "white" wire of the 3 wire power connection.

The conditional parameter, **a** is used to indicate how all following parameters will be used to determine if a report is triggered.

n = 1 to 8 ignition condition number

a = 0 trigger disabled (default)

a = 1 trigger on ignition going OFF

a = 2 trigger on ignition going ON

a = 3 trigger on transition (ON->OFF or OFF->ON)

The current ignition condition(s) for can be queried by **igncond n** where **n** is the condition number.

If **n** is blank, all ignition conditions will be queried.

Examples:

1. Set ignition condition 1 to trigger when ignition is going OFF

```
cmd igncond 1 1
OK
```

2. Set ignition condition 2 to trigger when an ignition transition (ON to OFF or OFF to ON) is detected.

```
cmd igncond 2 3
OK
```

A cmd save is required for this command to take effect.

See also: [ignreport](#)

[return to list of commands](#)

ignreport [n] [r]

This command sets the report to be used for ignition triggered reports.

Up to 8 ignition trigger reports can be configured.

n = 1 to 8 ignition trigger condition
r = 1 to 999 report number
r = 0 disables the report

Example:

1. Set report #2 for ignition trigger condition #1.

```
cmd ignreport 1 2
OK
```

A cmd save is required for this command to take effect.

See also: igncond, repaddmes, repdelmes, repemail, replocport, repremip, repremport, repsms, reptype

[return to list of commands](#)

input

Reads the value and state of all inputs. There are a total of six inputs. Both the analog voltage (range 0 to 10 Volts) and digital state (0 for off and 1 for on) are returned. This is a read only command.

Example:

1. Query the current status of input #1 through #6

```
cmd input
0.00V 0
0.00V 0
0.00V 0
0.08V 0
0.08V 0
0.08V 0
OK
```

[return to list of commands](#)

insetup n d x.x p a

Configures the six inputs. Their use as a digital or analog input can be set along with their alarm states. Note: Voltage threshold values are accurate to one decimal place, (X.X), if additional decimal place values are entered, they will be rounded to the nearest decimal place.

n = 1 to 6 input channel number

d = A set as analog input

d = D set as digital input

x.x = 0 to 9.9 sets the voltage threshold for alarm reporting (valid if input set as analog only, use 0.0 for digital input)

p = P sets input polarity to positive (this also determines the alarm level)

p = N sets input polarity to negative (this also determines the alarm level)

a = 0 alarm off

a = 1 alarm on

a = 2 alarm on change state (valid for digital inputs only)

The current setup can be queried by using the `insetup` without parameters.

Note: When configuring **insetup** with a **digital** input, the voltage threshold parameter is ignored. The modem's I/O module has fixed digital input thresholds of 3 V and 2 V (1 V hysteresis).

Examples:

1. Set input #2 as **digital**, with **alarm** when **ON**

```
cmd insetup 2 D 0.0 P 1
OK
```

2. Set input #4 as **analog**, with **alarm** when **> 7.5V**

```
cmd insetup 4 A 7.5 P 1
OK
```

3. Query the setup parameters for all 6 inputs

```
cmd insetup
cmd insetup 1 A 0.0 N 0
cmd insetup 2 A 0.0 N 0
cmd insetup 3 A 0.0 N 0
cmd insetup 4 A 0.0 N 0
cmd insetup 5 A 0.0 N 0
cmd insetup 6 A 0.0 N 0
OK
```

A `cmd save` is required for this command to take effect.

[return to list of commands](#)

ioaddmes n x [x2][x3][x4]

Adds a message to an IO report. 4 messages can be included in a single report. Duplicate messages cannot be included in a report.

Messages will be sent in a report in the same order that they are added.

Note that ULCP header messages will be sent as individual UDP packets – NMEA format messages will be combined into one UDP packet.

n = 1 to 8 IO report number

x message type to be added, valid message types must be used - see message list

Example:

cmd ioaddmes 4 16 adds message type #16 – GPS NMEA GLL – to IO report #4

cmd ioaddmes 4 displays all messages associated with IO report #4

A cmd save is required for this command to take effect.

[return to list of commands](#)

iocond n b t i1 i2 IP mt

Sets the condition(s) that would trigger an IO report.

The conditional parameter is used to indicate how all following parameters will be used to determine if a report is triggered.

Use the **Off** setting to disable the report.

n = 1 to 8 IO report number

b = 0 conditional operator for the following parameters: Off (default)

b = 1 conditional operator for the following parameters: AND

b = 2 conditional operator for the following parameters: OR

t = 0 timeout disabled

t = 1 to 65535 timeout in seconds

i1 = 0 alarm on input trigger: disabled

i1 = 1 to 6 alarm on input trigger: input number

i2 = 0 alarm on input trigger: disabled

i2 = 1 to 6 alarm on input trigger: input number

IP = 0 report if change in IP address: disabled

IP = 1 report if change in IP address: enabled

mt = 0 to 65535 maximum reporting rate in seconds (minimum time between reports)

The current condition(s) for a report can be queried by using **iocond n** where **n** is the report number.

If **n** is blank, all IO reports will be queried.

Examples:

cmd iocond 1 1 60 sends report #1 every 60 seconds

cmd iocond 2 1 60 1 sends report #2 every 60 seconds if input #1 is in alarm

cmd iocond 3 1 60 1 2 send report #3 every 60 seconds if inputs #1 and #2 are in alarm
cmd iocond 4 2 0 0 0 1 send report #4 whenever the IP address of the modem changes – this indicates that it has made a new network connection
cmd iocond 5 2 60 0 3 0 10 send report #5 every 60 seconds or while input #3 is in alarm but with a maximum report rate of one every 10 seconds
cmd iocond 6 1 0 6 0 0 10 send report #6 only while input #6 is in alarm but with a maximum report rate of one every 10 seconds
cmd iocond queries the conditions to trigger all IO reports
A cmd save is required for this command to take effect.

[return to list of commands](#)

iodelmes n x

Deletes a message (or all messages) from an IO report.

n = 1 to 8 IO report number

x message type to be deleted or 0 to delete all messages

Examples:

cmd iodelmes 1 16 deletes message type #16 from IO report #1

cmd iodelmes 4 0 deletes all messages from IO report #4

A cmd save is required for this command to take effect.

[return to list of commands](#)

ioemail n <email address>

Sets the email address that the IO report will be sent to (if configured for email using iorep).

Up to 8 email addresses may be configured – one for each of the 8 IO reports. The default email address is blank.

n = 1 to 8 IO report number

<email address> = name@domain email address to which the report will be sent
(leave blank to clear the email address)

The current email address can be queried for all IO reports by using the ioemail command without parameters.

Note that an email server is required – see **emailsrv**

Examples:

cmd ioemail 1 me@... sets the send to email address for IO report #1

cmd ioemail 1 clears the email address for IO report #1

cmd ioemail returns the email address for all 8 IO reports

A cmd save is required for this command to take effect.

[return to list of commands](#)

ioloport n xxxxx

Sets the port number of the local server that the IO report will be sent to. Up to 8 IO reports may be configured.

n = 1 to 8 IO report number

xxxxx = 0 to 65535 local port number

The current local port configuration for an IO report can be queried by using **ioloport n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

cmd ioloport 1 5005 report #1 will be sent to local port **5005**

cmd ioloport queries the local port setting of all IO reports

A cmd save is required for this command to take effect.

[return to list of commands](#)

iomes

Displays all messages associated with each IO report.

This is a read only command.

Example:

cmd iomes displays all messages associated with each IO report

[return to list of commands](#)

ioremip n iii.iii.iii.iii

Set the IP address of the remote server that the IO report will be sent to. Up to 8 IO reports may be configured.

n = 1 to 8 IO report number

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 remote IP address in decimal

The current IP address for an IO report can be queried by using **ioremip n** where **n** is the report number. If **n** is omitted, all reports will be queried.

Examples:

cmd ioremip 1 123.10.1.101 report #1 will be sent to remote IP address **123.10.1.101**

cmd ioremip queries the remote IP address setting of all IO reports

A cmd save is required for this command to take effect.

[return to list of commands](#)

iorempport n xxxxx

Sets the IP port number of the remote server that the IO report will be sent to. Up to 8 IO reports may be configured.

n = 1 to 8 IO report number

xxxxx = 0 to 65535 remote port number

The current IP port configuration for an IO report can be queried by using **iorempport n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

cmd iorempport 1 5005 report #1 will be sent to port **5005** on remote IP address set by ioremip

cmd iorempport queries the remote port setting of all IO reports

A cmd save is required for this command to take effect.

[return to list of commands](#)

iorep n l r s

Sets the reporting type for each IO report for the local and remote servers.

n = 1 to 8 IO report number

l = 0 disables the local report (default)
l = 1 asynchronous NMEA or ULCP messages over RS232
l = 2 asynchronous NMEA or ULCP messages with a ULCP header over RS232
l = 3 in-band NMEA or ULCP messages in a UDP Packet over Ethernet
l = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets over Ethernet
l = 5 in-band NMEA or ULCP messages in a TCP Packet over Ethernet
l = 6 file-based reports

r = 0 disables the remote report (default)
r = 3 in-band NMEA or ULCP messages in a UDP Packet
r = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets
r = 5 in-Band NMEA or ULCP messages in a TCP Packet
r = 6 email reports
r = 7 SMS reports

s = 0 disables the store and forward of IO reports
s = 1 enables the store and forward of IO reports

Note: For **r = 7** (SMS reports), the total length of the report must not exceed 166 characters including <CR> and <LF>

The current report configuration for an IO report can be queried by using **iorep n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples: **cmd iorep 4 3 3** this will send IO report #4 as a UDP packet over Ethernet and over the wireless link, and will not store IO reports

cmd iorep 2 3 7 1 this will send IO report #2 as a UDP packet over Ethernet and as an SMS message to the SMS destination set using the **iosms** command, and will enable the store and forward of IO reports

cmd iorep queries the reporting method for all IO reports

A **cmd save** is required for this command to take effect.

[return to list of commands](#)

iosms n pppppppppp or <email address>

Sets the destination of the IO report that is sent as an SMS message. Up to 8 IO reports may be configured. The default SMS destination is blank.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

n = 1 to 8 IO report number

pppppppppp phone number which the SMS report will be sent to. For long distance calls, a “1” needs to be added in front of the phone number.

(leave blank to clear the phone number)

<email address> email address which the SMS report will be sent to.

(leave blank to clear the address)

The current SMS destination configured for all IO reports can be queried by using the iosms command without parameters.

Examples:

cmd iosms 1 1234567890 sends IO report #1 as an SMS message to the specified phone number

cmd iosms 2 me@... sends IO report #2 as an SMS message to the specified email address

cmd iosms 1 clears the SMS destination for IO report #1

cmd iosms queries the phone numbers or email addresses for all IO SMS reports

A cmd save is required for this command to take effect.

[return to list of commands](#)

ipadr

Queries the IP address assigned to the modem by the wireless network.

This is a read only command.

Example:

1. Query the current IP address of the modem

```
cmd ipadr
96.2.1.161
OK
```

[return to list of commands](#)

8.1.9 “L” Commands

landhcp ddd n (Firmware version R1.3.x)

Configures the LAN dynamic host configuration protocol (DHCP) server settings, specifically the starting IP address to assign to DHCP users and the maximum number of DHCP users on the LAN.

ddd = 0 to 255 Last number of starting DHCP IP address in decimal (default: **20**)

n = 1 to 254 Maximum number of DHCP clients (default: **10**)

The starting DHCP IP address (default: 192.168.1.20) is `aaa.bbb.ccc.ddd` where `aaa.bbb.ccc` is the bitwise AND result of the LAN IP address and the LAN netmask, and `ddd` is specified in this command. The ending DHCP IP address (default: 192.168.1.29) is `aaa.bbb.ccc.eee` where `aaa.bbb.ccc` is the bitwise AND result of the LAN IP address and the LAN netmask, and `eee = ddd + n - 1`.

A `cmd apply` followed by a `cmd save` are required for this command to take effect.

Examples:

1. Assign DHCP users with IP addresses starting at 192.168.1.20 to a maximum of 15 users.

```
cmd landhcp 20 15
OK
```

2. When the LAN IP is set to 192.168.10.1, assign DHCP users with IP addresses starting at 192.168.10.20 to a maximum of 10 users.

```
cmd lanip 192.168.10.1
OK
cmd landhcp 20 10
OK
```

3. Query current DHCP range and number of users

```
cmd landhcp
cmd landhcp 20 10
OK
```

See also: `landns`, `lanip`, `lannetmask`, `lanrepip`

<http://en.wikipedia.org/wiki/DHCP>

[return to list of commands](#)

lanip iii.iii.iii.iii

Sets the IP address of the modem on the LAN.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 LAN IP address of the modem in decimal (default: **192.168.1.1**)

Note: Special care must be taken when configuring this command, if an improperly configured `lanip` IP address is entered the ethernet port can be rendered unusable. Before configuring this command it is advisable to make sure that a command console is available via the serial port, or the IP address is known and remote telnet is enabled to allow the modem to be accessed wirelessly.

The current LAN IP address can be queried by using **lanip**.

Examples:

1. Set the LAN IP address of the modem to **192.168.10.1**

```
cmd lanip 192.168.10.1
OK
```

2. Query the LAN IP address of the modem

```
cmd lanip
cmd lanip 192.168.1.1
OK
```

A cmd apply followed by a cmd save and a **power cycle** are required for this command to take effect. After taking effect, local Telnet should be accessed via the IP address specified in the command.

See also: landhcp, landns, lannetmask, lanrepip

[return to list of commands](#)

lannetmask iii.iii.iii.iii

Sets the netmask of the modem on the LAN.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 LAN netmask of the modem in decimal (default: **255.255.255.0**)

Note: Special care must be taken when configuring this command, if an improperly configured lannetmask IP address is entered the ethernet port can be rendered unusable. Before configuring this command it is advisable to make sure that a command console is available via the serial port, or the IP address is known and remote telnet is enabled to allow the modem to be accessed wirelessly. The current LAN netmask can be queried by using **lannetmask**.

Examples:

1. Set the LAN netmask of the modem to **255.255.0.0**

```
cmd lannetmask 255.255.0.0
OK
```

2. Query the LAN netmask of the modem

```
cmd lannetmask
cmd lannetmask 255.255.255.0
OK
```

A cmd apply followed by a cmd save and a **power cycle** are required for this command to take.

See also: landhcp, landns, lanip, lanrepip

<http://en.wikipedia.org/wiki/Netmask>

[return to list of commands](#)

lanrepip iii.iii.iii.iii

Sets the IP address of the local server connected to the modem's LAN that will receive local reports.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 LAN IP address to receive local reports in decimal (default: **192.168.1.20**)

This command requires a **cmd save** and **power cycle** to take effect.

The LAN IP address of the server currently used to receive local reports can be queried by using **lanrepip**.

Examples:

1. Set the local reporting LAN IP address to **192.168.1.21**

```
cmd lanrepip 192.168.1.21
OK
```

2. Query the LAN IP address to which local reports will be sent

```
cmd lanrepip
cmd lanrepip 192.168.1.20
OK
```

A **cmd save** is required for this command to take effect.

See also: **landhcp**, **landns**, **lanip**, **lannetmask**

[return to list of commands](#)

8.1.10 “M” Commands

mip n

Sets the Mobile IP operation of the modem. This command is only applicable to CDMA/EV-DO devices.

n = 0 simple IP only (mobile IP disable)

n = 1 mobile IP preferred (default)

n = 2 mobile IP only

The current mobile IP can be queried by using the mip without parameters.

Examples:

cmd mip 1 sets the MIP option to be MIP preferred

cmd mip returns the current MIP value

A cmd save is required for this command to take effect.

http://en.wikipedia.org/wiki/Mobile_IP

[return to list of commands](#)

modbusadd

This command when used without arguments is used to display all the entries in the MODBUS slave gateway list.

Example:

cmd modbusadd displays the MODBUS list

modbusadd id nnn.nnn.nnn.nnn

This command is used when the modem is being used as a MODBUS SLAVE device.

Adds a MODBUS TCP Slave. The listening port for TCP slaves is the port number configured using modbusport.

id = 1 to 247 MODBUS ID

nnn.nnn.nnn.nnn = 1.0.0.0 to 255.255.255.255 MODBUS slave IP address (IP address of MODBUS devices connected to the modem's ethernet port)

modbusadd id Serial m

Adds a MODBUS Serial Slave (Added in firmware version R1.2.1)

id = 1 to 247 MODBUS ID

m = a or A ASCII transmission mode

m = r or R RTU transmission mode

Note1: The MODBUS slave gateway will use the serial port settings configured using the port command for all serial slaves.

Note2: For MODBUS RTU configuration to function properly **d = 8** must be entered for the port command. (This configuration is in accordance with the MODBUS specification)

Note3: modbusadd will return "Invalid IP address (Sx)" followed by an "OK" if modbusadd is configured with parameters missing or incorrect parameters. Ensure that the modbusadd parameters match those from the above list.

Note4: All MODBUS serial slave devices connected to a serial bus configuration such as RS485 must use the same transmission mode. (This configuration is in accordance with the MODBUS specification)

modbusadd id n p d s m w

Adds a MODBUS Serial Slave (Previously in firmware version R1.2.0 and below)

id = 1 to 247 MODBUS ID

n = 1200 1200 Baud

n = 2400 2400 Baud

n = 4800 4800 Baud

n = 9600 9600 Baud

n = 19200 19200 Baud

n = 38400 38400 Baud

n = 57600 57600 Baud

n = 115200 115200 Baud

p = n or N no parity

p = e or E even parity

p = o or O odd parity

d = 7 or 8 data bits

s = 1 or 2 stop bits

m = a or A ASCII transmission mode

m = r or R RTU transmission mode

w = f or F flow control, leave empty for no flow control

Note1: For MODBUS RTU configuration to function properly **d = 8** must be entered. (This configuration is in accordance with the MODBUS specification)

Note2: modbusadd will return ERROR if modbusadd is configured with parameters missing or incorrect parameters. Ensure that the modbusadd parameters match those from the above list.

Note3: If the baud rate of the serial port is changed from the serial console using the **modbusadd** command, and the baud rate of the host application is changed to match the new configuration after implementing this command, then the serial console should still be able to accept commands. This functionality is only available if the connection mode of the modem is **mode = 1** or **mode = 2** before issuing **modbusadd**. After changing the serial port configuration, a cmd save and a power cycle is highly recommended.

modbusadd backward compatibility

Starting in firmware version R1.2.1, the newer form **modbusadd id Serial m** used with the **port** command is the preferred way for adding new serial slaves.

Starting in firmware version R1.2.1, the form **modbusadd id n p d s m w** is provided for backward compatibility only. This form uses the **n p d s w** parameters with **port** to set the serial port settings and the **id m** parameters with **modbusadd id Serial m**. The form **modbusadd id n p d s m w** is only used for setting and will not be queried back in the same form. The changes that come into effect by using this form can be queried by using the **modbusadd** and the **port** commands; using **modbusadd** without parameters will always display commands in the form **modbusadd id Serial m**.

Example:

```
# cmd modbusadd 5 9600 e 7 2 a
OK
# cmd port
cmd port 9600 7 E 2 0
OK
# cmd modbusadd
cmd modbusadd 5 Serial A
OK
```

When the modem is upgraded to firmware version R1.2.1 and has been previously set to **cmd mode 6**, modem configurations containing the form **modbusadd id n p d s m w** will automatically be converted upon power cycle to **modbusadd id Serial m** and **port n d p s f** (where f = 2 if w = f or F, and f = 0 in all other cases).

After upgrading to firmware version R1.2.1, to convert from **modbusadd id n p d s m w** to **modbusadd id Serial m** when another mode has been previously configured, enter **cmd mode 6**, **cmd save**, and power cycle. To restore the modem to its previous mode, enter **cmd mode n** (where n is the previous mode), **cmd save**, and power cycle.

modbusadd id

Adds MODBUS self slave - only one is permitted.
id = 1 to 247 MODBUS ID

Examples:

1. add TCP slave with ID 1 and IP 192.168.100.122

```
cmd modbusadd 1 192.168.100.122
```

2. add itself as a MODBUS slave with ID = 3

```
cmd modbusadd 3
```

3. Add serial slave with baud 115200, no parity, 8 data bits, 1 stop bit and as ASCII transmission mode

```
cmd port 115200 8 N 1 0
cmd modbusadd 17 Serial A
```

4. Display the list of modbus devices.

TCP slave device with ID = 247, self slave device with ID = 10, serial slave device (ASCII transmission mode) with ID = 155

```
cmd modbusadd
(192.168.1.20,247)
(Localhost,10)
(Serial.A,155)
```

A **cmd save** is required for this command to take effect.

[return to list of commands](#)

modbusctm130 n

Enables MODBUS backward compatibility with the CTM13x by using MODBUS RTU encapsulated in UDP packets for messages transmitted/received over-the-air.

The CTM13x modems only use MODBUS RTU over UDP as the over-the-air protocol for communicating between other modems configured as MODBUS master and slave gateways.

n = 0 use MODBUS TCP for over-the-air communications (default)

n = 1 use MODBUS RTU over UDP for over-the-air communications

A **cmd save**, and a **power cycle** are required before the modem is configured to use the specified MODBUS over-the-air protocol.

Examples:

cmd modbusctm130 1 Set MODBUS gateway to send/receive MODBUS RTU over UDP messages

cmd modbusctm130 Query the currently configured MODBUS over-the-air protocol

A cmd save is required for this command to take effect.

[return to list of commands](#)

modbusdel n

Deletes an entry or all entries from the MODBUS list.

n = 0 deletes all MODBUS entries

n = 1 to 247 MODBUS ID entry

Examples:

cmd modbusdel 1 delete the entry with MODBUS ID 1

cmd modbusdel 0 delete all entries in the MODBUS list

A cmd save is required for this command to take effect.

[return to list of commands](#)

modbusgw

Use this to initiate the MODBUS gateway manually from the serial port console. **In firmware version R1.3.0 and above, "cmd freeconsole" must be run first before using this command from the SSH/Telnet console.**

Use cmd mode 6 to put the modem in permanent MODBUS mode (enter MODBUS automatically after a power cycle).

Example:

1. Initiate the MODBUS gateway manually

```
cmd freeconsole
Killed
OK
cmd modbusgw
OK
```

See also: freesonsole, modbusadd, modbusctm130, modbusdel, modbusidmap, modbusmode, modbusport

[return to list of commands](#)

modbusidmap n a.a.a.a p

This command is only configured when using the modem as a MASTER GATEWAY (**cmd modbusmode 1** or **cmd modbusmode 2**). This command returns ERROR if the modem is configured as a SLAVE GATEWAY (**cmd modbusmode 0**).

This command sets up the MODBUS ID to modem IP for each remote MODBUS slave device (i.e. another CTM15x modem configured as a MODBUS slave gateway).

The default for all entries is n 0.0.0.0. Use n 0.0.0.0 0 to erase an entry. Use 0 0.0.0.0 to erase all entries.

One entry is added at a time with a limit of up to 247 entries (each entry requires a unique ID).

To change an entry, one must first erase it then enter the changed IP address and port number.

n = 1 to 247 MODBUS ID, in decimal

a.a.a.a = 0.0.0.0 to 255.255.255.255 MODBUS slave modem IP address, in decimal(wireless modem IP address)

p = 0 to 65535 Port that the slave modem will be listening on, in decimal

Examples:

1. Set the MODBUS master gateway to forward messages designated for the slave device with ID 1 to the modem at 123.1.2.3, port 502


```
cmd modbusidmap 1 123.1.2.3 502
OK
```

2. Clear the MODBUS ID to modem IP entry for slave ID 1

```
cmd modbusidmap 1 0.0.0.0 0
OK
```

3. Change slave ID 1 entry to the modem with an IP of 123.1.2.4

```
cmd modbusidmap 1 123.1.2.4 502
OK
```

4. Clear all MODBUS ID to modem IP entries

```
cmd modbusidmap 0 0.0.0.0
OK
```

5. Query all MODBUS ID to modem IP entries

```
cmd modbusidmap
OK
```

A `cmd save` is required for this command to take effect.

See also: `modbusctm130`, `modbusmode`

[return to list of commands](#)

modbusmode n

Sets the specified MODBUS gateway mode of the modem, specifically, the transmission mode between the modem configured as the serial master gateway and the MODBUS serial device connected to the modem.

n = 0 slave gateway (default)

n = 1 RTU master gateway

n = 2 ASCII master gateway

A `cmd mode 6`, `cmd save`, and a **power cycle** are required before the modem is fully configured in a MODBUS mode.

Examples:

1. Set modem to be a MODBUS serial RTU master gateway

```
cmd modbusmode 1
OK
```

2. Query the currently configured MODBUS gateway mode

```
cmd modbusmode
cmd modbusmode 1
OK
```

A cmd save is required for this command to take effect.

See also: mode

[return to list of commands](#)

modbusport xxxxx

Sets the listening port number for the MODBUS server and the listening port number for MODBUS TCP slaves.

Default is 502.

xxxxx = 1 to 65535 MODBUS server port number

The current MODBUS port number can be queried by entering the **modbusport** command without parameters.

Note:

If the modem is currently in MODBUS mode and any other LAN or firewall configuration commands are set after issuing the **modbusport** command, then both a cmd save and a power cycle are required to resume proper MODBUS operation.

Examples:

1. Set the MODBUS port to **12345**

```
cmd modbusport 12345
OK
```

2. Query the existing MODBUS port

```
cmd modbusport
cmd modbusport 502
OK
```

A cmd save and power cycle are required for this command to take effect.

See also: modbusadd, modbusdel, modbusctm130, modbusidmap, modbusmode, mode

[return to list of commands](#)

mode n

Sets the required connection mode of the modem.

n = 1 manual connection

n = 2 auto connect to the network (default)

n = 3 auto connect to the network and go directly into PPP mode (only supported on firmware version R1.2.x and earlier)

n = 4 auto connect to both the network and the PAD host interface

n = 5 auto connect to the network and serial LCD (future)

n = 6 auto connect to both the network and the MODBUS host interface

n = 8 auto connect to both the network and the Elmscan diagnostic tool for OBD II

n = 9 auto connect to both the network and the magnetic swipe card reader

n = 10 auto connect to both the network and the WPAN Gateway

n = 12 auto connect to both the network and the Chlorobyte Salt Spreader interface

n = 13 configure the serial port for connection to an external GPS receiver, see [gpsparam](#) for details) (only supported on firmware version R1.3.0)

n = 20 configure the serial port for direct input of LoopBack WPAN PAD client(device type 10) (only supported on firmware version R1.3.0)

For all mode settings except n = 1 or 2, a [cmd save](#) and a **power cycle** are required before the mode takes effect.

To escape out of the mode (to get a command prompt – console) do the following:

mode = 3 – type EXIT, type cmd port nnnn (where nnnn is the current baud rate)

mode = 4 – type ++, wait 3 seconds, type cmd port nnnn (where nnnn is the current baud rate); Refer to [padesc](#) and [padesc](#) for escape sequence

mode = 8 – change hyper terminal baud rate to 9600, type EXIT, change hyper terminal baud rate to nnnn, type [cmd port](#) nnnn (where nnnn is the currently set baud rate)

The current mode setting can be queried by using the mode without parameters.

Examples:

1. Set the mode to auto connect

```
cmd mode 2
OK
```

2. Query the current connection mode of the modem

```
cmd mode
```

```
cmd mode 2
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

modemdevice [/dev/ttyUSBn]

Configure the modem serial port device. Default is **/dev/ttyUSB0**.

This command requires a cmd save and modem power cycle to take effect.

Example:

```
cmd modemdevice /dev/ttyUSB1
OK
```

```
cmd modemdevice
cmd modemdevice /dev/ttyUSB1
OK
```

[return to list of commands](#)

modemid <string>

Assigns a user configurable ID to the modem.

If no ID is given then the modem's 11-digit decimal ESN (if available) will be used.

If less than 11 characters is entered, trailing 0's will be automatically inserted in message type 112.

Examples:

cmd modemid CAR1234 sets the modem ID to <CAR1234>

cmd modemid returns the currently configured modem ID

A cmd save is required for this command to take effect.

[return to list of commands](#)

modemmode n

Configures the modem for "half bridge mode"

This command is used to provide the connected device, such as a laptop the same IP address that is assigned to the modem.

This command is useful for application software that requires a specific IP address to operate properly.

n = 0 modem mode off (default)

n = 1 modem mode on

The current modem mode can be queried by entering **modemmode** without parameters.

For **modemmode** to take effect, a **cmd save** and a **power cycle** is required.

Notes (all versions):

- In modem mode, remote web interface, remote ssh/telnet on the modem are not available.
- This feature should not be used with other modem features.

Notes (applicable to OpenCTM firmware only):

- For a static IP configuration, the client computer's Ethernet settings must be configured to use the WAN IP address, Gateway IP address, and DNS addresses of the phone card/module. If the modem has an active wireless connection, obtain these addresses from output displayed by using **cmd syslog**.
- For a dynamic IP configuration, the modem must also be configured using [modemmodedhcp](#) and [clientmac](#) commands in addition to using **cmd modemmode**.
- For modems configured in half bridge mode and using later model Sierra Wireless data devices that support A-GPS (USB598, USB597), A-GPS support is not available and must be disabled. Refer to [agpspde](#) for details on disabling the A-GPS feature.

Notes (applicable to Snapgear firmware only):

- This feature also requires a phone card/module that is configured to acquire a static IP address from the wireless carrier.
- **modemmode** does not support WAN IP addresses that have either a **xxx.xxx.xxx.0** or **xxx.xxx.xxx.255** as part of their IP address
- On the connected device, a DHCP release, a DHCP renew, and a power cycle may need to be performed for it to acquire the modem's IP address.

Examples:

cmd modemmode 1 enable modem mode

cmd modemmode queries the current modem mode setting

See also: [agpspde](#), [clientmac](#), [modemmodedhcp](#)

[return to list of commands](#)

modemmodedhcp n

Configures the modem to use DHCP when configured for "half bridge mode"

DHCP with modem mode should only be enabled when the modem does not have a static IP address from the wireless carrier.

n = 0 modem mode will not use DHCP (default)

n = 1 modem mode will use DHCP

The current modem mode DHCP setting can be queried by entering **modemmodedhcp** without parameters.

For **modemmodedhcp** to take effect, a **cmd save** and a **power cycle** is required.

Note:

- If **modemmodedhcp** is enabled, the client computer mac address must also be configured using **cmd clientmac**
- The client computer must be configured with the following Ethernet settings:
 - DHCP to obtain an IP address automatically
 - Manually specified DNS server addresses. If the modem has an active wireless connection, obtain these addresses from output displayed by using **cmd syslog**

Examples:

cmd modemmodedhcp 1 use DHCP with modem mode

cmd modemmodedhcp queries the current modem mode DHCP setting

See also: [clientmac](#), [modemmode](#)

[return to list of commands](#)

8.1.11 “N” Commands

netwd t n

Sets the network watchdog feature.

This feature is used to listen for incoming data traffic to make sure there is network connectivity.

If no data is received within the watchdog timer time out period ($t * n$), the modem will disconnect from the network and reconnect to the network. If the watchdog timer expires a second time after attempting to reconnect unsuccessfully the first time (no data received), the modem will be power cycled.

The user will define the time interval (t) the command will use to monitor network activity. The user will also define the number of times the command needs to see consecutive data packets (n) before the watchdog timer expires and the command resets the network connection/device. If data is received within this interval, the timer interval and number of times will be reset.

t = 0 disable (default)

t = 1 to 65535 time to wait for incoming data (seconds)

n = 0 to 65535 number of times the timer needs to expire before disconnecting and reconnecting to the network

A cmd save and **power cycle** is required before this setting takes effect.

Typically, **netwd** is used in conjunction with the ping command. The ping command will generate the network traffic that **netwd** will watch for.

Examples:

1. Set the timer to 10 seconds and check 6 times.

```
cmd netwd 10 6
OK
```

In the above example, the command will look for incoming traffic from the network at **10** seconds intervals. If no data traffic is detected for **6** consecutive intervals **6 x 10 = 60** sec. the command will disconnect and reconnect to the network. If a reconnect does not resolve the issue (approx 10 seconds reconnect time) the command will cycle the modem power completely (approx 50 seconds reconnect time) after an additional 6 intervals of no data.

If data is received, the command will not reset the network connection and the device will operate without interruption.

2. Query the current netwd configuration

```
cmd netwd
cmd netwd 10 6
OK
```

See also: ping

[return to list of commands](#)

networktime n

Set priority of cellular network time as an external system time synchronization source. This feature works with Sierra Wireless data devices/modules only.

n = 0 Disabled

n = 1-3 Priority relative to other external system time synchronization sources with 1 = highest (default: 2)
A **cmd save** and a **power cycle** are required for this command to take effect.

Example:

1. Set cellular network time as highest priority relative to other external time synchronization sources:

```
cmd networktime 1
OK
```

See also: [gpstime](#), [ntpserver](#), [ntptime](#), [timesync](#)

[return to list of commands](#)

nmeamode n

Sets the NMEA 0183 version that applies to the GPS message format for GPGLL and GPRMC sentences. NMEA 0183 v3.0 standard supports an additional field for the Mode Indicator.

n = 0 use NMEA 0183 v2.0 messages (default)

n = 1 use NMEA 0183 v3.0 messages

Examples:

1. Enable NMEA 0183 v3.0 message format

```
cmd nmeamode 1
OK
```

2. Query current NMEA 0183 version

```
cmd nmeamode
cmd nmeamode 0
OK
```

[return to list of commands](#)

ntpserver url

Set the network time protocol (NTP) server used by the modem's built-in NTP client for external system time synchronization. Requires a non-zero priority for [ntptime](#) and a modem to be configured in a mode other than manual connection mode (not in **cmd mode 1**).

url = URL/IP of the NTP server (default: **0.openwrt.pool.ntp.org**)

A **cmd save** and a **power cycle** are required for this command to take effect.

Example:

1. Use an alternate NTP server:

```
cmd ntpserver 1.openwrt.pool.ntp.org
OK
```

See also: gpstime, mode, networktime, ntptime, timesync

[return to list of commands](#)

ntptime n

Set priority of the built-in network time protocol (NTP) client as an external system time synchronization source. Requires a valid NTP server URL/IP to be configured using `ntpserver` and a modem to be configured in a mode other than manual connection mode (not in **cmd mode 1**).

n = 0 Disabled

n = 1-3 Priority relative to other external system time synchronization sources with 1 = highest (default: 3)

A **cmd save** and a **power cycle** are required for this command to take effect.

Example:

1. Set NTP time as highest priority relative to other external time synchronization sources:

```
cmd ntptime 1
OK
```

See also: gpstime, mode, networktime, ntpserver, timesync

[return to list of commands](#)

8.1.12 “O” Commands

obdcond n b t mt [trig1 ... trig4]

Sets the condition(s) that will trigger an OBD report.

The conditional operator is used to indicate how all following parameters will be used to determine if a report is triggered.

n = 1 to 8 OBD trigger number

b = 0 conditional operator for all following parameters: **Off**

b = 1 conditional operator for all following parameters: **AND**

b = 2 conditional operator for all following parameters: **OR**

t = 0 timeout disabled

t = 1 to 65535 timeout in seconds

mt = 0 to 65535 maximum reporting rate in seconds (minimum time between reports)

Optional parameters:

trigx trigger parameter x enclosed in single quotes and without spaces in between, in the form '**pid^val**' where:

pid = p1 to pb engine parameters as per OBD2/J1939 Parameters Table except for **p4** and **id**

^ - > trigger using greater than operator

^ - = trigger using equal to operator

^ - < trigger using less than operator

val engine parameter value that sets off the trigger, in decimal nnnn.nn (refer to OBD2/J1939 Parameters Table for allowable range of values)

Each OBD trigger condition may be configured with up to 4 trigger parameters.

The current parameter(s) for a trigger condition can be queried by using the **obdcond n** command. If **n** is blank, all OBD trigger conditions will be queried.

Examples of OBD trigger parameters:

'**p1>0**' trigger is set off when p1 (vehicle speed) is greater than 0 km/h

'**p2=5000**' trigger is set off when p2 (engine RPM) is equal to 5000 RPM

'**p8<200.75**' trigger is set off when p8 (engine coolant temperature) is less than 200.75°C

Examples:

1. Set OBD trigger #1 to send a report every **60** seconds

```
cmd obdcond 1 1 60
OK
```

2. Set OBD trigger #2 to send a report every **30** seconds **AND** P1 (vehicle speed) is equal to **0.0** km/h with a maximum report rate of one every **5** seconds

```
cmd obdcond 2 1 30 5 'p1=0.0'
OK
```

3. Set OBD trigger #3 to send a report every **60** seconds **OR** P1 (vehicle speed) is greater than **0** km/h **OR** P2 (engine RPM) is greater than **2000** with a maximum report rate of one every **5** seconds

```
cmd obdcond 3 2 60 5 'p1>0' 'p2>2000'
OK
```

4. Set OBD trigger #4 to send a report **only** when P1 (vehicle speed) is less than **10** km/h **AND** P2 (engine RPM) is equal to **0** RPM **AND** P7 (calculated engine load value) is equal to **0** percent **AND** P8 (engine coolant temperature) is **-40**°C with a maximum report rate of one every **15** seconds

```
cmd obdcond 4 1 0 15 'p1<10.00' 'p2=0.00' 'p7=0.00' 'p8=-40.00'  
OK
```

5. Query all the trigger conditions used for OBD reports

```
cmd obdcond  
cmd obdcond 2 1 30 5 'p1=0.0'  
cmd obdcond 3 2 60 5 'p1>0' 'p2>2000'  
OK
```

6. Query the parameters for OBD trigger condition #3

```
cmd obdcond 3  
cmd obdcond 3 2 60 5 'p1>0' 'p2>2000'  
OK
```

A `cmd save` is required for this command to take effect.

See also: OBD2/J1939 Parameters Table, `obdreport`, `pobda-pobdd`

[return to list of commands](#)

obddata

Displays the current OBD engine parameters and corresponding values obtained from the OBDII transmitter and the time since they were last updated.

If no engine parameters have been obtained yet, the command returns **ERROR**

This command is read-only.

Example:

cmd obddata displays OBD engine parameters and time since they were last updated

```
# cmd obddata  
These OBD engine parameters were updated 001 seconds ago  
Timestamp : Thu Jan 1 00:14:48 1970  
p1=131,p2=0,p3=40,p4=AGV-SIMULATOR 1.5  
p5=0,p6=0,p7=16,p8=55  
p9=384,p10=128,p12=80,p13=81.92  
id=0013A200403078CF,pa=0,pb=0  
OK
```

[return to list of commands](#)

obdreport [n] [r]

This command sets the report to be used for a OBD triggered report.

n = 1 to 8 number of the OBD trigger condition

r = 1 to 999 report number

r = 0 disables the report

obdreport requires the modem to be listening for traffic from the WPAN gateway, this requires cmd mode 10 to be configured.

Example:

1. Set report #2 for OBD triggered report #1.

```
cmd obdreport 1 2
OK
```

A cmd save is required for this command to take effect.

See also: mode, obdcond, repaddmes, repdelmes, repemail, replocport, repremip, repremport, repsms, reptype

[return to list of commands](#)

obdsp n

Sets the protocol used by the OBDII transmitter.

n = 0 Automatic

n = 1 SAE J1850 PWM

n = 2 SAE J1850 VPW

n = 3 ISO 9141-2

n = 4 ISO 14230-4 KWP (slow)

n = 5 ISO 14230-4 KWP (fast)

n = 6 ISO 15765-4 CAN (11 bit ID, 500 Kbaud)

n = 7 ISO 15765-4 CAN (29 bit ID, 500 Kbaud)

n = 8 ISO 15765-4 CAN (11 bit ID, 250 Kbaud)

n = 9 ISO 15765-4 CAN (29 bit ID, 250 Kbaud)

n = 10 SAE J1939 CAN (29 bit ID, 250 Kbaud)

n = 11 USER1 CAN (11 bit ID, 125 Kbaud)

n = 12 USER2 CAN (11 bit ID, 50 Kbaud)

The current OBDII transmitter protocol can be queried by using the **obdsp** command without parameters. Note that option 0 (Automatic) only replaces OBD2 protocol options 1-9. Some vehicles may exhibit problems with automatic protocol discovery. **obdsp** must specifically be set to match the protocol on those vehicles.

Examples:

1. Set the OBDII transmitter to use the J1939 protocol

```
cmd obdsp 10
OK
```

2. Query the current OBDII transmitter protocol

```
cmd obdsp
cmd obdsp 7
OK
```

A cmd save and a **power cycle** are required for this command to take effect.

[return to list of commands](#)

odometer n

Sets/queries the GPS odometer.

The GPS odometer keeps track of the distance travelled in km by using GPS position data. If **n** is omitted, the current value of the GPS odometer will be queried.

The maximum odometer value is 1999999 km. The odometer will roll over to 0 km when the current odometer value exceeds the maximum.

The GPS odometer is reset to 0 km whenever one of these cases applies:

- (i) **n** is specified as reset
- (ii) **n** is specified as 0
- (iii) cmd factory is issued.

Examples:

1. Reset the GPS odometer value to 0

```
cmd ctm15x
OK
cmd odometer reset
OK
```

2. Reset the GPS odometer value to 0

```
cmd ctm15x
OK
cmd odometer 0
OK
```

3. Set the GPS odometer to 100000 km

```
cmd ctm15x
OK
cmd odometer 100000
OK
```

4. Query the current GPS odometer value in km

```
cmd odometer
1245 KM
OK
```

See also: [ctm15x](#)

[return to list of commands](#)

otasp

This command is used to perform automatic wireless network activation and updates any required network related files that are embedded in the wireless modem.

The modem responds with one or more of the following messages:

- SPL Unlocked
- Authentication key has been exchanged
- Shared secrets data has been updated
- New NAM parameters have been downloaded
- New MDM has been downloaded
- IMSI has been downloaded
- PRL has been downloaded

During updating, if any of the above data is unsuccessful, an OTASP Timeout message will be displayed.

A progress message OTASP Processing will be displayed every 10 seconds.

When the OTASP process has been completed, the OTASP Disconnected message will be displayed.

Example:

1. Initiate automatic wireless network activation

```
cmd otasp
OK
```

[return to list of commands](#)

8.1.13 “P” Commands

pad

Initiates a packet data connection. Use this to initiate a manual PAD connection from the serial port console. **In firmware version R1.3.0 and above, "cmd freeconsole" must be run first before using this command from the SSH/Telnet console.**

Use cmd mode 4 to put the modem in permanent PAD mode (enter PAD automatically after a power cycle).

Example:

1. Initiate a manual PAD packet connection to the wireless network

```
cmd freeconsole
Killed
OK
cmd pad
OK
```

See also: freeconsole, padecho, padesc, padestc, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padclientport xxxxx

Sets the default client PAD port number for use with dialup emulation via UDP mode (**cmd padmode 6**) or dialup emulation via TCP mode (**cmd padmode 7**). Default is 5006.

padclientport is valid for only **cmd padmode 6** or **cmd padmode 7** when the dial command **ATDT** is issued by an external serial device to initiate an outgoing connection.

xxxxx = 0 to 65535 dialup emulation PAD client port number

The current dialup emulation PAD client port number can be queried by entering the **padclientport** command without parameters.

Examples:

1. Set the dialup emulation PAD client port to **5006**

```
cmd padclientport 5006
```

OK

2. Query the existing dialup emulation PAD client port

```
cmd padclientport
cmd padclientport 5006
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padecho n

Sets the PAD echo mode – if echo is enabled then all data sent to the modem on its RS232 port by an external device is echoed back to that device.

n = 0 PAD echo mode: disabled

n = 1 PAD echo mode: enabled (default) The current PAD echo mode can be queried by using the **padecho** command without parameters.

Examples:

1. Disable the PAD echo – characters received on the modem’s RS232 port will not be echoed to the connected device

```
cmd padecho 0
OK
```

2. Query the current PAD echo setting

```
cmd padecho
cmd padecho 1
OK
```

A cmd save is required for this command to take effect.

See also: pad, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padesc <str>

Sets the PAD escape sequence used to return to command line mode.

Default is +++.

When using the escape sequence it is necessary to wait the guard time (padesct) before entering data

Enter only the escape sequence (do not enter any other characters including <CR> or <LF>)

If PAD forwarding time (padfwdt) is set there will be a delay until the escape characters are forwarded.

The guard time (padesct) must also be honored, to allow the modem to escape from PAD mode.

<str> PAD escape sequence, 10 characters maximum, no spaces, case sensitive

The current PAD escape sequence can be queried by using the padesc command without parameters.

Examples:

1. Set the PAD escape sequence to ASCII string **12345**

```
cmd padesc 12345
OK
```

2. Query the current PAD escape string

```
cmd padesc
cmd padesc +++
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesct, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padesct n

Sets the PAD escape guard time.

This is the idle time before and after the PAD escape sequence which must be present for the escape sequence to be recognized.

n = 0 to 65535 PAD escape guard time in seconds. Default is 3 seconds.

NOTE: values greater than **8 seconds** shouldn't be used in **TCP PAD client mode**.

The current PAD escape guard time can be queried by using the padesct command without parameters.

Examples:

1. Set the PAD escape guard time to 4 seconds

```
cmd padesc 4
OK
```

2. Query the current PAD escape guard time

```
cmd padesc
cmd padesc 3
OK
```

A `cmd save` is required for this command to take effect.

See also: `pad`, `padecho`, `padesc`, `padfwdc`, `padfwdl`, `padfwdt`, `padip`, `padmode`, `padport`, `padreset`, `padsvct`

[return to list of commands](#)

padfwdc x r

Sets the PAD forwarding character and to remove the forwarding character before forwarding the packet (optional). Default forwarding character = 13 (ASCII <enter>), default forwarding character removal disabled.

x = 0 `padfwdt` or `padfwdl` will invoke sending the packet

x = 1 to 255 PAD forwarding character representing an ASCII character.

r = 0 Do not remove the forwarding character before forwarding the packet (default)

r = 1 Remove the forwarding character before forwarding the packet

If the **r** parameter is omitted, it is considered to be 0. The current PAD forwarding character can be queried by using the **padfwdc** command without parameters

Examples:

1. sets the PAD forwarding character to ASCII <space> and do not remove the forwarding character before forwarding the packet

```
cmd padfwdc 32 0
OK
```

2. sets the PAD forwarding character to ASCII <space> and remove the forwarding character before forwarding the packet

```
cmd padfwdc 32 1
```

OK

3. Query the current PAD forwarding character

```
cmd padfwdc
cmd padfwdc 32 0
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesc, padescct, padfwdl, padfwdt, padip, padmode, padpfc, padport, padreset, padsvct

[return to list of commands](#)

padfwdl x

Sets the maximum PAD packet length. Default = 40.

If 0 is specified then every character is sent immediately.

x = 0 sent every characters immediately

x = 1 to 1000 maximum PAD packet length

The current PAD packet length can be queried by using the **padfwdl** command without parameters.

Examples:

1. Configure the received RS232 data to be sent in packets of 10 characters each

```
cmd padfwdl 10
OK
```

2. Query the current PAD forwarding length setting

```
cmd padfwdl
cmd padfwdl 10
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesc, padescct, padfwdc, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padfwdt x

Sets the PAD forwarding time. Default = 1 second.

If 0 is specified then this disables the forwarding timer and every character will be sent immediately.

x = 0 to 255 PAD forwarding time in increments of 50ms

The current PAD forwarding time can be queried by using the **padfwdt** command without parameters.

Examples:

1. Set the PAD forwarding time to 2 seconds

```
cmd padfwdt 40
OK
```

2. Query the current PAD forwarding time

```
cmd padfwdt
cmd padfwdt 40
OK
```

A `cmd save` is required for this command to take effect.

See also: `pad`, `padecho`, `padesc`, `padesct`, `padfwdc`, `padfwdl`, `padip`, `padmode`, `padport`, `padreset`, `padsvct`

[return to list of commands](#)

padip iii.iii.iii.iii

Sets the remote PAD IP address.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 remote IP address

Use 0.0.0.0 to set the modem in PAD server mode. Default is 0.0.0.0

The current remote PAD IP address can be queried by using the `padip` command without parameters.

Examples:

1. Set the PAD IP address to **192.168.1.1**

```
cmd padip 192.168.1.1
OK
```

2. Query the current PAD IP address

```
cmd padip
cmd padip 192.168.1.1
OK
```

A `cmd save` is required for this command to take effect.

See also: `pad`, `padecho`, `padesc`, `padescct`, `padfwdc`, `padfwdl`, `padfwdt`, `padmode`, `padport`, `padreset`, `padsvct`

[return to list of commands](#)

padmode x

Sets the PAD mode.

x = 0 start up UDP PAD mode. The modem will revert to server mode once the connection is closed.
(default)

x = 1 start up TCP PAD mode. The modem will revert to server mode once the connection is closed.

x = 2 start up UDP PAD client mode - one session. The modem will revert to command mode once the connection is closed.

x = 3 start up TCP PAD client mode - one session. The modem will revert to command mode once the connection is closed.

x = 4 start up persistent UDP PAD client mode

x = 5 start up persistent TCP PAD client mode

x = 6 start up Dialup Emulation over UDP mode

x = 7 start up Dialup Emulation over TCP mode

The current PAD mode can be queried by entering the **padmode** command without parameters. The connection is closed if one of the following occurs:

padsvct idle timeout expires

padsvct maximum session timeout expires

cmd padreset is executed

The connection is closed by remote host (TCP PAD only)

If `padip` is set to 0.0.0.0, PAD will start in server mode. Otherwise it will start in client mode. Note that for the client modes (2, 3, 4 and 5), `padip` must be different than 0.0.0.0. Note that for dialup emulation modes (6 and 7), `padclientport` must be set.

Examples:

1. Set to TCP PAD mode

```
cmd padmode 1
OK
```

2. Query the current PAD mode

```
cmd padmode
cmd padmode 1
OK
```

A cmd save is required for this command to take effect.

See also: pad, padclientport, padecho, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padport, padreset, padsvct

[return to list of commands](#)

padpfc x

Sets the PAD postfix character that is added at the end of each packet. Default = none (disabled)

x = none Disabled. No character is added to the end of a PAD packet.

x = 1 to 255 PAD forwarding character representing an ASCII character.

The current PAD forwarding character can be queried by using the **padpfc** command without parameters

Examples:

1. Set the PAD postfix character to ASCII <LF>

```
cmd padpfc 10
OK
```

2. Query the current PAD postfix character

```
cmd padpfc
cmd padpfc none
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset, padsvct

[return to list of commands](#)

padport xxxxx

Sets the remote PAD port number.

This is the listening port if the modem is in PAD server mode. Default is 5005.

xxxxx = 0 to 65535 remote PAD port number

The current PAD port number can be queried by entering the **padport** command without parameters.

Note:

If the modem is currently in PAD mode and any other LAN or firewall configuration commands are set after issuing the **padport** command, then both a cmd save and a power cycle are required to resume proper PAD operation."

Examples:

1. Set the PAD port to **5005**

```
cmd padport 5005
OK
```

2. Query the existing PAD port

```
cmd padport
cmd padport 5005
OK
```

A cmd save is required for this command to take effect.

See also: pad, padecho, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padmode, padreset, padsvct

[return to list of commands](#)

padreset

Resets the PAD connection.

The actions taken by **padreset** are to drop the PAD connection and to return the modem to server mode. These actions are equivalent to those that occur when the padsvct timer expires.

Examples:

1. Reset the PAD port

```
cmd padreset
OK
```

See also: pad, padecho, padesc, padescct, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padsvct

[return to list of commands](#)

padsvct n [c]

Sets the PAD server connection timeout.

If no data is sent or received within this timeout value, the PAD connection will be dropped and the modem will return to server mode.

If the optional parameter for the maximum PAD connection timer is specified, once the timer expires, the current PAD connection will be dropped regardless of the data connection condition.

The modem will revert to the current PAD mode setting and maintain the PAD session.

n = 0 PAD server connection timeout: disabled

n = 1 to 65535 PAD server connection timeout in seconds. Default is 15 seconds

Optional Parameter:

c = 0 Maximum PAD connection time: disabled (default)

c = 1 to 65535 Maximum PAD connection time in seconds.

The current PAD server connection timeout setting can be queried by entering **padsvct** command without parameters

Examples:

1. Configure the modem to revert to server mode after 10 seconds of data inactivity

```
cmd padsvct 10
OK
```

2. Configure the PAD connection to be dropped after 60 seconds

```
cmd padsvct 15 60
OK
```

3. Query the current padsvct settings

```
cmd padsvct
cmd padsvct 15 0
OK
```

A `cmd save` is required for this command to take effect.

See also: pad, padecho, padesc, padescr, padfwdc, padfwdl, padfwdt, padip, padmode, padport, padreset

[return to list of commands](#)

panicreport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command will set the report(s) to be used for pendant triggered panic reports (PANIC and MPANIC only)

Up to 8 reports can be assigned to the panicreport.

r = 0 disables the report

r = 1 to 999 report number

panicreport requires the modem to be listening for traffic from the WPAN gateway, this requires cmd mode 10 to be configured.

The modem must be configured using the commands wpanadddev and wpanacktype and wpanpanid for **panicreport** to function properly.

Note: panicreport does not support server ACK mode and report type 8 and 9

Example: use report 1 for pendant panic triggered reports

```
cmd panicreport 1
OK
```

A cmd save is required for this command to take effect.

A Pendant panic report is triggered by a panic message received from the pendant. The following message is appended to the report:

\$PPEN, ID, SEQ, MES*CHKSUM

ID - 64 bit unique hex ID of Pendant

SEQ - Packet sequence number

MES - Pendant panic message payload (PANIC or MPANIC)

CHKSUM - NMEA message checksum

Examples:

```
$PPEN,0013A200402CB498,17,PANIC*07
```

```
$PPEN,0013A2004000DBA9,16,MPANIC*33
```

See also: mode, repaddmes, repdelmes, repemail, replocport, repremip, repreport, repsms, reptype

[return to list of commands](#)

panicreportack t

This command will set the modem to wait for a Pendant panic triggered report (PANIC or MPANIC message only) and send the corresponding acknowledgment message.

t = 0 disables **panicreportack** (default)

t = 1 to 65535 time period, in seconds, to wait for the next PANIC or MPANIC message from a pendant and send it an ACK

For **panicreportack** to function properly, the modem must be configured with `wpanacktype` set to server type acknowledgment and with `panicreport`. When **panicreportack** is set, `panicreport` will be disabled to stop triggering the script. This command is meant to be used with custom report triggered scripts via `reportscripts` and is always volatile.

When **panicreportack** is entered without parameters, the command returns the configured time period and the elapsed time, in seconds, since **panicreportack** was set.

Examples:

1. Wait for 60 seconds for a PANIC or MPANIC message and send a pendant an ACK if received

```
cmd panicreportack 60
OK
```

2. Query the time period set for waiting for a PANIC or MPANIC message to ACK, and the current time elapsed since **panicreportack** was set

```
cmd panicreportack
cmd panicreportack 60 15
OK
```

See also: `mode`, `panicreport`, `reportscripts`, `wpanacktype`

[return to list of commands](#)

pendantreport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command sets the report(s) to be used for pendant triggered reports.

Up to 8 reports can be assigned to the `pendantreport`.

r = 0 disables the report

r = 1 to 999 report number

pendantreport requires the modem to be listening for traffic from the WPAN gateway, this requires [cmd mode 10](#) to be configured.

The modem must be configured using the commands [wpanadddev](#) and [wpanacktype](#) and [wpanpanid](#) for **pendantreport** to function properly.

Example: use report 1 for pendant triggered reports

```
cmd pendantreport 1
OK
```

A cmd save is required for this command to take effect.

Pendant report is triggered by any message received from the pendant. The following message is appended to the report:

\$PPEN,ID,SEQ,MES*CHKSUM

ID - 64 bit unique hex ID of Pendant

SEQ - Packet sequence number

MES - Pendant message payload

CHKSUM - NMEA message checksum

Example:

```
$PPEN,0013A200402CB498,17,PANIC*07
```

See also: mode, repaddmes, repdelmes, repemail, replocport, repremip, repremport, repsms, reptype

[return to list of commands](#)

ping n [iii.iii.iii.iii or <website name>]

Configures the modem to ping a specific IP address or website periodically.

This feature is similar to ppp keep alive.

n = 0 disables ping

n = 1 to 65535 number of seconds between pings

iii.iii.iii.iii IP address of the site to ping, IP Address must be in the range 0 to 255 for each value of **iii**, If values outside this range are entered, it will be interpreted as a URL

<website name> website to ping

The current ping setting can be queried by using the ping command without parameters.

Examples:

1. ping www.google.ca every 10 seconds

```
cmd ping 10 www.google.ca
OK
```

2. ping 66.102.7.147 every 15 seconds

```
cmd ping 15 66.102.7.147
OK
```

3. Disable ping

```
cmd ping 0 0.0.0.0
OK
```

4. Queries the modem's ping setting

```
cmd ping
cmd ping 15 66.102.7.147
OK
```

See also: netwd

[return to list of commands](#)

pobdx n1 [n2] [n3] [n4]

Configures the engine - vehicle diagnostic report messages.

Maximum of 4 report messages.

Maximum of 4 parameters can be configured for each report message.

x = a, b, c, d

n1 (n2, n3, n4 are optional parameters) = engine parameters as per table

Examples:

cmd pobda p1 reports vehicle speed

cmd pobdb p2 p12 p25 reports engine speed, intake air temperature and total engine hours

cmd pobdc pa pb reports calculated peak acceleration and calculated peak deceleration

cmd pobdd p20 reports distance travelled since diagnostic trouble codes cleared

A cmd save is required for this command to take effect.

[return to list of commands](#)

port n d p s f

Configures the modem's serial port baud rate and data format.

After implementing this command it will be necessary to change the baud rate of the host application to match the new configuration.

n = 1200 1200 Baud

n = 2400 2400 Baud

n = 4800 4800 Baud

n = 9600 9600 Baud

n = 19200 19200 Baud

n = 38400 38400 Baud

n = 57600 57600 Baud

n = 115200 115200 Baud (default)

d = 5,6,7 or 8 number of data bits (d=8, default)

p = n or N no parity (default)

p = e or E even parity

p = o or O odd parity

s = 1 or 2 number of stop bits (s=1, default)

f = 0 no flow control (default)

f = 1 software flow control

f = 2 hardware flow control

The current port setting can be queried by entering the **port** command without parameters.

Examples:

cmd port 115200 8 n 1 2 baud rate=115200bps, 8 data bits, no parity, 1 stop bit and hardware flow control

cmd port returns the current port value

Note1: For MODBUS Serial Master Gateway there are 2 options only for the data bit configuration:

- 7 and 8 for ASCII Mode.
- 8 for RTU-over-UDP Mode.

Note 2: If the baud rate of the serial port is changed from the serial console using the **port** command, and the baud rate of the host application is changed to match the new configuration after implementing this command, then the serial console should still be able to accept commands. This functionality is only available if the connection mode of the modem is **mode = 1** or **mode = 2** before issuing **port**.

A cmd save and a powercycle is required for this command to take effect.

[return to list of commands](#)

ppp

Provide the connected device a **PPP** connection through the **serial** port.

After the modem is powered up, enter the **cmd ppp** command and disconnect from the terminal program.

Use a Windows Dial Up Network (DUN) connection to connect to the modem. Use **#777** as the dial string/phone number for the serial PPP connection.

To escape from this mode and return to the command line, type **EXIT** in the terminal program.

Use cmd mode 3 to put the modem into permanent PPP mode.

When the modem is configured for PPP mode, the IP addresses used in the serial PPP connection will use the same subnet as the modem's Ethernet LAN IP, after configuring using **cmd lanip**, **cmd apply**, **cmd save**, and a **power cycle**. For example, if the modem was configured with a LAN IP of 192.168.6.1, the serial PPP connection will use 192.168.6.200 and 192.168.6.202 as the IP addresses for the serial PPP client and the modem, respectively.

When using cmd mode 3 or **cmd ppp**, the modem's DHCP server IP pool, configured using **landhcp**, must not include the range x.x.x.200 - x.x.x.202.

Example:

1. Start the modem into PPP mode

```
cmd ppp
OK
```

See also: **landhcp**, **lanip**, **mode**

[return to list of commands](#)

pswd n

Sets the password used for wireless network access via simple IP. This is often set to the electronic serial number (ESN) of the modem.

n a maximum of 40-character alpha-numeric username

A save operation is required.

Examples:

cmd pswd 12345678900 sets the password to 12345678900

cmd pswd displays the current password used for wireless network access via simple IP

A **cmd apply** followed by a **cmd save** are required for this command to take effect.

See also: **mip**, **user**

[return to list of commands](#)

pupcond n a

Sets the condition(s) that would trigger a power up report.

The conditional parameter is used to indicate how all following parameters will be used to determine if a report is triggered.

n = 1 to 8 power up condition numbers

a = 0 power up trigger disabled

a = 1 power up trigger enabled

The current power up reporting condition(s) can be queried by entering the pupcond n where n is the condition number.

If n is blank, all power up condition triggers will be queried.

Examples:

cmd pupcond 1 1 enables powerup condition 1

cmd pupcond 2 0 disables powerup condition 2

cmd pupcond queries the conditions to trigger all power up reports

A cmd save is required for this command to take effect.

See also: pupreport

[return to list of commands](#)

pupreport [n] [r]

This command sets the report to be used for power-up triggered reports.

Up to 8 ignition trigger reports can be configured.

n = 1 to 8 power-up trigger condition

r = 1 to 999 report number

r = 0 disables the report

Example:

1. Configure report #2 for power-up trigger condition #1.

```
cmd pupreport 1 2
OK
```

A cmd save is required for this command to take effect.

See also: pupcond, repaddmes, repdelmes, repemail, replocport, repremip, repremport, repsms, reptype

[return to list of commands](#)

pwrmode n

Controls the modem's power mode.

n = 1 puts the modem in shutdown mode - it can be woken up either by a power cycle, an input alarm event if configured, or a configured periodic wakeup, see **pwrwoe**.

n = 2 will power cycle the modem immediately

This command is immediate and does not require a save operation.

Example:

cmd pwrmode 2 this command will power cycle the modem

[return to list of commands](#)

pwrsdwn a dddd

Places the modem into shutdown mode (blinking power LED) based on the state of the modem's standby signal (ignition).

The ignition state is controlled by the "white" wire of the 3 wire power connection to the modem.

To disable any ignition sense capability connect the "white" wire to the + Voltage "Red" wire.

Default is **pwrsdwn 1 10** (modem will switch off based on the standby (ignition) signal state changing with a 10 second delay before entering shutdown mode).

a = 0 disables the standby signal (ignition) event qualifier

a = 1 enables the standby signal (ignition) event qualifier (default)

dddd = 10 to 65535 the delay time in seconds after the standby signal event changing state that the modem will go into power shutdown mode.

The current configuration can be queried by using the **pwrsdwn** without parameters.

Examples:

cmd pwrstdwn 1 3600 this will cause the modem to power down when the standby signal (ignition) has been inactive for 1 hour. The modem will power back up when the standby signal becomes active with no delay.

cmd pwrstdwn returns the current settings of enable/disable and delay time
A cmd save is required for this command to take effect.

[return to list of commands](#)

pwrvcct vv.v t

Controls the supply voltage below which the modem will automatically go into shutdown mode (blinking power LED). This command is useful for battery powered applications where the modem can be put into a very low power consumption mode (shutdown mode) to prevent draining the battery.

vv.v = 9.0 to 25.5 The threshold supply voltage at which the modem will go into shutdown (default = 9.0V, typical for 12V battery operation)

t = 10 to 255 the time in seconds after which the modem will go into shutdown once the supply voltage has gone below the threshold voltage. (default = 10)

Note that this timeout applies for powering the modem back up as well.

The current setting can be queried by entering the **pwrvcct** command without parameters.

Examples:

1. Set the threshold to 20.0 volts with 10 seconds delay – this may be appropriate for a 24 volt battery

```
cmd pwrvcct 20.0 10
OK
```

2. Query the current voltage and time settings

```
cmd pwrvcct
cmd pwrvcct 9.0 10
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

pwrwoe m t1 t2 i

Configures what event will wake the modem up (input alarm event or timer expire) and how long the modem will stay awake after the event.

This is used to have the modem in minimum power mode (< 2 mA) until it is required to communicate over the wireless network.

If it is required to have the modem start its shutdown mode immediately (without waiting for timer **t1** to expire) than use the **pwrmode** command to put the modem into shutdown with immediate effect.

If the standby signal in the **pwrswdn** command is enabled or **on** then this will cause the modem to be on whenever the standby signal is on. The modem will only use the **pwrwoe** parameters when the standby signal is **off** (and after the delay timer has expired). If the standby signal is disabled then the **pwrwoe** parameters will be in effect all the time.

This command can also be used to configure scheduled power cycles without having to put the modem into shutdown.

m = 0 disables the power wake on event operation

m = 1 shutdown

m = 2 shutdown with periodic wakeup when ignition is off

t1 = 0 disables the ON timer (stay on forever – **pwrswdn** can be enabled to shutdown the modem)

t1 = 1 to 65535 the ON time in minutes – the modem will remain on for this time once it has woken up due to an input alarm event, or periodic wakeup (set by parameter **t2**)

t2 = 0 disables the OFF timer (stay in shutdown mode forever or until an input alarm event occurs –or standby signal if enabled in **pwrswdn**).

t2 = 1 to 255 the OFF time in minutes - the time that the modem will stay in shutdown if an input alarm event (or standby signal if enabled in **pwrswdn**) does not occur

t2 = c power cycle the modem immediately once the ON timer expires (only use with **m = 1** and **i = 0**)

i = 0 disables the input event trigger

i = 1 to 6 selects which input going into alarm will trigger wake up

Default configuration is 0 0 10 0 (wake on event disabled). The current configuration can be queried by using the **pwrwoe** without parameters.

Examples:

1. Configure the modem to go into shutdown mode in 5 minutes. An alarm event on input #2 – and only this - will cause it to wake up for 5 minutes then go back into shutdown

```
cmd pwrwoe 1 5 0 2
OK
```

2. Configure the modem to go into shutdown mode in 5 minutes. Every 55 minutes it will wake up and remain on for 5 minutes then go back into shutdown.

```
cmd pwrwoe 1 5 55 0
OK
```

3. Configure the modem to power cycle after 60 minutes.

```
cmd pwrwoe 1 60 c 0
OK
```

4. QUery the current configured parameters for wake on event

```
cmd pwrwoe
cmd pwrwoe 0 0 10 0
OK
```

A `cmd save` is required for this command to take effect.

[return to list of commands](#)

8.1.14 “R” Commands

ratesel n

Sets the required network rate mode (CDMA vs. EV-DO) of the device. This command is not valid for GSM/GPRS/HSPA devices.

Note:

- Prior to using the **cmd ratesel** command, use `cmd mode` to verify that the modem is in manual connection mode=1. Otherwise, use `cmd mode 1` to put the modem in manual connection mode. The **ratesel** command talks directly to the embedded card/module and does not require `cmd save` for the setting to be saved.
- Entering **cmd ratesel** without parameters will return an “ERROR”, this is normal operation.
- **ratesel** is valid for Sierra Wireless CDMA/EV-DO data devices and modules only
- The Sierra Wireless AC580 (EV-DO revision 0, Cardbus device) only supports **ratesel n = 2**

n = 0 1xRTT only

n = 1 EV-DO only

n = 2 Auto Rate Select (hybrid mode) - default

Example:

Set the network rate mode to 1xRTT only

```
cmd ratesel 0
OK
```

[return to list of commands](#)

ratetmr n

Sets the required network rate test timer of the device. This is used to configure the modem to test for an available EV-DO network while it is in a 1xRTT connection.

This command is valid for Sierra Wireless CDMA/EV-DO data devices and modules only.

n = 0 disable the timer (default)

n = 1 to 65535 time in seconds. Note that time in second is an approximate value; the time between periods will be greater than the “n” value set

The current timer setting can be queried by entering the **ratetmr** without parameters.

Examples:

1. During a 1xRTT connection the modem will disconnect approx. every 120 seconds and then reconnect on the EV-DO network if available, otherwise it will reconnect on the 1xRTT network

```
cmd ratetmr 120
OK
```

2. Query the current network rate test timer setting

```
cmd ratetmr
cmd ratetmr 120
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

repaddmes n x [x2][x3][x4]

Adds a message type to a report. 4 messages can be included in a single report. Duplicate messages cannot be included in a report.

Messages will be sent in a report in the same order that they are added.

ULCP header messages will be sent as individual UDP packets – NMEA format messages will be combined into a single UDP packet.

n = 1 to 999 report number

x message type to be added, valid message types must be used - see message list

The messages associated with a single report can be displayed by using the **repaddmes n** command. If **n** is omitted, the messages associated with all configured reports will be displayed.

Examples:

1. Add message type #16 – GPS NMEA GLL – to report #4

```
cmd repaddmes 4 16
OK
```

2. Query messages associated with report #4

```
cmd repaddmes 4
cmd repaddmes 4 80 82 3 30
OK
```

3. Query messages associated with all configured reports

```
cmd repaddmes
cmd repaddmes 1 80 82
cmd repaddmes 4 80 82 3 30
OK
```

A cmd save is required for this command to take effect.

See also: messages, repdelmes, repemail, replocport, repremip, repreport, repsms, reptype

[return to list of commands](#)

repdelmes n x

This command is used to delete a message type (or all messages) from a report.

n = 1 to 999 report number

x message type to be deleted (0 to delete all messages)

Examples:

1. Delete message type #16 from report #1

```
cmd repdelmes 1 16
OK
```

2. Delete all messages from report #4

```
cmd repdelmes 4 0
OK
```

A cmd save is required for this command to take effect.

See also: repaddmes, repemail, replocport, repremip, repreport, repsms, reptype

[return to list of commands](#)

repemail n <email address>

Sets the email address that the report will be sent to (if configured for email using reptype).

The default email address is blank.

Note that an email server is required – see emailsrv.

n = 1 to 999 report number

<email address> = name@domain email address to which the report will be sent

The current email address configured for all reports can be queried by using the **repemail** command without parameters.

Examples:

1. Set the send to email address for report #1

```
cmd repemail 1 me@home.com
OK
```

2. Query the email address for report #1

```
cmd repemail 1
cmd repemail 1 me@home.com
OK
```

3. Query the email address for all reports

```
cmd repemail
cmd repemail 2 me@home.com
OK
```

A cmd save is required for this command to take effect.

See also: repaddmes, repdelmes, replocport, repremip, repreport, repsms, reptype

[return to list of commands](#)

repfiledelivery n t rt username server-path port

where

n - report number (1-999)

t - file upload time period [s] (0-65535) 0=disable upload

rt - file upload retry period if uploads fail (0-65535) 0=disable retries
username - ssh username
server-path - ssh server host:path definition
port - ssh server TCP/IP port number, usually 22

Firmware version R1.3.0 only: To complete file-based reporting configuration, do a **cmd save** and **power cycle** the modem.

Example:

1. Set file delivery for report 1

```
cmd repfiledelivery 1 60 10 report 199.199.199.99:~/reports 4222
OK
```

A cmd save and power cycle is required for this command to take effect.

See also: repfilename, sshkey

[return to list of commands](#)

repfilename n name

Sets the file prefix used for a file-based report.

n = 1 to 999 report number

name file prefix to be used

File reports are named using a concatenation of this prefix, the report number, the modem mac address, and a timestamp (UNIX format). eg. diginput-1-0010A1772797-1267216159

Firmware version R1.3.0 only: To complete file-based reporting configuration, **power cycle** the modem.

Example:

1. Set file name for report 1 to diginput.

```
cmd repfilename 1 diginput
OK
```

A cmd save and power cycle is required for this command to take effect.

See also: repfiledelivery

[return to list of commands](#)

repfilezip c

Enables or disables the ability to compress data files generated by the file-based reporting system using different formats. Data files will be output in a required format with file names ending with the proper file extension.

where

c = 0 compression of data files = disabled (default)

c = 1 compression of data files = enabled GZIP format (.gz)

c = 2 compression of data files = enabled ZIP format (.zip)

The current status of compression of data files generated by the file-based reporting system can be queried by using the **repfilezip** command without parameters.

Firmware version R1.3.0 only: To complete file-based reporting configuration, do a **cmd save** and **power cycle** the modem.

Example:

1. Enable compression of file-based reporting data files using GZIP format.

```
cmd repfilezip 1
OK
```

2. Query the current state of compression of file-based reporting data files.

```
cmd repfilezip
0
OK
```

A cmd save and power cycle is required for this command to take effect.

See also: repfiledelivery, repfilename, sshkey

<http://en.wikipedia.org/wiki/Gzip>

[return to list of commands](#)

replocport n xxxxx

Sets the port number of the local server that the report will be sent to.

Up to 999 reports may be configured.

n = 1 to 999 report number

xxxxx = 0 to 65535 local port number in decimal

The current local port configuration for a report can be queried by entering **replocport n**, where **n** is the port number.

If **n** is omitted, all reports will be queried.

Examples:

1. Report #1 will be sent to local port 5005

```
cmd replocport 1 5005
OK
```

2. Query the local port setting of all reports

```
cmd replocport
cmd replocport 1 7000
OK
```

A **cmd save** is required for this command to take effect.

See also: **repaddmes**, **repedelmes**, **repemail**, **reprempip**, **reprempport**, **repsms**, **reptype**

[return to list of commands](#)

reportscripts n

This command enables custom scripts to be triggered when reports are generated

n = 0 disable custom report triggered scripts (default)

n = 1 enable custom report triggered scripts

A **cmd save** and a **power cycle** are required for this command to take effect.

Custom scripts should be located in the directory **/etc/reports/scripts**, and must be named **"reportN.sh"** where **N** is

N = 1 to 999 for general reports 1 to 999

N = 1020 to 1027 GPS reports 1 to 8

N = 1040 to 1047 I/O reports 1 to 8

Custom scripts must be copied over to the modem via local **scp**.

Examples:

1. Enable custom report triggered scripts

```
cmd reportscripts 1
OK
```

2. Query the current configuration

```
cmd reportscripts
cmd reportscripts 0
OK
```

[return to list of commands](#)

repremip n iii.iii.iii.iii

Sets the IP address of the remote server that the report will be sent to. Up to 999 reports may be configured.

n = 1 to 999 report number

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 remote IP address in decimal

The current IP address for a report can be queried by using the **repremip n** where **n** is the report number. If **n** is omitted, all reports will be queried.

Examples:

1. Report #1 will be sent to remote IP address **123.10.1.101**

```
cmd repremip 1 123.10.1.101
OK
```

2. Query the remote IP address setting of all reports

```
cmd repremip
cmd repremip 1 123.10.1.101
cmd repremip 2 199.99.99.99
OK
```

A cmd save is required for this command to take effect.

See also: repaddmes, repdelmes, repemail, replocport, repreport, repsms, reptype

[return to list of commands](#)

repreport n xxxxx

Sets the IP port number of the remote server that the report will be sent to.

n = 1 to 999 report number

xxxxx = 0 to 65535 remote port number

The current IP port configuration for a report can be queried by using **rempport n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

1. Report #1 will be sent to port **5005** on remote IP address set by **reprempip**

```
cmd remport 1 5005
OK
```

2. Query the remote port setting of all reports

```
cmd report
cmd remport 1 5001
cmd remport 2 5005
OK
```

A **cmd save** is required for this command to take effect.

See also: **repaddmes**, **repedelmes**, **repremail**, **replocport**, **reprempip**, **repsms**, **reptype**

[return to list of commands](#)

repsms n pppppppppp or <email address>

Sets the destination of the report that is sent as an SMS message. Up to 999 reports may be configured. The default SMS destination is blank.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

n = 1 to 999 report number

pppppppppp phone number which the SMS report will be sent to. For long distance calls, a "1" needs to be added in front of the phone number.

<email address> email address which the SMS report will be sent to.

The current SMS destination configured for all reports can be queried by using the **repsms** command without parameters.

Examples:

1. Send report #1 as an SMS message to the specified phone number

```
cmd repsms 1 1234567890
OK
```

2. Send report #2 as an SMS message to the specified email address

```
cmd repsms 2 me@home.com
OK
```

3. Query the SMS destination for report #1

```
cmd repsms 1
cmd repsms 1 1234567890
OK
```

4. Query the SMS phone numbers or email addresses for all reports

```
cmd repsms
cmd repsms 1 1234567890
cmd repsms 2 me@home.com
OK
```

A `cmd save` is required for this command to take effect.

See also: `repaddmes`, `repdelmes`, `repeemail`, `replcport`, `reprempip`, `reprempport`, `reptype`

[return to list of commands](#)

reptype n l r s

Sets the reporting type for local and remote servers.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

n = 1 to 999 report number

l = 0 disables local report (default)

l = 1 asynchronous NMEA or ULCP messages over RS232

l = 2 asynchronous NMEA or ULCP messages with a ULCP header over RS232

l = 3 in-band NMEA or ULCP messages in a UDP Packet over Ethernet

l = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets over Ethernet

l = 5 in-band NMEA or ULCP messages in a TCP Packet over Ethernet

l = 6 file-based reports

r = 0 disables remote report (default)

r = 3 in-band NMEA or ULCP messages in a UDP Packet

r = 4 in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets

r = 5 in-band NMEA or ULCP messages in a TCP Packet
r = 6 email reports
r = 7 SMS reports

s = 0 disables the store and forward of report
s = 1 enables the store and forward of report

Note: For **r = 7** (SMS reports), the total length of the report must not exceed 166 characters including <CR> and <LF>

The current report type configuration for a report can be queried by using **reptype n** where **n** is the report number.

If **n** is omitted, all reports will be queried.

Examples:

1. Send report #4 as a UDP packet over Ethernet and over the wireless link, and will not store reports

```
cmd reptime 4 3 3
OK
```

2. Send report #2 as a UDP packet over Ethernet and as an SMS message to the SMS destination set using the **repsms** command, and will enable the store and forward of reports

```
cmd reptime 2 3 7 1
OK
```

3. Query the reporting methods for all reports

```
cmd reptime
cmd reptime 1 3 0 0
cmd reptime 2 3 0 0
cmd reptime 10 0 6 0
OK
```

A **cmd save** is required for this command to take effect.

See also: **repaddmes**, **repedmes**, **repemail**, **replcport**, **repremp**, **repreport**, **repsms**

[return to list of commands](#)

restore

Restores the configuration to the previously saved version (overwrite any commands not yet saved).

This command has the same effect as a power cycle with regard to the configuration.

Example:

cmd restore

[return to list of commands](#)

rmtmd iii.iii.iii.iii xxxx

Configures the modem to perform a reverse telnet connection to an IP address and port.

The modem tries to connect periodically until a connection is established.

By default this is disabled with IP 0.0.0.0 and port 0.

iii.iii.iii.iii = 0.0.0.0 to 255.255.255.255 remote IP address. 0.0.0.0 = disabled (default)

xxxx = 0 to 65535 remote port number. 0 = disabled (default)

The current state of remote reverse telnet setting can be queried by using the **rmtmd** command without parameters

Examples:

cmd rmtmd 204.123.1.10 5000 sets the IP to **204.123.1.10** and the port to **5000**

cmd rmtmd queries the modem's rmtmd setting

A cmd save is required for this command to take effect.

[return to list of commands](#)

rmtssh n

Enables or disables remote SSH access to the modem.

If enabled, it will be possible to access the modem with a SSH client, using the current IP address allocated to the modem by the network.

n = 0 remote access = disabled (default)

n = 1 remote access = enabled

The current status of remote SSH access can be queried by using the **rmtssh** command without parameters.

Examples:

cmd rmtssh 1 enables remote access to the modem using SSH

cmd rmtssh queries the current status of remote SSH access.

A cmd apply followed by a cmd save are required for this command to take effect.

[return to list of commands](#)

rmttelnet

This command configures the modem to respond to incoming telnet commands over the wireless network.

The modem must be connected to a wireless network.

n=0 remote telnet = disabled (default)

n=1 remote telnet = enabled

The current state of remote telnet setting can be queried by using the **rmttelnet** command without parameters.

Examples:

cmd rmttelnet 1 sets the modem to respond to incoming telnet commands

cmd rmttelnet queries the modem's setting for remote telnet access

A cmd apply followed by a cmd save are required for this command to take effect..

[return to list of commands](#)

rmtweb n

Enables or disables remote access to the embedded web server feature of the modem.

If enabled, it will be possible to access the modems embedded web pages by using the current IP address allocated to the modem by the network.

n = 0 remote access = disabled (default)

n = 1 remote access = enabled

The current status of remote web server access can be queried by using the **rmtweb** command without parameters.

Examples:

cmd rmtweb 1 enables remote access to the modem's web pages

cmd rmtweb queries the current status of remote web

A cmd apply followed by a cmd save are required for this command to take effect.

[return to list of commands](#)

rss

This command queries to the current wireless network signal strength seen by the modem for both the 1x and EV-DO networks.

The values are given in dBm in the range, for example: -105dBm (poor), to -60dBm (excellent).

Note: This command is not supported by all wireless network cards and modules.

This is a read only command.

Example:

1. Query the current network signal strengths seen by the modem

```
cmd rss
EVDO: -98dBm
1xRTT: -99dBm
OK
```

[return to list of commands](#)

8.1.15 “S” Commands

saltreport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command sets the report(s) to be used for the chlorobyte salt-spreader interface triggered reports.

Up to 8 reports can be assigned to the saltreport configuration:

r = 0 disables the report

r = 1 to 999 report number

When saltreport is configured to use a report, it appends to the already existing messages configured in the report a modified 114 message.

The appended message contains the specific salt spreader parameters received on the serial port instead of the modem ID in the default 114 message. The mode must be configured correctly to allow the spreader controller to communicate with the modem.

Example:

```
cmd saltreport 2
cmd repaddmes 2 114
cmd save
```

uses report 2 for salt-spreader interface triggered reports, adds a standard message 114 as a message, saves the configuration.

Report output:

```
$PGPS,000000.00,V,0000.0000,N,00000.0000,E,000.0,000.0,000000,+00000,0,0960489
0958*42
```

```
$PGPS,000000.00,V,0000.0000,N,00000.0000,E,000.0,000.0,000000,+00000,0,1312131
41516171819202122232425262728293031*7E
```

In the above example the first line is the default 114 message, the second line shows the 114 message but with the salt spreader information instead of the modem ID. Note, the message type 114 does not have to be explicitly added as a message, this is handled automatically by the **saltreport** command.

A cmd save is required for this command to take effect.

See also: mode, reptime, repreport, repremip, replocport, repemail, repsms, repaddmes

[return to list of commands](#)

satbackup b bt g gt o

Sets the option to switch to a backup satellite modem if the cellular network's coverage is poor.

The satellite modem power must be driven by a modem output for this feature to work.

The user defines the RSSI(receive signal strength) threshold to initiate the switchover, the timeouts and the output number to use.

When the RSSI value falls below the bad RSSI threshold for a certain timeout period, an output will be set.

When the RSSI value rises above or equal to the good RSSI threshold for a certain timeout period, an output will be cleared.

NOTE: This command is only available on data cards/modules that provide RSSI information to the modem. Contact Cypress Solutions for a complete line of supported data devices

b = 0 Disable (default) **bt = -1 to -125** Bad RSSI threshold in dBm; requires the negative sign

bt = 0 to 65535 Bad RSSI timeout in seconds; if the RSSI is less than the bad threshold for the timeout period, than set the output. Default is 0

g = 0 Disable (default)

g = -1 to -125 Good RSSI threshold in dBm; requires the negative sign

gt = 0 to 65535 Good RSSI timeout in seconds; if the RSSI is greater than or equal to the good threshold for the timeout period than clear the output. Default is 0

o = 1 to 4 Output number. Default is 1

A **cmd save** and **power cycle** are required before this setting takes effect.

The current satellite backup setting can be queried by entering **satbackup** without parameters.

To clear setting, use cmd satbackup 0 0 0 0

Examples:

cmd satbackup -100 30 -95 30 2 Set the bad RSSI threshold to -100dBm with a timeout of 30 seconds; set the good RSSI threshold to -95dBm with a timeout of 30 second; trigger output 2.

cmd satbackup Queries the current satbackup configuration

A cmd save is required for this command to take effect.

[return to list of commands](#)

save

Save modem configuration to non-volatile memory.

Note: A single **cmd save** can be entered after a series of commands are configured, the entire session will be saved.

If settings are not saved, they will remain in effect until the next **powercycle**

Example:

1. Save current configuration

```
cmd save
OK
```

[return to list of commands](#)

showconfig

Returns the current configurations of the modem.

This is a read only command.

showconfig returns the configuration of the commands as they were entered, including the **cmd** statement.

The output of **showconfig** is written to a script file **/tmp/config.sh** and to the console, both of which can be used to configure the modem.

The below commands are not supported in **showconfig**. To query the status of the below commands use **showstate**. To configure these commands the **showconfig** script file or input text must be manually updated.

```
cmd odometer
cmd smstext
```

```
cmd enghours
cmd data
```

The below commands are not supported in either **showconfig** or showstate commands. To configure these commands the **showconfig** script file or input text must be manually updated.

```
cmd factory
cmd ratesel
cmd telnetpswd
```

Commands can be manually entered as shown in the output of **showconfig** using the syntax shown. The **showconfig** output can be 'Copy & Pasted', if there is a long list of commands, it is recommended to use a telnet session rather than the serial console to capture the output of **showconfig**.

Example:

cmd showconfig returns the current modem configurations

[return to list of commands](#)

showstate

Returns the current state of the modem.
This is a read only command.

showstate returns the modem state:

- firmware revision
- modem ESN
- modem ID
- modem IP address
- odometer
- engine hours
- RF Switch output mode, 0 = RF device connected or connecting, 1 = RF device off, awaiting switch input.
- SMS destination number
- SMS text
- amount of data transmitted and received over the wireless data link

Example:

```
# cmd showstate
Firmware Version:CTM15x R1.2.2 (rev. 1483)
ESN:09604890958
Modem ID:09604890958
Modem IP Address:96.1.3.13
Odometer:0 KM
```

```
Engine Hours:0.00 h
Output mode (RF Switch):0
SMS Destination Number:
SMS Text:
Wireless link data count:
TX: 0 MB
RX: 0 MB
Total: 0 MB
OK
```

[return to list of commands](#)

singlepc n

Sets the modem's DHCP allocation of IP addresses.

If enabled, the modem's DHCP server will only allocate one IP address.

This single IP address assigned by the modem will be **192.168.1.20**.

n = 0 Disable (default)

n = 1 Enable

The current DHCP allocation setting can be queried by entering **singlepc** without parameters.

Examples:

1.Enable single PC mode

```
cmd singlepc 1
OK
```

2. Query the current singlepc configuration

```
cmd singlepc
cmd singlepc 0
OK
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

smssend

Used to SEND the previously setup SMS message (**smsto** and **smstext**).

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

The modem needs to be connected to the network.

Example:

cmd smssend send the SMS message

[return to list of commands](#)

smstext <string> <delimiter>

Used to enter the text message of the SMS.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

The delimiter is used to indicate an end of text message.

Text message is not saved in non-volatile memory a <CR> denotes a carriage return.

<string> text message(max 166 chars)

<delimiter> sequence of a blank line followed by a carriage return and then the sequence “.”

Example:

cmd smstext <CR>

Hi <CR>

This is test <CR>

message<CR>

from Bob<CR>

.<CR>

Note: cmd smstext cannot be used from a serial console.

[return to list of commands](#)

smsto pppppppppp

This command is used to set the phone number of the SMS text message to be sent.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.
The phone number is not saved in non-volatile memory.

pppppppppp phone number which the text message will be sent to. For long distance calls, a “1” needs to be added in front of the phone number.

The current settings can be queried by using the **smsto** command without parameters.

Examples:

cmd smsto 1235551212 sets the phone number to send the SMS

cmd smsto returns the phone number this command is set to

[return to list of commands](#)

smsview

Query's the message entered via smstext command.

Note: SMS features are only available for specific manufacturer, RF modules, cards or devices. Please contact Cypress Solutions for a complete list of products that support SMS functionality.

This is a read only command.

Example:

cmd smsview returns the text message to be sent

[return to list of commands](#)

snfdelay [n]

This command sets the store-and-forward delay time. The delay time is the number of seconds the modem must have a good quality RF connection before stored messages are forwarded. Valid range is 1 to 65535 seconds. The default is 20 seconds.

Note that message forwarding may not occur exactly at the snfdelay interval specified, and stored messages will only start forwarding when network conditions are deemed acceptable. Example:

1. Set the delay time before forwarding SNF data to 60 seconds

```
cmd snfdelay 60
```

A cmd save is required for this command to take effect.

[return to list of commands](#)

snfflush

Flushes and resets store and forward NVRAM.

[return to list of commands](#)

snflog n

Used to display the contents of the store and forward log locally thru a serial console, and the status of the log entries. The log can contain up to 3000 records.

This is a read only command.

n = 1 to 3000 number of store reports to be displayed

The number of stored reports and their status can be queried by entering **snflog** without parameters.

T:t where **t** is the total number of stored reports

F:f where **f** is the number of reports forwarded

N:n where **n** is the number of reports not yet forwarded

Examples:

cmd snflog 100 displays the first 100 SnF log entries

cmd snflog displays the SnF log status

Note: snflog may erroneously report number of forwarded messages as 1 in cases where number of forwarded messages is actually 0. When network coverage resumes, all packets will be forwarded.

[return to list of commands](#)

spc nnnnnn

This command is used to enter the modem's CSL (Client Subsidy Lock) as part of the network activation commands prior to loading the modem's 10-digit phone number using the **dir** command.

The 6-digit lock code is used by the modem's embedded module to compare against the pre-loaded 6-digit CSL. This number will be provided by the service provider at the time of service activation.

nnnnnn 6-digit lock code

Example:

cmd spc 123456 set the modem's SPC to 123456

A cmd save is required for this command to take effect.

[return to list of commands](#)

speedth ss t

Sets the speed threshold for automatically enabling the RF module of the modem when it has been previously disabled.

Turns off output **#4** when it has been previously turned on.

The RF module of the modem is disabled by using an external switch box(supplied by Cypress Solutions) connected to the modem when the modem is used in areas sensitive to RF interference.

The defaults are 30 km/h for ss and 3 seconds for t.

If ss and t are omitted, the current speed threshold will be queried.

ss speed threshold(kph)

t time (seconds)

Example:

cmd speedth 50 5 set the RF module of the modem to automatically turn on when the speed reaches **50 km/h** for at least **5 seconds**

cmd speedth queries the current speed threshold conditions

A cmd save is required for this command to take effect.

[return to list of commands](#)

sshkey [dss/rsa]

Generate a SSH public/private key pair.

dss Generate a 1024 bit DSS key pair

rsa Generate a 1024 bit RSA key pair

Example:

cmd sshkey dss

```
root@OpenWrt:~# cmd sshkey dss
```

Will output 1024 bit dss secret key to '/etc/dropbear/id_dss'

Generating key, this may take a while...

Public key portion is:

```
ssh-dss
```

```
AAAAB3NzaC1kc3MAAACBAKV8x80K0wnyc4Ia/NiD0BTZLhPYVPO8FhB3kWzLOdB99SyQBgl6tXaYvPXT+rV2  
4qzmJaNIDlwMAsJRxp86Jki/WogktrN1jjjI8bnwrvjvM1kCCmWf8SUrYRhk+tvqCgQX1qk3CQsFE0JjU66Fk6+s  
5+Ng7ofigajDNCJYCD07AAAAFQDDTQ9nonJwG5xLxoOeHO21CDjOZwAAAI6MxUSC34am0YmmiCAOUPa  
6Vy6SbJVhsffoBBVFkoDmTqkdv/IMR4iP4Rhjb3rI27r+8wnlZorm5sKJGvhbLjLbQqlvv0aUiywmM31L5Zllglq7  
adGJ6cLwIQKZ5+1Vt1Nx9MQiayD9vey5HCdgtS6OBENVOp4H7bWfqAOkuZnDAAAAIBd1f8d5aguW/ySngm  
jH64MNYk7t8k9bmN+2kFS6szUd40EwjAHMTAK+Rgu4Q/tiXlVOq8qomCgfd2oEN6KbiJDoqEYsRzCQ8AhCW  
fNEKiQd9X3Dw7Q8dRxD6Qx+Ro18ptkIXIQtsURURBWxJtet0wpihQnkhLtdu028o1+Ex6A==
```

```
root@OpenWrt
```

```
Fingerprint: md5 6b:06:6e:f4:2e:0e:58:21:12:1d:f8:51:25:2a:a5:6d
```

```
OK
```

[return to list of commands](#)

sshport [port]

Sets the port for ssh access (both local and remote).

A `cmd apply`, followed by `cmd save` and **power cycle** are required for this command to take effect.

port = 1 to 65535 port to be used for ssh (default: port 22)

The current ssh port setting can be queried by entering `cmd sshport` without parameters.

Example:

1. Set ssh port to 3322

```
cmd ssh 3322
```

```
OK
```

[return to list of commands](#)

sshtimeout n

Sets the timeout period for a ssh session with no activity. The ssh timeout will take effect on the next sshlogin.

n = 0 to 65535 timeout time, in seconds (default: 60 seconds)

The current ssh timeout setting can be queried by entering **sshtimeout** without parameters.

Example:

1. Disable ssh timeout

```
cmd sshtimeout 0
OK
```

[return to list of commands](#)

swipemode n

Sets the swipe card interface to be used with the modem.

n = 0 Serial HID swipe card interface (default), requires **cmd mode 9**

n = 1 Serial iButton swipe card interface, requires **cmd mode 9**

n = 10 GPIO HID swipe card interface, works in any [mode](#) and takes priority in **cmd mode 9**

When **swipemode** is configured with **n = 0** or **n = 1**, the command **cmd mode 9** must be used. When **swipemode** is configured with **n = 10**, any [mode](#) can be used.

Note: In order to use **swipemode 10**, power management controller firmware **version 105** must be loaded. To check this version **cmd mmq 47** command can be issued and should return the value of **69**. Contact Cypress Solutions for instructions on upgrading power management controller firmware.

Examples:

1. Set modem to use the serial iButton swipe card interface

```
cmd mode 9
OK
cmd swipemode 1
OK
```

2. Set modem to use the GPIO HID swipe card interface

```
cmd swipemode 10
OK
```

3. Query the currently configured swipe card interface

```
cmd swipemode
cmd swipemode 0
OK
```

A cmd save and a power cycle are required for this command to take effect.

See also: [mode](#)

[return to list of commands](#)

swipereport [r1] [r2] [r3] [r4] [r5] [r6] [r7] [r8]

This command sets the report(s) to be used for swipe card reader triggered reports.

Up to 8 reports can be assigned to the swipereport configuration:

r = 0 disables the report

r = 1 to 999 report number

When **swipereport** is configured to use a report, it appends to the already existing messages configured in the report a modified 114 message.

The appended message contains the ID of the swipe card detected by the swipe card reader. [mode](#) must be configured correctly to allow the swipe card reader to communicate with the modem. When using the redboot loader swipe card reader application to trigger remote reports, store and forward must be enabled for the report(s) assigned using **swipereport**.

Example:

```
cmd reptype 2 0 3 1
cmd repremip 2 123.123.123.123
cmd repremport 2 5555
cmd repaddmes 2 114
cmd swipereport 2
cmd save
```

uses report 2 with store and forward enabled for swipe card reader triggered reports, adds a standard message 114 as a message, saves the configuration.

Report output:

```
$PGPS,171134.00,A,4915.3868,N,12259.8049,W,000.0,000.0,170609,+00004,5,0960489
0958*4A
```

```
$PGPS,171134.00,A,4915.3868,N,12259.8049,W,000.0,000.0,170609,+00004,5,0960489
0958,039-30391,V*33
```

In the above example the first line is the default 114 message, the second line shows the appended swipe card ID information added to the message. Note, the message type 114 does not have to be explicitly added as a message, this is handled automatically by the **swipereport** command.

A cmd save is required for this command to take effect.

See also: mode, reptime, repremport, repremip, replocport, repemail, repsms, repaddmes

[return to list of commands](#)

syslog n

Provides a mechanism to retrieve the log of system events recorded by the modem.

Log events include network connects and disconnects.

Note that the system log is stored in volatile memory so it will be lost when power is cycled on the modem.

n = 0 to 65535 number of system log records to return. Leaving **n** blank will return the entire contents of the system log up to a maximum of 65535.

Examples:

cmd syslog 10 returns the last 10 events stored in the system log

cmd syslog returns all events stored in the system log

[return to list of commands](#)

8.1.16 “T” Commands

telnetport n

Sets the port for telnet access (both local and remote).

A [cmd save](#) and power cycle is required for this command to take effect.

n = 1 to 65535 port to be used for telnet (default: port 23)

The current telnet port setting can be queried by entering telnetport without parameters.

Firmware version R1.2.1 and below: When the telnet port is changed using telnetport from within a local/remote Telnet session, this session will be disconnected. To complete telnet port configuration, you will need to reconnect to the telnet server at the new telnet port, issue a cmd save and power cycle.

Firmware version R1.3.0 only: To complete telnet port configuration, power cycle the modem.

Example:

1. Set telnet port to 33

```
cmd telnetport 33
OK
```

A `cmd apply` followed by a `cmd save` are required for this command to take effect.

See also: `telnetpswd`, `telnettimeout`

[return to list of commands](#)

telnetpswd n

Sets password for telnet access (both local and remote) and ssh access (both local and remote). ssh access is available in firmware version R1.3.0 only.

n a maximum of 40-character alpha-numeric password

Example:

1. Set telnet password to 'cypress'

```
cmd telnetpswd cypress
OK
```

Firmware version R1.2.1 and below: A [cmd save](#) is required for this command to take effect.

Firmware version R1.3.0 only: This command takes effect immediately.

See also: `telnetport`, `telnettimeout`

[return to list of commands](#)

telnettimeout n

Sets the timeout period for a telnet session with no activity. The telnet timeout will take effect on the next telnet login.

n = 0 to 65535 timeout time, in seconds (default: 60 seconds)

The current telnet timeout setting can be queried by entering **telnettimeout** without parameters.

Example:

1. Disable telnet timeout

```
cmd telnettimeout 0
OK
```

A `cmd save` is required for this command to take effect.

See also: `telnetpswd`, `telnetport`

[return to list of commands](#)

timesync t

Set the period in seconds when the modem's system time and the power management controller's time are synchronized with one or more external sources:

- Valid GPS (`gpstime`)
- Network time protocol (NTP) built-in client (`ntptime`)
- Cellular network time (`networktime`)

t = 0 to 65535 synchronization period in seconds (default: 3600 seconds)

A `cmd save` and a `power cycle` are required for this command to take effect.

Examples:

1. Update system time and power management controller time as fast as possible

```
cmd timesync 0
OK
```

2. Update system time and power management controller time every 10 seconds

```
cmd timesync 10
OK
```

See also: `gpstime`, `networktime`, `ntpserver`, `ntptime`

[return to list of commands](#)

8.1.17 “U” Commands

univwd <mode> <url>/<report>

Configure the Universal Watchdog.

mode = 0 disabled

mode = 1 detect increase in received packets.

mode = 2 ping specified url
mode = 3 send specified report

Examples:

1. Configure a report to send PMID message #3, to remote server on UDP port 7002.
Set universal watchdog into mode 3, which will use report 1 to generate ping activity.

```
cmd repremip 1 209.121.68.211
cmd repreport 1 7002
cmd reptime 1 0 3
cmd repaddmes 3
cmd univwd 3 1
cmd save
```

A `cmd save` is required for this command to take effect.

See also: `messages`, `repedmes`, `reppmail`, `replocport`, `repremip`, `repreport`, `repsms`, `reptime`

[return to list of commands](#)

univwdtimer [n] [p]

Sets the timer value (in seconds) for the universal watchdog timer.

n = 1 to 65535 seconds watchdog timer interval

p = 1 to 60 seconds watchdog ping interval, valid for univwd modes = 2 and 3

A `cmd save` is required for this command to take effect.

[return to list of commands](#)

upgradefw imagefile.tar url username passwd

Remote upgrade of the CTM-15X firmware (kernel and root filesystem images).

The command requires 5 parameters when accessing an FTP server, 3 parameters when accessing an HTTP server, or 3 parameters when accessing scripts locally.

imagefile.tar the name of the file containing the firmware image

url can be **localhost**, or the address of the FTP or HTTP server, can also be an IP address, prefixed by `ftp://` or `http://` respectively; if no prefix is specified (eg. `cypress.bc.ca`) then `ftp://` is used.

username username to access FTP server (ignored when **url** is prefixed by `http://` or **url** is **localhost**)

passwd password to access FTP server (ignored when **url** is prefixed by `http://` or **url** is **localhost**)

When **localhost** is specified as the **url**, the image file must be located in **/tmp** on the modem.

Examples:

cmd upgradefw openctm-1.3.0-r1590.tar cypress.bc.ca guest guestpw where **openctm-1.3.0-r1590.tar** is the image file, **cypress.bc.ca** is the FTP server, **guest** is the username of the FTP server, and **guestpw** is the password of the FTP server

cmd upgradefw openctm-1.3.0-r1590.tar localhost where **openctm-1.3.0-r1590.tar** is the image file, and **/tmp** is the location of the image file.

[return to list of commands](#)

upgradesrv a.a.a.a

This command is used to set the IP address of a remote client that is authorized to run remote administration commands.

The RemoteAdminServer commands: Showconfig, Confupgrade and Pwrcycle are restricted to an authorized IP.

a.a.a.a = 0.0.0.0 to 255.255.255.255 IP address of the authorized IP client. Default = 0.0.0.0
0.0.0.0 disables all remote clients 255.255.255.255 enables all remote clients

The current upgrade server IP address can be queried by using the upgradesrv without parameters.

Examples:

1. Set the upgrade server IP address to 209.121.68.211

```
cmd upgradesrv 209.121.68.211
OK
```

2. Query current email server

```
cmd upgradesrv
cmd upgradesrv 209.121.68.211
OK
```

[return to list of commands](#)

usepeerdns x

This command is used to enable or disable the modem from obtaining its DNS nameserver IP addresses from the carrier when it connects to the network.

This is enabled by default whenever a cmd factory is issued.

If specific DNS nameservers are to be used, this setting should be disabled. DNS nameserver IP addresses can be added from the main **Network** web page under the **lan DNS servers** section by entering the DNS nameserver IP address in the text field, clicking on the **Add** button, followed by clicking on the **Save Changes** button.

x = 0 disable obtaining DNS nameserver IP addresses from the carrier

x = 1 enable obtaining DNS nameserver IP addresses from the carrier (default)

Examples:

1. Disable obtaining DNS nameserver IP addresses from the carrier.

```
cmd usepeerdns 0
OK
```

This command takes effect immediately.

[return to list of commands](#)

user n

Sets the username used for wireless network access via simple IP. This is often in the format of **[phone number]@[carrier].com**.

n a maximum of 40-character alpha-numeric username

A save operation is required.

Examples:

cmd user 6045551234@... sets the username to 6045551234@...

cmd user displays the current username used for wireless network access via simple IP

A **cmd apply** followed by a **cmd save** are required for this command to take effect.

See also: **mip**, **pswd**

[return to list of commands](#)

8.1.18 “V” Commands

vcc

Returns the current value of the modem's supply voltage. This is a read only command.

Example:

1. Query the supply voltage in xx.xx ASCII format

```
cmd vcc
11.99V
OK
```

[return to list of commands](#)

vcccond [n] [o] [a.a] [mt]

This command is used to set the condition(s) that would trigger a supply voltage level report.

The conditional parameter is used to indicate how all following parameters will be used to determine if a report is triggered. Use the Off setting to disable the report.

n = 1 to 8 supply voltage level condition trigger

o=0 trigger disabled (default)

o=1 trigger while supply voltage is below threshold

o=2 trigger while supply voltage is above threshold

o=3 trigger on transition (whenever supply voltage threshold is passed)

(above threshold->below threshold or below threshold->above threshold)

Optional parameters:

a.a = 9.0 to 36.0 threshold voltage, in volts (default = 9.0 V)

mt = 0 to 65535 maximum reporting rate in seconds (minimum time between reports)
(default = 60 s)

The current condition(s) can be queried by using the vcccond n command.

If n is blank, all vcccond triggers will be queried.

Examples:

1. Triggers vcccond 1 every 60 seconds while supply voltage is below the threshold voltage of 9.0 volts

```
cmd vcccond 1 1
OK
```

2. Triggers vcccond 2 every 60 seconds while supply voltage is below the threshold voltage of 9.0 volts

```
cmd vcccond 2 1 9.0
OK
```

A cmd save is required for this command to take effect.

See also: `vccreport`

[return to list of commands](#)

vccreport [n] [r]

This command sets the report to be used for supply voltage level triggered reports. Up to 8 supply voltage level trigger reports can be configured.

n = 1 to 8 supply voltage level trigger condition

r = 1 to 999 report number

r = 0 disables the report

Example:

cmd vccreport 1 1 uses report #1 for supply voltage level trigger condition #1. A `cmd save` is required for this command to take effect.

See also: `vccond`, `repdelmes`, `repaddmes`, `repemail`, `replocport`, `reprempip`, `reprempport`, `repsms`, `reptype`

[return to list of commands](#)

ver

Queries the currently installed firmware version of the modem.

Example:

1. Query the current firmware version

```
cmd ver
CTM15x R1.2.0 (rev. 1140)
OK
```

[return to list of commands](#)

8.1.19 “W” Commands

wifiwd n [t]

Enable/disable Wi-Fi watchdog.

n 0 = disabled; 1 = enabled **t** watchdog threshold time in seconds, time must be in range 31 to 65535 (optional: default is 120 seconds).

Example:

1. Enable Wi-Fi watchdog with a 5 minute threshold

```
cmd wifiwd 1 300
OK
```

[return to list of commands](#)

wpanacktype n

Assigns an acknowledgment type for the Work Alone system.

There are two acknowledgment types:

- modem
- server

Note: CTM-15X Modem firmware 1.2.0 only supports **modem mode** acknowledgment type.

If a user initiates a ‘Man Down Emergency’ alert, the pendant will provide the worker with either a **positive acknowledgment** or a **negative acknowledgment**.

n = m modem type acknowledgment (default)

n = s server type acknowledgment

Entering **wpanacktype** with no arguments returns the current command configuration.

A **cmd save** and a **power cycle** are required before either mode takes effect.

- Modem type acknowledgment:
A positive acknowledgment (ACK) means the modem has received the alert. If the pendant has not received an acknowledgment from the modem the pendant will continue to send PANIC/MPANIC messages until an acknowledgement (ACK) is received. (Pendant firmware V1.1 and later)
- Server type acknowledgment:
A positive acknowledgment means that the server has received the alert from the modem and acknowledged back to the modem then to the pendant. If the pendant has not received an acknowledgment from the server the pendant continue sending PANIC/MPANIC messages until it receives an acknowledgement (ACK). (Pendant firmware V1.1 and later)

Note:

The remote server must also be configured to respond to messages from the modem.
The message format sent from the modem is as follows:

```
$PPEN,0013A200402CB498,13,PANIC*03
```

The acknowledgment that the modem expects from the server is as follows:

```
$PPQ,PAN,0013A200402CB498,13,ACK*36
```

The 16-digit hex number following the PPEN message is the Pendant ID and is unique to each pendant.

Examples:

1. Configured as modem type acknowledgment

```
cmd wpanacktype m
OK
```

2. Configured as server type acknowledgment

```
cmd wpanacktype s
OK
```

[return to list of commands](#)

wpanadddev *xx-xx-xx-xx-xx-xx-xx-xx*

Adds a WPAN device ID to the Chameleon Modem's registered WPAN devices list. Up to 16 WPAN IDs can be entered.

xx-xx-xx-xx-xx-xx-xx-xx WPAN device ID (hex digits), hyphens are optional

Using **wpanadddev** without a device ID, queries all WPAN devices IDs currently registered in the Chameleon Modem.

Note that the ID of FF-FF-FF-FF-FF-FF-FF-FF will allow any pendant to talk through the modem.

Example:

cmd wpanadddev 00-13-a2-00-40-08-58-5e add WPAN device with this ID to the registered devices list

cmd wpanadddev 0013a2004008585e above example with optional hyphens omitted

cmd wpanadddev queries all devices IDs

A cmd save is required for this command to take effect.

Note that the modem needs to be power cycled for the new settings to take effect.

[return to list of commands](#)

wpandelall

Deletes all WPAN device IDs from the Chameleon Modem's registered WPAN devices list.

Example:

cmd wpandelall deletes all WPAN devices from the registered devices list

Note that the modem needs to be power cycled for the new settings to take effect.

[return to list of commands](#)

wpandeldev xx-xx-xx-xx-xx-xx-xx-xx

Deletes a WPAN device ID from the Chameleon Modem's registered WPAN devices list. **xx-xx-xx-xx-xx-xx-xx-xx** WPAN device ID (hex digits), hyphens are optional

Example:

cmd wpandeldev 00-13-a2-00-40-08-58-5e delete WPAN device with this ID from the registered devices list

cmd wpandeldev 0013a2004008585e above example with optional hyphens omitted

A cmd save is required for this command to take effect.

Note that the modem needs to be power cycled for the new settings to take effect.

[return to list of commands](#)

wpanpanid xxxx

Set the WPAN PAN ID to communicate with the WPAN devices.

xxxx WPAN PAN ID (hex digits)

Using **wpanpanid** without a PAN ID, queries the WPAN PAN ID currently configured in the Chameleon Modem.

Example:

cmd wpanpanid 2000 change the WPAN PAN ID to 0x2000

cmd wpanpanid queries the current WPAN PAN ID

Note: A **cmd save** and a **power cycle** must occur for the new settings to take effect.

[return to list of commands](#)

wpanpensrv x yyyy

Configure the listening protocol and port of the Pendant Server that provides remote access to Man Down Pendant devices.

x = 0 UDP protocol (default)

x = 1 TCP protocol

yyyy = 0 to 65535 port number of listening port, in decimal (0 = disabled, default)

Using **wpanpensrv** without arguments returns the currently configured protocol and port in the Chameleon Modem.

Note:

If the modem is currently in WPAN Gateway mode, **mode 10**, and any other LAN or firewall configuration commands are set after issuing the **wpanpensrv** command, then both a **cmd save** and a power cycle are required to resume proper remote access to pendant devices through **wpanpensrv**.

Example:

cmd wpanpensrv 0 21001 change the Pendant Server to listen on UDP port 21001

cmd wpanpensrv 1 21002 change the Pendant Server to listen on TCP port 21002

cmd wpanpensrv queries the current Pendant Server settings

A **cmd save** and a power cycle must occur for the new settings to take effect.

See also: mode

[return to list of commands](#)

9 Report Messages

Decimal ID	Message description
03	Modem ID, proprietary NMEA message- \$PMID
16	GPS NMEA GLL message- \$GPGLL
20	Digital Input States, proprietary NMEA message- \$PIND
21	Analog Input #1 status, proprietary NMEA message- \$PINA
22	Analog Input #2 status, proprietary NMEA message- \$PINA
23	Analog Input #3 status, proprietary NMEA message- \$PINA
24	Analog Input #4 status, proprietary NMEA message- \$PINA
25	Analog Input #5 status, proprietary NMEA message- \$PINA
26	Analog Input #6 status, proprietary NMEA message- \$PINA
30	Network status, proprietary NMEA message- \$PCTM
31	Wireless link TX/RX data count, proprietary NMEA message- \$PDATA
40	Device phone number, PAD Port/Type, serial port baud- ID=
80	GPS NMEA GGA message- \$GPGGA
82	GPS NMEA RMC message- \$GPRMC
84	GPS NMEA GSA message- \$GPGSA
85	ULCP binary format GPS data message
88	ULCP binary format acceleration/deceleration event data with GPS
89	ULCP binary format Modem ID/firmware revision/odometer data
90	ULCP binary format odometer data
92	ULCP binary format wireless Link TX/RX Data Count with Modem ID
98	ULCP binary format digital input event data with GPS
100	GPS TAIP PV message
101	GPS TAIP LN message
112	ULCP binary format modem ID with GPS
114	GPS with modem ID proprietary NMEA (based on RMC)- \$PGPS
115	Proprietary NMEA message for Google Earth application (kmlserver)- \$PKML
116	Power status, proprietary NMEA message- \$PPWR
117	CDMA/EV-DO Network diagnostic report, proprietary NMEA message- \$PRFI
118	GPS NMEA GSV message- \$GPGSV
119	OBD II Group A, proprietary NMEA message- \$POBDA
120	OBD II Group B, proprietary NMEA message- \$POBDB
121	OBD II Group C, proprietary NMEA message- \$POBDC
122	OBD II Group D, proprietary NMEA message- \$POBDD
136	GPS Acceleration/Deceleration with Modem ID, proprietary NMEA message- \$PACCEL
137	GPS Odometer with Modem ID, proprietary NMEA message- \$PODO

9.1 Message Type 03, PMID

Proprietary NMEA message containing the modem's **ESN** and **ID**. Note that the default ID is the modem's **ESN**

Message format is:

\$PMID,xxxxxxxxxx,yyyyyyyyyy*hh<CR><LF>

Where:

xxxxxxxxxx is the modem's unique 11 digit ESN (CDMA/EV-DO devices only) or 15-digit IMEI (GSM/GPRS/HSPA devices only)

yyyyyyyyyy is the modem's ID as set by the user (maximum 15 characters)

hh is the message checksum

Example:

With CDMA/EV-DO wireless device installed, serial number is ESN:

\$PMID, 09604890968, 09604890968*10

With GSM/GPRS/HSPA wireless device installed, serial number is IMEI:

\$PMID, 359475021717716, 359475021717716*10

9.2 Message Type 16, \$GPGLL

This is a standard NMEA message containing GPS latitude and longitude information and time.

NMEA 0183 v2.0 message format is:

\$GPGLL,IIII.IIII,a,yyyyy.yyyy,b,hhmmss.ss,v*hh<CR><LF>

NMEA 0183 v3.0 message format is:

\$GPGLL,IIII.IIII,a,yyyyy.yyyy,b,hhmmss.ss,v,c*hh<CR><LF>

Where:

IIII.IIII is the position latitude in degrees, minutes and decimal minutes

a is N(orth) or S(outh)

yyyyy.yyyy is the position longitude in degrees, minutes and decimal minutes

b is E(ast) or W(est)

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

c is the positioning system mode indicator (NMEA 0183 v3.0 only): A = autonomous mode, D = Differential mode, E = Estimated (dead reckoning) mode, M = Manual input mode, S = Simulator mode, N = Data not valid. Note: The CTM-15X internal GPS module supports autonomous mode only.

hh is the message checksum

Examples:

NMEA 0183 v2.0:

\$GPGLL, 4915.3927,N, 12259.8049,W, 223636.00,A*18

NMEA 0183 v3.0:

```
$GPGLL,4915.3920,N,12259.8072,W,222414.00,A,A*79
```

9.3 Message Type 20, PIND

Proprietary NMEA message containing the digital state of the six inputs on the CTM-15x modem and a counter that keeps tracks of the number of times Input 1 has been triggered.

Message format is:

```
$PIND,abcdef,nnnn*hh
```

Where:

abcdef is the current digital state of inputs 1 through 6: **0 = low; 1 = high**

nnnn is the counter for the number ticks from **input 1**; Counter max 65535; Max tick frequency is 40Hz.

Note: This parameter is valid with power management microcontroller firmware revision r101 only.

Contact Cypress Solutions for details.

hh is the message checksum

Example:

```
$PIND,000000,2*21
```

9.4 Message Type 21 to 26, PINA

Proprietary NMEA message containing the analog state of the specified input on the CTM-15x modem.

Message format is:

```
$PINA,n,x.xx*hh
```

Where:

n is the analog input number with range 1 through 6.

x.xx is the current analog value of input n in volts

hh is the message checksum

Example:

```
$PINA,1,0.00*39
```

```
$PINA,2,0.00*3A
```

```
$PINA, 3, 0.00*3B
$PINA, 4, 0.00*3C
$PINA, 5, 0.00*3D
$PINA, 6, 0.00*3E
```

9.5 Message Type 30, PCTM

Proprietary NMEA message containing the current wireless network (e.g. cellular network, Wi-Fi network) status.

Note: If used with Store and Forward the network status parameters will be invalid.

Cellular network message format

\$PCTM,-xxxdBm,-yydBm,zzzz,b,s,r,nnn.nnn.nnn.nnn*hh<CR><LF>

Where:

xxx is the current EV-DO network signal strength, or HSPA network signal strength (firmware version R1.3.0 and above only)

yyy is the current 1xRTT network signal strength (CDMA only; not available for HSPA where value always set to -0dBm)

zzzz is the current System ID (SID) (CDMA only; not available for HSPA where value always set to 0)

b is the band class (CDMA only; not available for HSPA where value always set to 0): 0 = 800MHz, 1 = 1900MHz

s is the service flag:

CDMA: 0 = unknown, 1 = 1xRTT; 2 = EV-DO(revision 0) 3 = EV-DO(revision A)

HSPA (firmware version R1.3.0 and above only): 0 = no service, 1 = GPRS, 2 = EDGE, 3 = UMTS, 4 = HSDPA, 5 = HSUPA, 6 = HSPA+

r is the registered flag: 0 = not registered, 1 = registered.

nnn.nnn.nnn.nnn is the modem's assigned IP address.

hh is the message checksum

Wi-Fi network message format

\$PCTM,ttt,ssid,ap:ap:ap:ap:ap:ap,txdBm,lq,-rxdBm,-nodBm,nnn.nnn.nnn.nnn*hh

Where:

ttt is the Wi-Fi technology

ssid is the ESSID of the access point

ap:ap:ap:ap:ap:ap is the access point MAC address

tx is the TX power

lq is the link quality

rx is the RX signal strength

no is the noise level

nnn.nnn.nnn.nnn is the current IP address of modem's WAN interface

hh is the message checksum

Examples:

EV-DO:

```
$PCTM,-87dBm,-100dBm,16422,1,3,1,96.1.5.204*0B
```

HSPA (firmware version R1.3.0 and above only):

```
$PCTM,-90dBm,-0dBm,0,0,6,1,10.163.78.249*33
```

Wi-Fi:

```
$PCTM,IEEE802.11abg,cypress,00:24:A5:AD:61:4F,18dBm,70/70,-22dBm,n/a  
dBm,192.168.100.202*53
```

9.6 Message Type 31, PDATA

Proprietary NMEA message containing the values of data transmitted and received over the wireless data link. The total data usage in MB can be determined by adding the reported value of data transmitted with the reported value of data received.

Message format is:

```
$PDATA,xxxxxxxxxxxxxxxxxxxxx,yyyyyyyyyyyyyyyyyy,zzzzzzzzzz*hh<CR><LF>
```

Where:

xxxxxxxxxxxxxxxxxxxxx is the amount of data transmitted over the wireless link (MB)

yyyyyyyyyyyyyyyyyy is the amount of data received over the wireless link (MB)

zzzzzzzzzz is the modem's ID as set by the user (maximum 11 characters)

hh is the message checksum

Example:

```
$PDATA,0,9,09604204991*59
```

9.7 Message Type 40, ID=

This is a proprietary ASCII message containing the modem's phone number, PAD port, serial port baud rate and PAD type.

Message format is:

```
ID=pppppppppp,nnnnn,bbbbbb,ttt
```

Where:

pppppppppp is the modem's 10-digit phone number

nnnnn is the PAD port number
bbbbbb is the serial port's baud rate
ttt is the PAD type, UDP or TCP

Example:

ID=7788282538,5005,9600,UDP

9.8 Message Type 80, \$GPGGA

Standard NMEA message containing time, GPS latitude and longitude, satellite status information and altitude.

Message format is: **\$GPGGA,hhmmss.ss,llll.llll,a,yyyyy.yyyy,b,c,d,ee.e,sffff,M,,M,,0000*hh<CR><LF>**

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

llll.llll is the position latitude in degrees, minutes and decimal minutes

a is N(orth) or S(outh)

yyyyy.yyyy is the position longitude in degrees, minutes and decimal minutes

b is E(ast) or W(est)

c is the GPS quality: 0 = not valid; 1 = valid

d is the number of satellites in use (range 0 to 12)

ee.e is the Horizontal Dilution of Precision (HDOP)

s is sign + or – for altitude above or below mean sea level

ffff is the altitude in metres

hh is the message checksum

Example:

\$GPGGA,000512.00,4910.9588,N,12254.6560,W,1,8,01.1,-00015,M,,M,,0000*5C

9.9 Message Type 82, GPRMC

Standard NMEA message containing time, GPS latitude and longitude, speed, altitude and heading information.

NMEA 0183 v2.0 message format is:

\$GPRMC,hhmmss.ss,v,llll.llll,a,yyyyy.yyyy,b,ccc.c,ddd.d,ddmmyy,,*hh<CR><LF>

NMEA 0183 v3.0 message format is:

\$GPRMC,hhmmss.ss,v,llll.llll,a,yyyyy.yyyy,b,ccc.c,ddd.d,ddmmyy,,,e*hh<CR><LF>

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

llll.llll is the position latitude in degrees, minutes and decimal minutes

a is N(orth) or S(outh)

yyyyy.yyyy is the position longitude in degrees and decimal degrees

b is E(ast) or W(est)

ccc.c is the horizontal velocity in knots

ddd.d is the heading in degrees (relative to true north)

ddmmyy is the day, month and year

e is the positioning system mode indicator (NMEA 0183 v3.0 only): A = autonomous mode, D = Differential mode, E = Estimated (dead reckoning) mode, M = Manual input mode, S = Simulator mode, N = Data not valid. Note: The CTM-15X internal GPS module supports autonomous mode only.

hh is the message checksum

Examples:

NMEA 0183 v2.0:

```
$GPRMC,001207.00,A,4911.2236,N,12254.4779,W,012.3,201.0,170109,,*2D
```

NMEA 0183 v3.0:

```
$GPRMC,222414.00,A,4915.3920,N,12259.8072,W,000.2,242.0,211210,,,A*49
```

9.10 Message Type 84, \$GPGSA

Standard NMEA message containing GPS receiver mode, ID of satellites used in the fix, and Dilution of Precision (DOP) values.

Message format is:

```
$GPGSA,a,b,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,p,p,h,h,v,v,*hh<CR><LF>
```

Where:

a is the receiver mode: A = automatic; M = manual (select 2D or 3D)

b is fix mode: 1 = fix not available; 2 = 2D; 3 = 3D.

xx is the ID of each satellite used in the fix (unused are 00)

p.p is the Percent DOP value

h.h is the Horizontal DOP value

v.v is the Vertical DOP value

hh is the message checksum

Example:

```
$GPGSA,A,1,11,11,20,23,32,16,00,00,00,00,00,00,03.1,02.4,02.0*03
```

9.1.1 Message Type 85, ULCP binary position message with GPS coordinates

Header: **0x55 0xSS 0x06 0x00 0x00 0x18 0x0000**

Message body:

Hex	Description
4 bytes	Normalized latitude (RMC latitude x 100,000)
4 bytes	Normalized longitude (RMC longitude x 100,000)
2 bytes	Speed in knots
2 bytes	Heading
1 byte	GPS data validity: 0x"A" = valid; 0x"V" = invalid; 0x"B" = buffered valid; 0x"W" = buffered invalid.
1 byte	Number of satellites used for position fix
1 byte	Position type (from GGA message)
1 byte	Digital input state (0= off, 1=on): bit 0 = input #1, bit 1 = input #2... bit 5 = input #6, bit 6 = Not used, bit 7 = ignition status.
2 bytes	Altitude in meters
2 bytes	Differential correction age (only valid if differential correction being used)
4 bytes	Time (based on number of seconds since 00:00:00 January 1st 1970)

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.1.2 Message Type 88, ULCP message with Acceleration/Deceleration and GPS information

Header: **0x58 0xSS 0x06 0x00 0x00 0xNN 0x0000**

Where **NN** is the message length range 0x13 to 0x1D - dependent on the Modem ID string length.

Message body:

Hex	Description
4 bytes	Normalized latitude (RMC latitude x 100,000)
4 bytes	Normalized longitude (RMC longitude x 100,000)
2 bytes	Speed in km/h
2 bytes	Acceleration/Deceleration in km/h/s x 10
4 bytes	Time (based on number of seconds since 00:00:00 January 1st 1970)
1 byte	GPS data validity: 0x"A" = valid; 0x"V" = invalid; 0x"B" = buffered valid; 0x"W" = buffered invalid.
1 byte	GPS quality: 0 = not valid; 1 = valid
1 to 11 bytes	Modem ID: ASCII string

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.13 Message Type 89, ULCP binary format, Modem ID/Firmware, Revision/Odometer value

Header: **0x59 0xSS 0x06 0x00 0x00 0xNN 0x0000**

Where NN is the message length - dependent on the Modem ID string length and on the Firmware Revision string length.

Message body:

Hex	Description
11 bytes	Modem ID in ASCII
<= 32 bytes	Firmware Revision in ASCII
4 bytes	Odometer (m) in little endian byte order

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.14 Message Type 90, ULCP binary format, Odometer value

Header: **0x5A 0xSS 0x06 0x00 0x00 0x04 0x0000**

Message body:

Hex	Description
4 bytes	Odometer (m) in big endian byte order

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.15 Message Type 92, ULCP binary format, Wireless Link TX/RX Data Count with Modem ID

Header: **0x5C 0xSS 0x06 0x00 0x00 0xNN 0x0000**

Where NN is the message length - dependent on the Modem ID string length.

Message body:

Hex	Description
8 bytes	Amount of data transmitted over the wireless link (MB) in little endian byte order
8 bytes	Amount of data received over the wireless link (MB) in little endian byte order
<= 11 bytes	Modem ID in ASCII

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.16 Message Type 98, ULCP binary format, Digital Inputs plus GPS data

Header: **0x62 0xSS 0x06 0x00 0x00 0x1c 0x0000**

Message body:

Hex	Description
4 bytes	Normalized latitude (RMC latitude x 100,000)
4 bytes	Normalized longitude (RMC longitude x 100,000)
2 bytes	Speed in knots
2 bytes	Heading
1 byte	GPS data validity: 0x"A" = valid; 0x"V" = invalid
1 byte	Number of satellites used for position fix
1 byte	Position type (from GGA message)
1 byte	Digital input state (0=off, 1=on): bit 0 = input #1, bit 1 = input #2...bit 5 = input #6, bit 6 = RF switch box output mode (1 = RF off, 0 = RF on), bit 7 = ignition status.
2 bytes	Altitude in meters
2 bytes	Differential correction age (only valid if differential correction being used)
4 bytes	Time (based on number of seconds since 00:00:00 January 1st 1970)
1 byte	Digital output state (0= off, 1=on): bit 0 = output #1, bit 1 = output #2, bit 2 = output #3, bit 3 = output #4, bit 4 ... bit 7 = Not used
0x00	Not used
0x00	Event source: None
0x00	Event reason: None

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.17 Message Type 100, Trimble proprietary TAIP PV message

This is the standard TAIP PV response message of format:

>RPVAAAAASBBCCCCSDDDEEEFFFGGGHI<

Where:

AAAAA is the GPS time in seconds

S is + or –

SBBCCCC is the Latitude in degrees and decimal degrees

SDDDEEEE is the Longitude in degrees and decimal degrees

FFF is the speed in mph

GGG is the heading in degrees

H is the fix mode: 0 = 2D, 1 = 3D, 9 = no fix available

I is the data age: 2 = <10sec, 1 = >10sec, 0 = not available

Example:

>RPV81854+4902565+1220996700000012<

9.18 Message Type 101, Trimble Proprietary LN message

This is the standard TAIP LN response message of format:

```
>RLNAAAAABBBSCDDDDDDSEEEFFFFFFFSGGGGGGHIIJSKKKLMMMNOOPPQQ.....PPQRRRRRRRRR
RRXT<
```

Where:

AAAAA.BBB is the GPS time in seconds and decimal seconds

S is + or –

SCC.DDDDDDD is the Latitude in degrees and decimal degrees

SEEE.FFFFFFFF is the Longitude in degrees and decimal degrees

SGGGGGG.HH is the altitude above mean sea level in feet and decimal feet

III.J is the horizontal speed in mph and decimal mph

SKKK.L is the vertical speed in mph and decimal mph

MMM.N is the heading in degrees and decimal degrees

OO is the number of SVs (satellites) used

PP is the SV ID for each satellite used

QQ is the IODE for each satellite used, but it should be always **zero** because it is not supported

RRRRRRRRRR is not used

X is the fix mode: 0 = 2D, 1 = 3D, 9 = no fix available

T is the data age: 2 = <10sec, 1 = >10sec, 0 = not available

Example:

```
>RLN83830000+490256603+1220996704+000001240000+0000000008130007000800190023002
80003002500000000000012<
```

9.19 Message Type 112, ULCP binary format, Digital input and Output states, Modem ID and GPS data

Header: **0x70 0xSS 0x06 0x00 0x00 0xNN 0x0000**

Where **NN** is the message length range 0x1d to 0x27 - dependant on the Modem ID string length.

Note: This message is similar to message type 98, but adds output state information as well as modem ID

Message body:

Hex	Description
4 bytes	Normalized latitude (RMC latitude x 100,000)
4 bytes	Normalized longitude (RMC longitude x 100,000)
2 bytes	Speed in knots
2 bytes	Heading
1 byte	GPS data validity: 0x"A" = valid; 0x"V" = invalid
1 byte	Number of satellites used for position fix
1 byte	Position type (from GGA message)
1 byte	Digital input state (0= off, 1=on): bit 0 = input #1, bit 1 = input #2...bit 5 = input #6, bit 6 = RF switch box output mode (1 = RF off, 0 = RF on), bit 7 = ignition status.
2 bytes	Altitude in meters
2 bytes	Differential correction age (only valid if differential correction being used)
4 bytes	Time (based on number of seconds since 00:00:00 January 1st 1970)
1 byte	Digital output state (0= off, 1=on): bit 0 = output #1, bit 1 = output #2, bit 2 = output #3, bit 3 = output #4, bit 4 ... bit 7 = Not used
0x00	Not used
0x00	Event source: None
0x00	Event reason: None
1 to 11 bytes	Modem ID: ASCII string

Note: ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

9.20 Message Type I 14, \$PGPS

Proprietary NMEA message based on the NMEA \$GPRMC message with the addition of altitude, number of satellites in use, and the modem's ID.

Message format is:

\$PGPS,hhmmss.ss,v,IIII.IIII,a,yyyyy.yyyy,b,ccc.c,ddd.d,ddmmyy,seeeee,f,gggggggggg*hh<CR><LF>

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

IIII.IIII is the position latitude in degrees, minutes and decimal minutes

a is N(orth) or S(outh)

yyyyy.yyyy is the position longitude in degrees and decimal degrees

b is E(ast) or W(est)

ccc.c is the horizontal velocity in knots

ddd.d is the heading in degrees (relative to true north)

ddmmyy is the day, month and year

s is sign + or – for altitude above or below mean sea level
eeee is the altitude in metres
f is the number of satellites in use (range 0 to 8)
gggggggggg is the modems ID (padded with zeros at end if < 11 characters)
hh is the message checksum

Example:

```
$PGPS,224820.00,A,4915.3897,N,12259.8031,W,000.0,000.0,200409,+00007,6,0960489
0968*4F
```

9.2 I Message Type 115, \$PKML

Proprietary NMEA message very similar to message 114 with the only difference being the format of the modem ID field. The \$PKML is used in the [KMLServer](#) application for plotting data within the [Google Earth](#) Application.

Message format is:

```
$PKML,hhmmss.ss,v,lll.llll,a,yyyyy.yyyy,b,ccc.c,ddd.d,ddmmyy,seeee,f,gggggggggg*hh<CR><LF>
```

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds
v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data
lll.llll is the position latitude in degrees, minutes and decimal minutes
a is N(orth) or S(outh)
yyyyy.yyyy is the position longitude in degrees and decimal degrees
b is E(ast) or W(est)
ccc.c is the horizontal velocity in knots
ddd.d is the heading in degrees (relative to true north)
ddmmyy is the day, month and year
s is sign + or – for altitude above or below mean sea level
eeee is the altitude in metres
f is the number of satellites in use (range 0 to 12)
gggggggggg is the modem's ID (shortened if < 11 characters)
hh is the message checksum

Example:

```
$PKML,224820.00,A,4915.3897,N,12259.8031,W,000.0,000.0,200409,+00007,6,0960489
0968*41
```

9.22 Message Type 116, \$PPWR

Proprietary NMEA message providing the modem's current supply voltage (Vcc), standby signal/ignition status (on or off), and the internal temperature.

Message format is:

\$PPWR,vv.vv,i,tt*hh<CR><LF>

Where:

vv.vv is the modem supply voltage in volts.

i is the standby signal/ignition status: 0 = off; 1 = on.

tt is the modem's internal temperature in degrees Celsius.

hh is the message checksum

Example:

\$PPWR,14.12,1,43*37

9.23 Message Type 117, \$PRFI

Proprietary NMEA message containing CDMA network information to assist in network diagnostics.

Note: parameters for this command are only available for specific data cards/modules.

Message format is:

\$PRFI,aaaa,rdBm,tdBm,b,c,e,s*hh<CR><LF>

Where:

aaaa is the network System ID (SID)

r is the current EVDO RSSI value

t is the current TX power adjust value

b is the band class: 0 = 800MHz; 1 = 1900MHz

c is the current center channel number

e is the current Ec/Io value

s is the current Slot Cycle Index (SCI)

hh is the message checksum

Example:

\$PRFI,16422,-81dBm,-0dBm,1,255,8,2*22

9.24 Message Type 117, \$PRFI

Proprietary NMEA message containing CDMA network information to assist in network diagnostics.

Note: parameters for this command are only available for specific data cards/modules.

Message format is:

\$PRFI,aaaa,rdBm,tdBm,b,c,e,s*hh<CR><LF>

Where:

aaaa is the network System ID (SID)

r is the current EVDO RSSI value

t is the current TX power adjust value

b is the band class: 0 = 800MHz; 1 = 1900MHz

c is the current center channel number

e is the current Ec/Io value

s is the current Slot Cycle Index (SCI)

hh is the message checksum

Example:

`$PRFI,16422,-81dBm,-0dBm,1,255,8,2*22`

9.25 Message Type 118, \$GPGSV

Standard NMEA message containing the number of satellites in view, their ID, elevation, azimuth, and SNR value.

Up to four satellites can be contained in a single GSV string so up to three strings are possible to cover up to 12 satellites.

Message format is:

\$GPGSV,m,n,vv,i1,e1,a1,s1,i2,e2,a2,s2,i3,e3,a3,s3,i4,e4,a4,s4,*hh<CR><LF>

Where:

m is the total number of GSV messages in this sequence: 1 to 3

n is the sequence number of this message: 1, 2 or 3

vv is the number of satellites in view

i1-4 is the satellite ID

e1-4 is the satellite elevation in degrees

a1-4 is the satellite azimuth in degrees true

s1 is the satellite SNR in dB

hh is the message checksum

Example:

`$GPGSV,3,1,09,11,08,210,41,25,13,222,39,20,76,229,46,23,54,281,32*73`

`$GPGSV,3,2,09,31,39,054,,32,62,149,46,16,24,132,36,04,18,316,*7E`

`$GPGSV,3,3,09,13,21,271,30,00,00,000,,00,00,000,,00,00,000,*76`

9.26 Message Type 119, \$POBDA

Proprietary NMEA message containing OBD II information captured from a vehicle. There are 4 available messages for reporting OBD II/J1939 data, each message can return information on up to 4 parameters based on the OBDII/J1939 parameters table.

Message format is:

\$POBDA,v,px=xxxxxx,[px=xxxxxx],[px=xxxxxx],[px=xxxxxx]*hh<CR><LF>

Note: the number and type of **px** values are based on the configuration of pobda thru pobdd commands.

Where:

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

px=xxxxx is the parameter ID **px** followed by the value of the parameter **xxxxx**

hh is the message checksum

Example:

\$POBDA,V*22

9.27 Message Type 120, \$POBDB

Proprietary NMEA message containing OBD II information captured from a vehicle. There are 4 available messages for reporting OBD II/J1939 data, each message can return information on up to 4 parameters based on the OBDII/J1939 parameters table.

Message format is:

\$POBDB,v,px=xxxxxx,[px=xxxxxx],[px=xxxxxx],[px=xxxxxx]*hh<CR><LF>

Note: the number and type of **px** values are based on the configuration of pobda thru pobdd commands.

Where:

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

px=xxxxx is the parameter ID **px** followed by the value of the parameter **xxxxx**

hh is the message checksum

Example:

\$POBDB,V*21

9.28 Message Type 121, \$POBDC

Proprietary NMEA message containing OBD II information captured from a vehicle. There are 4 available messages for reporting OBD II/J1939 data, each message can return information on up to 4 parameters based on the OBDII/J1939 parameters table.

Message format is:

\$POBDC,v,px=xxxxxx,[px=xxxxxx],[px=xxxxxx],[px=xxxxxx]*hh<CR><LF>

Note: the number and type of **px** values are based on the configuration of pobda thru pobdd commands.

Where:

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

px=xxxxx is the parameter ID **px** followed by the value of the parameter **xxxxx**

hh is the message checksum

Example:

\$POBDC,V*20

9.29 Message Type I 22, \$POBDD

Proprietary NMEA message containing OBD II information captured from a vehicle. There are 4 available messages for reporting OBD II/J1939 data, each message can return information on up to 4 parameters based on the OBDII/J1939 parameters table.

Message format is:

\$POBDD,v,px=xxxxxx,[px=xxxxxx],[px=xxxxxx],[px=xxxxxx]*hh<CR><LF>

Note: the number and type of **px** values are based on the configuration of pobda thru pobdd commands.

Where:

v is the data validity flag: A = valid current data, B = valid stored data, V = invalid current data, W = invalid stored data

px=xxxxx is the parameter ID **px** followed by the value of the parameter **xxxxx**

hh is the message checksum

Example:

\$POBDD,V*27

9.30 Message Type I 36, \$PACCEL

Proprietary NMEA message containing hard acceleration/deceleration information obtained from GPS velocity data. This NMEA message is designed to be sent whenever the GPS hard acceleration/deceleration thresholds are exceeded (see cmd gpsaccel).

Message format is:

\$PACCEL,hmmss.ss, llll.llll,a,yyyyy.yyyy,b,vvv.v,uuu.u,ddmmyy,gggggggggg*hh<CR><LF>

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

llll.llll is the position latitude in degrees, minutes and decimal minutes

a is N(orth) or S(outh)

yyyyy.yyyy is the position longitude in degrees, minutes and decimal minutes

b is E(ast) or W(est)

vvv.v is the velocity in km/h

uuu.u is the acceleration/deceleration in km/h/s

ddmmyy is the day, month and year

gggggggggg is the modems ID

hh is the message checksum

Example:

```
$PACCEL,225623.00,4915.3907,N,12259.8040,W,000.0,000.0,200409,09604890968*06
```

9.31 Message Type 137, \$PODO

Proprietary NMEA message containing information about the odometer, or the total distance travelled, obtained via GPS position data. This returns the same value as cmd odometer.

Message format is:

```
$PODO,hhmmss.ss,ooooooo,ddmmyy,gggggggggg*hh<CR><LF>
```

Where:

hhmmss.ss is the UTC time in hours, minutes, seconds, and decimal seconds

ooooooo is the odometer value in km

ddmmyy is the day, month and year

gggggggggg is the modems ID

hh is the message checksum

Example:

```
$PODO,225623.00,27,200409,09604890968*0F
```

9.32 Message Type 255, ULCP binary format, Custom Message

Header: **0xFF 0xSS 0x06 0x00 0x00 0xNN 0x0000**

Where NN is the message length.

Message body:

Hex	Description
<= 255 bytes	User Message

Note: This message type, 255, is for specific customers. ULCP binary messages should not be used for local serial report mode 1 and 2 in applications where timed message delivery is critical.

Example:

To send the string, "TEST"

Send "0xFF 01 06 00 00 04 00 00 54 45 53 54"

IO Email Message Format

E-mail reporting is configured in the following manner:

emailsv sets the mail server the modem will use to relay the email message.

reppmail, gpsemail, ioemail configure the e-mail address to send the reports too.

reptype, gpsrep, iorep configure the reporting mechanism to use email vs. other mechanisms such as UDP or TCP

repaddmes, gpsaddmes or ioaddmes adds messages to the report that make up the body of the email message.

The "From:" field of the email will read:

gggggggggg @ xxx.xxx.xxx.xxx

gggggggggg is the modem ID configured using modemid.

xxx.xxx.xxx.xxx is the modem IP address.

From: 09604890968@96.1.5.204

To:

Cc:

Subject:

To: youremail@domain.com

Subject: Wireless Report

Return-Path: xxxxx@xxxxx.xxx

Message-ID: <DC2K3niBdw9KB0YMXor00000350@xxxxxx.xxx>

X-OriginalArrivalTime: 20 Apr 2009 22:54:00.0468 (UTC)

FILETIME=[E5071D40:01C9C20A]

Date: 20 Apr 2009 15:54:00 -0700

\$POBDD,V*27

\$PACCEL,225623.00,4915.3907,N,12259.8040,W,000.0,000.0,200409,09604890968*06

\$PODO,225623.00,27,200409,09604890968*0F

I I MODBUS Messages

The CTM-15x modem can be used in [MODBUS](#) mode for SCADA applications. This allows the modem to operate as a simple SCADA device that can understand and format MODBUS messages based on various modem parameters, such as inputs and outputs, device information and GPS position. The modem can simultaneously support a MODBUS slave gateway connection.

The modem can be configured to "read" and "write" MODBUS messages using the mode command and modbusadd commands.

The MODBUS message format is defined by the MODBUS organization.

MODBUS Message Format

MODBUS uses a binary format expressed in HEX. It is a Request/Response protocol with allowance for Report by Exception Responses from the slave device.

Parameter	Format
MODBUS ID 0xII	1 byte, range 1 to 247
Function code 0xFF	1 byte defined by MODBUS protocol
Data 0xNN.....0xNN	Variable size dependant on function code
Error check 0xZZZZ	2 bytes CRC (not used in MODBUS TCP messages)

The following MODBUS messages are supported by the CTM-15x for reading and setting of its Input/Output.

I I . I Read Digital Outputs

In MODBUS term this is called "read coils" and has function code 0x01.

Request message: **0xII 0x01 0x00 0x00 0x00 0x04 0xZZ 0xZZ**

Where:

0xII is the modem's assigned MODBUS ID

0xZZ 0xZZ is the CRC checksum for this message

Response message: **0xII 0x01 0x01 0xSS 0xZZ 0xZZ**

Where:

0xSS is the current state of the 4 digital outputs

Bit 0 represents output #1

Bit 1 represents output #2

Bit 2 represents output #3

Bit 3 represents output #4

1.2 Set Digital Output

In MODBUS term this is called “**write coil**” and has function code 0x05.

Request message: **0xII 0x05 0x00 0xWW 0xSS 0x00 0xZZ 0xZZ**

Where:

0xII is the modem’s assigned MODBUS ID

0xWW is the output to be set: range 0x00 to 0x03 corresponding with outputs 1 through 4

0xSS is the output set state: 0x00 = off, 0xFF = on.

0xZZ 0xZZ is the CRC checksum for this message

Response: **0xII 0x05 0x00 0xWW 0xSS 0x00 0xZZ 0xZZ**

Where:

0xWW is the output set: range 0x00 to 0x03 corresponding with outputs 1 through 4

0xSS is the set state of the output: 0x00 = off, 0xFF = on.

1.3 Read Digital Inputs

In MODBUS term this is called “**read discrete inputs**” and has function code 0x02.

Request message: **0xII 0x02 0x00 0x00 0x00 0x06 0xZZ 0xZZ**

Where:

0xII is the modem’s assigned MODBUS ID

0xZZ 0xZZ is the CRC checksum for this message

Response message: **0xII 0x02 0x01 0xSS 0xZZ 0xZZ**

Where:

0xSS is the current state of the 6 digital inputs

Bit 0 represents output #1

Bit 1 represents output #2

Bit 2 represents output #3
Bit 3 represents output #4
Bit 4 represents output #5
Bit 5 represents output #6

1.4 Read Analog Inputs

In MODBUS term this is called “**read input registers**” and has function code 0x04.

Request message: **0xII 0x04 0xSS 0xSS 0xNN 0xNN 0xZZ 0xZZ**

Where:

0xII is the modem’s assigned MODBUS ID
0xSS 0xSS is the start address for reading registers
0xNN 0xNN is the number of registers to read
0xZZ 0xZZ is the CRC checksum for this message

Example:

To read all the modem’s six analog input values:

0xII 0x04 0x00 0x00 0x00 0x06 0xZZ 0xZZ

Response message:

0xII 0x04 0x0C 0xH1 0xL1 0xH2 0xL2 0xH3 0xL3 0xH4 0xL4 0xH5 0xL5 0xH6 0xL6
 0xZZ 0xZZ

Where:

0xHn is the high byte for analog input n
0xLn is the low byte for analog input n

Reg. #	Register content	Notes
0 – 5	Analog input 1 to 6 values	Value in volts x 100, big endian byte order
6	Modem supply Vcc	volts x 100, big endian byte order
7	Modem 1xRTT RSSI value	HEX, big endian byte order – units dBm (without the negative sign)
8	Modem internal temperature	HEX, big endian byte order – units degrees Celsius
9	GPS day & month	HEX
10	GPS year	HEX, big endian byte order
11	GPS hours & minutes	HEX
12	GPS seconds & GPS validity flag	Seconds in HEX, Validity flag in ASCII: A = valid; V = invalid
13 – 14	GPS Latitude	Floating point radian format, little endian byte order. To convert to degrees multiply by 180/pi (negative numbers are South, positive are North)
15 – 16	GPS Longitude	Floating point radian format, little endian byte order. To convert to degrees multiply by 180/pi (negative numbers are West, positive are East)
17	GPS speed	Value in m/sec x 10
18	GPS heading	Value 0 to 359 degrees (integer)

11.5 Error response

If the modem is not able to correctly respond to a request then it will send an error response.

Error response format: **0xII 0x8N 0xXX 0xZZ 0xZZ**

Where:

0xII is the modem's assigned MODBUS ID

0x8N is the error code corresponding with the request:

0x81 is for read coils

0x82 is for read discrete inputs

0x84 is for read input registers

0x85 is for write coil

0xXX is the exception code: 0x01, 0x02, 0x03, or 0x04

0xZZ 0xZZ is the CRC checksum for this message

11.6 MODBUS TCP Messages

MODBUS TCP messages are identical to those used with standard MODBUS except that they drop the two byte CRC check sum at the end of every message.

Parameter	Format
MODBUS ID	0xNN 1 byte, range 1 to 247
Function code	0xNN 1 byte defined by MODBUS protocol
Data	0xNN.....0xNN Variable size dependant on function code

12 ULCP Remote Configuration Messages

The modem may be remotely configured by sending it **ULCP** configuration messages. Configuration messages are sent as **UDP** packets to port **6100** of the modem.

12.1 ULCP Message Format

Hex	Description
0xPP	Packet type – defines the message type:
	0x59 = Set output
	0x5B = Execute application-specific script
	0x50 = NMEA GGA query
	0x52 = NMEA RMC query
	0x55 = GPS ULCP binary data query
	0x56 = Delta-based GPS report query and setting
	0x57 = Time-based GPS report query and setting
0xSS	Sequence number – incremented for each message.
0xCC	Command type:
	0x00 = Query
	0x01 = Response to query
	0x02 = Set
	0x03 = response to set
	0x06 = Event report
0x00	Async time – not used so set to 0x00
0x00	Error code – not used so set to 0x00
0xLL	Message length (number of bytes following the password)
0x0000	Password – default 0x0000
0xDD.....	Data – message body of length defined by message length above

12.2 ULCP Remote Configuration Messages

12.2.1 Set Digital Outputs

Request header: **0x59 0xSS 0x02 0x00 0x00 0x08 0x0000**

Request message body:

Hex	Description
1 byte	Output #1: 0x00 = turn off; 0xFF = turn on; 0xNN = turn on for 0xNN x 50 ms, then turn off
1 byte	Output #2: 0x00 = turn off; 0xFF = turn on; 0xNN = turn on for 0xNN x 50 ms, then turn off
1 byte	Output #3: 0x00 = turn off; 0xFF = turn on; 0xNN = turn on for 0xNN x 50 ms, then turn off
1 byte	Output #4: 0x00 = turn off; 0xFF = turn on; 0xNN = turn on for 0xNN x 50 ms, then turn off
0x00000000	Not used

If the command was not successful then no response is sent.

Response header: **0x59 0xSS 0x03 0x00 0x00 0x00 0xNNNN**

Where **NNNN** is the password.

Response message body: None.

I 2.2.2 Execute Application-Specific Script

Request header: **0x5B 0xSS 0x02 0x00 0x00 0x08 0x0000**

Request message body:

Hex	Description
1 byte	0x00 = Execute application-specific script 0; 0x01 = Execute application-specific script 1
0x0000000000000000	Not used

If the command was not successful then no response is sent.

Response header: **0x5B 0xSS 0x03 0x00 0x00 0x00 0xNNNN**

Where **NNNN** is the password.

Response message body: None.

I 2.2.3 NMEA GGA Query

Request header: **0x50 0xSS 0x00 0x00 0x00 0x00 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x50 0xSS 0x01 0x00 0x00 0x00 0xNNNN**

Where **NNNN** is the password.

Response message body:

Refer to **Message Type 80 \$GPGGA**

I 2.2.4 NMEA RMC Query

Request header: **0x52 0xSS 0x00 0x00 0x00 0x00 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x52 0xSS 0x01 0x00 0x00 0x00 0xNNNN**

Where **NNNN** is the password.

Response message body:

Refer to **Message Type 82 \$GPRMC**

12.2.5 ULCP Binary Position Query

Request header: **0x55 0xSS 0x00 0x00 0x00 0x00 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x55 0xSS 0x01 0x00 0x00 0x18 0xNNNN**

Where **NNNN** is the password.

Response message body:

Refer to **Message Type 85 ULCP binary format GPS data message GPSULCPP0S**.

12.2.6 Wireless Link Data Count Query

Request header: **0x5C 0xSS 0x00 0x00 0x00 0x08 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x55 0xSS 0x01 0x00 0x00 0xLL 0xNNNN**

Where **LL** is the length - dependent on the Modem ID string length, **NNNN** is the password.

Response message body:

Refer to Message Type 92, ULCP binary format, Wireless Link TX/RX Data Count with Modem ID **ULCPLINKDATACOUNT**.

12.2.7 Time Based Reporting

Setup

Request header: **0x57 0xSS 0x02 0x00 0x00 0x18 0x0000**

Request message body:

Hex	Description
4 bytes	Report destination IP address: xx.xx.xx.xx If 0.0.0.0 is set then use the IP address of this incoming setup message
4 bytes	Report source IP address (the modems IP address): xx.xx.xx.xx
2 bytes	Report destination UDP Port number. If 0 is set then use the port number of this incoming setup message
2 bytes	Report source UDP port number: set to 6100
2 bytes	Report time. Range 1 to 65535 seconds. 0 disables time based reporting
1 byte	Control flags:
	Bit 0 is used to make time based reporting active: 1 = active; 0 = inactive (switch off the start-up reporting)
	Bit 1 is used to save this configuration to NV memory, but currently not supported : 0 = do not

	save; 1 = save to NV memory.
	Bit 2 is used to select the report destination IP address: when bit2 is 1 = use the IP address(destination UDP Port number) configured above; when bit2 is 0 = use the IP address(fixed UDP Port number 6101) of this incoming setup message.
	Bit 3 is used to select the message mode: 1 = ASCII mode (no ULCP header); 0 = with ULCP header
1 byte	Number of messages to report
8 bytes	Message list: up to 8 messages may be specified. Refer to the above list of possible messages

If the command was not successful then no response is sent.

Response header: **0x57 0xSS 0x03 0x00 0x00 0x18 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

Query

Request header: **0x57 0xSS 0x00 0x00 0x00 0x00 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x57 0xSS 0x01 0x00 0x00 0x18 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

I 2.2.8 Delta Position Based Reporting

Setup

Request header: **0x56 0xSS 0x02 0x00 0x00 0x18 0x0000**

Request message body:

Hex	Description
4 bytes	Report destination IP address: xx.xx.xx.xx If 0.0.0.0 is set then use the IP address of this incoming setup message
4 bytes	Report source IP address (the modems IP address): xx.xx.xx.xx
2 bytes	Report destination UDP Port number. If 0 is set then use the port number of this incoming setup message
2 bytes	Report source UDP port number: set to 6100
2 bytes	Report distance: range 1 to 65535 metres – 0 disables distance based reporting

2 bytes	Maximum report time: sets a timer to send reports if the unit has not moved the set distance
2 bytes	Minimum report time: sets a minimum time between reports
1 byte	Control flags:
	Bit 0 is used to make time based reporting active: 1 = active; 0 = inactive (switch off the start-up reporting)
	Bit 1 is used to save this configuration to NV memory, but currently not supported : 0 = do not save; 1 = save to NV memory.
	Bit 2 is used to select the report destination IP address:
	when bit2 is 1 = use the IP address(destination UDP Port number) configured above;
	when bit2 is 0 = use the IP address(fixed UDP Port number 6101) of this incoming setup message.
	Bit 3 is used to select the message mode: 1 = ASCII mode (no ULCP header); 0 = with ULCP header
1 byte	Number of messages to report
8 bytes	Message list: up to 8 messages may be specified. Refer to the above list of possible messages

If the command was not successful then no response is sent.

Response header: **0x56 0xSS 0x03 0x00 0x00 0x18 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

Query

Request header: **0x56 0xSS 0x00 0x00 0x00 0x00 0x0000**

Request message body: None.

If the command was not successful then no response is sent.

Response header: **0x56 0xSS 0x01 0x00 0x00 0x18 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

2.2.9 Download Script Files

Request header: **0x5E 0xSS 0x02 0x00 0x00 0xLL 0x0000**

Where **0xLL** is the length of the message body.

Request message body:

Parameter	Length
script-name	0 to W bytes
delimiter1	1 byte - 0x2C(,)
url	1 to X bytes
delimiter2	1 byte - 0x2C(,)
username	0 to Y bytes
delimiter3	1 byte - 0x2C(,)
passwd	0 to Z bytes

Where the sum of W, X, Y and Z is not over 252 to make 0xLL not exceed the maximum, 0xFF.

If the command was not successful then no response is sent.

Response header: **0x5E 0xSS 0x03 0x00 0x00 0xLL 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

12.2.10 Trigger Reports

Request header: **0x5F 0xSS 0x02 0x00 0x00 0xLL 0x0000**

Where 0xLL is in the range of 0x10 to 0x14 depending on the number of the message list.

Request message body:

Hex	Description
2 bytes	1st report number
2 bytes	2nd report number
2 bytes	3rd report number
2 bytes	4th report number
2 bytes	5th report number
2 bytes	6th report number
2 bytes	7th report number
2 bytes	8th report number
0 to 4 bytes	Message list: up to 4 messages may be specified. Append these messages to the reports.

where report number is between 1 and 999.

If the command was not successful then no response is sent.

Response header: **0x5F 0xSS 0x03 0x00 0x00 0xLL 0xNNNN**

Where **NNNN** is the password.

Response message body: the message body as defined above

Note 1: Appending NMEA messages to reports using this command when reports are configured using either remote reporting types $r = 3$ (in-band NMEA or ULCP messages in a UDP Packet), or $r = 4$ (in-band NMEA or ULCP messages with a ULCP header and in individual UDP packets) is supported.

Note 2: For remote reporting type $r = 4$, appended NMEA messages will be combined into a single ULCP packet with message type 0xFF (255) for ULCP custom messages.

2.3 Examples

1. Set all OUTPUT ports (1~4) on

Send the following packet to the modem through the UDP port number 6100
0x59 01 02 00 00 08 00 00 FF FF FF FF 00 00 00 00

The response packet will come from the UDP port number 6101

2. Set Delta Position Based Reporting

Destination IP/Port: 192.168.1.20:2000
Time period: every 5(min)~10(max) seconds
Distance: every 7 metre
Message Type: \$GPGGA(0x50) and \$GPRMC(0x52) in ASCII mode

Send the following packet to the modem through the UDP port number 6100
0x56 00 02 00 00 00 00 00 C0 A8 01 14 00 00 00 00
D0 07 D4 17 07 00 0A 00 05 00 0D 02 50 52 00 00
00 00 00 00

The response packet will come from the UDP port number 6101

3. Download a Script File

```
//script file information
script-name - config_mickey_9600.sh
url         - cypress.bc.ca
username    - cypress
passwd      - cypress6004
```

Send the following packet to the modem remote ip through the UDP port number 6100.

```
0x5E 01 02 00 00 37 00 00 63 6F 6E 66 69 67 5F 6D
69 63 6B 65 79 5F 39 36 30 30 2E 73 68 2C 63 79
70 72 65 73 73 2E 62 63 2E 63 61 2C 63 79 70 72
65 73 73 2C 63 79 70 72 65 73 73 36 30 30 34
```

The Message body string is
"config_mickey_9600.sh,cypress.bc.ca,cypress,cypress6004" in ASCII.
The response packet will come from the UDP port number 6100.

4. Trigger Reports

```
//To trigger report number 1 padding message 82 and 80
```

Send the following packet to the modem remote ip through the UDP port number 6100.

```
0x5F 01 02 00 00 12 00 00 00 01 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 52 50
```

The response packet will come from the UDP port number 6100.

13 Technical Specifications

The Chameleon range of wireless data modems are subject to regular feature enhancement. Cellular wireless networks are constantly changing and enhancing their capabilities. In order to meet these changing needs, Cypress Solutions Inc. reserves the right to modify these product specifications without notice.

13.1 FCC/IC Approvals

- EMC FCC part 15 Class A; ICES-003 Class A
 - Mobile device FCC CFR 47 part 2.1091; Industry Canada RSS-102
-

13.2 Temperature

- Operating MIL-STD 810F Method 502-II, -30 to +65 Celsius
 - Storage SAE J1455 4.2.3, -40 to +75 Celsius
-

13.3 Humidity

- 5 to 95%RH SAE J1455 4.2.3, 85-95% RH for two 24hr cycles
-

13.4 Vibration

- 5 to 500Hz MIL-STD 810F Method 514.5C, 1.6 to 2.0 grams
-

I 3.5 Shock

- 40G, 11msec MIL-STD 810F Method 516-I, saw-tooth wave
-

I 3.6 Sealing

- IP41 Protection against objects greater than 1 mm and vertically dripping water
-

I 3.7 Material

- Case 6061 High strength Aluminum with high impact ABS chassis
 - Mounting Bracket Oil & Solvent resistant automotive grade Elastomer mounting bracket
-

I 3.8 Power Supply

- Voltage 9 to 36 VDC
 - Current Operation 350mA typical, 500mA max at 12VDC, <2mA shutdown mode with Wake on Event/timer wake up
 - Protection SAE J1455
-

I 3.9 Host Connectivity

- Ethernet RJ45 10/100 base T
 - RS232 DB9, DCE configuration, MODBUS Serial
 - Protocols PPP, DHCP, PAD (UDP/TCP), SMTP, MODBUS TCP, MODBUS RTU(UDP)
-

I 3.10 I/O

- Outputs 4 Digital outputs, open drain configuration
500mA sink capability, overload protection
 - Inputs 6 Digital or Analog inputs
2.5V +/- 0.5V digital detection threshold, 36VDC withstand 0 to 10V analog range, 10mV resolution, +/- 50mV accuracy
-

- Report format NMEA, ULCP,MODBUS
-

13.1 | RF

13.1.1 | CDMA/EV-DO

- Cellular / 800 Mhz
 - Transmit 824-849 MHz
 - Receive 868-894 MHz
 - PCS / 1900 Mhz
 - Transmit 1850 to 1910 MHz
 - Receive 1930 to 1990 MHz
 - Receive Diversity (both bands)
 - CDMA IS98F compliant
-
- SMA or TNC, 50 ohm connector, +23.5 dBm max

13.1.2 | GSM/GPRS/HSPA

- Cellular 850/1900
 - 850/900MHz GSM/GPRS/EDGE
 - 1800/1900 MHz GSM/GPRS/EDGE
 - SMA or TNC, 50 ohm connector, +24 dBm max
-

13.1.2 | GPS

- Type 12 channel, continuous tracking
 - Accuracy <2.5 metres 50%, <5m 90%
 - Acquisition Cold start < 38 secs typ.; Hot start < 3 secs typ.; Reacquisition <2secs typ
 - Sensitivity: Tracking -160dBm, Standard Acquisition -142 dBm
 - Report format NMEA, TAIP, ULCP
 - Store & Forward 2,400 reports
 - Antenna 3.3VDC Active, MCX connector or SMA
-

13.1.3 | Physical

- Width 172mm
 - Depth 98mm (excluding cabling)
 - Height 42mm (CTM-155) 54mm (CTM-152)
-

- Weight 500 grams

14 Technical Support

For information about your CDMA network account, please contact your Network Operator: have the ESN and telephone number of the modem available to provide on the call.

www.cypress.bc.ca

**Cypress Solutions Service
Support Group**

1.877.985.2878 or 604.294.4465

9.00am to 5.00pm PST

www.cypress.bc.ca

support@cypress.bc.ca