

CYBERNETICS

Operator's

M A N U A L

miSAN-V-Series

*D2D2T Backup with removable
AIT Tape Drive*



UM-MV-86
Rev. B1-0801

Guide to conventions

Throughout the miSAN-V-Series manual, you will find caution and note boxes similar to those below. Please read the contents of the cautions and notes carefully.



Caution

This icon indicates the existence of a potential hazard that could result in personal injury, damage to your equipment or loss of data if the safety instruction is not observed.



Note

This icon indicates useful tips on getting the most from your miSAN-V-Series.

FCC Notice

This equipment is tested to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Table of Contents

Guide to conventions	2
FCC Notice	2
Chapter 1 Introduction to the miSAN	11
miSAN-V-Series Overview	11
Options	11
Features	12
Hardware	12
Software	12
Functionality	13
Network Connection	13
Parallel SCSI Connection	13
High-Speed Archiving	13
Multiple Host Access	13
Selective Device Visibility	13
Web Control Panel	14
Telnet Menu System	14
Network Traffic	14
Information available without password	14
Uninterruptable Power Supply (UPS)	14
Introduction	15
Java™ Installation	15
Telnet Installation	15
iSCSI Initiator Driver Installation	15
Chapter 2 Setting Up the miSAN	17
Installation Requirements	17
Installing the Hardware Components	18
Rackmount Installation	18
Parallel SCSI	18
Connecting the Cables	18
Parallel SCSI	18
Network	19
Management LAN Port (ETH0)	19
iSCSI Network Ports (ETH1, ETH2)	19
Power	19
Connecting Power to an Uninterruptible Power Supply (UPS)	19
Power Button	20
Configuring the Network and iSCSI Settings	21
Prerequisites	21
Network Setup Preparation	21
Network Setup	22
iSCSI Communication	22
Remote iSCSI Target Device Setup	23
miSAN-V-Series iSCSI Features	24
Host iSCSI Setup	24
User Types	24
The Administrator	25
The User	25
The Security Officer	26
Setting Up the miSAN-V-Series Virtual Components	26
Initial Setup Guide	26

Creating Virtual Components	26
Deciding How Many Virtual Tapes to Create	27
Deciding What Kind of Virtual Tape Drives to Create	27
Virtual Standalone Drives	28
Virtual Stacker Drives	28
Deciding How to Assign Virtual Tapes	28
Creating Virtual Tapes	28
Creating Virtual Devices	29
Assigning Virtual Tapes to Virtual Devices	30
Configuring a Physical Stacker	30
Testing the Installation	31
Shut Down	31
Chapter 3 Operating the Web Control Panel	33
Interface Layout	33
Introduction	33
Main Menu Bar Introduction	33
Tools	34
HSTC Options	34
Information	34
Browser links	35
Help	35
Tabs introduction	35
Devices Tab	35
Virtual tape Tab	36
Physical tapes Tab	36
Jobs	36
Messages	36
Main Menu	36
Tools	36
Disk Storage	37
Create Virtual Tapes	38
Basic Tab	39
Advanced Tab	40
Format Disks Tab	40
Configure Virtual Devices	41
Assign Virtual Tapes	42
Physical Stacker Copy Profiles	43
Configure Auto-archive	44
Set Date and Time	45
Update License	46
Export or Import Configuration	46
Rescan Physical Devices	46
Shut Down the HSTC	47
HSTC Options	49
Configuration	49
Device ID order	49
Host vs. job I/O policy	50
Host I/O idle minutes	51
Overwrite non-committed	51
Drive compression for copying	52
Copy volume tags	52
Virtual Device Emulations	52
Receive SNMP messages from UPS	53
Configuring a Tripp Lite® SmartPro®/SmartOnline™ model UPS with	

SNMPWEBCARD	54
Data Compression	55
SCSI Configuration	56
SCSI HBA Ports	56
HBA X direction	56
HBA X base SCSI ID	56
HBA X speed	57
Incoming iSCSI Connections from Hosts	57
iSCSI login control	57
iSCSI access password	57
iSCSI host username	57
iSCSI host password	58
Outgoing iSCSI Connections to Devices	58
Remote iSCSI device X	58
Device X DNS Name or IP address	58
Device X iSCSI Username	58
Device X iSCSI password	58
Setup for using an external iSCSI device for additional Virtual Tape storage	58
Network Configuration	62
Hostname	62
Default gateway	62
Nameserver	62
ethX (1000 Mbps)	62
ethX IP bonding	64
ethX IP address	64
ethX subnet mask	64
ethX MTU	64
bondX	65
bondX IP address	65
bondX subnet mask	65
bondX MTU	65
Message Delivery	65
Send messages by email	66
SMTP server	66
SMTP username	66
SMTP password	66
Email address(es)	66
Accounts	67
Admin	67
User	67
Advanced Options	68
Advanced Menu(s)	68
Define Emulations	68
Debugging	69
Host iSCSI Debug Messages	69
Information	69
Product Information	69
Physical Devices	70
Virtual Devices	70
Virtual device assignments	70
Credits and Licenses	70
Browser links	70
Tabs	71
Devices Tab	71
Virtual Tape Drive Device Panel	72

Mounted Medium listbox	72
Autoload checkbox	72
Virtual Stacker Device Panel	72
Physical Tape Drive Device Panel	75
Menu Button	76
Host access	81
Job control	81
Physical Stacker Device Panel	82
Inventory tab	82
Properties tab	91
Optical Drive Device Panel	91
Virtual Tapes Tab	93
Status Fields	93
Virtual Tape Popup Menu	94
Bar code:	96
Physical Tapes Tab	97
Status Fields	98
Jobs Tab	99
Jobs Table	99
Job Log	100
Activity Monitor	101
Messages Tab	102
USB offload	102
.	103
 Chapter 4 Telnet Menu System	 105
Telnet Menu System	105
miSAN-V-Series Messages	106
Menu Operation	106
SCSI configuration	107
Configure iSCSI hosts	107
Assign virtual devices to hosts	107
Swap SCSI HBA ports	108
Offline Maintenance	108
Display debug output	108
Rescan SCSI buses	108
Reset options to defaults	109
Test system memory	109
Shut Down	109
.	109
 Chapter 5 Using the 3ware Disk Manager®	 111
Browser Requirements	111
Accessing From a Browser	111
Logging In	112
Working with the 3DM Screens	112
3DM Menus	113
Refreshing the Screen	113
3DM Screens and What They're Used For	114
Setting Up 3DM Preferences	115
Setting and Changing 3DM Passwords	115
Managing E-mail Event Notification	115
Caution About Disabling Remote Access	116
Caution About Changing Incoming Port #	116
Setting the Frequency of Page Refreshes	116

3DM2 Reference	117
Controller Summary Page	118
Controller Details Page	119
Unit Information Page	120
Unit Details Page	121
Drive Information Page	122
SMART Details About Drive at Particular Port Page	123
Controller Settings Page	124
Background Task Rate	125
Unit Policies	125
Unit Names	126
Other Controller Settings	126
Scheduling Page	127
About Task Schedules	128
About Self-tests	128
Maintenance Page	129
Rescan Controller	129
Unit Maintenance	130
Unit Information	130
Drive Information	130
Maintenance Task Buttons	131
Available Drives (to Create Units)	132
Alarms Page	133
3DM Settings Page	134
E-mail Notification	135
Password	135
Page Refresh	135
Remote Access	136
Incoming Port #	136
Configuring Units	136
Creating a New Unit	136
Drives to Be Included in the Unit	136
Type of RAID Configuration	137
Rebuilding a Unit	137
Configuring Drives	138
Creating a Hot Spare	138
Adding a Drive	138
Removing a Drive	138
 Chapter 6 Packing and Shipping Instructions	 141
Removing the miSAN-V-Series from its Installation Environment	141
Using the Proper Packing Materials	142
 Chapter 7 Product Specifications	 147
Supported iSCSI Initiators	147
Drive Interface Compatibility	147
Ethernet Interfaces	147
Management LAN Port (ETH0)	147
iSCSI Network Ports (ETH1, ETH2)	148
SCSI Parallel Interfaces	148
Low Voltage Differential (LVD)	148
Physical Dimensions	148
Power Supply	148
Humidity and Temperature	148
Non-operating	148

Operating	148
Appendix A Microsoft® iSCSI Initiator Software Client	A-149
Downloading the Setup Program	149
Installing the Software	151
Configuring the iSCSI Initiator	154
Changing initiator node name	155
Adding Target Devices	155
Creating System Dependencies	158
Using iSCSI Disk Devices with the iSCSI Initiator	158
Using Backup Software with the iSCSI Initiator	160
Logging Off	161
Appendix B Linux iSCSI Initiator	B-163
Introduction	163
Installation	163
Linux Kernel 2.6 Notes	163
Core-iSCSI Setup	164
Debian Ik 2.6	164
Red Hat 9 & Enterprise Linux 3	165
SuSE Linux Pro 9.1	165
Source Compilation	165
Setup	165
Test the setup	165
Appendix C Glossary	C-167
Appendix D Common Questions	D-175
Appendix E Return Policies	E-179
Shipping Damage	179
Hardware Products	179
Software Products	180
Tape Media Products	180
Promotional Items	180
Maintenance Contracts	180
Exceptions to Cybernetics' 30-day Hardware Return Policy:	180
Return Procedure	180
Appendix F Technical Support	F-183
Appendix G Cybernetics miSAN-V-Series Notices	G-i

List of Figures

Figure 2-1 miSAN-V-Series Rear Components	18
Figure 2-2 miSAN-V-Series Front Components	20
Figure 2-3 "Confirm shutdown method" Window	32
Figure 3-1 Main Menu Bar	33
Figure 3-2 "Tools" Menu	34
Figure 3-3 "HSTC Options" Menu	34
Figure 3-4 Information	35
Figure 3-5 Information	35
Figure 3-6 "Browser links" Menu	35
Figure 3-7 "Help" Menu	35
Figure 3-8 "Tools" Menu	37
Figure 3-9 Virtual Tape Disk Space Allocation	38
Figure 3-10 Create Virtual Tapes Basic Tab	40
Figure 3-11 Create Virtual Tapes "Advanced" Tab	40
Figure 3-12 Create Virtual Tapes "Format disks" Tab	41
Figure 3-13 "Configure virtual devices" Window	42
Figure 3-14 "Virtual tape assignments" Window	42
Figure 3-15 "Physical stacker copy profiles" Window	43
Figure 3-16 "Auto-archive configuration" Window	44
Figure 3-17 "Set date and time" Window	46
Figure 3-18 "Update License" Window	46
Figure 3-19 "Rescan physical devices" Window	47
Figure 3-20 "Confirm shutdown method" Window	48
Figure 3-21 Configuration	49
Figure 3-22 "Devices" Tab	71
Figure 3-23 Renaming a Virtual Tape Drive	71
Figure 3-24 Virtual Tape Drive Device Panel	72
Figure 3-25 Virtual Stacker Device Panel	73
Figure 3-26 "Move to slot" Popup Menu	74
Figure 3-27 "Move to drive" Popup Menu	74
Figure 3-28 Physical Tape Drive Device Panel	75
Figure 3-29 "Setup offload" Window	77
Figure 3-30 "Select virtual tape" Window	77
Figure 3-31 "Clear VT for offloading" Option	78
Figure 3-32 "Offload disk to tape" Window	79
Figure 3-33 "Load tape onto disk" Window	80
Figure 3-34 Physical Stacker Device Panel	83
Figure 3-35 "Setup offload" Window	84
Figure 3-36 Assigning a Virtual Tape to a Physical Tape	84
Figure 3-37 "Wait for backup" Option	86
Figure 3-38 "Clear VT for offloading" Option	86
Figure 3-39 "Copy selections" Tab	87
Figure 3-40 "Copy profiles" Frame	87
Figure 3-41 "Copy options" Tab	87
Figure 3-42 "Load tapes onto disk" Window	89
Figure 3-43 Assigning Physical Tapes To Copy	89
Figure 3-44 Physical Stacker "Properties" Tab	91
Figure 3-45 Optical Drive Device Panel	92
Figure 3-46 "Select virtual tape to backup" Window	93
Figure 3-47 "Virtual tapes" Tab	93
Figure 3-48 Virtual Tape Popup Menu	94
Figure 3-49 "Rename virtual tapes" Window	94
Figure 3-50 "Select copy destination" Window	95

Figure 3-51 “Confirm data overwrite” Window	95
Figure 3-52 “Manage volume tags” Window	96
Figure 3-53 “Copy profiles” Frame	96
Figure 3-54 “Edit” Tab for Volume Tags.	97
Figure 3-55 Virtual Tape Properties Windows.	97
Figure 3-56 “Physical tapes” Tab	98
Figure 3-57 “Jobs” Tab	99
Figure 3-58 Exporting the “Job log”.	101
Figure 3-59 “Activity monitor” Tab	101
Figure 3-60 “Messages” Tab	102
Figure 3-61 New Message Indicator.	102
Figure 5-1 3DM Main Screen	112
Figure 5-2 3DM Menu Bar.	113
Figure 5-3 Controller Summary Page	118
Figure 5-4 Controller Details Page	119
Figure 5-5 Unit Information Page	120
Figure 5-6 Unit Details Page	121
Figure 5-7 Drive Information Page	122
Figure 5-8 S.M.A.R.T Data Page	123
Figure 5-9 Controller Settings Page	124
Figure 5-10 Scheduling Page	127
Figure 5-11 Maintenance Page	129
Figure 5-12 3DM Settings Page	134
Figure 5-13 Removing a Drive in 3DM	139
Figure 5-14 Result of Removing Drive from Unit in 3DM	140
Figure A-1 Advanced Settings	156

Chapter 1

Introduction to the miSAN

miSAN-V-Series Overview

The Cybernetics miSAN-V-Series is a disk-based storage appliance that runs Cybernetics' CY-HSTC (High Speed Tape Cache) tape virtualization engine. Using the HSTC engine, the miSAN-V-Series emulates conventional tape drives and tape cartridges. Host applications use miSAN-V-Series virtual tapes and drives as conventional backup resources. Virtual drives appear to hosts as physically-attached, parallel SCSI devices. Virtual tapes appear as tape cartridge images written in their native format. The miSAN-V-Series stores virtual tapes securely on disk drives and allows for copying to physical tape cartridges.

miSAN-V-Series virtual drives write and read data using virtual tapes at speeds unreachable with physical devices.

miSAN-V-Series resources are administered remotely over the network using a web browser or telnet terminal. Using the iSCSI protocol, the miSAN-V-Series can function as a network backup solution, by offering tape backup and archiving services to multiple hosts. Virtual tape backups can be automatically duplicated to tape cartridges, assuring data integrity by maintaining redundant tape backups.

The miSAN-V-Series increases the functionality and extends the usefulness of a current parallel SCSI backup solution. iSCSI provides network accessibility for peripheral backup devices. With virtual tape drive autoloading, the miSAN-V-Series handles tapes like a library changer. The internally mounted AIT tape drive allows for integrated tape offload. Attached tape drives and tape libraries, connected remotely via iSCSI, can also be made available for direct host access.

Options

The miSAN-V-Series models use internal hot-swap disk drives for the virtual tape cache. The total storage capacity for the virtual tape cache is based on the number and configuration of the disk drives. For example, the miSAN-V-Series, with six internal disk drives of nearly 750 GB capacity each, will have about 4.5 TB of raw capacity available for the virtual tape cache. However, in a RAID 5 configuration, the usable capacity would be approximately 3.75TB. In the most secure, and recommended configuration of RAID 5 plus Hot Spare, usable capacity would be about 3.0TB.

Standard miSAN-V-Series models include software support for virtual tapes, drives and libraries. Hardware support is offered for data backup and restoration using the integrated SCSI tape drive or via network with the iSCSI interface.

The LVD parallel SCSI interface can allow the miSAN-V-Series to connect directly to a host system, either instead of or in addition to the iSCSI interface, allowing for off-network backup and data restoration.

All miSAN-V-Series models come with an integrated Tape Drive. A new feature for miSAN-V-Series is a removable AIT Tape Drive. If your model comes equipped with this feature, please note that the drive must not be installed or removed while the miSAN-V-Series is powered on. For more details on this feature, please see the Removeable AIT manual that was included in your product documentation CD.



Caution

Although the miSAN-V-Series uses a removable AIT drive, the tape drive is NOT able to be hot swapped in the miSAN-V6. In order to remove or install the tape drive you must power down the miSAN first. Not doing so can cause damage that will make the miSAN inoperable.

Features

Hardware

- Two iSCSI interface ports for data transfer (Gigabit Ethernet, 10/100/1000Base-T)
- One Ethernet interface port for remote administration (Gigabit Ethernet, 10/100/1000Base-T) (Web Control Panel and Telnet Menu System)
- Two 68-pin VHDCI LVD ports ("Host": Ultra160, "Reserved": Ultra320)
- Removable AIT Tape drive
- Up to 6 Hot Swap SATA Disk Drives

Software

- CY-HSTC (High Speed Tape Cache) tape virtualization engine
- Web browser-based control panel
- Telnet menu system control
- iSCSI interface for multiple-host access
- optional Tape Library Control support

Functionality

Network Connection

The miSAN-V-Series includes two Gigabit Ethernet network interfaces (10/100/1000Base-T capable) for iSCSI data transfer. Each interface provides a connection for hosts to access and use the miSAN-V-Series virtual devices like directly-connected SCSI devices. A third Gigabit Ethernet interface (10/100/1000Base-T capable) provides a connection for hosts to configure and operate the miSAN-V-Series via the Web Control Panel and Telnet Menu Interface.

Parallel SCSI Connection

The two installed Ultra 3 Wide LVD parallel SCSI ports are available to provide the option for a direct host connection. With a single parallel SCSI interface, the miSAN-V-Series offers a direct SCSI path to a tape drive or library for archiving virtual tapes to physical tapes. As an option, the miSAN-V-Series can also be connected to a host, so that the directly-connected host can use the miSAN-V-Series, without reducing network bandwidth, while allowing iSCSI remote backups over the network.

High-Speed Archiving

With disk-speed virtual tape access, and gigabit-capable data transfers for iSCSI, the miSAN-V-Series reaches backup speeds that exceed even the fastest SCSI tape drive. miSAN-V-Series hardware and software are tuned to generate the widest possible data pipe for increased archiving speed. Multiple Ethernet interfaces can be aggregated ("bonded") for increased data transfer bandwidth. The RAID-based disk storage provides enhanced data integrity and security. The miSAN-V-Series makes efficient use of storage space and network bandwidth. It transfers stored data in raw block format without the overhead of traditional file systems. This can dramatically narrow the time required for even the most extensive backup schedule. Limited and broad scale restores from virtual tapes are accelerated as well.

Multiple Host Access

The Web Control Panel allows the ability to administer the miSAN-V-Series, using a web browser, from any point on the network. The iSCSI interface allows any iSCSI-capable host system to write data to the miSAN-V-Series.

The miSAN-V-Series can maintain concurrent host connections. This allows multiple hosts to operate and view the status of the miSAN-V-Series simultaneously. The gigabit bandwidth combined with disk-to-disk transfer rates enables the miSAN-V-Series to support and maintain high backup speeds from multiple host systems to multiple virtual tape drives. This level of multitasking greatly decreases the necessary backup time window.

Selective Device Visibility

The miSAN-V-Series allows you to make individual virtual or physical devices available only to selected host systems via iSCSI or a direct parallel SCSI connection. This allows multiple simultaneous backups. Each host system sees only its designated tape device(s) and writes only to its designated tapes at disk-to-disk speeds.

Web Control Panel

The miSAN-V-Series offers a universally compatible Web Control Panel accessible through a network connection. The Web Control Panel is used for configuring, operating and viewing the status of the miSAN-V-Series in real-time. Multiple clients can access the interface using any Java™-enabled web browser. Chapter 3 “Operation” describes the Web Control Panel layout and functions.

Telnet Menu System

The miSAN-V-Series provides an extensive text-based menu system for remote configuration via telnet over a network connection. Used primarily for device and network setup or offline maintenance, the telnet menu system allows a client to view and make changes to the miSAN-V-Series configuration. Chapter 3 “Operation” describes the Telnet Menu System context-sensitive menus and functions.

Network Traffic

Some network traffic is encrypted for security purposes, and some network traffic isn't encrypted.

Encrypted:

- Control link between miSAN and Java applet
- Web browser session to 3ware 3DM2 utility
- iSCSI passwords during login

Not encrypted:

- iSCSI data during backup or restore
- Telnet session to miSAN

It would normally be safe to access the Java applet or 3ware 3DM2 utility over an untrusted network, but iSCSI and telnet should be used only over trusted networks

Information available without password

The miSAN makes the following information available without asking for a password:

- 1) The debug log
- 2) The menu settings page (passwords are not shown)
- 3) The hardware info page
- 4) The Java applet can be downloaded but not used without a password

Uninterruptable Power Supply (UPS)

The miSAN has the ability to receive SNMP messages from a UPS to shut down cleanly before power fails. This feature is turned off by default as a security measure because the SNMP messages don't include passwords for authentication. If you enable this feature,

an illegitimate device on the network could perform a denial-of-service attack on the miSAN by sending it a SNMP message to shut down.

Open Ports

The miSAN has the following open ports:

```
23 Telnet
80 HTTP
162 SNMP-trap
888 3ware 3DM2
3260 iSCSI
18083 Java applet control
Client and Host Software
```

Introduction

The miSAN-V-Series is accessed and controlled over a TCP/IP network connection. Two methods are available: a Java™-based graphical interface and text-only telnet menus. Since some configuration items are available exclusively via either the Java-based Web Control Panel or the Telnet Menu System, both interfaces should be available.

Java™ Installation

The miSAN-V-Series requires at least one host system installed with a web browser and the Java™ plug-in (version 1.4.2 or later) be available on the local network. The Java plug-in is included with most installations of the Java Runtime Environment™ (JRE) or Java Virtual Machine™ (JVM).

Refer to the Sun Microsystems Java website (<http://www.java.sun.com>) for a list of compatible operating systems and download locations. The miSAN-V-Series's Java-based Web Control Panel will not be available until the unit is connected to the network and configured, as described later in this chapter.

Telnet Installation

The miSAN-V-Series requires at least one host system installed with telnet client software for access to the text-only Telnet Menu System. The menu system will not be available until the unit is connected to the network and configured. For convenience, it is recommended that the same host system be used for both the Java™ Web Control Panel and the Telnet Menu System, although this is not required.

iSCSI Initiator Driver Installation

Internet SCSI (iSCSI) refers to a method of transmitting SCSI commands, data and status across Ethernet-based transmission control protocol/Internet protocol (TCP/IP) networks. This allows SCSI devices, such as tape drives, and SCSI-aware software, such as backup applications, to communicate remotely via existing IP networks. To do this, iSCSI uses an interface for both the host system, the *initiator*, and the miSAN-V-Series, the *target*, to encapsulate SCSI within TCP/IP packets.

On a host system (the initiator), the iSCSI interface will typically include a TCP/IP network interface card (NIC) and iSCSI initiator software (driver or daemon) that presents a virtual

SCSI host bus adapter (HBA) to the operating system and application software. To the host system, this appears to be a physical HBA, but all traffic for the iSCSI HBA is encapsulated for delivery via the network to the remote iSCSI target.

Host systems that will transmit commands and data via iSCSI should have iSCSI initiator software installed and configured. iSCSI initiator drivers are available for many operating systems. For host systems running the Windows® operating system, Microsoft® offers an iSCSI initiator driver. See [Appendix A, “Microsoft® iSCSI Initiator Software Client”](#), for information on downloading, installing and configuring the driver. Linux users should see Appendix B “Linux iSCSI Initiator setup..

Host systems for which iSCSI initiator drivers are not available cannot access iSCSI devices directly. For these systems, the Cybernetics iClient device is available, which enables hosts to access remote iSCSI devices as if they were directly connected to the host system. The iClient connects to the SCSI bus on the host system and relays SCSI commands and responses between the host system and the iSCSI target devices via the network.

Chapter 2

Setting Up the miSAN

This chapter provide requirements and instructions for unpacking and installing the miSAN-V-Series:

- Installation Requirements
- Installing the Hardware and Software Components
- Connecting the Cables
- Configuring the Network and iSCSI Settings
- Setting Up the miSAN-V-Series Virtual Components
- Testing the Installation

To ensure correct installation and proper operation, make sure all the items listed in “Installation Requirements” are available before beginning.

Installation Requirements

Make sure the following are available before beginning the installation:

- Level surface (or 2U rackmount space) near a readily accessible power outlet
- Cybernetics miSAN-V-Series unit
- Rackmount hardware kit and tools for rackmount installations
- Standard, 3-prong AC power cord (IEC320 C13 to NEMA 5-15P) for each power supply (2 cords)
- Ethernet cable (CAT 5e or 6 unshielded twisted pair with RJ-45 connector) for each standard network interface (3)
- Parallel SCSI cable with male, 68-pin connector for each SCSI device. Depending on case configuration, the required connector may be either VHDCI 68-pin or High Density 68-pin socket (Ultra Wide SCSI-3).
- Either the Microsoft® Internet Explorer 6.0 or Mozilla™ Firefox® 1.0 Web browser with the Java™ plug-in version 1.4.2 or later, and telnet client software, on a network accessible host system for configuration and operation of the miSAN-V-Series

Installing the Hardware Components

Rackmount Installation

The rackmount installation requires a 2U space in your rack. Follow the instructions included in the rackmount kit.

Parallel SCSI

Host systems that will transmit commands and data via a directly-connected SCSI interface to the miSAN-V-Series should have the host SCSI bus adapter installed and configured.

Connecting the Cables

Parallel SCSI

The miSAN-V-Series includes two installed VHDCI 68-pin LVD ports. Each parallel SCSI port is terminated internally. The port marked “host” is an Ultra160 LVD which is factory-set to connect to an initiator (host system). The port marked “Reserved” or “Unused” is used for the internal tape drive and should not be connected to by the user. The miSAN-V-Series may not function properly if any device is attached to the reserved port..





Figure 2-1 shows the rear view of a typical miSAN-V-Series.

Figure 2-1 miSAN-V-Series Rear Components



Network

Management LAN Port (ETH0)

Using the Management LAN port, connect the miSAN-V-Series to your LAN using a CAT 5e or CAT 6 Ethernet cable. Please note that in some configurations the ETH0 port may be located in a different position than shown in the above illustration. Each port is clearly labeled.

iSCSI Network Ports (ETH1, ETH2)

Using one or both iSCSI network ports, connect the miSAN-V-Series to your LAN, Gigabit Ethernet switch or backup server using a CAT 5e or CAT 6 Ethernet cable. Please note that in some configurations the ETH1 and ETH2 ports may be located in a different position than shown in the above illustration. Each port is clearly labeled.

Power

Using the AC socket on both power supplies, connect the miSAN-V-Series to a readily accessible AC power source using a standard 3-prong power cord for each socket.

Connecting Power to an Uninterruptible Power Supply (UPS)

You should use an Uninterruptible Power Supply (UPS) rated to at least 460 watts with the miSAN-V-Series. This will ensure data buffered in the RAM cache will get written to disk during a power outage. Use both power supplies when connecting the miSAN-V-

Series to a UPS. If you do not use a UPS, each power supply should be connected to a separate power main.



Caution

Both power supplies must be connected to an AC power source, preferably separate power mains. The miSAN-V-Series uses both power supplies simultaneously to provide immediate failover in case one power supply fail



Note

If you use an APC® Smart-UPS® model UPS with a Network Managem Card or a Tripp Lite® SmartPro®/SmartOnline™ model UPS with SNMPWEBCARD, you can configure the UPS to send messages to the HS when the power fails, enabling the HSTC to automatically shut itself do cleanly.

Power Button

The miSAN-V-Series is powered on using the power button on the front panel (See Figure 2-2). Figure 2-2 shows the front view of a typical miSAN-V-Series.

Figure 2-2 miSAN-V-Series Front Components



Configuring the Network and iSCSI Settings

The following sections include procedures for configuring the miSAN-V-Series network and iSCSI settings. You must complete the Network and iSCSI device configuration prior to initially using the miSAN-V-Series.

Prerequisites

Make sure to have the following available to allow for accessing the miSAN-V-Series on a private network:

- Desktop or laptop computer with a JavaScript™-enabled Web browser.
- Standard, 3-prong AC power cord (IEC320 C13 to NEMA 5-15P) for each power supply (2)
- CAT-5 Ethernet cable with RJ-45 connectors, to establish a direct-cable TCP/IP connection
- Network parameters specific to your network: *IP Address*, *Netmask*, *Gateway* (“Default Route”) and *Nameserver*

Network Setup Preparation

1. Make sure the computer is powered on and ready for use.
2. Connect a CAT 5e or CAT 6 ethernet cable between the Administrative LAN interface port (ETH) on the rear of the miSAN-V-Series and the network interface port on the rear of the computer.
3. Power on the miSAN-V-Series using the momentary power switch on the front panel (See Figure 2-2). Wait for the miSAN-V-Series to complete initialization before continuing, after about three minutes.
4. Configure the computer to communicate with the miSAN-V-Series To do so, change the computer’s IP address to an address in the 192.168.1.X subnet (but not 192.168.1.1), for example *192.168.1.10*, and change the subnet mask to *255.255.255.0*.)



Note

Before changing the IP Address and Netmask, make sure to write down their current settings to be used when resetting them later.



Note

When any network parameters are changed, and the changes are committed by clicking OK, the changes will take effect almost immediately.

Network Setup

Certain network parameters must be changed to make the miSAN-V-Series visible on your network.

1. Open the web browser on the computer to the default Management LAN port (“ETH 0”) IP address at **http://192.168.1.1**. A dialog box may appear asking for your approval to load the Web Control Panel Java applet.



2. Approve the Java applet, and wait for it to load before proceeding further.
3. Select “Network Configuration” from “HSTC Options” on the main menu bar. On the “Network Configuration” window, change the network parameters to those that provide access over your network. The default values are shown in the figure to the bottom right.
 - To configure the iSCSI Network ports, change the parameters for “ETH1” and “ETH2”
 - To configure the Management LAN port, change the parameters for “ETH0”
4. Restore the previous network settings for the computer used to configure the miSAN-V-Series to allow the computer to see and communicate with the miSAN-V-Series on your network.
5. Remove the ethernet cable between the Administrative LAN interface port (ETH 0) on the rear of the miSAN-V-Series and the network interface port on the rear of the computer. Replace with a cable that is attached to the network.
6. Reload the Web Control Panel in the browser at the new miSAN-V-Series IP address for the Management LAN port (“ETH0”) to verify the new configuration. After the Web Control Panel loads, you may change the other miSAN-V-Series settings as desired, as well as create virtual tapes and configure virtual devices. If necessary, the Web Control panel may also be reached through the iSCSI ports.

iSCSI Communication

The iSCSI architecture is based on the client-server model, such that host computers are clients, as *initiators*, and iSCSI devices are servers, as *targets*. Each iSCSI device, initiator or target, must have a functioning network interface, with an IP address that is accessible to other iSCSI devices.

A target device should be set up first, so it will be able to respond when an initiator attempts to discover the available iSCSI target devices.

The initiator and target are identified to each other by iSCSI Names. The iSCSI Names must be unique within the operational domain (networks encompassing the initiator and target), and are designed to be unique worldwide. The iSCSI Name may be permanently assigned to a hardware iSCSI device, or it may be constructed automatically as part of the process of installing an iSCSI software driver. If the target includes multiple devices (tape drives, libraries, etc.), each one has a unique iSCSI Name.

Examples of iSCSI Names are:

eui.1122334455667788

iqn.2003-07.com.cybernetics:example.name.tape.1

Once connected, iSCSI target devices are able to identify iSCSI initiators by iSCSI Name, or alias (hostname), or IP address. The principal means of identification, however, is the iSCSI Name.

The miSAN-V-Series is a remote iSCSI target device for iSCSI hosts, which are initiators. If another iSCSI tape device is also on the network, you can configure the miSAN-V-Series to use the device (See below). Before configuring the miSAN-V-Series to use remote iSCSI tape devices, it must first be set up on the network (See earlier, “Network Setup” on page 22). This makes the miSAN-V-Series visible to host iSCSI initiators on the network, and thus available as an initiator for other iSCSI devices. Once configured for network access, you can then configure the miSAN-V-Series to discover and use, as targets, other iSCSI tape devices.

To enable iSCSI communication on the miSAN-V Series, select **SCSI configuration > Outgoing iSCSI connections to devices** from the HSTC Options menu.

The screenshot shows the HSTC Options menu with 'SCSI configuration' selected, leading to 'Outgoing iSCSI connections to devices'. Below this, a 'Remote iSCSI device 1' configuration window is shown with a dropdown menu set to 'Enabled'. To the right, the 'Network Configuration' dialog is open, showing settings for three network interfaces (eth0, eth1, eth2).

Remote iSCSI Target Device Setup

By default, iSCSI is disabled. You can choose to protect iSCSI by password or “Open to everyone”

Remote iSCSI device 1: Disabled (dropdown menu)
 Device 1 DNS name or IP address: Disabled
 Device 1 iSCSI username: Enabled
 Device 1 iSCSI password: No password set

Network Configuration

Hostname	cyberasp
Default gateway	127.0.0.1
Nameserver	127.0.0.1
eth0 (1000 Mbps)	Enabled
eth0 IP address	192.168.1.1
eth0 subnet mask	255.255.255.0
eth0 MTU	1500
eth1 (1000 Mbps)	Enabled
eth1 IP address	192.168.2.1
eth1 subnet mask	255.255.255.0
eth1 MTU	1500
eth2 (100 Mbps)	Enabled
eth2 IP address	192.168.3.1
eth2 subnet mask	255.255.255.0
OK Cancel	

192.168.1.1. Once the Web Control Panel has loaded, select **Remote iSCSI Devices** from **miSAN-V-Series Options** on the main menu bar. On the **Remote iSCSI Devices** window, set the following parameters:

Remote iSCSI Devices

Remote iSCSI device X Set this to **Enabled** to make the remote device visible to iSCSI host initiators.

Device X IP address Set this to match the IP address of the remote iSCSI target tape device.

Device X iSCSI password Set this to match the iSCSI access password of the remote iSCSI target tape device.

miSAN-V-Series iSCSI Features

The miSAN-V-Series is capable of using CHAP authentication, either uni or bi-directional, in order to restrict communication between specific targets and specific initiators. This is explained in the [“Security Configuration” on page 95](#).

The miSAN-V-Series can also be set to restrict device visibility to specific initiators. For example, a local/remote iSCSI target with two tape drives can be configured so that one of the tape drives is visible only to a specific iSCSI initiator (host system) and the other tape drive is visible only to a different iSCSI initiator, allowing simultaneous backups from both host systems without the possibility of interference. This is explained in the [“Offline Maintenance” on page 108](#).

Host iSCSI Setup

Once the miSAN-V-Series is available on the network, as an iSCSI device, it will then be listening on the default iSCSI TCP port **3260**. iSCSI hosts can discover, then access and use the device. Test the miSAN-V-Series network connection by pinging it from a prospective iSCSI host. Once found, the host iSCSI initiator software will allow the host to discover, access and then use the miSAN-V-Series virtual devices as peripheral SCSI devices.



Caution

If more than one iSCSI initiator (i.e., multiple hosts) is to use the miSAN, conflicts may occur if multiple host systems try to issue commands to the same tape device. Ensure hosts do not try to use connected tape devices simultaneously.

User Types

The HSTC/miSAN-V Series has three user types:

1. **Security Officer** (*only available on units with encryption*)

- Configures encryption.
- Manages tokens and keys.
- Performs offloads with encryption disabled.

2. Administrator

- Can do anything except change encryption settings.
- Configures menu settings, networking, iSCSI, virtual devices, etc.
- Creates, deletes, and modifies VTs.
- Configures the user account.
- Can access SSH and telnet.

3. User

- Limited set of abilities defined by the administrator.

Only the administrator account is enabled by default. You may optionally enable the other two accounts. If you do not enable the security officer account, then all the privileges of the security officer are granted to the administrator instead.

The Administrator

The administrator account may be protected by a password (there is no password by default). You may set or change the administrator password in the menu "HSTC Options -> Accounts -> Administrator Account". The administrator password is used for the following purposes:

- Java applet login as administrator.
- SSH and telnet login as "menu".
- Viewing the debug messages web page.
- Viewing the menu settings web page.
- Viewing the hardware information web page.
- Performing a firmware upgrade.



Note

If the Web Browser prompts the Administrator for a username and password to view a web page on the unit, leave the username blank and enter the administrator password.

The User

The user account is disabled by default. To enable the user account, go to the menu "HSTC Options -> Accounts -> User Account". This menu allows the administrator to enable or disable the user account, set the user password, and grant certain optional privileges to the user. Note that only the administrator can set the user password; the user cannot set his own password.

When logged in as the user, many functions and menu options will be missing or highlighted in gray.

The Security Officer

The security officer account is disabled by default. While the security officer account is disabled, the administrator has all the capabilities of the security officer. Enabling the security officer account takes away encryption-related capabilities from the administrator and reassigns them to the security officer. The administrator can enable the security officer account, but only the security officer can disable it. To enable the security officer account, go to the menu "HSTC Options -> Accounts -> Security Officer Account".

Once the security officer account is enabled, only the security officer can perform the following tasks:

- Disabling or reconfiguring the security officer account.
- Using most of the functions of the Encryption tab (although other users may still plug in tokens and enter their PINs).
- Initializing a token.
- Changing a token's PIN.
- Creating a key on a token.
- Enabling, disabling, or revoking an encryption or signing key.
- Deleting tokens or keys.
- Starting an offload with encryption disabled.
- Accessing the "Encryption Configuration" menu.

Setting Up the miSAN-V-Series Virtual Components

This section explains the basic setup operations for configuring the miSAN-V-Series virtual components. The "Initial Setup Guide" section includes a series of short instructions for setting up the miSAN-V-Series before its first use or a complete reconfiguration. The "Configuring Virtual Components" section is a companion guide explaining the initial setup instructions in further detail.

Initial Setup Guide

The instructions below should be used for setting up the miSAN-V-Series before its first use or before a complete reconfiguration; follow them sequentially to ensure that miSAN-V-Series components are configured in their proper order:

1. Create virtual tapes
2. Create virtual devices (tape drives and/or stackers)
3. Assign virtual tapes to virtual devices
4. Configure physical stacker

Creating Virtual Components

The miSAN-V-Series virtual components include virtual tapes, drives and stackers. Each component must be configured during initial miSAN-V-Series setup. Since the devices are virtual, their configurations may be changed later if desired. However, take care with the virtual tapes, since changing

the number of virtual tapes will destroy all data currently stored on them. Changing the numbers and types of virtual devices may result in the need to reassign virtual tapes to the drives or stackers. Changing the virtual device configuration does not affect the data currently stored on the virtual tapes.

Deciding How Many Virtual Tapes to Create

Choosing the number of virtual tapes to create involves deciding how to allocate the available miSAN-V-Series storage space. Factors to consider are the size of each physical tape, number of disk drives used by the miSAN-V-Series, total miSAN-V-Series disk storage capacity, tape cartridge capacity, and historical/estimated compression ratio for backup data. For archiving efficiency, the virtual tapes should closely match tape cartridges in capacity, and the number of virtual tapes should completely use the miSAN-V-Series disk cache, as virtual tapes do not span disk drives.

Deciding What Kind of Virtual Tape Drives to Create

Deciding the number of virtual tape drives and stackers to create involves considering the amount of data to be backed up, the intended backup schedule (e.g., incremental vs. full backups), the time length of the backup window, and the number of backup host systems that can send data. The miSAN-V-Series can be configured to create multiple virtual tape drives and stackers, up to the purchased limit, and can support multiple simultaneous backup and restore operations using the independent virtual devices.



Note

The miSAN-V-Series emulates the IBM® 3580 LTO Ultrium tape drive for virtual drives and the Overland™ NEO Series tape library for virtual stackers. The IBM 3580 and Overland NEO are supported by nearly all backup applications. Thus, virtual drives and stackers should be recognized correctly by host backup software.



Caution

Do not allow more than one backup host to access a virtual device at the same time. Virtual tapes can become corrupted and data lost if backup software on more than one host is allowed to access a virtual device simultaneously. To prevent this, create a virtual device for each host, and then configure “Device Visibility” so each host only sees its own device.



Note

If the miSAN-V-Series is not configured with Tape Library Control support, an external tape library will appear to the miSAN as a physical standalone tape drive, rather than a physical stacker. Thus, a physical library will be accessible by using a virtual standalone tape drive.

Virtual Standalone Drives

Standalone drives are useful in cases where tapes are not assigned for different uses (e.g., when backups are typically large scale, spanning multiple tapes). For a virtual standalone drive, the miSAN-V-Series can automatically change the mounted tape, a method called autoloading, when using multiple tapes during a backup or restore. The “Autoload” feature is user-selectable for each virtual drive. If not set to “autoload” tapes, virtual tapes must be changed by a client using the Web Control Panel.

Virtual Stacker Drives

Stacker drives are more appropriate when tapes are designated for specific uses (e.g., when tapes are grouped into “full” and “incremental” media pools or are designated for backing up specific host systems). Virtual tapes assigned to the stacker appear to a host as conventional slotted tapes. Virtual stackers behave in random access mode. Thus, stacker virtual tapes can be used independently. Since a host can see all the available tapes and slots, a virtual stacker drive is effective for performing different backup operations initiated by one or more hosts.

For miSAN-V-Series models configured with Tape Library Control support, a virtual stacker is required for direct host access to an external tape library (physical stacker). When setting the number of virtual stacker drives, consider the number of physical drives in the external tape library. You should create the same number of virtual drives as there are physical drives, so that if you enable direct host access, each physical drive will have a corresponding virtual drive.

You can enable host access with the physical stacker’s popup menu. Access from a virtual stacker pairs the physical stacker slots and drives with the virtual stacker slots and drives. A host can access the physical stacker directly by proxy using the virtual stacker.

Deciding How to Assign Virtual Tapes

Whenever virtual components are configured, virtual tapes must be assigned to the virtual devices afterward. Tapes are assigned to a virtual device individually or in contiguous groups or can be left unassigned. Unassigned tapes are inaccessible to a host system. When assigning virtual tapes to a virtual standalone drive, the operation is similar to stacking a portion of the available tapes next to each tape drive. For a virtual stacker, the operation is similar to loading the stacker slots with a portion of the available tapes. The result is, the virtual devices have exclusive use of their tapes.

Creating Virtual Tapes

The miSAN-V-Series can be configured to provide up to the maximum number of virtual tapes based on the miSAN-V-Series model.

1. Connect to the miSAN-V-Series using the Web Control Panel in a web browser.
2. Select the “Tools” option from the main menu bar, once the Web Control Panel has loaded.

3. Select the “Create virtual tapes...” option.
A window will appear showing the current number of virtual tapes and their disk space allocation over the total storage capacity.

**Caution**

Make sure to format the disks before creating virtual tapes for the first time. Use the Format disks tab to do so. Failure to initially format the disks may cause errors when creating virtual tapes. After creating virtual tapes, remember that formatting the disks will erase the data stored on all disks used for the virtual tape cache.

4. Choose either the **Basic** or **Advanced** tab to use for creating the virtual tapes. (See “[Create Virtual Tapes](#)” on page 41 for explanations of each tab.)
5. Enter a “Number of virtual tapes.”
6. For the **Advanced** tab, choose to “Use all available space” or “Specify the tape size,” and then select the free space on the disk to add the tapes to.
7. Click **Set/Add** to allocate the disk space. The “Item” column for the affected disk(s) will be updated to show how the miSAN-V-Series will allocate the tapes.
8. Once the desired virtual tapes have been added, click the **Apply changes** button to execute the changes to the tape cache. A confirmation box will appear; click **Yes** to continue. A box will appear while the miSAN-V-Series commits the changes to the disk(s). The “Create virtual tapes” window will close when finished.

Creating Virtual Devices

The miSAN-V-Series can be configured to emulate up to the purchased maximum number of virtual tape drives, whether standalone or assigned to a virtual stacker, based on the miSAN-V-Series model.

1. Connect to the miSAN-V-Series using the Web Control Panel in a web browser.
2. Select the “Tools” option from the main menu bar, once the Web Control Panel has loaded.
3. Select the “Configure virtual devices...” option.
A window will appear showing the current number of virtual devices.
4. Enter the desired number of standalone tape drives.
5. Enter the desired number of stackers.
6. Enter the desired number of tape drives and slots for each stacker.

7. Click **OK** to save changes.
The device tree on the “Devices” tab will refresh to update the configuration changes.

**Note**

Anytime the number of virtual devices is changed, the virtual tapes should be reassigned to the virtual devices.

Assigning Virtual Tapes to Virtual Devices

The virtual tapes can be assigned to a virtual device in either a random manner (e.g., VT 1.1, VT 1.3, VT 1.5, and VT 1.9) or a contiguous group (e.g., VT 1.1, VT 1.2, VT 1.3 and VT 1.4). *Thus, when selecting tapes to assign to a device, the tapes can be selected individually or in a contiguous range. Virtual tapes appear in the “Unassigned Tapes” box until assigned to a virtual device, and can be left unassigned if desired.*

The following steps are used to assign virtual tapes to a virtual device:

1. Connect to the miSAN-V-Series using the Web Control Panel in a web browser.
2. Select the “Tools” option from the main menu bar, once the Web Control Panel has loaded.
3. Select the “Assign virtual tapes...” option.
A window will appear showing the current virtual tape assignments.
4. Select the desired unassigned virtual tapes to assign to the desired virtual device.
To select a range, click the first tape in the range, hold down **SHIFT**, and then click the last tape in the range.
5. Click **Assign** to assign the selected virtual tapes to the desired virtual device.
6. Click **OK** when finished assigning virtual tapes.

Configuring a Physical Stacker

**Note**

The physical stacker features discussed below will only be available if the miSAN-V-Series is configured to operate an external tape library. The HSTC license specifies limits on the number of slots and drives that are supported. If your physical stacker has more slots or drives than allowed by the license, the extra slots will not show up and the extra drives will be treated like standalone drives.

When configured with the optional Tape Library Control support, the miSAN-V-Series can operate an external tape library (physical stacker). An external tape library can be set to inventory tapes, offload virtual tapes to physical tapes, load physical tapes onto

virtual tapes, and access the physical stacker directly using the virtual stacker. To configure a physical stacker, see [“Physical Stacker Device Panel” on page 84.](#))

Testing the Installation

Once configured for use by iSCSI initiator software on a host system, as explained earlier in, in general, the miSAN-V-Series can be treated as any other tape device.

Virtual tape drives are normally seen by a host as IBM® 3580 LTO Ultrium tape drives, and virtual libraries are seen as Overland™ NEO Series tape libraries. These emulations provide for maximum compatibility with existing operating systems and backup software applications. Using the IBM 3580 may require device drivers to be installed, which are available from the IBM FTP site (<ftp://ftp.software.ibm.com/storage/devdrv/>). Drivers for the Overland NEO are not needed, although they are included with many backup applications. For host systems not compatible with the IBM 3580 and Overland NEO, other tape drives and libraries can be emulated. Contact Cybernetics Technical Support (See [Appendix E “Technical Support and Repair Procedures”](#)) regarding tape device emulation.

After installing and configuring the miSAN-V-Series and creating virtual tapes and devices, make sure to verify data and tape path integrity by performing a test backup and restore over the iSCSI network. Some backup software packages include a *VERIFY* feature that will check to ensure the data on disk and the data on tape are identical. If the backup software package does not include a *VERIFY* capability, make sure to perform a test backup and restore operation to check the integrity of the entire data path from the iSCSI host initiator to the miSAN-V-Series, with connected SCSI devices, and back. The data and tape path verification process should be repeated periodically throughout the life of the miSAN-V-Series.

Shut Down

Do not power off the miSAN-V-Series without first logging off the iSCSI initiator if applicable, and shutting down the device using the Web Control Panel shut down menu.

Use this item for safely shutting down or rebooting the miSAN-V-Series. Shutting down the HSTC engine before powering off the unit helps insure the integrity of data in the virtual tape cache.



Caution

To prevent data loss before shutting down the miSAN-V-Series, make sure all current and queued jobs have completed. To ensure no jobs are left in the queue, wait a minimum of 30 seconds while all tape drives are idle. Never power off the miSAN unit without first shutting down the HSTC engine.

**Note**

If the Host machine is connected to the miSAN-V-Series via Microsoft iSCSI Initiator software, it is necessary to log off the iSCSI connections before shutting down in order to avoid possible data loss. Failure to log off the iSCSI connections will cause Microsoft Windows to send “Unsafe Device Removal” messages. Instructions for this procedure are found in Appendix A “Microsoft iSCSI Initiator Client.”

When **Shutdown** is selected, a window will appear confirming the HSTC engine shutdown (See Figure 2-3). Once confirmed, the HSTC engine will complete current operations. When the HSTC has finished shutting down, another window will appear saying the miSAN-V-Series is then ready to be powered off. In most cases, shutting down the miSAN-V-Series, also powers off the machine. If the device is still running after 30 seconds, then press and hold the power button on the front panel until it powers off. Failure to log off the iSCSI initiator before shutting down the miSAN-V-Series will result in error messages

When **Reboot** is selected, the shutdown routine explained above will occur, and the miSAN-V-Series will restart and be ready for use again after about 90 seconds.

Figure 2-3 “Confirm shutdown method” Window



Chapter 3

Operating the Web Control Panel

Interface Layout

Introduction

The miSAN-V-Series presents the Web Control Panel Java applet in an 800×600 pixel frame (See Figure 3-1). You may have to adjust the screen size to accommodate the frame dimensions. After the applet is authenticated and fully loaded, the interface will appear. The interface features a main menu bar and several tabs for displaying the status of devices, labeled “Devices,” and virtual tapes, labeled “Virtual tapes.” If the miSAN-V-Series is configured with the Tape Library Control support option, another tab labeled “Physical tapes” will show the status of physical tapes in an external tape library.




Note

Not all menu and tab items will appear or be displayed in every context. The appearance of an item is based on the miSAN-V-Series model configuration and its current state of operation.

Main Menu Bar Introduction

The Web Control Panel main menu bar appears at the top of the interface. The menu bar offers five selections: **Tools**, **HSTC Options**, **Information**, **Browser links** and **Help** (See Figure 3-1). The “Menu Descriptions” section, later in this chapter, includes detailed explanations for menu selections and item options.


Figure 3-1 Main Menu Bar



Tools

The Tools selection contains menu items that allow clients to configure the HSTC virtual components. The menu offers the following items, which are explained in the “Menu Descriptions” section: Disk storage, Create virtual tapes, Configure virtual devices, Assign virtual tapes, Physical stacker copy profiles, Configure auto-archive, Set date and time, Update license, Export or import configuration, Rescan physical devices, Logout admin, and Shut down the HSTC (See Figure 3-2). For detailed information see [“Tools” on page 36](#)


Figure 3-2 “Tools” Menu



HSTC Options

The HSTC Options selection contains menu items that allow you to configure the optional HSTC engine components. The menu offers the following items, which are explained in the “Menu Descriptions” section: Configuration, SCSI configuration, Network Configuration, Message Delivery, Accounts and Advanced Options. See “HSTC Options” on page 49 for more detailed information..

Figure 3-3 “HSTC Options” Menu




Information

The Information selection contains menu items that allow you to view information about the miSAN-V-Series hardware components. The menu offers the following

items, which are explained in the “Menu Descriptions” section: Product Information, SCSI Device List, Local iSCSI Initiator Name, Local iSCSI Target List and Credits and Licenses (See Figure 3-4). For further details see “Information” on page 69.


Figure 3-4 Information



Browser links

The Browser links selection contains menu items that allow you to view information about the current miSAN-V-Series operating status, menu settings and hardware configurations. The menu offers the following items, which are explained in the “Menu Descriptions” section: View debug messages, View list of menu settings and View hardware information. See “Browser links” on page 70.

Figure 3-6 “Browser links” Menu



Help

The Help selection contains the Applet Acknowledgements (See Figure 3-7). The applet acknowledgements text is reproduced in the “Notices” under “Apache Software License.”

Figure 3-7 “Help” Menu



Tabs introduction

Devices Tab

The “Devices” tab shows a “tree” view on the left with an entry representing each virtual and physical device (physically attached or connected via iSCSI). See [“Devices Tab” on page 71](#) for more information.

Virtual tape Tab

The “Virtual tapes” tab shows the current status of each miSAN-V-Series virtual tape. See [“Virtual Tapes Tab” on page 93](#) for more information.

Physical tapes Tab

The “Physical tapes” tab shows the current status of tape cartridges in a physical library. The HSTC remembers the contents for physical tapes containing copies of virtual tapes, displaying the status information on the “Physical tapes” tab. The tab shows the “Contents” of the tape cartridges and whether the contents are identical to their copied virtual tapes. When a backup of a virtual tape begins, its associated physical tapes will be used. See [“Physical Tapes Tab” on page 97](#) for more information.

Jobs

The HSTC uses jobs to do its own internal work such as offloading virtual tapes to physical tapes. These jobs are similar in concept but separate from the jobs that your backup software may use to do backups and restores.

The HSTC performs the following types of jobs:

- Copy from virtual tape to physical tape
- Copy from physical tape to virtual tape
- Copy from virtual tape to virtual tape
- Auto-archive
- Inventory a physical tape in a stacker
- Enable host access to a physical tape in a stacker using a standalone virtual tape drive
- Erase a virtual tape

Jobs of different types are created in different ways, but once created, all jobs can be managed using the “Jobs” tab. The job database view is split into three parts: the “Jobs” table showing summary information for all the jobs, the “Job log”, and the “Activity monitor”. See [“Jobs Tab” on page 99](#) for more information.

Messages

The “Messages” tab reports disk [“Messages Tab” on page 102](#)


Main Menu

Tools

The Tools selection contains menu items that allow clients to configure the HSTC virtual components. The menu offers the following items, which are explained in the “Menu Descriptions” section: Disk storage, Create virtual tapes, Configure virtual devices, Assign virtual tapes, Physical stacker copy profiles, Configure auto-archive, Set date and time, Update license, Export or import

configuration, Rescan physical devices, Logout admin, and Shut down the HSTC (See Figure 3-2)

Figure 3-8 “Tools” Menu



Note


The “Physical stacker copy profiles” menu item only appears when the HSTC is configured to operate an external tape library using Tape Library Control support.

Disk Storage

This item provides menu options for managing the miSAN-V-Series disk drives:

- **Manage disk storage:** Opens a web-based GUI interface called the 3ware Disk Manager 2 (3DM® 2) that manages the integrated 3ware® Escalade® 9500S-8 SATA RAID controller. See [Chapter 4 “Using the 3ware Disk Manager®” on page 109](#) for further instructions.
- **Disks online for normal usage / Disks offline for management:** Only one of these options can be selected at a time; they toggle the disks online and offline. When the disks are online, hosts can access the virtual tapes, and the miSAN-V-Series operates normally. When the disks are offline, the host can create, delete and reconfigure the RAID arrays via the 3DM® 2 (See above). When you take the disks offline by selecting **Disks offline for management**, the miSAN-V-Series will first prompt you to make sure that the virtual tapes are not in use before going offline. If you continue, the virtual tapes will disappear from the Web Control

Panel. Actions such as creating virtual tapes will give an error message while the disks are offline. Tools >Disk Storage



Create Virtual Tapes

This item allows for creating virtual tapes from the disk storage space available to the miSAN-V-Series. When selected, a window will appear showing the total number of virtual tapes and their disk space allocation over the total storage capacity (See Figure 3-9). Each disk partition seen by the miSAN-V-Series is presented in the “Item” column: The numbered disk is immediately followed by the names of the virtual tapes it contains. The total capacity, in gigabytes, for each disk and virtual tape is shown in the “Size” column. The “Free Space” for each disk is also listed.

Figure 3-9 Virtual Tape Disk Space Allocation

Total virtual tapes: 15 / 200	
Item	Size
Disk 1	250.9 GB
Free space	250.9 GB
Disk 2	250.9 GB
VT 2.1	5.0 GB
VT 2.2	5.0 GB
VT 2.3	5.0 GB
VT 2.4	5.0 GB
VT 2.5	5.0 GB
VT 2.6	5.0 GB
VT 2.7	5.0 GB
VT 2.8	5.0 GB
VT 2.9	5.0 GB
VT 2.10	5.0 GB
VT 2.11	5.0 GB
VT 2.12	5.0 GB
VT 2.13	5.0 GB
VT 2.14	5.0 GB
VT 2.15	5.0 GB
Free space	175.9 GB
Apply changes Cancel	

The “Create virtual tapes” window presents the following three tabbed panels for managing the disks used for the virtual tape cache: **Basic**, **Advanced** and **Format disks**.

The miSAN-V-Series allows for creating virtual tapes using either the **Basic** or **Advanced** tab. The **Format disks** tab is used before creating virtual tapes to erase the disks used for the virtual tape cache.

To create a number of virtual tapes use either the **Basic** or **Advanced** tab:

1. Enter a “Number of virtual tapes.”
2. For the **Advanced** tab, choose to “Use all available space” or “Specify the tape size,” and then select the free space on the disk to add the tapes to..

Item	Size
Disk 1	250.9 GB
Free space	250.9 GB

3. Click **Set/Add** to allocate the disk space. The “Item” column for the affected disk(s) will be updated to show how the miSAN-V-Series will allocate the tapes.

Item	Size
Disk 1	250.9 GB
New virtual tape	20.0 GB



Note

To remove a virtual tape from the disk cache. Right-click the selected tape, and then a popup menu will appear with a command to “Remove.”

VT 2.3	5.0 GB
VT 2.4	5.0 GB
VT 2.5	5.0 GB

Remove



Caution

Removing a virtual tape from the disk cache will destroy all its contents


4. Once the desired virtual tapes have been configured, click the **Apply changes** button to execute the changes to the tape cache. While the miSAN-V-Series creates the virtual tapes, the “Create virtual tapes” window will be greyed-out and unavailable; it will close when finished.

Basic Tab

The **Basic** tab is used for setting a number of virtual tapes to be created as equally sized out of the total capacity for all disks. The miSAN-V-Series will decide how to use

the total storage capacity for all disks to create equally sized virtual tapes (See Figure 3-10).

Figure 3-10 Create Virtual Tapes Basic Tab



Basic Advanced Format disks

NOTE: use the Advanced tab instead if you wish to keep any pre-existing virtual tapes (listed below in grey).

Number of virtual tapes (0 - 200):

Set

Advanced Tab

The **Advanced** tab is used for specifying a disk to use for creating virtual tapes (See Figure 3-11). Choose “Use all available space” to create equally sized virtual tapes from all the selected free space. By choosing to “Specify the tape size,” you can create groups of virtual tapes having different sizes.

Figure 3-11 Create Virtual Tapes “Advanced” Tab



Basic Advanced Format disks

Number of virtual tapes:

☒ Use all available space

☐ Specify the tape size (GB):

Select a **free space** area to use below

Add Clear all tapes

Format Disks Tab


The **Format disks** tab is used for formatting (erasing) the disks used for the miSAN-V-Series virtual tape cache. The tab indicates if any number of disks need to be formatted, which is necessary before initially using the disk storage space (See Figure 3-12).



Note

The RAID disks must be formatted after any change to the disk configuration, such as after adding/removing a disk drive or changing the RAID-level configuration.

Figure 3-12 Create Virtual Tapes “Format disks” Tab

**Caution**


Make sure to format the disks before creating virtual tapes for the first time. Failure to do so may cause errors when creating the virtual tapes. After creating tapes, remember that formatting the disks will erase the data stored on all disks used for the virtual tape cache.

To begin formatting the disks, click **Format all disks**. The miSAN-V-Series will then erase the data stored on all disks used for the virtual tape cache. The message box on the tab will change to show that the miSAN-V-Series is formatting the disks. Wait for the formatting to complete, and then proceed to create virtual tapes (See [“Creating Virtual Tapes” on page 29](#)).

Configure Virtual Devices

This item allows for setting the number of standalone tape drives and stackers. The maximum number of virtual tape drives allowed, whether standalone or stacker, is based on the model configuration. When selected, a window will appear showing the current number of virtual devices (See Figure 3-13). To set the number of standalone tape drives or stackers, enter the desired quantity for the device, and then click **OK**. **When configuring a stacker, the number of tape drives and slots must also be set. The device tree on the “Devices” tab will reset to update the configuration changes** (See [“Deciding What Kind of Virtual Tape Drives to Create” on page 27](#)).


Figure 3-13 “Configure virtual devices” Window



Assign Virtual Tapes

This item allows for viewing and changing the assignments of the virtual tapes to the virtual devices. When this menu item is selected, a window will appear showing the current virtual tape assignments and any unassigned virtual tapes (See Figure 3-14). The listbox on the left shows the currently “Unassigned tapes.” Listboxes corresponding to the virtual devices appear to the right of the unassigned tapes listbox. *The tapes in the unassigned listbox can be selected individually or in a contiguous range. To select a range, click the first tape in the range, hold down **SHIFT**, and then click the last tape in the range. To assign the selected virtual tapes, click **Assign** for the desired virtual device. Click **OK** after making the assignments to commit the changes and update the Web Control Panels for all connected clients*

Figure 3-14 “Virtual tape assignments” Window



Physical Stacker Copy Profiles



Note

This option only appears when the miSAN-V-Series is configured with optional Tape Library Control support and a tape library is connected.

This item allows you to create copy profiles to use when enabling the **Offload disk to tapes** mode for a physical stacker. Copy profiles are saved physical stacker slot associations. They make it easier to set up copying virtual tapes to physical tapes when offloading disk to tapes. Using copy profiles saves from manually having to select virtual tapes to copy each time **Offload disk to tapes** is enabled (See [“Offload disk to tapes...” on page 86](#)).

When this menu item is selected, a window will appear showing all the virtual tapes and all the physical stacker slots. The “Profiles” frame shows all the existing copy profiles. When a copy profile is selected, its saved slot associations are shown in the “Virtual tape” column in the “Slot associations” table

Figure 3-15 “Physical stacker copy profiles” Window

Slot	Virtual tape
1	VT 2.3
2	VT 2.4
3	
4	
5	
6	
7	
8	

To create a copy profile, click **New**. To rename the copy profile, select it, enter the new “Profile name,” and then click **Set**. To associate a virtual tape to a physical stacker slot, first, select the virtual tape in the “Virtual tapes listbox. Then, select the row for the desired physical stacker slot in the “Slot associations” table. Finish by

clicking the -> button, which assigns the virtual tape name to the “Virtual tape” cell for that slot (See Figure 3-15). Once all the desired virtual tapes have been assigned, click **Save changes** to save the copy profile.

The **Help** button provides an explanation of how to set up the associations.

Configure Auto-archive




Note

This setting will only be available if a physical standalone tape drive is connected to the miSAN-V-Series.

The “Auto-archive” feature allows you to automating the process of creating and maintaining tape cartridge duplicates of virtual tape backups. Each physical tape drive may be assigned a group of virtual tapes to maintain backups for.

When this menu item is selected, a window will appear showing a frame for each physical standalone tape drive. The “Unassigned tapes” frame lists the virtual tapes not assigned to a physical drive (See Figure 3-16).

Figure 3-16 “Auto-archive configuration” Window



To assign virtual tapes to a physical tape drive, to be used for automatic backups, first enable “Auto archive” for the desired physical tape drive by selecting the option.

Next, select the desired virtual tapes from the “Unassigned tapes” listbox. Tapes may be selected individually or in a contiguous range. To select a range, click the first tape

in the range, hold down **SHIFT**, and then click the last tape in the range. To assign the selected virtual tapes, click **Add** for the desired physical tape drive.

Finally, choose the desired backup source:

“All backups” allows the miSAN-V-Series to create and maintain tape cartridge duplicates of *all the virtual tapes* assigned to the drive. When a tape cartridge is inserted into the drive, “All backups” mode will cause the miSAN-V-Series to automatically duplicate each virtual tape, ejecting the tape cartridge after each successful copy. If more than one virtual tape awaits copying, each will be copied in order. Since the virtual tapes are write-protected while auto-archiving occurs, the “All backups” mode is effective for taking a “snapshot” of the current state of the entire miSAN-V-Series virtual tape cache.

“Most recent backup only” allows the miSAN-V-Series to create an immediate backup of *only the most recent* virtual tape backup. When a tape cartridge is inserted into the drive, the “Most recent backup” mode will cause the miSAN-V-Series to automatically duplicate only the most recent virtual tape backup, regardless of how long ago the backup was made. The miSAN-V-Series will not eject the tape after a successful copy, so the tape cartridge will be available for duplicating another backup. Thus, with the “Most recent backup” mode selected, a user is assured a physical copy will always be made automatically after a backup to virtual tape. If after a successful copy a user wants to keep the tape cartridge backup, the user must eject the tape, else it will be overwritten after the next backup to a virtual tape.



Note


To keep track of which virtual tapes have been successfully written to physical tape and which still need copying, use the Web Control Panel. The “Copies” column on the “Virtual tapes” tab shows the number of successful copies made.

Set Date and Time

This item allows you to set the miSAN-V-Series date, time and timezone using the local information on the client running the Web Control Panel (See Figure 3-17). The time information is used for setting the “Last modified” attribute for virtual tapes (See [“Virtual Tape Popup Menu” on page 94](#)) and giving a valid timestamp to messages on

the “Messages” tab and for email messages sent from the miSAN-V-Series (See [“Message Delivery” on page 65](#)).


Figure 3-17 “Set date and time” Window



Update License

This item allows for entering license text provided by Cybernetics for changing the miSAN-V-Series model configuration. When selected, a window will appear showing a text box into which license text can be pasted (See Figure 3-18). Once pasted, the **OK** button is used to initialize changes to the miSAN-V-Series configuration.

Figure 3-18 “Update License” Window



Export or Import Configuration

Clicking on this option will open a new web page. Additional instructions are given; as well as the ability to View Configuration, Export Configuration to a File, and Import Configuration from a File.

Rescan Physical Devices

This item forces the miSAN-V-Series to rescan the parallel SCSI buses for connected devices. If a previously undetected SCSI device is found, the Web Control Panel will update to reflect the new hardware configuration. For a detected tape device, either a

standalone tape drive or tape library, the “Devices” folder on the “Devices” tab will refresh to allow for accessing and using the new device.




Caution

Since multiple clients can access and view the control panel simultaneously, users must not rescan for physical devices while other users are connected. Doing so may interrupt current operations, disconnect other clients or cause other browser control panels to display incorrect information. If the miSAN-V-Series must be reconfigured while other users may be accessing the control panel, wait until all current and queued jobs have completed. To ensure no jobs are left in the queue, wait a minimum of 30 seconds while all tape drives are idle before rescanning for physical devices.

When this menu item is selected, a window will appear asking for confirmation before bringing the miSAN-V-Series temporarily offline to scan for devices (See Figure 3-19).

Figure 3-19 “Rescan physical devices” Window



Shut Down the HSTC

Use this item for safely shutting down or rebooting the miSAN-V-Series. Shutting down the HSTC engine before powering off the unit helps insure the integrity of data in the virtual tape cache.



Caution

To prevent data loss before shutting down the miSAN-V-Series, make sure all current and queued jobs have completed. To ensure no jobs are left in the queue, wait a minimum of 30 seconds while all tape drives are idle. Never power off the miSAN-V-series unit without first shutting down the miSAN.


**Note**

If the Host machine is connected to the miSAN-V-Series via Microsoft iSCSI Initiator software, it is necessary to log off the iSCSI connections before shutting down in order to avoid possible data loss. Failure to log off the iSCSI connections will cause Microsoft Windows to send “Unsafe Device Removal” messages. Instructions for this procedure are found in Appendix A “Microsoft iSCSI Initiator Client.”

When **Shutdown** is selected, a window will appear confirming the HSTC engine shutdown (See Figure 3-20). Once confirmed, the HSTC engine will complete current operations. When the HSTC has finished shutting down, another window will appear saying the miSAN-V-Series is then ready to be powered off. In most cases, shutting down the miSAN-V-Series, also powers off the machine. If the device is still running after 30 seconds, then press and hold the power button on the front panel until it powers off. Failure to log off the iSCSI initiator before shutting down the miSAN-V-Series will result in error messages

When **Reboot** is selected, the shutdown routine explained above will occur, and the miSAN-V-Series will restart and be ready for use again after about 90 seconds.

Figure 3-20 “Confirm shutdown method” Window



HSTC Options

Configuration.

Figure 3-21 Configuration

Device ID order	Drives then stacker	▼
Start offloading	When VT is ejected	▼
Minutes to wait before offload	5	▲ ▼
Host vs. job I/O policy	Concurrent	▼
Host I/O pauses running jobs	Disabled	▼
Host I/O idle minutes	5	▲ ▼
Drive compression for copying	Disabled	▼
Copy volume tags	Disabled	▼
Wait for backup after PT changed	Enabled	▼
Compress VTs	Disabled	▼
Compress encrypted VTs and PTs	Enabled	▼
PT trust level	Trust direct or indirect signatures	▼
Receive SNMP messages from UPS	Disabled	▼
OK		Cancel



Note

Some of the options shown in the above menu will only be present if Compression or Encryption options are installed.

Device ID order

This option is only displayed when the miSAN-V-Series is configured for a virtual stacker.

This item controls whether the base SCSI ID is assigned to the virtual stacker ("Stacker then drives") or to a virtual standalone drive ("Drives then stacker"). If there is more than one virtual stacker, each stacker and its virtual tape drives will be assigned SCSI IDs as a set.

Examples: A miSAN-V-Series with two virtual standalone drives, and with Base SCSI ID set to **2**, will use SCSI ID **2** for the first tape drive and SCSI ID **3** for the second tape drive.

An miSAN-V-Series with two standalone drives and one changer, Base SCSI ID set to **2**, and Device ID Order set to “Stacker then drives,” will use SCSI IDs as follows:

ID	Device
2	Stacker
3	Master (first) standalone drive
4	Slave (second) standalone drive

An miSAN-V-Series with two virtual stackers, each with two virtual tape drives, with Base SCSI ID set to **0**, and Device ID Order set to “Drives then stacker,” will use SCSI IDs as follows:

ID	Device
0	Master tape drive, first stacker
1	Slave tape drive, first stacker
2	First stacker
3	Master tape drive, second stacker
4	Slave tape drive, second stacker
5	Second stacker

Host vs. job I/O policy

When host backup and restore jobs use the HSTC's disk input/output (I/O) resources, these disk I/O resources are called “host I/O” resources. When the HSTC's disk I/O resources are used for jobs such as offloading disk to tape, these disk I/O resources are called “job I/O” resources.

The “Host vs. job I/O policy” setting is used to control the priority given to job I/O resources relative to host I/O resources. The option you choose for this setting determines the policy the HSTC will use when allocating I/O resources.

The options are as follows:

- **Concurrent** – Host I/O and job I/O may proceed concurrently
- **Host disk write exclusive** – Job I/O is disabled only on disks the host is writing to
- **Host disk exclusive** – Job I/O is disabled only on disks the host is reading from or writing to
- **Host write exclusive** – All job I/O is disabled when a host is writing to any disk
- **Host exclusive** – All job I/O is disabled when a host is reading from or writing to any disk

When one of the policy options other than **Concurrent** is selected and a host begins using disk I/O resources, any running job I/O on the disk(s) affected by the

policy will pause and remain in the running state but will not access the disk(s) until the host I/O finishes.

Individual jobs can be configured to either use or ignore this setting's policy. Jobs that ignore the policy run immediately without concern for the impact on the host's available I/O bandwidth.

You can make a job use or ignore this setting's policy at any time by first selecting the "Jobs" tab, then right-clicking the job, and then from the pop-up menu, selecting the desired option from the I/O scheduling submenu.

Host I/O idle minutes

"Host I/O idle minutes" specifies the amount of time the HSTC will wait from when the host I/O stops before restarting job I/O. This option does not apply when **Concurrent** is selected for "Host vs. job I/O policy".

Overwrite non-committed



Note

If the miSAN-V-Series is configured with a virtual or physical stacker, this setting will be unavailable and set to Enabled by default. This is to allow host software to manage virtual tape protection, which would otherwise interfere with protection controlled by the miSAN-V-Series. This setting will also be unavailable if the miSAN-V-Series is not configured to use a physical tape drive.

The "Overwrite non-committed" setting determines whether a virtual tape becomes write-protected after a backup. Write-protecting a virtual tape after a backup ensures it will remain unchanged until a successful tape cartridge backup has been committed (successfully copied). This secures against unintentional or unauthorized virtual tape modification before a tape cartridge copy has been made, since a host can neither append to nor erase a write-protected virtual tape. Regardless of host write-protect status, a virtual tape can always be erased via the "Virtual tapes" tab on the Web Control Panel.

If **Enabled**, a virtual tape will remain *unprotected* after a backup, making it available for appending or overwriting by another backup. Enabling the overwrite feature ensures a virtual tape is available for writing, even if its contents have not been committed to tape. This is useful in cases where tape cartridge duplicates are not always written for each virtual tape backup.

If **Disabled**, a virtual tape will be *write-protected* until it is committed to a tape cartridge. To keep track of which virtual tapes are write-protected, use the Web Control Panel. The "Copies" column on the "Virtual tapes" tab shows the number of successful copies made. A virtual tape backup is write-protected if it has not been successfully copied to a tape cartridge ('0' copies). Disabling the overwrite feature ensures a tape cartridge duplicate will be made before a virtual tape can be modified, such as before an append or erase. This is useful in cases where a tape cartridge duplicate is always written for each virtual tape backup.

Drive compression for copying

This option enables or disables internal tape drive data compression for connected tape devices (e.g., physical standalone or library tape drives).



Note

This feature can toggle drive data compression only if the tape drive is physically set to allow host-controlled compression. See documentation for connected tape devices for information about drive compression settings.

If **Enabled**, all physical tape drives connected to the miSAN-V-Series will write data using their internal compression algorithm.

If **Disabled**, all physical tape drives connected to the miSAN-V-Series will write data in their native block size format.

Copy volume tags

This option allows the miSAN-V-Series to associate virtual tape volume tags (See [“Virtual Tapes Tab” on page 93](#)) with the barcodes on their physical tape copies.

If **Enabled**, the miSAN-V-Series will automatically copy the barcodes read from physical tapes in an external library to the volume tags of their associated virtual tapes. The volume tag is updated with the barcode after a virtual tape is written to a physical tape cartridge.

If **Disabled**, the virtual tape volume tags will remain unchanged after a copy to barcoded physical tapes. See [“Virtual Tape Popup Menu” on page 94](#) for information about adding volume tags to virtual tapes.

Virtual Device Emulations



Note

This option only applies to models configured with multiple emulation support. For miSAN-V-Series models configured with only the default emulations this option will show a message box saying there is nothing to configure.

If the miSAN-V-Series is configured with multiple emulation support (See [“Define Emulations” on page 68](#)), this option will display a window that allows for selecting a different emulation for each virtual device. The window shows all the configured virtual devices with a drop-down listbox for each. The listboxes contain the names of the emulations configured in the “Define Emulations” menu, under the

“Advanced Options” menu. For each virtual device, select a tape device emulation for backup hosts to see and use.



Note

Device emulation may require a driver to be installed on the host computer system.

Receive SNMP messages from UPS

This menu option allows you to enable the HSTC to receive SNMP messages from an APC® Smart-UPS® model UPS that has a Network Management Card or a Tripp Lite® SmartPro®/SmartOnline™ model UPS that has an SNMPWEBCARD. You can configure the UPS to send messages to the HSTC when the power fails, enabling the HSTC to automatically shut itself down cleanly.

By enabling this option, you allow the miSAN-V-Series to take the following actions in response to the UPS power events:

Event	Action
AC power failed; UPS on battery	The miSAN-V-Series remains operational but prepared for shutting down quickly.
AC power restored before UPS battery is drained	The miSAN-V-Series returns to normal operation.
UPS battery is low	The miSAN-V-Series shuts down cleanly, ensuring the safety of saved data.



Caution

The miSAN-V-Series does not authenticate the UPS, so enabling this option enables anyone capable of sending SNMP messages on your network to shut down the miSAN remotely.

Configuring an APC® Smart-UPS® model UPS with Network Management Card

You must configure the Network Management Card's network parameters so the Smart-UPS can communicate with the miSAN-V-Series. Under “Network” > “SNMP”, set “Access” to “Enabled”. Under “Events” > “Recipients” > “Trap Receivers”, enter the following information:

Community Name	public
Receiver NMS IP/Domain Name	[IP address of miSAN-V-Series]
Generation	Enabled
Authentication Traps	Disabled

**Note**

From the miSAN-V-Series's Web Control Panel, make sure "Receive SNMP messages from UPS" is set to Enabled.

To test the configuration, pull the AC power plug on the UPS. The "Messages" tab on the Web Control Panel should give a message that the UPS is on battery power. Wait a few seconds, then plug the UPS AC power back in. The "Messages" tab on the Web Control Panel should give a message that power has been restored.

**Note**

The APC Smart-UPS model does not send SNMP power failure messages when using the diagnostics function for simulating a power failure, so you cannot use this diagnostic to test the communication with the miSAN-V-Series.

Configuring a Tripp Lite® SmartPro®/SmartOnline™ model UPS with SNMPWEBCARD

You must configure the SNMPWEBCARD's network parameters so the SmartPro®/SmartOnline™ can communicate with the HSTC. Under "Settings" > "Contacts" > "SNMP" > "New", enter the following information:

IP Address	[IP address of HSTC]
Name	[A descriptive name (e.g., miSAN-V-Series)]
Community	public
Trap Port	162

Under "Settings" > "Events", check "SNMP Notification" for "On Battery", "Battery Low", and "Battery Capacity Below Warning Level". When you check "SNMP Notification", a window will pop up with more configuration options. Under "Message Settings", set the two time values to **0**. Under "IP Addresses", highlight the HSTC's IP address so the HSTC is notified of the event. Also, make sure the "Shutdown" action for the "On Battery" event is not checked, since this could cause a loss of output power without an SNMP warning message.

Under "Settings" > "Device" > "Low Battery Warning", enter the percentage of the battery charge that you want to trigger the HSTC shutdown. Note that a loss of output power can occur before 0% is reached, so do not use a value that is too low. Cybernetics recommends a minimum value of 30 or more, depending on the load.

You do not have to configure “Settings” > “Network” > “SNMP”, because the HSTC does not send SNMP messages to the UPS; it only receives them.

**Note**

From the HSTC’s Web Control Panel, make sure “Receive SNMP messages from UPS” is set to Enabled.

To test the configuration, pull the AC power plug on the UPS. The “Messages” tab on the Web Control Panel should give a message that the UPS is on battery power. Wait a few seconds, then plug the UPS AC power back in. The “Messages” tab on the Web Control Panel should give a message that power has been restored.

Data Compression

Rule: you can’t compress encrypted data, but you can encrypt compressed data. If you want to use data compression and encryption together, you must compress first and then encrypt.


Most tape drives have the capability of compressing the data they receive during a backup and decompressing the data they read from the tape during a restore. Tape drives handle data compression transparently in hardware; the application software doesn’t have to do anything except tell the tape drive to enable it. Unfortunately, a tape drive’s internal compression is useless for encrypted PTs, since the tape drive receives the data only after encryption (see the rule above). The HSTC always disables the tape drive’s internal compression when creating encrypted tapes.

The HSTC itself also has the capability of compressing data. The HSTC supports using its own compression for both VTs and PTs. The HSTC’s compression may be used with encrypted or non-encrypted VTs and encrypted PTs, but not with non-encrypted (plain) PTs. For non-encrypted PTs, the HSTC lets the tape drive compress the data instead.

There are two menu options that control when the HSTC uses its own compression:

- * **Compress VTs:** Disabled/Enabled
- * **Compress encrypted VTs and PTs:** Disabled/Enabled

SCSI Configuration



The image shows a configuration window titled "SCSI HBA ports". It contains several fields and dropdown menus for configuring HBA ports. The fields are: "HBA 1 name" with the value "Library", "HBA 2 name" with the value "Payroll Server", "HBA 2 direction" with a dropdown menu showing "Connects to host", "HBA 2 base SCSI ID" with a numeric spinner set to "2", "HBA 2 speed" with a dropdown menu showing "Auto", and "HBA 2 5702 mode" with a dropdown menu showing "Disabled". At the bottom are "OK" and "Cancel" buttons.

SCSI HBA Ports

Depending on the miSAN-V series configuration, there will be HBA 1 and HBA2, or HBA 1a, HBA1b, HBA2a, and HBA2b. HBA 2 will normally be connected to a host, though it may be configured to connect to a target.

HBA X direction

Choose between **Connects to host** and **Connects to devices**.

HBA X base SCSI ID

This item controls the SCSI IDs for virtual devices which are presented to host systems, and has no connection with the actual SCSI ID settings for any attached physical devices. This setting and the "Device ID Order" setting below have no effect and will not be displayed on an iSCSI-only system.



Note

When selecting the Base SCSI ID, make sure not to inadvertently create a conflict with the host controller SCSI ID, which is normally set to 7.

This item sets the base (lowest numbered) SCSI ID that the unit uses. Default is **2**. These are the SCSI IDs that will be seen by the host computer system. Available selections are **0** through **15**. The miSAN-V-Series will use one SCSI ID for each installed device (tape drive or changer), assigning SCSI IDs consecutively beginning with the Base SCSI ID.

HBA X speed

The “SCSI bus speed” setting defaults to “Auto.” The “Auto” setting provides the optimal bus speed for most configurations. To set a fixed, limiting bus speed, select from the wide and narrow speeds in the drop-down menu..



Note

The actual SCSI bus speed negotiated between the miSAN-V-Series and the attached host system depends on the host hardware configuration and the bus termination.

Incoming iSCSI Connections from Hosts

iSCSI login control

There are three choices for iSCSI login control: iSCSI disabled (default), Protected by password, and Open to everyone (insecure)..

iSCSI login control	iSCSI disabled
iSCSI access password	iSCSI disabled
iSCSI host username	Protected by password
iSCSI host password	Open to everyone (insecure)
	No password set
OK	Cancel

iSCSI access password

The iSCSI protocol supports optional authentication in either or both directions (host-to-target, or target-to-host). The “iSCSI access passwd” is used to prevent unauthorized hosts from gaining access to the miSAN-V-Series. This requires host systems to be authenticated by the miSAN-V-Series. Default is no password. When a password has been set, host systems must be configured to use CHAP authentication with the same password set in order to connect to the iSCSI target devices.

To set, change or remove the “iSCSI access passwd,” follow the same procedures as for the “Menu password.”

iSCSI host username

This menu item is used together with the “iSCSI host password” (See “iSCSI host password”) to permit the miSAN-V-Series to identify itself as a legitimate device to iSCSI host systems. Default is none (no “iSCSI host username” is set). An iSCSI host system that is configured to use bi-directional authentication will check the “iSCSI host username” and the “iSCSI host password” setting using CHAP authentication. Both must match the entries that are set on the host system itself.

If the host system is set to use bi-directional authentication and these entries do not match those on the host system, CHAP authentication will fail. If the host sys-

tem is not set to use bi-directional authentication, these entries will not be checked by the host system and will have no effect.

Since the miSAN-V-Series only maintains a single “iSCSI host username” and “iSCSI host password,” all hosts that are intended to connect to the miSAN-V-Series must use the same host username and password for CHAP authentication with this miSAN-V-Series.

To set, change or remove the “iSCSI host username,” follow the same procedures as for the “Menu password.”

iSCSI host password

This is the password that goes with the “iSCSI host username” above.

To set, change or remove the “iSCSI host password,” follow the same procedures as for the “Menu password.”

Outgoing iSCSI Connections to Devices

You can configure the miSAN-V-Series to use up to four remote iSCSI target devices. There are three submenu items for each numbered device: “Remote iSCSI device X,” “Device X IP address” and “Device X iSCSI password.”

Remote iSCSI device X

Choices are “Enabled” and “Disabled” for each remote iSCSI device.

Device X DNS Name or IP address

Set this to match the DNS Name or IP address of the remote iSCSI device (tape drive, library, and/or iSCSI storage device (i.e. miSAN-D Series) with which the miSAN-V-Series is to communicate.

Device X iSCSI Username

Default is CyberneticsASP. This can be changed if necessary.


Device X iSCSI password

Set this to match the iSCSI Access Password of the remote iSCSI device with which the miSAN-V-Series is to communicate.

Setup for using an external iSCSI device for additional Virtual Tape storage

The following steps show how to connect the miSAN-V Series to a iSCSI device for additional Virtual Tape storage.

1. Select **SCSI configuration > Outgoing iSCSI** connections to devices from the **HSTC Options** drop-down menu.



2. Enable Remote iSCSI device 1.

Remote iSCSI device 1	Disabled
Device 1 DNS name or IP address	Disabled
Device 1 iSCSI username	Enabled
Device 1 iSCSI password	CyberneticsASP
	No password set

3. Enter the IP address iSCSI device.
4. Enter iSCSI username (default iSCSI username is CyberneticsASP)..


Remote iSCSI device 1	Enabled
Device 1 DNS name or IP address	192.168.1.2
Device 1 iSCSI username	CyberneticsASP
Device 1 iSCSI password	No password set
Remote iSCSI device 2	Disabled

5. Click on iSCSI password.

Device 1 DNS name or IP address	192.168.1.2
Device 1 iSCSI username	CyberneticsASP
Device 1 iSCSI password	No password set
Remote iSCSI device 2	Disabled


An 'Enter new password' dialog box is open, showing fields for 'Enter new password' and 'Confirm new password'.

6. Enter new password. (Password must match the password on the iSCSI device and is recommended to be 14 characters long). Press **OK**.




A dialog box titled "Enter new password" with two text input fields. The first field is labeled "Enter new password" and the second is labeled "Confirm new password". Both fields contain a series of dots representing masked characters. Below the fields are three buttons: "OK", "Undo changes", and "Cancel". A mouse cursor is pointing at the "OK" button.

7. A dialog box will pop up. Wait for it to disappear.




A dialog box with a purple information icon on the left. The text inside reads: "Please wait while the changes are activated. This window will close automatically when the unit comes back online. If you have just changed the unit's IP address, close this window now and load the new URL in your web browser." At the bottom is a button labeled "Cancel wait".

8. Select **Rescan physical devices...** form the **Tools** drop-down menu.




9. Select **Yes**.




A confirmation dialog box with a green question mark icon. The text reads: "The unit will go offline momentarily while scanning for devices. Do you wish to continue?" At the bottom are two buttons: "Yes" and "No". A mouse cursor is pointing at the "Yes" button.

10. Select Create virtual tapes... from the Tools drop-down menu.



11. Open the **Format disks** tab. Select either **Format disks that need formatting**, or **Format all disks**. After formatting the disks, press the **Apply changes**.



12. Use either the Basic or Advanced tabs to set up the new virtual tapes.

Network Configuration

This submenu is used to configure the network interface(s). Based on the configuration, the unit may have three or more interfaces, which are used for either configuration and remote display only or for data transfer (iSCSI) as well. Each network interface may be configured individually. All network interfaces use the industry standard TCP/IP protocol.

When any network parameters are changed, and the changes are committed, the changes will take effect immediately. In the case of a change to the IP Address, the miSAN-V-Series connection will be dropped as soon as the new IP Address takes effect, since the unit will no longer respond at the old IP Address. Re-establish a connection to the miSAN-V-Series to verify the new configuration.



Caution

Be careful when making changes to network parameters. Make sure network settings will not render the unit unreachable on the network. If the miSAN-V-Series becomes unreachable on the network, you can reset the network parameters to their default values using the network reset button on the rear panel. To perform the reset, while the miSAN is powered-on, first, insert a #0 Phillips screwdriver or paper clip into the network reset button hole on the rear panel (See Figure 2-1). Then, press and hold down the reset button for 5 seconds. The miSAN will then restart. Afterward, you may change the network parameters from their default values according to instructions in “Network” on page 16. The first three submenu items below (“Hostname,” “Default gateway” and “Nameserver”) apply to all network interfaces. The remaining items are grouped by the interface involved: “eth0”, “eth1”, “bond0”, etc.

Hostname

Set the TCP/IP hostname. This may be either a hostname or a fully qualified domain name (FQDN; see [Appendix C, “Glossary”](#)).

Default gateway

The default gateway IP address (default is **127.0.0.1**) is set with this option.

Nameserver

A single nameserver IP address (default is **127.0.0.1**) may be set in the same manner as the miSAN-V-Series default gateway IP address.

ethX (1000 Mbps)

Choices are “Enabled”, “Disabled”, and “Bonded” for each interface.

The primary Ethernet interface is “eth0”. Depending on the configuration, there will usually be either three or five Ethernet interfaces installed. They will be named in sequence (“eth0”, “eth1”, etc.). Default for each interface is **Enabled**. For each

interface, menu options are to enable the interface, and to set “IP address”, “subnet mask”, and “MTU”.

At least one network interface (“bond0”, “eth0”, “eth1”) must be **Enabled**. If all network interfaces are set to **Disabled**, attempting to save changes will give an error message.

The menu item set (**Enabled**, “IP address”, “subnet mask”, “MTU”) will be repeated for each interface. Settings below for “IP address”, “subnet mask” and “MTU” will be shown only if the corresponding Ethernet interface is **Enabled**.

If more than one interface is enabled, the network addresses must be disjoint (i.e., the combination of “IP address” and “subnet mask” must resolve to separate interfaces). The following examples include valid and invalid configurations to further explain this requirement:

eth0	192.168.1.1/255.255.255.0
eth1	192.168.2.1/255.255.255.0
This is a <i>valid</i> combination. IP addresses looking like 192.168.1.X are routed to “eth0”, and addresses looking like 192.168.2.X are routed to “eth1”.	

eth0	192.168.1.1/255.255.0.0
eth1	137.157.1.8/255.255.0.0
This is a <i>valid</i> combination. IP addresses looking like 192.168.X.X are routed to “eth0”, and addresses looking like 137.157.X.X are routed to “eth1”.	

eth0	192.168.1.1/255.255.255.0
eth1	192.168.1.1/255.255.255.0
This is an <i>invalid</i> combination. Both interfaces have the same network parameters.	

eth0	192.168.1.1/255.255.255.0
eth1	192.168.1.2/255.255.255.0
This is an <i>invalid</i> combination. The miSAN-V-Series cannot route outgoing IP requests without additional configuration information.	

eth0	192.168.1.1/255.255.0.0
eth1	192.168.2.1/255.255.255.0
This is an <i>invalid</i> combination. Because of the different subnet masks, the network addresses overlap, so the miSAN-V-Series cannot route IP requests without additional configuration information.	

If the user tries to save an invalid configuration, the miSAN-V-Series will display an error message. Return to the “Network Configuration” menu so that the conflict can be corrected or the changes cancelled.

Two or more interfaces may be “bonded” together to transfer data as a single Ethernet interface “bondX”. This combines the available bandwidth for the multiple interfaces into the “bondX” Ethernet interface. See [Appendix C, “Glossary”](#) for a further explanation of bonding, including requirements.

To do this, set “eth0” and “eth1” to **Bonded**, and then set the network parameters for the “bondX” interface.

ethX IP bonding



Note

This menu item only appears if the Ethernet interface is set to “Bonded”.

This menu option sets the “bondX” interface that the Ethernet interface is part of. Default value is **bond0**.

ethX IP address

All network interfaces must be assigned static IP addresses. The miSAN-V-Series does not support DHCP (Dynamic Host Configuration Protocol), since it is intended that the network interface(s) will be up indefinitely, and lease renegotiation might interrupt a backup operation in progress.

The default “IP address” for the first Ethernet interface is **192.168.1.1**. Default “IP addresses” for subsequent interfaces are **192.168.2.1**, **192.168.3.1**, etc. The static IP address is set with this option.

ethX subnet mask

The default “subnet mask” is **255.255.255.0**. Change the subnet mask in the same manner as for the “IP address”.

ethX MTU



Note

This menu item only appears if the Ethernet interface supports “jumbo” packets. Otherwise, this item is hidden, and the MTU is set to 1500 by default.

This sets the Maximum Transmission Unit (MTU) size. Default value is **1500**. Choices are **1500** and **9000**. The **9000** setting is for use only with Gigabit Ethernet networks that are “jumbo” packet capable (See [Appendix C, “Glossary”](#)).

bondX



Note

This menu item only appears when two or more Ethernet interfaces are set to “Bonded”.

Settings for “bondX IP address”, “bondX subnet mask” and “bondX MTU” will be shown only if Bonding is set to **Enabled**.

However, settings for the “eth” interfaces will be displayed only if “Bonding” is set to **Disabled**.

bondX IP address

The default “bond0 IP address” is **192.168.1.1**. A static IP address is set with this option.

bondX subnet mask

The default “bond0 subnet mask” is **255.255.255.0**. This may be changed in the same manner as for the “IP address”.

bondX MTU



Note

This menu item only appears if the Ethernet interface supports Jumbo frames. Otherwise, this item is hidden, and the MTU is set to 1500 by default.

This sets the Maximum Transmission Unit (MTU) size. Default value is **1500**. Choices are **1500** and **9000**. The **9000** setting is for use only with Gigabit Ethernet networks that are “jumbo” packet capable (See [Appendix C](#), “Glossary”).

Message Delivery

The miSAN-V-Series can be configured to send email messages to notify selected recipients when any of the following events occur:

- A copy from virtual to physical tape completes, which also reports whether the copy was successful
- A disk error occurs, which may require replacing the disk
- The miSAN-V-Series goes offline unexpectedly due to a fatal error

To set up email messaging, the miSAN-V-Series must have access to a Simple Mail Transfer Protocol (SMTP) server on the network.

Email messages sent by the miSAN-V-Series contain the following information fields:

- “From” line: Given as the miSAN-V-Series “Hostname,” as set in the “Network Configuration” menu (See [“Network Configuration” on page 62](#)) with the email address “techsupport@cybernetics.com.”
- “Reply-To” line: Given as, “Cybernetics Technical Support <techsupport@cybernetics.com>.” The Cybernetics Technical Support email address is supplied for miSAN-V-Series email recipients who need assistance after receiving a message reporting an error.
- Message body: Contains information also shown on the “Messages” tab of the Web Control Panel, and for fatal errors, a web link (URL) to the debug log for the miSAN-V-Series, which is available for viewing in a web browser.

The following menu items are used to enable/disable messaging, configure the server location and login information and enter the email addresses for the recipients:

Send messages by email	Enabled
SMTP server (name:port)	147.127.1.8:587
SMTP username (if required)	production
SMTP password (if required)	*** Changed ***
Email address(es) (separate with ";")	techsupport@domain.com
OK	Cancel

Send messages by email

Choices are “Enabled” and “Disabled” for the miSAN-V-Series email messaging feature. Immediately after saving this setting as **Enabled**, the miSAN-V-Series will send an email message to all addresses configured in the “Email address(es)” setting to test and verify the configured SMTP server settings.

SMTP server

Set this menu item to the IP address and port of the SMTP server on the network. Enter the IP address, (or DNS name if a “Nameserver” has been set under the “Network Configuration” menu), followed by a colon (‘:’) and the SMTP port number. If a port is not specified, the miSAN-V-Series will use the standard SMTP submission port **587**, (however, many SMTP servers use port **25**). For example:
137.157.1.8:587

SMTP username

If the SMTP server requires authentication for sending messages, enter a username for the miSAN-V-Series to provide when logging in to the server.

SMTP password

This is the password that goes with the “SMTP username” above.

Email address(es)

This menu item is used for entering the list of recipients who will receive email messages from the miSAN-V-Series. When entering multiple email addresses,

separate each with a semi-colon (;) followed by a space. For example:
`techsupport@domain.com; webmaster@domain.com; admin@domain.com`

Accounts

This sub-menu sets a password for restricting access to the Java Web Control Panel and the Telnet Menu System. For the Web Control Panel, this password is used to load the Java applet. For the Telnet Menu System, this password is specifically used for the “menu” username. For both interfaces, the default password is no password, which allows anyone at any client system that can connect to the miSAN-V-Series to load the Web Control Panel and/or enter the Telnet Menu System and make configuration changes.

Admin

To set a password, or to change an existing password, Click on the **No password set** button (The button may also be labeled **Changed** or **Not changed**). Enter the desired (new) password, and then save the change.

To disable password authentication (remove an existing password), clear the current entry without entering a new password, and then save the change.

Password for Java admin, SSH, telnet, and HTTP	No password set
OK	Cancel

Enter new password

Confirm new password

Once a new password is entered, the user is logged off and a login screen appears. Choose Admin or User and enter the proper password.



Note

For password protection to be effective, both Admin and User accounts must have passwords.

User

The user account may be Enabled (default is *Disabled*). To set a password, or to change an existing password, enter the desired (new) password, and then save the change.

To disable password authentication (remove an existing password), clear the current entry without entering a new password, and then save the change.

The following options apply to the user account:

- User may offload to PTs (Disabled or Enabled).
- User may offload to removable VTs (Disabled or Enabled).
- User may mount VTs (Disabled or Enabled).
- User may write to primary VTs (Disabled or Enabled).
- User may restore from PT (Disabled or Enabled).

All the above options are disabled by default.

User account	Enabled	▼
User password	Not changed	
User may offload to PTs	Disabled	▼
User may offload to removable VTs	Disabled	▼
User may mount VTs	Disabled	▼
User may write to primary VTs	Disabled	▼
User may restore from PT	Disabled	▼
OK		Cancel

Advanced Options

Advanced Menu(s)

These menu selections present a set of submenus named “Advanced Menu 0,” “Advanced Menu 1,” etc. These are preset. Do not change these settings unless directed by Cybernetics Technical Support.

Define Emulations



Note

This menu item only appears if the miSAN-V-Series is configured with multiple emulation support and will not appear on most units.

This menu selection allows for configuring the miSAN-V-Series to support different emulations for tape drives and stackers, up to four each. Each configurable tape or stacker emulation allows for entering a descriptive name for the emulation and selecting a specific manufacturer model, represented by a number.

The configured emulations can be selected for use by virtual devices using the “Virtual Device Emulations” menu (See [“Virtual Device Emulations” on page 52](#)).

**Note**

Enabling support for each emulation requires a passcode. Contact Cybernetics Technical Support to identify numbered emulations and obtain passcodes for specific manufacturer models.

Debugging

This menu selection presents a set of menu items used for enabling specific types of debugging messages. Do not change these settings unless directed by Cybernetics Technical Support.

**Note**

The “Speed test mode” setting is used to test the data transfer rate between the host computer and the miSAN-V-Series independently of the connected SCSI tape devices. When Enabled, the miSAN-V-Series will discard all data from host write commands. For host read commands, the miSAN will return random data.

Host iSCSI Debug Messages

This menu selection presents a set of menu items used for enabling specific types of debugging messages. Do not change these settings unless directed by Cybernetics Technical Support.

Information

This menu displays information about the installed miSAN-V-Series code and devices. Nothing can be changed through this menu.

Product Information

This menu item displays the installed CY-HSTC engine code version (“Version”), unit serial number (“EUI serial #”), HASP security device ID number (“ID #”), host bus mask (“Host bus mask”), miSAN-V-Series flags (“Flags”), Ethernet interface(s) (numbered as “eth”), and MAC address(es) (“HWaddr”). “Host bus mask” is a number indicating which SCSI ports are assigned as targets for host systems.

“Host bus mask” is a number indicating which SCSI ports are assigned as targets for host systems.

“Flags” are installed configuration options, such as “ASP”, “iSCSI-HOST” and “iSCSI DEVICE.” If no options are installed, this line will simply display “Flags:”



Note

The network settings (IP address/subnet mask) and MAC address will be shown for each installed network interface. If bonding is enabled, the network settings and MAC address will be identical for all interfaces.

Physical Devices

This menu item displays a list of all SCSI devices (tape drives and/or libraries) connected to the miSAN-V-Series, with manufacturer, model number, and firmware version.

Virtual Devices

This menu item displays a list of all iSCSI devices (tape drives and/or libraries) connected to the miSAN-V-Series, with manufacturer, model number, and firmware version.

Virtual device assignments

This menu item displays a list of Virtual device assignments.

Credits and Licenses

This menu item acknowledges the proprietary software code copyrighted by Cybernetics and various 3rd-party programs copyrighted by others; the usage licenses for those programs are included as well. The text is reproduced in the “Notices” section of this manual.

Browser links

This item provides web browser clients with access to additional web pages on the miSAN-V-Series. Each web page opens in a new browser window. The following menu items are useful for troubleshooting and viewing settings and hardware configurations:


- **View debug messages:** Shows the miSAN-V-Series message log, which can be updated by refreshing the browser window. If trouble occurs with the miSAN-V-Series, this page may be saved and emailed to Cybernetics Technical Support (techsupport@cybernetics.com) for further assistance.
- **View list of menu settings:** Shows a complete list of miSAN-V-Series menu settings, virtual device configurations and virtual tape assignments. Before loading new firmware code into the miSAN-V-Series, save this page. After the code installs, refer back to this saved page when reconfiguring the miSAN-V-Series settings.
- **View hardware information:** Shows information about the miSAN-V-Series network interfaces, IP routing table and attached SCSI devices.

Tabs

Devices Tab

The “Devices” tab shows a “tree” view on the left with an entry representing each virtual and physical device (physically attached or connected via iSCSI) (See Figure 3-22). Virtual tape drives and stackers (libraries) appear as numbered “VirtTapeDrive” and “VirtStacker” objects, respectively. Physical tape drives and stackers appear as numbered “Tape drive” and “Optical drive” objects, respectively. Optical drives, also supported by the miSAN-V-Series, appear as “Optical drive” objects. The device tree, under the head folder “Devices”, is fully expanded by default, showing a folder for “Virtual” and “Physical” devices. All configured virtual devices are found in the “Virtual” folder. All external physical devices, whether physically attached or connected over the network using iSCSI, appear in the “Physical” folder. If an externally connected physical device does not appear in a folder, make sure the miSAN-V-Series is configured properly to use it. The “Devices” folder will update automatically whenever the miSAN-V-Series device configuration changes, such as after changing the number of virtual devices.

Figure 3-22 “Devices” Tab



Note

To rename a virtual tape drive or stacker, click on the desired device to select it, and then right-click it to show a pop-up command to Rename

Figure 3-23 Renaming a Virtual Tape



Virtual Tape Drive Device Panel

When selected in the device tree, a virtual standalone tape drive will expand to reveal a device panel in the frame on the “Devices” tab (See Figure 3-24). The device panel presents a “Mounted medium” drop-down listbox where the assigned virtual tapes can be mounted. Along the right side of the “Mounted medium” box is a checkbox for enabling the “Autoload” feature. Right-click on VirtTapeDrive X to rename..

Figure 3-24 Virtual Tape Drive Device Panel



Mounted Medium listbox

The “Mounted medium” listbox displays the currently mounted tape. The listbox lists all the virtual tapes assigned to the drive and an option for “None”. The “None” option ejects a virtual tape and leaves the drive empty. Although possible, a virtual tape should not be copied while mounted, since a host could possibly use it. Thus, selecting “None” allows all virtual tapes assigned to the drive to be copied to tape cartridges.

Autoload checkbox

The “Autoload” checkbox controls the virtual tape autoloading feature. If enabled, the miSAN-V-Series will automatically mount the next virtual tape listed in the “Mounted medium” listbox when a host issues an “eject” command. This is useful during backups, such as when the currently mounted tape is full, and during restores, such as when searching through tapes. When “Autoload” is enabled, tapes are changed sequentially, allowing a virtual standalone drive to behave like an autoloading tape media changer. When the last virtual tape is ejected, the miSAN-V-Series will remount the initial tape in the sequence in a “round-robin” manner. Autoloading can be temporarily disabled during a backup or restore by selecting “None” from the “Mounted medium” listbox. To resume, select a virtual tape to continue with in the sequence.

Virtual Stacker Device Panel

When selected in the device tree, a virtual stacker will reveal a device panel in the frame on the “Devices” tab (See Figure 3-25). The “Access mode” field shows which tapes the miSAN-V-Series presents to a host accessing the virtual stacker. The following modes may be shown:

- “virtual tapes”: Virtual tapes assigned to the virtual stacker
- “physical tape drive X”: Physical tape in the tape drive
- “physical stacker X”: Physical tape(s) in the stacker


- Stacker slots are presented as a table with columns for the following fields:
- **Element:** Numbered virtual stacker slots and tape drive(s)
- **Tape:** Tapes presented in the virtual stacker slots and drive(s)
- The “Tape” column shows the tapes a virtual stacker presents to a host system. A virtual stacker presents its tapes by populating the slots from the top of the column, beginning at *Slot 1*.

If the miSAN-V-Series is configured with a physical tape drive and/or library, a host can access the physical tape drive/library by proxy using the virtual stacker.

Direct host access for a physical tape drive pairs the physical tape in the drive with the first slot in the virtual stacker. To access the physical tape, move the tape from *Slot 1* to the virtual stacker drive. You can enable direct host access to a physical tape drive from the physical tape drive’s **Menu** button (See [“Physical Stacker Device Panel” on page 82](#)).

Direct host access for a physical stacker pairs the physical stacker slots with the virtual stacker slots, beginning at *Slot 1*. You can enable direct host access to a physical stacker with the physical stacker’s popup menu (See [“Physical Stacker Device Panel” on page 82](#)). When direct host access to a physical stacker is enabled, the virtual stacker’s “Tape” column will show each physical tape by listing in each slot the corresponding physical stacker’s slot number along with the physical tape’s name.

Figure 3-25 Virtual Stacker Device Panel



Tapes can be moved within the virtual stacker to other slots or drives using a popup menu. This allows for moving tapes without having to use host backup software.

The “Move to” popup menu is accessed by first selecting the desired virtual tape and then right-clicking it. The submenus allow for moving the selected tape to

another slot (See Figure 3-26) or drive (See Figure 3-27). Unavailable slots and drives are greyed out.

Figure 3-26 “Move to slot” Popup Menu





Figure 3-27 “Move to drive” Popup Menu



Physical Tape Drive Device Panel

When selected in the device tree, a physical tape drive will reveal a device panel in the frame on the “Devices” tab. The device panel presents the status information for the tape drive (See Figure 3-28).

Figure 3-28 Physical Tape Drive Device Panel

Physical tape drive 1

Model:	SONY SDX-700C
Firmware version:	01b10001
Serial number:	0000003054
Drive state:	Not in use
Drive status:	OK
Tape name:	PT 2
Tape status:	Loaded
Tape capacity:	26.0 GB
Tape position:	25.4 GB
Current RWR:	0.00%
Average RWR:	0.01%
Average ECC:	0.00%
> Writing	
Transfer rate: 4.2 MB/s	
Menu	

The physical tape drive status information is presented with the following fields:

- **Model:** Tape drive model, as returned from the SCSI Inquiry command
- **Firmware version:** Tape drive firmware, as returned from the SCSI Inquiry command
- **Serial number:** Tape drive serial number, as returned from the SCSI Inquiry command
- **Drive state:** Current physical tape drive activity as one of the following: “Not in use”, “Host access: *virtual tape drive*”, “Host access: *virtual stacker*”, or “Assigned to a job”. Physical stacker tape drives will also report when reading/writing a physical tape header or copying to a virtual tape.
- **Drive status:** Tape drive mechanism condition, which reports “OK”, unless the drive is requesting that you load a cleaning tape (“NEEDS CLEANING”), the drive is reporting a serious problem that prevents normal operation (“HARDWARE ERROR”), or the drive is not responding to commands (“OFFLINE”); check power and connections
- **Tape name:** Name of the currently-loaded physical tape

- **Tape status:** Tape cartridge load status, which reports “Loaded” when ready for use. For a “Loaded” tape cartridge, “MEDIUM ERROR” will also appear if a loaded tape has a problem that prevents the drive from reading or writing data, and “Write-protected” if physically write-protected.
- **Tape capacity:** Total tape capacity (gigabytes)
- **Tape position:** Current tape position as the space remaining until the end of the tape (gigabytes)

**Note**

For a tape drive reporting the unused space (e.g., IBM Ultrium LTO drive), rather than the current tape position, the status will show the remaining space between EOD (End-of-Data) and the end of the tape. The status field will show “Unused space” instead of “Tape position”.

- **Current RWR/ECC:** Current WRITE/READ operation error rate percentage
- **Average RWR:** Average WRITE operation error rate percentage
- **Average ECC:** Average READ operation error rate percentage
- **Transfer rate:** Current WRITE/READ data transfer rate

Menu Button

Pressing the Menu Button brings up a drop-down menu with the following options:

1) Inventory


- **Identify tape...** – This option lets you manually identify the currently-loaded tape from a list of tapes in the database. Use this option after reinserting a tape that you had previously loaded and ejected so the miSAN-V-Series can use the same database entry for the tape as before. This option is usually not necessary for AIT or LTO tapes, which the miSAN-V-Series can identify automatically by their serial numbers. You may find it easier to identify tapes in the database if you rename them from the “Physical tapes” tab when you initially load them ([“Physical Tapes Tab” on page 97](#)).

2) Disk cache

- **Setup offload...**

This option allows for setting up offloading from a virtual tape to the physical tape drive.


Figure 3-29 “Setup offload” Window



To specify which virtual tape to be offloaded to the physical tape:

- 1) Click **Select VT to offload...**
- 2) Select the virtual tape you want to copy to the physical tape.


Figure 3-30 “Select virtual tape” Window



- 3) Click **Use selected VT.**

You can clear the association between a physical tape and the virtual tape for offloading from the “Physical tapes” tab.

Figure 3-31 “Clear VT for offloading” Option



- **Action**

After you choose a virtual tape to be offloaded to a physical tape, you may select one of the following actions to be performed to the virtual tape:

Do nothing to VT – Choose this if the virtual tape already contains a backup you want to offload to the physical tape. This is useful in the following situations:

1. You performed a backup to virtual tape before associating the virtual tape with a physical tape for offloading.
2. You had previously associated the virtual tape with a different physical tape that had an error while offloading (e.g. a bad tape). You can choose this option to associate the virtual tape with a different physical tape.

Erase VT – Choose this if the virtual tape contains data you no longer need, for example if the virtual tape contains an older backup that has already been offloaded to physical tape. Your backup software will see the virtual tape as a new blank tape.

Copy PT header -> VT – Choose this if the virtual tape contains data which you no longer need, and the physical tape contains a backup that you want to purge from your backup software’s database. The miSAN-V-Series will create a job to copy the data header from the physical tape to the virtual tape. When your backup software sees the data header on the virtual tape, it should purge the old backup from its database when overwriting the virtual tape with a new backup.

Copy PT -> VT – Choose this if the virtual tape contains data you no longer need, and the physical tape contains a backup you want to either restore or append.



Note

“Host access” is often an easier method for restoring from a physical tape.

An alternative way to purge the record of an old backup from your backup software's database is to use "Host access" to have your software erase the physical tape (See ["Host access" on page 81](#)). Or, you can delete the old database entry manually through your software.

- Wait for backup

While "Wait for backup" is set, any job to offload the virtual tape to physical tape will wait for the host to do a backup before offloading. The miSAN-V-Series will clear the "Wait for backup" flag when the host does a backup.

Select the "Wait for backup" option if the virtual tape does not contain any data that you want to offload to the physical tape (e.g., if the virtual tape was already offloaded successfully). Deselect the "Wait for backup" option if the virtual tape does contain data from a backup that you want to offload. "Wait for backup" is always selected if you choose "Copy PT header -> VT" or "Copy PT -> VT". "Wait for backup" is selected by default if you choose "Erase VT" or if the virtual tape is already blank, but you can deselect it if desired.

- Offload disk to tape...


Once you have setup offloading, use this option to create a job that does the actual work of copying the virtual tape to physical tape.



Note

"Offload disk to tape..." creates a new set of jobs each time you use it. If you had suspended an offload job and you want to resume that job instead, you can do so from the "Jobs" tab.

Figure 3-32 "Offload disk to tape" Window



The “Source and Destination” frame shows the name of the source (“Virtual tape”) and destination (“Physical tape”) for offloading the tape.

Click “Select VT to offload...”, and then choose the virtual tape to set the source.

“Offload status” shows the status for the selected virtual tape to be offloaded:

Wait for backup – The job will wait for a backup to the virtual tape before starting the offload. You can toggle this flag from the “Setup offload...” option.

Needs offload – The virtual tape needs to be offloaded to physical tape.

In progress – The offload is already in progress; see the “Jobs” tab.

PT same as VT – The virtual tape has already been offloaded to the physical tape. There is no work to be done now, but if you have the job run continuously then any future backups will be offloaded.

- Load tape onto disk...

Use this option to import the data from your physical tapes into the disk cache using “Load tape onto disk...”. Note, you can also do this by selecting the “Setup offload...” option, and then the “Copy PT -> VT” option for the “Action”, which is the preferred way if you intend to append to the backup and offload the appended data back to the physical tape. If you want to import the data for restoring from the disk cache, then “Load tapes onto disk...” is easier.




Note

“Host access” is often an easier method for restoring from a physical tape.

To import the data from the physical tape, you will need to create one virtual tape for each physical tape being imported that has enough capacity to hold the tape’s data after decompression. Make sure the virtual tape is safe to overwrite and not mounted in any virtual drive. Then, select “Load tape onto disk...” to create the jobs that will do the copying.

Figure 3-33 “Load tape onto disk” Window



Host access

Host access enables you to access the physical tape drive directly from your software, bypassing the disk cache. This is often useful for restoring directly from a physical tape.

Enabling host access

Choose one of the virtual devices listed in the “Host access” submenu, and the miSAN-V-Series will temporarily reconfigure the selected virtual device to map to the physical tape drive.

Using host access


You may load and eject physical tapes at will. If you are using a virtual standalone drive, the virtual drive simply mirrors the state of the physical drive. If you are using a virtual stacker, the miSAN-V-Series simulates the operation of a stacker with only one tape in its inventory. The miSAN-V-Series lets the software move the single physical tape around in the virtual stacker, however the physical tape just remains loaded in the tape drive. If you physically eject and replace the tape, to your software it looks like you opened the stacker door, changed the tape in the magazine slot, and then closed the stacker door.

Disabling host access – Go back to the “Host access” submenu and choose “Disable”. The miSAN-V-Series will reconfigure the virtual device to access the virtual tapes rather than the physical tape drive.

Job control

This menu enables you to suspend any jobs using the physical tape drive. This can also be accomplished via the “Jobs” tab (See [“Jobs Tab” on page 99](#)).

If the tape drive is located in a stacker, then the **Menu** button offers only a “Help” option that tells you to use the stacker’s **Menu** button; all control for the stacker’s tape drive(s) is handled using the stacker’s **Menu** button (See [“Physical Stacker Device Panel” on page 82](#)).



Physical Stacker Device Panel



Note

This section only applies if the miSAN-V-Series is configured with Tape Library Control support. The physical stacker device panel is only used when the miSAN-V-Series is configured to operate an external tape library.

Tapes can be moved within the physical stacker to other slots or drives using a popup menu. The popup menu is used only when “Host access” is not enabled, since the library is then inaccessible to hosts. This allows clients to move tapes within the library without possibly interrupting host backup jobs.

The popup menu is accessed by first selecting the desired physical tape and then right-clicking it. The submenus allow for moving the selected tape to another slot or drive. Unavailable slots and drives are greyed out on the popup menu.

Status – Shows one of the following:

- “Door open or not ready”
- “Initializing”
- “Too many tapes loaded” – This happens if you have a tape in every magazine slot plus an additional tape in the tape drive. Remove the the tape from the tape drive, and try again.
- “Ready”
- “Moving tape”
- “In use by another machine” – Some other machine is using the stacker
- “OFFLINE” – The stacker is not responding to commands. Check power and SCSI connections.


Inventory tab

Physical tape library slots are presented as a table with columns for the following fields:

- **Element** – Numbered physical library slots and tape drive(s)

- **Tape** – Tapes inserted in the physical library slots and drive(s)

Figure 3-34 Physical Stacker Device Panel



All control and jobs for the physical stacker are initiated using commands available from a popup menu. To access the popup menu, right-click in the stacker table. Some menu commands require you to select one or more physical tapes before activating the menu; others work with no tapes selected.

The following menu commands are visible. Depending on the stacker's current state, some commands may be greyed-out and unavailable:

- Inventory
- Identify tapes...

This option lets you manually identify the tapes currently present in the stacker from a list of tapes in the database. Use this option after loading tapes that you had used previously so the miSAN-V-Series can use the same database entries for the tapes as before. You may find it easier to identify tapes in the database if you rename them from the "Physical tapes" tab when you initially load them (["Physical Tapes Tab" on page 97](#)).

To help you find the correct set of tapes from the database, the tapes are grouped into sets that were all loaded at once, and then the groups are sorted chronologically.

You can choose from the following options to inventory the tapes:

- Inventory unknown tapes
- Inventory selected tapes
- Inventory all tapes

The "Inventory tapes..." option you choose creates a job that sequentially loads and reads the physical tapes in a physical stacker drive. This enables the miSAN-V-Series to determine the following information about a tape:

- Tape manufacturer and serial number (if available)

- Tape capacity, used space, and free space
- Write-protect status


If the tape has a serial number, then the “Inventory tapes...” option can be used to identify the tape from the database of known tapes.

- **Disk cache**

- Setup offload...


This option allows for setting up offloading from virtual tapes to the physical tapes. Use this option to specify a set of virtual tapes to offload to the physical tapes in the physical stacker inventory.

Figure 3-35 “Setup offload” Window



To assign a virtual tape to a physical tape for automatic copying, first, select the desired virtual tape in the “Virtual tapes” listbox. Then, select the row for the desired physical tape cartridge in the “Physical tapes” table. Finish by clicking the -> button, which assigns the virtual tape name, in the “Virtual tape” column, to the physical tape. (The **Help** button provides an explanation of how to set up the copy.)

Figure 3-36 Assigning a Virtual Tape to a Physical Tape



After you assign the virtual tapes to the physical tapes, for each assignment, you may select one of the following actions to be performed to the virtual tape. To

select one of the actions, right-click the row for the desired physical tape/virtual tape assignment, and choose the “Set action” menu option.

Do nothing to VT – Choose this if the virtual tape already contains a backup you want to offload to the physical tape. This is useful in the following situations:

- 1) You performed a backup to virtual tape before associating the virtual tape with a physical tape for offloading.
- 2) You had previously associated the virtual tape with a different physical tape that had an error while offloading (e.g. a bad tape). You can choose this option to associate the virtual tape with a different physical tape.

Erase VT – Choose this if the virtual tape contains data you no longer need, for example if the virtual tape contains an older backup that has already been offloaded to physical tape. Your software will see the virtual tape as a new blank tape.

Copy PT header -> VT – Choose this if the virtual tape contains data which you no longer need, and the physical tape contains a backup that you want to purge from your software’s database. The miSAN-V-Series will create a job to copy the data header from the physical tape to the virtual tape. When your software sees the data header on the virtual tape, it should purge the old backup from its database when overwriting the virtual tape with a new backup.

Copy PT -> VT – Choose this if the virtual tape contains data you no longer need, and the physical tape contains a backup you want to either restore or append.



Note

“Host access” is often an easier method for restoring from a physical tape.

An alternative way to purge the record of an old backup from your backup software’s database is to use “Host access” to have your software erase the physical tape (See [“Host access” on page 81](#)). Or, you can delete the old database entry manually through your software.

- Wait for backup

While “Wait for backup” is set, any job to offload the virtual tape to physical tape will wait for the host to do a backup before offloading. The miSAN-V-Series will clear the “Wait for backup” flag when the host does a backup.

Select the “Wait for backup” option if the virtual tape does not contain any data that you want to offload to the physical tape (e.g., if the virtual tape was already offloaded successfully). Deselect the “Wait for backup” option if the virtual tape does contain data from a backup that you want to offload. “Wait for backup” is always selected if you choose “Copy PT header -> VT” or “Copy PT -> VT”. “Wait

for backup” is selected by default if you choose “Erase VT” or if the virtual tape is already blank, but you can deselect it if desired

Figure 3-37 “Wait for backup” Option

Physical tapes				
Slot	Physical tape	Virtual tape	Action	Wait for backup
1	PT 9	VT 2.1	Do nothing to VT	☒
2	PT 10			☐
3				☐

You can clear the association between a physical tape and the virtual tape for offloading from the “Physical tapes” tab (See [“Physical Tapes Tab” on page 97](#))

Figure 3-38 “Clear VT for offloading” Option

Physical tapes					
Filters: All tapes All devices					
Name	Location	Status	VT for offloading	Offload status	
PT 3	Stacker 1 slot 1	Unknown			
PT 4	Stacker 1 slot 2	Unknown			
PT 5	Stacker 1 slot 1	Unknown			
PT 6	Stacker 1 slot 2	Unknown			
PT 7	Stacker 1 slot 1	Unknown			
PT 8	Stacker 1 slot 2	Unknown			
PT 1	Stacker 1 slot 1	OK			
PT 10	Stacker 1 slot 2	OK			
PT 11	Stacker 1 slot 1	Unknown			
PT 12	Stacker 1 slot 2	Unknown			
PT 2	Tape drive 2	OK	VT 2.1	Needs offload	

Rename
 Clear error flags
Clear VT for offloading
 Forget current contents
 Remove from database

- Offload disk to tapes...

This option creates jobs that do the actual work of copying the virtual tapes to physical tapes.



Note


“Offload disk to tapes...” creates a new set of jobs each time you use it. If you had suspended an offload job and you want to resume that job instead, you can do so from the “Jobs” tab.

(See [“Jobs Tab” on page 99](#)) for more information on Jobs.

Selecting “Offload disk to tapes...” will show the “Offload disk to tapes” window with its two tabs: “Copy selections” and “Copy options”.


The “Copy selections” tab is used to offload the set of virtual tapes specified using the “Setup offload...” option to the physical tapes.

Figure 3-39 “Copy selections” Tab




The “Copy profiles” frame (See Figure 3-40) allows for selecting and using one of the saved copy profiles to automatically assign virtual tapes to physical tapes (See [“Physical Stacker Copy Profiles” on page 43](#)).

Figure 3-40 “Copy profiles” Frame



The “Copy options” tab is used for specifying when to initiate the copies. It presents two sets of buttons for setting the frequency of the copies and an option for delaying their start (See Figure 3-41).

Figure 3-41 “Copy options” Tab



You can choose how many times the jobs will offload before stopping:

Offload each virtual tape only once – If you need to do the offload again, you can start more jobs later.

Run jobs continuously, offloading after each backup to VT – To stop offloading, suspend the job or remove the physical tape.

Continue running jobs even when tapes are changed (requires a copy profile) – This option lets you offload a specific set of virtual tapes to any physical tapes that you load in specific slots in the stacker. The jobs will continue to run even when you open the stacker door and change the physical tapes. To stop offloading, suspend the jobs.

The miSAN-V-Series remembers the details of the last offload to the physical tape. If your backup software appends to the virtual tape after an offload, the next offload will also append to the physical tape rather than doing a full copy. If the offload status is “PT is same as VT”, then the miSAN-V-Series will refuse to offload until your backup software writes to the virtual tape again. You can force the miSAN-V-Series to perform the full offload again by using the “Forget current contents” option from the “Physical tapes” tab (See [“Physical Tapes Tab” on page 97](#)). You may find this useful for doing testing.

- **Load tape onto disk...**

Use this option to import the data from your physical tapes into the miSAN-V-Series’s disk cache. This is useful for making multiple copies of a physical tape cartridge by first staging the physical tape to virtual tape and then selecting to “Offload disk to tapes” using multiple physical tapes.

Note, you can also do this by selecting the “Setup offload...” option, and then the “Copy PT -> VT” option for the “Action”, which is the preferred way if you intend to append to the backup and offload the appended data back to the physical tape. If you want to import the data for restoring from the disk cache, then “Load tapes onto disk...” is easier.



Caution

Before selecting to copy from physical tape, make sure the virtual tape has enough capacity to hold all the decompressed data to be transferred from the tape cartridge. If the virtual tape is not large enough, the data copied from the tape cartridge will be cut short. In that case, the miSAN-V- Series will copy until the virtual tape is full and then stop.


Do not try to access a virtual tape while it is being copied to/from a physical tape (e.g., by mounting it in a virtual tape drive or copying it to a different physical tape), else the virtual tape could become corrupted

To import the data from the physical tapes, you will need one virtual tape for each physical tape being imported that has enough capacity to hold the tape’s data after decompression. Make sure the virtual tapes are safe to overwrite and not mounted in any virtual drive. Then, select “Load tape onto disk...” to create the jobs that will do the copying.

Selecting the “Load tapes onto disk...” option to show the “Load tapes onto disk” window with a list box, on the left, showing all the slots and physical tapes in the


physical stacker and a table, on the right, with all the virtual tapes assigned to devices (See Figure 3-42).

Figure 3-42 “Load tapes onto disk” Window



To assign a physical tape to a virtual tape for copying, first, select the desired physical tape cartridge in the “Physical tapes” listbox. Then, select the row for the desired virtual tape in the “Virtual tapes” table. Finish by clicking the -> button, which assigns the physical tape name to the virtual tape “Copy source” (See Figure 3-43). (The **Help** button provides an explanation of how to set up the copy.)

Figure 3-43 Assigning Physical Tapes To Copy



Once all the desired physical tapes have been assigned, click **Start**. After clicking **Start**, the copy job will begin immediately or will be queued until the physical stacker tape drive becomes available. During the copy process, the physical stacker tape drive device panel will show the “Drive state” as “Copying to *virtual tape name*”.

- Host access

Host access enables you to access the physical stacker directly from your host backup software by proxy using a virtual tape drive or stacker. This is often useful for restoring directly from a physical tape.

Enabling host access

- 1) Choose the slot(s) in the physical stacker that you want to allow host access; you can select slots individually or in a contiguous group:

**Note**

To allow host access to the physical stacker using a virtual tape drive, select only one slot.

**Note**

This icon indicates useful tips on getting the most from your unit.

- **Selecting slots individually:** To select more than one slot, hold down the **CTRL** (PC) or Command (Mac) key, then and click each slot.
 - **Selecting slots in a contiguous group:** To select a group of slots, click the first slot in the group, hold down the **SHIFT** key, and then click the last slot in the group.
- 2) Choose one of the virtual devices listed in the “Host access” submenu, and the miSAN-V-Series will temporarily reconfigure the selected virtual device to map to the physical tape drive.

Using host access

You may load and eject physical tapes at will. If you are using a virtual standalone drive, the virtual drive simply mirrors the state of the physical drive. If you are using a virtual stacker, the miSAN-V-Series simulates the operation of a stacker with only one tape in its inventory. The miSAN-V-Series lets your backup software move the single physical tape around in the virtual stacker, however the physical tape just remains loaded in the tape drive. If you physically eject and replace the tape, to your backup software, it looks like you opened the stacker door, changed the tape in the magazine slot, and then closed the stacker door.

- **Disabling host access**

Go back to the “Host access” submenu and choose “Disable”. The miSAN-V-Series will reconfigure the virtual device to access the virtual tapes rather than the physical tape drive.

- **Job control**

This menu enables you to suspend any jobs using the physical tape drive. This can also be accomplished via the “Jobs” tab (See [“Jobs Tab” on page 99](#)).


- **Move to slot**

This menu option enables you to move the selected tape to another slot. Unavailable slots are greyed out.

Properties tab

The “Properties” tab gives the following information: the model, firmware version, serial number, stacker type (“Normal stacker” or “Autoloader”), number of slots, number of import/export slots, and number of tape drives.

Figure 3-44 Physical Stacker “Properties” Tab



The screenshot shows a web interface for 'Physical stacker 1'. It has two tabs: 'Inventory' and 'Properties', with 'Properties' being the active tab. Below the tabs is a table with the following information:

Model:	BDT ThinStor AutoLdr
Firmware version:	M11r
Serial number:	E475000197
Stacker type:	Autoloader
Slots:	8
Import/export slots:	0
Tape drives:	1

The “Properties” tab gives the following information about the physical stacker:

- Model, firmware version, and serial number of the stacker
- Stacker type: “Normal” or “Autoloader”
- Number of magazine slots, import/export slots, and tape drives

These numbers give the actual number of elements rather than the HSTC license-limited numbers.

Optical Drive Device Panel


When selected in the device tree, an optical drive will reveal a device panel in the frame on the “Devices” tab (See Figure 3-45). The optical drive device panel shows the following:

Whether a disc is loaded

- **Virtual tape:** Name of the virtual tape stored on the optical disc, “None” or “NEEDS FORMAT” (needs to be formatted; see **Format** button below)

- **VT->VT:** Shows “Not copying” (idle), “Reading disc” (copying from optical disc to virtual disk) or “Writing disc” (copying from virtual disk to optical disc).

Figure 3-45 Optical Drive Device Panel



The device panel presents three buttons for operating the optical drive (See Figure 3-45):

- **Eject:** Ejects a disc inserted into the optical drive

Note: The optical drive’s Eject button is disabled by the miSAN-V-Series

- **Format:** Formats a disc inserted into the optical drive and creates a new virtual tape called “VT optical disc”.

After formatting the disc, the miSAN-V-Series determines the available storage

capacity of the optical disc and then creates a single virtual tape of that size.



Caution

Make sure to format the disc before writing to it for the first time. Remember that formatting the disc will erase any data currently stored on it.

- **Backup a VT:** Allows for copying a virtual tape to optical disc.




Caution

The size of the virtual tape to be copied to the optical disc must not be larger than the optical disc storage capacity, else the copied virtual tape will be truncated and incomplete.

After clicking **Backup a VT**, a window will appear with a drop-down listbox that includes all the virtual tapes.

To begin the copy, select the desired virtual tape from the listbox (See Figure 3-46), and then click **OK**. The copy will begin immediately or be queued until the optical drive becomes available. The miSAN-V-Series will automatically eject the disc after the copy completes

Figure 3-46 “Select virtual tape to backup” Window



Virtual Tapes Tab

The “Virtual tapes” tab shows the current status of each miSAN-V-Series virtual tape.

Status Fields

The virtual tape cache is presented as a table with rows for each virtual tape and columns for the following tape fields (See Figure 3-47):

- **Tape name:** Virtual tape name (tape label), which can be renamed using the Control Popup Menu
- **Status:** Current tape activity as one of the following: “Idle,” “Mounted” or “Copying”
- **Capacity:** Total tape size (gigabytes)
- **Used:** Used tape capacity (gigabytes)
- **Free:** Free tape capacity (gigabytes)
- **Use %:** Tape use percentage
- **Copies:** Number of copies committed to physical tape cartridge


Figure 3-47 “Virtual tapes” Tab

Virtual tapes							
Tape name	Status	Capacity	Used	Free	Use %	Copies	
VT 2.1	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.2	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.3	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.4	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.5	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.6	Mounted	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.7	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.8	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.9	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.10	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.11	Idle	5.0 GB	2.3 GB	2.7 GB	45%	0	
VT 2.12	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.13	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.14	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	
VT 2.15	Idle	5.0 GB	0.0 GB	5.0 GB	0%	0	

Virtual Tape Popup Menu

Virtual tape control is handled using a popup menu (See Figure 3-48).


Figure 3-48 Virtual Tape Popup Menu



The virtual tape popup menu is accessed by first selecting the desired virtual tape and then right-clicking it. The virtual tape popup menu offers the following controls:

- **Mount:** Mounts the virtual tape in its assigned virtual tape drive
- **Rename:** Allows for renaming (relabeling) the virtual tape. Selecting “Rename” will bring up a window for changing the name of the selected virtual tape. After entering the new name, click **OK**. To continue renaming virtual tapes in sequence, click **Next** or **Previous**.

Figure 3-49 “Rename virtual tapes” Window



- **Set volume tag:** Allows for adding a volume tag to the virtual tape. A volume tag contains information used to physically identify a tape cartridge, such as is presented by a barcode label on a tape cartridge. Thus, the “Set volume tag” control allows a virtual tape to present a virtual barcode to a host.



Note

A virtual tape volume tag is only useful if the tape is assigned to a virtual stacker, since a virtual standalone drive is incapable of reporting a volume tag to a host.


- **Erase:** Erases the virtual tape contents. After confirming the tape erase, the HSTC will also ask whether to clear the volume tag (See the “Set volume tag” control). Keeping the volume tag will present the same empty tape to the host. Clearing the

volume tag will allow the virtual tape to appear as if it has been replaced by a new empty tape in the virtual device.

Copy to another VT: Used to initiate a copy from the virtual tape to another virtual tape. The destination virtual tape copy will be identical to the source virtual tape, including the contents and properties, with the exception of the volume tag (the volume tag will not be copied).


When selected, a box will appear prompting for the destination virtual tape:

Figure 3-50 “Select copy destination” Window



After selecting the desired virtual tape and clicking OK, a box will appear asking for confirmation about overwriting the contents of the destination virtual tape; click Yes to start the copy.

Figure 3-51 “Confirm data overwrite” Window



When the copy begins, the name of the destination virtual tape will be changed to show name of the source virtual tape inside brackets (e.g., [VT 1]). During the copy, the name of the destination virtual tape will be followed by an asterisk to indicate the copy is in progress (e.g., [VT 1] *). The asterisk will disappear after the copy completes.



Note

If the copy is cancelled, the asterisk will be replaced by “incomplete”. In this case, the destination virtual tape should be erased and renamed.

The “Jobs” tab will show the progress of the copy operation.

Bar code:



Note

This tab can only be used when the miSAN-V-Series is configured with Tape Library Control support and is configured to operate an external tape library that reports barcodes.

Use the Physical tapes tab to select and assign a volume tag from the bar code labels on the tapes in the physical stacker. This makes it easier later when offloading virtual tapes to physical tapes (See [“Setup offload...”](#) on page 84).

Figure 3-52 “Manage volume tags” Window

Element	Tape
Slot 1	PT 5
Slot 2	PT 6
Slot 3	
Slot 4	
Slot 5	
Slot 6	
Slot 7	
Slot 8	

Virtual Tape	Volume Tag	Action
VT 2.1		
VT 2.2		
VT 2.3		
VT 2.4		
[VT 2.2]		
VT 2.6		
VT 2.7		
VT 2.8		
VT 2.9		
VT 2.10		
VT 2.11		
VT 2.12		
VT 2.13		
VT 2.14		
VT 2.15		

To assign a physical tape barcode to a virtual tape volume tag, first, select the row for the desired physical tape cartridge in the “Physical stacker” table. Then, look to the upper-right; select the row for the desired virtual tape.

Finish by clicking the **-> Assign ->** button, which assigns the physical tape barcode to the virtual tape “Volume Tag”.

The “Copy profiles” frame (see below) allows for selecting and using one of the saved copy profiles to automatically assign physical tape barcodes to the virtual tape volume tags (See [“Physical Stacker Copy Profiles”](#) on page 43).

Figure 3-53 “Copy profiles” Frame

- **Edit tab:** Use this tab to enter the volume tag manually. The volume tag consists of identification text (32 character maximum, 0-9, A-Z, and _) and a sequence

number (0-65535). The **OK** button sets and the **Clear** button erases the volume tag. Be sure not to assign the same volume tag to more than one virtual tape.

Figure 3-54 “Edit” Tab for Volume Tags

Virtual Tape	Volume Tag	Action
VT 2.1		
VT 2.2		
VT 2.3		
VT 2.4		
VT 2.5		
VT 2.6		
VT 2.7		
VT 2.8		
VT 2.9		
VT 2.10		
VT 2.11		
VT 2.12		
VT 2.13		
VT 2.14		
VT 2.15		

- **Properties:** Brings up a properties box listing the following virtual tape information: “Name” (tape label), “Location” (disk number the VT resides on), “Writable” (whether it’s currently write-protected), “Volume tag” (ID text and sequence number), “Capacity” (bytes), “Used space” (bytes), “Free space” (bytes), “Up-to-date copies” (number of copies committed to physical tape cartridge) and “Last modified” (month, day, year and time of last update; see “Set Date/Time”) (See Figure 3-55).

Figure 3-55 Virtual Tape Properties Windows

VT 2.11 properties

Name: VT 2.11
 Location: Disk 2
 Writable: Yes
 Volume tag: (none)
 Capacity: 4999610368 bytes (5.0 GB)
 Used space: 2256711680 bytes (2.3 GB)
 Free space: 2742898688 bytes (2.7 GB)
 Up-to-date copies: 0
 Last modified: Aug 30, 2005 5:56:51 PM

Close

Physical Tapes Tab



Note

This section only applies if the miSAN-V-Series is configured with Tape Library Control support, and is configured to operate an external tape library.

The “Physical tapes” tab shows the current status of tape cartridges in a physical library. The HSTC remembers the contents for physical tapes containing copies of virtual tapes, displaying the status information on the “Physical tapes” tab. The tab shows the “Contents” of the tape cartridges and whether the contents are identical to

their copied virtual tapes. When a backup of a virtual tape begins, its associated physical tapes will be used.

Whenever the library door is opened and then closed, the tape status for all physical tapes is automatically refreshed. During the refresh, the physical tape barcodes will be read and their “Contents” remembered. Else, if a tape does not have a barcode, or a barcode error occurs, the physical tape status will be reset. Thus, barcoded tapes will retain the reference to their “Contents”. However, tapes not reporting a barcode will not.

The “Contents” and status of an individual tape cartridge can be reset by invalidating the physical tape status. Invalidating the tape status drops the reference to its “Contents” and refreshes the physical library slot.

To invalidate a tape cartridge and refresh the physical library slot, first select the tape cartridge on the physical tapes tab. Right-click the selected tape, and then a popup menu will appear with a command to “Invalidate this information”.

Status Fields

The physical tapes in the library are presented in a table with rows for each tape cartridge and columns for the following tape fields (See Figure 3-56):

- **Name**
- **Location:** Tape cartridge label or slot number. If the tape cartridge is not labeled, the tape is identified by its slot number.
- **Status:** Tape cartridge condition as either “OK” or “Bad tape”. The “Status” will report “Bad tape” if an error occurs when writing/reading or accessing the tape. Along with the condition, “write protect” will also appear if physically write-protected.
- **VT for offloading:** Virtual tape the contents were copied from, else “(unknown)”. “Contents” also indicates the virtual tape to which the *tape cartridge** is referenced. (* or *library slot*, if the library does not report barcodes)
- **Offload Status.**

Figure 3-56 “Physical tapes” Tab

Name	Location	Status	VT for offloading	Offload status
PT 1	Stacker 1 slot 1	OK		
PT 3	Stacker 1 slot 1	Unknown		
PT 4	Stacker 1 slot 2	Unknown		
PT 5	Stacker 1 slot 1	Unknown		
PT 6	Stacker 1 slot 2	Unknown		
PT 2	Tape drive 2	OK		

Jobs Tab

The HSTC uses jobs to do its own internal work such as offloading virtual tapes to physical tapes. These jobs are similar in concept but separate from the jobs that your backup software may use to do backups and restores.

The HSTC performs the following types of jobs:

- Copy from virtual tape to physical tape
- Copy from physical tape to virtual tape
- Copy from virtual tape to virtual tape
- Auto-archive
- Inventory a physical tape in a stacker
- Enable host access to a physical tape in a stacker using a standalone virtual tape drive
- Erase a virtual tape


Jobs of different types are created in different ways, but once created, all jobs can be managed using the “Jobs” tab. The job database view is split into three parts: the “Jobs” table showing summary information for all the jobs, the “Job log”, and the “Activity monitor”.

Jobs Table

The jobs database is presented in a table with rows for each job and columns for the following fields (See Figure 3-57):

- **ID:** A unique, sequential, numeric identifier for each job
- **Description:** Indicates the type of job with the involved physical and virtual elements

Figure 3-57 “Jobs” Tab



- **State:** Indicates one of the following states:
 - “Running” – Either Actively doing work, waiting for some trigger condition, or waiting for a required resource to become available
 - “Suspended” – Not doing any work until you manually resume it
 - “Ended” – Finished its work and cannot be resumed or restarted (However, you can start another job to do the same thing if needed).
 - “Deleting” – Performing a cleanup action such as rewinding a physical tape. Once the cleanup finishes, the job will disappear from the database.
- **Status:** Indicates the progress of a job in the “Running” state. For further details, see the “Activity monitor”.

You can suspend a job manually by selecting the job in the table, right-clicking for a popup menu, and selecting “Suspend”. Some jobs may also suspend themselves under certain circumstances. For example, if a copy from virtual tape to physical tape encounters a problem with the physical tape, then the HSTC will automatically suspend the job until the user decides what to do. If you try to start a new job that suspends itself immediately, then you will get a popup message to notify you of the problem.

You can resume a job by selecting the suspended job in the table, right-clicking for a popup menu, and selecting “Resume”. The job may suspend itself again immediately if there is a condition that prevents the job from being able to run. In this case, you must clear the condition before resuming the job. For example, if a copy from virtual tape to physical tape is suspended because of a problem with the physical tape, then you must either use a different tape or go to the “Physical tapes” tab, select the physical tape, right-click for a popup menu, and then choose “Clear error flags”.

Job Log

The “Job log” and shows detailed information for the jobs selected in the “Jobs” table.




Note

If you select multiple jobs from the “Jobs” table, the “Job log” will list each job sequentially.

You can copy the “Job log” contents to the clipboard by first right-clicking in the “Job” log, from the popup menu, selecting “Copy to clipboard”, and then pasting the text into a text editor.

Figure 3-58 Exporting the “Job log”



You can export the entire “Jobs” table by selecting all the jobs in the table, copying the text in the “Job log” to the clipboard, and then pasting the text into a text editor.

Activity Monitor


The “Activity monitor” shows detailed information for the job selected in the “Jobs” table. Only a job in the “Running” state will display any activity on the “Activity monitor”.



Note

Multiple “Running” job statuses cannot be shown simultaneously on the “Activity monitor”. Thus, when you select multiple jobs from the “Jobs” table, the “Activity monitor” will be blank.

Figure 3-59 “Activity monitor” Tab




Messages Tab

The “Messages” tab reports disk accessibility and reading/writing errors, which indicates possible disk drive failure.

This tab also reports the completion status of UM-MV-86 copy operations. After a copy to a virtual or physical tape completes, the “Messages” tab will update with a report indicating statistics such as tape usage, error rate and transfer rate information (See Figure 3-60).

Figure 3-60 “Messages” Tab



An asterisk on the “Messages” tab label indicates a new message has been reported.

Figure 3-61 New Message Indicator



USB offload

Up to two USB disk drives may be plugged in simultaneously using the USB ports on the front of the chassis. USB disk drives may be hotplugged while the unit is running; the firmware will detect the disk drive and start using it automatically. There is no need to power down the unit or rescan for devices. USB disk drives may also be hot unplugged; however, to prevent data loss, the user should click the ‘Remove disk’ button in the Java applet first.

Offloading a Virtual Tape to a USB disk has a speed averaging about 28 MB/s. Restoring from a USB disk drive must be done through the miSAN-V-Series; no other software understands the format of the data on the disk.

Virtual Tapes on USB disk drives may be treated like any other virtual tapes as long as the USB drive remains plugged in. You can assign a USB Virtual Tape to a virtual tape drive or virtual stacker, mount it, do a backup or restore, or even offload from USB to physical tape.

USB disks are intended for offloading Virtual Tapes rather than being used as primary storage, so the HSTC treats USB disks slightly differently than other disks. A USB disk will show up in the Java applet under the physical device tree with its own panel of information and controls, just like a physical tape drive would. The control panel shows the Virtual Tapes that are on the USB disk and indicates if they are idle or busy. There are three control buttons:

-
- 1) "Create VTs" - this brings up the same window as "Tools->Create virtual tapes...", except that it is specifically for the one USB disk only. You may create multiple VTs on one USB disk, just like any other disk drive. Note that "Tools->Create virtual tapes..." does not list USB disks.
 - 2) "Backup a VT" - creates a VT->VT copy job to copy a VT to the USB drive. The destination VT must be created first using the "Create VTs" button.
 - 3) "Remove disk" - prepares the USB drive for hot-unplug. Always press this button and wait for the "Ready for removal" message before unplugging the USB drive to prevent data loss.

Chapter 4

Telnet Menu System

Telnet Menu System


This section describes the telnet menu system available used for configuration and operation of the miSAN-V-Series.

To use the telnet menu system, the unit must be powered on and fully initialized. To connect, open a standard telnet or terminal emulation program on a host system connected to the local network. Point to the miSAN-V-Series Management LAN Ethernet interface ("ETH0") IP address (default is **192.168.1.1**; see ["Network Configuration" on page 60](#)) and the standard telnet port **23**. The telnet client should be set to VT100 emulation, no local echo, and 80×24 characters or more.

Telnet access must be made via the TCP/IP network connection. If the unit includes more than one network interface, a telnet session may be opened on any of the interfaces. Access via a serial port is not supported.

Only one telnet session at a time is supported. If a second telnet session is opened from the same or another host, on any interface, only a blank screen will be displayed.

When the telnet session connects, it will immediately display the following screen:



```
Cybernetics ASP, HSTC, and miSAN-V8
Copyright (c) 2002 - 2007 Cybernetics

*** NOTE: SSH is now available! ***

You may still login using telnet, but consider switching to SSH for better
security.
cyberasp login: _
```

Type the username **menu** and press **ENTER**. The username "menu" is required for access to the menu system. This username cannot be changed. If a password has been set, the miSAN-V-Series will prompt for the password. If a password has not been set (default is no password), an initial screen will be displayed, similar to the following:

```
High Speed Tape Cache 2.46
Copyright (c) 2002 - 2007 Cybernetics

Hostname: cyberasp

eth0: 192.168.1.4
eth1: 192.168.2.1
eth2: 192.168.3.1

Type 'm' to activate the menu.
```

miSAN-V-Series Messages

The miSAN-V-Series may on occasion need to display a message to the user. Messages are displayed during startup initialization or to announce completion of an offline operation or to request user confirmation of an action.

When the menu system is being accessed, all messages will be held by the miSAN-V-Series. Any pending messages will be displayed when the user exits from the menu system and returns to the initial screen.

Menu Operation

The telnet menu structure is described briefly in the next section. Not all menu items will be available in all miSAN-V-Series configurations. Menu item appearance depends on hardware configuration and installed options. The “Menu Descriptions” section, earlier in this chapter, includes detailed explanations for menu selections and items options. This section will focus on those menu items that are only found in the Telnet menu system as opposed to the Web Control panel.

At the initial screen, typing **m** will bring up the “Main Menu.” Each menu item is numbered, and pressing a number will bring up the corresponding submenu. Similarly, within each submenu, pressing a number will bring up the corresponding numbered item.

The “Main Menu” will look similar to the following:

```
Main menu

1> Configuration
2> SCSI configuration
3> Network configuration
4> Message delivery
5> Accounts
6> Information
7> Advanced options
8> Offline maintenance
9> Shut down

x> Exit menu
```

To change a setting, type the number or letter corresponding to the menu or submenu item, and type the new information. Some items (generally, those that need the user to type information, such as a hostname) require confirmation by pressing **ENTER**, though most do not. An item is changed by typing a number to select from a list of choices. Changes are not made effective until after leaving the menu system.

The “Main Menu” and each submenu include an item marked:

x) Exit

If any changes are made to the information, the changes are not committed until after leaving the menu system. The exit item will change to a pair of menu items:

s) Save changes and exit

x) Discard changes and exit

Type **s** or **x** as desired, to exit the menu with changes saved or not.

Example: to change the hostname for the unit:

1. At the initial screen, type **m** to bring up the “Main Menu.”
2. At the Main Menu, type **2** to bring up “Network Configuration.”
3. Type **1** to bring up the Hostname entry. This will display the current hostname (default is “cyberasp”).
4. Enter the desired hostname, and press **ENTER**. This will change the hostname display, and return to the “Network Configuration” menu.
5. Type **s** to save the change and exit from the menu. The message “Changes saved” will be displayed briefly; then the initial screen will return.

SCSI configuration

This menu is used to set up SCSI and iSCSI connections. Items 1, 2, and 3 are set up as described in “SCSI HBA Ports” on page 54.

```
SCSI configuration
1) SCSI HBA ports
2) Incoming iSCSI connections from hosts
3) Outgoing iSCSI connections to devices
4) Configure iSCSI hosts
5) Assign virtual devices to hosts
6) Swap SCSI HBA ports
x) Exit menu
```

Configure iSCSI hosts

```
iSCSI hosts
No iSCSI hosts defined.
1) Add host by IP address
2) Add host by iSCSI InitiatorName
3) Add host by iSCSI InitiatorAlias
4) Add cached host
x) Exit
```

Assign virtual devices to hosts

Use this sub-menu to control host access to virtual devices.

```
Current host: SCSI host port HBA 2 "Payroll Server"
1> Virtual stacker 1    Assigned
2> Virtual tape drive 1 Assigned
n> Next host
p> Previous host
u> Unassign all devices from this host
x> Exit
```

Swap SCSI HBA ports

```
First HBA to swap
1> HBA 1 Ultra320 LUD "Library"
2> HBA 2 Ultra160 LUD "Payroll Server"
x> Exit menu
```

Offline Maintenance



Note

This menu option and its submenu item are only available using the Telnet Menu System.

This menu is used for maintenance such as uploading hardware code or debugging. While the miSAN-V-Series is in this mode, all connected SCSI devices will be “offline” and unavailable to a host computer system.

The miSAN-V-Series will enter this mode automatically if it detects an unrecoverable error.

Do not enter this mode unless the miSAN-V-Series is idle. If possible, eject all tapes from tape drives and stop host system device drivers that communicate with the miSAN-V-Series. A prompt will appear for confirmation to bring the unit offline before entering “Offline Maintenance” mode, and again to bring the unit back online when through.

Display debug output

This menu item displays debugging information useful to Cybernetics Technical Support.

Rescan SCSI buses

This menu item forces the miSAN-V-Series to rescan for connected SCSI devices.

Load board code

This menu item loads firmware into the miSAN-V-Series from a connected physical tape drive or via a TCP/IP network connection, for code upgrades as directed by Cybernetics Technical Support.

Reset options to defaults

This menu item resets all settings to default values. Do not do this unless directed by Cybernetics Technical Support.

Test system memory

This menu item will run a series of tests on the miSAN-V-Series system memory. Total run-time is typically several minutes. If this item is selected, a confirmation dialog will be displayed. Pressing **ENTER** will start the testing, and the screen will display the following:

```
This may take a while...
```

When testing is complete, the screen will display the test result, as though “Display debug output” had been selected from the “Offline Maintenance” menu.

Shut Down

This menu item is used for safely shutting down or rebooting the miSAN-V-Series. Shutting down the miSAN-V-Series engine before powering off the unit helps insure the integrity of data in the virtual tape cache.



Caution

Never power off the unit without first shutting down the HSTC engine.

If the “Shutdown” option is selected, a confirmation dialog will be displayed with the following:

```
Shut down the unit for the power-off?  
Press Enter to continue or 'x' to cancel.
```

Pressing **ENTER** will cause the miSAN-V-Series to disconnect the telnet session and then shut down. When the miSAN-V-Series has finished shutting down, the unit will remain running until powered off using the power button on the rear panel

If the “Reboot” option is selected, the shutdown routine explained above will occur, and the miSAN-V-Series will restart and be ready for use again after about 90 seconds.

Chapter 5

Using the 3ware Disk Manager®

The miSAN-V-Series integrates the 3ware® Escalade® 950S-X SATA RAID controller to control the hot swappable SATA disk drives. The 3ware RAID controller offers a web-based GUI interface called the 3ware Disk Manager 2 (3DM® 2) that allows for viewing the status of and managing the controller and associated disk drives remotely.



Note

3DM can be used while the drives are online, but changing the RAID configuration will fail because the disks will be mounted.

See [“Disk Storage” on page 40](#) for instructions on how to take the disk drives offline so they can be reconfigured.

Browser Requirements

3DM 2 (3ware Disk Manager) displays information in a web browser. It requires the following:

- Microsoft® Internet Explorer 5.5 and later or Mozilla 1.2 or later
- JavaScript™ must be enabled
- Cookies must be enabled
- For best viewing, screen resolution should be 1024×768, with 16-bit color or more

Accessing From a Browser

The 3DM runs a web server on its default HTTPS (SSL Encrypted HTTP) port 888. To access 3DM, point the web browser to the miSAN-V-Series hostname or IP address with the port 888.

Examples include (using defaults):

`https://cyberasp.domain.com:888`

`https://192.168.1.1:888`

Logging In

When you first view 3DM in a browser, you must log in before you can view or change any information.

Two levels of access are provided:

- **User** can check the status of the controller, units, and drives attached to it.
 - **Administrator** can check status, configure, and maintain the equipment.
1. On the 3DM logon screen, select whether you are a **User** or **Administrator**.
 2. Enter the password and click **Login**.



Note

The default password for both User and Administrator is blank. Thus, leave the password field empty.

Working with the 3DM Screens

3DM's features are organized on a series of pages you view in your browser.

After you log in to 3DM, the Summary page shows a list of controllers installed in the computer at the URL specified.

Figure 5-1 3DM Main Screen

Operating system and version on the server.

Address of the system to which you are connected.

Menu bar

Messages area

List of controllers on this system

Time of last page refresh

Version of 3DM

ID	Model	Serial #	Firmware	Driver	Status
0	Geronimo/Apache	3ware Internal Use	FGXX 2.01.00.030	2.4.0.12	OK

The menu bar across the top of the screen gives you access to other pages in 3DM. You can move between pages by using the menu bar, or by clicking a link on the page.


The main area of the page provides summary or detail information about your 3ware RAID controller and the resources connected to it.

As you work in 3DM, the Messages area just below the menu bar displays information about the results of commands you have selected.

3DM Menus

The 3DM menu bar groups access to a number of 3DM pages on menus, and provides direct link access to others.

Figure 5-2 3DM Menu Bar



Status information is available from the **Information** menu. You can view controller, unit, and drive information for a particular controller.

The **Management** menu gives you access to tasks used for managing controller-level settings (background task rate, enabling of unit write cache, and policies that affect all units managed by the controller), tasks that can be scheduled (rebuild, verify, and self-test), and maintenance of individual units. Unit configuration can also be done through the **Management > Maintenance** page.

The **Alarms** page shows a list of alarms, including the specific alarm message, and the exact date and time it occurred.

The **3DM Settings** page lets you set preferences, including email notification for alarms, passwords, page refresh frequency, whether remote access is permitted, and the incoming port which 3DM will use for listening.

Help lets you access information about using 3DM, and provides access to an electronic copy of a user's manual.

Refreshing the Screen

You can refresh the data on the screen at any time by clicking **Refresh** in the menu bar. This causes 3DM to update the information shown with current information from the controller and associated drives.

Automatic refreshes can also be set. For details, see [“Setting the Frequency of Page Refreshes” on page 116](#).

3DM Screens and What They're Used For

3DM Page	Description
-----------------	-------------

Controller Summary Provides basic information the 3ware RAID controller in the miSAN-V-Series. To see this page, click **Summary** in the menu bar.

Controller Details Provides detailed information about the current controller.
To see this page, choose **Information > Controller Details** from the menu bar.

Unit Information Shows a list of the units on the current controller and provides summary information about each unit.

To see this page, choose **Information > Unit Information** from the menu bar or click an ID number on the Controller Summary.

Drive Information Shows a list of drives on the current controller and provides summary information about each drive.

To see this page, choose **Information > Drive Information** from the menu bar.

SMART Details About Shows the SMART data for a specific drive.

To see this page, click the Port # for a Drive at Specific Port drive on the Drive Information page.

Controller Settings Allows for viewing and changing settings that affect the units on the current controller.

To see this page, choose **Management > Controller Settings** from the menu bar.

Scheduling Allows for viewing and changing the schedule for tasks that affect all units on the current controller.

To see this page, choose **Management > Scheduling** from the menu bar.

Maintenance Allows for configuring new units and make changes to existing units.

To view this page, choose **Management > Maintenance** from the menu bar.

Alarms Shows a list of alarms, including the specific alarm message, and the exact date and time it occurred.

To view this page, click **Alarms** on the menu bar.

3DM Settings Allows for setting preferences, including email notification for alarms, passwords, page refresh frequency, whether remote access is permitted, and the incoming port that 3DM will use for listening.

To view this page, click **3DM Settings** on the menu bar.

Setting Up 3DM Preferences

The 3DM Settings page allows for defining preference settings that affect the overall operation of 3DM. Most of these settings are factory-set during installation of 3DM.

Setting and Changing 3DM Passwords

3DM provides different access levels for users and administrators. The Administrator access level allows the user to fully configure 3DM. The User access level allows the user to view pages within 3DM. These passwords work independently of each other.

The default password for both the User and Administrator is blank (i.e., the field is empty).

Passwords are case sensitive.

Passwords can only be changed if logged in as Administrator. If the Administrator password is changed, you will be automatically logged out, and must log back in with the new password.

To set or change the password:

1. Click 3DM Settings on the 3DM menu bar.
2. On the 3DM Settings page, in the Password section, select the type of password you want to change: User or Administrator.
3. Type the current password in the Current Password field. If you are changing the password for the first time, the factory-set default password is blank; leave the Current Password field empty.
4. Enter the new password in the New Password field and again in the Confirm New Password field.
5. Click the **Change Password** button to enact the change.

Managing E-mail Event Notification

3DM can notify you when the 3ware RAID controller requires attention, such as when a disk unit becomes degraded and is no longer fault tolerant.

Event notification can only occur while 3DM is running, so it is recommended that 3DM be left running on the system that contains the 3ware RAID controller.

When events occur, notification can be e-mailed to one or more recipients. You can specify the type of events for which notifications will be sent by selecting the severity:

- Information will send e-mails for all alarms
- Warning will send e-mail for alarms with severity of Warning and Error only.
- Error will send e-mail for alarms with severity of Error only.

Event notification is initially set up during 3DM installation, but can be changed on the 3DM Settings page.

To set up event notification:

1. Click **3DM Settings** on the menu bar.

2. In the E-mail notification section of the 3DM Settings page, enter or change the settings you want.
 - Enable or Disable all notifications
 - Set the severity level of events for which e-mail notifications are sent
 - Specify the email address of the sender. This will appear in the “From” field of the e-mail.
 - Enter the e-mail address(es) to which notifications are sent. (Separate multiple addresses with a comma (,) or a semicolon (;)
 - Enter the SMTP server name or IP of your mail server.
 - Click **Save E-mail Settings**

To send a test message:

You can send a test message to make sure you’ve entered the e-mail notification settings correctly. Click **Send Test Message**.

Caution About Disabling Remote Access



Caution

Do not disable Remote Access. If Remote Access is disabled, it will be impossible to access the 3DM web browser interface. If remote access must be enabled again, contact Cybernetics Technical Support. If remote access is disabled and a user attempts to connect to 3DM remotely, they will see the following error message: *Remote Access to 3DM has been disabled. Please connect using the local machine by entering “localhost” in the URL bar.*

Caution About Changing Incoming Port



Caution

Do not change the Incoming Port # from the default 888. If the Incoming Port # default is changed from 888, the Web Control Panel will not be able to open 3DM using the Manage disk storage option. (See “Disk Storage” on page 67).

Setting the Frequency of Page Refreshes

Since the status of the drives attached to your 3ware RAID controller can change while you are viewing information about them in 3DM, it’s important to refresh the page information regularly. That way you can be assured that the information you see in 3DM is current.

You can manually refresh the information on a page by clicking Refresh Page in the menu bar. But you can also have 3DM refresh the information on a regular basis.

To set the frequency of page refreshes:

1. Click **3DM Settings** on the menu bar.
2. In the **Page Refresh** section of the 3DM Settings page, select how often you want you want the page to be refreshed in the Minutes Between Refresh field.

**Note**

If you don't want 3DM to refresh the screen automatically, select **Never** in the Minutes Between Refresh field. You can then refresh manually by clicking **Refresh** on your web browser.

3DM2 Reference


This section includes details about the fields and features available on the pages you work with throughout 3DM 2.

It is organized by page, as the pages are organized on the 3DM menu bar.

- Controller Summary Page
- Controller Details Page
- Unit Information Page
- Unit Details Page
- Drive Information Page
- SMART Details About Drive at Particular Port Page
- Controller Settings Page
- Scheduling Page
- Maintenance Page
- Alarms Page
- 3DM Settings Page

Controller Summary Page

Figure 5-3 Controller Summary Page




The Summary page appears after you first logon to 3DM, and when you click the Summary link in the menu bar.

The Summary page provides basic information about each 3ware RAID controller in your system. To see details about the units in a controller, click the link in the ID column.

- **ID:** The ID that the operating system assigns to the controller.
- **Model:** The model name of the controller. (The model number is also printed on a sticker on the outside bracket of the controller.)
- **Serial #:** The serial number of the controller. (The serial number is also printed on a sticker on the outside bracket of the controller.)
- **Firmware:** The firmware version running on the controller.
- **Driver:** The driver version being used to interact with the controller.
- **Status:** The overall status of the controller. Possible statuses include OK, Warning, Error, and No Units. Warning indicates that a background task is currently being performed (rebuilding, verifying, or initializing). Error indicates that a unit is degraded or inoperable. If both Error and Warning conditions exist, the status will appear as Error.

Controller Details Page

Figure 5-4 Controller Details Page



The Controller Details page appears when you choose **Information > Controller Details** from the menu bar.


The Controller Details page provides detailed information about the controller specified in the drop-down list on the menu bar.

You can also open or download an error log from this screen.

- **Model:** The model name of the controller.
- **Serial #:** The serial number of the controller.
- **Firmware:** The firmware version running on the controller.
- **Driver:** The driver version being used to interact with the controller.
- **BIOS:** The BIOS version on the controller.
- **Boot Loader:** Boot Loader version on the controller. This field appears only for 9000-series controllers.
- **# of Units:** The number of units on the controller. **# of Ports:** The number of total ports on the controller, regardless of whether each currently has a drive connected.
- **# of Ports:** The number of total ports on the controller, regardless of whether each currently has a drive connected.
- **Error Log:** Provides access to the firmware's error log. When you click this link, a dialog box gives you the option to save the log to your computer, or open it.

Unit Information Page

Figure 5-5 Unit Information Page



The Unit Information page appears when you choose **Information > Unit Information** from the menu bar, and when you click an ID number on the Controller Summary page.

The Unit Information page shows a list of the units on the controller specified in the drop-down list on the menu bar and provides summary information about each unit.

To see details about a particular unit, click the link in the Unit # column.

- **Unit #:** The unit number assigned to the unit by the firmware.
- **Type:** The type of unit, specified during configuration: RAID 0, RAID 1, RAID 5, RAID 10, RAID 50, Single Disk, JBOD, or Spare. For details about each of the RAID levels, see [Appendix C, "Glossary"](#).
- **Capacity:** The logical capacity (size) of the unit.




Note

3DM 2 displays the capacity (in MBytes or GBytes) the same way that Microsoft Windows and Linux operating systems do: as 1KB = 1024 bytes.

- **Status:** The operational status of the unit: OK, Rebuilding, Initializing, Verifying, Degraded, or Inoperable (missing drives). When a unit is Rebuilding, Initializing, or Verifying, the percentage (%) complete is also shown.

Unit Details Page

Figure 5-6 Unit Details Page



The Unit Details page appears when you click an ID number on the Unit Information page. Since it is a sub-page of Unit Information, the page title in the menu bar continues to display “Unit Information” even when you view details of a unit. To return to the list of units, click Unit Information in the menu bar.

The Unit Details page shows details about a particular unit. The specific information shown depends on what type of unit it is. For example, details about a RAID 10 unit made up of two subunits, each of which contains two drives, will include details about the unit and each subunit. However, if the unit was a Single Disk, only information about one disk would be shown.

Details on this page may include all or some of the following information described below.

To see details about a particular drive, click the Port #. You’ll see a list of all drives, with the drive you selected highlighted.

- **Status:** The operational status of the unit or subunit: OK, Rebuilding, Initializing, Verifying, Degraded, or Inoperable (missing drives). When a unit is Rebuilding, Initializing, or Verifying, the percentage (%) complete is also shown.
- **Capacity:** The total capacity of the unit (capacities of subunits are not shown).
- **Type:** The type of unit or subunit it is. RAID 0, RAID 1, RAID 5, RAID 10, RAID 50, Single Disk, Spare, JBOD, or Disk
- **Stripe:** The stripe size of the unit, if applicable.

- **Subunits:** If the unit has subunits, details of the subunits are shown.
- **Port #:** If the Type is Disk, Single Disk, JBOD, or Spare, the port to which the drive is connected is shown. For multiple drive units, the port numbers are shown in the subunits section. The port number is a link to the Drive Information page.

Drive Information Page

Figure 5-7 Drive Information Page

3ware 3DM - Drive Information - Microsoft Internet Explorer

Address: https://192.168.2.143:888

3ware 3DM[®] 2 ALAINTEST (Microsoft Windows 2000 build 2195 Service Pack 4) ADMINISTRATOR logged in Logout

Summary Information Management Alarms 3DM Settings Help

Refresh Drive Information Select Controller Controller ID 0 (7566-12)

Drive Information (Controller ID 1)

Port #	Model	Capacity	Serial #	Firmware	Unit	Status
0	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1122267	65.13G65	0	OK
1	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1301223	65.13G65	0	OK
2	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1223541	65.13G65	0	OK
3	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1178992	65.13G65	--	OK
4	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1250890	65.13G65	--	OK
5	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1235933	65.13G65	--	OK
6	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1211822	65.13G65	--	OK
7	WDC WD1600BB-00DAA0	149.05 GB	WD-WMACK1231469	65.13G65	--	OK
8	NOT PRESENT	--	--	--	--	--
9	NOT PRESENT	--	--	--	--	--
10	NOT PRESENT	--	--	--	--	--

The Drive Information page appears when you choose **Information > Drive Information** from the menu bar, or when you click a port # on the Unit Details page. If you arrive at this page from the port # hyperlink on the Unit Information page, the line showing the port # you clicked on is highlighted.

The Drive Information page shows a list of drives on the controller specified in the drop-down list on the menu bar, and a summary of each one.

To see the SMART data for a drive, click the link in the Port # column.

- **Port #:** The port to which the drive is connected.
- **Model:** The model of the drive.
- **Capacity:** The physical capacity of the drive. (Note that the capacity as shown on 3DM screen is calculated as 1KB = 1024. This amount may differ from the capacity that is printed on the disk drive, where it typically has been calculated as 1K = 1000. Consequently, the capacity of the drive may appear smaller in the 3DM screens. No storage capacity is actually lost; the size has simply been calculated differently for consistency.
- **Serial #:** The serial number of the drive.

- **Firmware:** The firmware version of the drive.
- **Unit:** The unit the drive belongs to, if applicable.
- **Status:** The status of the drive: OK, Not Supported, Read Timeout, Read Failure, Orphan, DCB Data Check, Unsupp DCB, Unconv DCB, Offline JBOD, or Not Present. (In the event of a problem, the status shown for the drive can be useful to customer support.)




Note

In most cases, the status of the drive will not correspond to the status of the unit, shown on the Unit Information page.

SMART Details About Drive at Particular Port Page

Figure 5-8 S.M.A.R.T Data Page



The SMART Details page appears when you click a Port # on the Drive Information page.

SMART data is displayed as hex values.

Consult your disk drive manufacturer for information on how to interpret the SMART data. The SMART data meaning varies by disk drive manufacturer and model.

Controller Settings Page

Figure 5-9 Controller Settings Page

3ware 3DM2 - Controller Settings - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address <https://192.168.1.1:888/>

3ware 3DM2[®] User logged in Logout

Summary Information Management Monitor 3DM 2 Settings Help

Refresh Controller Settings Select Controller Controller ID 0 (9500S-8)

Background Task Rate (Controller ID 0)

Rebuild/Migrate Rate ☐ Faster Rebuild ☐ ☐ ☒ Faster I/O

Verify Rate ☐ Faster Verify ☐ ☐ ☒ Faster I/O

Unit Policies (Controller ID 0)

	Write Cache	Auto Verify	Continue on Source Error during Rebuild
Unit 0 [SINGLE DISK]	☐	☒	--
Unit 1 [SINGLE DISK]	☐	☒	--
Unit 2 [SINGLE DISK]	☐	☒	--
Unit 3 [SINGLE DISK]	☐	☒	--
Unit 4 [SINGLE DISK]	☐	☒	--
Unit 5 [SINGLE DISK]	☐	☒	--
Unit 6 [SINGLE DISK]	☐	☒	--
Unit 7 [SINGLE DISK]	☐	☒	--

Unit Names (Controller ID 0)

Unit 0 [SINGLE DISK]	
Unit 1 [SINGLE DISK]	
Unit 2 [SINGLE DISK]	
Unit 3 [SINGLE DISK]	
Unit 4 [SINGLE DISK]	
Unit 5 [SINGLE DISK]	
Unit 6 [SINGLE DISK]	
Unit 7 [SINGLE DISK]	

Save Names Reset Names

Other Controller Settings (Controller ID 0)

2TB Auto-Carving ☐ Enabled ☒ Disabled

Number of Drives per Spin-up 1

Delay between Spin-up 2 second(s)

Export Unconfigured Disk No

Disable Write Cache on Unit Degrade No

Last updated Fri, Apr 22, 2005 09:14:33AM
 This page will automatically refresh every 5 minute(s)
 3DM 2 version 2.03.00.025
 Copyright © 1997-2004 3ware, Inc. All rights reserved.

The Controller Settings page appears when you choose **Management > Controller Settings** from the menu bar.

The Controller Settings page lets you view and change settings that affect the units on the controller specified in the drop-down list on the menu bar.

Background Task Rate

The Background Task Rate fields let you change the balance of background tasks and I/O performed by the controller.

The 5 radio buttons let you set the ratio at which background tasks are performed in comparison to I/O. The furthest left buttons set the firmware to the fastest settings for background tasks settings. This means, maximum processing time will be given to background tasks rather than I/O. The furthest right buttons set the firmware to the slowest background rates, giving maximum processing time to I/O.

Unit Policies

You can enable or disable two policies: Auto-verify and Continue on Source Error During Rebuild. 3DM lists each unit on the controller specified in the drop-down list on the menu bar, and shows you whether the policies are currently enabled or disabled for each unit.

- **Write Cache:** You can enable or disable write cache for each unit. 3DM lists each unit on the controller specified in the drop-down list on the menu bar, and shows you whether the write cache is currently enabled or disabled for it. Write cache is a combination of the physical hard drives' write cache as well as the controller's memory, depending on what type of unit you are using.



Caution

Make sure Write Cache is enabled, and do not disable Write Cache for any units. If Write Cache is disabled, the write/read performance for the physical hard drives will be noticeably slower.

- **Auto-verify:** The Auto-verify policy causes verify tasks to be performed automatically, whenever the controller firmware algorithms determine that a verify task is needed. This feature is designed to make verification of units easier. When you check this box, the controller will run verify tasks as they are required.

If there is no schedule set up for verify tasks, then the controller firmware can initiate a verify task at any time. If a verify time window is scheduled, then the controller will not start a verify task for that unit outside the time window, and may or may not start a verify task for that unit within the time window, depending on whether one is needed.

If Auto-verify is not set and there is no schedule, you must manually specify when you want to run a verify, on the 3DM Management page.

- **Continue on Source Error During Rebuild:** This policy applies only to units which are redundant. (For units which are not redundant, a check box is not available.) When this policy is set, ECC errors are ignored when they are encountered during a rebuild. When this policy is not set, a rebuild will abort upon encountering an ECC error and the unit will be set back to Degraded.

Since this option could result in the loss of some source data in the event of source errors, select this option only if you want to ensure that a rebuild will complete successfully without manually intervention. If the rebuild fails and Continue on Source Error During Rebuild is not selected, then you have the option to start a rebuild

manually. It is recommended that a file system check be executed when the rebuild completes.

Unit Names


Units can be assigned names. A name can be assigned when the unit is created and can be changed from this screen.

Other Controller Settings

- **2TB Auto-Carving:** Auto-carving can be enabled or disabled by selecting the appropriate radio button. When this feature is enabled, any unit that is over 2TB will be broken down into multiple volumes of 2TB each, plus a remainder volume. For example, if the unit is 2.5 TB then it will contain two volumes, with the first volume containing 2TB and the second volume containing 0.5 TB. If the unit is 5.0 TB then it will contain 3 volumes, with the first two volumes containing 2TB each and the last volume containing 1TB.
- **Number of Drives Per Spin-up:** Number of drives that will spin up at the same time when the controller is powered up.
- **Delay between Spin-ups:** The delay between drive groups that spin up at one time on this particular controller.
- **Export JBOD (Unconfigured) Disks:** Indicates whether unconfigured disks (JBODs) should be exported to the operating system. By default, this setting is disabled and JBOD drives are not exported to the operating system.
- **Disable Write Cache on Unit Degrade:** Indicates whether write cache will be automatically disabled on a unit if it becomes degraded. After the unit is rebuilt, the write cache will be re-enabled automatically.

Scheduling Page

Figure 5-10 Scheduling Page



The Scheduling page appears when you choose **Management > Scheduling** from the menu bar.

The Scheduling page lets you view and change the schedule for background tasks that affect all units on the controller specified in the drop-down list on the menu bar, including:

- Rebuild tasks (also applies to initialization and migration tasks)
- Verify tasks (also applies to media scans)
- Self-tests

You select the type of task for which you want to set the schedule from the drop-down list at the top of the page.

You can also enable or disable use of the schedule for the selected background tasks by selecting either **Follow Schedule** or **Ignore Schedule**. When these schedules are set to be ignored, these tasks can be performed at any time, and are not restricted to the scheduled times.

About Task Schedules

Each type of task may be scheduled for up to seven times per week. This limits active initializing, rebuilding, verifying, and testing of a unit to the times you specify, so that the task does not interfere with peak I/O times.

If all seven schedule slots are filled, you must first remove one or more schedule times before you can add another.

You may set schedule times whether scheduling is set to be followed or ignored. This is useful if you want to temporarily disable the schedule.

If you remove all the schedule times for a particular background task, initializations and rebuilds will run anytime, as they are needed. Verify will only run if started by the CLI or if the Verify Unit button is clicked.

About Self-tests

Unlike scheduling of rebuilds and verifies, scheduling of self-tests is always followed. To disable self-tests you either remove all schedule times, or uncheck the tests listed in the Tasks column.

Two self-tests can be scheduled:

- **Upgrade UDMA mode:** This test checks the speed at which data transfer to drives is occurring, to see if the UDMA mode can be increased. (If you are already running at the fastest UDMA mode, then this self-test has no effect.)

The UDMA mode can become downgraded in the event that cable CRC errors are encountered, requiring multiple retries to read sectors. In severe cases, the UDMA mode may be downgraded from ATA 150 to ATA 133, to ATA 100, to 66, to 33.

This check is also done every time the system is booted. UDMA mode does not apply to SATA.

- **Check SMART Thresholds:** This test checks to see whether SMART thresholds have been exceeded.

The SMART thresholds indicate when a drive is likely to fail, based on the number of errors that have been recorded through SMART (Self-Monitoring, Analysis and Reporting Technology).

Maintenance Page

Figure 5-11 Maintenance Page

3ware 3DM[®] SERVER3 (Microsoft Windows 2000 build 2195 Service Pack 4) ADMINISTRATOR logged in Logout

Summary Information Management Alarms 3DM Settings Help

Refresh Maintenance Select Controller Controller ID 0 (7566-12)

Rescan Controller (This will scan all empty ports for newly inserted drives)

Unit Maintenance (Controller ID 0)

Unit	Drives	Configuration	Total Size	Status	Action
Unit 0	4 drives	RAID 10	298.10 GB	OK	
subunit 0 Port 0	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]	
subunit 0 Port 1	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]	
subunit 1 Port 2	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]	
subunit 1 Port 3	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]	
Unit 4	1 drive	SPARE	149.05 GB	OK	
Port 4	WDC WD1600BB-00DAA0	149.05 GB	OK		

Verify Unit Rebuild Unit Remove Unit Delete Unit

*Before deleting/removing a unit, make sure there is no I/O on the unit and unmount it

Available Drives (Controller ID 1)

Port	Model	Size	Status	Action
Port 5	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]
Port 6	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]
Port 7	WDC WD1600BB-00DAA0	149.05 GB	OK	[Remove Drive]

Create Unit

The Maintenance page appears when you choose **Management > Maintenance** from the menu bar. The Maintenance page lets you perform maintenance tasks on existing units on the current controller (shown in the drop-down list on the menu bar), and lets you create new units by configuring available drives.

Rescan Controller

Use the **Rescan Controller** button to have 3DM scan the available drives in the controller and update the list of available drives shown. This is useful in a variety of maintenance tasks. For example, if you physically plug in a drive and want the controller to recognize the newly plugged in drive.

Rescan checks empty ports for newly plugged in drives. If those drives were previously part of a 3ware RAID configuration and they still have valid DCB (Disk Configuration Block) information on them, the controller tries to piece them back together into a working unit. If a working unit can be formed, it will appear in the Unit Maintenance list when the scan is complete.

This process is known as importing drives. If new drives do not have any data indicating they were previously part of a 3ware RAID configuration, they will appear in the Available Drives list.

In addition, if there is a unit with the status Inoperable before a rescan (for example, a RAID 5 unit missing two or more drives), and a rescan finds drives that complete the unit, the inoperable unit will become a valid unit.

Unit Maintenance

The Unit Maintenance section of the page lists all existing units on the current controller, and displays summary information about them.

The top row shows information about the unit, while subsequent rows show summary information about each drive in the unit.

Unit Information

- **Unit Number:** The unit number assigned to the unit by the firmware.
- **# Drives:** Number of drives in the unit.
- **Type of Unit:** Type of unit specified during configuration: RAID 0, RAID 1, RAID 5, RAID 10, RAID 50, Single Disk, Spare, or JBOD.
- **Capacity:** The usable capacity (size) of the unit.
- **Status:** Operational status of the unit: Ok, Rebuilding, Initializing, Verifying, Degraded, or Inoperable (missing drives). When Rebuilding, Initializing, or Verifying, the percentage (%) complete is also shown. The % complete can be active or paused. To see whether this task is currently active or paused, click on the unit number to display the Unit Information page, which has that information.

Drive Information

- **Port:** The port to which the drive is connected.
- **Model:** The model of the drive.
- **Capacity:** The capacity (size) of the drive.
- **Status:** The status of the drive: OK, Not Supported, Not Present, and so forth. If you need help regarding a status displayed here, please contact Technical Support.
- **Remove Drive:** The Remove Drive link removes a drive from the controller so that you can safely unplug it. In the Unit Maintenance section, this link is only provided for drives that can be safely removed without creating an inoperable unit. (For example, a RAID 5 missing two or more drives or a RAID 0 missing one or more drives would become inoperable.) If you remove a drive from a redundant unit, the unit will become degraded. Once a unit has become degraded, additional drives cannot be removed without making it inoperable, so no Remove Drive link will display.



Caution

Removing or adding drives which are not in hotswap carriers can result in a system hang or may even damage the system and the drive.

Maintenance Task Buttons

Below the list of units, a row of task buttons lets you perform maintenance and configuration tasks related to the unit. Before clicking one of these buttons, select the appropriate unit:

- **Verify Unit:** Puts the selected unit in verifying mode. If verify scheduling is enabled on the Scheduling page, the unit will not start actively verifying until the scheduled time, and the status will indicate “Verify-Paused.” (The Unit Details page will indicate whether a unit is actively verifying.) If verify scheduling is not enabled, clicking **Verify Unit** begins the verification process.

If the unit you selected to verify is a redundant unit, the redundancy of the unit will be verified. For example it will check parity for a RAID 5 or check data consistency for a RAID 1. If the unit you checked is not a redundant unit, verify will do a surface scan of the media. During verification, I/O continues normally. For RAID 0, single disks, JBODs, and spares, there is only a slight performance loss. For redundant units, you can set the background task rate on the Controller Settings page to specify whether more processing time should be given to verifying or to I/O.

While a unit is verifying, the status changes to Verifying and a **Stop Verify** link appears in the right-most column of the Unit Maintenance table.

- **Rebuild Unit:** Replaces a degraded drive in a degraded unit with an available drive and begins rebuilding the RAID. When you select a degraded unit and click **Rebuild Unit**, a dialog box listing available drives appears, so that you can select the drive you want to use. If the degraded unit has more than one degraded drives (for example, a RAID 10 where both mirrored pairs each have a degraded drive), you will repeat this process a second time.

If rebuild scheduling is enabled on the Scheduling page, the unit will not start actively rebuilding until the scheduled time, and the status will change to say “Rebuild-Paused.” (The Unit Details page indicates whether a unit is actively rebuilding.) If rebuild scheduling is not enabled, the rebuild process will begin right away.

- **Remove Unit:** Removes a selected unit and allows you to unplug the drives and move the unit to another controller. the data on the unit remain intact.

When you click Remove Unit, you will be asked to confirm that you want to proceed. When you confirm the removal, the unit number and information will be removed from 3DM. (Units created in the future can reclaim this unit number.)

Information about the unit remains intact on the drives. This allows the drive or drives to be reassembled into a unit again on this controller, or if moved to another controller.

- **Delete Unit:** Deletes the selected unit and allows you to use the drives to create another unit. The drives appear in the list of Available Drives.



Caution

When a unit is deleted, the data will be permanently deleted: the drives cannot be reassembled into the same unit. If you want to reassemble the drives on another controller and access the existing data, use Remove Unit instead of Delete Unit.

Available Drives (to Create Units)

This section lists the drives on the controller which are not currently configured as part of a unit. The Port number, model, capacity, and status are all displayed, as they are for drives in existing units.

- **Remove Drive:** The Remove Drive link removes a drive from the controller so that you can safely unplug it. Any drive in the Available Drives list can be removed.



Caution

When a unit is deleted, the data will be permanently deleted: the drives cannot be reassembled into the same unit. If you want to reassemble the drives on another controller and access the existing data, use Remove Unit instead of Delete Unit.

- **Create Unit:** Use the **Create Unit** button to create a unit for use on the current controller. Begin by selecting the drives you want to use in the list of Available Drives, and then click **Create Unit**. You will be prompted to select the unit Type, Stripe size (if applicable), Write Cache, and Auto Verify settings.
- **Type:** The drop-down list lists the possible RAID configurations for the drives selected in the list of Available Drives. Available configurations may include RAID 0, RAID 1, RAID 5, RAID 10, RAID 50, Single Disk, and Spare Disk. For information about these configurations, see “Available RAID Configurations” on page 9.

When you are configuring a RAID 50 with twelve drives, an additional field appears, in which you select the number of drives per subunit—3, 4, or 6.

- **Stripe:** The drop-down list of stripe sizes lists the possible stripe sizes for the configuration you selected in the RAID level drop-down.

The default stripe size of 64KB will give the best performance with applications that have many sequential reads and writes. A larger stripe size will give better performance with applications that have a lot of random reads and writes. In general, the smaller the stripe size, the better the sequential I/O and the worse the random I/O. The larger the stripe size, the worse the sequential I/O and the better the random I/O.

Write Cache, Auto-Verify, and Continue on Source Error during Rebuild. These check boxes let you set the policies for the unit. These policies can also be set and changed on the Controller Settings page.



Note

If the configuration window disappears while you are selecting drives, 3DM 2 may have refreshed. Click Create Unit again. If desired, you can reduce the frequency with which information refreshes in 3DM 2, or disable refresh temporarily, on the 3DM Settings page.

Alarms Page

The Alarms page appears when you click Alarms on the menu bar.

This page displays a list of AENs (Asynchronous Event Notifications) received from the controller displayed in the drop-down list in the menu bar.

Up to 1000 alarms can be listed. After the 1000-limit is reached, the oldest alarms are deleted, as new ones occur.

You can sort the alarms by severity or time. To do so, just click the column header.

- **Clear Alarms:** The Clear Alarms button removes all alarms shown in the list.
- **Sev:** Shows the severity of the event. Three levels are provided:
 - Errors are shown next to a red box
 - Warnings are shown next to a yellow box
 - Information is shown next to a blue box
- **Time:** The time shown for alarms generated by 9000-series controllers is the time received by the driver from firmware.
- **Message:** The specific text relating to the alarm condition.

3DM Settings Page

Figure 5-12 3DM Settings Page

3ware 3DM - 3DM Settings - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back Forward Stop Search Favorites Media Print

Address <https://localhost:888/> Go Links

3ware 3DM[®] 2 AUTHORIZ-DLTX2W (Microsoft Windows 2000 build 2195 Service F) **ADMINISTRATOR** logged in Logout

Summary Information Management Alarms 3DM Settings Help

Refresh 3DM Settings

E-mail Notification

Send E-mail ☐ Enabled ☒ Disabled

Send Severity and Above

Sender

Recipient(s)

Server (name or IP)

Password

Change Password For

Current Password

New Password

Confirm New Password

Page Refresh

Minutes Between Refresh

Remote Access

Allow Remote Access ☒ Enabled ☐ Disabled

Incoming Port #

Listening Port

The 3DM Settings page appears when you click 3DM Settings on the menu bar. Use this page to set preferences, including email notification for alarms, passwords, page refresh frequency, whether remote access is permitted, and the incoming port for 3DM to listen for requests.

The initial settings for most of these preferences are specified during installation of 3DM.

E-mail Notification

Use the fields in this section to set up and manage notifications of events by e-mail.

- **Send E-mail:** This field determines whether e-mail notification is Enabled or Disabled.
- **Send Severity and Above:** Specifies the type of events for which notifications should be sent. A severity of Information will send e-mails for all alarms, a severity of Warning will send e-mail for alarms with severity of Warning and Error. A severity of Error will send e-mail for alarms with severity of Error.
- **Sender:** Enter the email address which will appear in the "From" field.
- **Recipient:** The e-mail address to which notifications should be sent. You can enter multiple addresses, separated by commas (,).
- **Server (name or IP):** If the machine on which you are running 3DM has access to a nameserver, you may enter the machine name of the mail server in the Server field. Otherwise, use the IP address.
- **Save E-mail Settings button:** Saves the e-mail notification settings.
- **Send Test Message button:** Sends a test message using the saved e-mail settings.

Password

Use the fields in this section to set the passwords for the User and Administrator. When 3DM is first installed, the default password for both is 3ware.

Change Password For: Select the access level for which you are setting the password: User or Administrator. Users can only view status information in 3DM, while Administrators can make changes and administer the controller and associated drives.

Current Password: Enter the current password.

New Password: Enter the new password.

Confirm New Password: Enter the new password a second time, to be sure you have entered it correctly.

Change Password button: Saves password changes.

Page Refresh

Minutes Between Refresh: Displays how frequently pages in 3DM will be refreshed with new data from the controller. To change this setting, select another option from the drop-down. If you prefer 3DM to only refresh when you click Refresh Page, select Never.

The Login, Help and Drive SMART data pages do not automatically refresh. All other 3DM pages do.

Remote Access



Caution

Do not disable Remote Access. If Remote Access is disabled, it will be impossible to access the 3DM web browser interface. If remote access must be enabled again, contact Cybernetics Technical Support (See Appendix D).

Allow Remote Connections: This field enables or disables the ability for users and administrators to access 3DM from a remote computer.

Incoming Port



Caution

Do not change the Incoming Port # from the default 888. If the Incoming Port # default is changed from 888, the Web Control Panel will not be able to open 3DM using the Manage disk storage option (See “Disk Storage” on page 67).

Listening Port: This field specifies the HTTP: port to be used by 3DM when listening for communications. The default port setting is 888.

Change Port button: Saves a new port number.

Configuring Units



Note

Keep in mind, the term “unit” and “array” are used interchangeably in this manual.

Creating a New Unit

When you create a new unit, you must specify the following:

- Drives to be included in the unit
- Type of configuration
- Stripe size, if appropriate for the RAID level

Drives to Be Included in the Unit

You may include from one to eight, depending on the number available. However, you may only include drives that are not already part of a unit. If you want to use drives that are currently part of a different unit, you must delete a unit first to make the drives available. If the drives are listed under “Incomplete Drives and Others,” they must be deleted

before they can be used. If you want to add drives to be used in the unit, see [“Adding a Drive” on page 138](#).

Type of RAID Configuration

Available configuration types include RAID 0, RAID 1, RAID 5, RAID 10, RAID 50 and Single Disk. For information about the different RAID levels [Appendix C, “Glossary”](#).



Note

Creating a unit erases all data on all drives. Although creating a RAID 1 (mirror) creates a unit that will have a duplicate of data on both drives after it is put in use, creating a RAID 1 cannot be used to make a backup copy of data that currently exists on a single drive.

In general, smaller stripe sizes are better for sequential I/O such as video and larger strip sizes are better for random I/O (such as databases).

Striping size is not applicable for RAID 1, because it is a mirrored array without striping.

Using the default stripe size of 64KB usually gives you the best performance for mixed I/Os. If your application has some specific I/O pattern (purely sequential or purely random), you might want to experiment with smaller or larger stripe size.

1. In 3DM, choose **Management > Maintenance**.
2. In the “Available Drives” list, select the drives you want to include in the unit by marking the checkbox in front of the Port number for each one.

If you are creating single drive units, (single disks or hot spares), you can configure multiple drives at once.

3. Click **Create Unit**.
4. In the dialog box that appears, select the RAID configuration you want.
5. If stripe size applies to the RAID type you select, select a Stripe Size.
6. Click **OK**.

The new unit will appear in the Unit Maintenance list at the top of the page and the miSAN-V-Series will be notified of the new unit.

Rebuilding a Unit

When a drive on a unit degrades, you replace it with an available drive and then rebuild the unit.

1. If necessary, add a new drive to be used to replace the failed drive. (For details, see [“Adding a Drive” on page 138](#).)
2. In 3DM, choose **Management > Maintenance**.
3. In the Unit Maintenance section, select the degraded unit and click **Rebuild Unit**.
4. When a dialog box displays available drives, select the drive you want to replace the degraded drive with, and click **OK**.

Configuring Drives

Creating a Hot Spare

You can designate an available drive as a hot spare. If a unit degrades and a hot spare the size of the degraded disk (or larger) is available, the hot spare will dynamically replace the failed drive in the unit without user intervention. When this occurs, an event notification is generated and appears in the list of alarms in 3DM.

It's a good idea to select a hot spare after you create a redundant unit. In order to replace a failed drive, a hot spare must have the same or larger storage capacity than the drives it is replacing.

To specify a hot spare after the system is booted:

1. In the **Available Drives** section of the **Maintenance** page, select the drive by checking the box next to it.
2. Click **Create Unit**.
3. In the dialog box that appears, select the configuration type **Spare**.
4. Click **OK**. You will see the spare appear at the top of the page, under Unit Maintenance.

Adding a Drive

If you have a hot-swap carrier, you can add a drive to your system and make it available through 3DM without powering down the system.

To add a drive through 3DM when you have hot-swap carriers:

1. Connect the drive physically to the controller.
2. In 3DM, choose **Management > Maintenance**.
3. Click **Rescan Controller**.

The drive will appear in the list of available drives. You can now use it in a new RAID configuration, or as a replacement drive in the event that another drive degrades.

4. If you want to use this drive as a spare, see "Creating a Hot Spare" above.

Removing a Drive

If you have a hot-swap carrier and want to physically remove a drive from your system without powering it down, you must first remove it through the 3ware software.

This is useful if you know that a drive is developing a problem and you want to replace it, or to replace a drive which has already failed.



Caution

If you unplug a drive without first removing it through 3DM, Rescan will not recognize it as gone. Always use the Remove Drive command to remove a drive before unplugging it.

1. In 3DM, choose **Management > Maintenance**.

Remove Drive links appear next to all drives that can be removed from units, and next to drives in the Available Drives list.

2. Locate the drive you want to remove and click the **Remove Drive** link.
(You can remove a drive that is part of a unit, or that is shown in the list of Available Drives.)

Figure 5-13 Removing a Drive in 3DM

3ware 3DM[®]2 Administrator logged in Logout

Summary Information Management Monitor 3DM 2 Settings Help

Refresh Maintenance Select Controller Controller ID 1 (9500S-8)

Rescan Controller (This will scan all empty ports for newly inserted drives/units)

Unit Maintenance (Controller ID 1)

Unit	Drives	RAID	Capacity	Status	Action
Unit 0	4 drives	RAID 5	1.09 TB	OK	
	Port 0	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 1	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 2	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 3	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
Unit 1	4 drives	RAID 5	1.09 TB	OK	
	Port 4	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 5	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 6	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]
	Port 7	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]

Verify Unit Rebuild Unit Remove Unit Delete Unit

*Before removing or deleting a unit, make sure there is no I/O on the unit and unmount it

Available Drives (Controller ID 1)

NO DRIVES

Create Unit

Last updated Thu, Dec 16, 2004 11:22:52AM

3. When 3DM asks you to confirm that you want to remove the drive, click **OK**.

You can now remove the drive from your system. If you removed a drive that was part of a unit, the unit may become degraded.

Figure 5-14 Result of Removing Drive from Unit in 3DM


Administrator logged in [Logout](#)

[Summary](#)
[Information](#)
[Management](#)
[Monitor](#)
[3DM 2 Settings](#)
[Help](#)

[Refresh](#)
[Maintenance](#)
[Select Controller](#)
Controller ID 1 (9500S-8)

[Rescan Controller](#) (This will scan all empty ports for newly inserted drives/units)

Unit Maintenance (Controller ID 1)

Unit 0	4 drives	RAID 5	1.09 TB	OK	
Port 0	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Port 1	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Port 2	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Port 3	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Unit 1	4 drives	RAID 5	1.09 TB	DEGRADED	
--	--	--	DRIVE NOT PRESENT		
Port 5	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Port 6	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	
Port 7	HDS724040KLSA80	372.61 GB	OK	[Remove Drive]	

[Verify Unit](#)
[Rebuild Unit](#)
[Remove Unit](#)
[Delete Unit](#)

*Before removing or deleting a unit, make sure there is no I/O on the unit and unmount it

Available Drives (Controller ID 1)

NO DRIVES

[Create Unit](#)

Last updated Thu, Dec 16, 2004 11:22:52AM
This page will automatically refresh every 5 minute(s)
3DM 2 version 2.02.00.015
Copyright © 1997-2004 3ware, Inc. All rights reserved.

Chapter 6

Packing and Shipping Instructions

This chapter provides instructions for transporting the miSAN-V-Series or returning the miSAN-V-Series to Cybernetics for service or repair. The packing and shipping process involves first removing the miSAN-V-Series from the place where it is installed, enclosing the unit in an anti-static bag, and then placing the miSAN-V-Series in the packing materials.



Caution

Failure to properly prepare the miSAN-V-Series for shipping can result in shipping damage. Any damage to the miSAN incurred during transport as a result of improper packaging will void the warranty. Cybernetics' warranty does not cover shipping damage.

Removing the miSAN-V-Series from its Installation Environment

1. Make any attached SCSI devices (disk arrays, tape drives or libraries) ready for removal from the SCSI bus, in accordance with the user manual for those devices.
2. Power down the miSAN-V-Series. Disconnect all cables (network, upstream and downstream SCSI, power). Remove SCSI terminator(s) if installed.
3. If the miSAN-V-Series is rack-mounted, remove it from the rack, and remove the slides from the sides of the unit. This will require a No. 2 Phillips screwdriver.
4. If the unit is a miSAN-V-Series-AIT, remove the dust cover from the removable tape drive

Using the Proper Packing Materials

You must use the original packing materials that came with the miSAN-V-Series from Cybernetics. Replacement packing materials can be purchased by contacting Cybernetics' Technical Support at (757) 833-9200.



Note

Styrofoam pellets or “peanuts” are not adequate for packing, since they may shift and allow the miSAN-V-Series to move about in the shipping box. Wadded newspaper, computer printouts, and such are not adequate for the same reason.

- Cybernetics box for the accessories and two filler boxes for spacing.




- Anti-static bag for the chassis



- Two cardboard and clear plastic shells.

(Front)



- Cybernetics box
- Packing Tape




To prepare the chassis for shipping, complete the following steps:

1. Enclose the unit in an anti-static bag to prevent ESD damage.




2. Place the Cybernetics box on a level surface.
3. Place one of the cardboard shells (identified in “Using the Proper Packing Materials” on page 142) plastic-side up at the bottom of the Cybernetics box. Make sure it is settled in properly..



4. Place the chassis on the cardboard shell so it is centered on the plastic..



5. Place the second cardboard shell on top of the chassis.



6. Open the accessory box, place the accessories inside (e.g., cables, terminators, and AC power cord), if requested by Cybernetics, and close the box.
7. Place the two filler boxes on top of the cardboard shell.



8. Place the accessory box on top of the cardboard shell and if you are returning the rackmount kit, place it next to the accessory box as shown in the bottom right picture..



9. The figure below illustrates the previous steps.



10. Tape the box shut, and place the shipping label on the box.
11. If the box is being shipped to Cybernetics, make sure the Return Authorization Number (RAN) received from Cybernetics Customer Support is prominently displayed on the outside of the box.
12. Since the box contains delicate electronic components, it should be shipped fully insured via an airfreight carrier.

Chapter 7

Product Specifications

Supported iSCSI Initiators

Microsoft iSCSI Initiator 2.0 or higher

Windows XP/2000/2003 Server

Go to <http://www.microsoft.com/downloads/details.aspx?FamilyID=12cb3c1a-15d6-4585-b385-befd1319f825&displaylang=en>

Cisco iSCSI Driver 3.x

Sun Solaris 7/8/9

Go to <http://www.cisco.com/univercd/cc/td/doc/product/sn5000/sn5400/iscsidrv/index.htm>

Sun Solaris 10

Go to <http://www.sunsolve.sun.com/search/document.do?assetkey=1-21-119090-20-1>

QLogic SANblade iSCSI HBA QLA4010C

Windows 2000/2003 Server, Sun Solaris SPARC, Linux (32-bit and 64-bit)

Go to http://www.qlogic.com/support/product_resources.asp?id=341

Protocols and Standards

CHAP (RFC 1334)

IP (RFC 791, 894, 1092)

iSCSI (IETF draft version 20; RFC 3720)

SCSI-2 and SCSI-3

TCP (RFC 793)

Drive Interface Compatibility

Serial ATA (1.5 Gigabits/sec.)

Ethernet Interfaces

Management LAN Port (ETH0)

10/100/1000Base-T (1 Gigabit/sec.) TCP/IP

RJ-45 connector

iSCSI Network Ports (ETH1, ETH2)

10/100/1000Base-T (1 Gigabit/sec.) TCP/IP
RJ-45 connector

SCSI Parallel Interfaces

Low Voltage Differential (LVD)

VHDCI 68-pin, female socket
Ultra3 (Ultra160) Wide SCSI
Maximum synchronous data transfer rate of 160 megabytes/sec.
Auto-selectable between LVD and Single-Ended (SE) mode

Physical Dimensions

Height	3.5 in. (8.9 cm) (2U)
Width, chassis	16.9 in. (42.9 cm), front panel 18.9 in. (48.0 cm)
Depth	26.4 in. (67.1 cm)
Weight	48.8 lbs. (22.1 kg), with 6 disk drives

Power Supply

Power supply input voltage is auto-sensing:

Voltage	100–240 VAC, 47–63 Hz, 8–4 A
Consumption	460 W maximum, each power supply

	Watts	Amps	Volts	Volt Amps
BTU/HR				
Idle	216.5 W	1.81 A	118.75 V	215.39 VA
740.62				
Typical Activity	249.0 W	2.09 A	118.0 V	246.33 VA
851.65				

Humidity and Temperature

Non-operating

Humidity	10–90%, non-condensing
Temperature	-40–140°F (-40–60°C)

Operating

Humidity	20–80%, non-condensing
Temperature	50–104°F (10–40°C)

Appendix A

Microsoft® iSCSI Initiator Software Client

Host systems running Microsoft® Windows® 2000, XP or 2003 can access Cybernetics iSCSI devices using the Microsoft iSCSI Initiator software. The following sections provide detailed steps for downloading and running the setup program and installing and configuring the driver. The following information is subject to change by Microsoft. The screen shots that follow may be different than what will show on your computer, depending on what software you are running, and whether you are updating or newly installing the Microsoft® iSCSI Initiator Client.

Downloading the Setup Program

The iSCSI Initiator setup program can be downloaded from the Microsoft Web site by doing the following:

1. Go to the Web site <http://www.microsoft.com/downloads>
2. Type *Microsoft iSCSI Software Initiator* in the “Keywords” box, and then click **Go**.



3. Click the link for the latest version of the driver that appears. As of 05/26/2006 the latest version is 2.02 and can also be found by clicking the following link:

<http://www.microsoft.com/downloads/details.aspx?FamilyID=12cb3c1a-15d6-4585-b385-befd1319f825&DisplayLang=en>


4. Scroll down to the “Files in this Download” section, and then click the applicable “fre” link for a 32-bit (“x86”) or 64-bit (“ia64”) system.

Files in This Download

The links in this section correspond to separate files available in this download. Download the files most appropriate for you.

File Name:	File Size	
Initiator-2.02-QFE-bld1895-amd64fre.exe	1.6 MB	Download
Initiator-2.02-QFE-bld1895-ia64fre.exe	2.2 MB	Download
Initiator-2.02-QFE-bld1895-x86fre.exe	1.4 MB	Download
relnotes.txt	5 KB	Download
uguide.doc	874 KB	Download


5. Click **Save** in the “File Download” dialog box.



Note

It is also recommended that you download and study the release notes and user guide. They are shown above as relnotes.txt and uguide.doc

6. Choose a location for the file in the **Save As** dialog box, and then click **Save**. The file is then saved to the specified location.



Installing the Software

To install and set up the iSCSI Initiator software, complete the following steps:




Note


The information presented here is provided as a courtesy only and may not reflect the current software version provided by Microsoft.

1. To install the driver, first, double-click the “.msi” file to run the setup program. The Setup Wizard will then execute.


2. Click **Next** to continue.



3. Read the license agreement in the "License Agreement" window, select "I agree," and then click **Next**.




4. Choose a location to install the driver files in the “Select Installation Folder” window, and then click **Next** to continue.



Note

The ability to select a location for the installation of the Microsoft iSCSI Initiator is only available for new installations. If you are upgrading to a newer version of the initiator, the options will be different than shown here.

5. Click **Next** to continue in the “Confirm Installation” window.




The Microsoft iSCSI Installation Program will execute once the setup files have been copied.



6. Choose to “Install Complete iSCSI Initiator,” and then click **OK**.


Configuring the iSCSI Initiator

The iSCSI Initiator Properties window is used for configuring the driver and can be accessed by launching the “iSCSI Initiator” from the Windows Control Panel.




Changing initiator node name

The initiator is automatically assigned a unique name during the installation process. Make a note of the “initiator node name,” which can be used by Cybernetics iSCSI devices for assigning control of storage resources. This name is displayed on the “General” tab and can be changed if a target has not yet been assigned to it. To change the name, click the “Change” button and type in the new name..




Adding Target Devices

1. Select the “Discovery” tab to allow for adding target devices.



2. Click **Add...** in the Target Portals area to enter the IP address or DNS name and socket number for an iSCSI target device.



3. Clicking **Advanced...** allows access to security settings, such as CHAP authentication, which is supported by Cybernetics iSCSI devices. The CHAP password must be between 12 and 16 characters.

Figure A-1 Advanced Settings

The image shows a Windows-style dialog box titled "Advanced Settings" with a question mark icon and a close button. It has two tabs: "General" and "IPSec", with "IPSec" currently selected. The dialog is divided into several sections. The first section, "Connect by using", contains three dropdown menus: "Local adapter:" (set to "Default"), "Source IP:" (set to "Default"), and "Target Portal:". The second section, "CRC / Checksum", contains two checkboxes: "Data digest" and "Header digest", both of which are unchecked. The third section, "CHAP logon information", is preceded by a checked checkbox. It contains a text box for "User name:" with the value "iqn.1991-05.com.microsoft:rattlesnake" and a text box for "Target secret:" filled with asterisks. Below this is a checkbox for "Perform mutual authentication", which is unchecked. A descriptive paragraph explains that CHAP helps ensure data security by providing authentication between a target and an initiator, and that for mutual authentication, an initiator secret must be configured on the Initiator Settings page and the target secret on the target. At the bottom of the dialog are three buttons: "OK", "Cancel", and "Apply".

Advanced Settings

General | IPSec

Connect by using

Local adapter: Default

Source IP: Default

Target Portal:

CRC / Checksum

☐ Data digest ☐ Header digest

☒ CHAP logon information

CHAP helps ensure data security by providing authentication between a target and an initiator trying to establish a connection. To use it specify the same target CHAP secret that was configured on the target for this initiator.

User name: iqn.1991-05.com.microsoft:rattlesnake


Target secret: xxxxxxxxxxxx

☐ Perform mutual authentication


To use mutual CHAP specify an initiator secret on the Initiator Settings page and configure that secret on the target.

OK Cancel Apply

Select the “Targets” tab to view the iSCSI targets discovered through the added target portals. To log onto an iSCSI target, select it from the list, and then click **Log On...**




4. Select the option to “Automatically restore this connection when the system boots” to make a target persistent, so the iSCSI Initiator will attempt to reconnect to it each time the computer is rebooted. Click **OK** to log onto the target.



5. If you added a CHAP password in step 3, you will need to click on “Advanced...”. This will bring up the menu shown in Advanced Settings. Enter the Target secret and press “OK”. This will bring up the Log on to Target screen. Press “OK” to Log on.

After the target has been logged onto, it will show as “Connected” on the “Available Targets” tab.



6. Repeat this process to add additional target portals as desired.

Creating System Dependencies

Using iSCSI Disk Devices with the iSCSI Initiator


When using an iSCSI disk device to create file shares (e.g., for network storage, backup copies, e-mail), the iSCSI Initiator service needs to start before the Server service, which creates file shares. This is because the Server service cannot create file shares for iSCSI disk devices until the iSCSI Initiator service is initialized. If the services are not started in the proper order, the file shares located on the iSCSI disk device may not be re-created when you restart the iSCSI host computer that the shares are created on.

To start the services in the proper order, you can use system dependencies to make one service start before another.

The following instructions explain how to set up the dependencies:

1. Run the Windows Registry Editor by opening `regedt32.exe` using **Start > Run...**
2. Go to `HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services`

3. Select `lanmanserver` in the folder tree.




4. Select **Edit > Add value...** from the menu bar

5. Enter the **Value Name** `DependOnService`

6. Select `REG_MULTI_SZ` for the **Data Type**

7. Click **OK**

8. Make the value `DependOnService` set to the iSCSI Initiator service `MSiSCSI`.



9. After you are finished editing the registry, be sure to restart the computer to make sure the settings will take effect.


Using Backup Software with the iSCSI Initiator

When using backup software with the Microsoft® iSCSI Initiator, the iSCSI Initiator service needs to start before the backup software services. This ensures the backup software will be able to detect the SCSI devices that the iSCSI Initiator logs into. This requires starting the services in a specific sequence.

To do this, you can use system dependencies to make one service start before another. By setting up the correct dependencies, you can create a chain reaction and thus start the services in the correct sequence.


The following instructions explain how to set up the dependencies for a backup product:

1. Run the Windows Registry Editor by opening `regedt32.exe` using **Start > Run...**
2. Go to `HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services`
3. Make sure each backup software service has a `DependOnService` value. If the `DependOnService` value does not exist for the service, you must create it:



- A Select the service in the folder tree.
 - B Select **Edit > Add value...** from the menu bar
 - C Enter the **Value Name** `DependOnService`
 - D Select `REG_MULTI_SZ` for the **Data Type**
 - E Click **OK**
4. Make the value `DependOnService` set to the names of services you want started before the service itself starts. For backup software services, make sure to include the iSCSI

Initiator service `MSiSCSI` and the Workstation network and connection service `LanmanWorkstation`.



5. After you are finished editing the registry, be sure to restart the computer to make sure the settings will take effect.

Logging Off




Caution

It is necessary to log off the iSCSI connections before shutting down a target in order to avoid possible data loss. Failure to log off the iSCSI connections will cause Microsoft Windows to send “Unsafe Device Removal” messages.


If it becomes necessary to shut down the miSAN-V-Series use the following steps to log off the iSCSI connections between the host and the miSAN-V-Series.

1. Open the “Targets” Tab in iSCSI Initiator Properties.

2. Highlight one of the targets and press "Details"



3. Click "Log off".
4. Repeat the process for each target on the machine you are shutting down.



Appendix B

Linux iSCSI Initiator

Introduction

There are many variations of Linux available. Your installation and configuration of Linux may be different than those mentioned later in this Appendix. Cybernetics takes no responsibility for any of the code recommendations or content of the links provided.

Before starting, determine the kernel version being used by typing **uname -r**

The project page for Linux iSCSI is: <http://linux-iscsi.sourceforge.net/>

The linux-iscsi driver began as an open source version of the Cisco iSCSI Initiator. Much of the configuration of the 3.xx (for Linux Kernel 2.4) and 4.xx (for Linux Kernel 2.6) drivers is the same as it is for the Cisco driver on other platforms such as Solaris.

As of the 5.xx series, the linux-iscsi project is merging with the [Open-iSCSI](#) project. The merged driver is still hosted on the linux-iscsi Sourceforge page with a parallel versioning system on the [Open-iSCSI webpage](#). As of now, this version is still experimental. Since it is drastically different, it will not be covered in this appendix.

Installation

In all cases, you should get the latest packaged version of linux-iscsi from the Linux distro's package manager if a packaged version exists.

Linux Kernel 2.6 Notes

Version 4.02 only supports up to Linux kernel 2.6.9.

According to the linux-iscsi developers, you should use Open-iSCSI for lk 2.6.11 and higher for now. There are no production releases of the Open-iSCSI driver yet though.

As an alternative, the Core-iSCSI project revived an earlier iSCSI initiator effort. It claims to be the only production-level iSCSI initiator for > lk 2.6.9.

The Core-iSCSI project provides an iSCSI Initiator kernel driver for Linux along with a separate package with user-land management utilities.

Since the linux-iscsi project has moved back into the development phase due to its merger with Open-iSCSI in the 5.xx series, there were no production Linux iSCSI initiator implementations available for lk 2.6.10 and up. Core-iSCSI was revived to fill this gap until linux-iscsi/Open-iSCSI matures. The developers hope to make the user-land man-

agement utilities pluggable with the kernel portion of Open-iSCSI or any future initiator du-jour.

Core-iSCSI is based on GPLed portions of the commercial PyX Initiator from PyX Technologies (now owned by SBE, Inc.) The current maintainer is an employee of SBE, Inc.

The project does not have a web page. It has an active discussion board at <http://groups.google.com/group/core-iscsi>

core-iscsi Initiator: <http://www.kernel.org/pub/linux/kernel/people/nab/iscsi-initiator-core/>

core-iscsi-tools: <http://www.kernel.org/pub/linux/utils/storage/iscsi/>

Core-iSCSI Setup

The configuration file is `/etc/sysconfig/initiator`, and the syntax is different from `linux-iscsi's /etc/iscsi.conf`. For an iTape/HSTC, you need a line like:

```
CHANNEL="0 1 eth0 192.168.1.1 3260 0 HeaderDigest=None;DataDigest=None"
```

Replace `eth0` with the name of the network interface you are using for iSCSI. The parameters `"HeaderDigest=None;DataDigest=None"` are optional but increase performance by turning off CRC checksums.

To login/logout, use:

```
/etc/init.d/initiator start
```

```
/etc/init.d/initiator stop
```

To login to multiple iSCSI targets at the same IP address (e.g. a HSTC with two virtual devices), use something like the following in `/etc/sysconfig/initiator`:

```
CHANNEL="0 1 eth0 192.168.1.1 3260 0 HeaderDigest=None;DataDigest=None none  
eui.000b560000004a41"
```

```
CHANNEL="1 1 eth0 192.168.1.1 3260 0 HeaderDigest=None;DataDigest=None none  
eui.000b560000004a42"
```

In this example, `"eui.000b560000004a41"` and `"eui.000b560000004a42"` are the iSCSI target names from an example HSTC. You need to substitute the actual target names from the device you are using. You may get the iSCSI target names from a ASP, HSTC, or miSAN-VX in the Information menu under "Local iSCSI Target List". Alternately, you may leave off the target name initially, login, logout, get the target name list from `"dmesg | grep 'Discovered iSCSI Target'"`, edit the config file with the names, then log back in.

Debian lk 2.6

This applies for all Debian-based distros (Debian, Ubuntu, Knoppix, etc) with kernel 2.6.

There is no `linux-iscsi` package available via `apt`. You will need to compile from source. First, resolve the dependencies if needed:

```
apt-get install libsysfs-dev
```

```
apt-get install udev
```

Red Hat 9 & Enterprise Linux 3

To install an RPM:

Go to <http://sourceforge.net/projects/linux-iscsi> and download the latest Production RPM for your distro version.

Install from the RPM - run ``rpm -i rpmfile``

SuSE Linux Pro 9.1

The package name is linux-iscsi (version 4.0.1-83). This initiator works with cy-iscsi products (hstc, misan, itape). However, you must edit `/etc/init.d/iscsi` to point to the proper location for the kernel driver. If you do not edit this file, the attempt to start iscsi will hang. Edit `/etc/init.d/iscsi` as follows:

Find the line (in most cases line 207) that has the following:

```
EM=/lib/modules/"uname -r"/misc/iscsi.ko
```

Change it to `EM=/lib/modules/"uname -r"/extra/iscsi.ko`

Source Compilation

To install from source:

Go to <http://sourceforge.net/projects/linux-iscsi> and download the Production source file for your kernel version. You will probably want to make a directory such as `/usr/src/iscsi` to download to.

Read the README file and make sure that all dependencies are resolved.

Extract the source folder. ``gunzip`` the file and then ``tar -xvf`` the unzipped file

Change to the folder and run ``make`` to build the driver.

Then run ``make install`` to build the installation script and start the installation.

Setup

Edit the iSCSI configuration file at `/etc/iscsi.conf` using your favorite file editor. You will add the remote iSCSI target IP address (iTape, HSTC, etc) as a `DiscoveryAddress` (example: `DiscoveryAddress=192.168.1.1`). Save the file.

Stop & restart the iSCSI service. Change to the `/etc/init.d` directory and run ``./iscsi stop`` followed by ``./iscsi start``

Test the setup

Confirm that the OS sees the tape device(s). ``cat /proc/scsi/scsi`` will list all attached SCSI devices (including iSCSI).

You should now have a device called "st0". Run ``mt -f /dev/st0 status`` to confirm this. If there are multiple remote iSCSI target tape drives, check the status of each (st1, st2, etc).

Also, try a tar to write & read to the drive. ``tar -cvf /dev/st0 /somedir`` will backup the "somedir" directory. ``tar -tvf /dev/st0`` will display the file listing on the drive. ``tar -xvf /dev/st0 /somedir`` will restore to the "somedir" directory.

Appendix C

Glossary

The following list of terms and definitions are used in the preceding chapters and should be read and understood by administrators of the miSAN-V-Series.

3DM – 3ware Disk Manager 2 (3DM®) is a web-based interface used for viewing the status of and managing the 3ware® Escalade® 9500S-8 SATA RAID controller and associated disk drives remotely.

Array – One or more disk drives that appear to the operating system as a single unit. Within 3ware software (3BM and 3DM) arrays are typically referred to as units.

Auto-archive – A feature used for automatically copying virtual tapes to physical tapes after a backup to the virtual tapes. Auto-archive allows for automating the process of creating and maintaining tape cartridge duplicates of virtual tape backups.

Autoload – A feature used for automatically changing the virtual tape for a virtual tape drive. When enabled, the miSAN-V-Series will mount the next virtual tape listed in the “Mounted medium” listbox when a host issues an “eject” command.

Barcode label – A label affixed to a tape cartridge that shows a barcode.

Basic disk – A physical disk drive containing basic volumes, such as primary partitions and logical drives.

CAT 5/5e/6 – Ethernet cable standards defined by the Electronic Industries Association and Telecommunications Industry Association (EIA/TIA).

- **CAT 5** is the 5th generation of twisted pair Ethernet cabling and the most popular of all twisted pair cables in use today. CAT 5 usually contains four pairs of copper wire, although Fast Ethernet communications only utilize two pairs.
- **CAT 5 enhanced (5e)** supports short-run Gigabit Ethernet (1000 Mbps) networking by utilizing all four wire pairs and is backward-compatible with ordinary CAT 5.
- **CAT 6** cable contains four pairs of copper wire and unlike CAT 5, utilizes all four pairs. CAT 6 supports Gigabit Ethernet (1000 Mbps) and supports communications at more than twice the speed of CAT 5e, the other popular standard for Gigabit Ethernet cabling.

CHAP – “Challenge-Handshake Authentication Protocol” (CHAP) is a scheme that uses a 3-way “handshake” (peer-response-authenticator) to periodically verify the identity of the peer (iSCSI host initiator). Authentication begins after a network link is established and the authenticator (iSCSI target; iSAN Vault) sends a “challenge” message to the peer. The peer responds with a calculated value that embeds a “secret” (user password). The authenticator checks the response value against its own expectation. If the value matches, the peer is then authenticated (logged on to the iSAN Vault).

Compression – Compression reduces the amount of storage space required to store a given amount of data. The miSAN-V-Series is incapable of compressing data while writing to virtual tapes. Data compression is only performed by a physical tape drive when the miSAN-V-Series writes to physical tape. The “Drive compression for copying” menu option toggles internal tape drive data compression for all attached tape devices.

Copy Profile – Copy profiles allow the user to define and save relationships between virtual tapes and physical tapes slotted inside the physical stacker. For example, the first virtual tape will always be copied to the first physical tape, the second virtual tape to the second physical tape, the third virtual tape to the third physical tape and so forth. Using copy profiles saves from manually having to select virtual tapes to copy each time “Offload disk to tapes” is enabled.

D2D2T – Disk-to-Disk-to-Tape (D2D2T) is an approach to computer backup and archiving in which data is initially copied to a disk storage device and then periodically copied again to a tape storage device (or to an optical disc drive).

Daisy-chaining – Connecting multiple devices one to another in a series.

Distributed Parity – Parity works in combination with striping on RAID 5 and RAID 50. Parity information is written to each of the striped drives, in rotation. Should a failure occur, the data on the failed drive can be reconstructed from the data on the other drives.

ECC – Error-Correcting Code (ECC) is integrated into many tape drives for the purpose of reconstructing data bits missing from the tape as a result of tape quality degradation. The number of ECC occurrences since the last tape rewind is calculated as a percentage. In general, error rates are the highest at the beginning of a tape since this part of the tape is written to every time the tape unloads.

Host I/O – The HSTC’s disk drive input and output (disk I/O) resources used by hosts for backup and restore jobs. Both host I/O resources and job I/O resources draw from the same disk I/O resources. Thus, one impacts the other’s performance. You can use the “Host vs. job I/O policy” setting to determine the priority of host I/O relative to job I/O.

Hot Swap – The process of swapping out a drive without having to shut down the system. This is useful when you need to swap out a degraded drive, manually or automatically, with a pre-designated spare.

HSTC – High Speed Tape Cache (HSTC) is a software engine that emulates conventional tape drives and tape cartridges. Host applications use HSTC virtual tapes and drives as conventional backup resources.

iSCSI – Internet SCSI (iSCSI) is a method of transmitting SCSI commands, data and status across Ethernet-based standard TCP/IP networks. This allows SCSI devices and SCSI-aware software (e.g., backup applications) to communicate remotely via existing networks.

iSCSI Initiator – A device that begins an iSCSI transaction by issuing a command to another device (the iSCSI target) to perform a task. Typically an iSCSI host bus adapter is the initiator, but targets may also become initiators, such as when the miSAN-V-Series is configured to use remote iSCSI devices.

iSCSI Target – An iSCSI device that executes a command given by an iSCSI initiator to perform a task. The miSAN-V-Series is the target for an iSCSI host initiator.

Fault Tolerance – The ability of a system or component to continue normal operation despite a hardware or software failure. This often involves some degree of redundancy. For disk drives, complete redundancy is “Mirroring”, where every write operation is performed on two or more disk drives, so if one fails the other can take over.

JBOD – “Just a Bunch of Disks” (JBOD) is an acronym that refers to disk drives that have not been configured in a RAID array (See “RAID”). With JBOD, each drive is either operated independently or drives may be seen as a single drive by combining the drives into one larger logical disk. JBOD does not provide RAID aggregation, fault tolerance or redundancy.

Job I/O – The HSTC’s disk drive input and output (disk I/O) resources used for the HSTC’s jobs (e.g., offloading disk to tape). Both job I/O resources and host I/O resources draw from the same disk I/O resources. Thus, one impacts the other’s performance. You can use the “Host vs. job I/O policy” setting to determine the priority of host I/O relative to job I/O.

Logical Disk – A number of areas on one or more disk drives that the computer system considers as one filesystem. The areas of disk space are not necessarily contiguous but are presented to the computer system as a single disk drive. In disk arrays, drives are presented as individual logical disks (See “JBOD”) or are configured by a RAID controller as logical disks spanning multiple disks (See “RAID”).

LVD – Low Voltage Differential (LVD) uses less power than the HVD bus, is less expensive and allows the higher speeds of Ultra 2/3 SCSI. LVD terminators run on 3.3 Volts DC.

Media changer – A mechanical device within a tape library that moves tapes to an internal tape drive. A media changer allows the library to load tapes sequentially into a tape drive during a write/read operation requiring multiple tapes. The media changer device usually has its own SCSI ID and resides on LUN 0 of that ID.

MTU

Maximum Transmission Unit (MTU) is the maximum packet size, in bytes, that can be transmitted across a link. Changing the default packet size from an MTU size of 1,500 to 9,000 (also called a “jumbo” packet) can significantly increase performance depending upon the activity. For this to be effective, however, each point in the network must be configured to support jumbo packets. If much of the network is dedicated to 10/100 Mbps Ethernet, the MTU packet size ought to be set to 1,500 to minimize layer-two fragmentation and reassembly.

Optical Ethernet – Ethernet consisting of optical fiber cabling. The miSAN-V-Series Optical Fiber interface requires a dual mode optical fiber cable having an SC duplex connector.

Optical Disc – An optical disc is an electronic data storage medium that can be written to and read using a low-powered laser beam (e.g., CD-R/W, Blu-ray, ProData).

Optical Disc Drive – For the miSAN-V-Series, a SCSI drive that records data on an optical disc.

Physical Device – A physical tape drive or physical tape library. This is the miSAN-V-Series

“back-end” as seen by the miSAN-V-Series. These devices are installed (internal), attached (SCSI) or connected (iSCSI) to the miSAN-V-Series and are used for offloading disk to tapes.

Physical Stacker – A physical tape library (these terms are used interchangeably). If the miSAN-V-Series is not configured with optional Tape Library Control support, an external tape library will appear to the miSAN-V-Series as a standalone tape drive. With optional Tape Library Control support, the miSAN-V-Series can use an external tape library drive and its slotted tapes.

Physical Tape – A data tape cartridge.

Physical Tape Drive – An installed (internal), attached (SCSI) or connected (iSCSI) tape drive.

Physical Tape Library – An attached (SCSI) or connected (iSCSI) tape library. If the miSAN-V-Series is not configured with optional Tape Library Control support, an external tape library will appear to the miSAN-V-Series as a standalone tape drive. With optional Tape Library Control support, the miSAN-V-Series can use an external tape library drive and its slotted tapes.

RAID – “Redundant Array of Independent Disks” (RAID) is a grouping of disk drives (an array) combined in such a way as to provide fault tolerance and increased write/read performance. Several disk grouping methods exist, called RAID levels, which are configured by a disk array controller in the storage enclosure. Most storage enclosures implement the RAID levels described below. Configuring the RAID storage enclosure for the appropriate use will make the most effective use of disk storage resources and provide the correct level of fault tolerance.

RAID 0 – This is the most basic implementation of the Striping technique. However, because this type of array has no inherent fault tolerance (i.e., redundancy), RAID 0 is not true RAID unless it is used in conjunction with other RAID levels (e.g., RAID 10 and RAID 50).

RAID 0 arrays can provide high write performance relative to true RAID levels because there is none of the overhead associated with parity calculations or other data recovery techniques. This same lack of provision for rebuilding lost data means RAID 0 arrays should be restricted to storage of noncritical data and combined with a strict backup program.

In a RAID 0 array, which requires a minimum of two disks to be installed, storage capacity for each disk is determined by the smallest disk in the array. For example, an array with a 100, 250 and 150 Gigabyte drive will show a total storage capacity of 300 Gigabytes (100 Gigabytes $\times$ 3).

RAID 0 is recommended for use with large, non-critical file applications, such as multimedia and scientific computing.

RAID 1 – This is the simplest form of a fault-tolerant array. Based on the concept of mirroring, this array consists of multiple sets of data stored on two or more drives. Although many RAID 1 implementations involve two sets of data (hence the term mirror), three or more sets can be created if increased reliability is desired.

In a RAID 1 array, storage capacity is determined by the smaller of the two disks in the array. This provides maximum fault tolerance with complete redundancy but minimum data storage capacity, since a host system sees only the capacity of a single disk drive. Writing the same data to the two disks in the array results in poor write speeds, but RAID 1 yields high performance for read-intensive operations.

If a drive failure occurs in a RAID 1 array, subsequent read and write operations are directed to the surviving drive(s). A replacement drive is then rebuilt using data from the surviving drive. This rebuilding process has some impact on the array's I/O performance because all data must be read and copied from the surviving drive(s) to the replacement drive.

RAID 1 offers high data availability, because at least two complete sets of data are stored. Connecting the primary drives and mirrored drives to separate drive controllers can further enhance fault tolerance by eliminating the controller as a single point of failure.

RAID 1 has the highest storage cost of any non-hybrid RAID level, because it requires sufficient drive capacity to store at least two complete sets of data.

RAID 1 arrays are recommended and better suited for small databases or other small-scale systems that emphasize reliability, such as in accounting or finance.

RAID 10 – This RAID level, originally called RAID 1+0, is implemented as a striped array (RAID 0) whose segments are RAID 1 arrays. RAID 10 requires a minimum of four disks installed and is basically several RAID 1 drives linked together with RAID 0. This yields the speed benefits of RAID 0 with the redundancy benefits of RAID 1. The high I/O rates are achieved by striping RAID 1 segments. This provides better transfer rate speeds than RAID 1 alone, especially with write speeds, but not as high as pure RAID 0. This is recommended for database servers requiring high performance and fault tolerance.

RAID 5 – This widely used RAID type overcomes some of the drawbacks of other parity-based arrays. In essence, RAID 5 allows for parity information for the array's data to be distributed among all drives in the array, a minimum of three, instead of being stored on a dedicated parity drive.

This distribution parity approach reduces the write bottleneck common to other RAID levels, because concurrent writes do not always require access to parity information on a dedicated drive. However, overall write performance still suffers because of the overhead cause by reading, recalculation and updating parity information.

To improve the read performance of an RAID 5 array, the data stripe size can be optimized for the particular application program using the array. Overall RAID 5 array performance is equivalent to that of a RAID 3 array except in the case of sequential reads, which reduce the efficiency of the drives' read-ahead algorithms because of the distributed parity information.

As in other parity-based arrays, data recovery in a RAID 5 array is accomplished by computing the XOR of information on the array's remaining drives. Since parity information is distributed among all the drives, loss of any drive reduces the availability of both data and

parity information until the failed drive is regenerated. This can cause degradation in application program performance for both reads and writes.

This is the most versatile RAID level, and thus recommended for application, database, and file servers, and also ideal for email, news and WWW servers.

RAID 50 – This RAID level is a combination of RAID 5 and RAID 0, and requires a minimum of six disks installed, in order to provide striping to RAID 5 subarrays. This provides better transfer rate speeds than RAID 5 alone, especially with write speeds, but not as high as pure RAID 0. RAID 50 is recommended for critical small file applications requiring higher transfer speeds.

RAID 5 + Hot Spare – The RAID 5 + Hot Spare configuration is a RAID 5 array with a dedicated “Hot Spare” drive.

In essence, the RAID 5 array operates as described previously, however, there is an additional Hot Spare drive that is set up as a standby drive for use as a global spare (i.e., immediately available for use by any RAID 5 array). The Hot Spare drive sits idle awaiting a failure in the RAID 5 array. In the event of a failure, the Hot Spare drive will take over for the failed drive automatically and the RAID 5 array will not suffer performance degradation.

The Hot Spare drive configuration is recommended for a critical RAID 5 array where a drive failure in the array should not cause downtime.

SCSI Cable – For use with the miSAN-V-Series, a shielded cable having a VHDCI 68-pin male connector for an LVD bus or an HD 68-pin male connector for an HVD bus.

SCSI Terminator – A device attached to the end-points of a bus network or [daisy-chain](#). The purpose of the terminator is to absorb signals so that they do not reflect back down the line.

Striping – A data storage technique used in most RAID levels. Striping is a method of mapping data across the physical drives in an array to create a large logical drive. The data is subdivided equally into consecutive segments, or “stripes,” that are written sequentially across the drives in the array. Each stripe has a defined size or depth in blocks.

A striped array of drives can offer improved write/read performance compared to an individual drive if the stripe size is matched to the type of application program supported by the array:

- In an I/O-intensive or transactional environment where multiple concurrent requests for small data records occur, larger (block-level) stripes are preferable. If a stripe on an individual drive is large enough to contain an entire record, the drives in the array can respond independently to these simultaneous data requests.
- In a data-intensive environment where large data records are stored, smaller (byte-level) stripes are more appropriate. If a given data record extends across several drives in the array, the contents of the record can be read in parallel, improving the overall data transfer rate.

System Policy – The policy specified by the “Host vs. job I/O policy” setting, which determines the priority of host I/O relative to job I/O.

TCP/IP – The suite of communications protocols used to connect hosts on the Internet.

Unit – A logical unit of storage, which the operating system treats as a single drive. A unit may consist of a single drive or several drives. Also known as an array.

Virtual Device – A virtual tape drive or virtual stacker. This is the miSAN-V-Series “front-end” as seen by iSCSI host initiators. Virtual devices appear to host computers as directly attached SCSI devices. Thus, backup hosts must handle all the pros and cons thereof (e.g., drivers, device configuration, media rotation, etc.).

Virtual Stacker – An emulated tape library recognized by iSCSI host initiators as having a SCSI media changer.

Virtual Tape – An emulated tape cartridge, which allows for storing volume tag information as if a barcode label had been applied. This is the backup media used by the virtual devices.

Virtual Tape Drive – An emulated tape drive recognized by iSCSI host initiators as a SCSI tape drive.

Volume Tag – The information used to physically identify a tape cartridge, such as is presented by a barcode label on a tape cartridge. Notice, the volume tag will appear as a barcode label in the backup software.

Appendix D

Common Questions

The following text explains possible answers and solutions to common miSAN-V-Series questions and problems. If a solution to the problem you are experiencing is not found below, contact Cybernetics Technical Support (See [Appendix E, “Technical Support”](#)).

Question: *What is the proper order for powering on all devices?*

Answer:

1. Power on all tape drives and libraries first. Wait for all devices to finish their Power On Self-Test (POST).
2. Power on the miSAN-V-Series. Wait for the miSAN-V-Series to respond to a ping command.
3. Power on any iClients. Wait for the iClients to respond to a ping command.
4. Power on any servers that will directly access the miSAN-V-Series.

Question: *What are the default IP addresses for the miSAN-V-Series?*

Answer:

ETH0 - IP: **192.168.1.1**, subnet mask: **255.255.255.0**

ETH1 - IP: **192.168.2.1**, subnet mask: **255.255.255.0**

ETH2 - IP: **192.168.3.1**, subnet mask: **255.255.255.0**

Problem: *The tape cartridges in my attached tape library have barcode labels. How do I copy the label information to the virtual tapes?*

Note: The miSAN-V-Series will only be able to query for barcode information if the external library reports barcodes (i.e., the library has a barcode reader).

Solution: From the Web Control Panel, select “HSTC Options” > “Configuration” > “Copy volume tags” > **Enabled**. Enabling this option causes the virtual tape volume tag to be automatically updated with the barcode label information after a virtual tape is written to a physical tape cartridge (See [“Copy volume tags” on page 52](#)). Then, to transfer all the barcode labels to virtual tapes, select the physical stacker from the “Devices” tab, and then click

Offload disk to tapes. The **Offload disk to tapes** window is used for assigning virtual tapes to physical tapes to be used in making the copy (See [“Offload disk to tapes...” on page 86](#)). This process will overwrite all data on the physical tapes with the data on the

virtual tapes. As explained earlier, the barcode labels will also be copied from physical tape to virtual tape.

Problem: *The miSAN-V-Series will not respond to a ping command.*

Solution:

1. Make sure the miSAN-V-Series is powered on and fully initialized.
2. Make sure you are using a known good CAT 5e or 6 networking cable.
3. Confirm the IP address of the machine you are attempting to ping the miSAN-V-Series from is on the same subnet as the miSAN-V-Series.

Problem: *The miSAN-V-Series does not detect a physical tape device that is directly attached to the miSAN-V-Series.*

Solution:

1. Verify the physical devices are powered on and have passed their Power On Self-Test (POST).
2. Confirm the physical tape devices are securely connected to the SCSI ports labeled "DRIVE" on the rear panel of the miSAN-V-Series.

Note: Ports labeled "HOST" are configured for a direct-host connection and cannot be used for a SCSI device. If the other port is labeled "Reserved", then your miSAN-V-Series is not meant to connect directly to an external physical tape drive.

3. Check all cabling for damage and replace if necessary.
4. "Rescan physical devices" from the Web Control Panel (See ["Rescan SCSI buses" on page 103](#)).
5. Save the Debug Log, accessible from the Web Control Panel: "Browser Links" > "View debug messages", and then contact Technical Support (See ["Technical Support" on page 179](#)).

Problem: *The miSAN-V-Series does not detect any physical tape devices connected via iSCSI.*

Solution:

1. Verify you can successfully ping the IP address of the iSCSI physical tape devices. If not successful, troubleshoot the network connections for both the miSAN-V-Series and the iSCSI device.
2. Verify the "Remote iSCSI Devices" settings for the iSCSI devices are properly configured (See ["Remote iSCSI Devices" on page 91](#)).
3. Verify the "Device Visibility" settings for the iSCSI devices are properly configured (See ["Device Visibility" on page 98](#)).
4. Select "Tools" > "Rescan physical devices..." from the Web Control Panel (See ["Rescan SCSI buses" on page 103](#)).

Problem: *The miSAN-V-Series does not show any or all of the virtual tapes.*

Solution:

1. Verify you have previously created the virtual tapes (See ["Create Virtual Tapes" on page 38](#)).

2. Confirm you have assigned the created virtual tapes to the desired virtual devices from the Web Control Panel: “Tools” > “Assign virtual tapes...”.
3. Capture a Debug Log from “Browser Links”, and then contact Cybernetics Technical Support (See [“Browser links” on page 70](#))

Problem: *The Web Control Panel appears as a blank gray box. (The Java applet failed to load.)*

Solution:

1. Clear the Web browser cache.
2. Download and install the latest version of the Java™ web browser plug-in from the Sun Microsystems Java website at <http://www.java.com>.

Problem: *The Web Control Panel displays a “Lost communication” box, saying “The unit is not responding.”*

Solution: Telnet to the miSAN-V-Series, and then login as `menu`. If the “Offline Maintenance” menu appears, try exiting the menu to bring the miSAN-V-Series back online, which effectively restarts the unit. While restarting the miSAN-V-Series, read the startup messages, and if the unit goes back to the “Offline Maintenance” menu, act accordingly to fix the problem: for a SCSI bus problem, inspect the SCSI bus cabling. Else, if the problem persists, contact Technical Support for assistance (See [Appendix E, “Technical Support”](#)).

Problem: *One of the internal disk drives seems to have gone bad.*

Solution: Log in to the 3ware Disk Manager 2 to see the status of the drive (See [“Drive Information Page” on page 122](#)). If the disk drive is bad, follow instructions for removing the drive in [“Removing a Drive” on page 138](#) and then instructions for adding a drive in [“Adding a Drive” on page 138](#). A good way to test the disk drive once it is removed from the miSAN-V-Series is to install it in a PC and run a low-level (long) format. If the format completes successfully, then the problem may be elsewhere. If the format fails, as explained in [“Product Warranty Statement” on page vi](#), contact Cybernetics Technical Support (See [Appendix E, “Technical Support”](#)) to initiate a service request. Customers can opt to send the hard drive to Cybernetics to coordinate the service request through the manufacturer or obtain service directly from the manufacturer.

Problem: *The speeds on the miSAN-V-Series are slower than expected.*

Solution: There are several possible causes for slower than expected speeds. Some of the most common:

1. Slower than expected speeds to the miSAN-V-Series (i.e., writing/reading virtual tapes)
 - a. Network Attached
 - Make sure that *ALL* the networking hardware is capable of and connecting at 1000Base-T (1000 megabits per second).

Note: If the data travels through a single medium that is slower than 1000Base-T (e.g., 100Base-T), then the data will travel at the slower speed throughout all the network.
 - Make the data path as simple as possible, such that the number of network hops is reduced if possible. Implement a dedicated 1000Base-T SAN (subnetwork) for the miSAN-V-Series and connected data sources.

- If using a managed network switch, verify the miSAN-V-Series is synchronizing at 1000Base-T. If not, change the networking hardware.
 - Directly connect the miSAN-V-Series to the backup server.
 - Disable all virus scanning software on the backup server and the data source machines.
- b. SCSI Attached
- Isolate the miSAN-V-Series as the only device on the SCSI bus.
 - Check the SCSI cable for any bent or damaged pins/connectors.
 - Verify you are using an Ultra 3 Wide SCSI (Ultra 160) or better SCSI HBA and that the miSAN-V-Series is synchronizing at 160 MB/sec.
 - Verify that the manufacturer's drivers are loaded for the SCSI HBA.
 - Disable all virus scanning software on the backup server and the data source machines.
2. Slower than expected speeds *from the miSAN-V-Series* (copying virtual to physical tape).
- a. Make sure "Drive compression for copying" is enabled before copying from virtual to physical tape (See ["Drive compression for copying" on page 52](#)). Selecting this feature enables the built-in data compression (if available) for the physical tape drive.
 - b. Check the SCSI cable for any bent or damaged pins/connectors.
 - c. Clean the tape drive, and then retry normal operation with a new, never-before-used tape cartridge.

Appendix E

Return Policies

Shipping Damage

You must immediately inspect your new Cybernetics equipment and notify Cybernetics and the freight carrier within 2 business days of receipt, if the item arrives damaged. Cybernetics cannot be responsible for shipping damage that is not immediately reported

Hardware Products

At Cybernetics, we take customer satisfaction very seriously, and we value our relationship with every customer. We go to great lengths to understand every aspect of your requirements before we quote a solution, and we work closely with customers to make sure the solution you receive will meet your expectations. Accordingly, our products are backed by a 30-day functionality guarantee. If you experience any technical issues, please contact our Technical Support group (see “Technical Support and Repair Procedures” appendix) for free telephone support within 30 days of receipt of your order. If we determine that the hardware is incompatible, and fails to function in your environment, we will issue a RAN (Return Authorization Number) for the equipment. Upon receipt of the equipment in new condition, we will issue a credit or refund for the purchase price paid, less shipping and handling. If the equipment is returned for any reason other than an approved functionality issue, a 15% restocking fee will apply. In all cases, the hardware must be returned via prepaid air freight.

To qualify as eligible for return (with or without restocking fee), the transaction must meet the following requirements:

- The product was purchased directly from Cybernetics
- The product was originally shipped within the past 30 days
- The customer made a good faith effort to cooperate with Cybernetics’ Technical Support for troubleshooting
- Cybernetics has issued a RAN for the product
- The product is returned via an airfreight carrier
- The product arrives in undamaged, like new condition within 5 days of RAN issue date

Software Products

Software is not eligible for return.

Tape Media Products

Unopened tapes are eligible for return within 14 days of the original shipment date. Opened tapes are not eligible for return.

Promotional Items

If a promotional item was provided as the result of a hardware purchase, the promotional item must also be returned in like new condition in the event a return is approved for the qualifying hardware purchase. Media Club promotional items are not eligible for return.

Maintenance Contracts

Extended service contracts and upgraded maintenance service fees are not eligible for refund. Cybernetics may, at its own discretion, prorate and transfer any remaining service period to a new hardware purchase.

Exceptions to Cybernetics' 30-day Hardware Return Policy:

- Special order products and accessories are not eligible for return
- Custom built products and configurations are not eligible for return

Return Procedure

To return products, you must first contact Cybernetics Technical Support or Customer Service at (757) 833-9200 to request a Return Authorization Number (RAN) within the return policy period applicable to the product you want to return. A refund or credit will not be issued unless accompanied by a valid RAN.



Note

For a return, you must ship the product(s) to Cybernetics within five (5) days of the date the RAN was issued.

You must:

1. **All** products returned to Cybernetics must be packed in the original shipping containers. If the original shipping containers were discarded, you can purchase replacements through Customer Service or Technical Sales.
2. Return the products properly prepared for shipment, and in their original packaging material, in new condition along with any media, documentation, and all other items that

were included in the original shipment. For more information about preparing the equipment for shipping, please see your product manual.

3. Ship the product(s) at your expense, and and fully insured, via an airfreight carrier to the following address:

Cybernetics (RAN XX-XXXX)
111 Cybernetics Way
Yorktown, VA 23693



Warning

The customer accepts full responsibility for any and all products that are lost or damaged in transit when shipped without insurance or with insufficient insurance.



Note

Before you ship the product(s) to us, make sure to back up the data on the hard drive(s) and any other storage device(s) in the product(s). Remove any confidential, proprietary or personal information, removable media, such as floppy disks, CDs, or PC Cards. We are not responsible for any of your confidential, proprietary or personal information; lost or corrupted data; or damaged or lost removable media.

Upon receipt of the complete, undamaged and like new returned purchase, Cybernetics will issue a credit, replacement, or refund of the purchase price paid, less shipping, handling and applicable restocking fees.

Appendix F

Technical Support

If problems occur during installation or operation of the miSAN-V-Series, contact our Technical Support staff at (757) 833-9200 with the following information available:

- Your company name, ZIP code, and phone number
- The 8-digit serial number, located on the rear of the device case and on the Product Documentation CD
- The following information about your system and problem:
 - System Configuration
 - SCSI Daisy-Chaining/Termination Configuration
 - Drive-Switch Settings
 - Computer System Type
 - Operating System and Version Number
 - Backup Procedure and Software
 - Error Behavior
 - System Errors and Messages
 - Drive Errors and Messages

This information may instead be faxed to (757) 833-9300 or emailed to techsupport@cybernetics.com.

Send to "Attention: Technical Support."

Appendix G

Cybernetics miSAN-V-Series

Notices

Notices

Copyright

© 2006 Cybernetics, Inc. All rights reserved. This manual and the information contained herein are the property of Cybernetics. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means - electronic, mechanical, magnetic, optical, chemical, manual, or otherwise - without prior written permission of Cybernetics, 111 Cybernetics Way, Yorktown, VA 23693.

Chapter 4 "Using 3ware Disk Manager" contains portions excerpted from the AMCC Storage User Guide for the 3ware Serial ATA RAID Controller that supports the 9000 series (PN 720-0114-01, March 2005) available online at <http://www.3ware.com/support/UserDocs/3ware9000UsrGuide.pdf>.

Warranty

Cybernetics makes no representation or warranties with respect to the contents of this document and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, Cybernetics reserves the right to revise this publication and to make changes in it from time to time without obligation to notify any person or organization of such revision or changes.

Trademarks

CY-HSTC, CY-miSAN-V-Series, High Speed Tape Cache and miSAN are trademarks or registered trademarks of Cybernetics.

3BM, 3DM, 3ware and Escalade are all trademarks or registered trademarks of 3ware, Inc.

Java, Java Runtime Environment, Java Virtual Machine and the Java Coffee Cup logo are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries, and refer to Sun's Java programming language and browser technologies. This user manual is not sponsored by or affiliated with Sun Microsystems, Inc.

Other names and products are trademarks or registered trademarks of their respective holders.

FCC Notice

This equipment was tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Shielded cables are required for this device to comply with FCC regulations. Use shielded cables when connecting this device to others.

CSA Notice

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe A prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

English translation: This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications.

GNU GPL Notice

A portion of the software contained in this Cybernetics product is used under the GNU General Public License. The GPL is published by the Free Software Foundation at <http://www.gnu.org/copyleft/gpl.html>. The source code for the software used under that license is available from Cybernetics. A full copy of the GNU General Public License is included with the source code.

Apache Software License

This product includes software developed by the Apache Software Foundation (<http://www.apache.org/>).

The full license for the Apache software is included below:

Apache License
Version 2.0, January 2004
<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

“License” shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

“Licensor” shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

“Legal Entity” shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, “control” means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or

more of the outstanding shares, or (iii) beneficial ownership of such entity.

“You” (or “Your”) shall mean an individual or Legal Entity exercising permissions granted by this License.

“Source” form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

“Object” form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

“Work” shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

“Derivative Works” shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship.

For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

“Contribution” shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or

Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or

Legal Entity authorized to submit on behalf of the copyright owner.

For the purposes of this definition, “submitted” means any form of electronic, verbal, or written communication sent to the Licensor or its

representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue

tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding

communication that is conspicuously marked or otherwise designated in writing by the copyright owner as “Not a Contribution.”

“Contributor” shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge,

royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without

modifications, and in Source or Object form, provided that You meet the following conditions:

(a) You must give any other recipients of the Work or Derivative Works a copy of this License; and

(b) You must cause any modified files to carry prominent notices stating that You changed the files; and

(c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices

from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and

(d) If the Work includes a “NOTICE” text file as part of its distribution, then any Derivative Works that You distribute must include a readable

copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the

Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the

Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if

and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not

modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum

to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions

for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use,

reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to

the Licensors shall be under the terms and conditions of this License, without any additional terms or conditions.

Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.

6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.

7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an “AS IS” BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.

8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

gSOAP Software License

Part of the software embedded in this product is gSOAP software.

Portions created by gSOAP are Copyright © 2001-2004 Robert A. van Engelen, Genivia inc. All Rights Reserved. The full license for the gSOAP software is included below:

THE SOFTWARE IN THIS PRODUCT WAS IN PART PROVIDED BY GENIVIA INC AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS

INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Product Warranty Statement

The miSAN-V-Series is warranted to be free from defects in materials, parts and workmanship and will conform to the current product specification upon delivery. For specific details of your warranty, contact Cybernetics.

The warranty for the miSAN-V-Series shall not apply to failures of any unit when any of the following occur:

- the miSAN-V-Series is repaired by anyone other than Cybernetics or authorized service personnel
- the miSAN-V-Series is physically abused or is used in a manner inconsistent with the operating instructions or product specifications defined by Cybernetics
- the miSAN-V-Series fails because of abuse, accident, acts of God, alteration, excessive dirt/dust buildup, faulty installation, misapplication, mishandling, misuse, modification, neglect, or service by anyone other than Cybernetics or authorized service personnel
- the miSAN-V-Series is damaged during transport because of improper packaging, including using unauthorized packaging

For Cybernetics devices with integral hard disk drives (HDD) in their enclosures, each HDD is covered by its manufacturer's warranty. If a HDD malfunctions, contact Cybernetics Technical Support at (757) 833-9200 or techsupport@cybernetics.com to initiate a service request. Customers can opt to send the HDD to Cybernetics to coordinate the service request through the manufacturer or obtain service directly from the manufacturer.