


Instruction Manual

Model 2015-26 Upconverter

December 2010 Rev. 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment. Printed in USA.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 2015-26 Upconverter

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	5
1.4 Environmental Use Information	8
2.0 Installation	9
2.1 Mechanical	9
2.2 Rear Panel Inputs & Outputs	10
2.3 Front Panel Controls & Indicators	11
2.4 Operation	12
2.5 Menu Settings	14
2.6 Availabe Options	18

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

MODEL 2015-26 Upconverter

1.0 General

1.1 Equipment Description

The 2015-26 Upconverter converts 140 ± 36 MHz to 2000 to 2500 MHz in 1.0 MHz steps (0.5 MHz steps optional) with low group delay and flat frequency response. Synthesized local oscillators (LO) provide frequency selection. Multi-function push button switches select the RF frequency, gain, and other parameters. Front panel LEDs provide indication of DC power (green), PLL alarm (red), Remote operation (yellow) or the TX carrier is Muted (yellow). Variable attenuators for the IF input and output provide a gain range of -10 to +30 dB as adjusted by the front panel multi-function pushbutton switches. Remote operation allows selection of frequency and gain. Parameter selection and frequency and gain settings appear on the LCD display. Connectors are BNC female for IF input, external reference input, and RF output. The 2015-26 is powered by a $100-240 \pm 10\%$ VAC power supply, and is housed in a 1 3/4" X 19" X 16" rack mount chassis.




FIGURE 1.1 Model 2015-26 Front and Rear Panels




FIGURE 1.2 Model 2015-26 Upconverter Block Diagram

1.2 Technical Characteristics

TABLE 1.0 2015-26 Upconverter Specifications*

Input Characteristics

Impedance/Return Loss	75 Ω /18 dB
Frequency	140 \pm 36 MHz
Input Level	-40 to -10 dBm

Output Characteristics

Impedance/Return Loss	50 Ω /12 dB
Frequency	2000 to 2500 MHz
Output level	0 to -20 dBm
Output 1 dB compression	+5 dBm

Channel Characteristics

Gain range (adjustable)	-10 to +30.0 dB
Spurious Response	<-45 dBC
Frequency Response	\pm 1.5 dB, 2000 - 2500 MHz; \pm 1.0 dB, 36 MHz BW
Group Delay, max	.0035 ns/MHz ² parabolic; 0.025 ns/MHz linear; 1 ns ripple
Frequency Sense	Non-inverting

Synthesizer Characteristics

Frequency Accuracy	\pm 1.0 ppm internal ref (\pm 0.01 ppm, option H)
Frequency Step	1.0 MHz (0.5 MHz, option 5 ; 125kHz, option X)
10 MHz Level (In/Out)	+3 dBm \pm 3 dB (option E)

Phase Noise @ Freq	100 Hz	1kHz	10kHz	100kHz	1MHz
dBc/Hz	-70	-70	-80	-95	-105

Controls, Indicators

Frequency Selection	direct readout LCD; pushbutton switches or remote selection
Gain Selection	direct readout LCD; pushbutton switches or remote selection
Power	Green LED
Alarm	Red LED
Remote	Yellow LED; RS232C, 9600 baud (RS485, option Q)
Mute	Yellow LED

Other

RF Connector	BNC (female), 50 Ω
IF Connector	BNC (female), 75 Ω
Ext 10 MHz	BNC (female), 50 Ω /75 Ω (option E)
Connector, Alarm, Remote	DB9 - NO or NC contact closure on Alarm
Size	19 inch, 1RU standard chassis 1.75"high X 16.0" deep
Power	100-240 \pm 10% VAC, 47-63 Hz, 45 watts max

Options


Available Options	See SECTION 2.6, page 18
Connector options	See TABLE 2.2, page 10

*+10°C to +40°C; Specifications subject to change without notice.

1.3 Monitor and Control Interface

A) Remote Serial Interface

Protocol - RS-485, RS-422 or RS-232C (selectable), 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit.



Connector: Rear panel, DB-9 male.

J10 Pinouts (RS-232C/422/485)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

B) Status Requests - Table 1.1 lists the status requests for the 2015-26 and briefly describes them.

* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485, (OPTION-Q), is selected.

Table 1.1 2015-26 Status Requests		
Command	Syntax*	Description
Command Status	{aaS1}	Returns {S1bbbbccccddAM} where:
		<ul style="list-style-type: none"> • bbbb = Tx frequency (MHz)
		4 characters - standard (7 characters - Option-X)
		<ul style="list-style-type: none"> • Standard 1 dB step format: ccc = Tx gain (-10 to +30) • Z OPTION (0.1 dB steps): cccc = Tx gain (-100 to +300)
		<ul style="list-style-type: none"> • dd = Tx input level (10 to 40 => -10 to -40) • A = 0 if no alarm, 1 if summary alarm) • M = Tx RF Status (1 = Normal, 0 = Muted)
Command Status	{aaS2}	Returns {S2E} where:
		<ul style="list-style-type: none"> • E = Ext 10MHz Status (1 = on, 0 = off)

C) Commands Table 1.2 lists the commands for the 2015-26 and briefly describes them. After a command is sent the 2015-26 sends a return “>” indicating the command has been received and executed.

General Command Format - The general command format is {aaCND...}, where:

- { = start byte
- aa = address (**RS-485 only - option Q**)
- C = 1 character, either C (command) or S (status)
- N = 1-digit command or status number, 1 through 9
- D = 1 character or more of data (depends on command)
- } = stop byte

* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485, (OPTION-Q), is selected.

Table 1.2 2015-26 Commands		
Command	Syntax*	Description
Set Transmitter Frequency	{aaC1xxxx}	where: <ul style="list-style-type: none"> • xxxx = 4 characters standard (7 characters -Option-X) • Range: 2000 to 2500 MHz
Set Input Level	{aaClxx}	where: <ul style="list-style-type: none"> • xx = 2 characters • Range: 10 to 40 (-10 to -40 dBm, in 1 dB steps)
Set Transmit Gain	{aaC3xxxx}	where: <ul style="list-style-type: none"> • Standard 1 dB step format: - xxx = 2 char (0 to 30dB), or 3 char (-10 to -01dB) if neg. - Range: -100 to 300 (-10.0 dB to +30.0 dB, in 0.1 dB steps) • Z OPTION (0.1 dB steps): - xxxx = 3 char (0 to 300dB), or 4 char (-100 to -001dB) if neg. - Range: -100 to 300 (-10.0 dB to +30.0 dB, in 0.1 dB steps)
Enable Tx	{aaCAx}	where x =: <ul style="list-style-type: none"> • 0 to disable Tx signal • 1 to enable Tx signal
Enable External 10MHz	{aaCEx}	where x =: <ul style="list-style-type: none"> • 0 to disable External 10MHz ref signal • 1 to enable External 10MHz ref signal
Enable Remote	#	Just # sign
Disable Remote	{aaCRO}	{CR and zero}

1.4 Environmental Use Information

- A. Rack-Mounting** - To mount this equipment in a rack, please refer to the installation instructions located in the user manual furnished by the manufacturer of your equipment rack.
- B. Mechanical Loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- C. Elevated Operating Ambient Temperature** - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to T_{mra} .
- D. Reduced Air Flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between unit may be required.
- E. Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- F. Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- G. Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.

2.0 Installation

2.1 Mechanical - The 2015-26 consists of one RF/Controller PCB housed in a 1 RU (1 3/4 inch high) by 16 inch deep chassis. A switching, ± 12 , +24, +5 VDC power supply provides power for the assemblies. The 2015-26 can be secured to a rack using the 4 holes on the front panel. Figure 2.1 shows how the 2015-26 is assembled.




FIGURE 2.1 2015-26 Mechanical Assembly

2.2 Rear Panel Input/Output Signals - Figure 2.2 shows the input and output connectors on the rear panel.




FIGURE 2.2 2015-26 Rear Panel I/Os

TABLE 2.1 J10 Pinouts (RS-232C/422/485*)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

*Remote Serial Interface

Interface: DB-9 Male

Protocol: RS-232C (RS-232C/422/485 **option Q**), 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit.

TABLE 2.2 IF/RF Connector Options		
Option	IF	RF
STD	BNC, 75Ω	BNC, 50Ω
-B	BNC, 75Ω	BNC, 75Ω
-D	BNC, 50Ω	BNC, 50Ω
-N	BNC, 75Ω	Type N, 50Ω
-M	BNC, 50Ω	Type N, 50Ω

2.3 Front Panel Controls and Indicators - The following are the front panel controls and indicators.




FIGURE 2.3 2015-26 Front Panel Controls and Indicators

2.4 Operation

2.4.1 Installing and Operating the 2015-26 Upconverter

1. Connect a -10 dBm to -40 dBm signal to IF In, J4 (Figure 2.2)
2. Connect the RF OUT, J5, to the external equipment
3. Connect 100-20 \pm 10% VAC, 47 - 63 Hz to AC1 on the back panel.
4. Set the desired output frequency (See Section 2.5 Menu Settings).
5. Set the input level (See Section 2.5 Menu Settings).
6. Set the gain for -10 to +30 dB. Make sure the output stays within -20 to 0 dBm with the gain selected and the input level provided. The firmware will prevent setting gain and input level outside this range. (See Section 2.5 Menu Settings).
7. Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.3).
8. AC Fuse - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.4. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.4 Fuse Location and Spare Fuse

2.5 Menu Settings

2.5.1 Functions

This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components.

The functions are (See Figure 2.5):

Power Up

Normal Display

Menu 1 Frequency in MHz

Menu 2 Input Lvl (Set from -40 to -10)

Menu 3 Gain (-10 to +30)

Menu 4 Mute

Menu 5 Set Unit to Remote Operation (**NOTE**: the local controls still function when in REMOTE)

Menu 6 Select External 10 MHz Ref (**option E**)

Menu 7 Set Remote Mode (**option Q**)

Menu 8 Set RS-485 Address (**option Q**)

Save Menu When “R” is selected or at the end

Alarm indications appear on the LEDs (See figure 2.3).

All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the “Save Settings?” Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 12 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

2.5.2 Power On Settings

NOTE: THE LAST STATUS OF A UNIT IS RETAINED EVEN WHEN POWER IS REMOVED. WHEN POWER IS RESTORED, THE UNIT WILL RETURN TO IT'S PREVIOUS SETTINGS.


When power is first applied, the LCD display goes through three steps.

1. The LCD goes black to show all segments are functioning.
2. The software version will be displayed.



REV 1.00

3. The present frequency and gain of the upconverter is shown.



F=2350 G=+10.0

The unit is now operational and ready for any changes the operator may desire.

2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
 - a. During frequency, gain changes, the vertical movement will raise or lower the number in the direction of the arrows.
 - b. For other functions such Mute on/off, the vertical switch will alternately turn the function on or off regardless of the direction operated.

2.5.4 Frequency Changes

At any time during the modification process, if you have made a mistake and do not wish to save the changes you have made, **do not press the Menu/Execute switch**; simply do nothing for approximately 12 seconds, and the system will return to the normal operating mode or scroll to “**R**” and push the menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window.

To change the FREQUENCY:

Operate the Menu/Execute switch until you get to the menu item you want to change. See Figure 2.5 for the sequence of menu options. The following display is for changing the upconverter frequency:

F = 2350	R
-----------------	----------

Pressing the Up/Down switch down will toggle the display to:

F = 2450	R
-----------------	----------

By using the horizontal rocker switch the cursor can be moved left or right.

F = 245<u>0</u>	R
------------------------	----------

NOTE: CHANGES DO NOT TAKE PLACE ON FREQUENCY UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES. THE CARRIER IS MUTED WHEN FREQUENCY IS CHANGED.

When the display indicates the value desired you can push the Menu/Execute switch to the next item:

INLVL = -2<u>0</u>	R
---------------------------	----------

OR you can scroll to “**R**”, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
-----------------------	-------------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to this:

F=2450	G=+10.0
---------------	----------------

Figure 2.5 gives the menu items and how to make changes.

2.5.5 Gain Changes

When you get to this menu note that the gain changes will be made as you make them but if you do not wish to save the changes you have made, scroll to “R” and push the menu/Execute switch and select “NO” in the “SAVE SETTINGS?” window or **do not press the Menu/Execute switch**; simply do nothing for approximately 12 seconds, and the system will return to the normal operating mode.

The following display is for changing the upconverter input level. This is an important setting to optimize spurious and should be made as accurately as possible:

```
INLVL = -20      R
```

NOTE: CHANGES TAKE PLACE ON LEVEL AND GAIN IMMEDIATELY BUT DO NOT GET SAVED UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.

Pressing the Up/Down switch to change the level in 1 dB steps and then push the Menu/Execute switch to get to the Gain setting:

```
G = +10      R
```

Pressing the Up/Down switch to change the gain in 1 or 10 dB steps and then push the Menu/Execute switch to get to the Gain setting:

```
G = +20      R
```

By using the horizontal rocker switch the cursor can be moved left or right .

Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

NOTE: THE GAIN WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW.DO NOT SET A GAIN THAT WOULD EXCEED 0 dBm OR HAVE LESS THAN -20 dBm OUTPUT LEVEL. THE FIRMWARE PREVENTS YOU FROM THIS.

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to “R”, push the Menu/Execute switch to get to:

```
SAVE SETTINGS?  Y N
```

Selecting Y will save the new settings. Selecting N will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to this:

```
F=2450      G=+20.0
```

Figure 2.5 gives the menu items and how to make changes.

2.5.5 Alarm Indications

An alarm condition will occur if any local oscillator phase lock loop (PLL) comes out of lock. The Mute LED will light if you select Mute and the Remote LED will light when you select the Remote mode.




FIGURE 2.5 Menu Display and Sequence

2.6 Available Options (Models: 2015-XX, 2016-XX & 2017-XX)

Table 2.6.A Options Document		
Option	Available Product(s)	Option Description
AGC	2016-XX	Provides Automatic Gain Control (AGC) capability on 70 MHz Output on 2016-XX IF Downconverter.
AGC/2	2015-XX 2016-XX	Provides Automatic Gain Control (AGC) capability for 50 to 200 MHz Output via an add-on PCB On-board SMA connectors allow insertion of bandpass filters (Option BPF-#) if required.
B	2015-XX 2016-XX	Connectors: All RF & IF Connectors, 75 Ohm BNC, (2015-XX & 2016-XX).
BPF-1	2015-XX 2016-XX	Bandpass Filter Option #1, highly selective elliptic function bandpass filter with multiple all pass delay equalizers.
C	2015-XX 2016-XX	Connectors, IF - 75 Ohm BNC, RF - 50 Ohm BNC for 2015-XX & 2016-XX Frequency Converters.
CE-Cert	2015-XX 2016-XX 2017-XX	CE Certification Compliance, Documentation & Labeling for 2015-XX, 2016-XX and 2017-XX frequency converters and 2115-XX & 2116-XX block converters.
D	2015-XX 2016-XX	All RF & IF Connectors, 50 Ohm BNC, 2015-XX & 2016-XX.
E	2015-XX 2016-XX	External 10 MHz reference input, also supports insertion of either internal or external 10 MHz source on RF, models 2015-XX & 2016-XX Up & Downconverters.
E/2	2015-XX 2016-XX	External 10 MHz reference input for IF to UHF-, S-, C-, Ku- Agile Frequency Converters.
F	2015-XX 2016-XX	Connectors, 75 F-type RF, 75 F-type IF, for 2015-XX & 2016-XX Frequency Converters.
H	2015-XX 2016-XX 2017-XX	High Stability (± 0.01 ppm) internal reference, for 2015 , 2106, & 2017-XX frequency converters and 2083-714A/-914A IF Translators.
I	2015-XX 2016-XX	Spectrum Inversion for 2015-XX Upconverters or 2115-XX Block Upconverters.
J	2015-XX 2016-XX	Connectors, 75 F-type RF, 50 Ohm BNC IF, for 2015 & 2016-XX Frequency Converters.
K	2015-XX 2016-XX	Connectors, 75 BNC RF, 50 Ohm BNC IF, for 2015 & 2016-XX Frequency Converters.
L	2015-XX 2016-XX	LNB Voltage + 24 VDC, 0.4 Amps, for 2016-XX Downconverter.
M	2015-XX 2016-XX	Connectors: N-type, 50 Ohm RF & BNC 50 Ohm IF; 2015 & 2016-XX Frequency Converters.
N	2015-XX 2016-XX	Connectors: N-type, 50 Ohm RF & BNC 75 Ohm IF; 2015 & 2016-XX Frequency Converters.
NF	2015-XX 2016-XX	Connectors: RF = N/50 Ohm , IF = F/75 Ohm, for 2015 & 2016-XX Frequency Converters.
P24	2015-XX 2016-XX	Option P24 – ± 24 VDC Power Supply, for 2015, 2016, & 2017-XX Frequency Converters; and 2115-XX & 2016-XX Block Converters.
P48	2015-XX 2016-XX	Option P48 – ± 48 VDC Power Supply, for 2015, 2016 & 2017 Frequency Converters; 2115-XX & 2016-XX Block Converters.
PWR	2015-XX 2016-XX	Option PWR - Provides +15 dB Output @ 1 dB Compression for 2015-XX L-band Upconverter. 50 Ohm Connectors ONLY.

Table 2.6.B Options Document - Continued		
Option	Available Product(s)	Option Description
Q	2015-XX 2016-XX 2017-XX	RS485/RS422 Remote Interface, for 2017-XX Frequency converters.
Q/2	2015-XX 2016-XX 2017-XX	RS485/RS422 Remote Interface, for 2015, 2016, & 2017-XX Frequency converters.
R	2015-XX 2016-XX 2017-XX	Redundant Power Supply, for 2015, 2016 & 2017-XX Frequency Converters. NOT AVAILABLE on units with SSPB Power Option (Option V).
S	2015-XX 2016-XX	Connectors: RF = all SMA, 50 Ohm , IF = all BNC 50 Ohm; 2115-XX & 2116-XX Frequency Converters.
S7	2015-XX 2016-XX	Connectors: RF - SMA 50 Ohm; IF BNC 75 Ohm for 2015 & 2016 Up or Downconverters OR 2115-XX and 2116-XX BLOCK Up or Downconverters.
SP	2015-XX 2016-XX	Integrated 2 x 1 splitter to provide dual, simultaneous IF Outputs.
SS	2015-XX 2016-XX	Connectors: RF=SMA/50 Ohm, IF=SMA/50 Ohm for ALL L-, C-, and Ku-band Frequency Converters.
SW	2015-XX 2016-XX	Integrated RF Switch with Remote RS485/RS522 control to enable remote switching of RF Output from RF A to RF B Outputs.
SW1	2015-XX 2016-XX	Integrated RF Switch, designed to switch between Low and High RF Inputs based on selected RF Frequency from Front Panel LCD menu or Remote M&C interface.
T	2015-XX 2016-XX 2017-XX	Temperature Sensor, for 2017-XX Up/Downconverter.
V41	2015-XX 2016-XX 2017-XX	SSPB Voltage, +48 VDC. 2.10 Amps, 100 Watts, for 2015-XX Upconverters.
V46	2015-XX 2016-XX	SSPB Voltage, +48 VDC. 1.25 Amps, 65 Watts, for 2015-XX Upconverters.
W1	2015-XX 2016-XX	Level Detection for 2016-25 Downconverter.
W4	2015-XX 2016-XX	3 MHz bandwidth SAW Filter for 2015 & 2016-XX Up or Downconverters.
W5	2015-XX 2016-XX	Optional Reference Oscillator Adjustment, rear panel, screw adjust for 2015 & 2016-XX Up or Downconverters.
W7	2015-XX 2016-XX	Front Panel, RF & IF Test/Monitor Ports for 2015 & 2016-XX Up or Downconverters; Connectors RF - SMA 50 Ohms, IF - BNC 50 Ohms.
W8	2015-XX 2016-XX 2017-XX	Ethernet M & C Remote Interface, for 2015, 2016, & 2017-XX Frequency converters.

Table 2.6.C Options Document		
Option	Available Product(s)	Option Description
W10	2015-XX 2016-XX 2017-XX	Front Panel Disable for Series 2015/2016 & 2017-XX Frequency Converters. Provides the ability to Disable the Front Panel Interface via the Remote Interface and to ONLY configure, monitor and control the unit via the Remote Interface.
W12	2015-XX 2016-XX	REAR Panel, LO1 (SMA Connector) and LO2 (BNC Connector) Test Ports for 2015-XX Upconverters.
W13	2015-XX 2016-XX	REAR Panel, LO1 (SMA Connector) Test Port for 2016-XX Downconverters.
W15	2015-XX 2016-XX 2017-XX	Power ON/OFF Switch, Rear Panel Mounted. 2015, 2016, & 2017 L-band Frequency Converters.
W16	2015-XX 2016-XX 2017-XX	Individual Test Data per unit. For Frequency Converters and/or Protection Switches.
W17	2015-XX 2016-XX	Front Panel, IF Test/Monitor Ports for 2015-XX Upconverters w/25 dB Gain, Max Output +5 dBm; Connector IF - BNC 50 Ohms.
W18	2015-XX 2016-XX	Ethernet M & C Remote Interface With SNMP, for 2015, 2016, & 2017-XX Frequency converters and 1582/2582-XXX Protection Switches.
X	2015-XX 2016-XX	Option X - 125 KHz Step Size for 2015-XX or 2016 -XX Frequency Converters.
X1	2015/16/17-XX	100 KHz Step Size for 2015-XX, 2016 -XX and 2017-XX Frequency Converters.
Z	2015-XX 2016-XX	Upconverter Attenuator 0.1 dB, on 2015-XX Upconverter or 2017-XX Upconverter portion.
Z1	2015-XX 2016-XX	Downconverter Attenuator 0.1 dB, on 2016-XX Downconverter or 2017-XX, Downconverter portion.
-5,	2015-XX	500 KHz Frequency Step for 2015-26 Upconverter.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

2010 • Printed in USA