


Model No. 831.24902.0

Serial No. _____

Write the serial number in the space above for future reference.



- Assembly
- Operation
- Maintenance
- Part List and Drawing

Sears, Roebuck and Co.
Hoffman Estates, IL 60179

CAUTION

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.

TREADMILL EXERCISER

User's Manual





TABLE OF CONTENTS

WARNING DECAL PLACEMENT	2
IMPORTANT PRECAUTIONS	3
BEFORE YOU BEGIN	5
ASSEMBLY	6
TREADMILL OPERATION	9
HOW TO FOLD THE TREADMILL	11
TROUBLESHOOTING	12
EXERCISE GUIDELINES	13
PART LIST	14
EXPLODED DRAWING	15
ORDERING REPLACEMENT PARTS	Back Cover
90 DAY FULL WARRANTY	Back Cover

WARNING DECAL PLACEMENT

This drawing shows the location(s) of the warning decal(s). **If a decal is missing or illegible, call 1-866-699-3756 and request a free replacement decal. Apply the decal in the location shown.**
 Note: The decal(s) may not be shown at actual size.



IMPORTANT PRECAUTIONS

⚠ WARNING: To reduce the risk of serious injury, read all important precautions and instructions in this manual and all warnings on your treadmill before using your treadmill. Sears assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

1. Before beginning this or any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
2. It is the responsibility of the owner to ensure that all users of the treadmill are adequately informed of all warnings and precautions.
3. Use the treadmill only as described.
4. Keep the treadmill indoors, away from moisture and dust. Do not put the treadmill in a garage or covered patio, or near water.
5. Place the treadmill on a level surface, with at least 8 ft. (2.4 m) of clearance behind it and 2 ft. (0.6 m) on each side. Do not place the treadmill on any surface that blocks air openings. To protect the floor or carpet from damage, place a mat under the treadmill.
6. Do not operate the treadmill where aerosol products are used or where oxygen is being administered.
7. Keep children under age 12 and pets away from the treadmill at all times.
8. The treadmill should not be used by persons weighing more than 250 lbs. (113 kg).
9. Never allow more than one person on the treadmill at a time.
10. Wear appropriate exercise clothes while using the treadmill. Do not wear loose clothes that could become caught in the treadmill. Athletic support clothes are recommended for both men and women. *Always wear athletic shoes; never use the treadmill with bare feet, wearing only stockings, or in sandals.*
11. Do not operate the treadmill if the treadmill is not working properly. (See TROUBLESHOOTING on page 12 if the treadmill is not working properly.)
12. Always hold the handrails while using the treadmill.
13. Do not attempt to raise or lower the treadmill until it is properly assembled. (See ASSEMBLY on page 6 and HOW TO FOLD THE TREADMILL on page 11.) You must be able to safely lift 25 lbs. (11 kg) to raise or lower the treadmill.
14. When folding the treadmill, make sure that the storage latch is holding the frame securely in the storage position.
15. Do not change the incline of the treadmill by placing objects under the treadmill.
16. Inspect and properly tighten all parts of the treadmill regularly.
17. Never drop or insert any object into any opening on the treadmill.
18. Servicing other than the procedures in this manual should be performed by an authorized service representative only.

19. Over exercising may result in serious injury or death. If you feel faint or if you experience pain while exercising, stop immediately and cool down.

20. Do not place hands or feet under the treadmill while it is in use.

21. This treadmill is intended for home use only. Do not use the treadmill in any commercial, rental, or institutional setting.

22. The roller guards must be 1/8 in. (3 mm) from the rear roller (see the drawing on page 5). Adjust the roller guards, if necessary.

SAVE THESE INSTRUCTIONS


BEFORE YOU BEGIN

Thank you for selecting the new WESLO® CARDIO STRIDE 2.0 treadmill. The CARDIO STRIDE 2.0 treadmill offers a selection of features designed to make your workouts at home more effective. And when you're not exercising, the unique treadmill can be folded up, requiring less than half the floor space of other treadmills.



For your benefit, read this manual carefully before using the treadmill. If you have questions after read-


ing this manual, please see the back cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number and the location of the serial number decal are shown on the front cover of this manual.

Before reading further, please familiarize yourself with the parts that are labeled in the drawing below.



ASSEMBLY


Assembly requires only the included hex key  and wrench . To avoid damaging parts, do not use power tools for assembly. Assembly requires two persons. Set the treadmill in a cleared area and remove all packing materials. **Do not dispose of the packing materials until assembly is completed.** In the drawing below, the numbers in parentheses are the key numbers of the parts, from the PART LIST near the end of this manual. The numbers after the parentheses are the quantities needed for assembly. **Note: Some small parts may be pre-assembled. Extra hardware may be included. If a part is missing, call 1-866-699-3756.**




1. Identify the Right Upright (36), which has a single hole in the indicated location. Orient the Right Upright so that the two indicated holes are on the side shown, and hold the Right Upright against the Base (14).

Attach the Right Upright (36) to the Base (14) with two M8 x 50mm Bolts (38), two M8 Curved Washers (37), and two M8 Nylon Nuts (13). **Do not tighten the Nylon Nuts yet.**


Orient the Left Upright (35) so that the two indicated holes are on the side shown, and attach the Left Upright to the Base (14) in the same way. **Do not tighten the Nylon Nuts yet.**



2. Raise the Left Upright (35) and the Right Upright (36) to the position shown.




3. Attach the Hood (28) to the front of the Frame (29) with two M5 x 10mm Screws (10).



4. **See drawing 4a.** Hold the front of the Frame (29) between the Left Upright (35) and the Right Upright (36). Align the holes near the front of the Frame with one of the two sets of adjustment holes in the Uprights. Insert the two Adjustment Pins (4) into the holes in the Uprights and the Frame. **Make sure that the Adjustment Pins are fully inserted at the same height.**

Next, look under the Frame (29) near the Left Upright (35). **See drawing 4b.** Locate the Reed Switch Clip (11) attached to the underside of the Frame. Insert the Reed Switch (6) into the Reed Switch Clip as shown. Next, locate the Magnet (12) on the left Flywheel (9). Turn the Flywheel until the Magnet is aligned with the Reed Switch. **Move the Reed Switch so that there is a 1/8" (3 mm) gap between the Reed Switch and the Magnet.** Then, tighten the M5 x 12mm Screw (44).




5. Hold the Handrail (5) near the Left and Right Uprights (35, 36). Connect the Handrail Wire (2) to the Reed Switch Wire (6). Insert the Wires down into the Left Upright.


Attach the Handrail (5) to the Uprights (35, 36) with four M8 x 15mm Screws (33) and four M8 Washers (34). **Be careful not to pinch the Wires (2, 6). Do not fully tighten the Screws yet.**

Place the treadmill in the storage position (see page 11). Center the Frame (not shown) between the Uprights (35, 36).

See step 1. Tighten the four M8 Nylon Nuts (13). Then, tighten the M8 x 15mm Screws (33). Lower the Frame (see page 11).




6. The Console (1) requires two “AAA” batteries; alkaline batteries are recommended. Press the indicated tab on the Battery Cover (27), and remove the Battery Cover. Insert two batteries into the two battery clips; **make sure that the negative (–) ends of the batteries are touching the springs in the battery clips.**




7. **See drawing 7a.** Hold the Console (1) near the Handrail (5). Connect the wire on the Console to the Handrail Wire (2). Then, attach the Console to the Handrail with two M4 x 12mm Screws (3). **Make sure that the wires are not pinched.**

See drawing 7b. Press the Battery Cover (27) onto the Console (1).



8. Remove the paper backing from the Adhesive Clip (30). Press the Adhesive Clip onto the left side of the Frame (29) in the indicated location. Then, press the Hex Key (20) into the Adhesive Clip.

Make sure that the walking belt is properly tightened (see SYMPTOM 3 on page 12).




9. **Make sure that all parts are properly tightened before you use the treadmill.** To protect the floor or carpet, place a mat under the treadmill.

TREADMILL OPERATION

STEP-BY-STEP CONSOLE OPERATION

Before the console can be operated, batteries must be installed (see assembly step 6 on page 8). If there is a thin sheet of plastic on the console, remove the plastic.



The console features six modes:

- Speed—This mode displays your speed, in miles per hour.
- Distance—This mode displays the number of miles you have walked.
- Time—This mode displays the elapsed time.
- Odometer—This mode displays the distance that the walking belt has moved since the batteries were changed.
- Calorie—This mode displays the approximate number of calories you have burned.
- Scan—This mode displays the Speed, Distance, Time, Odometer, and Calorie modes.


Follow the steps below to operate the console.

1. Turn on the power.

To turn on the power, press the console button or begin walking. Note: If batteries were just installed, the power will already be on. The first time you use the treadmill, lubricate the walking platform (see page 10).

2. Track your progress with the six modes.

When the power is turned on, the Scan mode will be selected and the SCAN indicator will appear. The console will display the Speed, Distance, Time, Odometer, and Calorie modes, for about six seconds each, in a repeating cycle.



To select only the Speed, Distance, Time, Odometer, or Calorie mode, press the console button until only the SPEED, DIST, TIME, ODO, or CAL indicator appears in the display. Make sure that the SCAN indicator does not appear.

To reset all modes (except for the odometer mode), press the console button for about three seconds.


3. Turn off the power.

To turn off the power, simply wait for a few minutes. If the walking belt is not moved and the console button is not pressed for a few minutes, **the power will turn off automatically.**

INCLINE ADJUSTMENT

The incline of the treadmill can be adjusted to two positions. Hold the front of the Frame (29), and remove the two Adjustment Pins (4). Raise or lower the Frame, align the holes in the Frame with one of the sets of holes in the Uprights (35, 36), and then reinsert the Adjustment Pins.


CAUTION: Make sure that both Adjustment Pins (4) are fully inserted at the same height.



LUBRICATING THE WALKING PLATFORM

Before the treadmill is used, the walking platform should be lubricated. Open the included lubricant packet. Reach under one side of the walking belt as far as you can, and apply half of the lubricant to the walking platform. Then, reach under the other side of the walking belt and apply the remaining lubricant.

After you have applied the lubricant, walk on the treadmill for a few minutes to spread the lubricant.




HOW TO FOLD THE TREADMILL

FOLDING THE TREADMILL FOR STORAGE


When the treadmill is not in use, it can be folded to the compact storage position. **CAUTION: You must be able to safely lift 25 pounds (11 kg) to raise or lower the treadmill.**

1. Hold the treadmill with your hands in the locations shown below. **CAUTION: Bend your legs and keep your back straight. As you raise the treadmill, make sure to lift with your legs rather than your back.** Raise the treadmill to the vertical position.



2. Hold the treadmill securely with your left hand as shown. Insert the Storage Pin (42) into the hole in the right side of the Right Upright (36) and into the Frame (29) **as far as it will go.**

Press the ends of the Spring Clip (43) together and slide the Clip onto the end of the Storage Pin.



LOWERING THE TREADMILL FOR USE

1. Hold the treadmill securely with your left hand as shown in drawing 2. Press the ends of the Spring Clip (43) together and slide the Clip off the end of the Storage Pin (42). Pull out the Storage Pin and pivot the treadmill downward a few inches.
2. Hold the treadmill firmly with both hands, and lower the treadmill to the floor. **CAUTION: Bend your legs and keep your back straight.** Then, reinsert the storage pin and reattach the spring clip.

TROUBLESHOOTING


Most treadmill problems can be solved by following the steps below. Find the symptom that applies, and follow the steps listed. If further assistance is needed, please see the front cover of this manual.

1. SYMPTOM: THE CONSOLE DOES NOT FUNCTION PROPERLY

- Replace the batteries in the console (see assembly step 6 on page 8).
- Make sure that the reed switch is properly adjusted (see assembly step 4 on page 7).
- Make sure that the handrail wire is plugged fully into the wire on the console (see assembly step 7 on page 8).
- The console, like most electronics, is susceptible to static electricity build-up caused by certain types of clothing or by the operation of the treadmill. If the display is blank or gives incorrect readings, apply an anti-static spray to the handrail. Anti-static spray is available where laundry supplies are sold.

2. SYMPTOM: THE WALKING BELT DOES NOT MOVE SMOOTHLY


- If the walking belt is overtightened, performance may be reduced and the walking belt may be permanently damaged. Using the hex key, turn both roller adjustment screws counterclockwise 1/4 of a turn.



When the walking belt is properly tightened, you should be able to lift each edge of the walking belt 2 to 3 in. (5 to 7 cm) off the walking platform. Be careful to keep the walking belt centered. Walk on the treadmill for a few minutes. Repeat until the walking belt is properly tightened.


3. SYMPTOM: THE WALKING BELT SLIPS OR IS OFF-CENTER

- If the walking belt slips when walked on, use the hex key to turn both adjustment screws clockwise, 1/4




of a turn. When the walking belt is properly tightened, you should be able to lift each edge of the walking belt 2 to 3 in. (5 to 7 cm) off the walking platform. Be careful to keep the walking belt centered. Walk on the treadmill for a few minutes. Repeat until the walking belt is properly tightened.

- If the walking belt has shifted to the left side, use the hex key to turn the left adjustment screw clockwise, and



the right adjustment screw counterclockwise, 1/4 of a turn each. Be careful not to overtighten the walking belt. Walk on the treadmill for a few minutes. Repeat until the walking belt is centered.

- If the walking belt has shifted to the right side, use the hex key to turn the left adjustment screw counter-



clockwise, 1/4 of a turn each. Be careful not to overtighten the walking belt. Walk on the treadmill for a few minutes. Repeat until the walking belt is centered.

EXERCISE GUIDELINES

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.

These guidelines will help you to plan your exercise program. For detailed exercise information, obtain a reputable book or consult your physician. Remember, proper nutrition and adequate rest are essential for successful results.

EXERCISE INTENSITY

Whether your goal is to burn fat or to strengthen your cardiovascular system, exercising at the proper intensity is the key to achieving results. You can use your heart rate as a guide to find the proper intensity level. The chart below shows recommended heart rates for fat burning and aerobic exercise.

165	155	145	140	130	125	115	♥♥
145	138	130	125	118	110	103	♥
125	120	115	110	105	95	90	♥
<hr/>							
20	30	40	50	60	70	80	


To find the proper intensity level, find your age at the bottom of the chart (ages are rounded off to the nearest ten years). The three numbers listed above your age define your “training zone.” The lowest number is the heart rate for fat burning, the middle number is the heart rate for maximum fat burning, and the highest number is the heart rate for aerobic exercise.

Burning Fat—To burn fat effectively, you must exercise at a low intensity level for a sustained period of time. During the first few minutes of exercise, your body uses *carbohydrate calories* for energy. Only after the first few minutes of exercise does your body begin to use stored *fat calories* for energy. If your goal is to burn fat, adjust the intensity of your exercise until your heart rate is near the lowest number in your training zone. For maximum fat burning, exercise with your heart rate near the middle number in your training zone.

Aerobic Exercise—If your goal is to strengthen your cardiovascular system, you must perform aerobic exercise, which is activity that requires large amounts of oxygen for prolonged periods of time. For aerobic exercise, adjust the intensity of your exercise until your heart rate is near the highest number in your training zone.

HOW TO MEASURE YOUR HEART RATE

To measure your heart rate, exercise for at least four minutes. Then, stop exercising and place two fingers on your wrist as shown.



Take a six-second heart-beat count, and multiply the result by 10 to find your heart rate. For example, if your six-second heartbeat count is 14, your heart rate is 140 beats per minute.

WORKOUT GUIDELINES

Warming Up—Start with 5 to 10 minutes of stretching and light exercise. A warm-up increases your body temperature, heart rate, and circulation in preparation for exercise.

Training Zone Exercise—Exercise for 20 to 30 minutes with your heart rate in your training zone. (During the first few weeks of your exercise program, do not keep your heart rate in your training zone for longer than 20 minutes.) Breathe regularly and deeply as you exercise—never hold your breath.

Cooling Down—Finish with 5 to 10 minutes of stretching. Stretching increases the flexibility of your muscles and helps to prevent post-exercise problems.

EXERCISE FREQUENCY

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

PART LIST


Model No. 831.24902.0 R0611A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Console	25	1	Rear Roller
2	1	Handrail Wire	26	1	Wrench
3	2	M4 x 12mm Screw	27	1	Battery Cover
4	2	Adjustment Pin	28	1	Hood
5	1	Handrail	29	1	Frame
6	1	Reed Switch/Wire	30	1	Adhesive Clip
7	10	M5 x 20mm Screw	31	2	Handrail Cap
8	2	Frame Cap	32	2	Handrail Foam Grip
9	2	Front Roller/Flywheel	33	4	M8 x 15mm Screw
10	4	M5 x 10mm Screw	34	4	M8 Washer
11	1	Reed Switch Clip	35	1	Left Upright
12	1	Magnet	36	1	Right Upright
13	4	M8 Nylon Nut	37	4	M8 Curved Washer
14	1	Base	38	4	M8 x 50mm Bolt
15	2	Base Pad	39	1	Grommet
16	2	Roller Guard	40	1	Warning Decal
17	2	Base Cap	41	2	Platform Cover
18	1	Walking Belt	42	1	Storage Pin
19	1	Walking Platform	43	1	Spring Clip
20	1	Hex Key	44	1	M5 x 12mm Screw
21	2	Frame Foot	45	2	Caution Decal
22	2	Roller Adjustment Screw	46	1	Latch Warning Decal
23	2	Roller Washer	*	—	Lubricant Packet
24	2	Frame Plate	*	—	User's Manual

Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. *These parts are not illustrated. **If a part is missing, call 1-866-699-3756.**

EXPLODED DRAWING

Model No. 831.24902.0 R0611A



Get it fixed, at your home or ours!

Your Home

For repair—**in your home**—of **all** major brand appliances, lawn and garden equipment, or heating and cooling systems, **no matter who made it, no matter who sold it!**

For the replacement parts, accessories, and user's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME® (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com

www.sears.ca

Our Home

For repair of carry-in items like vacuums, lawn equipment, and electronics, call or go on-line for the location of your nearest **Sears Parts & Repair Center.**

1-800-488-1222 Call anytime, day or night (U.S.A. only)

www.sears.com

To purchase a protection agreement (U.S.A.) or maintenance agreement (Canada) on a product serviced by Sears:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas:

1-888-SU-HOGAR® (1-888-784-6427)



® Registered Trademark / ™ Trademark / ™ Service Mark of Sears Brands, LLC
® Marca Registrada / ™ Marca de Fábrica / ™ Marca de Servicio de Sears Brands, LLC

90-DAY FULL WARRANTY

If this Sears Treadmill Exerciser fails due to a defect in material or workmanship within 90 days of the date of purchase, call 1-800-4-MY-HOME® (1-800-469-4663) to arrange for free repair (or replacement if repair proves impossible).

This warranty does not apply when the Treadmill Exerciser is used commercially or for rental purposes.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears, Roebuck and Co., Hoffman Estates, IL 60179