

USER GUIDE

UK

# DECT TELEPHONE

Solo Combo 15





## 1 BECAUSE WE CARE

Thank you for purchasing this product. This product has been designed and assembled with utmost care for you and the environment. This is why we supply this product with a quick installation guide to reduce the number of paper (pages) and therefor save trees to be cut for making this paper. A full and detailed user guide with all the features described can be found on our website [www.aegtelephones.eu](http://www.aegtelephones.eu). Please download the full user guide in case you want to make use of all the advanced features of your product. To save the environment we ask you not to print this full user guide. Thank you for supporting us to protect our environment.

## 2 IMPORTANT SAFETY INSTRUCTIONS

Please follow these safety instructions when using your telephone equipment to reduce risk of fire, electric shock and injury:

1. Read and understand all the instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. Keep this product away from hot, humid conditions or strong sunlight, and don't let it get wet or use it near water (for example, near a bath tub, kitchen sink, or swimming pool).
5. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
6. Unplug this product from the wall outlet and obtain the service of our Repair Centre under the following conditions:
  - When the power supply cord or plug is damaged or frayed.
  - If the product fails to operate normally despite following the operating instructions.
  - If the product has been dropped and the cabinet has been damaged.
  - If the product exhibits a distinct change in performance.
7. NEVER use your phone outdoors during a thunderstorm. Unplug the base from the telephone line and the mains socket when there are storms in your area. Damage caused by lightning is not covered by the guarantee.
8. Do not use the telephone to report a gas leak in the vicinity of the leak.
9. Use only the supplied NiMH (Nickel Metal Hydride) batteries that came with your phone or an authorised replacement recommended by the manufacturer. There is a risk of explosion if you replace the battery with an incorrect battery type. The use of other battery types or non-rechargeable batteries/primary cells can be dangerous. They may cause interference and/or damage to the unit or surroundings. The manufacturer will not be held liable for damage arising from such non-compliance.
10. Do not use third party charging pods. Damage may be caused to the batteries.
11. Please ensure that the batteries are inserted in the correct polarity.
12. Dispose of batteries safely. Do not burn, immerse them in water, disassemble, or puncture the batteries.

### 3 INTENDED USE

This telephone is intended to be connected to a public analogue telephone network or to an analogue extension of a compatible PBX system.

### 4 PACKAGE CONTENT

The package contains the following items:

- 1 Cordless Handset
- 1 Corded Handset
- 1 Corded Base Station
- 1 Charging Pod for the Cordless Handset
- 1 Mains Power Adapter for the Corded Base Station
- 1 Telephone Line Cord for the Corded Base Station
- 1 Coiled Telephone Handset Cord for the Corded Handset
- 2 AAA NiMH Rechargeable Batteries for the Cordless Handset
- 1 Back Cover for the Cordless Handset
- 1 User Guide

### 5 INSTALLING YOUR PHONE

#### 5.1 Connecting the corded base station (see P6)

- Plug the mains power cable, telephone line cord and coiled handset cord into the corded base station.
- Plug the other end of the coiled handset cord into the corded handset.
- Place the corded handset in the cradle of the corded base station.
- Plug the power adapter into a 100 - 240Vac, 50 - 60Hz mains power socket and the telephone line cord into a telephone line socket.

**Warning:**

Always use the cables provided in the box.

Use only the supplied adaptor. Using other power cables may damage the unit.

**Note:**

Place the corded base unit within easy reach of the mains power socket. Never try to lengthen the mains power cable.

The corded base station needs mains power for normal operation and the handsets will not work without it.

## 5.2 Installing the cordless handset and charging the batteries (see P5)

- Insert the 2 supplied batteries into the battery compartment of the cordless handset, observing the correct polarity (see markings inside battery compartment).

### Warning:

Use only the supplied NiMH rechargeable batteries.









- Place the back cover over the back of the cordless handset and press down until it clicks into place.
- Place the cordless handset on the charging pod and charge for 15 hours before using the cordless handset for the first time.
- The cordless handset will give a double beep when it is properly placed on the charging pod.
- The battery charging indicator on the charging pod lights up to indicate charging.




### Note:

The cordless handset may become warm when the batteries are being charged or during prolonged periods of use. This is normal and does not indicate a fault.

## 6 GETTING TO KNOW YOUR PHONE














### 6.1 Cordless handset overview (see P1)

#	Icon	Meaning
1		In standby mode, press to enter the Main Menu list. Press to select an item, or to save an entry or setting.
2		In menu mode, press to scroll up. During a call or message playback, press to increase the volume. In standby mode, press to access the call log.
3		Press to make or answer a call. During a call or message playback, press to switch between speakerphone and earpiece.
4		Press and hold to switch the key lock on or off.
5		During a call, press to send a Flash signal for network services.
6		In standby mode, press to access the redial list.
7		In standby mode or during a call, press to initiate an intercom call or transfer a call.
8		Press to cancel an action. During pre-dialling, press to delete the last digit entered. During a call, press to mute the microphone, and press again to resume conversation.

9		In menu mode, press to scroll down. In standby mode, press to access the phonebook list. During a call, or message playback, press to decrease the volume.
10		During a call, press to hang up. During programming, press to cancel and exit without making changes. In standby mode, press and hold to power the handset on/off.
11		Press and hold to turn the handset ringer off. Press and hold to add a dialling pause when dialling or entering numbers into the phonebook.














## 6.2 Cordless handset display (see P2)

The LCD display gives you information on the current status of the telephone.

Icon	Meaning
	Displays when the battery is almost empty.
	Displays when the battery is fully charged. Blinks when the battery level is low.
	Displays when the line is in use. Blinks when there is an incoming call.
	Displays when you have new voicemail messages*.
	Displays when you have new missed calls, or the call log is being viewed.
	Displays when the phonebook is accessed.
	Displays when the alarm is set.
	Displays when handset ringer is turned off.
	Displays when the handset is registered and within range of the base station. Blinks when the handset is out of range or is searching for a base.
	Displays when the answering machine is on. Flashes slowly when there are new answering machine message(s).
	Displays when the handset is in speaker mode.
	Turns on when confirmation of selection or programming is available.
	Turns on during phonebook editing mode to delete the last digit. Turns on during menu mode when you can return to the previous state or previous step.

\*You must subscribe to Voicemail service or Caller ID from your network providers for this feature to work. You may need to pay a subscription fee.

### 6.3 Corded Base Station (see P3 and P6)


















#	Icon	Meaning
12		Press to go back to the previous message during message playback.
13		During a call, press to mute the microphone and press again to resume conversation. Press to cancel an action. During pre-dialling or number editing, press to delete the last digit entered. During number editing, press and hold to delete all digits.
14		During a call, press to send a Flash signal for network services.
15		In standby mode, press to access the Phonebook.
16		Hookswitch : press to end a call.
17		In standby mode, press and hold to playback message on the answering machine. Press to stop playback.
18		During message playback, press to skip to the next message.
19		In standby mode, press and hold to set date and time. In settings mode, press to confirm a setting. In standby mode, press to access the call log (CID).
20		In standby mode, press to enter the redial list.
21		When dialling, press and hold to add a dialling pause. In standby mode, press and hold to turn the ringer On/Off.
22		In standby mode, press and hold to switch the key lock on or off.
23		Press to make or receive a call in speaker mode.
24		In standby mode, press to adjust ring volume. During a call, press to adjust the speaker volume. Press to browse through the phonebook or call log.
25		Press to find / page all registered handsets. Press again to turn off the page signal. Press and hold to start registration process.

#### Important:






- In the event of a mains power failure, the cordless handsets will not work, and the display on the corded base will be off, but the corded handset can still be used to make or receive calls.
- The corded base will still ring if there is an incoming call, and the call can be answered with the corded handset, but there will be a delay of up to 5 seconds after picking up the handset before the handset becomes active and you can start a conversation.

- If you want to make a call when the mains power is off, pick up the corded handset and wait for approximately 5 seconds until you hear the dial tone. Then dial the number you want to call. (The phonebook, call log and redial memories will not be accessible when there is no mains power to the base.)

#### 6.4 Base Station Display (see P4)

<b>AN ON</b>	Displays when the answering machine is On.
<b>AN OFF</b>	Displays when the answering machine is Off.
	Displays when the microphone is muted.
	Displays when the line is in use. Flashes when there is an incoming call.
	Flashes when you have a new voicemail message. (This is network service)
	Displays when you have new missed calls, or the call log is being viewed.
	Displays when the phonebook is accessed.
	Displays when the keypad is locked.
	Displays when the base unit is in speakerphone mode.
	Displays when the base unit ringer is turned off.
	Flashes slowly when there are new answering machine message(s). Flashes quickly when the answering machine is full. Displays when all answering machine messages have been read.
	Phonebook and Call Log record number indicator.
	Turns on when there are more digit(s) on the left for display. Press  /OK/  to view more digits on the left.
	Time/date display. The time is displayed in 24-hours format and the date in DD/MM format.
	Turns on when there are more digit(s) on the right for display. Press  /OK/  to view more digits on the right.

#### 6.5 Menu Map and Menu Navigation

- From the home screen, press /OK to access **"PHONEBOOK"**, the first option in the Main Menu list.
- Press  or  to go to other options in the menu list.
- Press /OK to enter a sub-menu or function.
- Press /OK to go back to the previous level.



- Press  to cancel the current operation and return to the home screen.

**Note:**

If you do not press any key on the handset for 15 seconds, the display will automatically return to standby.

## 6.6 Text and Number Entry


You can enter text via the keypad, by using repeated presses of the alphanumeric keypad. This should be used when storing a name in the phonebook or renaming your handset.

For example, to enter the name **Tom**:

<b>T</b>	Press <b>8</b> once
<b>O</b>	Press <b>6</b> three times
<b>M</b>	Press <b>6</b> once

In editing mode, a cursor is displayed to indicate the current text entry position. It is positioned at the right of the last character entered.

**Writing Tips:**

- Once a character is selected, the cursor will move to the next position after a short pause.
- Press  to delete the last letter or number.

## 6.7 Character Map

Key	1st press	2nd press	3rd press	4th press	5th press	6th press
<b>1</b>	Space	1	_	(	)	*
<b>2</b>	A	B	C	2		
<b>3</b>	D	E	F	3		
<b>4</b>	G	H	I	4		
<b>5</b>	J	K	L	5		
<b>6</b>	M	N	O	6		
<b>7</b>	P	Q	R	S	7	
<b>8</b>	T	U	V	8	?	
<b>9</b>	W	X	Y	Z	9	
<b>0</b>	0	-	/	\	#	+
<b>*</b>	*					
<b>#</b>	#					

## 7 HANDSET & BASE CONNECTION

- When purchased, all handsets are already registered to the base unit and should link to it when they are all powered up.
- To use your cordless handset and base unit together, you must be able to establish a radio link between them. The signal between the handset and the base unit is in accordance with the normal standards for a DECT phone: Maximum range up to 300 metres outdoors or 50 metres indoors. Be aware that:
  - > Large metal objects, such as refrigerators, mirrors or filing cabinets, between the handset and the base unit may block the radio signal.
  - > Solid structures, such as walls, may reduce the signal strength.
  - > Electrical equipment may cause interference and/or affect the range.
- Do not place the base unit close to another telephone, TV or audio equipment - it may cause interference.
- Putting the base unit as high as possible ensures the best signal.
- **Out of Range** warning. If you hear a warning tone during a call, and/or the sound in the earpiece becomes faint or distorted, you may be going out of range of the base unit. Move nearer to the base unit within 20 seconds; otherwise the line may be cut off.

## 8 USING YOUR CORDLESS HANDSET

### 8.1 Make a Call

#### 8.1.1 Pre-dialling

- Enter the phone number (maximum 24 digits).
- If you make a mistake, press  $\curvearrowright/\boxtimes$  to delete the last entered number.
- Press  $\text{C}_\ast$  to dial the phone number.

#### 8.1.2 Direct Dialling

- Press  $\text{C}_\ast$ .
- Dial the number (maximum 24 digits).

#### 8.1.3 Call from the Redial List

- Press  $\text{C}_\bullet$  key in standby mode.
  - > The last number dialled is displayed.
- Press  $\Delta/\nabla$  to select the desired entry in the redial list and then press  $\text{C}_\ast$  to dial out the selected redial number.




#### 8.1.4 Call from the Call Log

- Press  $+/\text{P}/\Delta$  in standby mode.
- Press  $\Delta/\nabla$  to select the desired entry in the call log and then press  $\text{C}_\ast$  to dial out the selected call log number.



**Note:**

You need to subscribe to Caller Line Identification service to be able to see the caller's number or name in the call log.

**8.1.5 Call from the Phonebook**

- Press  key in standby mode.
- Press  to select the desired entry in the phonebook and then press  to dial out the selected phonebook number.

**8.2 Answer and End a Call**

- When the phone rings, press .
- To end a conversation, press .

**Warning:**

When the handset is ringing, please do not hold it too close to your ear as the volume of the ringing tone may damage your hearing.

**Note:**


You can simply place the handset back on its base station or charger pod to end the call. Make sure that you have not deactivated the **Auto hang-up** feature.

**8.3 Handset Speakerphone**

During a call, you can press  to alternate between hands-free speakerphone and handset earpiece.


**8.4 Adjust Earpiece Volume**

There are 3 levels of earpiece volume.

- During a call, press  to select from **"VOLUME 1"** to **"VOLUME 3"**.
  - > The current setting is shown.
  - > When you end the call, the setting will remain at the last selected level.

**8.5 Adjust Speaker Volume**

There are 5 levels of speaker volume.

- During a call, press  to select from **"VOLUME 1"** to **"VOLUME 5"**.
  - > The current setting is shown.
  - > When you end the call, the setting will remain at the last selected level.


**8.6 Mute/Unmute the Microphone**

When the microphone is muted, the handset displays **"MUTE ON"**, and your caller cannot hear you.

- During a call, press  to turn on/off the microphone.


**8.7 Paging**

The paging feature enables you to locate a missing handset if the handset is in range and contains charged batteries.

- Press  under the base unit.
  - > All the registered handsets that are in range will start to ring.

You can stop the paging by pressing any key on the handset or the  under the base unit again.

## 8.8 Switching the Handset On/Off

- Press and hold  for more than 2 seconds to switch the handset on or off in standby mode.
  - > The display will show **"SEARCHING..."** until the handset finds the base.

### Note:



You can switch the handset off to save battery life, if the handset is not on the base or a charger pod and you do not want to use it for a while.

### Important:

When the handset is OFF, it cannot be used for making calls including emergency calls. It will not ring when there is an incoming call. To answer a call, you will need to switch it back on and it may take some time for the handset to re-establish a radio link with the base unit.

## 8.9 To Lock/Unlock the Keypad

You can lock the keypad to avoid making calls or pressing the keys accidentally.

- In standby mode, press and hold  for 2 seconds to lock the keypad.
  - > The handset displays **"KEYS LOCKED"**.
- To turn the keypad lock off, press and hold  again.

### Note:



Incoming calls can still be answered even if the keypad is locked.

## 8.10 Make an Internal Call

The system allows an intercom call between two handsets registered to the same telephone base, or a cordless handset and the corded handset. It also allows you to transfer external calls from one handset to another, and set up a 3-way conference with two handsets and an external call.

If you try to make a call while another handset is already on an external call, you will hear a busy tone for a few seconds before the display returns to standby.

## 8.11 Initiate an Intercom Call to the Corded Base

- In standby mode, press INT.
  - > Intercom with the corded base is established immediately if there is only one registered cordless handset.
  - > If there are more registered cordless handsets, the handset numbers which are available for intercom will be displayed. Press 0 to call the corded base.
- Press  or pick up the corded handset from the corded base to answer the internal call, where both internal callers can talk.
- To end the intercom call, press  on the corded base or return the corded handset to the cordless base.

### Note:

If there is no answer from the corded base, or you wish to cancel the intercom call before it is answered, press INT to return to the external call.

## 8.12 Initiate an Intercom Call with another Registered Cordless Handset

- In standby mode, press INT.
  - > The handset numbers which are available for intercom will be displayed.
- Press the handset number you wish to call, or press  to call all handsets, including the corded base.

- Press  $\text{C}_a$  on a called handset to answer the internal call, where both internal callers can talk.
- To end the intercom call, press  $\text{D}$  on either handset.

**Note:**

- You can cancel the intercom call before it is answered by pressing **INT** or  $\text{D}$  on the originating handset.
- If there is no answer from the called handset or corded base within one minute, the paging will be cancelled automatically.

### 8.13 Answer an External Call during an Intercom Call

You will hear an alert tone when you receive an incoming external call during an intercom call, and you can choose from the following options:

- Press  $\text{D}$  to cancel the intercom call and let the corded base and cordless handsets receive normal incoming ringing.
- Press  $\text{C}_a$  to answer the incoming call and end the intercom call.
- Press **INT** to answer the incoming call and put the intercom call on hold.
- When the incoming call is connected and the intercom call is on hold, press and hold **INT** to start a three-party conference call with both the incoming and the intercom parties.
- When one handset is connected to an external call, you can press  $\text{C}_a$  on another handset to enter into a three-party conference call directly.

### 8.14 Initiate an Intercom during a Call

You can intercom with another system handset or the corded base during a call, or invite another system handset or the corded base to join in a conference call with you and the external caller.

- During the call, press **INT** to put the external call on hold.
  - > Intercom with the corded base is established immediately if there is only 1 registered cordless handset.
  - > If there are more than 2 registered cordless handsets, the handset numbers which are available for intercom will be displayed.
- Press the handset number you wish to call, press 0 to call the corded base, or press  $\text{*}/\text{A}$  to call all handsets.

**Note:**

If there is no answer from the called handset or the corded base, or you wish to cancel the intercom call before it is answered, press **INT** to return to the external call.

- Press  $\text{C}_a$  on the called handset or pick up the corded handset from the corded base to answer the internal call, where both internal callers can talk.
- When the intercom call is connected, you can choose from the following options on the originating handset:
  - > Press and hold **INT** for 2 seconds to connect both handsets to the call in conference mode.
  - > Press  $\text{D}$  on either cordless handset or return the corded handset to the corded base to terminate the intercom, and leave the external call connected to the remaining handset.

### 8.15 Transfer an External Call to another Handset

- During the call, press **INT** to put the external call on hold.
  - > Intercom with the corded base is established immediately if there is only 1 registered cordless handset.

- > If there are more than 2 registered cordless handsets, the handset numbers which are available for intercom will be displayed.
- > Press the handset number you wish to call, press 0 to call the corded base, or press **\*/☎** to call all handsets.

**Note:**

If there is no answer from the called handset or corded base, or you wish to cancel the intercom call before it is answered, press **INT** to return to the external call.

- Press **C** on the called handset or pick up the corded handset from the corded base to answer the internal call, where both internal callers can talk.
- Press **Ⓜ** on the originating handset to transfer the external call to the called handset or corded base.
  - > The external call is transferred.

## 9 USING YOUR CORDED BASE

### 9.1 Set Date & Time using the Corded Base

If you subscribe to Caller Display, the time and date settings should be updated automatically from the network when you receive a call. The time and date can also be set from a cordless handset. Using the cordless base, you can set the date in DD/MM format and the time in 24-hours format.

- In standby mode, press and hold **Ⓞ/OK/☎** to enter date & time settings.
  - > **--:-- --D / --M** is displayed.
- Enter the current time, followed by the date. If you make a mistake, press **C** to delete the last digit entered.
- Press **Ⓞ/OK/☎** to confirm the date and time settings.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.2 Make a call

#### 9.2.1 Pre-dialling

- In standby mode, enter the phone number (maximum 24 digits).
- If you make a mistake, press **C** to delete the last digit entered.
- Pick up the corded handset from the base unit or press **☎** to dial the number.
- When you complete the call, return the handset to the corded base unit or press **☎**.

#### 9.2.2 Direct dialling

- Pick up the corded handset from the base unit or press **☎**.
- Listen for the dial tone and then enter the phone number.
- When you complete the call, return the handset to the corded base unit or press **☎**.

### 9.3 Adjust Earpiece or Speaker Volume

There are 5 volume levels.

During a call, press **+** or **-** to select from L1 to L5.

- > The current setting is shown.
- > When you end the call, the setting will remain at the last selected level.


## 9.4 Set Ringer Volume

You can set the ringer volume on the corded base from L0 (ringer off) to L5.


- In standby mode, press + or - to select the desired setting (each volume level will play as it is select).

### Note:


The corded base will ring at the selected volume level when it receives an incoming call.

If you set ringer volume to L0,  will appear on the LCD and the corded base will not ring when it receives an incoming call.

## 9.5 Turn off Ringer

- In standby mode, press and hold # to turn off ringer.
  - >  is displayed on the LCD.
- To turn the ringer back on, press and hold # again.




## 9.6 Lock/Unlock the Keypad

- In standby mode, press and hold \* to lock the keypad.
  - >  is displayed on the LCD.
- To unlock the keypad, press and hold \* again.

### Note:




Incoming calls can still be answered even if the keypad is locked.

## 9.7 Mute/Unmute the Microphone


- During a call, press  to turn off the microphone.
  - >  is displayed.
- To unmute the microphone, press  again.

## 9.8 Initiate an Intercom Call from the Corded Base to a Cordless Handset

The system allows an intercom call between the corded base and another registered cordless handset.


- Pick up the corded handset from the corded base or press .
- Press  at the bottom of the corded base.
  - > All registered cordless handsets will start to ring.
- Press  on any handset to intercom with the corded base.
  - > The paging tone on all handsets and the corded base will stop.



### Note:

1. You can cancel the intercom call before it is answered by pressing  at the bottom of the corded base.
2. If there is no answer from the cordless handset within one minute, the paging will be cancelled automatically.


## 9.9 Answer an External Call during an Intercom Call on the Corded Base

You will hear an alert tone when you receive an incoming external call during an intercom call on your corded base, and you can choose from the following options:


- Replace the corded handset onto the corded base or press  to end the intercom call. The base will start ringing and you can answer the incoming call like a normal call.



- Press  at the bottom of the corded base to put the intercom call on hold and answer the incoming call. Then you can press and hold  to set up a conference call between all three parties, or you can end the call on the corded handset, which will transfer the incoming call to the other intercom handset.

### 9.10 Transfer an External Call from the Corded Base to a Cordless Handset

- During the call, press  at the bottom of the corded base to put the external call on hold.
  - > Intercom is established immediately with all registered cordless handsets.


#### Note:

If there is no answer from the cordless handset, or you wish to cancel the intercom call before it is answered, press  at the bottom of the corded base to return to the external call.


- Press  on the cordless handset to answer the internal call, where both internal callers can talk.
- Return the corded handset to the corded base or press  to transfer the external call to the cordless handset.



### 9.11 Initiate a Conference Call during a Call on the Corded Base

You can establish a 3-way conference by inviting another cordless handset to join in a conference call with you and the external caller.

- During the call, press  at the bottom of the corded base to put the external call on hold.
  - > Intercom ringing starts immediately with all registered cordless handsets.


#### Note:

If there is no answer from the cordless handset, or you wish to cancel the intercom call before it is answered, press  at the bottom of the corded base to return to the external call.




- Press  on the cordless handset to answer the internal call, where both internal callers can talk.
- When the intercom call is connected, press and hold  at the bottom of the corded base for 2 - 3 seconds to connect the call in conference mode.

### 9.12 Call from the Redial List


The corded base stores only the last number dialled.

- In standby mode, press  on the corded base.
  - > The last number dialled is displayed.
- Press  or lift up the handset from the corded base.
  - > The number will be dialled out automatically.

### 9.13 Store a pre-dial number to the Phonebook on the Corded Base

- In standby mode, enter the pre-dial number.
- Press and hold .
  - > The pre-dial number is displayed.
- Press /OK/ to save the pre-dial number into the phonebook.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.14 Store a number from the Redial List to the Phonebook on the Corded Base

- In standby mode, press  on the corded base.
  - > The last number dialled is displayed.
- Press and hold .



- > The redial number remains on the screen, but with a flashing cursor at the end.
- > To modify the redial number, press + or - to move the cursor and use C to delete digits.
- Press /OK/ to save the redial number into the phonebook.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.15 Access the Phonebook

The corded base can store up to 30 phonebook entries. Each phonebook entry can have a maximum of 24 digits for the phone number. However, you cannot store the names of your contacts on the phonebook.

- In standby mode, press to view the first record on the phonebook.
- Press + or - to scroll through the list of entries in the phonebook.
  - > #01 to #30 is displayed on the top right of the LCD to indicate the record number, where #01 represents the first record on the phonebook.

#### Note:

If the phone number is too long, press OK to view additional digits.  
Phonebook entries are stored in LAST IN, FIRST OUT order.

### 9.16 Store a Number to the Phonebook

- In standby mode, press and hold .
- Enter the telephone number. If you make a mistake, press C to delete the last digit entered.
- Press OK to confirm.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.17 Modify a Phonebook Entry on the Corded Base

- In standby mode, press .
  - > The first record in the phonebook is displayed.
- Press + or - to select the desired entry in the phonebook.
- Press and hold .
  - > The phone number is displayed.
- Press C to delete the last digit or press and hold C to delete all the digits.
- Enter the telephone number and press OK to confirm.
  - > A confirmation tone is played and the corded base returns to standby mode.


#### Note:

If you press and hold C to delete all digits, and then press C again, the corded base will return to standby mode, and the phone number will not be deleted or modified. You need to repeat the above steps to modify the phone number.

### 9.18 Delete a Phonebook Entry

- In standby mode, press and hold .
  - > The first record in the phonebook is displayed.
- Press + or - to select the desired entry in the phonebook.
- Press C.
  - > ---- is displayed.
- Press OK to confirm.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.19 Delete All Phonebook Entries on the Corded Base

- In standby mode, press .
  - > The first record in the phonebook is displayed.
- Press and hold C.
  - > ----- is displayed.
- Press OK to confirm and delete all entries.
  - > A confirmation tone is played and the corded base returns to standby mode.


### 9.20 Access the Call Log

If you have subscribed to the Calling Line Identification (CLI) service with your network service provider, the phone number of your caller will appear on the handset display when there is an incoming call and then stored in your Call Log.

The corded base can store up to 20 call log entries. Each call log entry can have a maximum of 24 digits for the phone number.

#### Note:


If the call is from someone whose number is unavailable, withheld or if you have not subscribed to Caller Line Identification service, then only the date and time of the call will be displayed.

- In standby mode, press .
  - > The first record in the call log is displayed along with the date and time of the call.
  - > #01 on the top right of the LCD indicates that this is the first record on the call log.
- Press + or - to browse through the call log.


#### Note:

If the caller's number is too long, press OK to view additional digits.



### 9.21 Delete a Call Log Entry

- In standby mode, press .
- Press + or - to select the desired entry in the call log.
- Press C.
  - > ---- is displayed.
- Press OK to confirm.
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.22 Delete All Call Log Entries on the Corded Base

- In standby mode, press .
  - > The first record in the call log is displayed along with the date and time of the call.
- Press and hold C.
  - > ----- is displayed.
- Press OK to confirm and delete all entries from the base call log. (None will be deleted from any cordless handset call logs.)
  - > A confirmation tone is played and the corded base returns to standby mode.

### 9.23 Save a Call Log Entry into the Phonebook on the Corded Base





- In standby mode, press .
- Press + or - to select the desired entry in the call log.
- Press and hold .
  - > The phone number is displayed.

- Press OK to confirm.
  - > A confirmation tone is played and the base returns to standby mode.

## 9.24 Answering Machine Operations

When a new message is recorded on the answering machine, the base display flashes "o#o 01" (or 02 if there are 2 messages, etc.), or if the memory is full it flashes "FULL".









You can use the answering machine keys on the corded base to access some of the answering machine functions.

12		During message playback, press to repeat the current message, and press twice to skip back to the previous message.
13		Press to delete the current message.
17		Press and hold to playback messages in standby mode. During message playback, press to stop playback and return to standby mode.
18		During message playback, press to skip to the next message.

## 10 DIRECT ACCESS MEMORY ON A CORDLESS HANDSET






There are 2 direct access memories (Keys 1 & 2) in addition to the phonebook memory. A long press on the keys in standby mode will automatically dial the stored phone number.

### 10.1 Add Direct Access Memory to a Cordless Handset

- From the home screen, press /OK.
- Press /OK again to select "PHONEBOOK".
- Press  to "DIRECT MEM." and then press /OK to select.
- Press  to "KEY 1" or "KEY 2" and then press /OK to select.
  - > "NO NUMBER" is displayed if it is empty. Otherwise, the stored name is displayed.
- Press /OK to enter the menu options.
- Press /OK again to select "EDIT NUMBER".
  - > "ENTER NAME" is displayed if it is empty. Otherwise, the stored name is displayed.

#### Note:

If the main phonebook is already full, "MEMORY FULL" is displayed, and you cannot store or edit a direct memory until a phonebook entry has been deleted.

- Enter the name of the contact and press /OK.
  - > If you make a mistake, press  to delete the last character entered.
  - > "ENTER NUMBER" is displayed. Otherwise the stored number is displayed.
- Enter the number of your contact and press /OK.
  - > If you make a mistake, press  to delete the last digit entered.
  - > A confirmation tone is played.
- Press  to return to standby mode.

## 10.2 Delete Direct Access Memory from a Cordless Handset

- From the home screen, press /OK.
- Press /OK to select "PHONEBOOK".
- Press to "DIRECT MEM." and then press /OK to select.
- Press to "KEY 1" or "KEY 2" and then press /OK to select.
  - > "NO NUMBER" is displayed if it is empty. Otherwise, the stored name is displayed.
- Press /OK to enter the menu options.
- Press to "DELETE" and then press /OK to select.
  - > "DELETE?" is displayed.
- Press /OK again to confirm.
  - > A confirmation tone is played.
- Press to return to standby mode.

## 11 PHONEBOOK ON THE CORDLESS HANDSET

Each cordless handset can store up to 100 phonebook entries. Each phonebook entry can have a maximum of 24 digits for the phone number and 12 characters for the name.

### 11.1 Store a Phonebook Entry on your Cordless Handset

- From the home screen, press /OK.
- Press /OK again to select "PHONEBOOK".
- Press /OK to select "NEW ENTRY".
- Enter the name of the contact (maximum 12 characters) using the keypad.
  - > If you make a mistake, press to delete the last character entered.
- Press /OK to confirm the name entry.
- Enter the number of the contact (maximum 24 digits) using the keypad.
  - > If you make a mistake, press to delete the last digit entered.
- Press /OK to confirm.
  - > A confirmation tone is played.
- Press to return to standby mode.

#### Note:

You cannot store a new phonebook entry when the memory is full. In this case, you have to delete existing entries to make space for new ones.

### 11.2 Access the Phonebook on your Cordless Handset

- From the home screen, press /△ to open the phonebook list.
  - > Alternatively, from the home screen, you can press /OK twice to select "PHONEBOOK", then to "LIST" and /OK again to open the phonebook list.
- Press to scroll through the list of entries
  - > The phonebook entries are listed in alphabetical order.
- Press /OK to view the details of the selected entry.
- Press to return to standby mode.

#### Note:

Instead of pressing to browse the phonebook entries, you can press the numeric key corresponding to the first letter of the entry you wish to locate.

For example, pressing 2 will show the first entry starting with A. Pressing 2 again will show the first entry starting with B, and so on..., and then press  $\Delta/\nabla$ , if necessary, to find the entry you want.

### 11.3 Modify a Phonebook Entry on your Cordless Handset

- From the home screen, press  $\mathbb{E}/\text{OK}$ .
- Press  $\mathbb{E}/\text{OK}$  again to select **"PHONEBOOK"**.
- Press  $\Delta/\nabla$  to **"EDIT ENTRY"** and then press  $\mathbb{E}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select an entry you wish to modify and then press  $\mathbb{E}/\text{OK}$ .
  - > The current name is displayed.
- Edit the name using the keypad. Press  $\curvearrowright/\boxtimes$  to delete characters.
- Press  $\mathbb{E}/\text{OK}$  to confirm.
- Edit the number and then press  $\mathbb{E}/\text{OK}$  to confirm.
  - > A confirmation tone is played.
- Press  $\curvearrowright$  to return to standby mode.

### 11.4 Delete a Phonebook Entry on your Cordless Handset

- From the home screen, press  $\mathbb{E}/\text{OK}$ .
- Press  $\mathbb{E}/\text{OK}$  again to select **"PHONEBOOK"**.
- Press  $\Delta/\nabla$  to **"DELETE"** and then press  $\mathbb{E}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select an entry you wish to delete and then press  $\mathbb{E}/\text{OK}$ .
  - > **"DELETE?"** is displayed.
- Press  $\mathbb{E}/\text{OK}$  again to confirm.
  - > A confirmation tone is played.
- Press  $\curvearrowright$  to return to standby mode.

### 11.5 Delete All Entries from the Phonebook List on your Cordless Handset

- From the home screen, press  $\mathbb{E}/\text{OK}$ .
- Press  $\mathbb{E}/\text{OK}$  again to select **"PHONEBOOK"**.
- Press  $\Delta/\nabla$  to **"DELETE ALL"** and then press  $\mathbb{E}/\text{OK}$  to select.
  - > **"DELETE?"** is displayed.
- Press  $\mathbb{E}/\text{OK}$  again to confirm.
  - > A confirmation tone is played.
- Press  $\curvearrowright$  to return to standby mode.

## 12 CALLER DISPLAY ON THE CORDLESS HANDSET

If you have subscribed to the Calling Line Identification (CLI) service with your network service provider, the phone number of your caller will appear on the handset display when there is an incoming call and then stored in your Call Log.

If the caller's number is stored in your phonebook along with a name, the name will appear on the handset display when the call is received and in the Call Log.

### Note:

If the call is from someone whose number is unavailable, the handset will display **"UNAVAILABLE"** when you receive the call.

If the call is from someone whose number is withheld, the handset will display **"WITHHELD"** when you receive the call.

If you have not subscribed to Caller Line Identification service, the handset will display **"UNKNOWN"** when you receive the call.

## 12.1 Call Log on your Cordless Handset

The Call Log stores the last 40 external calls, whether or not you have answered the call. Only the most recent call is saved if there are repeat calls from the same number. When the Call Log is full, the next new call will replace the oldest entry.

### 12.1.1 Access the Call Log on your Cordless Handset

- From the home screen, press **+ / 👤 / ▲**.
- Press **▲ / ▼** to browse through the call list.
  - > The calls are displayed in chronological order with the most recent call at the top of the list.

### 12.1.2 Save a Call Log Entry into the Phonebook on your Cordless Handset

- From the home screen, press **+ / 👤 / ▲**.
- Press **▲ / ▼** to select an entry and then press **☰ / OK**.
- Press **☰ / OK** again to select **"SAVE NUMBER"**.
- Enter the name of the contact (maximum 12 characters) and then press **☰ / OK** to save.
  - > A confirmation tone is played.
- Press **⏪** to return to standby mode.

### 12.1.3 Delete a Call Log Entry on your Cordless Handset

- From the home screen, press **+ / 👤 / ▲**.
- Press **▲ / ▼** to select an entry and then press **☰ / OK**.
- Press **▲ / ▼** to **"DELETE"** and then press **☰ / OK** to select.
  - > **"DELETE?"** is displayed.
- Press **☰ / OK** again to confirm.
  - > A confirmation tone is played.
- Press **⏪** to return to standby mode.

### 12.1.4 Delete All Entries in the Call Log on your Cordless Handset

- From the home screen, press **+ / 👤 / ▲**.
- Press **☰ / OK**.
- Press **▲ / ▼** to **"DELETE ALL"** and then press **☰ / OK** to select.
  - > **"DELETE?"** is displayed.
- Press **☰ / OK** again to confirm and delete all entries from this handset's call log. (None will be deleted from the call log on the base or any other cordless handsets.)
  - > A confirmation tone is played.

## 12.2 Redial List on your Cordless Handset

The redial list stores the last 5 numbers dialled from that handset. A maximum of 24 digits can be displayed for each entry.

### 12.2.1 Access the Redial List on your Cordless Handset

- From the home screen, press **📞**.
- Press **▲ / ▼** to browse the redial list.
  - > The last dialled number will appear first in the redial list.
  - > If the number has more than 12 digits, press **↶ / ✖** to see the other digits.
  - > If there are no numbers in the redial list, **"NO NUMBER"** is displayed.

### 12.2.2 Save a Redial Number into the Phonebook on your Cordless Handset

- From the home screen, press **●**.
- Press **△/▽** to select an entry and press **☐/OK**.
- Press **☐/OK** again to select **"SAVE NUMBER"**.
- Enter the name of the contact (maximum 12 characters) and then press **☐/OK** to save.
  - > A confirmation tone is played.
- Press **⌂** to return to standby mode.

### 12.2.3 Edit a Redial Number on your Cordless Handset

- From the home screen, press **●**.
- Press **△/▽** to select an entry and then press **☐/OK**.
- Press **△/▽** to **"EDIT ENTRY"** and then press **☐/OK** to select.
- Edit the number and press **☐/OK** to confirm.
  - > A confirmation tone is played.
- Press **⌂** to return to standby mode.

### 12.2.4 Delete a Redial Number on your Cordless Handset

- From the home screen, press **●**.
- Press **△/▽** to select an entry and then press **☐/OK**.
- Press **△/▽** to **"DELETE"** and then press **☐/OK** to select.
  - > **"DELETE?"** is displayed.
- Press **☐/OK** again to confirm.
  - > A confirmation tone is played.
- Press **⌂** to return to standby mode.

### 12.2.5 Delete All Entries from the Redial List on your Cordless Handset

- From the home screen, press **●**.
- Press **☐/OK**.
- Press **△/▽** to **"DELETE ALL"** and then press **☐/OK** to select.
  - > **"DELETE?"** is displayed.
- Press **☐/OK** again to confirm.
  - > A confirmation tone played.

## 13 CLOCK AND ALARM SETTINGS ON YOUR CORDLESS HANDSET

### 13.1 Date and Time Settings

If you have subscribed to the Calling Line Identification (CLI) service, the time and date settings will be automatically updated by the network when you receive an incoming call, but you may still need to set the correct year.

You can also set the date and time manually.

- From the home screen, press **☐/OK**.
- Press **△/▽** to **"CLOCK&ALARM"** and then **☐/OK** to select.
- Press **☐/OK** again to select **"DATE/TIME"**.
  - > The last stored date is displayed, with the third digit of the year flashing.
- Enter the current date and press **☐/OK** to confirm.
  - > Enter 03 May 2012 as [1], [2], [0], [5], [0], [3].
  - > If you make a mistake, press **↵/✕** to delete the last digit entered.

- Enter the current time and press **⏏/OK** to confirm. The default time format is **"24 HOURS"**.
  - > For 24-hour format, enter 1:30pm as [1], [3], [3], [0].
  - > For 12-hour format, enter the time and then press **▲/▼** to select AM or PM.
  - > If you make a mistake, press **↶/⊗** to delete the last digit entered.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

### 13.1.1 Change the Time Format on your Cordless Handset

The time can be displayed either as 12-hour or 24-hour. The default setting is **"24 HOURS"**.

- From the home screen, press **⏏/OK**.
- Press **▲/▼** to **"CLOCK&ALARM"** and then **⏏/OK** to select.
- Press **▲/▼** to **"SET FORMAT"** and then press **⏏/OK** to select.
- Press **⏏/OK** again to select **"TIME FORMAT"**.
  - > The current setting is displayed.
- Press **▲/▼** to select **"12 HOURS"** or **"24 HOURS"** and then press **⏏/OK** to confirm.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

### 13.1.2 Change the Date Format on your Cordless Handset

The date can be displayed either as Month/Day or Day/Month. The default setting is **"DD/MM"**.

- From the home screen, press **⏏/OK**.
- Press **▲/▼** to **"CLOCK&ALARM"** and then **⏏/OK** to select.
- Press **▲/▼** to **"SET FORMAT"** and then press **⏏/OK** to select.
- Press **▲/▼** to **"DATE FORMAT"** and then press **⏏/OK** to select.
  - > The current setting is displayed.
- Press **▲/▼** to select **"DD/MM"** or **"MM/DD"** and then press **⏏/OK** to confirm.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

## 13.2 Alarm Settings on your Cordless Handset

An alarm can be set on a handset, to sound at a set time only once or repeated each day.

When an alarm is set, the alarm icon is shown on the handset display.

When the alarm time is reached, the handset will flash **"-ALARM-"** on the display and sound an alarm for 1 minute, at the same volume setting as the handset ringer. If the ringer is off, it will ring at volume setting 1. When the alarm rings, you can press any key on the handset to stop the ringing, even if the keylock is activated.

- From the home screen, press **⏏/OK**.
- Press **▲/▼** to **"CLOCK&ALARM"** and then press **⏏/OK** to select.
- Press **▲/▼** to **"ALARM"** and then press **⏏/OK** to select.
- Press **▲/▼** to an alarm option.
  - > **"OFF"**: Turn alarm off
  - > **"ON ONCE"**: The alarm sounds once at the set time.
  - > **"ON DAILY"**: The alarm sounds daily at the set time.
- Press **⏏/OK** to select the option.
- If **"ON ONCE"** or **"ON DAILY"** is selected, enter the desired hour and minute.
  - > Press **▲/▼** to select **"AM"** or **"PM"** if the time is in 12-hour format.
- Press **⏏/OK** to confirm the alarm setting.



>A confirmation tone is played.

- Press  $\text{Ⓜ}$  to return to standby mode.

### 13.2.1 Set the Alarm Tone on your Cordless Handset

You can select from 3 alarm melodies.

- From the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to "**CLOCK&ALARM**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to "**ALARM TONE**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select the desired alarm tone (each tone will sound as it is selected) and then press  $\text{Ⓜ}/\text{OK}$  to confirm.

>A confirmation tone is played.

- Press  $\text{Ⓜ}$  to return to standby mode.

## 14 PERSONAL SETTINGS ON YOUR CORDLESS HANDSET

Your phone comes with a selection of settings that you can change to personalise your phone to the way you like it to work.

### 14.1 Set the Ring Volume on your Cordless Handset

You can set the handset ringer volume from Level 1 to Level 4 or turn the ringer off.

- From the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to "**PERSONAL SET**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to "**HANDSET TONE**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\text{Ⓜ}/\text{OK}$  again to select "**RING VOLUME**".
- Press  $\Delta/\nabla$  to select the desired setting (each volume level will play as it is selected) and then press  $\text{Ⓜ}/\text{OK}$  to confirm.

>A confirmation tone is played.

- Press  $\text{Ⓜ}$  to return to standby mode.

#### Note:

Press and hold # to switch the ringer "**ON**" and "**OFF**" when the handset is in standby mode. The ringer off icon displays on the screen when ringer off feature is activated.

### 14.2 Set the Ring Tone on your Cordless Handset

You can select from 10 ringer melodies for both internal and external calls.

- From the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to "**PERSONAL SET**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to "**HANDSET TONE**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to "**RING TONES**" and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select the desired melody from 1 to 10 (each melody will play as it is selected) and then press  $\text{Ⓜ}/\text{OK}$  to confirm.

>A confirmation tone is played.

- Press  $\text{Ⓜ}$  to return to standby mode.

### 14.3 Set the Key Beep on your Cordless Handset

The handset emits a tone with each key press. You can choose to turn this tone on or off. The default setting is "**ON**".

- From the home screen, press **⏏/OK**.
- Press **△/▽** to **"PERSONAL SET"** and then press **⏏/OK** to select.
- Press **△/▽** to **"HANDSET TONE"** and then press **⏏/OK** to select.
- Press **△/▽** to **"KEY BEEP"** and then press **⏏/OK** to select.
- Press **△/▽** to select **"ON"** or **"OFF"** and then press **⏏/OK** to confirm.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

#### 14.4 Rename your Cordless Handset

You can personalise your handset by changing the name shown on the handset in standby mode.

- From the home screen, press **⏏/OK**.
- Press **△/▽** to **"PERSONAL SET"** and then press **⏏/OK** to select.
- Press **⏏/OK** to select **"HANDSET NAME"**.
  - > The current handset name is displayed.
- Press **↶/⊗** to delete the letters one by one and enter the new name (maximum 10 characters).
- Press **⏏/OK** to confirm.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

#### 14.5 Set the Display Language on your Cordless Handset

You can select different display languages.

- From the home screen, press **⏏/OK**.
- Press **△/▽** to **"PERSONAL SET"** and then press **⏏/OK** to select.
- Press **△/▽** to **"LANGUAGE"** and then press **⏏/OK** to select.
- Press **△/▽** to select your preferred language and then press **⏏/OK** to confirm.
  - > A confirmation beep is played.
- Press **⏏** to return to standby mode.

#### Note:

Once the display language is set, the handset will switch to display this language immediately

#### 14.6 Set Auto Hang-up on your Cordless Handset

This function enables you to end a call automatically by simply placing the handset back on the base unit or charging pod. By default, the Auto Hang up feature is **"ON"**.

- From the home screen, press **⏏/OK**.
- Press **△/▽** to **"PERSONAL SET"** and then press **⏏/OK** to select.
- Press **△/▽** to **"AUTO HANG-UP"** and then press **⏏/OK** to select.
- Press **△/▽** to select **"ON"** or **"OFF"** and then press **⏏/OK** to confirm.
  - > A confirmation tone is played.
- Press **⏏** to return to standby mode.

## 15 ADVANCED SETTINGS ON YOUR CORDLESS HANDSET

### 15.1 Cordless Handset Registration

#### Important:

When you purchase your phone system, all handsets are already registered to your base, so you do not need to register them. Handset registration is only necessary when you buy extra cordless handsets or if a cordless handset has become faulty.









You can register up to four handsets to one base station, with each handset's number (1 to 4) shown on its display.

#### Note:

Each handset can only be registered to one base.

You need to enter the Master PIN before you can register or unregister handsets. The default Master PIN is 0000.

### 15.2 Register Additional Cordless Handsets

- In standby mode, press and hold the key  under the corded base unit for approximately 5 seconds.
  - >  on the corded base will flash in Red for up to 1 minute, and the base will beep, while it is in registration mode.
- On the cordless handset, press /OK.
- Press  to **"ADVANCED SET"** and then press /OK to select.
- Press  to **"REGISTRATION"** and then press /OK to select.
  - > If no action is taken on the handset within 10 seconds, the registration procedure will be aborted. If this happens, repeat from step 1.
- Enter the Master PIN and then press /OK to confirm.







#### Note:

The default Master PIN is 0000.

- > **"WAITING"** flashes on the screen.
- > A confirmation tone is played to indicate successful registration, and the handset will return to standby mode, with its handset number displayed.
- > If no base is found with the entered PIN, error tones are played to indicate failed registration and the handset returns to standby mode. You will need to repeat from step 1 above.

### 15.3 Un-register your Cordless Handset

You can unregister the cordless handset you are using, or any other handset registered to the same base.

- From the home screen, press /OK.
- Press  to **"ADVANCED SET"** and then press /OK to select.
- Press  to **"UNREGISTER"** and then press /OK to select.
- Enter the Master PIN and then press /OK to confirm.

#### Note:

The default Master PIN is 0000.

- Press  $\Delta/\nabla$  to select the handset number to un-register and then press  $\text{■}/\text{OK}$  to confirm or press  $\text{Ⓢ}$  to cancel the un-registration procedure.  
> A confirmation tone is played to indicate successful un-registration.

#### 15.4 Change the Master PIN from your Cordless Handset

The Master PIN is used for registration/un-registration of the cordless handsets and for accessing the answering machine remotely. The default Master PIN number is 0000. The maximum length of the Master PIN is 8 digits.

##### Note:

If you forget your PIN code, you can reset it to its default 0000 using a handset Reset.

- From the home screen, press  $\text{■}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ADVANCED SET"** and then press  $\text{■}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to **"CHANGE PIN"** and then press  $\text{■}/\text{OK}$  to select.
- Enter the current Master PIN and then press  $\text{■}/\text{OK}$  to confirm.  
> The PIN will be shown as asterisks (\*) on the screen as you enter them.
- Enter the new PIN and then press  $\text{■}/\text{OK}$  to confirm.  
> A confirmation tone is played.

#### 15.5 Set the Auto Prefix on your Cordless Handset

You can set the phone to detect the start of a dialling number and replace it with another number. You can enter up to 5 digits for the number to be detected, which can be replaced with an auto prefix number of up to 10 digits.

- From the home screen, press  $\text{■}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ADVANCED SET"** and then press  $\text{■}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to **"AUTO PREFIX"** and then press  $\text{■}/\text{OK}$  to select.
- Press  $\text{■}/\text{OK}$  again to enter **"DETECT DIGIT"**.  
> The last stored detect number is displayed (if any).
- Enter the number you want to be detected (maximum 5 digits) and then press  $\text{■}/\text{OK}$  to confirm.  
> A confirmation tone is played.
- Press  $\Delta/\nabla$  to **"PREFIX"** and press  $\text{■}/\text{OK}$  to select.  
> The last stored prefix number is displayed (if any).
- Enter the number you want the detected number to be replaced with (maximum 10 digits) and then press  $\text{■}/\text{OK}$  to confirm.  
> A confirmation tone is played.
- Press  $\text{Ⓢ}$  to return to standby mode.

##### Note:

If the detect digit is not entered (blank), the prefix number will be automatically added to the pre-dial number after  $\text{C}_\text{a}$  is pressed.

For numbers starting with \*, # or P, the prefix number will not be added to the pre-dial number after  $\text{C}_\text{a}$  is pressed.

## 15.6 Change the Recall Time from your Cordless Handset

You may need to press R to send a Flash signal (also called Recall or Timed Break Recall) if you are connected to a PBX (Private Exchange) or use certain network features. You should normally leave the Recall Time at its default setting, Short (100ms), as this is the standard recall required in the UK telephone network. However, it can be changed to Medium (270ms) or Long (600ms) if your telephone is connected to a PBX that requires a different recall time.

- From the home screen, press **≡/OK**.
- Press **△/▽** to **"ADVANCED SET"** and then press **≡/OK** to select.
- Press **△/▽** to **"RECALL TIME"** and then press **≡/OK** to select.
- Press **△/▽** to select **"SHORT"**, **"MEDIUM"** or **"LONG"** and then press **≡/OK** to confirm.
  - > A confirmation tone is played.
- Press **Ⓜ** to return to standby mode.

## 15.7 Set the First Ring from your Cordless Handset

If you have subscribed to Caller Line Identification service and do not wish to hear the phone ring before the caller identification is displayed, you can set the **"FIRST RING"** to **"OFF"**.

- From the home screen, press **≡/OK**.
- Press **△/▽** to **"ADVANCED SET"** and then press **≡/OK** to select.
- Press **△/▽** to **"FIRST RING"** and then press **≡/OK** to select.
- Press **△/▽** to select **"ON"** or **"OFF"** and then press **≡/OK** to confirm.
  - > A confirmation tone is played.
- Press **Ⓜ** to return to standby mode.

## 15.8 Reset the Cordless Handset

You can reset your cordless handset to its default settings with this feature.

### Note:

Upon reset, all your personal settings, call log and redial list entries will be deleted and the phone will return to its default settings. However, your phonebook will remain unchanged after reset. Also, if you have an answering machine model, any recorded messages will remain unchanged, while all other settings will be reset.

- From the home screen, press **≡/OK**.
- Press **△/▽** to **"ADVANCED SET"** and then press **≡/OK** to select.
- Press **△/▽** to select **"RESET"** and then press **≡/OK** to select.
- Press **≡/OK** again to confirm.
  - > A confirmation tone is played and the unit is reset to its default settings.

## 16 OPERATING THE ANSWERING MACHINE ON YOUR CORDLESS HANDSET

Your phone includes a telephone answering machine that records unanswered calls when it is on. The answering machine can store up to 59 messages within the maximum recording time of approximately 30 minutes and each message can be up to 3 minutes long.

When the answering machine is on, calls are answered after the set **"RING DELAY"**.

If you have selected **"ANSW.&RECORD"** mode, the caller can leave you a message after hearing your announcement.

If you have selected **"ANSWER ONLY"** mode, the caller can only listen to your announcement but cannot leave you a message.

If the answering machine memory is full, **"MEMORY FULL!"** appears on the handset, and you will have to delete some messages before any new ones can be recorded.

### 16.1 Turning the Answering Machine On/Off

- From the home screen, press **☰/OK**.
- Press **△/▽** to **"ANSW MACHINE"** and then press **☰/OK** to select.
- Press **△/▽** to **"ANSW. ON/OFF"** and then press **☰/OK** to select.
- Press **△/▽** to select **"ON"** or **"OFF"** and then press **☰/OK** to confirm.
  - > A confirmation tone is played.
- Press **Ⓜ** to return to standby mode.

#### Note:

If the answering machine is off and the Master PIN is still set at its default 0000, the answering machine will not answer any incoming calls.

However, if the Master PIN has been changed, it will answer incoming calls after 10 rings to allow remote access.

### 16.2 Answer Mode

The phone comes with two pre-recorded outgoing messages (OGM) for the respective answer modes: **"ANSWER ONLY"** and **"ANSW. &RECORD"**.

By default, the answer mode is **"ANSW.&RECORD"**, which allows a caller to leave a message on the answering machine after hearing the announcement. This can be changed to **"ANSWER ONLY"** mode, which does not allow callers to leave any messages on the answering machine after hearing the announcement.

#### 16.2.1 Set Answer Mode

- From the home screen, press **☰/OK**.
- Press **△/▽** to **"ANSW MACHINE"** and then press **☰/OK** to select.
- Press **△/▽** to **"ANSWER MODE"** and then press **☰/OK** to select.
- Press **△/▽** to select **"ANSWER ONLY"** or **"ANSW.&RECORD"** and then press **☰/OK** to confirm.
  - > A confirmation tone is played.
- Press **Ⓜ** to return to standby mode.

### 16.3 Answering Machine Settings

#### 16.3.1 Set the Ring Delay

You can select the number of rings before the answering machine answers a call and starts playing the outgoing message (OGM). You can set the delay from 2 to 7 rings, or **"ECONOMY"**.

#### Important:

If your network voice messaging system (e.g. the 1571 service) is enabled, you must set your **"RING DELAY"** to less than 6 rings; otherwise the network service will answer all your calls before the answering machine of your telephone and prevent it from recording any messages.

- Using a cordless handset, from the home screen, press **☰/OK**.
- Press **△/▽** to **"ANSW MACHINE"** and then press **☰/OK** to select.
- Press **△/▽** to **"SETTINGS"** and then press **☰/OK** to select.

- Press /OK to select **"RING DELAY"**.
- Press / to select **"2 RINGS"** – **"7 RINGS"** or **"ECONOMY"** and then press /OK to confirm.
  - > A confirmation tone is played.
- Press to return to standby mode.

**Note:**

If you select **"ECONOMY"**, the answering machine will answer an incoming call on the fifth ring if you have no current new messages and on the third ring if you do.

When you call your answering machine to check messages, if it does not answer on the third ring, then you can hang up immediately, knowing that you have no new messages. This feature can save you the cost of a long-distance call when you check your messages remotely.

**16.3.2 Activate/Deactivate Remote Access**

- Using a cordless handset, from the home screen, press /OK.
- Press / to **"ANSW MACHINE"** and then press /OK to select.
- Press / to **"SETTINGS"** and then press /OK to select.
- Press / to **"REMOTE ACC."** and then press /OK to select.
- Press / to select **"ACTIVATE"** or **"DEACTIVATE"** and then press /OK to confirm.
  - > A confirmation tone is played.
- Press to return to standby mode.

**Note:**

Once the remote control access is activated, you can check the messages on your answering machine when you are away from home, by calling from another phone.

The Master PIN is used for accessing the answering machine remotely. If your answering machine is off, it will answer after 14 rings, so you can use the remote access feature to turn on your answering machine.

**16.3.3 Change the Voice Language**

You can select a different language for the answering machine's pre-recorded outgoing message.

- From the home screen, press /OK.
- Press / to **"ANSW MACHINE"** and then press /OK to select.
- Press / to **"SETTINGS"** and then press /OK to select.
- Press / to **"LANGUAGE"** and then press /OK to select.
- Press / to select your preferred language and then press /OK to confirm.
  - > A confirmation tone is played.
- Press to return to standby mode.

**16.4 Message Playback**

When there are new messages on the answering machine, the tape icon flashes on the handset screen.

- From the home screen, press /OK.
- Press / to **"ANSW MACHINE"** and press /OK to select.
- Press /OK to select **"PLAY"**.
  - > Your messages will automatically playback through the handset's speakerphone.
  - > Press to listen to your messages privately through the earpiece of your handset.
- During playback, press /OK to access the following options:

**REPEAT**

Repeat the currently playing message

<b>NEXT</b>	Play the next message
<b>PREVIOUS</b>	Play the previous message
<b>DELETE</b>	Delete the current message

- Press  $\text{Ⓜ}$  to return to standby mode.

## 16.5 Delete All Messages

### Note:

Only old messages can be deleted. New messages must be played before they can be deleted.

- From the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ANSW MACHINE"** and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select **"DELETE ALL"** and then press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\text{Ⓜ}/\text{OK}$  again to confirm.
  - >A confirmation tone is played.
- Press  $\text{Ⓜ}$  to return to standby mode.

## 16.6 Outgoing Message (OGM)

When the answering machine answers a call, the pre-recorded outgoing message is played to the caller unless you have recorded your own outgoing message.

The phone comes with two pre-recorded outgoing messages (OGM) for the respective answer modes: **"ANSWER ONLY"** and **"ANSW. & RECORD"**.

By default, the answer mode is **"ANSW.&RECORD"**, which allows a caller to leave a message on the answering machine after hearing the announcement. This can be changed to **"ANSWER ONLY"** mode, which does not allow callers to leave any messages on the answering machine after hearing the announcement.

### 16.6.1 Record a Personalised Outgoing Message

You can choose to replace the default OGM with your own personalised messages.

- From the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ANSW MACHINE"** and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to **"RECORD OGM"** and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select **"ANSWER ONLY"** or **"ANSW.&RECORD"** and then press  $\text{Ⓜ}/\text{OK}$  to confirm.
- Press  $\Delta/\nabla$  to **"RECORD OGM"** and press  $\text{Ⓜ}/\text{OK}$ .
  - >A confirmation tone is played.
- Speak into the handset to start recording your new outgoing message and press  $\text{Ⓜ}/\text{OK}$  again to end the recording.
  - >A confirmation tone is played.
- Press  $\text{Ⓜ}$  to return to standby mode.

### Note:

The maximum length of an outgoing message is 2 minutes.

### 16.6.2 Listen to an Outgoing Message

- Using a cordless handset, from the home screen, press  $\text{Ⓜ}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ANSW MACHINE"** and then press  $\text{Ⓜ}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to **"RECORD OGM"** and then press  $\text{Ⓜ}/\text{OK}$  to select.



- Press  $\Delta/\nabla$  to select **"ANSWER ONLY"** or **"ANSW.&RECORD"** and then press  $\text{☐}/\text{OK}$  to confirm.
- Press  $\text{☐}/\text{OK}$  to select **"PLAY"**.
  - > The outgoing message plays through the phone's speaker.
  - > Press  $\text{☐}$  if you wish to listen to the outgoing message privately over the earpiece.
- Press  $\text{☐}$  to return to standby mode.

### 16.6.3 Delete a Personal Outgoing Message

If you want to return to using the default OGM, simply delete your personal OGM.

- Using a cordless handset, from the home screen, press  $\text{☐}/\text{OK}$ .
- Press  $\Delta/\nabla$  to **"ANSW MACHINE"** and then press  $\text{☐}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to **"RECORD OGM"** and then press  $\text{☐}/\text{OK}$  to select.
- Press  $\Delta/\nabla$  to select **"ANSWER ONLY"** or **"ANSW.&RECORD"** and then press  $\text{☐}/\text{OK}$  to confirm.
- Press  $\Delta/\nabla$  to **"DELETE"** and press  $\text{☐}/\text{OK}$  to confirm.
  - > The default pre-recorded outgoing message is played.
- Press  $\text{☐}$  to return to standby mode.

## 16.7 Remote Access

The phone lets you listen to the messages on your answering machine, or otherwise operate your answering machine by calling in to your answering machine from another touch-tone phone. You need to enter a remote access code (same as your Master PIN) to access your answering machine remotely. The remote access code is used to prevent unauthorised access of your answering machine. Remote Access must be enabled if you want to use this feature.

### 16.7.1 Access the Answering Machine Remotely

- Dial your phone number from any touch-tone phone.
- When your answering machine answers your call and starts playing your outgoing message, press the  $\#/\text{P}/\text{☐}$  key.
  - > The outgoing message will stop playing.
- Enter your Remote Access Code (same as your Master PIN code) within 8 seconds using the numeric keypad on the touch-tone phone.
  - > Note that the answering machine will drop the call if you do not enter the Master PIN within 8 seconds.
- If the code is accepted, you will hear a confirmation tone.
- The answering machine will start to playback all the messages on your answering machine, beginning with new messages, or if there are no messages you will hear four beeps.
- Use the keypad on the touch-tone phone to carry out the following operations:

1	Repeat the previous message.
2	Start playing messages, or repeat the current message from the beginning.
3	Skip to the next message.
6	Delete the current message.
7	Turn on the answering machine in <b>"ANSW. &amp;RECORD"</b> mode.

<b>8</b>	Stop message playback.
<b>9</b>	Turn off the answering machine.

- When you have finished listening to your messages, simply hang up the phone to end.

**Note:**

If your answering machine is off but Remote Access is activated, the answering machine will answer your call after 14 rings and play the **"ANSWER ONLY"** outgoing message, so that you can access it remotely.

If you enter an incorrect Remote Access Code, you will hear a triple-beep error tone, and you will need to enter the code again. If you enter the wrong Remote Code twice consecutively, the call will end automatically.


## 17 TROUBLESHOOTING

### 17.1 ALWAYS check that:



- You have followed all the steps listed in the user guide to install and set up your telephone.
- All connectors are securely inserted into their sockets.
- Mains power for the base unit is switched on at the socket.
- The handset's batteries are correctly and securely installed and are sufficiently charged.

### 17.2 Everyday use

#### "I cannot make or answer calls"

- If the handset's display is blank, it may have been switched off. Press and hold  to switch it back on.
- Check that the corded base unit's mains power adapter is plugged in and power is switched on. The corded base unit needs mains power for normal operation of both the corded and cordless parts of the phone.
- Make sure that you are using the telephone line cable supplied with your phone. Other telephone line cables might not work.
- Move the cordless handset closer to the corded base unit.
- Check the Battery Level symbol on the cordless handset display. If it is low, put the cordless handset back on a charging pod to recharge the batteries.
- Switch off the power at the mains socket, wait for a short while and then switch it back on. This may solve the problem.

#### "I cannot make calls"

- If the cordless handset display shows **"KEYS LOCKED"**, press and hold  on the handset to unlock the keypad before you make a call with the cordless handset.
- If the base display shows the locked icon , press and hold \* on the base to unlock the base keypad before you make a call with the base.
- Only one handset (or the base unit) can be connected to an external line at a time. You cannot make calls if the base is already being used by either the answering machine or another handset.

**“When I press on the keys, nothing happens”**

- Make sure that the batteries are fitted in your cordless handset. If the Battery Level symbol on the display shows ‘low’, put your handset back on a charging pod to charge.

**“When I key in a number, it appears on the display, but I cannot make an external call”**

- Try a different position for the base unit – somewhere higher if possible, or further away from other electrical equipment.

**“The phone does not ring”**

- Check that the base unit’s mains power adapter is plugged in and power is switched on.
- The base unit needs mains power for normal operation of both the corded and cordless parts of the phone.
- Make sure that you are using the telephone line cable that was supplied with your phone.
- Make sure that the ringer volume settings are not set to off. Increase the ringer volume settings.

**“My call was cut off when I went out of range. Now I can’t use my handset.”**

- Move the cordless handset closer to the base unit before you try to make a call again.

**“There is interference and noise on the line”**

- Move the cordless handset closer to the base unit, or to a different position.
- Try moving the base unit away from other electrical equipment, such as a television or a computer.
- You’ll get the best reception if you place the base unit as high as possible. For example, in a two-floor building, the first-floor landing is an ideal place.

**“I hear ‘beeps’ from my handset while I’m on a call”**

- You may be moving out of range of the base unit. Move closer or your call may be cut off.
- Check the Battery Level symbol on the display. If it’s low, recharge the batteries.



**“The Caller Display feature isn’t working”**

- You need to subscribe to the Caller Line Identification service from your network service provider.
- The caller may have withheld their number by dialling 141. Or they may be calling from a network that does not transmit the caller’s number (e.g. if they are making international calls.)

**“When I try to make a call, I hear busy tone”**

- Because it is a multi-handset system, check whether another handset is already on a call.

**“The volume in the earpiece is low when I’m on a call”**

- Make sure you’re holding the earpiece correctly over your ear.
- Adjust the volume using **+ /  / ** on a cordless handset, or **+** on the base for the corded handset.

**“I cannot store a phonebook entry”**

- The maximum number of 100 phonebook entries on a cordless handset, or 30 on the base, has been reached. You must delete existing entries to make space for new ones.

**17.3 Intercom and transfer****“I can’t transfer a call”**

- Make sure that the other handset is in range of the base unit.

- Make sure that you have entered the correct number for the other handset.

#### 17.4 Batteries

##### **"The handset's battery cells are running low within an hour or two"**

- Before you first use the handset, you must leave it to charge on a charging pod for at least 15 hours.
- You may need to replace the batteries.
- Check the connection between the charging pod and the mains power socket.

##### **"I try to recharge the batteries but I still get a warning that they are low"**

- You need to replace the batteries. Dispose of used batteries safely – do not burn, immerse them in water, disassemble, or puncture the batteries.
- Do not use non-rechargeable batteries in your handset – they may explode, causing damage.

#### 17.5 Registration

##### **"I am not able to register another handset"**

- The maximum number of 4 cordless handsets has been reached. You will need to unregister a handset in order to register a new one.

#### 17.6 Answering Machine

##### **"The Answering machine does not record messages"**

- Make sure that the answering machine is switched on.
- Make sure that the Answer Mode is set to **"ANSW. & RECORD"**.
- The memory may be full. If so, you will need to delete some messages.

##### **"I cannot access my answering machine remotely"**

- Make sure that Remote Access is activated.
- Make sure that you have entered the correct Remote Access PIN (same as your Master PIN).

#### 17.7 If the fault persists...

- Disconnect all other instruments connected to the same line and try to make a call.
- Disconnect the base unit from the telephone line and plug a different phone into the master telephone socket. Try making a call.  
> If this works, the line is OK.
- If the call does not work, and you are using a two-way socket adapter, remove it and plug a telephone directly into the socket.
- If the call now works, the adapter may be faulty.
- If you cannot make a call, the fault may be on the exchange line.
- Contact the service provider.

## 18 GUARANTEE AND SERVICE

The phone is guaranteed for 24 months from the date of purchase shown on your sales receipt. This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, faults on the telephone line, lightning, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

**Please keep your sales (till) receipt this is your proof of guarantee.**

### 18.1 While the unit is under Guarantee

- Disconnect the base unit from the telephone line and the mains electricity supply.
- Pack up all parts of your phone system, using the original package.
- Return the unit to the shop where you bought it, making sure you take your sales receipt.
- Remember to include the mains adapter.

### 18.2 After the Guarantee has expired

If the unit is no longer under Guarantee, contact us via [www.aegtelephones.eu](http://www.aegtelephones.eu)

This product works with rechargeable batteries only. If you put nonrechargeable batteries in the handset and place it on the base, the handset will be damaged and this is NOT covered under the warranty conditions.

## 19 TECHNICAL DETAILS

<b>Standard</b>	Digital Enhanced Cordless Telecommunication (DECT)
<b>Frequency range</b>	1.88 to 1.9 GHz (bandwidth = 20 MHz)
<b>Channel bandwidth</b>	1.728 MHz
<b>Operating range</b>	Up to 300m outdoors; Up to 50m indoors
<b>Operating time</b>	Standby: 230 hours, Talking: 13 hours Battery charge time: 15 hours
<b>Temperature range</b>	Operating 0° C to 40° C, Storage -20° C to 60° C
<b>Electrical power</b>	Base unit power adapter: Ten Pao: S003IB0600050 & S003IV0600050 Input 100-240Vac 50-60Hz; Output 6Vdc/500mA Charger unit power adapter: Ten Pao: S003IB0600015 & S003IV0600015 Input 100-240Vac 50-60Hz; Output 6Vdc/150mA Battery information: 2 X 1.2V AAA size, 650mAh NiMH (Rechargeable)

#### Caution:

Risk of explosion if the battery is replaced by an incorrect type.  
Dispose of used batteries according to the instructions.

## 20 CE DECLARATION

This product is in compliance with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.

The Declaration of conformity can be found on: [www.aegtelephones.eu](http://www.aegtelephones.eu)



## 21 DISPOSAL OF THE DEVICE (ENVIRONMENT)

At the end of the product lifecycle, you should not throw this product into the normal household garbage but bring the product to a collection point for the recycling of electrical and electronic equipments. The symbol on the product, user guide and/or box indicate this. Some of the product materials can be re-used if you bring them to a recycling point. By reusing some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your local authorities in case you need more information on the collection points in your area.

**Batteries must be removed before disposing of the device. Dispose of the batteries in an environmental manner according to your country regulations.**

## 22 CLEANING AND CARE

**Do not clean** any part of your phone with benzene, thinners or other solvent chemicals as this may cause permanent damage which is not covered by the Guarantee.

**When necessary, clean it with a damp cloth.**

Keep your phone system away from **hot, humid conditions or strong sunlight**, and **don't let it get wet**. Every effort has been made to ensure high standards of reliability for your phone system. However, if something does go wrong, please **do not try to repair it yourself, but consult your supplier or call the Helpline.**









© 2012 Binatone Electronics International Limited

All rights reserved

Subject to availability. Rights of modification reserved.

AEG is a registered trademark used under license from AB Electrolux (publ)

[www.aegtelephones.eu](http://www.aegtelephones.eu)

