

Programmable Touch Screen Thermostat

1 Ordering Numbers: X13511538010, BAYSTAT152A, THT02775




Illustration shows a typical Home screen display.

SAFETY WARNING
Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

2 Warnings, Cautions, and Notices

Warnings, cautions, and notices are provided in appropriate places throughout this document:


WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE: Indicates a situation that may result in equipment or property-damage only accidents.

3 Specifications and Overall Dimensions

| Category | Specifications/Descriptions |
|------------------------------|--|
| Input power: | 24Vac, 50Hz or 60Hz (18Vac to 32Vac) Note: Frequency is selected using Configuration Option 0190. |
| Wire size: | 18 to 22 AWG |
| Output terminal ratings: | 1A resistive load @ 30Vac |
| Display type: | LCD/Touch |
| System modes: | <ul style="list-style-type: none">HeatCoolAutoOffEmergency Heat |
| Fan modes: | <ul style="list-style-type: none">OnAuto |
| Operating Temperature Range: | 32°F to 122°F (0°C to 50°C) |
| Temperature display range: | -45°F to 199°F (-42.8°C to 92.8°C) |
| Temperature setpoint range: | <ul style="list-style-type: none">Heat Setpoint: 40°F to 90°F (4.0°C to 32°C)Cool Setpoint: 50°F to 99°F (10°C to 37°C) |
| Humidity display range: | 0% to 99% (1% steps) |
| Humidity setpoint range: | 30% to 80% (1% steps) |



4 Installation

NOTICE
Hazardous Voltage!

Disconnect all electric power, including remote disconnects before servicing. Follow proper lockout/tagout procedures to ensure the power cannot be inadvertently energized. Failure to disconnect power before servicing could result in death or serious injury.


NOTICE
Equipment Damage!

Applying excessive voltage to the thermostat will permanently damage it.

To mount the backplate:

- Shut off the power to all HVAC equipment. If the security screw is used, remove it. Refer to the illustration.
- Push the cover thumb tab to release the cover from the backplate as shown.
- Route the wires through the opening in the backplate. Wires should be marked to ensure proper connection to terminals.
- If mounting the backplate directly to a wall surface, hold the backplate against the surface and then level and mark the fastener locations.
- Secure the backplate using appropriate fasteners. The thermostat should be mounted level and plumb for best air movement through the thermostat enclosure.
- Locate the terminal blocks from the packaging (new installation) or remove from pin header (existing installation).
- Connect the wires to the terminal blocks and then push the terminal blocks onto the circuit board pins.
- Push excess wire through the hole in the wall cavity or into the junction box. Do not coil excess wire between the thermostat and the backplate.

Push cover thumb tab to release cover from backplate.



NOTE: If the security screw is installed, remove it before attempting to remove the cover.

Terminal Block Identification

| | | |
|-----------------|-------------------|---|
| 8-pin Connector | Dh ^(a) | Dehumidify relay |
| | Hs | External humidity sensor input |
| | Hp | External humidity sensor power |
| | S2 | External temperature sensor |
| | S1 | External temperature sensor |
| | A | Economizer relay |
| | Y2 | Stage 2 compressor control relay |
| | (W1)W2 | (Emergency heat relay) ^(b) Second stage heat relay |
| 6-pin Connector | R | 24Vac heating Important: Terminal shipped with jumper connected. Remove jumper if the heat/cool 24 Vac power supplies are separate. |
| | Rc | 24Vac cooling Important: Terminal shipped with jumper connected. Remove jumper if the heat/cool 24 Vac power supplies are separate. |
| | (O/B)W | (Changeover valve) ^(b) Heat relay |
| | Y | Stage 1 compressor control relay |
| | G | Fan relay |
| | C | Common |
| | | |

(a) Label order above is how they appear on the thermostat terminal block.
(b) Text in parentheses indicates that it applies to heat pump systems.

5 Configuration

NOTICE

Adverse Control System Behavior!

Improper configuration setup could cause unwanted, possibly adverse control system behavior. Be sure to configure the thermostat according to your system type.

To change the installation configuration:

- Apply electrical power to the thermostat.
- Determine the configuration options and then write down the selections or other notes on the table in Panel 6.
- To activate **Configuration Option Setup** mode:


WARNING

Live Electrical Components!

The circuit board is energized. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform this step. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

- Remove the thermostat cover.
 - Press and hold the **Configuration** button for 3 seconds. The configuration wrench icon displays along with the configuration option number and value.
- Press the center **▲** or **▼** (as shown) to increment or decrement the **Option Number**.
Note: Changing the Option Number with the up/down arrows will also Save the Option Value. In addition, the OK will increment the Option Number and Save the Option Value.
 - Press the right side **▲** or **▼** (as shown) to increment or decrement the **Option Value**.

- Any of the following actions will save settings, exit Configuration Mode, and return to the Home screen:
 - Push the configuration button momentarily (less than 3 seconds)
 - Touch and hold **OK** for 2 seconds
 - A 10-minute time out after the last touch in Configuration Mode



Installation Options

Table 1. Installer configuration setup menu

| No. | Name | Def | Values/Descriptions | Notes |
|------------------------------|---|---|--|---|
| 0100 | Temperature indication/Resolution | 0 | <ul style="list-style-type: none">0= °F, 1 degree resolution1= °F, 0.5 degree resolution2= °C, 1 degree resolution3= °C with 0.5 degree resolution4= °C with 0.1 degree resolution | This setting affects indoor temperature display and setpoint display resolutions. Outdoor temperature display area resolution is always +/- 1 for both F and C. Refer to Option 0210. |
| 0110 | Clock Format | 12 | <ul style="list-style-type: none">12= 12-hours clock24= 24-hour clock | |
| 0120 | Year | 11 | <ul style="list-style-type: none">11–99 | Available year range: 2011–2099. This value is updated to the real time clock after setting. Day of the week is updated automatically. |
| 0121 | Month | 1 | <ul style="list-style-type: none">1–12 | This value is updated to the real time clock after setting. Day of the week is updated automatically. |
| 0122 | Day | 1 | <ul style="list-style-type: none">1–31 | Month dependent; this value is updated to the real time clock after setting. Day of the week is updated automatically. |
| 0125 | Daylight Savings | 2 | <ul style="list-style-type: none">0= Disabled1= US (1987), changeover at 2:00am2= US (2007), changeover at 2:00am3= Europe, changeover at 1:00am4= Manual, changeover at 2:00am | |
| 0126 0127 0128 0129 | <ul style="list-style-type: none">Spring Ahead MonthSpring Ahead DayFall Back MonthFall Back Day | <ul style="list-style-type: none">03011101 | <ul style="list-style-type: none">01-1201-3101-1201-31 | Options available only if 0125 is set to 4. |
| 0130 | System Selection | 8 | <ul style="list-style-type: none">1= 1H/1C (Conv) 1st Stage Heat (W), 1st Stage Comp (Y), Fan (G)2= 1H/1C (HP) 1st Stage Comp (Y), Changeover (O/B), Fan (G)3= 1H (Conv) 1st Stage Heat (W), without fan4= 1H (Conv) 1st Stage Heat (W), Fan (G)5= 1C (Conv) 1st Stage Comp (Y), Fan (G)6= 2H/1C (HP) 1st Stage Comp (Y), Changeover (O/B), Auxiliary Heat (W1), Fan (G)7= 2H/2C (Conv) 1st & 2nd Stage Heat (W,W2), 1st & 2nd Stage Comp (Y,Y2), Fan (G)8= 2H/1C (Conv) 1st & 2nd Stage Heat (W,W2), 1st Stage Comp (Y), Fan (G)9= 1H/2C (Conv) 1st Stage Heat (W), 1st & 2nd Stage Comp (Y,Y2), Fan (G)10= 2H/2C (HP) 1st & 2nd Stage Comp (Y,Y2), Changeover (O/B), Fan (G)11= 3H/2C (HP) 1st & 2nd Stage Comp (Y,Y2), Changeover (O/B), Auxiliary Heat (W1), Fan (G) | |
| 0140 | Schedule Options | 1 | <ul style="list-style-type: none">0=Non-programmable1= Programmable | |
| 0150 | TOD/Economizer Output (Terminal A) | 0 | <ul style="list-style-type: none">0= Unused1= TOD energizes terminal A during occupied period, not during unoccupied period.2= Economizer energizes terminal A during a call for cool. | TOD is not available in Non-programmable Mode (refer to Option 0140). |
| 0151 | Heat Fan Operation | 0 | <ul style="list-style-type: none">0= System controls fan1= Thermostat controls fan | Only shown for conventional system with heat stages and fan capability. For heat pump, the fan relay operates with thermostat control. |
| 0153 | Reversing Value O/B | 0 | <ul style="list-style-type: none">0= O/B ON when call for cool1= O/B ON when call for heat | Only shown for heat pump systems. |
| 0160 | Cycles Per Hour (CPH) [First Stage Compressor] | 3 | <ul style="list-style-type: none">1–5 | Only for systems with cool or HP stage. Refer to 0130. Selection in this stage changes 2nd stage cool default CPH. |
| 0161 | CPH (Second Stage Compressor) | 3 | <ul style="list-style-type: none">1–5 | Only for systems with 2-cool or HP stages. Refer to Option 0130. |
| 0162 | CPH (First Stage Conventional Heat) | 5 | <ul style="list-style-type: none">1–10 | Only for conventional systems with heat stages. Refer to Option 0130. Selection in this stage changes default CPH of 2nd stage heat. |
| 0163 | CPH (Second Stage Conventional Heat) | 9 | <ul style="list-style-type: none">1–10 | Only for conventional systems with two stages of conventional heat. |
| 0164 | CPH for Auxiliary Heat | 9 | <ul style="list-style-type: none">1–10 | Only shown for 2H/1C HP or 3H/2C HP systems. Refer to Option 0130. |
| 0165 | CPH for Emergency Heat | 9 | <ul style="list-style-type: none">1–10 | Only shown for 2H/1C HP or 3H/2C HP systems. Refer to Option 0130. |
| 0170 | Continuous Backlight | 0 | <ul style="list-style-type: none">0= Backlight ON time is limited1= Backlight ON continuously | |
| 0180 | Changeover | 1 | <ul style="list-style-type: none">0= Manual1= Auto | Only for systems with both heat and cool stages. Refer to Option 0130. |
| 0181 | Deadband | 3 | <ul style="list-style-type: none">2= 2°F (1°C)3= 3°F (1.5°C)4= 4°F (2.0°C)5= 5°F (2.5°C)6= 6°F (3.0°C)7= 7°F (3.5°C)8= 8°F (4.0°C)9= 9°F (4.5°C) | Only applies to auto or manual changeover systems. Refer to Option 0180. |
| 0182 | Minimum Compressor Off Time | 5 | <ul style="list-style-type: none">0= 0 minutes1= 1 minute2= 2 minutes3= 3 minutes4= 4 minutes5= 5 minutes | Only for systems with cool stage or heat pump. Refer to Option 0130. This setting will extend the compressor OFF time beyond any other delays that are incorporated into the Heat/Cool software algorithm. |
| 0190 | Power Supply Frequency | 0 | <ul style="list-style-type: none">0= 60 Hz1= 50 Hz | Power supply input is 24 Vac nominal at either 60 Hz or 50 Hz. |
| 0200 | Dehumidify Sensor Selection | 1 | <ul style="list-style-type: none">0= Humidity display and function is disabled1= Internal humidity sensor enabled2= External humidity sensor enable | For external humidity control, a 4–20 mA humidity sensor should be connected to the Hp and Hs terminals to avoid error code E1 . |

Table 1. Installer configuration setup menu (continued)

| No. | Name | Def | Values/Descriptions | Notes |
|------|---|-----|--|--|
| 0205 | Dehumidification Control | 0 | <ul style="list-style-type: none">0= Active Control1= Passive Control | Active control toggles Dh output terminal On and Off as specified by the dehumidify algorithm and is used with a device having its own dehumidification equipment. Passive control runs cool mode for up to 1 extra minute whenever there is a call for cool and dehumidification. |
| 0206 | Internal Humidity Offset Adjustment | 0 | <ul style="list-style-type: none">-9% to 9% in 1% increments | Allows adjustment of the internal relative humidity reading to account for accuracy, tolerance, and potential drift. FW should use the adjusted value for display and humidity control. |
| 0207 | External Humidity Offset Adjustment | 0 | <ul style="list-style-type: none">-9% to 9% in 1% increments | Allows adjustment of the external relative humidity reading to account for accuracy, tolerance, and potential drift. FW should use the adjusted value for display and humidity control. |
| 0210 | Temperature Sensor Selection | 0 | <ul style="list-style-type: none">0= Internal sensor only (10k)1= Internal sensor for H/C control (outdoor for display only) [10k]2= internal sensor for H/C control (outdoor for Compr/Aux lockout control)[10k]3= Remote indoor sensor for H/C control (10k)4= Use average temperature = (local+S1/S2)/2 for H/C control. | Setting 2 applies only to HP systems and is disabled on all conventional systems. For setting 1, 2, or 4; if either temperature sensor is out of range, then the E0 error code will display. |
| 0220 | Heat Pump Compressor Lockout Point | 0 | <ul style="list-style-type: none">0= None15= 15°F (–9.5°C)20= 20°F (–6.5°C)25= 25°F (–4.0°C)30= 30°F (–1.0°C)35= 35°F (1.5°C)40= 40°F (4.5°C)45= 45°F (7.0°C) | Only for heat pump systems with more heat stages than cool stages and remote outdoor control sensor. Refer to 0130 and 0210. Note: A 5°F (2.5°C) deadband between heat pump and auxiliary lockout will be enforced. |
| 0221 | Heat Pump Auxiliary Lockout Point | 0 | <ul style="list-style-type: none">0= None40= 40°F (4.5°C)45= 45°F (7.0°C)50= 50°F (10.0°C)55= 55°F (13.0°C)60= 60°F (15.5°C) | Only for heat pump systems with more heat stages than cool stages and remote outdoor control sensor. Refer to 0130 and 0210. Note: A 5°F (2.5°C) deadband between heat pump and compressor lockout will be enforced. |
| 0230 | Temporary Override Duration Limit | 3 | <ul style="list-style-type: none">0= zero hours1= one hour2= two hours3= three hours4= four hours | Used for temporary override (TOV) starting duration time. Setting of zero <i>does not</i> disable TOV. |
| 0231 | Starting Default Number of Periods | 2 | <ul style="list-style-type: none">2= two periods4= four periods | Provides a starting default number of periods for all days of the week. |
| 0232 | Starting Default Period Occ/Unocc Definitions | 4 | <p>If option #0231 is set to 2</p> <p>Day—Night</p> <ul style="list-style-type: none">0= UnOcc—UnOcc1= UnOcc—Occ2= UnOcc—UnOcc3= UnOcc—Occ4= Occ—UnOcc5= Occ—Occ6= Occ—UnOcc7= Occ—Occ8= UnOcc—UnOcc9= UnOcc—Occ10= UnOcc—UnOcc11= UnOcc—Occ12= Occ—UnOcc13= Occ—Occ14= Occ—UnOcc15= Occ—Occ <p>If option #0231 is set to 4</p> <p>Morn—Day—Evening—Night</p> <ul style="list-style-type: none">0= UnOcc—UnOcc—UnOcc—UnOcc1= UnOcc—UnOcc—UnOcc—Occ2= UnOcc—UnOcc—Occ—UnOcc3= UnOcc—UnOcc—Occ—Occ4= UnOcc—Occ—UnOcc—UnOcc5= UnOcc—Occ—UnOcc—Occ6= UnOcc—Occ—Occ—UnOcc7= UnOcc—Occ—Occ—Occ8= Occ—UnOcc—UnOcc—UnOcc9= Occ—UnOcc—UnOcc—Occ10= Occ—UnOcc—Occ—UnOcc11= Occ—UnOcc—Occ—Occ12= Occ—Occ—UnOcc—UnOcc13= Occ—Occ—UnOcc—Occ14= Occ—Occ—Occ—UnOcc15= Occ—Occ—Occ—Occ | Occupancy setting can be changed during scheduling for each period/day. |
| 0233 | Days Options for Scheduling Mode | 3 | <ul style="list-style-type: none">0= 1 day; Mo-Su all days share the same schedule1= 5+1+1 days; Mo-Fr share a schedule. Sa and Su each have an independent schedule2= 5+2 days; Mo-Fr share a schedule. Sa-Su share a schedule.3= 7 days; Each day has an independent schedule | Any value toggle of this option (0233) will reset the schedule to the default values of Options 0231 and 0232. In addition, it will return the schedule to default values. |
| 0240 | Heat Temperature Range | 90 | <ul style="list-style-type: none">40–90; 40°F to 90°F4–32; 4°C to 32°C | Only for systems with heat stage. Refer to Option 0130. |
| 0241 | Cool Temperature Range | 50 | <ul style="list-style-type: none">50–99; 50°F to 99°F10–37; 10°C to 37°C | Only for systems with cool stage. Refer to Option 0130. |
| 0260 | Temperature Display Offset | 0 | <ul style="list-style-type: none">–3= –3°F (–1.5°C)–2= –2°F (–1.0°C)–1= –1°F (–0.5°C)0= None1= 1°F (0.5°C)2= 2°F (1.0°C)3= 3°F (1.5°C) | Only applies to control temperature and display temperature for internal and indoor remote sensor. Does not apply to outdoor temperature for display. |
| 0270 | Extended Fan-on Time Heat | 0 | <ul style="list-style-type: none">0= Off90= ninety seconds | This option is not available if option 0151=0 or if the system is cool only. Refer to Option 0130. |
| 0271 | Extended Fan-on Time Cool | 0 | <ul style="list-style-type: none">0= Off40= forty seconds | This option is not available for systems with heat only. Refer to Option 0130. |
| 0275 | Filter Change Indicator | 1 | <ul style="list-style-type: none">0= OFF1= 30 days3= 90 days4= 120 days6= 180 days12= 365 days | Filter change disabled in OFF . Timer values start on first power up or reset of an active filter icon. |
| 0300 | Restore Factory Defaults | 0 | <ul style="list-style-type: none">0= No1= Yes | No= No action; Yes= Resets all parameters to default except calendar/daylight savings time/system selection. |

