

Cat. No. 14-1119
OWNER'S MANUAL

Please read before using this equipment.

CTR-113

**Voice-Activated Cassette
Tape Recorder**

OPTIMUS®

FEATURES

Your Optimus CTR-113 Voice-Activated Cassette Tape Recorder gives you convenient recording technology. You can have recording begin and end according to the sound level in a room, which gives you hands-free operation while recording.

Because the CTR-113 does not record long periods of silence, you not only save tape space and battery power, you also save time when you try to find a certain section on the tape. Your recorder is small enough to fit in a briefcase or purse, so you can take it almost anywhere.

The cassette recorder includes these special features:

Semi Auto Stop — during playback and recording, stops the recorder and releases the tape mechanism when the tape reaches the end, to save battery power and protect your cassette tape.

Digital Tape Counter — helps you quickly return to a specific section on the tape.

One-Touch Recording — lets you press one button to start recording.

© 1998 Tandy Corporation.
All Rights Reserved.

Optimus and RadioShack are registered trademarks
used by Tandy Corporation.

Cue/Review — lets you easily locate a certain section on the tape.

Voice-Activated Circuit — automatically starts recording when the recorder picks up sound and stops recording within 5 seconds after the sound falls below a preset level.

Built-In Microphone — lets you make quality recordings without having to use an external microphone.

Wrist Strap — makes the recorder convenient to carry and use.

Earphone — lets you listen without disturbing others.

Three-Way Power — lets you operate your cassette recorder using internal batteries, AC power (using an optional adapter), or your vehicle's cigarette-lighter socket (using an optional adapter).

Built-In Speaker — lets you listen to your recorder without an earphone.

Automatic Level Control (ALC) Circuit — automatically adjusts to the proper recording level.

CONTENTS

Preparation	5
Powering the Recorder	5
Using Internal Battery Power	5
Using AC Power	7
Using DC Power	8
Using the Earphone.....	10
Listening Safely	11
Traffic Safety	11
Operation	12
Loading a Cassette Tape.....	12
Recording	13
Using Voice Activation (VOX)	13
Manual Recording	14
Playing a Tape	15
Using Cue and Review	15
Using Fast-F and Rewind	16
Using the Tape Counter	16
Tape Tips	17
Restoring Tape Tension and Sound Quality ...	17
Erasing a Cassette Tape	18
Preventing Accidental Erasure	18
Maintenance	20
Cleaning the Tape-Handling Parts.....	21
Specifications	23

PREPARATION

POWERING THE RECORDER

For portable use, you can power the recorder from internal batteries. Using adapters, you can also power it from a standard AC outlet or your vehicle's cigarette-lighter socket.

Using Internal Battery Power

The recorder uses two AA batteries (not supplied). For the best results, we recommend alkaline batteries, such as RadioShack Cat. No. 23-552. Or, you can use rechargeable nickel-cadmium batteries, such as Cat. No. 23-125, with a battery charger (Cat. No. 23-133).

Cautions:

- Use only fresh batteries of the recommended size and type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

Follow these steps to install batteries.

(illus — show the removal of batt. compartment cover and installation of batteries.,

1. Slide the battery compartment cover in the direction shown by the arrow on the cover.

Caution: The battery compartment cover is hinged. Do not try to remove it.

2. Install two AA batteries as indicated by the polarity symbols (+ and -) marked on the back of the recorder.

3. Replace the cover.

When the recorder stops operating properly or the battery light is low, replace the batteries.

Cautions:

- If you do not plan to use the recorder for a week or more, or you plan to use only another power source, remove the batteries.
- Always dispose of old batteries promptly and properly.

Important: Your recorder is capable of using rechargeable nickel-cadmium batteries. At the end of the batteries' lives, they must be recycled or disposed of properly. Contact your local, county, or state hazardous waste management authorities for information on recycling or disposal programs in your area. Some options that might be available are: municipal curbside collection, drop-off boxes at retailers such as your local RadioShack store, recycling collection centers, and mail-back programs.

Using AC Power

To power the recorder from an AC outlet, you need an AC adapter (not supplied), such as Cat. No. 273-1654.

Cautions:

- You must use an adapter that supplies at least 3 volts and delivers at least 300 mA. Its center tip must be set to negative, and its barrel plug must fit the CTR-113's **DC 3V** jack. The recommended adapter meets these specifications. Using an adapter that does not meet these specifications could damage the CTR-113 or the adapter.
- Connecting an AC adapter automatically disconnects internal batteries.

-
- Always plug the adapter into the recorder before you plug it into the AC outlet. Always unplug the adapter from the AC outlet before you unplug it from the recorder.

Illust.

1. Set the adapter's voltage switch to 3V.
2. Attach the 3.4 mm outer diameter/1.3 mm inner diameter barrel plug to the AC adapter's cord with the tip set to negative (-).
3. Insert the barrel plug into the recorder's **DC 3V** jack.
4. Plug the adapter into a standard AC outlet.

Using DC Power

To power the recorder from your vehicle's cigarette-lighter socket, you need a DC adapter (not supplied), such as Cat. No. 273-1810 or Cat. No. 270-1560.

Cautions:

- You must use an adapter that supplies 3 volts and delivers at least 300 milliamps. Its center tip must be set to negative, and its barrel plug must fit the CTR-113's **DC 3V** jack. The recommended adapter meets these specifications. Using an adapter that does not meet these specifications could damage the CTR-113 or the adapter.
- Connecting a DC adapter automatically disconnects internal batteries.
- Always plug the adapter into the recorder before you plug it into the cigarette-lighter socket. Always unplug the adapter from the cigarette-lighter socket before you unplug it from the recorder.

Follow these steps to power the recorder from your vehicle's cigarette-lighter socket.

Illust.

1. Set the adapter's voltage switch to 3V.

2. Attach the 3.4 mm outer diameter/1.3 mm inner diameter barrel plug to the DC adapter's cord with the tip set to negative (-).
3. Insert the barrel plug into the recorder's **DC 3V** jack.
4. Plug the other end of the adapter into the vehicle's cigarette-lighter socket.

Note: If the recorder does not operate properly when powered from your vehicle's battery, unplug the adapter from the cigarette-lighter socket and clean the socket to remove any ashes or other debris.

USING THE EARPHONE

You can use the supplied earphone for private listening.

Insert the earphone's 1/8-inch (3.5-mm) plug into the **EAR** jack.

Illust.

Note: Connecting the earphone disconnects the recorder's built-in speaker.

Listening Safely

To protect your hearing, follow these guidelines when you use an earphone.

- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Set the volume to its lowest level before you begin listening. After you put on the earphone, adjust the volume to a comfortable listening level.
- Do not increase the volume once you have established a comfortable listening level. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear an earphone while operating a motor vehicle or riding a bicycle. This can cause a traffic hazard and could be illegal in some areas.

Even though some earphones let you hear outside sounds when listening at normal volume levels, they still can present a traffic hazard.

OPERATION

LOADING A CASSETTE TAPE

1. Take up any slack in the cassette tape by turning the hub with a pencil to prevent the tape from becoming tangled in the tape mechanism. Do not touch the tape.

Illust.

2. Open the cassette compartment door by lifting it at the notch. Insert a cassette tape into the door guides so the cassette's open edge faces out, the side you want to play or record on faces the compartment window, and the full reel is to the left.

Illust.

3. Close the cassette compartment door.

RECORDING

Notes:

- We recommend you use normal bias (Type I) cassette tapes, such as RadioShack LN and XR tape.
- We recommend regular length (60- or 90-minute) cassette tapes. We do not recommend long-play cassette tapes, such as C-120s, because they are thin and can easily tangle.
- The ALC (automatic level control) circuit automatically sets the recording level. **VOLUME** has no effect.
- For the best quality recordings, place the recorder 1 to 5 feet from the sound source.

Caution: Never try to force down ● **RECORD** after you remove an erase protection tab (see “Erasing a Cassette Tape” on Page 18). You might damage the recorder.

Using Voice Activation (VOX)

1. Load a blank cassette or one you want to record over, into the cassette compartment.

2. Set **VOICE ACTIVATION** to **IN**.

Illust.

3. Press **● RECORD**. Recording begins when the voice-activation mechanism detects a sound.

Illust.

4. To cause low sound levels to activate recording, rotate **VOLUME/VOX SENS** toward **MAX**. To automatically record only louder sounds, rotate **VOLUME/VOX SENS** toward **MIN**. (This does not change the volume of the recording.) Experiment to achieve the best setting for your recording environment.

The **RECORD BATTERY** indicator lights during recording.

Manual Recording

For manual recording, set **VOICE ACTIVATION** to **OUT**, then press **● RECORD**. Recording automatically stops when the recorder reaches the end of the tape side. To manually stop recording, press **■ STOP**.

PLAYING A TAPE

1. Load a prerecorded cassette into the recorder.
2. Press ◀ **PLAY**.

Illust.

3. Adjust **VOLUME** to a comfortable listening level.
4. The tape automatically stops when it reaches the end. To stop it sooner, press ■ **STOP**.

USING CUE AND REVIEW

While a tape is playing, hold down ◀◀ **FAST-F/CUE** to play the cassette tape at high speed to quickly locate any desired section on the tape. Release ◀◀ **FAST-F/CUE** to resume normal play.

Or, hold down ▶▶ **REWIND/REV** to play the cassette tape in reverse at high speed. Release ▶▶ **REWIND/REV** to resume normal play.

USING FAST-F AND REWIND

When the tape is stopped, press **◀ FAST-F/CUE** or **REWIND/REV ▶▶** to fast-forward or rewind the tape. The button locks, and the tape fast-forwards or rewinds to the end or until you press **STOP ■**. When the tape reaches the end, press **STOP ■** to release the button and the tape-handling parts.

Illust.

Note: The CTR-113 does not automatically stop when it reaches the end of the tape. To protect the tape after the tape has fully wound to either end, press **STOP** to release fast-forward or rewind.

USING THE TAPE COUNTER

The tape counter shows you the tape's current playing position, making it easier to locate a particular segment. Before you play a tape, press the reset button to reset the

counter to 000. As the tape plays, note the position you want to return to later.

Illust.

TAPE TIPS

Restoring Tape Tension and Sound Quality

After you play a cassette tape several times, the tape might become tightly wound on the reels. This can cause playback sound quality to deteriorate.

To restore the sound quality, fast-forward the tape from the beginning to the end of one side, then completely re-wind it. Then loosen the tape reels by gently tapping each side of the cassette's outer shell on a flat surface.

Caution: Be careful not to damage the cassette when tapping it. Do not touch the exposed tape or allow any sharp objects near the cassette.

Erasing a Cassette Tape

To record over a cassette tape, simply record as usual. The cassette deck records over the previous recording.

You can quickly erase both sides of a cassette tape using a bulk tape eraser, such as Cat. No. 44-232.

Preventing Accidental Erasure

Cassette tapes have two erase-protection tabs — one for each side. When a tab is in place, you can record on that side. To protect a recording from being accidentally recorded over or erased, use a screwdriver to remove one or both of the cassette tape's erase-protection tabs.

If you later decide to record on a tape side after you have removed the erase-protection tab, place a piece of strong plastic tape over that side's erase-protection hole. Be

sure you cover only the hole originally covered by the erase-protection tab.

Illust.

Caution: Removing the erase-protection tabs does not prevent a bulk eraser from erasing a cassette tape.

MAINTENANCE

Your CTR-113 Voice-Activated Cassette Tape Recorder is an example of superior design and craftsmanship. The following suggestions will help you care for your recorder so you can enjoy it for years.



Keep the recorder dry. If it gets wet, wipe it dry immediately. Liquids might contain minerals that can corrode the electronic circuits.



Use and store the recorder only in normal temperature environments. Temperature extremes can shorten the life of electronic devices, damage batteries, and distort or melt plastic parts.



Keep the recorder away from dust and dirt, which can cause premature wear of parts.



Handle the recorder gently and carefully. Dropping it can damage circuit boards and cases and can cause the recorder to work improperly.



Use only fresh batteries of the required size and type. Batteries can leak chemicals that damage your recorder's electronic parts.



Wipe the recorder with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the recorder.

Modifying or tampering with the recorder's internal parts can cause a malfunction and might invalidate its warranty. If your recorder is not operating as it should, take it to your local RadioShack store for assistance.

CLEANING THE TAPE-HANDLING PARTS

Dirt, dust, or particles of the tape's coating can accumulate on the tape heads and other parts that the tape touches. This can greatly reduce the performance of the cassette recorder. To prevent noise and poor high-frequency response, clean the cassette recorder's tape-handling parts after about 20 hours of use. Use a cassette deck cleaning kit (Cat. No. 44-1202) or follow these steps to clean the tape-handling parts.

-
1. Remove the batteries and disconnect any other power source.
 2. Open the cassette compartment door.
 3. Hold down the erase protection tab sensor, then press **RECORD** to expose the tape-handling parts.
 4. Use a cotton swab dipped in denatured alcohol or tape head-cleaning solution to clean the record/play head, pinch roller, capstan, erase head, and tape guides.

Illust.

5. When you finish cleaning, press **STOP** and close the compartment. Then reconnect power.

SPECIFICATIONS

Tape System 2 Track, Monophonic Cassette
(For use with normal bias tape (Type I) only)

Tape Speed $1\frac{7}{8}$ ips (4.75 cm/sec)

Wow and Flutter 0.35% (WRMS)

Signal-to-Noise Ratio 42 dB

Erase System Magnet

Record System AC Bias

Power Requirements:

DC Two AA Batteries (Cat. No. 23-552)
or 12 Volts from a Vehicle's Cigarette-Lighter
Socket with DC Auto Adapter,

3 Volt DC Output (Cat. No. 270-1560 and 273-1810)

AC 120 Volts with AC Adapter,
3 Volt DC Output (Cat. No. 273-1654)

Size (WHD) $3.46 \times 5.04 \times 1.48$ Inches
($128 \times 94 \times 37$ mm)

Weight 7.1 oz
(201 g)

Included Accessory Earphone

Specifications are typical; individual units might vary.
Specifications are subject to change and improvement
without notice.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W,
100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

9A8N

Printed in Hong Kong