

HI-SPEED

Checkweighing

StarweighTM

Checkweigher

System Manual


METTLER TOLEDO

6J-01K-0188B
(6/2008)

©Mettler-Toledo Hi-Speed 2008
5 Barr Road
Ithaca, NY 14850
USA
607-257-6000
<http://www.mt.com/hi-speed>

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of Mettler-Toledo Hi-Speed Inc.

U.S. Government Restricted Rights: This documentation is furnished with Restricted Rights.



FCC WARNING

Computing devices and peripherals may generate, use, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions in this manual and may cause interference to radio communications. Such equipment has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of the FCC Rules, which are designed to provide reasonable protection against radio interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user - at their own expense - will be required to take whatever measures may be required to correct the interference.

This page left intentionally blank.

X Series Access Code

The default settings (set by the manufacturer) of the access codes required for the operator access level and supervisor access level are as follows:

Operator access level: 2

Supervisor access level: 3

Remove this page and keep it in a safe location.

Should you lose this information contact:

Mettler-Toledo Hi-Speed's Service and Customer Support Teams

Email: hispeed.support@mt.com

Or

Call: 1-800-836-0836

International: US 607-257-6000

**Our highly trained staff is committed to
ensuring your success with your
Mettler-Toledo Hi-Speed product.**

This page left intentionally blank.

TABLE OF CONTENTS

1	INTRODUCTION	1-1
1.1	Symbols	1-1
1.2	Disclaimers	1-2
1.3	Safety Information	1-3
1.4	Precautions	1-3
2	DESCRIPTION	2-1
2.1	Function Of The Checkweigher	2-1
2.2	General Description	2-1
2.3	Starweigh Design (Front View)	2-2
2.4	Starweigh Design (Side Views)	2-3
2.5	Starwheel (Top View)	2-4
2.6	Transport Details	2-5
2.7	Starwheel Mount Identification	2-6
2.8	Interfaces	2-7
3	USING THE TOUCHSCREEN	3-1
3.1	Menu Tree	3-3
4	INSTALLATION	4-1
4.1	Arc Welding Caution Notice	4-1
4.2	Preliminary inspection	4-1
4.3	Checking The Installation Site	4-1
4.4	Placing The Checkweigher In-Line	4-2
4.5	Electrical Connections	4-3
4.6	Applying Power	4-3
5	MAINTENANCE	5-1
5.1	Cleaning The Checkweigher	5-1
5.2	Care Of The Scale And Scale Platform	5-1
5.3	Keep Electrical Cabinets Sealed Tightly	5-2
5.4	Electrical Components	5-2
5.5	Changing The Starwheel	5-2
6	FUNCTION ALLOCATIONS	6-1
7	STARWEIGH SETUP	7-1
7.1	Menu Setup	7-1
7.2	Wheel Design Parameter	7-2
7.3	Wheel Design Basic	7-3
7.4	Wheel Design Motion	7-4
7.5	Wheel Design Servo	7-6
7.6	Wheel Advanced Setup	7-7
7.6.1	Pockets	7-7
7.6.2	Load / Unload Station	7-8
7.6.3	Weigh Stations	7-10
7.6.4	Discharge Clear	7-11
7.6.5	Wheel Workshop	7-12
7.7	Wheel Specific Package Setup	7-14
7.8	Wheel Definitions	7-17

8	REJECTER	8-1
8.1	Rejecter Setup	8-1
8.2	Rejecter Calibration	8-2
9	TARE GROSS (OPTIONAL)	9-1
9.1	Definitions	9-2
9.2	Tare Interface	9-3
9.3	Tare Reject Requirements	9-4
9.3.1	Setting up the Optional Tare Rejecter (Must be Setup on the Tare Node Only)	9-5
9.3.2	Tare Rejecter Zone Classification (Must be Setup on the Tare Node Only)	9-6
9.4	Gross Node Item Tracking and Communications Channel	9-7
9.5	Synchronization Requirements	9-9
9.5.1	Clear Wheel	9-9
9.6	Security Requirements	9-10
9.7	Exclusions	9-10
9.8	How to Set Up the Tare/Gross Interface	9-11
9.9	Tare Queue Function Allocation Settings (Tare Machine only)	9-11
9.10	Gross Queue Function Allocation Settings (Gross Machine only)	9-12
9.11	Gross Queue Quarantine Function Allocation Settings (Gross Machine only)	9-13
9.12	Tare/Gross Serial Setup XRTC Settings (Both Tare and Gross Machines)	9-13
9.13	Main Package Setup – Supplemental Tare	9-14
9.14	Tare/Gross Large Weight Display (Gross Node Only)	9-15
9.15	Reset Actions	9-16
9.16	E-Stop	9-16
9.17	Bottle Down Safety Feature	9-16
10	X-PURGE ENCLOSURE (OPTIONAL)	10-1
10.1	Division 1: X-purge protection	10-1
10.2	Pre-installation testing	10-1
10.3	Division 1 X-purge test	10-1
10.3.1	Equipment required	10-1
10.3.2	Procedure	10-1
10.4	Pack-seal connection instructions	10-3
10.4.1	Equipment Required	10-3
10.4.2	Procedure	10-3
10.5	Purge air line connection instructions	10-5
10.5.1	Equipment required	10-5
10.5.2	Procedure	10-5
10.6	X-purge start-up operation	10-6
10.7	X-purge color codes	10-7
10.8	X-purge troubleshooting guide	10-9
10.9	X-purge specifications	10-10
10.9.1	Materials	10-10
10.9.2	Mechanical	10-10
10.9.3	Environmental	10-10
10.9.4	Electrical	10-10
10.9.5	Air requirements	10-10

11	TROUBLESHOOTING	11-1
11.1	How To Recognize A Weighing Problem.....	11-1
11.2	Drift (Gradual Change In Weight Values)	11-1
11.3	Weight Display Indicates 3-Asterisk * * * As Items Cross The Scale.....	11-1
11.4	Detailed List Of Weighing Errors And Possible Causes.....	11-1
12	TECHNICAL DATA	12-1
12.1	Weighing Functions	12-1
13	GLOSSARY	13-1

This page left intentionally blank.



1 Introduction

This chapter is designed to help users understand the symbols and information used throughout this manual, as well as all pertinent safety precautions and applicable laws.



1.1 Symbols

Symbols warn you that there is a potential danger in the procedure you're about to try. The two signs represent two distinct degrees of danger.

Example:



Below are some examples of the hazard warning stickers found on this system:



1.2 Disclaimers

- **DO NOT** modify your machine without authorization from Mettler-Toledo Hi-Speed Checkweigher Company; if you make any modifications in the field, you must install guards to shield exposed drive chains or other hazards.
- If you fabricate new guards for your equipment, apply new warning stickers where your production personnel can easily see them.
- If you need additional stickers, please contact your local Mettler-Toledo Hi-Speed Service Department. We will provide stickers free of charge.

1.3 Safety Information

- Drive guards are needed to be in place for operation to occur.
- E-stops are an essential safety component. They are found in several places on the system, and engaging them eliminates power to the system.
- All interlocks and reject shields must be in place before power is put on the system.

1.4 Precautions

	<div data-bbox="808 493 906 577"></div> <div data-bbox="917 514 1133 567">WARNING</div> <div data-bbox="662 598 1271 741"> <p>ONLY PERMIT QUALIFIED PERSONNEL TO SERVICE THIS EQUIPMENT. EXERCISE CARE WHEN MAKING CHECKS, TESTS AND ADJUSTMENTS THAT MUST BE MADE WITH POWER ON. FAILING TO OBSERVE THESE PRECAUTIONS CAN RESULT IN BODILY HARM.</p> </div>
	<div data-bbox="808 804 906 888"></div> <div data-bbox="917 825 1133 877">WARNING</div> <div data-bbox="662 909 1218 1003"> <p>FOR CONTINUED PROTECTION AGAINST SHOCK HAZARD CONNECT TO PROPERLY GROUNDED OUTLET ONLY. DO NOT REMOVE THE GROUND PRONG.</p> </div>
	<div data-bbox="808 1066 906 1150"></div> <div data-bbox="917 1087 1133 1140">WARNING</div> <div data-bbox="654 1171 1247 1203"> <p>DISCONNECT ALL POWER TO THIS UNIT BEFORE SERVICING.</p> </div>

- Do not operate without guards and safety mechanisms in place and functioning.
- Do not wear clothing that can be caught on this system.
- Always observe safety warnings and notices on the machine and in the manual.

This page left intentionally blank.

2 Description

2.1 Function Of The Checkweigher

Packaging and processing companies rely on checkweighers to guard against giving away too much product or not providing the consumer with enough product.

Checkweighers also help companies use statistical analysis techniques to maintain tight quality control and reduce costs.

Basically, a checkweigher weighs items as they move along a production line, classifies them into preset weight zones, and ejects the items that are unacceptable.

Checkweighers can be both continuous motion and intermittent motion. A continuous motion checkweigher weighs the item as it moves across the weigh scale. Intermittent motion checkweigher will stop an item briefly on the weigh scale.


Numerous variations of the design are possible due to a customized design. E.g.: the Start/Stop push-buttons for the transport belts and main power switch can be in different locations depending on the weighframe design. Usually a weighframe for lightweight items are equipped with their own infeed and outfeed conveyors. Weighing for larger weighframes can have infeed and outfeed conveyors supplied by the customer or Mettler-Toledo Hi-Speed.

2.2 General Description

The customer's product, in its container, (bottles, canisters, etc.) will travel on a conveyor to the checkweigher. Product can arrive in a random manner.

A starwheel mechanism will index the container for weighing.


The container will then be transferred onto the scale for weighing, and then the container will exit the checkweigher back onto the conveyor.

 **Note:** The conveyor may be supplied by the customer or Mettler-Toledo Hi-Speed.


Off weight classified products will be rejected with a conveyor-mounted rejector.

2.3 Starweigh Design (Front View)

Typical Starweigh configuration (models may vary).





1	Start/Stop	10	Motor and Gear Reducer
2	Reset Button	11	Wheel Position Sensor
3	E-Stop Button	12	Rotary Solenoid Rejector
4	Infeed Guide Rail	13	Downstream Backup Sensor
	Package Sensor (Mounted on Infeed Guide Rail)	14	Thru Conveyor
	Bottle-down Sensor (Mounted on Infeed Guide Rail)	15	Safety Door Interlock
5	Starwheel	16	Weigh Pan
6	Gas Spring	17	Weigh Cell
7	Weigh Terminal	18	Isolated Scale Base
8	Touchscreen Display	19	Checkweigher Frame
9	Stack Light	20	Adjustable Feet

 **Note:** Depending on your specific application and the options purchased, your system may not have all of the items listed above.


2.4 Starweigh Design (Side Views)

Typical Starweigh configuration (models may vary).




- | | |
|---|--------------------------------------|
| 1 | Package Sensor (see 2.6 for details) |
| 2 | Bottle-down Sensor |
| 3 | Raise/Lower Assist Knobs (Qty. 2) |
| 4 | Gas Spring |
| 5 | Stack Light |
| 6 | Display Angle Adjustment Nut |

- | | |
|----|---------------------------------------|
| 7 | Weigh Cell |
| 8 | Lockable Main Power Disconnect Switch |
| 9 | Raise/Lower Assist Knobs (Qty. 2) |
| 10 | Lock/Unlock Lever for Linear Slide |
| 11 | Electrical Enclosure |


 **Note:** Depending on your specific application and the options purchased, your system may not have all of the items listed above.

2.5 Starwheel (Top View)


Starwheels vary in size according to container size.




1	Guide Rails
2	Starwheel
3	Rotary Solenoid Rejector
4	Downstream Backup Sensor
5	Rezero Pocket
6	Weigh Position

 **Note:** Depending on your specific application and the options purchased, your system may not have all of the items listed above.


2.6 Transport Details



1	Pocket Sensor Adjustment
2	Bottle Down Sensor
3	Package Sensor
4	Pocket Sensor (For One-Scale Operation Only)
5	Quick Release Thumbwheels for Starwheel Changeout
6	Wheel Position Sensor (Home Sensor)
7	Rotary Solenoid Rejector
8	Reject Position Sensor (Sync Eye)

 **Note:** Depending on your specific application and the options purchased, your system may not have all of the items listed above.


2.7 Starwheel Mount Identification



1	Gas Spring
2	Raise/Lower Assist Knobs (Qty. 2)
3	Lock/Unlock Lever for Linear Slide
4	Linear Slide

2.8 Interfaces

All interfaces are located on the IPC unit of the X-series, which, depending on the design is either located in the control cabinet door or in another location within the control cabinet.



1	Serial Interface COM2 D-Sub 9 Pins
2	Serial Interface COM1 D-Sub 9 Pins
3	LED indicator 12 V/5 V
4	24 VDC

5	HMI (Terminal Connection)
6	PS/2 (Keyboard Connection)
7	USB (2x)
8	Ethernet

If the weighing terminal has to be equipped with an externally accessible interface, a respective connection (extension of the IPC connection) usually is located in the control cabinet floor in the vicinity of the screwed cable gland.




Note: Some interfaces are used only when purchased as an option.

This page left intentionally blank.

3 Using The Touchscreen

The XS Touchscreen is fast and easy to operate by touching buttons, menu items and screen areas with your fingertip.



1	This area identifies the name of the current product selected and its corresponding setup number. When touched, the Main Package Setup screen appears.
2	Weight display – shows weight of current item on weigh section. When touched, toggles to a full-screen weight display.
3	This optional feedback icon provides immediate access to the Feedback Screen. The icon changes appearance depending on the control process: <ul style="list-style-type: none"> Red arrow pointing up: increasing trend Green arrow pointing down: decreasing trend
4	The padlock icon shows whether the system is password-protected; touching the icon will display the Login screen.
5	The Rezero icon allows for manual rezeroing of the system when the weigh platform is empty.
6	Touch the language icon to switch languages.
7	The date and time area shows the current date and time, and the area underneath that alternates between the profile group name and the name of the user currently logged on. Also, an additional security feature is found underneath the date and time area – if the touchscreen has not been touched for a specified amount of time (by the time the status bar has reached the end), the user is logged off the system (and the status bar will turn red).
8	View individual weights – this area shows the rolling statistics of average and standard deviation. When touched, the Setup Statistics Screen appears.

9	Throughput – this area shows the current throughput being achieved by the system. When touched, conveyor speed indicator appears.
10	Status – this area shows the status of the system, as defined by OMAC's Machine State Model. When touched, the OMAC Status Screen appears.
11	The Help icon (?) can be touched for on-screen information about the current screen.
12	This area contains, when appropriate, left and right arrow icons (← and →) to help move between recently viewed screens (functions just like the arrows on a browser).
13	This message area shows system information, including descriptions, alarms, and errors. When touched, the Message Screen appears.
14	The Menu listing icon will display the screens available to the current user.
15	The Home icon always returns a user to this Basic Screen
16	The Stop/Start icon allows the belt to be started or stopped.
17	This bar shows the remaining batch time available, if selected.
18	This bar shows the proportion of accepted to rejected packages.
19	Statistics – this area shows a statistical summary of total number of accepted items, the rolling mean value, and the proportion of accepted to rejected items (via the status bar). When touched, the Setup Statistics Screen appears.
20	Zone classification – this area shows the current zone limits, the total number of items classified into each zone, where the current weight is being classified, as well as special function counts (such as countercheck, metal rejects, or other faults). When touched, the Setup Zone Screen appears.
21	Mean value – this area displays the current rolling mean value. When touched, the user can choose among three mean value displays: gliding mean, total statistics, and hour statistics.
22	This area displays the name of the current screen being displayed. When touched, the Select Package Screen appears.
23	This area shows the nominal and tare weights of the currently selected package. When touched, the Setup screen appears. If Tare/Gross system this screen shows the tare weight of the active item.

3.1 Menu Tree

The appearance of the menu depends on the access rights (profile). If access is limited, not all of the menu options described below will appear.

Information	Messages	OMAC Machine Status	
	State	Component Status	
		Output Info	
		Input Info	
		Allocated Actions	XRTC: Log Selection
	XRTC		XRTC: Log Message
	System Information		XRTC: Motor and IO
	Stored Printouts		XRTC: Oscilloscope
		Total Statistics	Line Analyzer
		Current Hour	Motor Analysis
Production Data		Interval Statistics	
	Zone Classification	Batch Statistics	
	Statistics	Records	
	Items	Record Graphics	
	Large Weight Display		
	Approval Test		
			Main Package Setup
			Add. Package Setup
			Limit Setup
			Statistical Limits
Packages	Active Package		Interval Setup
			Dynamic Calibration
			Wheel Setup
	Package Maintenance	Package Changeover	
		Create New Package	
	Zone Calculation Setup	Edit Package	
		Delete Package	
		Copy Package	
		Print Package	
Actions	Login		
	Final Evaluation		
	Clear Wheel		
	Reset Machine		
	Gross Queue Size		
	Resync Gross Queue		
	Shutdown		

Continued on next page.


Continued from previous page.

Setup	Users		Edit Users
			Edit Profiles
			Assign Profiles
			Quick Access Setup
	General	Time and Date	
		Rejecter Settings	
		Rejecter Adjustment	
		Zone Actions	Printer Setup
		Miscellaneous Setup	Network
	System	Interfaces	Serial Setup PC
			Serial Setup XRTC
			Speed
			Motor Basic Setup
		Motor	Motor Setup
			Motor Calibration
			Motor Tick Size Setup
		Wheels	Wheel Design
			Rejecter Calibration
		Functions	Function Allocation
	Updates	Lane Setup	Logic Outputs
		Loadcell Setup	Logic Inputs
	PC System	Calibration	Output Actions
	Manufacturing Data	Loadcell Advanced Setup	Extra Counter: Actions
	File Copy	Filter Curve	Message Actions
	Shutdown		
Maintenance			

4 Installation

This chapter provides a quick overview of checkweighing and some of the common checkweighing terms.

4.1 Arc Welding Caution Notice

	CAUTION
	<p>NEVER arc weld anything to a checkweigher.</p> <p>NEVER connect or ground an arc welder to any part of a checkweigher.</p> <p>NEVER connect an arc welder to the same AC circuit as a checkweigher or its control.</p> <p>If you do, the heavy electrical currents induced by an arc welder will destroy your checkweigher's electronic components and will void your system's warranty.</p>

4.2 Preliminary inspection

Check all shipping containers for signs of damage upon receipt. **It is your responsibility to report any such damage to the carrier and file a claim at once.**

4.3 Checking The Installation Site

Examine the proposed installation site carefully. Make certain of the following:


The floor must be solid. Vibration from other machinery, passing fork-lift trucks, etc., can be transmitted to the scale by a flexible floor. Such vibration causes random weighing errors.


There must be no detectable air currents. A scale in a drafty area may "drift." That is, weight readings may change gradually, even if the same item is weighed over and over. The reason: air currents alter the forces on the scale platform and/or items being weighed in unpredictable ways.

The checkweigher must not touch any other machinery. Leave a small (at least .020 inch) air gap between the checkweigher and any other equipment in your line, such as an infeed or discharge conveyor. Any contact, no matter how slight, can transmit vibration to the checkweigher's scale; this vibration causes random weighing errors. If other equipment touches the checkweigher's scale assembly, this binds the scale and makes accurate weighing impossible.

4.4 Placing The Checkweigher In-Line

1. Move the machine, as shipped, to the installation site.
2. Carefully remove protective packaging materials.
3. Remove machinery from skids.
 - **DO NOT** strain interconnecting cables. Support units to prevent toppling.
4. Place the checkweigher in position in the production line.
 - Adjust height so items transfer on and off the checkweigher smoothly and without jamming.
 - Level the checkweigher by adjusting the jack screws. Check level, both in the direction of motion and crossways, at each end of the machine. Use a good quality machinist's level.
 - Leave a small visible air gap between the checkweigher and any adjacent equipment such as infeed or discharge conveyors. **DO NOT** let the checkweigher touch any other machinery.
 - Make certain that the checkweigher is firmly supported by all its legs. **DO NOT** leave a leg hanging in mid-air.
5. Verify the tightness of all fasteners on the checkweigher, in case some loosened during shipping.
 - Install the scale platform.
6. Bolt the checkweigher's feet to the floor.
7. Bolt the isolated scale base feet to the floor (see Note below).

 **Note:** After marking the hole locations on the floor for the isolated scale base (if supplied with your system), and before drilling the holes, remove the weigh pan(s) from the weigh cell(s) to ensure no damage occurs while drilling the holes.

	CAUTION
	Be sure to remove the weigh pan(s) from the isolated scale base before drilling the holes for the isolated scale base feet.

4.5 Electrical Connections

1. If your equipment was disconnected for shipping, interconnect all components as shown in the schematics provided.
2. Connect electrical power to the checkweigher system.
 - Power your system from a light-duty, transient-free 115/230 VAC line (1-phase, 50/60 Hz).
 - Provide a remote disconnect so power can be removed from the control for safe servicing.
 - **DO NOT** supply the checkweigher from the same power line as other machinery.
 - **DO NOT** power the checkweigher from a service outlet built into another machine. If you do, inductive loads that are part of that machine may interfere with the control's operation.
3. Provide a proper ground.
 - Connect the control to your building ground grid, using a continuous 14 gauge or larger stranded wire for the ground connection. **DO NOT** use wire nuts. Refer to the schematics shipped with your equipment.
 - The ground wiring must have a total resistance of one ohm or less.
 - **DO NOT** use the checkweigher frame, other machinery, or building structural members as ground connections.
 - **DO NOT** daisy-chain ground connections.


4.6 Applying Power


1. Apply power to the system.
 - Switch on power to the system at the main disconnect.
 - Verify that the control is operating normally. (Refer to the XS System Manual.)

This page left intentionally blank.

5 Maintenance

5.1 Cleaning The Checkweigher

	<p style="text-align: center;">CAUTION</p> <p>DO NOT wash down your checkweigher. It is not designed for use in a washdown environment.</p> <p>A water stream can force its way past the weigh cell's seals and destroy the strain gauges. In addition, such a stream can cause failure of electrical components.</p>
---	--

	<p style="text-align: center;">WARNING!</p> <p>Wear safety glasses while cleaning your checkweigher. This will protect your eyes from dust or other matter that may be thrown up by the compressed air blast.</p>
---	--

1. Stop the starwheel and thru conveyor (if configured).
2. Open the front Lexan door to gain access to the interior components.
3. Raise starwheel and lock in upper position.
4. Clean the machine by blowing it down with low pressure compressed air, brushing it gently, or both. **DO NOT** wash down your machine.

5.2 Care Of The Scale And Scale Platform

DO NOT use your checkweigher as a storage shelf, step ladder, or handhold.

Load cells used in Mettler-Toledo Hi-Speed equipment are sized to provide generous overload protection in normal use. However, stepping on a scale platform, using it as a storage shelf for heavy parts, or dropping a heavy tool or other object onto the scale may cause failure.

Before moving your checkweigher, remove the scale platform or weigh pan.

When moving your checkweigher, handle it by the supporting framework, not the scale platform. Applying excessive force to the scale platform will cause weigh cell failure.

5.3 Keep Electrical Cabinets Sealed Tightly

Avoid getting water or other contaminants inside the control cabinet, junction boxes, or electrical conduits.

Open the control cabinet only when needed for servicing or adjustment.

Whenever you open the housing, inspect the interior carefully for any evidence of water leaks. If found, repair immediately.

When finished, close the housing. Tighten the door clamping screws to seal out water.

If zone light lenses fail or are broken by accident, replace them promptly.

If you must replace the door gasket, apply silicone rubber sealant (RTV or equivalent) to the butt ends of the new gasket. Be certain that the butt joint is watertight.

Wherever an electrical cord enters an enclosure through a strain relief, apply silicon rubber sealant at the entry point.

5.4 Electrical Components

Before changing circuit boards or other components, remove AC power from the control at a customer-supplied remote disconnect.


Keep spare boards, fuses, and power supply assemblies on hand.

DO NOT expose spare boards to excessive heat, water, dirt, or static electricity.

Spare boards are supplied in special plastic envelopes or other packaging materials. These protect against static electricity. Keep boards packaged until they are needed.

5.5 Changing The Starwheel

1. Press E-stop to stop the conveyor.
2. Loosen the up/down lever lock¹.
3. Raise the starwheel mechanism by grasping the round knobs on the sides² and lift up.
4. Tighten the up/down lever lock¹ to lock the starwheel in the up position.
5. Place one hand under and against the bottom of the starwheel while loosening the black knobs on top of the starwheel. Place the black knobs in a secure place.
6. The starwheel will drop down onto your hand then gently remove the starwheel and place it someplace secure.
7. Reverse procedure with the new wheel.



6 Function Allocations

This screen allows a Supervisor or Technician to Activate or Deactivate available system functions. The list of available functions will vary according to the system options purchased by a customer.

The function allocation screen is used to view available functions. To view Function Allocations on the X-series control; from the Home screen touch **MENU—Setup—System—Functions—Function Allocations**.

Note: To view this screen you need Supervisor or Technician level access.

The following screen appears:




The “Function List” contains all functions available for a specific checkweigher. The functions are arranged in four groups, each identifying a different function classification (Standard, Control, Function, and Events).

Note: The active functions of each group are listed in the section “USED” on top.


Note: The inactive functions of each group are listed in the section “NOT USED” below.

 **Note:** The list of available functions will vary according to the system options purchased by a customer.


Standard




Control




Function



Events




Activate

To activate one of the inactive functions ("Not Used") select the desired function using the arrow buttons in and touch .


The function now appears in the same group under "USED" and the dialog box for editing the selected function opens.

Edit Function


To edit an active function select the desired function using the arrow buttons and touch .

The allocated function window appears, through which the user may configure the function.

Deactivate


To deactivate a function select the desired ("Used") function using the arrow buttons and touch .


The function now appears in the same group under "NOT USED".


 **Note:** Depending on which function is chosen there may be a choice of the following three:

- Inputs
- Parameters
- Actions

Assigning Inputs


1. Select the Function Input in the center dialog box. Use the "Inputs" dialog box to select the physical input to be assigned to the Function Input.
2. Touch the right arrow  between the dialog boxes to assign the Input to the Function Input.
3. In the case of a Sensor, define the sensor position (relative to the WLB) in the Input dialog box that displays on the bottom left.
4. If additional Function Inputs are required, repeat the above steps.


 **Note:** Required Function Inputs may vary based on the system configuration.

5. To unassign an Input, select the Input to unassign in the center dialog box and then touch the left arrow  between those boxes.

Setting Function Parameters


1. Select the parameter to be set by touching the parameter listed in the center dialog box under Parameters.
2. Touch the current parameter setting located below the parameter list. A dialog box will appear for changing the value.

 **Note:** For "Function Parameters" there may be a drop down box or an alpha/numeric value required.






Select Input Example


The distance input is relative to the edge of the Starwheel




Assigning Action

1. If not already expanded, the Action tree may be expanded by touching in the Actions tree area.
2. Select the sub-function in the tree to which you want to apply an action.
3. Select the Action to apply in the Actions dialog box to the right.
4. Touch the left arrow  between the two dialog boxes to assign the action to the sub-function.
5. Repeat the above 3 steps for additional action assignments.
6. To unassign an action, select the action to unassign in the center dialog box, then touch the right arrow  between those dialog boxes.

 **Note:** If required, an action may be added to more than one sub-function.



Assigning Action Sample


 **Note:** Actions are optional responses to specific system events. Be sure to review the actions allocated for each system to ensure required alerts are active.

Actions are split into five (5) different categories; System, Outputs, Messages Counters, and Rejecters. The list of available action categories will vary based on the sub-function selected.

The list of available actions is shown in the box on the right side of the screen. Some are global, some are function specific, and others are manually created in the action screens found in the menu (Output Actions, Message Actions, and Extra Counter Actions).

7 Starweigh Setup

7.1 Menu Setup


 **Note:** The Starwheel setup can only be accessed at supervisor level or higher.

1. Select the menu items **Setup—System—Wheels**.

The following screen is the menu default.



2. Touch the down arrow to view the rest of the Wheels sub-menu.



7.2 Wheel Design Parameter

This screen defines all parameters for a Wheel Design. You can add or remove different Wheel Designs and get access to the advanced settings for specific designs.

The screenshot shows the 'Wheel Design' screen on a Starweigh scale. At the top, the scale is in 'Little Can' mode, showing a weight of 17.14 g. The target weight is 18.00 g, and the tare is 0.00 g. The screen is divided into several sections:

- Selection:** A list of wheel designs (Design 1, Design 2, Design 3, Design 4) with 'Add' and 'Remove' buttons.
- Basic:** A section for 'Design 1' with parameters: Pockets (20), Positions (1), Weigh Pan Diameter (25), and Package Diameter (20 and 23).
- Motion:** A section for 'Design 1' with parameters: Pockets (20), Positions (1), Weigh Pan Diameter (25), and Package Diameter (20 and 23).
- Servo:** A section for 'Design 1' with parameters: Pockets (20), Positions (1), Weigh Pan Diameter (25), and Package Diameter (20 and 23).
- Advanced:** A section with buttons for 'Pockets', 'Load / Unload', 'Weigh Stations', 'Discharge Clear', and 'Wheel Workshop'.

The bottom of the screen features a status bar with a timestamp of 9:19:54 AM and a message 'Servo is ready'. Below this, a log shows three entries: '9:19:54 AM Backup cleared', '9:19:54 AM Backup cleared', and '9:19:54 AM Waiting for StarWeigh Servo RESET'. Navigation buttons include 'Start', 'HOME', 'MENU', 'Back', 'Help', and 'Apply'.

7.3 Wheel Design Basic

The basic parameters are defined by the physical design of the wheel.

Select the menu items **Setup—System—Wheel Design >Basic**

The screenshot shows the Starweigh Setup interface. At the top, there's a header with 'Little Can' and 'wertzu'. Below that, a target of 18.00 g and tare of 0.00 g are displayed. A large central display shows '17.14 g'. The 'Wheel Design' menu is active, showing a list of designs (Design 1 to Design 4) and an 'Add' button. The 'Basic' tab is selected, showing parameters: Pockets (20), Positions (1), Weigh Pan Diameter (25), and Package Diameter (20 and 23). The 'Advanced' tab shows 'Pockets', 'Load / Unload', 'Weigh Stations', 'Discharge Clear', and 'Wheel Workshop'. The bottom bar shows a status message: '9:19:54 AM Servo is ready'.

Press Add to create the new design. Next enter a name and the physical parameters defined below.

Definitions:

Number of Pockets

Number of pockets on the circumference of the wheel. Defined by the physical dimensions of the wheel. This count includes rezero and calibration pockets.

Number of Positions

Number of positions inside a pocket. Defined by the physical dimensions of the wheel. This count includes 1 position for each loaded item.

Weigh Pan Diameter

Diameter of the weigh pan aligned with the pockets of the specified wheel.

Min and Max Product Diameter

Define the minimum and maximum product diameters for the specific wheel.

7.4 Wheel Design Motion

Select the menu items **Setup—System—Wheel Design >Motion**

The screenshot displays the 'Motion' configuration screen for a specific wheel design. The interface includes a top status bar with product information and a large weight display. The main area is divided into sections for design selection, parameter configuration, and advanced settings. The 'Motion' tab is currently active, showing various motion parameters that can be adjusted. The bottom of the screen features a status bar with system messages and navigation buttons.

The motion screen shows the basic motion parameters for the specific wheel design. These parameters will be defined inside the Wheel Workshop. The motion parameters defined in the Wheel Workshop will be used as the upper limits (plus 10%) during article setup. The article specific values can then be modified as needed without changing the wheel design.

Definitions:

Index Rate

Shows the number of indexes during a one minute period.

Home Offset

Shows the offset for the wheel sensor to define the zero position of the wheel (in degrees).

Rotation Forward

Shows the number of degrees for a forward step. This angle represents the number of degrees required to properly center an item on the weigh pan.

Rotation Reverse

Shows the number of degrees for a reverse step. This angle represents the number of degrees required to release the product from the wheel such that a static measurement can be made.

Velocity Forward

Shows the velocity value for the forward step.

Velocity Reverse

Shows the velocity value for the reverse step.

Acceleration Forward

Shows the acceleration value for the forward step.

Acceleration Reverse

Shows the acceleration value for the reverse step.

Deceleration Forward

Shows the deceleration value for the forward step.

Deceleration Reverse

Shows the deceleration value for the backward step.

7.5 Wheel Design Servo

Select the menu items Setup—System—Wheel Design—Servo

The screenshot shows the X-Series Starweigh HMI interface. At the top, there's a header with 'Little Can' and 'wertzu'. Below that, a large display shows '17.14 g'. To the left of the display is a yellow circle with the number '1'. Below the display, there's a status bar showing '9:51:45 AM 4/9/2008' and 'Administrator'. The main menu on the left includes 'Wheel Design'. The 'Wheel Design' screen has a 'Selection' panel with a list of designs: 'Design 1', 'Design 2', 'Design 3', and 'Design 4'. Below the list are 'Add' and 'Remove' buttons. The 'Servo' tab is selected, showing parameters: 'Transmission Ratio' (10), 'Rotation Direction' (CW), 'Torque Limit Counts' (200), and 'Torque Limit Duration' (25). To the right of the 'Servo' panel is an 'Advanced' panel with buttons for 'Pockets', 'Load / Unload', 'Weigh Stations', 'Discharge Clear', and 'Wheel Workshop'. At the bottom, there's a status bar with a 'Start' button, 'HOME' and 'MENU' icons, a message '9:47:53 AM Servo is ready', and a 'HELP' button.

The Servo screen **shows** the basic servo parameter for the specific wheel design. These parameters will be defined inside the Wheel Workshop. The Torque Limit Counts and Duration parameters defined in the Wheel Workshop will be used as the upper limits (plus 10%) during article setup. The article specific values can then be modified as needed without changing the wheel design.

Definitions:

Transmission Ratio

Shows the transmission ratio of the gearbox

Rotation direction

Shows the direction for a forward step (Clockwise (CW) or Counterclockwise (CCW))

Torque Limit Counts

Shows the maximum torque limit of the servo motor

Torque Limit Duration

Shows the amount of time at the torque limit before a fault is triggered.

7.6 Wheel Advanced Setup

7.6.1 Pockets

Select the menu items **Setup—System—Wheel Design >Advanced >Pockets**

This screen is used to define special pockets.

Defined pockets are listed by index number in the Selection box. The index number represents the physical location of the pocket when the wheel is in the home position (after Reset). The pocket in-line with the load station is defined as index 1. Index number increments are in the direction of the wheel rotation. To add a new special pocket, choose the index where the pocket is physically located and choose the right pocket type.

Note: The Wheel Design Home Offset value should be chosen so that the Rezero pocket is located at index 1. This ensures that a rezero operation is completed immediately prior to the first item weighment.

Definitions:

Index

Enter the index number where the special pocket will be located.

Pocket Type

Choose the type of the specific pocket.

7.6.2 Load / Unload Station

Select the menu items **Setup—System—Wheel Design >Advanced >Load/ Unload**

This screen is used to define the load and unload stations.

The **Load Station** is the station where the products enter the starwheel. The station index is always 1.

Definitions:

Package Eye

The **Package Eye** is used to count the products entering the starwheel and synchronizes the start of indexing.

Package Eye Distance

Enter the distance from the package eye sensor to the edge of the starwheel. Choose the correct distance unit.

Package Eye Input

Choose physical input from the XRTC where the package eye sensor is connected.

Bottle Down

The **Bottle Down** sensor is used to detect fallen items. The bottle down detection process stops indexing, preventing invalid weighments and damage to the starwheel or the fallen product.

Bottle Down Distance

Enter the distance from the bottle down sensor to the edge of the starwheel. Choose the correct distance unit.

Bottle Down Input

Choose physical input from the XRTC where the bottle down sensor is connected.

Bottle Down Enable

Checkbox defines the presence or absence of bottle down sensor.

Unload Station

The **Unload Station** is the station where the products exit the starwheel.

Unload Index

Enter the position of the unload station with respect to the load station. The load station is defined as index 1. The index number increments are in the direction of the wheel's rotation.

Exit Distance

The **Exit Distance** and associated units are measured from the edge of the wheel to a common point beyond the wheel's circumference. The edge of the top plate is generally used as the common reference point. The Exit Distance is normally "0" when a Photo-Gated rejecter is used. The Exit Distance is a reference point required for single position wheels without a Sync Eye.

Sync Eye

The **Sync Eye** will be used to compensate for timing errors and product slip at the unload station. This function is only available when a photo-gated rejecter is present.

Sync Eye Distance

Enter the distance from the photo-gated rejecter sensor to the edge of the starwheel. Choose the correct distance unit.

7.6.3 Weigh Stations

Select the menu items **Setup—System—Wheel Design >Advanced >Weigh Stations**

This screen is used to define the weigh stations.

Weigh stations define the physical position of the weighcell inside the starwheel,

Definitions:

Selection

Under selection you find the configured weigh stations for the selected wheel design. You can add and remove stations for each individual wheel design.

Station Name

Name of the specific weigh station.

Station Index

Index where the weigh station is located.

Lane

Lane of the weigh cell.

Position

Position of the weigh cell inside the pocket. The positions are counted from the center of the wheel to the edge.

7.6.4 Discharge Clear

Select the menu items **Setup—System—Wheel Design >Advanced >Discharge Clear**

The screenshot shows the 'Discharge Clear' configuration screen. At the top, a status bar indicates 'Little Can' with a target of 18.00 g and a tare of 0.00 g. A large yellow display shows '18.70 g'. The main area is titled 'Little Can: Discharge Clear' and contains two panels: 'Selection' and 'Station Configuration'. The 'Selection' panel shows 'Discharge Station 1' with 'Add' and 'Remove' buttons. The 'Station Configuration' panel has fields for 'Station Name' (Discharge Station 1), 'Station Index' (15), 'Sensor Input' (XRTC_Inp1), and 'Sensor Delay' (15 ms). It also has buttons for 'System', 'Output Actions', 'Message Actions', and 'Counter Actions'. A bottom bar shows a status log with messages like '10:31:29 AM Servo is ready' and '10:31:29 AM Backup cleared'. Navigation buttons like 'Start', 'HOME', 'MENU', 'Back', and 'HELP' are at the bottom.

This functionality is required for systems which employ a discharge clear sensor.

Station Name

Name of the specific discharge clear station.

Station Index

Index where the discharge clear station is located. This value is normally 1 index beyond the unload station.

Sensor Input

Choose physical input from the XRTC where the discharge clear sensor is connected.

Sensor Delay

Defines a delay following the end of index after which the sensor state is evaluated.

7.6.5 Wheel Workshop

Select the menu items **Setup—System—Wheel Design >Advanced >Wheel Workshop**

The screenshot displays the 'Wheel WorkShop' interface. At the top, there's a header with 'Little Can' and 'wertzu'. Below this, a 'Target' of 18.00 g and 'Tare' of 0.00 g are shown. A large digital scale reads '17.07 g'. The 'Wheel WorkShop' menu is highlighted, showing various settings. On the right, there are buttons for 'Home Wheel', 'Start Indexing', 'Index Wheel', and 'Clear Wheel'. Below these are 'Apply', 'Edit', and 'Cancel' buttons. The bottom status bar shows the time '9:47:53 AM' and the message 'Servo is ready'.

The Wheel Workshop provides a test center to evaluate the optimum (maximum) settings for the specific wheel design's interaction with the product. The measured settings become the basic settings for the specified wheel design. A fine adjustment to these settings is permitted at the package definition level - **Packages—Active Package—Wheel Setup**.

Test Settings:

Index Rate

Enter the number of indexes during a one minute period. If the index rate is set too high, the wheel will skip indexes.

Home Offset

Enter the offset for the wheel sensor to define the zero position of the wheel (in degrees). Optimal measurements will be achieved when the home position places the rezero pocket in line with the load station. This configuration ensures that a rezero operation is performed immediately prior to the first item weighment.

Rotation Forward

Shows the number of degrees for a forward step. This angle represents the number of degrees required to properly center an item on the weigh pan. (360° divided by the number of pockets (including rezero)).

Rotation Reverse

Shows the number of degrees for a reverse step. This angle represents the number of degrees required to release the product from the wheel such that a static measurement can be made.

Velocity Forward

Enter the velocity value for the forward step.

Velocity Reverse

Enter the velocity value for the reverse step.

Acceleration Forward

Enter the acceleration value for the forward step. Excessive acceleration may compromise product stability.

Acceleration Reverse

Enter the acceleration value for the reverse step.

Deceleration Forward

Enter the deceleration value for the forward step.

Deceleration Reverse

Enter the deceleration value for the backward step.

Transmission Ratio

Enter the transmission ratio of the gearbox.

Rotation Direction

Choose the direction for a forward step (Clockwise (CW) or Counterclockwise (CCW)).

Torque Limit Counts

Shows the maximum torque limit of the servo motor.

Torque Limit Duration

Shows the amount of time at the torque limit before a fault is triggered.

Test Buttons:**Home Wheel**

Bring the wheel to the home position.

Start Indexing

Starts continuous indexing of the wheel.

Index Wheel

Perform 1 Index.

Clear Wheel

Begin indexing until the wheel is clear of products. Function disabled when the system is Stopped.

7.7 Wheel Specific Package Setup

Select the menu items **Packages—Active Package—Wheel Setup**. This screen is used to link a wheel configuration to a package.

Little Can
wertzu

Target 18.00 g Tare 0.00 g

17.91 g

9:55:56 AM 4/9/2008
Administrator

Little Can Wheel Setup

Wheel	Design 1		Unload Delay	10	ms
Index Rate	60		Window Lead	100	mm
Home Offset	20.00 °		Window Lag	20	mm

	Forward	Reverse		
Rotation	0.00	0.00 °	Queue Length	2
Velocity	200.00	200.00 %/s	Queue Settle Time	50.00 ms
Acceleration	400.00	400.00 %/s²	Torque Limit Counts	1
Deceleration	400.00	400.00 %/s²	Torque Limit Duration	1 ms

- Little Can
 - Main Package Setup
 - Add. Package Setup
 - Limit Setup
 - Interval Setup
 - Wheel Setup**

Apply Edit Cancel

Start HOME MENU

9:47:53 AM Servo is ready

9:47:51 AM %Serie HMI: 2.4.5
9:47:51 AM System started!

HELP

Touch the **Wheel** field to proceed to the **Wheel Selection** screen.

Select a wheel from the table and the button will turn yellow. The configuration display will update to show the default configuration for the selected wheel.

Select the basic, motion and servo tabs on the right side of the screen to view the design specific configuration settings. The displayed values show the configuration defined in the Wheel Setup > Wheel Workshop.

Choose the desired Wheel Design and press select.

The article specific settings of a Wheel Design allow a fine adjustment inside the article. The predefined wheel design values may be increased by 10% or decrease to any lesser value.

The adjustable settings inside the article are:

Index Rate

Enter the number of indexes during one minute period. If the index rate is set too high the wheel will skip indexes.

Home Offset

Enter the offset for the wheel sensor to define the zero position of the wheel (in degrees). This value may be modified for each package to accommodate specific loading requirements.

Rotation Forward

Shows the number of degrees for a forward step. This angle represents the number of degrees required to properly center an item on the weigh pan. (360° divided by the number of pockets (including rezero)).

Rotation Reverse

Shows the number of degrees for a reverse step. This angle represents the number of degrees required to release the product from the wheel such that a static measurement can be made.

Velocity Forward

Enter the velocity value for the forward step.

Velocity Reverse

Enter the velocity value for the reverse step.

Acceleration Forward

Enter the acceleration value for the forward step. Excessive acceleration may compromise product stability.

Acceleration Reverse

Enter the acceleration value for the reverse step.

Deceleration Forward

Enter the deceleration value for the forward step.

Deceleration Reverse

Enter the deceleration value for the backward step.

Unload Delay

Delay on product motion at the unload station. Set by rejecter calibration process when a photo-gated rejecter is present. The delay varies on index velocity, conveyor speed, and friction between the product and the conveyor. Changes to these variables may necessitate a updated photo-gated rejecter calibration.

Window Lead

Window Lead defines the leading edge of a window used by the photo-gated rejecter to resynchronize product positions. This value compensates for positional inconsistencies caused by product slip at the unload station. Choose the correct distance unit.

Window Lag

Window Lag defines the trailing edge of a window used by the photo-gated rejecter to resynchronize product positions. This value compensates for positional inconsistencies caused by product slip at the unload station. Choose the right distance unit.

Queue Length

Enter the number of products between the package eye and the edge of the starwheel. If the package eye is aimed beyond the trailing edge of an item, include the next item in the count.

Queue Settle Time

Enter the time that is needed to settle the queue.



Note: Avoid positioning the package eye near the trailing edge of the item body. This may lead to inconsistent queue counts, thereby by causing indexing irregularities.

Torque Limit Counts

Shows the servo motor maximum torque limit. This value may be adjusted to accommodate products of varying structural integrity.

Torque Limit Duration

Shows the amount of time at the torque limit before a fault is triggered.

7.8 Wheel Definitions

Pocket

A location on the circumference of the wheel which aligns with a station when the wheel is at rest. A given pocket may be open, in which case items may enter for processing, or the pocket may be specialized to meet other system processing needs (rezero, calibrate, etc).

Positions

The number of items which fit in a single pocket. Generally, there is one scale per position. The position closest to the center of the wheel is identified as position 1. Position numbers increase outward.

Wheel Design

A wheel design is named. If there are multiple wheel designs, a drop down list will be generated. When defining a new wheel, if the required wheel design does not exist, it must be created on the Wheel Design screen in section 7.3.

The properties of a specific type of wheel include:

- pocket count
- position count
- weigh pan diameter
- maximum throughput
- minimum package diameter
- maximum package diameter

Index (verb)

One complete movement of the wheel (not one complete revolution). This includes a forward movement component and a short reverse movement component, where the forward movement pushes an item onto the scale and the reverse movement releases the item so a static weight can be taken.

Index (noun)

The coordinate system used to identify pockets on the circumference of the wheel. Starting from 1, the index increases in the direction of the wheels forward movement. The load station is always located at Index 1.

Wheel Configuration

The wheel configuration is used when a specific package is being processed. When the target package changes, the wheel configuration changes to match the processing requirements of the new package. The wheel configuration includes the definition of specialized pockets, station setup, and motion characteristics. These configurations can then be linked to any existing package.

Station

A collection of hardware components at a given location within the Starweigh system. The station location is a combination of an index and a position. There are three different types of stations:

Load Station: Where packages load into the wheel. The load station is always located at Index 1.

Weigh Station: Links a weigh cell to a specific location within the wheel system. Each weigh cell within a system is linked to a specific lane. The weigh cell lane is then mapped to a specific index and position.

Unload Station: Where packages exit from the wheel. Typically 180° from load.

This page is intentionally blank.

8 Rejecter

8.1 Rejecter Setup

Select the menu items **Setup—General—Rejecter Settings**. This screen is used to define the rejecter device.

The screenshot shows the 'Rejecter Settings' screen. At the top, there's a header with 'Little Can' and 'wertzu'. Below that, 'Target' is 18.00 g and 'Tare' is 0.00 g. A large digital display shows '17.68 g'. To the right, there's a lock icon, a '0' button, and a date/time display '9:58:20 AM 4/9/2008' and 'Administrator'. The main area is titled 'Rejecter Settings'. On the left is a 'Rejecter List' with a table containing 'Rej 1'. Below the list are 'Add' and 'Remove' buttons. On the right is a detail pane for 'Rej 1' with the following fields: Name (Rej 1), Rejeter Type (Photo-Gated), Sync Eye (XRTC_Inp1), Output (XRTC_Outp1), Distance (155 mm), Duration (50 ms), and Delay Offset (+50) ms. To the right of the detail pane are buttons for 'Apply', 'Edit', and 'Cancel'. At the bottom, there's a status bar with 'Start', 'HOME', 'MENU' buttons, a status message '9:47:53 AM Servo is ready', and a 'HELP' button.

Create a new rejecter by pressing the button "Add". To modify an existing rejecter, select an entry from the Rejecter List and update the parameters provided in the detail pane.

Definitions:

Name

Enter the name of the rejecter station.

Rejecter Type

Enter the type of rejecter (Photo-gated will be standard for multi-position Starweigh applications).

Sync Eye

Physical input to the XRTC where the photo-eye is connected to the XRTC.

Output

Physical output from the XRTC which drives the rejecter device.

Distance

Photo-gated: Distance between the rejecter and the Sync Eye.

Standard: Distance between the rejecter and the Exit Position (specified as Exit Distance in Wheel Design).

Choose the right distance unit.

Duration

Duration of the output signal

Delay Offset

Offset for the rejecter dependent on rejecter type.

8.2 Rejecter Calibration


Select the menu items **Setup—General—Rejecter Calibration**. This screen is used to calibrate the photo-gated rejecter parameters (Window Lead, Window Lag, Unload Delay).




Follow the instructions displayed on the screen.



Fill two pockets prior to the unload station with product. This allows the calibration process to measure the effective distance to the rejecter photoeye (slip compensation) and the distance between subsequent groups of product.



Start the test cycle.



Review the measured calibration results and press Apply to commit the changes.



The calibration will be done.

This page is intentionally blank.

9 Tare Gross (Optional)


The Tare-Gross option has been designed to provide a means of monitoring variances in packaging to allow a more accurate assessment of the amount of product actually dispensed. It consists of two or more interconnected checkweighers; the first weighs the empty (tare) package, the other provides the weight of the amount of product added to the empty container.

A Tare-Gross system generally consists of two independent weigh platforms and their respective checkweigher controls. Such systems can be cascaded and may be asynchronous or synchronous (in terms of the ability to distinguish a package's presence), and captive or non-captive (in terms of mechanical package restraints).

In any of these forms, the checkweighers used can also perform as stand-alone units (in case of a communication or similar failure) to ensure that your production line does not depend on the special functions of the interconnected Tare-Gross checkweigher system.

In operation, the Tare checkweigher can be considered a standard control in most of its functions and user-interface. The major departure is the dedicated communication link (downstream) to the Gross or Gross cascaded control. This dedicated communication link is responsible for carrying data configurations concerning the weight of each package weighed and the tare reject status.


The Gross (or Gross cascaded control) is highly modified in its internal functions. It is responsible for communicating with the Tare machine, extracting each tare weight derived, storing that data in a FIFO (First In First Out) until needed, and determining whether or not an out-of-sync condition has occurred.

 **Note:** This out-of-sync condition typically occurs when a package has been removed between the Tare and Gross machines, either by an operator or a mechanical malfunction.

Display

During operations, the Gross or Gross cascade checkweigher displays the tare weight corresponding to the package being weighed in the tare field on the Basic Screen (unless the package rate is too fast). This tare weight is the sum of the tare weight determined by the upstream machine plus any supplemental tare you may have set up. The supplemental tare, typically "0.00", can represent a capping operation or other known fixed product addition that occurs between the two controls. The package weight displayed represents the weight of the package being weighed minus the tare weight shown in the tare field. This weight is often called the 'net' weight.

9.1 Definitions

 **Note:** The Tare/Gross system consists of 2 checkweighers. Tare being the upstream checkweigher and Gross being the downstream checkweigher.


Tare Machine – The upstream checkweigher responsible for weighing the empty containers. Each empty weight (or tare) is transmitted to the Gross machine.

Gross Machine – The downstream checkweigher responsible for receiving the tare weights from the tare machine, weighing each filled product, and subtracting the correct tare weight. The result is displayed as the net weight on the Gross machine's display.

Gross-Cascade Machine – Often referred to as a feed-forward system. Similar to the gross machine, but used in a system which consists of two or more product filler stations, each with the equivalent of their own Gross machine following.

FIFO – First In, First Out queue for the Tare/Gross system.

Asynchronous – A Tare/Gross system that stores tare weights in a FIFO of variable length. An asynchronous system cannot detect the removal of an item between the tare and gross scales.

 **Note:** An asynchronous Tare/Gross system means that item tracking is only guaranteed for items entering the system via the tare and leaving via the gross machine. Items added or removed between the tare and gross machines will result in an "out-of-sync" state, which will not be able to be detected by the checkweigher and will cause inaccurate weights.

Synchronous System – A Tare/Gross system that stores tare weights in a FIFO of fixed length and uses timed indexing pulses to shift weights through the FIFO. The indexing pulses must be generated whether or not items are actually present. This system can determine if an item was removed between the two checkweighers.

Out-Of-Sync Condition – Any condition where tare weights (from the FIFO) do not properly match up with the gross weights.

Non-Captive System – A Tare/Gross system without mechanically-restraining package transports. Which can be a synchronous or asynchronous system.

Captive System – A Tare/Gross system with mechanically-restraining package transports. Synchronous systems only.

Node – Represents a checkweigher

9.2 Tare Interface

Note: Tare queue parameters are defined in the tare queue function which is found in Function Allocations.

A tare node maintains a tare queue to track items ready for transmission to a gross node.


Global maximum size is defined in the tare queue. A tare node allows a Supervisory level user to set the maximum size of the tare queue. The maximum tare queue size defaults to 100 until modified by a supervisor.

The tare-to-gross conveyor's maximum item capacity should be considered the upper limit for the maximum tare queue size.

A tare node defines a tare queue entry point. The tare queue entry point is a physical location beyond the Weigh Light Barrier (WLB) at which a tare item's weight and status is added to the tare queue.


Note: Weigh Light Barrier (WLB) in a Starweigh system is defined as the end of index at the Unload Station.

Each item to reach the tare queue entry point will be added to the tare queue causing the tare queue size to grow by one. The tare queue stores each tare item until the communication channel indicates the item data has been successfully transmitted to the gross node.



9.3 Tare Reject Requirements

A tare node may classify an item as a reject regardless of the presence of a rejecter. Any item classified as a reject by a tare node is a 'tare reject'. Once classified as a 'tare reject', this item classification must follow the item as it proceeds from node to node. If a rejecter is not present, the 'tare reject' classification must follow the item to the subsequent gross node. A new rejecter type termed a 'tare rejecter' handles 'tare reject' items flowing downstream. A 'tare reject' stays in statistics until the item is physically rejected.



Note: A system classified as a gross node allows a supervisory level user to define any rejecter as a 'tare rejecter' in gross queue function allocations.


9.3.1 Setting up the Optional Tare Rejecter (Must be Setup on the Tare Node Only)

Note: To view this screen you need Supervisory level access.

The function of the Tare Rejecter is to tag an item until it is physically rejected at the Gross node or further down the line.

On the tare node, the user must create a tare rejecter. The Rejector Settings screen can be accessed on the X-series control by touching **MENU**→**Setup**→**General**→**Rejector Settings**


Note: The rejecter name is defined by the user.



Touch the Rejecter List field then choose Tare Rejecter from the drop down menu and confirm with OK.

Touch Apply.

After a Tare rejecter is created then zone classification(s) need to be assigned. See next page.



9.3.2 Tare Rejecter Zone Classification (Must be Setup on the Tare Node Only)

Note: To view this screen you need Supervisory level access.

The Tare Rejecter Zone Classification is required in order to tag an item until it is physically rejected at the Gross node or beyond. Be sure to setup the Gross node to physically reject the tare reject item either at the Gross node or further down the line.

On the tare node, the zone classification(s) need to be setup for the tare rejecter. The Zone Classification screen can be accessed on the X-series control by touching **MENU**→**Packages**→**Active Package**→**Limit Setup**



Touch a zone then touch Actions. The Zone Actions screen will appear.

Note: Names in quotes under the Actions List may not be the same on all systems as the names are user defined.

Under Actions List touch Rejecter "Tare Rejecter" then touch the right arrow to place it in the Allocated Actions field.



Touch the left arrow below the Allocated Actions.

A prompt appears, touch **Yes** to confirm.




9.4 Gross Node Item Tracking and Communications Channel

A system is classified as a gross node once the gross queue function is setup. A gross node maintains a gross queue to store the item data received from the tare queue. Tare weights are transferred from the tare queue over the communication channel to the gross queue. An item is maintained in the gross queue until the item leaves the gross node in a FIFO (first-in first-out) manner. The gross queue is defined with a global maximum size.

Gross Maximum

Note: Gross queue maximum parameters are defined in the gross queue function which is found in Function Allocations.

The gross node allows the supervisory level user to set the maximum size of the gross queue. The maximum gross queue size defaults to 100 until modified by the supervisor. A gross node allows a supervisory-level user to require execution of any standard X-series action when the gross queue size exceeds the specified maximum. Such an occurrence will be termed a gross queue overflow.



Gross Minimum

Note: Gross queue minimum parameters are defined in the gross queue function which is found in Function Allocations.

The gross queue is defined with a package-specific expected minimum size. This gross-queue-expected minimum should be set to a non-zero value only if the system is expected to be under a continuous quantifiable load.

A gross node allows a supervisory level user to set the expected minimum size of the gross queue. The expected minimum gross queue size defaults to 0 until modified by the supervisor.


A gross node allows a supervisory level user to require execution of any standard X-Series action when the minimum gross queue size is not met. Such an occurrence will be termed a gross queue underflow. The response to this error is typically a warning message or a stack light pulse.

The gross queue underflow error is ignored after resync operations until the minimum queue size threshold is broken.

X-series Gross Node Action Response


Note: Gross action response is defined in the gross queue function which is found in Function Allocations.

A gross node allows a supervisory-level user to specify a standard X-Series action in response to the arrival of new physical items while the gross queue is empty. This occurrence will be termed a buffer empty exception.



Additionally, the available actions associated with a buffer empty exception include the auto tare option. When selected, the auto tare option generates a tare weight should a measured tare weight be unavailable.

When selected, the auto tare option is configured to generate a tare from either a default package specific total tare weight (tare weight + supplemental tare) or from an average of the previous N tare weights.



If the average algorithm is selected, the default package specific total tare weight is used until at least 1 tare weight is received, after which a running average is used until N is reached.

If the auto tare option is triggered by a buffer empty exception, the system continues to use the selected auto tare algorithm until a resync is performed.

Each subsequent auto tare item will trigger the actions associated with the buffer empty exception.

9.5 Synchronization Requirements



All Tare/Gross nodes include a Resync button which clears the local system's communication queues.

Note: The system does not recalculate statistics to accommodate items removed during resynchronization operations.

Depending on whether Gross or Tare Queue is active you will have the following choice.

To view the Resync Gross Queue on the XS control touch **MENU—Actions—Resync Gross Queue**. If active.

To view the Resync Tare Queue on the XS control touch **MENU—Actions—Resync Tare Queue**. If active.



Note: Typically Tare Resync will not be necessary.

9.5.1 Clear Wheel



Note: Be sure to remove all items from the system when performing a resync.

A clear wheel execution may also be needed to remove items in the wheel.


Always execute clear wheel to remove items in the wheel. The system will not know the items have been removed if they are removed manually but the clear wheel wasn't performed on the X-series control.

Note: Be sure to have Clear Wheel assigned to Supervisor level in assigned profile.

To view the Clear Wheel screen touch **MENU—Actions—Clear Wheel**. A confirmation will display, touch **Yes**.



9.6 Security Requirements

 **Note:** The ability to enable Tare/Gross functionality is restricted to users granted Technician 3 access.


9.7 Exclusions

An asynchronous Tare/Gross system is not responsible for synchronization issues caused by rogue items entering or leaving the system between a tare node and a gross node. This limitation covers operators adding or removing items, items falling from a conveyor, and items which fail to successfully trigger synchronization devices like reject and accept verification sensors.


The communication channel will not transmit the machine state between a set of tare-gross nodes. While machine state may be directly communicated by an external supervisory automation system, or indirectly inferred via input sensors (i.e. downstream backup sensors, etc), the communication channel itself will provide no such status information.


The system operator is responsible for determining when a resynchronization operation is necessary. The system will never demand a resynchronization operation.

The system operator is responsible for appropriately removing items prior to resynchronization operations. This may include a Clear Wheel execution (see Clear Wheel on Page 8-9). Never remove items from the wheel manually.


 **Notes:** Package changeover events and resynchronization operations will not be communicated via the communication channel.

The Tare and Gross queues are reset following a power cycle or XRTC reboot.

 **Notes:** Change made in the Function Allocations screen may trigger an XRTC reboot. Changes to the Function Allocation screen should only be made when the Tare/Gross system has no products loaded on the system.

 **Notes:** Tare specific statistics are not available at the gross node and vice versa.

9.8 How to Set Up the Tare/Gross Interface

 **Note:** To view this screen you need Supervisory level access..

Tare-Gross is setup on the XS control by touching **MENU —Setup —System —Functions—Function Allocations**. (See section 6 for an overview of the Function Allocations screen)

9.9 Tare Queue Function Allocation Settings (Tare Machine only)

Setting	Default	Description
Inputs		
None		
Parameters		
Tare Output Port	COM2	Serial port used for transmitting the tare weight to the gross machine.
Maximum Queue Size	10	Maximum number of tare weight values that will be buffered in the tare machine. Normally the tare weight values are immediately transmitted. However, if there are communication problems, up to this number of tare weights values will be queued in the tare machine before they begin to be discarded. This value should never be greater than the number of items normally loaded between the tare and the gross scale.
Actions		
Tare Queue Message Sent	None	Provide a counter that counts the number of tare messages that are transmitted, including resends.
Tare Queue Send	None	Provide a counter that counts the number of tare weight messages that are prepared for transmission.
Tare Reject	None	Provide a counter that counts the number of items classified as “tare rejects”. These items will be physically rejected at the gross node with an active tare rejecter.

9.10 Gross Queue Function Allocation Settings (Gross Machine only)

Setting	Default	Description
Inputs		
None		
Parameters		
Tare Input Port	COM2	Serial port used for receiving the transmitted tare weights from the tare machine.
Minimum Queue Size	0	Minimum number of tare weight values that will be buffered in the gross machine before a Gross Queue Underflow condition is determined. Normally the tare weight values are immediately transmitted from the tare machine and received at the gross machine. However, if there are communication problems, or the gross machine is starved for incoming items, the number of tare weight values will fall below this setting. Setting this value to zero disables the function.
Maximum Queue Size	100	Maximum number of tare weight values that will be buffered in the gross machine. This number should be set greater than the number of items that would ever be able to between the tare scale (weigh station) and the gross scale (weigh station). If additional tare weight values are received, causing the Gross Queue to expand beyond this number, a Gross Queue Overflow condition is determined and tare values will be discarded.
Auto Tare Configuration	Default Tare	Selects the value to use as the tare weight if a tare value is not available from the Gross Queue. Choices are None which will use a zero tare value, Default Tare which uses the value entered in Package Setup, and Average Tare which uses the average weight of the last number of weights.
Average Tare Sample Size	5	The number of weights to average for the Average Auto Tare.
Actions		
Gross Queue Overflow	None	Actions may be selected to occur in response to the gross queue exceeding its maximum number of tare weights (maximum queue size).
Gross Queue Underflow	None	Actions may be selected to occur in response to the gross queue exceeding its minimum queue size setting.
Buffer Empty Exception	None	Actions may be selected to occur in response to the gross queue being empty at the point where a tare value is needed to apply to an item gross weight.
Tare Rejecter	None	Specifies the rejecter used to reject incurring "tare reject" items (see Section 8.3.1). Additional actions may be selected to occur in response to a "tare reject" item.

9.11 Gross Queue Quarantine Function Allocation Settings (Gross Machine only)

The gross quarantine function places the gross machine into an automatic reject mode where all items currently in the gross queue plus an extra number of items will be rejected.

Setting	Default	Description
Inputs		
Trigger Input	None	External input used to trigger the quarantine function.
Parameters		
Extra Quarantine Items	5	Number of items in addition to all items in the gross queue at the time that the quarantine function is triggered to be rejected.
Actions		
—	None	Actions may be selected to occur in response to a quarantine condition.

9.12 Tare/Gross Serial Setup XRTC Settings (Both Tare and Gross Machines)

Setting	Default
COM2	
Baud Rate	9600
Data Bits	8
Parity	None
Stop Bits	1
Protocol	Tare Gross

9.13 Main Package Setup – Supplemental Tare

Note: To view this screen you need Supervisory level access..


Supplemental tare accounts for additional tare weight after a filler operation e.g. label, cap, or any other additional non-product weight applied after the filling process and before gross node.

The supplemental tare weight must be defined on the machine immediately following the application of the supplemental tare.

To view the Supplemental Tare screen on the XS control touch **Menu**→**Packages**→**Active Packages**→**Main Package Setup**

The Tare value is driven by the active tare value used to calculate the displayed net weight.

Net Weight = Gross Weight – Tare Weight – Supplemental Tare (See the diagram below.)



9.14 Tare/Gross Large Weight Display (Gross Node Only)

Touch the Large Weight Display on the main screen to toggle to the Net/Tare screen.

The “Tare” display depends on whether it’s a Static Weight or Dynamic Weight Value.

- **Static Weight:** Package Tare Weight + Package Supplemental Tare
- **Dynamic Weight:** Gross Queue Dynamic Tare or Auto Tare




The large weight display always displays dynamic weights while the machine is running. Once the machine is stopped then static weights are displayed. To toggle between the dynamic and static weights touch the lock.

9.15 Reset Actions

A system reset will be required after a system reboot, an e-stop, or a servo fault.

1. Press the **Reset** button attached to the conveyor to perform a reset.

 **Note:** When the Reset is pressed or initiated from the X-series controller you will lose all of the products that are in queue on both the Tare and Gross machines.

You will be prompted to clear the items just past the package and the bottle down photoeyes.


The system will reset back to the servo home position.

9.16 E-Stop


When either e-stop is pressed it will stop both conveyors and the X-series controller will prompt the user to clear the starwheel.

9.17 Bottle Down Safety Feature

When a bottle down is detected by the bottle down photoeye the X-series controller will prompt the user to clear the area.

 **Note:** The system will not startup until the area is cleared.

10 X-Purge Enclosure (optional)

 **Note:** Disregard this section of the manual if your system does not have an explosion proof enclosure. Skip to section 11.

10.1 Division 1: X-purge protection


The installation of an X-purge system on an enclosure in a Division 1 area renders the area within the enclosure to an essentially non-rated environment. Thus, normally rated equipment may be installed within the enclosure (within reasonable limits, such as complying with temperature and power restrictions).

An X-purge system is fully automated. The system not only provides the protective purge and maintains positive pressure, but it also automatically controls the connection and disconnection of power supplies and signal paths. A well-designed X-purge system will also automatically control flow rates, internal pressure regulation, purge timing, and switching of states between purge flow and normal operation

10.2 Pre-installation testing

Before installing your system in its final location, you may wish to test it to verify that the purge system is functioning correctly.

10.3 Division 1 X-Purge Test


 **Note:** Pre-installation testing should *always* be conducted in a safe area.

10.3.1 Equipment Required

- Clean, dry purge air or inert gas supply equipped with local water/oil separator or filter capable of supplying 40 to 300 SCFH at 60 to 80 PSI.
- Fittings and tubing for purge air or inert gas supply (0.25" NPT Male to connect to the inlet of the purge system).
- Local air pressure shutoff valve.
- AC power line (with ground) to pigtails (tinned bare wire, stripped 0.25"), 120V fused at 10A.

10.3.2 Procedure

1. Place the unit in a safe area near a source of the purge gas to be used (compressed air line or other inert gas source).
2. Temporarily install a pressure regulator, water/oil separator or filter, shutoff valve, pressure relief valve, and pressure gauge in the purge air or inert gas line.
3. Bleed the purge air or inert gas line to insure that dirt, moisture, and other contaminants are cleared from the line prior to connecting the line to the unit!
4. Connect the purge gas line to the inlet of the regulator on the Purge Unit.
5. Remove the cover of the explosion-proof I/O casting.
6. Connect an AC power line (not plugged into AC power outlet!) to the power interface board. For connection location and wiring, see system schematic.

7. Close all access doors and covers.
 8. Apply purge gas to the system by opening the shutoff valve (if installed). Adjust the pressure regulator on the air-in box so that the pressure gauge indicates 80 PSI.
 9. Apply AC power to the unit.
 10. Once the pressure inside the unit reaches 1.0" Water Column and at least 40 SCFH, the Purge Status LED will illuminate yellow, indicating that it is purging. If the purge status indicator does not turn yellow, inspect the unit for leakage. The gasketed panels can be checked with a soap solution. If leaks are not obvious, verify that the purge air of inert gas is clean and dry and that the pressure at the inlet is 33 - 60 PSI.
 11. **DO NOT ATTEMPT TO OPEN THE ENCLOSURE WHILE IT IS PRESSURIZED!**
 12. Note the reading on the Pressure Gauge while slowly turning the Air Input Regulator up until the purging process stops and the Purge Status LED flashes red with an error code of 2 – 2 (over pressure) or 3 –2 (over flow).
 13. Remove AC power from the enclosure for a minimum of 30 seconds. Decrease the pressure reading on the pressure gauge by 5 PSI. This change may vary slightly on some unit; if in later testing the unit fails with an over flow error (3-2 blink code), decrease the inlet pressure by another 2 PSI. Note this pressure for use during start-up.
 14. Re-apply AC power. The Purge Status LED will illuminate orange. The system should purge for a minimum of 8 minutes. The time will vary according to the flow rate of the air into the enclosure; lower flow rates will result in a longer purge time.
 15. After the purge is complete, the Purge Status indicator will illuminate green. AC power is now applied to the internal electronics so the display or PC will now turn on automatically.
 16. If the purge status light blinks red, one of several possible errors has been detected. Please refer to **10.7 X-Purge** on page 10–7 for an explanation of the possible error codes.
-  **Note:** Other equipment on the airline can cause pressure fluctuations that may result in the unit shutting down to protect itself.

10.4 Pack-Seal Connection Instructions

A conduit seal is necessary for most equipment enclosures in hazardous areas. For Y-purge and X-purge systems, they are always required. Please consult your local code for other instances and full details.



Note: ALWAYS follow all NEC, NFPA, and local codes when installing conduit and packseals in hazardous areas! It is *very important* that knowledgeable personnel, familiar with national and local codes, supervise hazardous area equipment installations.

The sealing compound generally used for pack-seals is an inorganic, chemically setting, magnesium oxide base material, which develops a slight expansion while hardening into a porcelain-like body. Sealing Compound is supplied as a powder and need only be mixed with water to apply. Approximately one ounce of sealing compound is needed per cubic inch of space to be filled.

The sealing compound powder has a shelf life of six months when stored in unopened, tightly sealed containers in a dry location at 70°F.

Any equipment accidentally splashed with sealing compound should be cleaned with soap and water before the sealing compound cures.

10.4.1 Equipment Required

Four PAC-Seal fittings, 0.75"NPT only for the X-Purge (2 for conduit connection at the enclosure or I/O casting, 2 for connection in the safe area), or sealing conduits. The PAC Seal and conduit size selected will depend on the size and number of conductors, which must be run to the unit. Check the NEC tables to determine the conduit size necessary

- Conduit for electrical signals and for electrical power (separate runs), NEC and NFPA approved for use in hazardous areas.
- NEC and NFPA approved flexible conduit if needed for difficult installations.
- Fittings as required for permanent conduit installation NEC and NFPA approved for use in hazardous areas.
- Signal cables, power cables, and connectors as required to mate with the equipment within the enclosure or cast aluminum box.
- AC power switch for use in the safe area

10.4.2 Procedure

1. Threaded surfaces and pour locations should be cleaned with soap and water and thoroughly dried before proceeding.
2. Install two conduit runs (one signal, one power) between the I/O casting (X-Purge) and AC power source (located in a safe area or in an explosion-proof box).
3. Shake the sealing compound powder well before mixing with water. The recommended mix ratio is 5 parts powder to 1 part clean water, by weight. Place 70°F water into a clean mixing container and gradually add powder to water while mixing. Continue mixing until a uniform consistency is obtained. Mixing may be done with a slow-speed mixer or by hand with a spatula. The minimum amount of water (as specified above) should be used as excess water reduces mechanical strength, increases shrinkage, and delays set time. Failure of the cement to adhere indicates setting has begun – discard cement, do not attempt to re-temper by adding more water.

4. The compound may be applied by pouring, casting, or mechanical dispenser. The sealing compound hardens with an internal chemical-setting action in 18 to 24 hours at ambient temperature. Working time of the sealing compound when the powder is mixed with water is approximately 30 minutes at 70°F. If accelerated curing is desired, low temperature oven drying at 180°F can be used. Do not expose the sealing compound to higher temperatures, constant water immersion, or steam environments while curing. If high humidity resistance is required in the cured product, a moisture-resistant lacquer or silicone coating should be applied to the exposed surfaces.
5. The packing fiber is made from an environmentally safe, non-asbestos material. It is easy to use and forms a positive dam to hold the compound. The fiber is placed around each individual wire or cable at both ends of the cavity for horizontal pouring in the PAC Seal so that the Sealing Compound can encapsulate each completely. For vertical pouring, the packing fiber need only be placed at one end.
6. We recommend a special blend of lubricants, LUBT-2, for use with threaded joints. This lubricant is to be used to prevent galling of the pipe threads when threaded into a coupling, junction box, etc. It insures a quick release and undamaged male and female threads when parts are disassembled. The thread lubricant is high quality lubricant to be used in temperatures ranging from -40°F to +50°F. It is recommended for use in a hazardous location.

The PAC Seal Compound, packing fiber and LUBT-2 are available from Killark at <http://www.killark.com/>.
7. For enhanced reliability of the unit, install an AC line conditioner. AC power lines should be no smaller than 14 gauge and have a TRUE EARTH GROUND.

10.5 Purge Air Line Connection Instructions

After the unit has been mounted in its final location in the hazardous area, it must be permanently connected to a purge air or inert gas line and checked for leaks and proper operation of the purge/pressurization system. Only when its pressure integrity has been established should electrical signals and power be brought “live” to the unit.

ALWAYS follow all NEC, NFPA, and local codes when installing purge systems in hazardous areas! It is *very important* that knowledgeable personnel, familiar with national and local codes, supervise hazardous area equipment installations.

10.5.1 Equipment Required

- Clean, dry purge air or inert gas supply equipped with local water/oil separator or filter capable of supplying 40 to 300 SCFH at 60 to 80 PSI.
- Fittings and tubing for purge air or inert gas supply (0.25” NPT Male to connect to the inlet of the purge system).
- Local air pressure shutoff valve.

10.5.2 Procedure


1. Mount the enclosure in the location in which it will be installed. This must be near the source of air or inert gas to be used for the purge system.
2. Install the pressure regulator, water/oil separator or filter, shutoff valve, pressure relief valve, and pressure gauge in the purge air or inert gas line.
3. Bleed the purge air or inert gas line to insure that dirt, moisture, and other contaminants are cleared from the line prior to connecting the line to the unit!
4. Connect the purge gas line to the inlet of the regulator on the Purge Unit.
5. The Pack-Seals bringing the power and signals to the explosion-proof I/O casting should already be installed. Connect the signal lines to the interlock system.
6. Ensure that the power to the AC supply lines is disconnected. Connect the power line(s) to the X-purge system.
7. If the area can be made safe, you may want to test your connections before closing the explosion-proof I/O casting. If you test the system in place, it is VITAL that you ENSURE THAT THE AREA IS SAFE during the test and FOLLOW ALL APPLICABLE SAFETY PROCEDURES for “hot work” in a hazardous area! You can test connections without purging by holding down the “Bypass Purge” button while applying power to the XPI Board, release the button within 30 seconds of power application to prevent a diagnostic error. When the button is released, power and signals are immediately “live” to the system and the Purge Status LED will blink green; you can test operation to make sure that the connections have been made correctly. Disconnect power IMMEDIATELY upon completion of this test to ensure that the unit is not erroneously operated in bypass mode!
8. When the signal and power connections are complete, replace the cover on the I/O casting and secure with the supplied 14 hex-head bolts. Torque these bolts to 7.5 ft. lbs.

10.6 X-Purge Start-Up Operation

1. When the air, signal, and power connections are complete, replace and close all access doors and covers.
2. Determine the size of enclosure in cubic feet to set the Dip Switches on the DMB Board.
3. Apply AC power. The Purge Status LED will illuminate red. Power is now applied through the Intrinsic Safety Barriers to the purge/pressurization control circuits only.
4. Apply purge gas to the system by opening the shutoff valve (if installed). If the pre-installation test has been performed, the air-in pressure regulator will be preset – you should begin the start-up process at the pressure noted during testing. Otherwise, adjust the pressure regulator on the air-in box so that the pressure gauge indicates 30 to 60 PSI.
5. Once the pressure inside the unit reaches 1.0" Water Column and at least 40 SCFH, the Purge Status LED will illuminate orange, indicating that it is purging. If the purge status indicator does not turn orange, inspect the unit for leakage. The gasketed panels can be checked with a soap solution. If leaks are not obvious, verify that the purge air or inert gas is clean and dry and that the pressure at the inlet is 30 - 60 PSI (or, if a pre-installation test was completed, at the pressure noted during that test).
6. **DO NOT ATTEMPT TO OPEN THE ENCLOSURE WHILE IT IS PRESSURIZED!**
7. If the pre-installation test was completed and the unit appears to be functioning correctly within the same parameters as during the test, you may skip the remaining steps of this procedure.
8. Note the reading on the Pressure Gauge while slowly turning the Air Input Regulator until the Purge Status LED flashes red with an error code of 2 – 2 (over pressure) or 3 – 2 (over flow).
9. Remove AC power from the enclosure for a minimum of 30 seconds. Decrease the pressure reading on the pressure gauge by 5 PSI. This change may vary slightly on some unit; if the unit fails during purging with an over flow error (3-2 blink code), decrease the inlet pressure by another 2 PSI.
10. Re-apply AC power. The Purge Status LED will illuminate yellow. The time will vary according to the flow rate of the air into the enclosure and size. (See step #2)
11. After the purge is complete, the Purge Status indicator will illuminate green. AC power is now applied to the internal electronics and the signal relays are closed.
12. If the purge status light blinks red, one of several possible errors has been detected. Please refer to **10.7 X-Purge** on page 10–7 for an explanation of the possible error codes.

10.7 X-Purge Color Codes

X-purge systems are fully automatic; the system safely disconnects power and signal paths in the event of a purge failure. The purge control also performs automatic self diagnostics and can report other errors. The table below details both the normal conditions and the errors (fatal and non-fatal) that are reported by the purge status LED.

 **Note:** Blink codes can be read in forward or reverse; that is, code 2-3 is the same as code 3-2. A “0” in the code column indicates steady (non-blinking) light.

The status column indicates the nature of the information being given: “informative” is the status indication and no action needs to be taken, “non-fatal” is a condition that can be corrected and operation will then proceed normally, and “fatal” are errors that require that the purge system be shut down before correcting the problem and restarting the purge cycle.

Color Code Meaning Status Recommended Action

Color	Code	Meaning	Status	Recommended Action
Green	0	Purge complete	Informative	No action required
Green	1-1	Purge bypass	Information	No action required
Orange	0	Purge in progress.	Informative	No action required
Orange	1-1	Minor over flow	Non-fatal	Turn the air in regulator down a few PSI.
Red	0	Waiting to begin purge	Non-fatal	Turn the purge gas supply on. If it is on, the enclosure may not be developing enough internal pressure – make sure all doors and access panels are closed. Also, the air inlet pressure may not be high enough – try turning the regulator up.
Red	1-1	System Error	Fatal	Contact Mettler-Toledo Hi-Speed Service.
Red	2-1	Under pressure	Fatal	Loss of pressure is usually due to a door being opened or failure of the purge gas supply. Check both.
Red	2-2	Over pressure	Fatal	Turn the air inlet regulator down at least 5 PSI. Repeat until purge will complete without error. If problems continue, or occur during operation, Contact Mettler-Toledo Hi-Speed Service.
Red	3-2	Major over flow	Fatal	Turn the air inlet regulator down at least 5 PSI.
Red	3-3	Water detected	Fatal	This should only occur if a water sensor option is installed. If it is installed, the unit must be opened and dried completely out. Ensure that no water remains in the unit and that there is no damage to the internal components resulting from the water. In case of serious water incursion. DO NOT ATTEMPT TO REAPPLY POWER TO THE EQUIPMENT ; the equipment should be returned for evaluation.

Color	Code	Meaning	Status	Recommended Action
Red	4-1	Faulty pressure sensor	Fatal	A purge system component has failed.
Red	4-2	Faulty flow sensor	Fatal	A purge system component has failed. Contact Mettler-Toledo Hi-Speed Service.
Red	4-3	Short purge switch is stuck	Fatal	The "Short Purge" switch on the DIP switch mounting board is either shorted or stuck, or the operator has held it down too long while beginning a test. Ensure that there is nothing holding the switch closed or shorting the circuit. If you continue to experience problems, Contact Mettler-Toledo Hi-Speed Service.
Red	4-4	Bypass purge switch is stuck	Fatal	The "Bypass Purge" switch on the DIP switch mounting board is either shorted or stuck, or the operator has held it down too long while beginning a test. Ensure that there is nothing holding the switch closed or shorting the circuit. If you continue to experience problems, consult Mettler-Toledo Hi-Speed Service.

10.8 X-Purge Troubleshooting Guide

Problem	Possible cause	Suggested solution
When power is applied, the purge status indicator light does not come on	Power is not connected to the unit	<ul style="list-style-type: none"> ■ Connect AC power to the power connection on the purge system. ■ Ensure that the power switch is on. ■ Ensure that AC power is on.
	Improper line voltage selection	Ensure that the 120/240 VAC switch on the purge control is set appropriately for your power source.
After power is applied, the purge status indicator stays solid red; it does not switch to yellow or blink	No air supply to unit	<ul style="list-style-type: none"> ■ Ensure that a purge gas line is connected to the unit and that the supply line is "on." ■ The pressure gauge on the air-in box should indicate a higher pressure than 20 PSI
	Restrictions in air line	Ensure that supply line and inlet connect have no restrictions and that the supply line is not kinked
	Restrictions in main purge line inside enclosure	Ensure that the main purge line (terminating in a brass tee fitting) is not kinked or disconnected
	Leaks in the enclosure	<ul style="list-style-type: none"> ■ Ensure that all access doors are closed and latched. ■ Ensure that all access panels are closed and sealed. There should be no holes or openings in the enclosure.
The purge status indicator is yellow, but the enclosure takes an excessively long time to complete the purge (when the status indicator turns green)	Low purge gas supply pressure	Increase purge gas inlet pressure at the air-in regulator or on the main supply line
	Restriction in the main purge line	Ensure that the main purge line within the enclosure (ending in a brass tee fitting) is not kinked or obstructed
Purge status indicator flashes yellow and purge takes an excessively long time to complete.	Low purge gas supply pressure	Increase purge gas inlet pressure at the air-in regulator or on the main supply line
Purge or operation stops and purge status indicator flashes red code	Fatal purge error	10.7 X-Purge on page 10–7

10.9 X-Purge Specifications

10.9.1 Materials

All materials comply with IP66 standards

Enclosure and Hardware	Stainless steel
Explosion-proof I/O Casting (Division 1 X-purge)	Cast aluminum
Explosion-proof I/O Casting (Division 1 X-purge)	Bolts brass, ¼-20 1.5" long

10.9.2 Mechanical

See mechanical drawings for dimensions

10.9.3 Environmental

Operating Temperature	0° - 50° C
Storage Temperature	0° - 70° C
Relative Humidity	10% - 95% RH non-condensing

10.9.4 Electrical

Voltage	120VAC, 60/50 Hz
Equipment Relays	120VAC fused at 10A
Alarm Relays	120VAC or 30VDC
FCC Class A Computing Device	
Number of Switching Signal Data Lines	= 36 lines @ 1A 24VDC

10.9.5 Air requirements

Division 1 X-Purge	40 SCFH Minimum 300 SCFH Optimum 60 – 80 PSI Recommended at inlet 1" – 4" of Water column operating pressure
--------------------	---

11 Troubleshooting

11.1 How To Recognize A Weighing Problem

Watch the control's displays as the line runs. Some problems are easily spotted in this way.

Example: if the weight display blinks as each item crosses the scale, but the weight values are 3-asterisk ***, this may indicate a faulty weigh cell or incorrect calibration.

Become familiar with your checkweigher. Learn to distinguish between normal and abnormal operation. For example, if your checkweigher suddenly starts rejecting all items weighed, there may be a problem with the weigh cell, with the checkweigher's control or its setup – or a problem with your filler.

Learn the basic symptoms.

1. The machine fails a single, 25-pass scale accuracy test.
2. If you weigh the same item over and over, the displayed weights vary widely.

Test scale accuracy. Accuracy is listed on the Machine Record Sheets, found in Tab 1 in the documentation package sent with your system.

11.2 Drift (Gradual Change In Weight Values)

"Drift" means a consistent weighing error that changes gradually. Typical symptoms: Your line is running and producing consistently good items (as verified by the check scale). In spite of this, the checkweigher displays the wrong net weight for each item. As your line runs, the displayed weights either become progressively heavier than the actual weights, or become progressively lighter.

11.3 Weight Display Indicates 3-Asterisk * * * As Items Cross The Scale

This symptom suggests a failure of the load cell or its wiring or power supply. The most likely cause is an overloaded scale. An overload, even of short duration (as when a heavy tool is dropped onto the scale platform), can rupture the cell's internal strain gauges, which unbalances the bridge and causes the cell's output voltage to be abnormally high (resulting in 3-asterisk * * * weight value for every item).

11.4 Detailed List Of Weighing Errors And Possible Causes

Short-term random weight errors

- Item transfers on and off the weigh pan is not smooth. Check the weigh pan alignment.
- Items swaying or rocking as they cross the scale weigh pan. Check the weigh pan alignment.
- Bulk product or other foreign material buildup on the weigh pan or inside the scale housing.
- Improper alignment of the weigh pan.
- Any noticeable air currents which affect items on the scale. (Place your hand just above the weigh pan, and the infeed and discharge ends of the checkweigher. As a general rule, any draft which you can feel may affect accuracy.)
- Mechanical vibration transmitted to the scale through the floor or by other machines touching the checkweigher.

Drift

- Air currents affecting items on the scale. (Place your hand in the position of an item being weighed. Any draft you can feel may cause drift.)
- Faulty weigh cell.
- Mechanical vibration, transmitted through the floor or by other machinery touching the checkweigher. To correct, reposition machinery so the checkweigher is separated by visible air gaps from other equipment.
- Incorrect setup values. To correct, compare values with those listed in the Control Record Sheets; reenter if incorrect. Then recalibrate. The Control Record sheet is in Tab 1 of your documentation set sent with your system.

Weight display appears “stuck” – shows 3-asterisk * * * for every item weighed, and doesn’t change as items cross the scale.

- Faulty weigh cell, wiring to weigh cell, or power supply.
- Incorrect calibration or incorrect initial setup, including timers.

The checkweigher weighs each item normally, but then suddenly starts displaying 3-asterisk * * * for every item weighed.

- Faulty weigh cell.

12 Technical Data

Screen	<ul style="list-style-type: none"> • High-contrast, high-resolution 15" LC color display • Logic operator guidance by means of a touch screen display
Housing/Front Panel	<ul style="list-style-type: none"> • Stainless steel and plastic for harsh industrial use • Protection of the weighing terminal
Ingress Protection	Against dust and water as per IP55 or IP65 (depending on version)
Operating Temperature	0 to +40 °C (32 to +104 °F)

12.1 Weighing Functions

Main Function	<p>Dynamic weighing displaying weights and weight classification as well as automatic sorting/rejecting of the weighed goods; available with various options (depending on the ordered customized version):</p> <ul style="list-style-type: none"> • Data transmission via interface • Reports (statistics) • Printouts of data • Programs for controlling fill processes (feedback control) • Various "special modes" of operation (depending on customized version)
Secondary Function	Static weighing (displaying of weights)
Rezero (setting to null)	Automatically or manually, depending on customized version.

This page is intentionally blank.

13 Glossary

10,000 pieces rule

If this rule is applied, the current production hour ends after 60 minutes or after 10,000 "accepted" items are achieved in less than sixty minutes.

Checkweigher

A mechanism which weighs items as they move along a production line; classifies the items into preset weight zones (typically as overweight, acceptable, and underweight); and ejects or sorts items of unacceptable weight.

Continuous motion checkweigher

This type of checkweigher weighs items as they move across the scale weighing pan on a chain or belt conveyor.

Dynamic weighing

Occurs when an item is weighed while in motion over the scale.

Final evaluation

Printing and subsequent automatic deletion of the production results and statistical results of this package.

Index (verb)

One complete movement of the wheel (not one complete revolution). This includes a forward movement component and a short reverse movement component, where the forward movement pushes an item onto the scale and the reverse movement releases the item so a static weight can be taken.

Index (noun)

The coordinate system used to identify pockets on the circumference of the wheel. Starting from the load station (index 1), and increasing in the direction of the wheels forward movement.

Item

A specific product. For example, if your package is 20 ounce boxes of cereal, an item is a single box of cereal.

Intermittent motion checkweigher

This type of checkweigher brings each item to a complete stop on the scale weigh pan, weighs the item, and then discharges it. This type of checkweigher weighs more precisely, but at a slower line rate than a continuous motion checkweigher because there is no scale conveyor to cause vibration while the item is being weighed.

Menu

Like a restaurant menu, X-series software menus allow you to choose among functions you might need to run your line or to set up your control.

Package

Name you have given the package you are running. For example, you may run 20 ounce boxes of cereal and 14 ounce boxes of crackers. Cereal is a package, as are crackers. An item is a specific package, such as a single 20 ounce box of cereal.

Pocket

A location on the circumference of the wheel which aligns with a station when the wheel is at rest. A given pocket may be open, in which case items may enter for processing, or the pocket may be specialized to meet other system processing needs (rezero, calibrate, etc).

Positions

The number of items which fit in a single pocket. Generally, there is one scale per position. The position closest to the center of the wheel is identified as position 1. Position numbers increase outward.

Rejector

This mechanism removes unacceptable items from the line after receiving a signal from the control. The rejector often consists of a solenoid-operated valve, air cylinder, and associated mechanical parts. A light-weight product might utilize a rotary solenoid (which doesn't require compressed air).

Rezero

Refers to automatic compensation for product buildup on the scale platform or gradual changes in the weight signal from the scale as components age. Some systems incorporate an automatic rezero function every revolution of the wheel.

Static weighing

Occurs when an item is weighed by being placed on the scale.

Station

A collection of hardware components at a given location within the Starweigh system. The station location is a combination of an index and a position. There are three core station types:

Load Station: Where packages load into the wheel.

Weigh Station: Links a weigh cell to a specific location within the wheel system. Each weigh cell within a system is linked to a specific lane. The weigh cell lane is then mapped to a specific index and position.

Unload Station: Where packages exit from the wheel.

Tare weight

Weight of the packaging without any product (i.e., an empty box).

Wheel Design

Each wheel design is given a name and is configured with the physical dimensions in place when the associated wheel is installed. Create at least one wheel design for each physical wheel using the Wheel Design screen in section 7.3. Additional wheel designs may be created to accommodate various system integration requirements. Each package is assigned a wheel design. The parameters specified in the wheel design provide the default values and limits for the package's system configuration.

The properties of a specific type of wheel include:

- pocket count
- position count
- weigh pan diameter
- minimum package diameter
- maximum package diameter

This page is intentionally blank.

METTLER TOLEDO HI-SPEED

5 Barr Road
Ithaca, N.Y. 14850 USA

©Mettler-Toledo Hi-Speed 2009

Printed in U.S.A.

Phone: 607-257-6000
Toll Free: 1-800-836-0836
Fax: 607-257-5232
Email: hisppeed@mt.com

www.mt.com/hi-speed