



D508/D512 PRINTER



SERVICE MANUAL

SATO America, Inc.

**10350A Nations Ford Road
Charlotte, NC 28273**

Main Phone: (704) 644.1650

Technical Support: (704) 644.1660

Technical Support Fax: (704) 644.1661

**E-Mail: satosales@satoamerica.com
techsupport@satoamerica.com**

www.satoamerica.com

Table of Contents

Overview

Introduction	1-3
Unpacking	1-4
Printer Part Names	1-5
Setting Up The Printer	1-6
Loading Media	1-7
Label Sensing	1-9
3.1 Operating Panel	1-10
Configuration: The Rear Panel	1-11
The Configuration Panel	1-12
Switch 4: Unused	1-13
Switch 5: Head Check	1-13
Switch 6: VR1 Potentiometer Adjustment mode	1-13
Offsets	1-15
Potentiometer Adjustments	1-16
Data Dump Diagnostic Label	1-18
Printing Test Labels	1-19
Printing Factory/Service Test Prints	1-20

Basic and Interface Specifications

1.1 Basic Printer Specifications	2-2
1.1 General Specifications (cont'd)	2-3
Interface types	2-6
The Receive Buffer	2-7
IEEE1284 Parallel Interface	2-9
RS-232C Interface	2-10
RS-232C Interface Signals	2-11
Universal Serial Bus Interface	2-12
Local Area Network Interface	2-13
Wireless 802.11 LAN Interface	2-13

Troubleshooting

Interface Troubleshooting	3-5
Troubleshooting Flowcharts	3-7
Problem: Printer Does Not Power Up	3-7
Problem: Label Does Not Feed Outward In A Straight Path	3-8
Problem: Printer Does Not Print	3-8
Problem: Printer Does Not Print	3-9
Problem: Printer Does Not Feed Labels	3-10
Problem: Printer Does Not Stop At The Correct Position	3-11
Problem: Wireless LAN Printer Is Not Printing	3-11
Problem: Printing Is Too Dark	3-12
Problem: Printing is Too Light On One Side	3-12

Problem: Print Start Position Is Incorrect Vertically	3-13
Problem: Print Start Position Is Incorrect Horizontally	3-14
Problem: White Lines Appear In Printed Labels	3-14
Problem: Labels are Not Being Dispensed Properly By The Optional Dispenser Unit	3-15
Problem: The Cutter Is Not Working	3-16
Problem: The Cutter Is Not Working	3-16
Test Print Troubleshooting	3-17
Test Labels	3-17
Data Dump Diagnostic Label	3-19
Printing Factory/Service Test Labels	3-20

Replacement Procedures

Print Head Replacement	4-2
Platen Roller Replacement	4-3
Accessing the Main Board	4-4
Fuse Replacement	4-5
Main Circuit Board Replacement	4-6
Panel Board Replacement	4-7
Relay Board (Label Sensor Board) Replacement	4-8
Label Sensor Replacement	4-10
Cover Sensor Replacement	4-12
Drive Motor Replacement	4-14
Drive Gear Replacement	4-16
Cutter Assembly	4-18

Checks/Adjustment Procedures

Top of Forms Offset	5-2
Factory Clear	5-3
Print Darkness	5-4
Printer Counter Clear	5-6
Cutter Counter Clear (If Cutter Is Installed)	5-6
Test Print Counter Clear	5-7
Cut Position (If Cutter Is Installed)	5-7
Eye Mark / Paper End Sensor Sensitivity	5-8
Paper End Sensor Sensitivity (Alternate)	5-8
Gap Sensor Sensitivity	5-9
Gap Sensor Sensitivity (Alternate)	5-9
Power Supply Checks	5-10

1

OVERVIEW

OVERVIEW

Thank you for your investment in this SATO printer product.

This Service Manual contains information about the specifications, replacement procedures, checking/calibration procedures, and troubleshooting of common problems associate with the D508/D512. A total of four topics are covered herein, and they are organized as follows:

- Section 1: Overview**
- Section 2: Basic and Interface Specifications**
- Section 3: Troubleshooting**
- Section 4: Replacement Procedures**
- Section 5: Checks and Adjustment Procedures**

The **Overview** section provides a description of the printer, information on how to access the main board, how to unpack the printer, how to identify the printer parts, how to set up the printer, how to load media, information on label sensing and configuration, adjustments, and test labels.

The **Basic and Interface Specifications** section serves as a guide to personnel who need to understand the communication protocols needed to control the printer using third party software, and for troubleshooting interface problems.

The **Troubleshooting** section aids in the process of diagnosing and correcting common problems. After troubleshooting, the service personnel can then determine whether any repairs, parts replacements and/or adjustments are necessary,

The **Replacement Procedures** section covers the main components of the product, and how the service personnel can dismantle and reassemble the parts in order to maintain, clean, repair or replace them.

Finally, the **Checks and Adjustment Procedures** are needed after certain maintenance or repair work involving certain precision components.

It is recommended that you become familiar with each section before attempting to service the product. Refer to the **Table Of Contents** at the front of this manual to search for the relevant information needed. All page numbers in this manual consist of a section number followed by the page number within the stated section.

Note:

All information herein was correct and current at the time of publication. The contents of this document are subject to revision and change without prior notification to users. To obtain the most current version of this document, refer to the SATO website at www.SATOAmerica.com.

INTRODUCTION

The SATO D508/D512 Printer Service Manual provides information for installing and maintaining D508/D512 Direct Thermal printers. Step-by-step maintenance instructions are included in this manual with typical problems and solutions. It is recommended that you become familiar with each section in this manual before installing and maintaining the printer.

The major difference in the D508 and the D512 printers is the resolution of the print head. The D508 with its 203 dpi head provides an economical labeling solution for most applications. It can print labels up to four inches wide. The D512's higher 305 dpi resolution provides greater detail for graphics and small point size text.

The D5 Series printers use a subset of the standard SATO Command Language. The D508 and D512 share the same command set, the only differences are the allowable values representing the print positions on the label. These values are specified in "dots" and will vary depending upon the resolution of the printer and the amount of memory available for imaging the label. The allowable range for each printer is specified in a table for those command codes. In addition, users can choose an interface—such as parallel (IEEE1284), serial (RS-232C), Ethernet (10/100-BaseT), USB 1.1and Wireless LAN IEEE 802.11b.

UNPACKING

When unpacking the printer, take note of the following:

1 The box should stay right-side up. Lift the printer out of the box carefully.	4 If the printer has been stored in the cold, allow it to reach room temperature before turning it on.
2 Remove the plastic covering from the printer.	5 Set the printer on a solid, flat surface. Inspect the shipping container and printer for any sign of damage that may have occurred during shipping.
3 Remove the accessory items from their protective containers.	

Note:

The following parts shown here are representative only. Due to regional requirements and our policy of continual improvement, your printer may not be packed with the exact parts as shown here, but the unpacking steps are similar.



Printer





AC adaptor and cable



User documentation and software
package (where applicable)

PRINTER PART NAMES



SETTING UP THE PRINTER



Consider the following when setting up the printer:

Locate a solid flat surface with adequate room to set the printer. Make sure the AC adaptor can be located so that the AC power cable can be attached to the printer and an AC power outlet. The location should be near the host or computer terminal. The maximum distance recommended is:

- 10 feet for a Parallel interface cable. Make sure it meets IEEE1284 specifications
- 18 feet for the optional Serial RS232 Interface
- 10 feet for the optional USB interface without hub
- the optional 10baseT Ethernet Interface depends upon the LAN cabling
- Up to 100m for the Wireless LAN, depending on structural conditions

Follow these steps to set up your printer:

1. Make sure the power switch on the Operator Panel is in the OFF (0) position and place the AC adaptor in a safe and secure location.
2. Connect the Input Power connector to the printer. This connector is buttoned and must be turned approximately 3/4 turn clockwise to secure it to the printer.
3. Connect the AC Power Cable to an AC Outlet supply of an appropriate voltage.
4. Connect the interface cable to the host system. If you are using the Parallel Port connection, a parallel IEEE1284 interface cable must be used to realize the high data transfer rate of the printer's parallel port. If another interface is installed, the appropriate cable should be used.
5. Load the label media following the instructions in this section.



6. Configure the printer for label width and operating mode using the instructions in this section.
7. Press the printer power button to the ON (I) position.
8. Print a test label to verify the printer is set up and operating correctly.


LOADING MEDIA

The SATO D508/D512 printer can print to direct thermal die-cut labels, tags or continuous media. The media supply can be either in Roll or Fanfold format.


Roll Media

Roll media should be between 0.98" (25 mm) and 4.3" (110 mm) in width and wound face-out on a core with a minimum internal diameter of 1.6" (40 mm).

1. Make sure the printer is turned OFF.
2. Open the Top Cover by pressing on cover release points located on the right-hand side of the printer. This releases the Top Cover and allows it to swing upward on the rear mounted hinge points.
3. With the Top Cover in the upright position, press the Paper Guide Release while adjusting the Paper Guides until they allow a media roll to fit between them. A millimeter scale is molded into the case to provide a guide when making the adjustment. The Paper Guides are center justified and interact with each other so that each moves an equal distance.
4. Make sure the Roll Holders are in the released position. If they are not, lift up on each one and they will snap to the open position.
5. Unwind approximately 12" of label material from the roll. The labels should be wound face-out (printing side to the outside of the roll). Drop the roll in-between the Paper Guides so that the labels come off the top of the roll. The Paper Guides will automatically position the Roll Holders to suspend the roll.



6. Route the label material through the Paper Sensor Assembly and over the Platen. Note that the Sensor is part of the left Label Roll Guide so that the Paper Sensor is always positioned in the same location relative to the left edge of the label.
7. Close the Top Cover.
8. Press the LINE button so that the printer is in the OFF LINE mode and then press the FEED button. The label should advance to the next index (label gap) position.



Paper Sensor Paper Guide

Fanfold media

1. Place the fanfold media behind the printer with the printing surface up.
2. Open the Top Cover by pressing on the cover release latch located on the right-hand side of the printer. This releases the cover and allows it to swing upward on the rear mounted hinge points.
3. Carefully pull up the Fanfold-label Loading Slot from the back of the Top Cover.
4. With the Top Cover in the upright position, press the Paper Guide Release while adjusting the Paper Guides until they allow a media to fit between them. A millimeter scale is molded into the case to provide a guide when making the adjustment. The Paper Guides are center-justified and interact with each other so that each moves an equal distance apart from each other.
5. Route the label material through the Sensor Assembly and over the Platen.



**Pull up
the
loading
slot**



**Pull
open
the Top
Cover**




**Load
the
fanfold
paper**



6. Close the Top Cover.


7. After loading the label media, it is recommended that you run a Test Print to make sure the labels are correctly loaded and printed.



LABEL SENSING

Overview of the fanfold-paper loading path

The SATO D508/D512 uses label Gap (see-through) or Eye-Mark (reflective) sensing. The Sensor Assembly is located on the left edge of the media and is automatically positioned by the Paper Guides.



CONFIGURATION


Before using the printer, it is best to read this manual thoroughly first. Otherwise, you may disturb default settings around which the instructional procedures in this manual are based upon.

3.1 OPERATING PANEL

The Operator Panel consists of three LED indicators and three switches.

POWER

The green LED lights up when the printer is ON.



ON LINE

The green LED lights up when the printer is ON LINE and ready to receive data. The ON LINE button takes the printer ONLINE or OFFLINE.

LINE Button

If the ONLINE LED is lit, pressing it will take the printer OFFLINE. Pressing the button again then takes the printer back ONLINE. When ONLINE, the printer is ready to receive data from the host. When OFFLINE, the printer will not print or accept data from the host. While the printer is printing, press this button to suspend the printing. To resume printing, press this button again.

FEED BUTTON

Press this button to eject one label in OFFLINE mode. Hold this button down while power is applied, to print a printer status label.

POWER SWITCH

A two position switch for turning the printer ON (I) or OFF (0).

CONFIGURATION: THE REAR PANEL

All of the printer cable connectors are located on the Rear Panel, as follows.

Fanfold-label Loading Slot

Remove this panel to route fanfold paper into the printer




**Interface
Slot
(IEEE1284
Parallel
Interface
Connector
shown)**

**Power
Connector
for DC power
input from the
supplied AC
Adapter**

THE CONFIGURATION PANEL

The Configuration Panel is accessible when you lift up the top cover.

The panel consists of an eight-position DIP switch, four adjustment potentiometers and a seven-segment LED Error Status display. Receptacles for connecting the optional Cutter (factory installed) are also located on this panel.



DIP SWITCH SETTINGS

This is an eight-position switch used for setting the operating conditions of the printer. Switches 1 to 3 act as control for both paper handling and the loading of programs or fonts into the printer.

Switches 1–3: Paper Handling settings

These three switches select the method used for controlling paper handling:

Continuous mode - (default mode) Does not use the sensor for paper indexing. The paper movement will stop after all the label data has been printed.

Tear Off mode - Paper is fed out to the cut/tear off position after printing is complete. Before the next label is printed, the paper is pulled back in to the first print line position.

Cutter mode - Enables the Cutter option if installed.

DSW1	DSW2	DSW3	Mode
Off	Off	Off	Continuous
On	Off	Off	Tear Off
Off	On	Off	Cutter
On	Off	On	Reserved
Off	On	On	Load Font

Configuration Switch

ON							
OFF							

1 2 3 4 5 6 7 8

DIP SWITCH SETTINGS (CONT'D)

Switches 1–3: Font/Graphic loading settings

Enables the loading of fonts and/or graphics into printer memory for faster retrieval.

DSW1	DSW2	DSW3	Mode
Off	On	On	Load Font

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

Switch 4: Unused

This switch is reserved for future use.

DSW4	Mode
Off	DT
On	Reserved

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

Switch 5: Head Check

Enables or Disables the printer function that checks the print head automatically.

DSW5	Mode
Off	Disabled
On	Enabled

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

Switch 6: VR1 Potentiometer Adjustment mode

Selects the function adjusted by VR1. When placed in the OFF position, VR1 will adjust the media tear-off / cut (backfeed distance) offset value over a range of +/- 3.75 mm. When placed in the ON position, VR1 will adjust the print darkness range.

DSW6	Mode
Off	Media Tear-Off
On	Print Darkness

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

DIP SWITCH SETTINGS (CONT'D)

Switch 7: DATA Dump

When ON, the printer will print out the hex value for each character received. When OFF, the printer will accept and process the data stream in a normal fashion.

DSW7	Mode
Off	Disabled
On	Enabled

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

Switch 8: Unused

This switch is reserved for future use.

DSW8	Mode
-	-
-	-

Configuration Switch

ON							
OFF							
1	2	3	4	5	6	7	8

OFFSETS

There are **two** offset settings stored in the printer; one for the **Cut mode** and one for the **Tear-Off mode**.

These two offsets can be set independently and will remain in the printer until a new command is received changing the setting or until power is turned off.

The default settings can be determined by printing a User Test Label.

The following should be used as starting points for establishing the three Offset values:

Mode	Length of Offset (mm)	Length of Offset (in)	Print head resolution
CUTTER	17.9	0.70	143/215
TEAR-OFF	29.2	1.15	234/350

POTENTIOMETER ADJUSTMENTS


PITCH OFFSET

This can be done using the VR4 potentiometer on the Configuration Panel. This potentiometer is set at the factory so that it has a range of +/-3.75 mm. The midpoint setting should have no effect on the label pitch. Turning the potentiometer all the way clockwise should move the print position 3.75 mm upwards towards the leading edge of the label. Turning it all the way counterclockwise should move the print position down 3.75mm away from the leading edge of the label.

1. Place DSW6 on the Configuration Switch in the OFF position.
2. Turn the power OFF.
3. While pressing the FEED button on the Operator Panel, turn the power ON.
4. When you hear one beep from the printer, release the FEED button.
5. Press the LINE button to begin printing large Test Labels (press the FEED button if you are using labels smaller than 4.1" (104 mm) in width).
6. Adjust potentiometer VR4 until the first print position is at the desired location on the label.
7. Press the FEED button to stop printing.

Note:

Adjusting the Label Pitch with VR4 will affect the stop position of the label and the cut/tear-off positions.



Print Darkness

A fine adjustment for PRINT DARKNESS can be made using potentiometer VR1 on the Front Operator Panel. It provides a continuous range of adjustment, allowing you to make precise changes. Turning VR1 clockwise will make the print darker, and counterclockwise will make it lighter.


1. Place DSW6 on the Configuration Switch in the ON position.
2. Turn the Power Switch OFF.
3. While pressing the FEED button on the Operator Panel, turn the Power Switch ON.
4. When you hear one beep from the printer, release the FEED button.
5. Press the LINE button to begin printing large Test Labels (press the FEED button if you are using labels smaller than 4.1" (104 mm) in width).
6. Adjust potentiometer VR1 until the desired print darkness is obtained.
7. Press the FEED button to stop the printing.

Adjustment of the Print Darkness using VR1 will affect the darkness in all the <ESC>#E command code ranges; that is, if the print darkness is adjusted with VR1 for lighter print, the darkness will be lighter in all the Print Darkness ranges selected by the command code.

DATA DUMP DIAGNOSTIC LABEL

The contents of the printer buffer can be examined using the DATA Dump mode. This printout labels each line of the received data in the left hand column, the data in the middle column followed by the same data in ASCII format in the right-hand column.


1. Turn the printer OFF.
2. Place DSW7 on the configuration Switch in the ON position.
3. Turn the printer ON.
4. Transmit data to the printer.
5. The data received is printed on the label.
6. Place DSW7 in the OFF position.
7. Turn the printer OFF and then back ON to place it back in the normal print mode.



```
00000000 1B411B4830303530 1B56303230301B42 E;A;H0050E;V0200E;B  
00000010 443130343130302A 434C3430382A1B48 D104100*CL408*;H  
00000020 303035301B563030 35301B4254303031 0050E;V0050E;BT001  
00000030 3033303130331B42 5730333130303132 030103E;BW0310012  
00000040 333435360D0A1B51 311B5A0D0A      3456E;R F;Q1E;Z E;L
```

PRINTING TEST LABELS

1. The User Test Label prints the current default settings of the printer.
2. Press the FEED button while turning the power ON.
3. When the printer beeps, release the FEED button.
4. To print a large (4" wide) test label, press the LINE button. To print a small (2" wide) test label, press the FEED button.
5. The printer will continuously print the USER TEST LABEL until the FEED button is pressed. If the FEED button is pressed another time, printing will resume.
6. To remove the printer from the Test Label mode, power the printer OFF.



Note:


Depending on the version of your printer's onboard software, the appearance of your test printout may be different from that shown here.

PRINTING FACTORY/SERVICE TEST PRINTS

The Factory/Service Test Label prints the internal operating parameters of the printer.

1. Open the top cover to open print head.
2. Press the LINE and FEED buttons while turning the printer ON.
3. When the printer beeps, release the LINE and FEED buttons. The printer will then beep 3 times, indicating that the print head/cover is open.
4. Close top cover to latch print head in closed position
5. Press the LINE button to print a large (4" wide") Factory/Service Test Label. Press the FEED button to print a small (2" wide) Factory/Service Test Label.
6. The printer will begin printing a series of test labels, the first containing the operational parameters of the printer followed by one containing the internal printer settings. These two label formats will alternate until the FEED button is pressed, suspending the print operation. If the FEED button is pressed again, the printing will resume.

To remove the printer from the Factory/Service Print Test mode, remove power by placing the POWER switch in the OFF position.



Note:

Depending on the version of your printer's onboard software, the appearance of your test printout may be different from that shown here.

2

BASIC AND INTERFACE SPECIFICATIONS

- Basic Printer Specs
- Interface Specs

1.1 BASIC PRINTER SPECIFICATIONS

Attribute	
PRINT	
Print Method	Direct Thermal
CPU	32-bit RISC processor
Printer Command Language	SBPL
Resident Fonts	U S M XU XS SM WB WL XB XL CG Times CG Triumvirate OCR-A OCR-B
Font Memory	4 MB
Print Head Resolution	8 dots per mm for 203 dpi 12 dots per mm for 305 dpi
Print Speed	6 ips
Max. Print Area	104 mm (width) by 400 mm (pitch)
MEDIA	
Label Thickness (Label + backing paper)	0.06 mm* ~ 0.19 mm (*Check with your dealer regarding conditions for using thin 0.06 mm labels)
Label Form	Roll Label : Maximum outer diameter of 110mm (face out), Core Inner Diameter of 40mm Fan-fold label : Max foldable height 100 mm (loaded externally)
Label Size (adhesive labels)	<p>For continuous feed: Width: 25~115 mm (including liner 28~118 mm) Pitch: 15~397mm (including liner 18~400 mm)</p> <p>For Cutter usage (optional): Width: 25~115 mm (including liner 28~118 mm) Pitch: 20~397mm (including liner 23~400 mm)</p> <p>For Tear Off mode: Width: 25~115 mm (including liner 28~118 mm) Pitch: 15~397mm (including liner 18~400 mm)</p>
Label Size (non-adhesive labels)	<p>For continuous feed or tear off mode: Width: 25~118mm Pitch: 15~400 mm</p> <p>With cutter installed: Width: 25~118mm Pitch: 20~400 mm</p>
SENSING	
See-Through for labels or tags	0.012" (3 mm)
Continuous Form	Sensor not used
Eye Mark	Fixed, 0.25" (6.3 mm) from left label edge. 0.12" (3 mm) wide x minimum 0.5" (12 mm) in length from left label edge.
*All specifications subject to change without notice.	

1.1 GENERAL SPECIFICATIONS (CONT'D)

Attributes	
CONTROLS AND SIGNALS	
On-Line LED	Green
Power LED	Green
Error LED	Red
LED Display Panel	7-Segment Single Character
On/Off-Line Button	Front Panel
Label Feed Button	Front Panel
Power On/Off Button	Front Panel
Self Diagnostics	Head check Paper end Cover open Test print
POTENTIOMETER ADJUSTMENTS	
Adjustment Potentiometers	VR1: Offset level (DIPSW6 = OFF) VR1: Print darkness (DIPSW6 = ON) VR2: Eye Mark / Paper End (to adjust the threshold) VR3: Gap sensor (to adjust the threshold) VR4: Label pitch offset
DIP switches	DIP-SW -1,2,3 : Operation mode(Print mode/Download mode) DIP-SW -4 : Reserved (constantly OFF) DIP-SW -5 : Head check (ON-Enabled / OFF-Disabled) DIP-SW -6 : VR1 function switch (ON-Print darkness level / OFF-Offset) DIP-SW -7 : DATA dump (ON-HEX dump print / OFF-Normal print) DIP-SW -8 : Reserved (constantly OFF)
INTERFACE CONNECTIONS	
Parallel (Option)	IEEE1284
Serial (Option)	RS232C (9600 to 57.6K bps) Hardware Flow Control (Ready/Busy) Software Flow Control (X-On/X-Off) Bi-directional Status
USB (Option)	USB Specification Version 1.1
LAN (Option)	10/100 Base-T
RFID (Option)	13.56 MHz band, TBA
Wireless LAN (Option)	TBA
*All specifications subject to change without notice.	

1.1 GENERAL SPECIFICATIONS (CONT'D)

Barcodes	
SYMOLOGIES	
Supported 1D formats (excluding customized barcode addressing in firmware)	UPC-A/E EAN-8/EAN-13 CODABAR CODE39 CODE93 CODE128 UCC/EAN128 Interleaved 2 of 5 Industrial 2 of 5 Matrix 2of5 RSS Composite MSI POSTNET Bookland
Supported 2D formats	PDF 417 Micro PDF 417 Truncated PDF 417 Maxicode Data Matrix QR Code
Ratios	1:2, 1:3, 2:5 User definable bar widths (depending on software)
Bar Height	4 to 600 dots (depending on software)
Rotation	0°, 90°, 180° and 270° (depending on software)
<i>*All specifications subject to change without notice.</i>	

Physical Attributes	
DIMENSIONS	
Width	7.8 in. (198 mm)
Depth	9.1 in. (230 mm)
Height	6.6 in. (167 mm)
Weight	5.5 lbs (2.5 Kg) excluding AC adaptor
POWER REQUIREMENTS	
Voltage	USA: AC 115 V (+/- 10 %) Europe: AC 230V (+/- 10 %) 50/60 Hz (+/-1%)
Power Consumption	67W nominal
ENVIRONMENTAL	
Operating Temperature	Operation environment 0~35°/30~80% (without condensation) Storage environment -5~45°/20~80% (without condensation)
REGULATORY APPROVALS	
Safety	USA : UL(UL60950-1) CANADA : C-UL(CSA C22.2 No.60950-1-3) Europe : TUV(EN60950-1), CE
EMC/EMS	USA : FCC15B (ClassB) Europe : EN55022 ClassB, EN61000-3-2, EN61000-3-3, EN55024

1.1 GENERAL SPECIFICATIONS (CONT'D)

Optional Accessories	
Internal Cutter	User or factory installed Internal option allowing labels to be cut at specified intervals.
IEEE1284 Interface	Parallel interface. Factory or User installable
Serial Interface	High Speed RS232 Interface option, 9600 bps to 57.6 Kbps. Factory or User installable.
LAN Interface	TCP/IP Protocol Interface option. Factory or User installable.
USB Interface	Universal Serial Bus Interface option. Factory or User installable.
RFID	To be announced
Wireless LAN Interface	802.11 b/g
<i>*All specifications subject to change without notice.</i>	

INTERFACE SPECIFICATIONS

INTERFACE TYPES

The SATO D508/D512 printer can be ordered with any of the interfaces described in this section. The user can specify the desired interface at the time of placing an order. Thereafter, if the user needs to change the interface, it is a simple matter of purchasing a suitable interface card from a SATO dealer.

The following are the different types of interface boards available:

- 1) RS232C Interface Board**
- 2) IEEE1284 Parallel Interface Board**
- 4) USB Interface Board**
- 5) LAN Interface Board (standard 10Base-T/100Base-T interface with RJ-45 connector)**
- 6) Wireless LAN (802.11 b/g)**


For programmers and technical personnel to fully utilize the printer, the following information is presented in this section:

- The Receive Buffer
- IEEE1284 Parallel Interface
- Universal Serial Bus (USB) Interface
- Local Area Network (LAN) Interface
- RS232C Serial Interface

General Specifications
Electrical Specifications
Pin Assignments
Ready/Busy Flow Control
X-On/X-Off Flow Control


THE RECEIVE BUFFER

This printer has the ability to receive a data stream from the host in one of two ways. The receive buffer may be configured to accept one print job at a time or multiple print jobs. The single job print buffer is generally used by software programs that wish to maintain control of the job print queue so that it can move a high priority job in front of ones of lesser importance. The multiple job buffer, on the other hand prints all jobs in the order they are received by the printer, and the order of printing cannot be changed.



Single Job Buffer

The printer receives and prints one job at a time. Each job must not exceed 2.95MB.



THE RECEIVE BUFFER (CONT'D)

Multi Job Buffer

The printer is able to continuously receive print jobs, compiling and printing other jobs at the same time. It acts much like a "print buffer" to maximize the performance of the host and the printer.

When you are using the RS232 Serial interface, the Multi Job Buffer uses either the Ready/Busy with DTR (pin 20) or X-On/X-Off flow control protocols. With an empty receiving buffer, the status of DTR is "high" (or an X-On status if using X-On/X-Off), meaning the printer is ready to receive data. When the receive buffer is holding 1.95MB of data (1MB from being full), DTR will go "low" (or an X-Off is sent) indicating the printer can no longer receive data. This condition is called "Buffer Near Full."

The receiving buffer will not be able to receive more data again until a "Buffer Available" condition occurs. This takes place when the receiving buffer has emptied so that only 1MB bytes of data are being held (1.95MB bytes from being full). At this time, DTR will go "high" or an X-On is sent to tell the host that it can again receive data.

All printer error conditions (i.e., label out, Time-out Error, etc) will cause the printer to go busy (DTR "low" or X-Off) until the problem is corrected and the printer is placed on-line. The printer will also be busy if taken off-line from the front panel.

IEEE1284 PARALLEL INTERFACE


The parallel interface for this printer conforms to the IEEE1284 specification. It will automatically detect the IEEE1284 signals and operate in the high speed mode. If it does not detect the IEEE1284 signals, it will operate in the standard Centronics mode, which is significantly slower. For this reason, an interface cable and host interface conforming to the IEEE1284 specification must be present to fully utilize the speed capabilities. This interface also operates bidirectionally and can report the status of the printer back to the host.

Electrical Specifications

Printer Connector	AMP 57-40360 (DDK) or equivalent
Cable Connector	AMP 57-30360 (DDK) or equivalent
Cable Length	10 ft. (3 m) or less
Signal Level	High = +2.4V to +5.0V Low = 0V to -0.4V

PIN	SIGNAL	DIRECTION	PIN	SIGNAL	DIRECTION
1	STROBE	To Printer	19	STROBE Return	Reference
2	DATA 1	To Printer	20	DATA 1 Return	Reference
3	DATA 2	To Printer	21	DATA 2 Return	Reference
4	DATA 3	To Printer	22	DATA 3 Return	Reference
5	DATA 4	To Printer	23	DATA 4 Return	Reference
6	DATA 5	To Printer	24	DATA 5 Return	Reference
7	DATA 6	To Printer	25	DATA 6 Return	Reference
8	DATA 7	To Printer	26	DATA 7 Return	Reference
9	DATA 8	To Printer	27	DATA 8 Return	Reference
10	ACK	To Host	28	ACK Return	Reference
11	BUSY	To Host	29	BUSY Return	Reference
12	PTR ERROR	To Host	30	PE Return	Reference
13	SELECT	To Host	31	INIT	From Host
14	AUTOFD (1)	To Host	32	FAULT	To Host
15	Not Used		33	Not Used	
16	Logic Gnd		34	Not Used	
17	FG	Frame Ground	35	Not Used	
18	+5V(Z=24Kohm)	To Host	36	SELECTIN ⁽¹⁾	From Host

⁽¹⁾ Signals required for IEEE1284 mode



RS-232C INTERFACE

The High Speed Serial Interface is an factory installed option that must be installed in the printer at the time of order. The D500 recognizes the RS-232 interface automatically.


General Specifications

Asynchronous ASCII	Half-duplex communication
	Ready/Busy Hardware Flow Control Pin 20, DTR Control Pin 4, RTS Error Condition
	X-On/X-Off Software Flow Control Bi-Directional Communication
Data Transmission Rate	9600, 19200, 38400, 57600 bps
Character Format	1 Start Bit (fixed) 7 or 8 data bits (selectable) Odd, Even or No Parity (selectable) 1 or 2 Stop bits (selectable)

Electrical Specifications

Connector	DB-25S (Female)
Cable	DB-25P (Male), 50 ft. maximum length. For cable configuration, refer to Cable Requirements appropriate to the RS232C protocol chosen.
Signal Levels	High = +5V to +12V Low = -5V to -12V

Pin Assignments



RS-232C INTERFACE SIGNALS

Pin	Direction	Signal Definition
1	Reference	FG (Frame Ground)
2	To Host	TD (Transmit Data) -Data from the printer to the host computer. Sends X-On/X-Off characters or status data (Bi-Directional protocols).
3	To Printer	RD (Receive Data) -Data to the printer from the host computer.
4	To Host	RTS (Request to Send) -Used with Ready/Busy flow control to indicate an error condition. RTS is high and remains high unless the print head is open (in this case, RTS would return to the high state after the print head is closed and the printer is placed back on-line) or an error condition occurs during printing (e.g. Time Out error, label out).
5	To Printer	CTS (Clear to Send) -When this line is high, the printer assumes that data is ready to be transmitted. The printer will not receive data when this line is low. If this line is not being used, it should be tied high (to pin 4).
6	To Printer	DSR (Data Set Ready) -When this line is high, the printer will be ready to receive data. This line must be high before data is transmitted. If this line is not being used, it should be tied high (to pin 20).
7	Reference	SG (Signal Ground)
20	To Host	DTR (Data Terminal Ready) -This signal applies to Ready/Busy flow control. The printer is ready to receive data when this pin is high. It goes low when the printer is off-line, either manually or due to an error condition, and while printing in the Single Job Buffer mode. It will also go low when the data in the buffer reaches the Buffer Near Full level.

Cable Requirements

DB9	DB2 5	HOST	INTERCONNECTION	PRINTER
1	1	FG		1 FG (Frame Ground)
2	3	RD		2 TD (Transmit Data)
3	2	TD		3 RD (Receive Data)
8	5	CTS		4 RTS (Request to Send)
7	4	RTS		5 CTS (Clear to Send)
4	20	DTR		6 DSR (Data Set Ready)
6	6	DSR*		20 DTR (Data Terminal Ready)
5	7	SG		7 SG (Signal Ground)

* This connection at the host side of the interface would depend upon the pin that is being used as the Ready/Busy signal by the driving software. Typically, on a PC, it would be either CTS (pin 5) or DSR (pin 6) on a DB-25 connector.

READY/BUSY FLOW CONTROL

Ready/Busy is the hardware flow control method for the serial interface on the printer. By raising/lowering the voltage level on Pin 20 of the RS232 port, the printer notifies the host when it is ready to receive data. Pin 4 (RTS) and pin 20 (DTR) are the important signals on the printer for this method of flow control. The host must be capable of supporting this flow control method for it to function properly.

X-ON/X-OFF FLOW CONTROL

X-On/X-Off flow control is used whenever hardware (Ready/Busy) flow control is not available or desirable. Instead of a voltage going high/low at pin 20, control characters representing "Printer Ready" (X-On =11 hexadecimal) or "Printer Busy" (X-Off = 13 hexadecimal) are transmitted by the printer on pin 2 (Transmit Data) to the host. In order for this method of flow control to function correctly, the host must be capable of supporting it. X-On/X-Off operates in a manner similar to the function of pin 20 (DTR) as previously explained. When the printer is first powered on it sends an X-Off when the "Buffer Near Full" level is reached and a X-On when the data level of the buffer drops below the "Buffer Available" mark. When the printer is taken off-line manually, it transmits an X-Off indicating it cannot accept data. When it is placed back on line manually, it sends an X-On, indicating it is again available for receipt of data. If an error occurs during printing (paper out, Time Out), the printer sends an X-Off as soon as an error condition is detected. When the error is cleared and the printer is placed back on-line, it transmits an X-On indicating it is again ready to accept data.

Upon power up if no error conditions are present, the printer will continually send X-On characters at five millisecond intervals until it receives a transmission from the host.

UNIVERSAL SERIAL BUS INTERFACE

The Universal Serial Bus (USB) interface is a factory installed option that must be specified at the time of order. It requires a driver (shipped with each printer that has the interface installed) that must be loaded on your PC and the PC must be configured to support USB peripherals using Microsoft Windows. Details for loading the USB driver are contained in the USB Interface Manual that is shipped with each printer with a USB Optional interface installed. Up to 127 devices may be connected to a USB port.

LOCAL AREA NETWORK INTERFACE

A Local Area Network (LAN) interface is a factory installed interface option that must be specified at the time of order. It requires a driver (shipped with each printer that has the interface installed) that must be loaded on your PC and the PC must be configured to support the TCP/IP network protocol using a 10BaseT LAN connection. Details for loading the LAN driver are contained in the LAN Interface Manual that is shipped with each printer with a LAN Optional interface installed.

WIRELESS 802.11 LAN INTERFACE

The wireless print server provides easy printer interface with 802.11G Wi-Fi compliant networks free of wired connections. Each printer is shipped with an integrated driver and interface installed. The driver must be loaded onto the host computer and configured to run one of the supported protocols. Details for setting up the Wireless 802.11 LAN Interface are contained in the documentation that is supplied with the interface card.

This page is left blank intentionally

3

TROUBLESHOOTING

- **Error Signals**
- **Troubleshooting Table**
- **Interface Troubleshooting**
- **Test Print Troubleshooting**

TROUBLESHOOTING

ERROR SIGNALS					
DISPLAY	LINE LED	ERROR LED	BUZZER	ERROR CONDITION	CORRECTIVE ACTION
0	Off	On	1 Beep	Flash Memory error	Consult SATO dealer
1	Not Assigned				
2	Off	On	1 Beep	Machine error	Consult SATO dealer
3	Off	On	1 Beep	EEPROM error	Replace EEPROM
4	Off	On	1 Beep	Head error	Replace Print Head
5	Off	Blink	3 Beeps	Top Cover Open	Close and latch cover
6	Off	Blink	3 Beeps	Out of Paper	1) Replenish media supply 2) Properly route media
7	Off	Blink	3 Beeps	Sensor error	Adjust sensor sensitivity
8	Off	Blink	3 Beeps	Cutter error	1) Reconnect cutter 2) Consult SATO dealer
8.	On	On	0 Beeps	Program error	Resend data to printer
A	On		1 Beep	Receive Buffer Overflow	1) Restart printer and retry 2) Ensure correct protocol
B	On		1 Beep	Serial Parity error	1) Ensure correct parity. 2) Consult SATO dealer
C	On		1 Beep	Serial Framing error	1) Ensure correct data bit 2) Consult SATO dealer
D	On		1 Beep	Serial Overrun error	1) Ensure correct flow control 2) Retry
E	On		1 Beep	LAN Time Out error	1) Check Interface card 2) Check connections 3) Replace the above
F			3 Beeps	Serial Font/Graphic error	Ensure correct data stream

TROUBLESHOOTING TABLE	
IMAGE VOIDS	
Damaged print head	Replace print head
Damaged electronics	Replace circuit board
Damaged or worn platen roller	Replace platen roller
Vertical line in printed image	Dirty or defective print head
LIGHT PRINT IMAGES	
Low print head energy/darkness	Adjust darkness control
Low print head pressure	Ensure top cover is securely closed.
Foreign material on print head	Clean print head and platen roller
Excessive print speed	Reduce print speed setting
UNEVEN PRINT DARKNESS	
Worn platen roller	Replace platen roller as required
Dirty print head	Clean as necessary
SMEARED PRINT IMAGES	
Poor label quality	Use high quality label stock
Foreign material on print head and platen roller	Clean print head and platen roller
Foreign material on labels	Use high quality label stock
Excessive print head energy	Adjust darkness control
Excessive print speed	Adjust speed as required. Remove excessive head pressure.
NO LABEL MOVEMENT	
Incorrect label pitch sensor selected	Select the correct label sensor type
No voltage output	Replace fuse on main circuit board. Test power supply and replace as required
Drive motor not operating	Ensure wiring harness connection. Replace as necessary
Defective main board	Troubleshoot board and replace as necessary
NO PRINTED IMAGE	
Print head is disconnected	Ensure print head wiring harness is connected on each end
No voltage output	Test power supply and replace as necessary
Damaged print head	Replace print head
Damaged electronics	Replace circuit board
Interface problems	Check. Refer to relative instructions below

NO PRINTED IMAGE	
Data input error	Ensure correct data stream
MEANDERING MEDIA	
Incorrectly loaded media	Ensure correct loading
Improperly adjusted media guides	Adjust as required
Worn or improperly adjusted platen roller	Adjust. Replace as required
PRINTER CREATES A BLANK LABEL	
Data input error	Ensure correct data stream
Improper media selected	Ensure correct media is in use
Disconnected print head	Cycle off power and ensure proper connection
Defective print head	Replace print head as required
Defective main board	Replace main board as required
INCORRECT LABEL POSITIONING	
Incorrect sensor selection	Ensure the correct sensor is selected
Improper sensor adjustment	Adjust as required
Incorrect media in use	Ensure the correct media is being used
Data input error	Ensure correct data stream

INTERFACE TROUBLESHOOTING

This unit provides a checklist for the various interface types. Locate the checklist relative to the interface used and perform each of the troubleshooting tasks until the problem has been isolated.

PARALLEL INTERFACE	
CHK	TROUBLESHOOTING STEP
	Ensure the interface card is correctly installed. Run self-test to verify.
	Ensure the printer cable is connected to the appropriate LPT port on the host computer. If using a Windows printer driver, ensure the correct port is selected.
	Ensure a IEEE1284 printer cable is being used.
	Ensure the host's peripheral settings are set to ECP for faster throughput. Refer to the computer manufacturer's documentation for details.
	Ensure the printer is receiving information from the computer using the Receive Buffer Data Dump mode. Refer to that procedure within this manual for instructions. The command stream should be continuous and possess 0Dhex and/or 0Ahex (carriage return and line feed) characters throughout.
	Replace the interface board with another to isolate the problem.
	Replace the interface board permanently if determined to be the problem.

RS-232 SERIAL INTERFACE	
CHK	TROUBLESHOOTING STEP
	Ensure the correct interface card is correctly installed. Run self-test to verify.
	Ensure the serial cable (Null Modem) meets specifications and is correctly connected at each end.
	Ensure the serial cable is not defective.
	Ensure the communication parameters for the baud rate, parity, data bits and stop bits are consistent with those being sent from the host computer.
	Ensure the printer is receiving information from the computer using the Receive Buffer Data Dump mode. Refer to that procedure within this manual for instructions. The command stream should be continuous and possess 0Dhex and/or 0Ahex (carriage return and line feed) characters throughout.
	Replace the interface board with another to isolate the problem.
	Replace the interface board permanently if determined to be the problem.

LAN ETHERNET INTERFACE

CHK	TROUBLESHOOTING STEP
	Ensure the interface has been correctly configured. Wait two minutes and run self-test to verify. If a test label does not print, there may be a hardware problem.
	Ensure the serial cable meets specifications and is correctly connected at each end.
	Ensure the cable and its ports are not defective.
	Ensure that a faulty print server or other protocol related scenarios are not creating a queue setup issue. Systematically perform checks and tests to isolate the cause.
	If using TCP/IP, ensure a valid IP address is specified and that all parameters are correct (subnet mask, gateway, etc.). Attempt to PING the IP address assigned to the network interface.
	Install the IPX/SPX protocol on a workstation to determine if the network device can be discovered via the MAC address. If able, configure the appropriate protocols and retest connectivity.
	Use a crossover cable to isolate the printer from the network by connecting from the interface and workstation. Verify that the parameters match on each. Test connectivity.

WIRELESS LAN INTERFACE

CHK	TROUBLESHOOTING STEP
	Ensure the interface has been correctly configured. Wait two minutes and run self-test to verify. If a test label does not print, there may be a hardware problem.
	Check the Wireless LAN connection by using the Ping command. If the Ping fails, double-check all WLAN hardware and connection settings. Print test labels to verify that the new settings can work.
	If the Ping test is OK, check the printer's location to adequate signal strength. For weak signals, try relocating the printer close to the access point. If the signal strength is high, replace the WLAN interface card.


UNIVERSAL SERIAL BUS (USB) INTERFACE

If nothing prints during a test print, verify the device drivers have been successively installed by performing the following:


	Click on Start, Settings, and then Control Panel.
	Click on System within the new window.
	Click on the Device Manager tab.
	Ensure that the View Device By Type is checked.
	Scroll to printer driver for your SATO device. Ensure that errors do not exist. Reinstall the driver as required.
	Reboot the PC and the printer.
	Contact Microsoft technical support for further assistance as required.

TROUBLESHOOTING FLOWCHARTS


PROBLEM: PRINTER DOES NOT POWER UP



PROBLEM: LABEL DOES NOT FEED OUTWARD IN A STRAIGHT PATH




PROBLEM: PRINTER DOES NOT PRINT




Unit 3: Troubleshooting

PROBLEM: PRINTER DOES NOT PRINT




PROBLEM: PRINTER DOES NOT FEED LABELS




Unit 3: Troubleshooting


PROBLEM: PRINTER DOES NOT STOP AT THE CORRECT POSITION




PROBLEM: WIRELESS LAN PRINTER IS NOT PRINTING



PROBLEM: PRINTING IS TOO DARK




PROBLEM: PRINTING IS TOO LIGHT ON ONE SIDE




Unit 3: Troubleshooting


PROBLEM: PRINT START POSITION IS INCORRECT VERTICALLY



PROBLEM: PRINT START POSITION IS INCORRECT HORIZONTALLY




PROBLEM: WHITE LINES APPEAR IN PRINTED LABELS




Unit 3: Troubleshooting


PROBLEM: LABELS ARE NOT BEING DISPENSED PROPERLY BY THE OPTIONAL DISPENSER UNIT



PROBLEM: THE CUTTER IS NOT WORKING



PROBLEM: THE CUTTER IS NOT WORKING



TEST PRINT TROUBLESHOOTING

Chapter provides instruction on special printing to identify and resolve specific print problems.

TEST LABELS

The test label is designed to assist in the identification of print problems.




Figure 3-1, Test Label Printing

NOTE: The only print problem that the following sample test label does not display is fading of print image from one side of the label to the other. This is the result of improper print head balance.




Figure 3-2, Sample Test Label

DATA DUMP DIAGNOSTIC LABEL

The contents of the print buffer can be examined using the Data Dump Mode. In the left column, each line of data received is numbered. The center column provides the data in hexadecimal format. And in the right column, same data is provided in the ASCII format. Follow the flow chart provided below to perform this activity.




Figure 3-3, Data Dump Diagnostic Mode

PRINTING FACTORY/SERVICE TEST LABELS

The Factory/Service Test Labels prints the internal operating parameters of the printer.




Figure 3-4, Factory/Service Test Label Printing

This page is left blank intentionally

4

REPLACEMENT PROCEDURES

- Print Head
- Platen Roller
- Fuse
- Main Circuit Board
- Panel Board
- Label Sensor Board
- Label Sensor
- Cover Open Sensor
- Drive Motor
- Drive Gear
- Cutter Replacement

REPLACEMENT PROCEDURES

This unit contains step-by-step instructions for the removal and replacement of all primary components and sub-assemblies.

PRINT HEAD REPLACEMENT

If the print head becomes damaged or worn, it can be easily removed and replaced without having to make critical adjustments.

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Lift up the top housing cover (1) (See Figure 4-1) to access the print head assembly.
- 3 Press the central release latch (2) to release the print head (3) from the bracket (4).

NOTE: To detach the print head, press the release latch (2), then simultaneously tilt the print head downwards. Tilt it at an angle and pull it out.

- 4 Disconnect the wiring harness from worn print head (3).
- 5 Connect the print head wiring harness to the replacement print head (3).
- 6 Latch the replacement print head (3) into the head bracket (2).

NOTE: Insert the lower portion of the print head first, sliding it into the pivot pins at each end of the bracket. Press inward and raise upward, the upper portion of the print head until it locks into position.

- 7 Load some media, close the cover, and do a test print to confirm proper function.




Figure 4-1, Print Head Replacement

PLATEN ROLLER REPLACEMENT

The platen roller is a high wear component due to its treading against the print media. This treading will eventually wear grooves into the rubber material and negatively affect print output.

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Lift up the top housing cover (1) (See Figure 4-2) to access the platen roller (2).
- 3 Detach the platen gear cover (3) from the printer housing (4).
- 4 Lift the dispenser bar (5) upward and away from the assembly (2, 5).
- 5 Install a replacement platen roller assembly (5, 2) to the housing (4).
- 6 Lower the dispenser bar (5) and reattach the gear cover (3).
- 7 Load some media, close the cover, and do a test print to ensure proper function.




Figure 4-2, Platen Roller Replacement

ACCESSING THE MAIN BOARD

Throughout the rest of this Service Manual, reference will be made to the main board of the printer. To access the main board, follow the instructions below.

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Place the printer with its underside facing upward.
- 3 Remove the bottom housing cover (See Figure below) by removing four screws.
- 4 Put the screws in a safe place so that they can be used to re-secure the bottom housing cover when servicing is complete.




Figure 4-3, Removing Bottom Cover

FUSE REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove the base cover from the housing cover to access the fuse.
- 3 Locate fuse (1), (See Figure 4-4) on the main circuit board (2).
- 4 Detach the defective fuse (1) from the metal holders (3).
- 5 Attach a replacement fuse (1) to the metal holders (3) on the main circuit board (2).
- 6 Attach base cover to the housing cover.
- 7 Load some media, and run some tests to confirm proper function.




Figure 4-4, Fuse Replacement

MAIN CIRCUIT BOARD REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove the base cover from the housing cover to access the main circuit board.
- 3 Remove the five screws (1) (See Figure 4-5) that secure the main circuit board (2) to the printer (3).
- 4 Disconnect all wiring harnesses from the defective main circuit board (2).
- 5 Remove the defective main circuit board (2), along with the interface cover (4), from the printer (3).
- 6 Detach the interface cover (4) from the defective board (2) and attach it to the replacement board (2).
- 7 Insert the replacement main circuit board (2) into the printer (3) and secure it using the five screws (1) previously removed from the old board.
- 8 Reconnect all the appropriate wiring harnesses to the replacement circuit board (2).

NOTE: Each wiring harness connector is different from the others. To reconnect the wiring harnesses, simply match mating halves.

- 9 Attach the base cover to the housing cover.
- 10 Load some media, and run some tests to confirm proper function.




Figure 4-5, Main Circuit Board Replacement

PANEL BOARD REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove the base cover from the housing cover to access the panel board.
- 3 Remove the two screws (1) (See Figure 4-6) that secure the panel board bracket (2) to the printer (3).
- 4 Disconnect the wiring harness for the defective panel board (4) from the main circuit board (5).
- 5 Detach the lens unit (6), button unit (7), and panel board (4), from the bracket, in this order (2).
- 6 Insert the wiring harness of the replacement panel board (4) through bracket (2) and connect to main circuit board (5).
- 7 Reattach the replacement panel board (4), button unit (7), and lens unit (6) consecutively to bracket (2).
- 8 Insert the assembly (7, 6, 4, 2) into the printer (3) and secure using two screws (1).

NOTE: When properly installed, the lens, buttons, and power switch should protrude through their respective slots on the printer's front panel.

- 9 Attach the base cover to the housing cover.
- 10 Load some media, and run some tests to confirm proper function.




Figure 4-6, Panel Board Replacement

RELAY BOARD (LABEL SENSOR BOARD) REPLACEMENT

- 1 Turn off the printer and disconnect the power supply cord.
- 2 Remove all media from the printer.
- 3 Remove one screw (1) (See Figure 4-7a) that secures the bar (2) to the printer (3).
- 4 Remove one screw (4) and gear (5) from the printer (3).
- 5 Lift away the left-side media holder (6) from the printer (3).




Figure 4-7a, Label Sensor Board Replacement

- 6 Remove the three screws (7) (See Figure 4-7b) securing the cover (8) to the left-side media holder (6).
- 7 As the main signal cable of the relay board (9) is soldered on, you need to disconnect the other end of the cable from the main board by the following steps.

NOTE: Each wiring harness connector is different from the others. To reconnect the wiring harnesses, simply match mating halves.




Figure 4-7b, Relay Board Replacement

- 8 Remove the base cover from the housing cover to access the main board (10) (Figure 4-7c).
- 9 Remove the five screws (11) securing the main circuit board (10) to the printer (3).




Figure 4-7c, Detachment of Relay Board signal cable from Main Board

- 10 Lift the main board (10) and disconnect the wiring harness of the relay board.
- 11 Now replace the relay board and reconnect the main signal wire to the main board.
- 12 Reinstall the main board and the cover.
- 13 Re-attach the base cover (8) to the left-side media holder (6) using three screws (7).
- 14 Place the left-side media holder (6) (See Figure 4-7a) into the printer (3) along with the gear (5) and secure using a screw (4).
- 15 Secure the bar (2) to the printer (3) using a screw (1).
- 16 Load some media, and run some tests to confirm proper function.

LABEL SENSOR REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove all media from the printer.
- 3 Remove one screw (1) (See Figure 4-8a) that secures the bar (2) to the printer (3).
- 4 Remove one screw (4) and gear (5) from the printer (3).
- 5 Lift away the left-side media holder (6) from the printer (3).
- 6 Remove one screw (7) that secures the sensor cover (8) to the left-side media holder (6).
- 7 Remove one screw (9) that secures the sensor (10) to the sensor cover (8).




Figure 4-8a, Label Sensor Replacement

- 8 Remove three screws (11) (See Figure 4-8b) securing the cover (12) to the left-side media holder (6).
- 9 Disconnect the wiring harnesses of the defective sensors (10&13) from the sensor board (14).
- 10 Insert replacement sensors (13&10) into the left-side media holder (6) and connect their relative wiring harnesses to the sensor board (14).

NOTE: Each wiring harness connector is different from the others. To reconnect the wiring harnesses, simply match mating halves. Ensure to properly route the wiring harnesses as before their removal.

- 11 Secure the cover (12) to the media holder (6) using three screws (11).
- 12 Insert the sensor (10) (See Figure 4-8a) into the underside of the sensor cover (8) and secure using a screw (9).
- 13 Attach the sensor cover (8) to the side of media holder (6) using a screw (7).
- 14 Place the media holder (6) into the printer (3) along with the gear (5) and secure using a screw (4).
- 15 Secure the bar (2) to the printer (3) using a screw (1).
- 16 Load some media, and run some tests to confirm proper function.




Figure 4-8b, Label Sensor Replacement

COVER SENSOR REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Lift up the top housing cover (1) (See Figure 4-9a) to access the sensor area.
- 3 Remove the two screws (2) securing the cable cover (3) to the top housing cover (1).
- 4 Remove the screw (4) that secures the cover sensor (5) to the top housing cover (1).




Figure 4-9a, Cover Sensor Replacement

- 5 Remove the base cover from the printer to access the main board (6) (See Figure 4-9b).
- 6 Remove the five screws (7) that secure the main board (6) to the printer (8).
- 7 Remove the main board (6) and disconnect all wiring harnesses of the defective cover-open sensor.
- 8 Detach the defective sensor from the printer and route the replacement sensor in its place.
- 9 Connect the replacement sensor to the main board (6) and re-secure the board (6) to the printer (8) using five screws (7).

- 10 Secure the base cover to the printer (8).
- 11 Secure the sensor (5) (See Figure 4-9a) to the top housing cover (1) using screw (4).
- 12 Return the cable cover (3) to the top housing cover (1) and secure it using two screws (2).
- 13 Load some media, and run some tests to confirm proper function.




Figure 4-9b, Cover Sensor Replacement

DRIVE MOTOR REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove the base cover from the housing cover to access the drive motor.
- 3 Remove the five screws (1) (See Figure 4-10a) that secure the main circuit board (2) to the printer (3).
- 4 Disconnect all wiring harnesses from the defective main circuit board (2).
- 5 Remove the circuit board (2), along with the interface cover (4), from the printer (3), and set it aside.
- 6 Remove the two screws (5) that secure the drive train (6) to the printer (3).
- 7 Remove the drive train (6) from the printer (3) and disconnect the motor's wiring harness.




Figure 4-10a, Drive Motor Replacement

Drive Motor Replacement (cont'd)

- 8 Remove the three screws (7) (See Figure 4-10b) that secure the gear cover (8) to the motor bracket (9).
- 9 Remove the screw (10) that secures the defective motor (11) to the motor bracket (9).
- 10 Install the replacement motor (11) to the motor bracket (9) using one screw (10).
- 11 Attach the gear cover (8) to the motor bracket (9) using three screws (7).
- 12 Insert the drive train (6) (See Figure 4-10a) into the printer (3) using two screws (5).
- 13 Connect the motor's wiring harness to main circuit board (2).
- 14 Apply circuit board (2), along with interface cover (4), to printer (3), and secure using five screws (1).
- 15 Reconnect all the appropriate wiring harnesses to the main circuit board (2).
- 16 Attach the base cover to the housing cover.
- 17 Load some media, and run some tests to confirm proper function.




Figure 4-10b, Drive Motor Replacement

DRIVE GEAR REPLACEMENT

- 1 Turn the printer OFF and disconnect the power supply cord.
- 2 Remove the base cover from the housing cover to access the drive motor.
- 3 Remove the five screws (1, Figure 4-11a) that secure the main circuit board (2) to the printer (3).
- 4 Disconnect all wiring harnesses from the defective main circuit board (2).
- 5 Remove the circuit board (2), along with the interface cover (4), from the printer (3), and set it aside.
- 6 Remove the two screws (5) securing the drive train (6) to the printer (3).
- 7 Withdraw the drive train (6) from the printer (3) and disconnect the motor's wiring harness.




Figure 4-11a, Drive Gear Replacement

Drive Gear Replacement (cont'd)

- 8 Remove the three screws (7) (See Figure 4-11b) that secure the gear cover (8) to the motor bracket (9).
- 9 Detach the two snap rings (10) securing the worn gears (11 & 12) and remove.
- 10 Insert replacement gears (12 & 11) onto their relative spindles using the snap rings (10).
- 11 Attach the gear cover (8) to the motor bracket (9) using three screws (7).
- 12 Insert the drive train (6) (See Figure 4-11a) into the printer (3) and secure using two screws (5).
- 13 Connect the motor's wiring harness to the main circuit board (2).
- 14 Install the circuit board (2), along with the interface cover (4), to the printer (3), using five screws (1).
- 15 Reconnect all the appropriate wiring harnesses to the main circuit board (2).
- 16 Attach the base cover to the housing cover.
- 17 Load some media, and run some tests to confirm proper function.




Figure 4-11b, Drive Gear Replacement

CUTTER ASSEMBLY

The cutter assembly is an optional unit typically preinstalled at the factory. To retrofit a X700 printer that was not originally delivered with a cutter, follow the procedures here but make sure to order the complete set of components that also includes the cutter alignment assembly that mounts near the print head.

- 1 Turn off the printer and disconnect the power supply cord.
- 2 Open top housing cover (1) and remove front cover (2) from printer base (3).
- 3 Connect the cutter unit's wiring harness to the accessory connector.

NOTE: If unsure which connector is the accessories connector, refer to the Introduction unit of this manual for identification.

- 4 Pivot the dispenser bar (4) upward (Figure 4-12a) to permit cutter assembly (5) installation.




Figure 4-12a, Cutter Installation

- 5 Apply cutter assembly (5) to the front of printer base (3) and secure using two screws (6).

NOTE: When mounting the cutter unit, ensure the hangers on the back side of the assembly insert into their respective slots on the printer base so as to suspend the assembly. If this is performed correctly, the two mounting holes will be properly aligned for the attaching hardware.

- 6 Lower the dispenser bar (4) and apply the front cover (2).
- 7 Perform steps 7 through 13 to install/replace the cutter blade as the situation requires.

NOTE: If the cutter assembly was pre-existing on this particular printer and this is a replacement operation, the cutter blade may not require installation nor replacement. Perform step 6 only if deemed necessary.

- 8 Press latch (7, Figure 4-12b) to release print head (8) from mounting bracket (9). Lift away print head (8).

NOTE: Press on the latch while manually lowering the print head to remove.

- 9 Remove two screws (10) securing alignment assembly (11) to mounting bracket (9). Lift away (11).
- 10 Remove two screws (12) securing upper plate (13) to lower plate (14) and separate.




Figure 4-12b, Cutter Blade Installation

- 11 Install the cutter blade (15) between the plates (14) and (13), secure it using two screws (12).

This page is left blank intentionally

5

CHECKS/ADJUSTMENT PROCEDURES

- **Top of Form Position**
- **Factory Clear**
- **Print Darkness**
- **Printer Counter Clear**
- **Cutter Counter Clear**
- **Test Print Counter Clear**
- **Cut Position**
- **Paper Sensor Sensitivity**
- **Gap Sensor Sensitivity**
- **Eye-Mark Sensor Adjustment**
- **Power Supply Checks**

ADJUSTMENT PROCEDURES

This unit covers all of the printer adjustment procedures that may occur following the initial configuration.


TOP OF FORMS OFFSET

This can be done using the VR4 potentiometer on the Configuration Panel. This potentiometer is set at the factory so that it has a range of +/- 3.75 mm. The midpoint setting should have no effect on the label top of form. Turning the potentiometer all the way clockwise should move the print position 3.75 mm upwards towards the leading edge of the label. Turning it all the way counterclockwise should move the print position down 3.75mm away from the leading edge of the label.

- 1 Place DSW6 on the Configuration Switch in the OFF position.
- 2 Turn the power OFF.
- 3 While pressing the FEED button on the Operator Panel, turn the power ON.
- 4 When you hear one beep from the printer, release the FEED button.
- 5 Press the LINE button to begin printing large Test Labels (press the FEED button if you are using labels smaller than 4.1" (104 mm) in width).
- 6 Adjust potentiometer VR4 until the first print position is at the desired location on the label.
- 7 Press the FEED button to stop printing.

Note:

Adjusting the Label Top Of Form with VR4 will affect the stop position of the label and the cut/tear-off positions.



FACTORY CLEAR

This procedure clears all data from the EEPROM. Once initialized and completed, the process cannot be reversed.

- 1 Open the Top Cover and remove the front cover.
- 2 Switch ON the DSW5 and DSW6 dip switches.

NOTE: Refer to Figure 5-1 for visual assistance in performing this procedure.

- 3 Press and hold the LINE and FEED buttons while switching on the printer.
- 4 Release the LINE and FEED buttons when a beep sounds.
- 5 Switch OFF the DSW5 and DSW6 dip switches and latch the Top Cover closed.

NOTE: When the Top Cover is closed, the clear process will automatically be initialized. During the clear process, the printer will be in an offline state. Press the LINE button to test print a large label and the FEED button to test print a small label.

NOTE: Press the LINE button to test print a large label and the FEED button to test print a small label. Pressing the FEED button terminates printing activity. Print at least two labels to ensure the clear process was successful.

PRINT DARKNESS

A fine adjustment for PRINT DARKNESS can be made using potentiometer VR1 on the Front Operator Panel. It provides a continuous range of adjustment, allowing you to make precise changes. Turning VR1 clockwise will make the print darker, and counterclockwise will make it lighter.

- 1 Place DSW6 on the Configuration Switch in the ON position.
- 2 Turn the Power Switch OFF.
- 3 While pressing the FEED button on the Operator Panel, turn the Power Switch ON.
- 4 When you hear one beep from the printer, release the FEED button.
- 5 Press the LINE button to begin printing large Test Labels (press the FEED button if you are using labels smaller than 4.1" (104 mm) in width).
- 6 Adjust potentiometer VR1 until the desired print darkness is obtained.
- 7 Press the FEED button to stop the printing.

Adjustment of the Print Darkness using VR1 will affect the darkness in all the <ESC>#E command code ranges; that is, if the print darkness is adjusted with VR1 for lighter print, the darkness will be lighter in all the Print Darkness ranges selected by the command code.




Figure 5-1, Test Panel




Figure 5-2, Test Module Usage

PRINTER COUNTER CLEAR

This procedure clears the internal cycle counters of various components and returns their values to zero.

- 1 Open the Top Cover and remove the front cover.
- 2 Set the DSW5 dip switch to the ON position.

NOTE: Refer to Figure 5-1 for visual assistance in performing this procedure.

- 3 Press and hold the LINE and FEED buttons while switching ON the printer.
- 4 Release the LINE and FEED buttons when a beep sounds.
- 5 Switch OFF the DSW5 dip switch and latch the Top Cover closed.

NOTE: When the Top Cover is closed, the clear process will automatically be initialized. During the clear process, the printer will be in an offline state.

Press the LINE button to test print a large label and the FEED button to test print a small label.

NOTE: Pressing the FEED button pauses test printing activity. Allow a minimum of two labels to be printed before terminating to ensure the clear process was successful.

CUTTER COUNTER CLEAR (IF CUTTER IS INSTALLED)

- 1 Open the Top Cover and remove the front cover.
- 2 Switch the DSW6 dip switch to the ON position.

NOTE: Refer to Figure 5-2 for visual assistance in performing this procedure.

- 3 Press and hold the LINE and FEED buttons while switching ON the printer.
- 4 Release the LINE and FEED buttons when a beep sounds.
- 5 Switch OFF the DSW6 dip switch and latch the Top Cover closed.

NOTE: When the Top Cover is closed, the clear process will automatically be initialized. During the clear process, the printer will be in an offline state.

Press the LINE button to test print a large label and the FEED button to test print a small label.

NOTE: Pressing the FEED button pauses test printing activity. Allow a minimum of two labels to be printed before terminating to ensure the clear process was successful.

TEST PRINT COUNTER CLEAR

- 1 Open the Top Cover.
- 2 Press and hold the LINE and FEED buttons while switching ON the printer.
- 3 Release the LINE and FEED buttons when a beep sounds.
- 4 Latch the Top Cover closed.

NOTE: When the Top Cover is closed, the clear process will automatically be initialized. During the clear process, the printer will be in an offline state.
Press the LINE button to test print a large label and the FEED button to test print a small label.

NOTE: Pressing the FEED button pauses test printing activity. Allow a minimum of two labels to be printed before terminating to ensure the clear process was successful.

CUT POSITION (IF CUTTER IS INSTALLED)

- 1 Open the Top Cover and remove the front cover.
- 2 Switch the DSW6 dip switch to the OFF position and adjust the VR1 potentiometer to its center position.

NOTE: Refer to Figure 5-2 for visual assistance in performing this procedure.

- 3 Press and hold the FEED button while switching ON the printer.
- 4 Release the LINE and FEED buttons when a beep sounds.
- 5 Press either the LINE or FEED button to print a test label.

NOTE: Press the LINE button to test print a large label and the FEED button to test print a small label. Pressing the FEED button pauses test printing activity.

- 6 Use the printed test label to determine the required direction for the desired adjustment.
- 7 Adjust the VR1 potentiometer accordingly and repeat the test print process.
- 8 Repeat steps 3 through 5 until a proper offset adjustment is achieved.

EYE MARK / PAPER END SENSOR SENSITIVITY

- 1 Open the Top Cover and remove the front cover.
- 2 Turn the VR2 potentiometer fully counter-clockwise.
- 3 Connect the Test Module to the test connector on the printer's test panel.

NOTE: Refer to Figure 5-2 for visual assistance in performing this procedure.

NOTE: Use of the Test Module on this printer also requires the use of a connector adapter cable that should also be purchased with the module.

- 4 Connect the multimeter ground probe to the pin identified as GND on the test module.
- 5 Connect the multimeter positive probe to the pin identified as SIG on the test module.
- 6 Set the multimeter to DC Voltage mode and turn the test module dial to position 4.
- 7 Physically place the media's reference point into the sensor.
- 8 Adjust the VR2 potentiometer until the multimeter displays a value of $+0.5\text{ V} \pm 0.2\text{ V}$.
- 9 Remove the label from the sensor and confirm that the voltage displayed is now 0.9 volts above the previous reading.
- 10 Repeat steps 7 through 9 until a acceptable sensitivity level is established.

PAPER END SENSOR SENSITIVITY (ALTERNATE)

CAUTION: Care should be taken not to short the pins on the test connector. Damage to the PCB board could occur if the pins are shorted.

- 1 Open the Top Cover and remove the front cover.
- 2 Turn the VR2 potentiometer fully counter-clockwise.
- 3 Connect an insulated multimeter ground probe to pin 3 (GND) on the test connector.
- 4 Connect an insulated multimeter positive probe to pin 2 on the test connector.
- 5 Set the multimeter to DC Voltage mode.
- 6 Physically place the media into the sensor.
- 7 Adjust the VR2 potentiometer until the multimeter displays a value of $+0.5\text{ V} \pm 0.2\text{ V}$.
- 8 Remove the label from the sensor and confirm that the voltage displayed is now 0.9 volts above the previous reading.
- 9 Repeat steps 7 through 9 until an acceptable sensitivity level is established.

GAP SENSOR SENSITIVITY

- 1 Open the Top Cover and remove the front cover.
- 2 Turn the VR3 potentiometer fully counter-clockwise.

NOTE: Refer to Figure 5-2 for visual assistance in performing this procedure.
- 3 Connect the Test Module to the test connector on the printer's test panel.

NOTE: Use of the Test Module on this printer also requires the use of a connector adapter cable that should also be purchased with the module.
- 4 Connect the negative multimeter ground probe to the pin identified as GND on the test module.
- 5 Connect the multimeter positive probe to the pin identified as SIG on the test module.
- 6 Set the multimeter to DC Voltage mode and turn the test module dial to position 3.
- 7 Physically place the media's reference point into the sensor.
- 8 Adjust the VR3 potentiometer until the multimeter displays a value of +0.5 volts or less.
- 9 Physically move the media so that its printable surface is over the sensor.
- 10 Confirm the voltage displayed on the multimeter is now +1.0 volts or greater.
- 11 Repeat steps 7 through 10 until a acceptable sensitivity level is established.

GAP SENSOR SENSITIVITY (ALTERNATE)

CAUTION: Care should be taken not to short the pins on the test connector damage to the PCB board could occur if the pins are shorted.


- 1 Open the Top Cover and remove the front cover.
- 2 Turn the VR3 potentiometer fully counter-clockwise.
- 3 Connect an insulated negative multimeter ground probe to pin 3 (GND) on the test connector.
- 4 Connect an insulated positive multimeter positive probe to pin 1 on the test connector.
- 5 Set the multimeter to DC Voltage mode.
- 6 Physically place the media's reference point or gap into the sensor.
- 7 Adjust the VR3 potentiometer until the multimeter displays a value of +0.5 volts or less.
- 8 Physically move the media so that its printable surface is over the sensor.
- 9 Confirm the voltage displayed on the multimeter is now +1.0 volts or greater.
- 10 Repeat steps 7 through 10 until an acceptable sensitivity level is established.
- 11 Repeat steps 7 through 10 until a acceptable sensitivity level is established.

POWER SUPPLY CHECKS


Obtain a DC Multimeter and Number 2 Phillips screwdriver for this check. To check voltage levels, first check the Main PCB fuse (see next page) and replace it if necessary. Then follow the steps below:

- 1 Turn the printer OFF.
- 2 Set the multimeter to DC mode.
- 3 Attach the negative (-) lead from the multimeter to Pin 3 (GND) of CN3 on the configuration panel.
- 4 Attach the positive (+) lead from the multimeter to Pin 4 of CN3 on the configuration panel.
- 5 Turn the printer ON.
- 6 Confirm that the voltages are correct. If not, remove the power connector from the rear of the printer, connect the test probes to Pin 1 (+) and Pin 4 (-) and measure the voltages.

Ideal Voltage	Test Points	Voltage Range
+ 5.0 V	Pin 3 (GNC) of CN3 Pin 4 of CN3	+4.8 V to +5 V



Power Supply Connector



- 7 If the voltages are not correct, replace the power supply.