



SIMPLY BETTER!

**B&K Components Device Interface Protocol
(BKC-DIP) Specification**

Version 2.01.00

B&K Components Device Interface Protocol (BKC-DIP) Specification
Version 2.01.00
Updated 01/24/07

Table of Contents

REVISION HISTORY	5
Version 2.01.00.....	5
Version 2.00.00.....	5
Version 1.02.01.....	5
Version 1.02.00.....	5
Version 1.01.xx.....	5
INTRODUCTION.....	6
Overview.....	6
Document Conventions	6
Product Specific Appendices	6
Supported RS-232 Settings	6
Basic Protocol Syntax.....	6
Begin/End Message Characters ()	7
ID, Receive or Transmit	7
Delimiter Character ,	7
Checksum Delimiter ;	7
Identifier SubIdentifier Delimiter	8
Checksum	8
Tag Delimiter :	9
NEW FEATURES OF BKC-DIP V2.0 VS. V1.0	10
8 alpha-numeric character tags.....	10
Changes to the Parser Allowing “ , : ; () in Strings.....	10
Parser Synchronization	10
Additional Intelligence require in Host Parser	11
SubIdentifiers Indicating Hardware Zone information.....	12
Zone Specific specifier.....	12
Macro specifier	12
Macro Trigger Command.....	12
Favorite Settings of a Preset.....	12

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

Additional Reply Display formats	13
SUMMARY OF BKC-DIP COMMANDS	14
Host to B&K Device Commands Summary	14
G (get) command	14
S (set) Command	14
D (display) Command	15
X (executive) Command	15
B&K Device to Host Commands Summary	16
E (echo) Command.....	16
R (reply) Command	16
U (update) Command	16
HARDWARE ZONES AND GROUPS	17
Hardware Zones	17
Groups	17
Code Sets, Zone IDs, and Logical Zones	18
Code Sets.....	18
Zone IDs.....	18
Logical Zones.....	19
Groups and Linking Hardware Zone Control	19
Default CT 610 Example	20
More Complicated CT 610 Example.....	21
SubIdentifiers	22
HOST TO B&K DEVICE COMMANDS	25
G (get) Command	25
Presets: (<i>receiveID</i> , G, Pz= <i>nn</i> , <i>identifier</i> , ... <i>identifier</i> ; cs16)	25
System Settings: (<i>receiveID</i> , G, S, <i>identifier</i> , ... <i>identifier</i> ; cs16)	26
Zone Adjustment (Hardware Special) Settings: (<i>receiveID</i> , G, H, <i>identifier</i> , ... <i>identifier</i> ; cs16).....	26
Zone Specific Settings: (<i>receiveID</i> , G, Zzz, <i>identifier</i> , ... <i>identifier</i> ;cs16).....	26
Macro Settings: (<i>receiveID</i> , G, Mt= <i>mm</i> , <i>identifier</i> , ... <i>identifier</i> ;cs16)	27
All Macro Settings: (<i>receiveID</i> , G, Mt, <i>identifier</i> , ... <i>identifier</i> ;cs16)	27
Tuner Station Settings: (<i>receiveID</i> , G, Tnn, <i>identifier</i> , ... <i>identifier</i> ;cs16)	27
Realtime Status: (<i>receiveID</i> , G, R, <i>identifier</i> , ... <i>identifier</i> ; cs16).....	28
Override Settings: (<i>receiveID</i> , G, O, <i>identifier</i> , ... <i>identifier</i> ;cs16)	29
Display Content: (<i>receiveID</i> , G, D, d;cs16).....	29
Format Specification: (<i>receiveID</i> , G, Ff; cs16)	29
Error Log Status: (<i>receiveID</i> , G, E, <i>identifier</i> , ... <i>identifier</i> ; cs16)	31
Favorite Settings of a Preset: (<i>receiveID</i> , G, A, <i>identifier</i> , ... <i>identifier</i> ; cs16)	31
S (set) Command	32
Presets: (<i>receiveID</i> , S, Pz= <i>nn</i> , <i>identifier</i> = <i>value</i> , ... <i>identifier</i> = <i>value</i> ; cs16)	32
System Settings: (<i>receiveID</i> , S, S, <i>identifier</i> = <i>value</i> ,... <i>identifier</i> = <i>value</i> ; cs16).....	33

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Zone Adjustment (Hardware Special) Settings: (<i>receiveID</i> , S, H, <i>identifier=value</i> ,... <i>identifier=value</i> ; <i>cs16</i>)	33
Zone Specific Settings: (<i>receiveID</i> , S, Zzz, <i>identifier = value</i> , ... <i>identifier = value</i> ; <i>cs16</i>).....	34
Macro Settings: (<i>receiveID</i> , S, Mt, <i>identifier = value</i> , ... <i>identifier = value</i> ; <i>cs16</i>)	34
Serial Macro	34
Escape Characters in Serial Macros	34
IR Macro.....	35
Tuner Station Settings: (<i>receiveID</i> , S, Tnn, <i>identifier = value</i> , ... <i>identifier = value</i> ; <i>cs16</i>).....	35
Favorite Settings of a Preset: (<i>receiveID</i> , S, A, <i>identifier=value</i> , ... <i>identifier=value</i> ; <i>cs16</i>)	35
Override Settings: (<i>receiveID</i> , S, O, <i>identifier=value</i> ,... <i>identifier=value</i> ; <i>cs16</i>)	36
Override Timeout	37
IR Command: (<i>receiveID</i> , S, I, <i>z=ir</i> ; <i>cs16</i>)	38
Front Panel Commands: (<i>receiveID</i> , S, F, <i>z=fp</i> ; <i>cs16</i>)	38
Error Logs: (<i>receiveID</i> , S, E, <i>identifier=value</i> ,... <i>identifier=value</i> ; <i>cs16</i>)	38
D (display) Command	39
On Screen Display (O): (<i>receiveID</i> , D, O, Ttt, Mm, Xcc, Yrr, "text", ... Xrr, Ycc, "text"; <i>cs16</i>)(only applicable to units with On Screen Display capabilities)	39
Front Panel Display (F): (<i>receiveID</i> , D, F, Ttt, Xcc, Yrr, "text"; <i>cs16</i>).....	40
LED display: (<i>receiveID</i> , D, L, Tt, <i>n=bitmap</i> ; <i>cs16</i>)	41
X (executive) Command.....	42
M (Macro Trigger) Command: (<i>receiveID</i>, M, t=mm, ... ,t=mm;<i>cs16</i>)	43
B&K DEVICE TO HOST COMMANDS	44
E (echo) Command.....	44
Implementing Software Flow Control using Echo Commands	44
R (reply) Command.....	44
Reply from the Get Display command (<i>transmitID</i> , G, D, <i>d</i> ; <i>cs16</i>)	45
BKC-DIP V1.0 Compliant Display Reply	46
BKC-DIP V2.0 Compliant Display Reply without Attributes.....	47
BKC-DIP V2.0 Compliant Display Reply with Attributes	48
U (update) Command.....	50
Status message: (<i>transmitID</i> , U, S, <i>n="status message"</i> ; <i>cs16</i>).....	50
BKC-DIP Active message: (<i>transmitID</i> , U, S, 0="BKC-DIP ACTIVE"; <i>cs16</i>)	50
IR message: (<i>transmitID</i> , U, I, <i>z=ir</i> ; <i>cs16</i>)	51
Front Panel message: (<i>transmitID</i> , U, F, <i>z=ir</i> ; <i>cs16</i>).....	51
Realtime Status message: (<i>transmitID</i> , U, R, <i>identifier=value</i> ; <i>cs16</i>)	51
USE OF RECEIVE AND TRANSMIT IDS	53
The Receive ID.....	53
The Transmit ID.....	53
A Multiple Unit Example	53

Revision History

Version 2.01.00

1. Add new Hardware Special Format (receiveID,G,F9;).

Version 2.00.00

1. New version of BKC-DIP with expanded capabilities and support for multi-hardware zone devices. See section **New Features of BKC-DIP V2.0 vs. V1.0** for details.
2. Override Parameters have diverged to be specific per product. Moved Override Parameters section to Product Specific Appendices' **Appendix P**.
3. Status Update Messages have been moved to the Product Specific Appendices' **Appendix Q** and further detailed.
4. Additional Format Specifiers have been added to support new commands. Refer to **Format Specification: (receiveID, G, Ff; cs16)** for more detail.

Version 1.02.01

1. Corrected examples for Set OSD Display command.
2. Corrected note regarding valid OSD row range.
3. Added note about 16:9 Aspect ratio interaction with OSD Display row specification.

Version 1.02.00

1. This is the first version of this documentation which is specified by version number.
2. This document includes augmentation to the original BKC-DIP V1.01 protocol and supersedes information found in "*B&K Components Device Interface Protocol (BKC-DIP) V1.01 Protocol Document*".

Version 1.01.xx

1. Documentation earlier than Version 1.02.00 was not specified by a version number. This encompasses all documentation prior to 08/07/00. Prior documentation entitled "*B&K Components Device Interface Protocol (BKC-DIP) V1.01 Protocol Document*" described BKC-DIP Version 1.01 is therefore referred to as Version 1.01.xx here.

Introduction

Overview

The following is the specification and implementation details of the B&K Components Device Interface Protocol, BKC-DIP. BKC-DIP is an ASCII text based serial protocol. The electrical specification is RS-232, thus B&K Components' devices may be controlled by standard "COM" ports or similar serial devices. Through the use of Receive and Transmit IDs, multiple B&K Components units may be controlled on a common serial bus.

Document Conventions

All numbers are assumed to be hexadecimal. Hexadecimal (or Hex for short) characters range from 0 to F.

For example:

The number 19 is the hexadecimal number 19 which is $(1 \times 16^1) + (9 \times 16^0)$ or 25 decimal. Similarly, EA is the hexadecimal number EA which is $(14 \times 16^1) + (10 \times 16^0)$ or 234 decimal. For clarity, some descriptions regarding numbers may use the *xxh* notation to remind the reader that the number is implicitly hexadecimal where *xx* are the hexadecimal characters 0 - F. Thus the previous examples would be 19h and EAh respectively, the "h" indicating hexadecimal.

Italics indicate a non-literal string.

For example:

(00,G, P00, 0;*cs16*)
cs16 indicates the calculated checksum and does NOT literally appear in the data stream.

Important concepts are denoted by **NOTE:**

Product Specific Appendices

Although all RS-232 capable B&K Components' devices support the BKC-DIP protocol, implementation details vary according to product family. The examples used in this document are based on the CT 610 and REF 30 products. Make sure to consult the product specific appendices for the specific B&K Components' unit being controlled.

Supported RS-232 Settings

The currently supported baud rates are:

1200, 2400, 9600, 14400, 19200, 28800, 38400, 57600, and 115200

The currently supported serial settings are N-8-1:

N, no parity
8, eight bit data
1, one stop bit

Hardware flow control is not supported.

Basic Protocol Syntax

The B&K Components Device Interface Protocol (BKC-DIP) is an ASCII text based serial protocol. All commands follow the same basic format:

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

(id, cc, ss, ... ; cs16)

where:

(indicates the start of a message
id is the Receive ID (for host to B&K unit commands) or Transmit ID (for B&K unit to host commands)
, is the delimiter character
cc is the command
, is the delimiter character
ss is the command specifier
; is the checksum delimiter
cs16 is 16-bit (optional, but recommended) checksum
) indicates the end of a message

NOTE: Leading zeros may be omitted.

NOTE: Upper and lower case characters may be used interchangeably. (00,G,P01;01EB) is equivalent to (00,g,p1;1FB)

Begin/End Message Characters ()

The ASCII open/close parenthesis characters "(" and ")" not occurring in a double quoted string indicate the beginning and the end of a BKC-DIP message respectively.

NOTE: Each time an open parenthesis character not occurring in a double quoted string is received, the parsing engine's state is reset. In the event of the host and B&K Component's device loses sync, the "(" will abort any previous state and the communication will once again be in sync except under conditions detailed in **New Features of BKC-DIP V2.0 vs. V1.0**.

ID, Receive or Transmit

The first token of each BKC-DIP message is an ID, which can be 00h – 7Fh. This allows up to 128 different units to be controlled on the same serial bus.

NOTE: The receive ID FFh is also supported as a “global” or “universal” receive ID. Any B&K Components device on a serial channel would respond to commands with a receive ID of FFh regardless of their specified receive ID. This is useful for determining if any B&K Components devices are on a particular serial channel.

See section entitled **Use of Receive and Transmit IDs** for more details.

Delimiter Character ,

All members of a BKC-DIP message are delimited by "," an ASCII comma (with the exception of the checksum delimiter ";", see below).

NOTE: Unlike V1.0 BKC-DIP, commas are allowed in double quoted strings (such as text strings as in "Comma, IS valid"). Refer to **New Features of BKC-DIP V2.0 vs. V1.0** for details.

Checksum Delimiter ;

The checksum of each message is optionally transmitted embedded in the message to assure data has not been corrupted during transmission. The checksum is the 4 digits hexadecimal digits (0-F) directly following the ";" delimiter. Software designed to parse BKC-DIP serial streams can easily detect the ";" delimiter, thus making message parsing simple.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

NOTE: Unlike V1.0 BKC-DIP, semi-colons are allowed in double quoted strings (such as text strings as in "Semi-colon; valid"). Refer to **New Features of BKC-DIP V2.0 vs. V1.0** for details.

Identifier SubIdentifier Delimiter

On units where multiple hardware zones can be “linked” using “Code Sets” to logical zones, such as the CT 610, identifiers from the unit may have addition SubIdentifiers. These SubIdentifiers are delimited from the identifier via an ASCII period, “.”.

An example reply which contains SubIdentifier Delimiters (and subsequently SubIdentifiers) is:

(0, R, G, P7=FF, 1.A=20, 1.B=18, 1.D.L=10; *cs16*)

This response containing Volume information for the current preset of Zone 7, P7=FF, indicates that there are 3 different hardware zones attached to the logical zone 7.

NOTE: For an in depth discussion of Hardware Zones vs. Logical Zones, see section **Hardware Zones and Groups**.

Checksum

The checksum itself is a 16 bit quantity calculated by summing all of the incoming ASCII characters up to and including the ";" checksum delimiter **AND** excluding the begin message "(".

For example, the checksum for the following message would be calculated as:

(00, G, P00; 01EA)

(begin message character, ignored in checksum calculation, reset checksum
0	checksum = checksum + 30h
0	checksum = checksum + 30h
,	checksum = checksum + 2Ch
G	checksum = checksum + 47h
,	checksum = checksum + 2Ch
P	checksum = checksum + 50h
0	checksum = checksum + 30h
0	checksum = checksum + 30h
;	checksum = checksum + 3Bh and signals to terminate checksum calculation and that message checksum follows

Thus the calculated checksum would be 01EAh, which matches the message checksum indicating the received message is valid and uncorrupted.

NOTE: The checksum is optional but *strongly* recommended to assure the integrity of the transmitted data. If the checksum is not transmitted, the checksum delimiter is immediately followed by the end message ")".

For example:

(00, G, P00;) The checksum 01EA has been omitted

NOTE: Whitespace appearing outside of quotes is ignored, and does not enter into the checksum calculation.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

For example, the following two commands both yield the same checksum, 01DFh.

```
(00, G, P00; 01EA)
(00, G,      P00; 01EA)
```

However, the following two commands yield different checksums because of the whitespace in the second title:

```
(00, S, P1, 0="Title";04A6)
(00, S, P1, 0=" Title ";04E6)      white space characters before and after Title
```

Tag Delimiter :

It is often useful to be able to determine which response from the B&K Component's device corresponds to a particular command issued by the host. To facilitate this, an optional tag may be concatenated to the receive ID. This tag may be up to 8 alpha-numeric characters in length, and is then concatenated to the transmit ID of the message(s) generated by the unit.

A few examples to demonstrate the use of the tag:

```
(0:1234wxyz, G, P3=1, 0;053D)      Get Z3 Preset 1, parameter 0 with tag
                                   1234wxyz
(0:1234wxyz,E,G,P3=1,053D;065A)    Echo from unit with tag 1234wxyz
(0:1234wxyz,R,P3=1,0="His TV      ";0897)Reply from unit with tag 1234wxyz
```

NOTE: The use of tags is optional. If no tag delimiter is detected in the received command, no tag is appended in the response from the unit.

NOTE: Unlike V1.0 BKC-DIP, V2.0's tag is 8 characters long, as opposed to only 4. Refer to **New Features of BKC-DIP V2.0 vs. V1.0** for details.

NOTE: Messages generated autonomously by the unit (such as "U" update commands) do not have tags associated with them.

```
(0,U,I,I=24;0261)      Update IR command Z1 of 24 (Volume +), no tag
```

NOTE: Unlike V1.0 BKC-DIP, colons are allowed in double quoted strings (such as text strings as in "Colon : valid"). Refer to **New Features of BKC-DIP V2.0 vs. V1.0** for details.

New Features of BKC-DIP V2.0 vs. V1.0

Several new features have been added to the BKC-DIP protocol. For those familiar with BKC-DIP V1.0, this section concisely lists all the new features now available. For those just becoming acquainted with BKC-DIP, you may want to note which features are not available in the B&K Components devices with V1.0 BKC-DIP implementations.

NOTE: If using this document with a BKC-DIP V1.0 device, please remember that the following features do not apply. This will **NOT** be explicitly noted throughout the remainder of the documentation.

The changes from protocol V1.0 to V2.0 are listed below.

8 alpha-numeric character tags

The optional tag which can be appended to the receive ID with a colon, “:” has been increased to 8 alpha-numeric characters as opposed to 4.

Changes to the Parser Allowing “ , : ; () in Strings

Perhaps the most important change to BKC-DIP V2.0 from V1.0 is the augmented support for strings. In previous versions of BKC-DIP specific characters could only appear as protocol syntax and were not allowed in any other context, specifically strings.

In adding the new Serial Macro feature (see the **Macro specifier** section below), it was desirable to allow BKC-DIP commands to be emitted. This implied that entire BKC-DIP commands needed to be supported as a valid BKC-DIP string, which further implied that BKC-DIP delimiters (i.e. “ , : ; ()) NOT be interpreted inside double quoted strings.

This further implied the addition of the escape character “\”, backslash to allow double quotes and the escape character itself to be embedded into strings.

A Serial Macro Set command follows as an example:

```
(0, S, M0=0, 0=1, 1=C4, 4="(0:1234,S,P1=0,0="Title\");");
```

Notice the BKC-DIP command (0:1234,S,P1=0,0="Title"); as a string in the previous example.

Parser Synchronization

In V1.0 versions of BKC-DIP, any time the parser received an opening parenthesis, “(”, the parser state machine was reset. This implied that no matter what characters had previously be sent to the BKC-DIP device, sending a (would begin a new BKC-DIP command.

The same still holds true with one very important exception: double quoted strings (which are delimited by the ASCII character “, 34). The V2.0 BKC-DIP parser holds state regarding finding a double quote character. When the parser finds a double quote it will not interpret any character until it finds a matching unescaped double quote. This implies that the parser could get into a state that a open parenthesis would not reset, namely if the parser is in the midst of a quoted string. The following examples will illustrate.

Let’s assume that a user wanted to set Zone 1 Preset 0’s title to extremely clever and descriptive word “Title”. The user began typing the following:

```
(0, S, P1=0, 0="Pit
```

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

It is then realized that the user has misspelled. With a V1.0 BKC-DIP parser, simply retyping the command would correct the issue as the parser would be reset upon receiving the opening ““. However, that is not the case with the V2.0 parser, as the parser is currently in a state of accumulating characters for the string <“Pit> (the < and > characters added for clarity). The parser will not interpret the “(“ character as part of the BKC-DIP syntax, but merely more of the string <“Pit(>.

Additional Intelligence require in Host Parser

When developing a BKC-DIP V2.0 parser additional intelligence must be incorporated so BKC-DIP syntax is not interpreted when appearing in double quoted strings. The following is pseudo code for the state machine for such a parser:

```
BeginCommandState
  If the character = '('
    Reset state (i.e. checksum calculation)
    Next state = GetReceiveIDState

GetReceiveIDState
  Add the character to the checksum calculation
  If the character = ';' or ':'
    Indicates last character of ReceiveID
    If the character = ':'
      Next state = GetTagState
    Else
      Next state = FillCommandBufferState
  Else
    Add the character to the ReceiveID

GetTagState
  Add the character to the checksum calculation
  If the character = ';'
    Indicates last character of the tag
    Next state = FillCommandBufferState
  Else
    Add character to the tag

FillCommandBufferState
  Add the character to the checksum calculation
  If the character = ""
    Next state = QuotedStringState
    Add character to command buffer

  Convert the character to upper case

  If the character = ';'
    Indicates checksum possibly coming
    Next state = ChecksumState
  Else if the character = '('
    Next state = BeginCommandState

  Add character to command buffer

QuotedStringState
```

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Add the character to the checksum calculation
If the character = '\'
 Next state = CharacterEscapeState
Else if the character = '\"'
 Next state = FillCommandBufferState
Add character to command buffer

CharacterEscapeState
Add the character to the checksum calculation
Next state = QuotedStringState
Add character to command buffer

ChecksumState
If the character = ')'
 Indicates completion of checksum
 If checksum = calculated checksum or no checksum received
 Further command parsing
 Next state = BuildCommandState
Else
 Add character to the checksum

SubIdentifiers Indicating Hardware Zone information

SubIdentifiers have been added to augment parameter identifiers to identify to which Hardware Zone the values is associated. These take the form of “.A”, “.B”, “.C”, etc. for stereo Hardware Zones and “.D.L”, “.D.R”, “.E.L”, “.E.R”, “.F.L”, “.F.R”, etc. for mono Hardware Zones. Please refer to the **Hardware Zones and Groups** and **SubIdentifiers** sections later in this document for further details about Hardware Zones, Logical Zones, and SubIdentifiers.

Zone Specific specifier

Since new multi-zone devices have varying number of Logical Zones (based upon the System Settings for Zone IDs and Code Sets), the Zone Specific specifier, “Z”, has been added to Get and Set commands. Please refer to sections **Zone Specific Settings: (receiveID, G, Zzz, identifier, ... identifier; cs16)** and **Zone Specific Settings: (receiveID, S, Zzz, identifier = value, ... identifier = value; cs16)** for more details.

Macro specifier

An additional specifier, M (for Macro), has been added to the Get and Set commands to allow Serial Macro configuration. Please refer to sections **Macro Settings: (receiveID, G, Mt=mm, identifier, ... identifier; cs16)** and **Macro Settings: (receiveID, S, Mt, identifier = value, ... identifier = value; cs16)** for more details.

Macro Trigger Command

To allow BKC-DIP triggering of the new Macro features, the M command has been added to BKC-DIP. This allows a specific Macro (type and number) to be triggered via BKC-DIP. Please refer to **M (Macro Trigger) Command: (receiveID, M, t=mm, ... ,t=mm; cs16)** section for more details.

Favorite Settings of a Preset

To allow an easy mechanism to Get/Set the favorite of a particular presets across several Logical Zones in a single command, the Favorite Command added to BKC-DIP. Please refer to **Favorite**

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Settings of a Preset: (receiveID, G, A, *identifier*, ... *identifier*; *cs16*) and **Favorite Settings of a Preset:** (receiveID, S, A, *identifier=value*, ... *identifier=value*; *cs16*) for more details

Additional Reply Display formats

There are two new reply formats for Display Replies, in addition to a BKC-DIP V1.0 compatible format. See sections **BKC-DIP V1.0 Compliant Display Reply**, **BKC-DIP V2.0 Compliant Display Reply without Attributes**, and **BKC-DIP V2.0 Compliant Display Reply with Attributes** for more details.

Summary of BKC-DIP Commands

The following is a summary of the BKC-DIP commands and some brief examples. Each command is described in detail in the remainder of the document. The commands are broken in to two categories: Host to B&K Device Commands and B&K Device to Host Commands.

Host to B&K Device Commands Summary

G (get) command

Presets: (*receiveID*, G, Pz=*nn*, <*identifier*, ... *identifier*>; *cs16*)
(0,G,P1=3,1,2,3;*cs16*) Get Z1 Preset 3 parameters 1,2,3
(0,G,P2=7,4,5,6;*cs16*) Get Z2 Preset 7 parameters 4,5,6
System Settings: (*receiveID*, G, S, <*identifier*, ... *identifier*>; *cs16*)
(0,G,S,0,1,5;*cs16*) Get System parameters 0,1,5
Zone Adjustment (Hardware Special) Settings:
(*receiveID*, G, H, <*identifier*, ... *identifier*>; *cs16*)
(0,G,H,0,1,5;*cs16*) Get System parameters 0,1,5
Zone Specific Settings: (*receiveID*, G, Zzz, *identifier*, ... *identifier*, *cs16*)
(00, G, Z0;0204) Get Logical Zone 0's settings.
Macro Settings: (*receiveID*, G, Mt=*mm*, *identifier*, ... *identifier*; *cs16*)
(00, G, M0=20;0296) Get Serial Macro 32's settings
(0,G,M0;0187) Get All Serial Macros
Tuner Station Settings: (*receiveID*, G, Tnn, <*identifier*, ... *identifier*>; *cs16*)
(0,G,T12;*cs16*) Get Tuner channel 18 all parameters
Realtime Status: (*receiveID*, G, R, <*identifier*, ... *identifier*>; *cs16*)
(0,G,R,3;*cs16*) Get Realtime Status parameter 3
Override Settings: (*receiveID*, G, O, <*identifier*, ... *identifier*>; *cs16*)
(0,G,O,0;*cs16*) Get Override parameter 0
Display Content: (*receiveID*, G, D, *d*; *cs16*)
(0,G,D,O; *cs16*) Get current contents of the OSD
(0,G,D,F; *cs16*) Get current contents of the front panel display
Error Log Status: (*receiveID*, G, E, <*identifier*, ... *identifier*>; *cs16*)
(0,G,E,1;*cs16*) Get unused RAM Error Log status
Format Specification: (*receiveID*, G, Ff; *cs16*)
(0,G,F1=0;*cs16*) Get Z1 Preset Format
(0,G,F2=0;*cs16*) Get Z2 Preset Format
(0,G,F1;*cs16*) Get System Format
(0,G,F2;*cs16*) Get Tuner Format
(0,G,F3;*cs16*) Get Realtime Format
(0,G,F4;*cs16*) Get Unit Specifier
(0,G,F5;*cs16*) Get Override Format
(0,G,F6;*cs16*) Get Error Log Format
(0,G,F1=7;*cs16*) Get Z1 Zone Specific Format
(0,G,F0=8;*cs16*) Get Type 0 Macro Format
(0,G,F9;*cs16*) Get Zone Adjustment (Hardware Special) Format
Favorite Settings of a Preset: (*receiveID*, G, A, *identifier*, ... *identifier*; *cs16*)
(0,G,A=10;01E9) Get Favorite Settings of Preset 10h (16 decimal)

S (set) Command

Presets: (*receiveID*, S, Pz=*nn*, *identifier* = *value*, ... *identifier* = *value*; *cs16*)
(0,S,P1=B,0="My Title";*cs16*) Set Z1 Preset 11 parameter 0
(0,S,P2=4,1=60,2=18;*cs16*) Set Z2 Preset 4 parameters 1, 2
System Settings: (*receiveID*, S, S, *identifier*=*value*,...*identifier*=*value*; *cs16*)
(0,S,S,0="LASER",9=15;*cs16*) Set System parameters 0 and 9

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Zone Adjustment (Hardware Special) Settings:

(receiveID, S, H, identifier=value,...identifier=value; cs16)
(0,S,H,00=00,09=15;cs16) Set Zone Adjustment parameters 0 and 9

Zone Specific Settings: *(receiveID, S, Zzz, identifier = value, ... identifier = value; cs16)*
(1, S, Z7, 0="Living Room";cs16) Set Z7 Zone title

Macro Settings: *(receiveID, S, Mt, identifier = value, ... identifier = value; cs16)*
(0,S,M0=A,5="(0,S,S,0="Laser?";)") Set Serial Macro

Tuner Station Settings: *(receiveID, S, Tnn, identifier = value, ... identifier = value; cs16)*
(0,S,T04,1=20;cs16) Set Tuner Channel 4 parameter 1

Override Settings: *(receiveID, S, O, identifier = value, ... identifier = value; cs16)*
(0,S,O,0=1;cs16) Set Override parameter 0

IR Command: *(receiveID, S, I, z=ir; cs16)*
(0,S,I,2=C4;cs16) Set IR Zone 2 command C4

Front Panel Commands: *(receiveID, S, F, z=fp; cs16)*
(0,S,F,1=0A;cs16) Set Front Panel Zone 1 command A

Error Log Status: *(receiveID, G, E, <identifier = value,... identifier = value>;cs16)*
(0,S,E,1=0;cs16) Clear unused RAM Error log status

Favorite Settings of a Preset: *(receiveID, S, A, identifier=value, ... identifier=value; cs16)*
(0,S,A=10,0=1,3=1,4=0; 0459) Set Preset 16 favorite in Z0 and Z3, not Z4

D (display) Command

OSD (O): *(receiveID, D, O, Ttt, Mm, Xcc, Yrr, "text", ... Xrr, Ycc, "text"; cs16)*
(0,D,O,T64, M0, X02, Y04, "Hello World";cs16)

T64 will clear the display after 64h * 100ms (10seconds)

M0 text displayed over background color "blue screen"

X02 displayed text will start at row 02h (the third row)

Y04 displayed text will start at column 04h (the fifth column)

Front Panel Display (F): *(receiveID, D, F, Ttt, Xcc, Yrr, "text";cs16)*
(0,d, f, t0, x0, y2, "Testing";cs16)

t0 display will NOT be clear by a timeout

x0 displayed text will start at row 00h (the first row)

y2 displayed text will start at column 02h (the third column)

LED display: *(receiveID, D, L, Ttt, n=bitmap; cs16)*
(00, D, L, T00, 1=21; 0360) Set DOWN and REAR LEVEL LED on

X (executive) Command

NOTE: Please refer to the Appendix L of the appropriate Product Specific Appendices to note implimentation details and of the executive commands.

Recall Preset Command: *(receiveID, X, 0, z=nn; cs16)*
(0,X,0,1=4;cs16) Recall Z1 Preset 4 to current preset

Save Preset Command: *(receiveID, X, 1, z=nn; cs16)*
(0,X,1,2=9;cs16) Save current preset to Zone 2 Preset 9

Power State Command: *(receiveID, X, 2, z=onOff; cs16)*
(0,X,2,1=1;cs16) Turn Z1 power on
(0,X,2,2=0;cs16) Turn Z2 power off

Noise Generator State Command: *(receiveID, X, 3, onOff; cs16)*
(0,X,3,1;cs16) Activate noise generator
(0,X,3,0;cs16) Deactivate noise generator

Noise Steering Command: *(receiveID, X, 4, index=onOff..., index=onOff; cs16)*
(0,X,4,0=1,1=1,5=1;cs16) Noise output Left Front, Center, and Sub

Noise Increment Command: *(receiveID, X, 5; cs16)*
(0,X,5;cs16) Increment noise output to next valid channel

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Cold Boot Command: (*receiveID*, X, 6; *cs16*)
 (0,X,6;*cs16*) Cold Boot BKC-DIP device

Factory Reset Command: (*receiveID*, X, 7; *cs16*)
 (0,X,7;*cs16*) Factory Reset BKC-DIP device

WARNING!: Issuing a Factory Reset Command will destroy all user modified data in the unit (preset, system settings, etc.).

Reinitialize BKC-DIP State Command: (*receiveID*, X, 8; *cs16*)
 (0,X,8;*cs16*) Reinitialize BKC-DIP State parameters

Test Tone State Command: (*receiveID*, X, 9, *level*; *cs16*)
 (0,X,9,2;*cs16*) Test Tone on at -30.0 dB level
 (0,X,9,0;*cs16*) Test Tone off

Mute State Command: (*receiveID*, X, A, *z=muteState*; *cs16*)
 (0,X,A,1=1;*cs16*) Mute Z1
 (0,X,A,2=0;*cs16*) Unmute Z2

B&K Device to Host Commands Summary

E (echo) Command

(2, E, G, P1=00, 0228;0393) Echo from unit 02h for Get Z1 Preset 0 command

R (reply) Command

(2, R, P2=1,3=5;02D8) Reply from unit 02h Z2 Preset 1 parameter 3 info
 (0, R, D, F, 0="X FRONT PANEL XX" , 80=1;*cs16*)
 Reply from the Get Display command (*transmitID*, G, D, *d*; *cs16*)

U (update) Command

Status message: (*transmitID*, U, S, 0="BKC-DIP ACTIVE";*cs16*)
 (0,U,S,0="BKC-DIP ACTIVE";*cs16*) Ready for BKC-DIP commands

IR message: (*transmitID*, U, I, *z=ir*; *cs16*)
 (0,U,I,1=C4;*cs16*) Update to host from Zone 1 <Volume ->

Front Panel message: (*transmitID*, U, F, *z=ir*; *cs16*)
 (0,U,F,1=A;*cs16*) Update to host from Zone 1 front panel <Volume ->

Realtime Status message: (*transmitID*, U, R, *identifier=value*; *cs16*)
 (0,U,R,5=*sample rate*; *cs16*) Update from sample rate change

Hardware Zones and Groups

In recent B&K Components' devices, such as the CT 610, there is the concept of Hardware Zones, Groups, and Logical Zones. This has implications with regards to BKC-DIP. In order to understand these parts of BKC-DIP, an understanding of Hardware and Software zones is required. This section describes the concepts of Hardware Zones, assignment of Groups to link command and control of Hardware Zones to form Logical Zones, and SubIdentifiers (which is how BKC-DIP presents Hardware Zone information).

NOTE: References to the B&K Components CT 610 will be used as examples since it is the first B&K product to contain these features. Again, recall that BKC-DIP V1.0 is a subset of V2.0x features. Thus this section has no meaning in BKC-DIP V1.0 products.

Hardware Zones

As the name implies, Hardware zones relate to hardware. Thus a Hardware zone can be thought of as the output jacks of the Device. On the CT 610, for example, there are 6 (stereo) output zones lettered A – F. In some instances a stereo zone can be “split” into 2 mono zones which are further subspecified by “.L” or “.R” referring to the left or the right half respectively.

NOTE: Hardware Zones are referred to by uppercase letter. For example, in the CT 610, the 6 stereo zone outputs are referred to as A, B, C, D, E, and F respectively. As another example, if all 6 zones of a CT 610 were configured to be mono zones, they would be referred to as A.L, A.R, B.L, B.R, C.L, C.R, D.L, D.R, E.L, E.R, F.L, and F.R respectively.

Groups

As the name implies, Groups relate to how Hardware Zones are to be linked and controlled. In the CT 610 and CT 310, we introduce the concept of Groups. Group is simply a method used to link command and control of one Hardware Zone, or many Hardware Zones, using a single Code Set/Zone ID. Currently, the CT 610 and CT 310, supports 18 groups. Groups are referred to by lowercase letters a – r. There also exists a Whole House Group that is always set for use with Code Set/Zone ID 0. A valid Code Set/Zone ID must be set for each Group that is to be used in the CT 610 and CT 310. Setting any CT 610 or CT 310 Group to use Code Set/Zone ID 0 (Off), effectively disables the Group for use as a Logical Zone (see Logical Zone below).

NOTE: Groups are referred to by lowercase letter. For example, there are 9 default Groups in the CT 610:

Group	Code Set	Title
0	0	Whole House
a	3	Downstairs
b	4	Upstairs
c	11	Living Room
d	12	Dining Room
e	13	Kitchen
f	14	Patio
g	15	Master Bdrm
h	16	Master Bath
i	off	
j	off	

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

k	off	
l	off	
m	off	
n	off	
o	off	
p	off	
q	off	
r	off	

Code Sets, Zone IDs, and Logical Zones

NOTE: The terms Code Set, Zone ID, and Logical Zone are synonymous.

The terms Code Set, Zone ID, and Logical Zones are synonymous, however various contexts typically use a specific terminology.

NOTE: Code Sets, Zone IDs, and Logical Zones are referred to by number. For example, there are 9 default Code Sets / Zone IDs / Logical Zones configured in a CT 610. The default Code Sets are as follows: 0, 3, 4, 11, 12, 13, 14, 15, and 16.

Code Sets

As in earlier B&K Components devices there are system parameters to allow command and control of individual Zones (ZA and ZB, previously Z1 and Z2). The term Code Set is primarily used in conjunction with command and control of a device via RS-232, Infra Red remotes and keypads. A Code Set is essentially a product ID associated with an IR remote or keypad. A single Code Set may be assigned to control a single Hardware Zone Group or a Grouping of Zones (see Groups above). This implies that multiple remotes and keypads may uniquely control the same Hardware Zone.

NOTE: Code Sets are referred to by number. For example, there are 9 default Code Sets in the CT 610:

One Whole House Code Set: 0

Two Code Sets assigned to control multiple Hardware Zones: 3 and 4

Six Code Sets assigned to control individual Hardware Zones: 11, 12, 13, 14, 15, and 16

Zone IDs

The term Zone ID is used basically in the same context as a Code Set. However, Zone ID is not commonly associated with Infra Red remotes and keypads, but thought of as purely a mechanism to assign Logical Zones to Hardware Zones.

The importance of the term Zone ID has lessened, and it is typically referred to as a Code Set.

Recall, a single Code Set may be assigned to control a single Hardware Zone or a Grouping of Zones. This implies that multiple remotes may uniquely control the same Hardware Zone.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

NOTE: Zone IDs (Code Sets) are referred to by number. For example, there are 9 default Zone IDs (Code Sets) in the CT 610:

One Whole House Code Set: 0
Two Code Sets assigned to control multiple Hardware Zones: 3 and 4
Six Code Sets assigned to control individual Hardware Zones: 11, 12, 13, 14, 15, and 16

Logical Zones

Logical Zones are the result of associating Code Sets/Zone IDs to a Group for the control of Hardware Zones. Whereas Hardware Zones **are** physical outputs of the device, a Logical Zone is a higher-level concept, which may encompass multiple Hardware Zones.

Logical Zones are created by Grouping Hardware Zones and assigning a unique Code Set/Zone ID to this Group. Up to 18 Groups, a – r, are available in the CT 610 and CT 310. It is the careful setup of the CT 610's Hardware Zones A-F, linking of Hardware Zones as Groups, and assignments of Code Sets/Zone Ids that allow Logical Zones to be a very simple and powerful multi-zone command and control concept. See **Groups and Linking Hardware Zone Control** below for more details.

NOTE: Logical Zones are referred to by number, and typically prepended with the letter “Z” for Zone. For example, there are 9 default Logical Zones in the CT 610:
Z0, Z3, Z4, Z11, Z12, Z13, Z14, Z15, and Z16

NOTE: Logical Zones are given titles and may be referred to by name. For example, there are 9 default Logical Zones in the CT 610 whose names are as follows:

Group 0	Z0	Whole House	Hardware Zones A, B, C, D, E, F
Group a	Z3	Downstairs	Hardware Zones A, B, C, D
Group b	Z4	Upstairs	Hardware Zones E, F
Group c	Z11	Living Room	Hardware Zones A
Group d	Z12	Dining Room	Hardware Zones B
Group e	Z13	Kitchen	Hardware Zones C
Group f	Z14	Patio	Hardware Zones D
Group g	Z15	Master Bdrm	Hardware Zones E
Group h	Z16	Master Bath	Hardware Zones F
Group i	Off		
Group j	Off		
Group k	Off		
Group l	Off		
Group m	Off		
Group n	Off		
Group o	Off		
Group p	Off		
Group q	Off		
Group r	Off		

Groups and Linking Hardware Zone Control

B&K Components Device Interface Protocol (BKC-DIP) Specification
Version 2.01.00
Updated 01/24/07

In earlier B&K Components device (Series II products specifically), there were system parameters to allow Z1 and Z2 power and/or volume controls to be linked.

With the development of the CT 610 (a 6 stereo zone unit, or up to a 12 mono zone unit), the concept of linking became even more important. In BKC-DIP V2.0x products, such as the CT 610 and CT 310, Logical Zones may be used to link command and control of multiple Hardware Zones.

Groups allow a means for multiple Hardware Zones to track each other (i.e. if the in volume in one zone changes, the volume in another zone changes too).

Hardware Zones, A – F, may be linked in up to 18 Groups, a - r. These Groups and their Code Set/Zone ID assignments determine how many Logical Zones are configured in a system.

NOTE: A Logical Zone is created by assigning a Group a unique Code Set/Zone ID for use in the control of Hardware Zones. For example, the CT 610's factory default setting has 9 logical zones: Z0, Z3, Z4, Z11, Z12, Z13, Z14, Z15, Z16.

An abstract concept such as this requires a concrete example for clarification. The following example is based upon the factory default Group and Code Set/Zone ID assignments of the Hardware Zones in the CT 610.

Default CT 610 Example

Using Groups each Hardware Zone of a CT 610 is capable of working with multiple Code Sets/Zone IDs.

The factory default for each Hardware Zone of the CT 610 is stereo mode. The Group and Code Set/Zone ID assignments are as follow:

Hardware Zone	Group Code Set (Zone ID)	Group Code Set (Zone ID)	Whole House Code Set (Zone ID)
A	3 (group a)	11 (group c)	0 (group 0)
B	3 (group a)	12 (group d)	0 (group 0)
C	3 (group a)	13 (group e)	0 (group 0)
D	3 (group a)	14 (group f)	0 (group 0)
E	4 (group b)	15 (group g)	0 (group 0)
F	4 (group b)	16 (group h)	0 (group 0)

Given the above Group and Code Set/Zone ID configuration yields the following 9 Logical Zones and their associated Hardware Zone members:

Logical Zone	Hardware Zone members
Z0	A, B, C, D, E, and F
Z3	A, B, C, D
Z4	E and F
Z11	A
Z12	B

Z13	C
Z14	D
Z15	E
Z16	F

Viewing the previous Group and Code Set/Zone ID assignments there are 9 Logical Zones: Zone 0 (Whole House), Zone 3, Zone 4 and Zones 11 through Zone 16. Also, note that there is always an implicit “Whole House” Zone, numbered Zone 0, which combines all Hardware Zones into a single Logical Zone.

Note, Logical Zone 11 controls Hardware Zone A, however, Hardware Zone A is also part of Logical Zone 3, and Logical Zone 0.

When referring to Logical Zone 3 in this example, Hardware Zones A, B, C and D are Grouped (linked) together by a common Code Set. Thus with the above settings, changing the volume in Logical Zone 3 will change the volume in Hardware Zones (A-D). However, changing the volume in Logical Zone 13, for example, will only change the volume on Hardware Zone C.

When referring to Logical Zone 4 in this example, Hardware Zones E and F are Grouped (linked) together via a common Code Set of 4. Thus with the above settings, changing the volume in Logical Zone 4 will change the volume in Hardware Zones (E and F). However, changing the volume in Logical Zone 15, for example, will only change the volume on Hardware Zone E.

Changing the volume in Logical Zone 0 changes the volume in all Hardware Zones regardless of Code Set/Zone ID setup.

More Complicated CT 610 Example

Let’s take another example with a more complicated Code Set/Zone ID configuration to further clarify some points regarding Logical Zones:

Hardware Zone	Group Code Set (Zone ID)
A.L	0 (group 0), 17 (group a), 1 (group d)
A.R	0 (group 0), 16 (group b), 12 (group h)
B	0 (group 0), 16 (group b), 3 (group e), 27 (group i)
C	0 (group 0), 16 (group b), 3 (group e), 27 (group i)
D.L	0 (group 0), 16 (group b), 4 (group f), 27 (group i)
D.R	0 (group 0), 16 (group b), 27 (group i), 35 (group g)
E	0 (group 0), 22 (group c), 35 (group g)
F	0 (group 0), 22 (group c), 35 (group g)

Given the above Group and Code Set/Zone ID configuration yields the following Logical Zones and their associated Hardware Zone members:

Logical Zone	Hardware Zone members
Z0	A.L, A.R, B, C, D.L, D.R, E, and F
Z1	A.L
Z3	B and C
Z4	D.L

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Z12	A.R
Z16	B, C, and D
Z17	A.L and A.R
Z22	E and F
Z27	B, C, D.L, and D.R
Z35	D.R, E, and F

There are several important concepts to note that are illustrated in the above Logical Zones.

1. Logical Zones need not be consecutive. Notice there are no Logical Zones 2, 5-11, 13-15, 18-21, 23-26, 28-34, or 36-128. Logical Zones are with created with Groups set to use a valid Code Sets/Zone ID with any value ranging from 0 (off), 1 to 128.
2. Logical Zones may be created and used to control a single Hardware Zone or Groups of Hardware Zones.
3. When a Hardware Zone is configured in Mono mode, its left and right halves may be assigned to various Groups. Such is the case of A.L in Z1, D.L in Z4, A.R in Z12, and in D.R Zone 35.
4. Logical Zone 0, Group 0 always encompasses all Hardware Zones.
5. Notice that Groups j – r are unused (Code Sets set to off).

NOTE: There is no real significance to the choice of Group letter (i.e. Group a has no more significance that Group r).

SubIdentifiers

Even though BKC-DIP refers only to Logical Zones, it is necessary to obtain information relating to Hardware Zones. SubIdentifiers are part of BKC-DIP V2.xx syntax that indicates Hardware Zone settings.

Again, this is best illustrated by example. Let’s again use the default CT 610 Code Set/Zone ID settings which are as follow:

Hardware Zone	Group Code Set (Zone ID)	Group Code Set (Zone ID)	Whole House Code Set (Zone ID)
A	3 (group a)	11 (group c)	0 (group 0)
B	3 (group a)	12 (group d)	0 (group 0)
C	3 (group a)	13 (group e)	0 (group 0)
D	3 (group a)	14 (group f)	0 (group 0)
E	4 (group b)	15 (group g)	0 (group 0)
F	4 (group b)	16 (group h)	0 (group 0)

Logical Zone	Hardware Zone members
Z0	A, B, C, D, E, and F
Z3	A, B, C, and D
Z4	E and F
Z11	A
Z12	B
Z13	C
Z14	D
Z15	E
Z16	F

Now let’s assume the following 6 BKC-DIP Set commands were issued:

B&K Components Device Interface Protocol (BKC-DIP) Specification
Version 2.01.00
Updated 01/24/07

(0,S,PB=FF,1=04;)	Set Zone 11 current preset's volume to -72 dB
(0,S,PC=FF,1=08;)	Set Zone 12 current preset's volume to -64 dB
(0,S,PD=FF,1=0C;)	Set Zone 13 current preset's volume to -56 dB
(0,S,PE=FF,1=10;)	Set Zone 14 current preset's volume to -48 dB
(0,S,PF=FF,1=14;)	Set Zone 15 current preset's volume to -40 dB
(0,S,P10=FF,1=18;)	Set Zone 16 current preset's volume to -32 dB

NOTE: Remember that the Zone is specified in hexadecimal, thus 11 = Bh, 12 = Ch, 13 = Dh, 14 = Eh, 15 = Fh, and 16 = 10h.

NOTE: If you are new to BKC-DIP, you can learn more about Set commands in the **S (set) Command** section. For now simply accept that the above commands do what their comments indicate.

The 6 Hardware Zones now have a different value. The issue now becomes what would be returned for a Get command sent to Logical Zone 0. Since Logical Zone 0 encompasses all six Hardware Zones, BKC-DIP must essentially return 6 different answers (one for each Hardware Zone). Thus:

(0,G,P0=FF,1;) Get Zone 0 current preset's volume

Would result in a response of

(0,R,G,P0=FF,1.A=4,1.B=8,1.C=C,1.D=10,1.E=14,1.F=18; cs16)

Notice how the use of SubIdentifiers distinguishes the values of the volume. In Logical Zone 0, there is a single parameter called volume (identifier "1"), but in this configuration, volume has 6 different values which are indicated by the use of SubIdentifiers in conjunction with the identifier "1". Dissecting the above response yields:

1.A=4	Hardware Zone A's volume is -72 dB
1.B=8	Hardware Zone B's volume is -64 dB
1.C=C	Hardware Zone C's volume is -56 dB
1.D=10	Hardware Zone D's volume is -48 dB
1.E=14	Hardware Zone E's volume is -40 dB
1.F=18	Hardware Zone F's volume is -32 dB

Thus the concept of SubIdentifiers further qualifies the identifier, and describes to which Hardware Zone the value is related.

Again referring to our more complicated example with the following settings:

Hardware Zone	Group Zone ID	Left (Mono) Group Code Set (Zone ID)	Right (Mono) Group Code Set (Zone ID)	Whole House Zone ID
A	17	1	12	0
B	16	3	N/A	0
C	16	3	N/A	0
D	16	4	35	0
E	22	35	N/A	0
F	22	35	N/A	0

Logical Zone	Hardware Zone members
Z0	A.L, A.R, B, C, D.L, D.R, E, and F
Z1	A.L
Z3	B and C
Z4	D.L
Z12	A.R
Z16	B, C, and D
Z17	A.L and A.R
Z22	E and F
Z35	D.R E, and F

Assume the following Set commands were previously issued:

(0,S,P10=FF,1=18;) Set Zone 16 (10h) current preset's volume to -32 dB
(0,S,P16=FF,1=1A;) Set Zone 22 (16h) current preset's volume to -28 dB

The following Get command would yield:

(0,G,P23=FF,1;) Request Zone 35's (23h) volume
(0,R,G,P23=FF,1.D.R=18,1.E=1A,1.F=1A;cs16)

Where

1.D.R=18 Hardware Zone D Right is -32 dB (mono mode)
1.E Hardware Zone E is -28 dB (stereo mode)
1.F Hardware Zone F is -28 dB (stereo mode)

Host to B&K Device Commands

There are five basic commands that the host can transmit to a B&K Components' device: G, S, D, M, and X. Each of these, and their format specifiers, are explained in detail below.

G (get) Command

The "G" command is issued by the host to the BKC-DIP device to get information about the current state of the unit. The BKC-DIP device will respond with an "R" (reply) command granting the host its desired information (refer to the **R (reply) Command** section for more about "R" responses).

There are different types of information the host may inquire about: Presets Settings, System Settings, Tuner Stations, Zone Specific Settings, Macro Settings, Favorite Settings, Realtime Status, Display Content, Override Settings, Format Specifications, and Error Log Status. Each of these is described in detail below.

Presets: (receiveID, G, Pz=nn, identifier, ... identifier, cs16)

Preset information is parameters, which the user can modify on a per preset basis, such as volume, source, preset title, etc. This information may be "gotten" to archive user presets, or to monitor the current preset settings (see Pz=FF below).

The preset number, *nn*, can take on the values 00h to FDh, and FFh. Presets Pz=00 – Pz=FDh are user presets. Which Logical Zone's preset is specified by *z*.

NOTE: Pz=FE is reserved for future expansion.

NOTE: Pz=FF is a special preset. It is the CURRENT PRESET of the unit, which indicates the CURRENT STATE of the unit.

NOTE: When a user recalls a preset, the recalled preset is copied into the current preset. Subsequent changes are to this current preset. It is not until the current preset is saved that these changes are written to a user preset location.

For example:

A user recalls preset 01, which has a V1 volume of –20 dB. The user then increases the volume to –15 dB. The current preset would reflect that the V1 volume is –15 dB, while preset 01 is still –20 dB.

NOTE: The identifier is a unique hex number assigned to each specific parameter. A complete list of the preset parameter identifiers for applicable zones are found in the product specific **Appendix A**.

NOTE: If no identifiers are specified, the entire preset is returned to the host device.

For example:

(00, G, P1=00; 0258)	returns all data in B&K User Z1 preset 0
(00, G, P2=12; 025C)	returns all data in B&K User Z2 preset 18

See the **Presets: (receiveID, S, Pz=nn, identifier = value, ... identifier = value; cs16)** section for more details.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

System Settings: (*receiveID, G, S, identifier, ... identifier; cs16*)

System settings are parameters which the user may modify, but they are global, or affect the entire system. Example of these includes power on strings, source input level settings, source names, etc. Querying system settings is useful for archival purposes.

NOTE: A complete list of the system identifiers is found in product specific **Appendix B**.

NOTE: If no identifiers are specified, all of the system settings are returned to the host device.

For example:

(00, G, S; 018D) returns all of the B&K unit's system settings

See the **System Settings: (*receiveID, S, S, identifier=value,...identifier=value; cs16*)** section for more details.

Zone Adjustment (Hardware Special) Settings: (*receiveID, G, H, identifier, ... identifier; cs16*)

Zone Adjustment (Hardware Special) settings are Zone A to Zone F adjustment parameters which the user may modify, but they are global, or affect the entire system. Example of these includes Bass/Treble Gain and Frequency, and Notch Filters. Querying system settings is useful for archival purposes.

NOTE: A complete list of the system identifiers is found in product specific **Appendix R**.

NOTE: If no identifiers are specified, all of the system settings are returned to the host device.

For example:

(00, G, H;) returns all of the B&K unit's zone adjustment (hardware special) settings

See the **Zone Adjustment (Hardware Special) Settings: (*receiveID, S, H, identifier=value,...identifier=value; cs16*)** section for more details.

Zone Specific Settings: (*receiveID, G, Zzz, identifier, ... identifier;cs16*)

The zone number, *zz*, can take on the values 00h to 80h (Zone 0 to Zone 128). If a particular Logical Zone does not exist in the current device, the command will be ignored and no echo will be generated.

NOTE: A complete list of zone specific identifiers is found in the product specific **Appendix N**.

NOTE: If no identifiers are specified, all of the Zone Specific information is returned to the host device.

For example:

(00, G, Z0;0204) returns Logical Zone 0's settings.

See the **Zone Specific Settings: (*receiveID, S, Zzz, identifier = value, ... identifier = value; cs16*)** section for more details.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Macro Settings: (*receiveID*, *G*, *Mt=mm*, *identifier*, ... *identifier*, *cs16*)

The macro number, *mm*, can take on the values 00h to FFh (0 to 255) depending on the amount of memory used by each macro. The macro type, *t*, specifies which of the various kinds of macros are being referenced.

NOTE: A complete list of macro identifiers and supported macro types is found in the product specific **Appendix O**.

NOTE: If no identifiers are specified, all of the macro information for that particular macro type is returned to the host device.

For example:

(00, G, M0=20;0296) returns Serial Macro 32's settings.

See the **Macro Settings: (receiveID, S, Mt, identifier = value, ... identifier = value; cs16)** section for more details.

All Macro Settings: (*receiveID*, *G*, *Mt*, *identifier*, ... *identifier*; *cs16*)

A special form of the Get Macro Settings command deserves discussion. If *=mm* is omitted, information for all macros of that type are returned. This is in the form of **multiple** replies generated from the single Get.

Given that the device contains 3 macros: 0, 1, 6, and 9 with the messages "added last", "multiple", "macros", and "fired" respectively using the following set commands:

```
(0,S,M0=1,5="multiple ";066F)
(0,S,M0=6,5="macros ";058D)
(0,S,M0=9,5="fired ";0515)
(0,S,M0=0,5="added last";06A8)
```

Issuing a Get serial macro (type 0) command without specifying a specific macro number results in the follow:

```
(0,G,M0;0187) Request of all Serial Macros
(0,E,G,M0,0187;02F4) Echo response
Multiple replys for each macro in the device
(0,R,M0=1,0=0,1=0,2=0,3=2,4=3F,5="multiple ",6=0,7=10,8=1F,9=C4;0EB1)
(0,R,M0=6,0=0,1=0,2=0,3=2,4=3F,5="macros ",6=0,7=E,8=1F,9=C4;0DB3)
(0,R,M0=9,0=0,1=0,2=0,3=2,4=3F,5="fired ",6=0,7=D,8=1F,9=C4;0D3A)
(0,R,M0=0,0=0,1=0,2=0,3=2,4=3F,5="added last",6=0,7=11,8=1F,9=C4;0EEB)
```

NOTE: The order of the replies is **NOT** ordered by ascending macro number, but instead by the order in which the macros were added.

NOTE: Since macros can be sparsely populated (i.e. need not be sequentially numbered 00h – FEh, and undefined macros do not exist), use of this form of the Get Macro command indicates which macros are defined in the device.

Tuner Station Settings: (*receiveID*, *G*, *Tnn*, *identifier*, ... *identifier*, *cs16*)

The tuner station number, *nn*, can take on the values 00h to 13h (stations 1 to 20 respectively).

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

NOTE: A complete list of station identifiers is found in the product specific **Appendix C**.

NOTE: If no identifiers are specified, all of the tuner station information is returned to the host device.

For example:

(00, G, T01;01BF) returns Station 2 AM frequency, FM frequency, and FM Stereo

See the **Tuner Station Settings: (receiveID, S, Tnn, identifier = value, ... identifier = value; cs16)** section for more details.

NOTE: In later B&K Component devices, the concept of Tuner Stations was discontinued. These newer devices do not respond to the Tuner Station specifier. The product specific **Appendix C** will indicate whether Tuner Stations are supported or not.

Realtime Status: (*receiveID, G, R, identifier, ... identifier, cs16*)

Realtime status contains current system information such as Audio Input Presence, Audio Output Presence, current sample rate, etc.

NOTE: A complete list of Realtime Status information identifiers is found in the product specific **Appendix D**. If Realtime Status messages are not supported by the particular product, it will also be indicated in that appendix.

NOTE: If no identifiers are specified, all of the realtime status information is returned to the host device.

KEY NOTE!: Realtime status may be "polled" using the (*receiveID, G,R, ...*) command, **however** the true power of the Realtime status is its ability to generate "interrupts" to the host unit when the unit senses a Realtime change.

For example, a host program that is to monitor OSD updates (so a "virtual OSD" can be updated to reflect what the B&K device is displaying) could be written in one of two ways:

- 1) Poll the unit continuously at some interval using the (*receiveID, G, R, A; cs16*) command comparing the returned value to the previous value to detect a change in status.
- 2) Enable the OSD Display Update using (*receiveID, S, S, 5A=04; cs16*). The unit will automatically generate a (*transmitID, U,R,A=1;cs16*) message only when the OSD has been updated.

Method 2 does not burden the host with determining if the value changed, does not require the host to spend time polling, and reduces RS232 bandwidth usage as messages are generated only on demand.

See the System Parameter for Realtime Enable and **Realtime Status message: (transmitID, U, R, identifier=value;cs16)** sections for more details on their usage.

NOTE: Realtime status registers can be read using the (*receiveID, G,R, ...; cs16*) command regardless of settings in the Realtime Enable registers.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Override Settings: (*receiveID*, G, O, *identifier*, ... *identifier*,*cs16*)

There are particular parameters (which primarily have to do with RS-232 and BKC-DIP settings) which can be “overridden”, forcing specific values regardless of the corresponding System setting parameters.

NOTE: A complete list of Override identifiers is found in **Appendix P** of the appropriate BKC-DIP Product Specific Appendices.

NOTE: If no identifiers are specified, all of the Override Setting information is returned to the host device.

For example:

(00, G, O;0189) returns all Override settings for receive ID 0 units

See the **Override Settings: (receiveID, S, O, *identifier=value*,...*identifier=value*; *cs16*)** section for more details on identifiers.

Display Content: (*receiveID*, G, D, *d*,*cs16*)

This command is used to obtain the ASCII text currently displayed by the unit.

The display device specifier, *d*, can currently take on the value of F for the front panel display or O for the On screen display (assuming the B & K Components' device under control supports a front panel display and/or an On screen display).

For example:

(00, G, D, O; *cs16*) requests the current contents of the OSD of units with Receive IDs of 00h

(01, G, D, F; *cs16*) requests the current contents of the front panel display of units with Receive IDs of 01h

NOTE: See the **Reply from the Get Display command (transmitID, G, D, *d*; *cs16*)** section for more details on the format of the returned data

Format Specification: (*receiveID*, G, *Ff*; *cs16*)

BKC-DIP is designed to be generic so that as B&K Components devices' features expand, backwards compatibility can be maintained. For this reason, the internal data structures and features can be queried to determine which particular B&K Component unit is currently connected. The currently supported format specifiers, *Ff* are:

Preset Format: (00, G, *Fz=0*; 01B0) request a comma delimited list of available PRESET parameter identifiers and their maximum values of units with Receive IDs of 00h for zone *z*. See the product specific **Appendix A** for a detailed listing.

System Format: (00, G, *F1*; 01B1) requests a comma delimited list of available SYSTEM parameter identifiers and their maximum values of units with Receive IDs of 00h. See the product specific **Appendix B** for a detailed listing.

Tuner Format: (00, G, *F2*; 01B2) requests a comma delimited list of available TUNER STATION parameter identifiers and their maximum values of units with Receive IDs 00h. See the

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

product specific **Appendix C** for a detailed listing.

NOTE: B&K Units after Series I (AVR 202, Ref 20, PT 3, etc.) do not support Tuner channels. If a F2 format request is made of these newer units, they will simply ignore the request.

RealtimeFormat: (00, G, F3; 01B3)	requests a comma delimited list of available REALTIME STATUS information identifiers and their maximum values of units with Receive IDs of 00h. See the product specific Appendix D for a detailed listing.
Unit Specifier: (00, G, F4; 01B4)	requests a comma delimited list of unit features and ASCII strings describing the device (name, version) of units with Receive IDs of 00h. See the product specific Appendix E for a detailed listing.
Override Format: (00, G, F5; 01B5)	requests a comma delimited list of available OVERRIDE parameter identifiers and their maximum values of units with Receive IDs 00h. See the product specific Appendix P for a detailed listing.
Error Format: (00, G, F6; 01B6)	requests a comma delimited list of available ERROR LOG parameter identifiers and their maximum values of units with Receive IDs 00h. See the product specific Appendix M for a detailed listing.
Zone Specific Format: (00, G, Fz=7;cs16)	request a comma delimited list of available ZONE SPECIFIC parameter identifiers and their maximum values of units with Receive IDs of 00h for zone <i>z</i> . See the product specific Appendix N for a detailed listing.
Macro Format: (00, G, Ft=8;cs16)	request a comma delimited list of available MACRO parameter identifiers and their maximum values of units with Receive IDs of 00h for Macro type <i>t</i> . See the product specific Appendix O for a detailed listing.
Zone Adjustment Format: (00, G, F9;cs16)	requests a comma delimited list of available ZONE ADJUSTMENT (HARDWARE SPECIAL) parameter identifiers and their maximum values of units with Receive IDs of 00h. See the product specific Appendix R for a detailed listing.

Several examples follow for clarification:

(00, G, F4; 01B4)	get unit format of units with Receive ID of 00h
(00, E, G, F4, 01B4; 02F8)	echo get command back to host from unit with a Transmit ID of 0Fh

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

(0, R, F4,0= "AVR 202", 1="V2.02" ...; *cs16*) reply containing unit (Transmit ID 00h) info

(00, G, F1=0;)	get available Z1 preset parameters and max values
(00, G, F2=0;)	get available Z2 preset parameters and max values
(00, G, F1;)	get available system parameters and max values
(00, G, F2;)	get available tuner station parameters and max values
(00, G, F3;)	get available realtime status info and max values
(00, G, F4;)	get available unit format info
(00, G, F5;)	get available override parameters and max values
(00, G, F6;)	get available error log parameters and max values
(00, G, F1=7;)	get available Z1 zone specific parameters and max values
(00, G, F2=7;)	get available Z2 zone specific parameters and max values
(00, G, F0=8;)	get available Macro Type 0 parameters and max values
(00, G, F1=8;)	get available Macro Type 1 parameters and max values
(00, G, F9;)	get available zone adjustment (Hardware Special) and max values

NOTE: Do not confused F1=0, F2=0, F1=7, F2=7, or F1=8 with F1 and F2. They look somewhat similar but have very different meanings. F1=0 and F2=0 access available **Preset** parameters for Z1 and Z2 respectively. F1=7 and F2=7 access available **Zone Specific** parameters for Z1 and Z2 respectively. F1=8 accesses available **Macro** parameters for Macro type 1. In contrast, F1 accesses available **System** parameters and F2 accesses available **Tuner** parameters.

Thus, when parsing Format specifiers, the presence of the equal sign, “=”, significantly alters the meaning of the Format specifier. Specifically, the format is Fx=fs, where x is some additional specifier (often a Logical Zone number) and fs is the Format Specifier.

For more information regarding the data returned to the host from the BKC-DIP device, see the **E (echo) Command** and **R (reply) Command** sections.

NOTE: For a complete listing of Format Specifier parameters refer to the appropriate Product Specific Appendices.

Error Log Status: (*receiveID, G, E, identifier, ... identifier; cs16*)

The B&K Components' device constantly monitors its performance. In the unlikely event that a system error occurs, the B&K Component's device logs the occurrence and corrects the problem (if possible). The status of the Error Logs can be queried monitor system performance.

For example:

(0, G, E, 0, 2;0209) Returns logged count of Preserved State and Non-Volatile Memory errors from a Series II device.

NOTE: For a complete listing of Error Log parameters and their meanings see the complete listing in the product specific **Appendix M**.

Favorite Settings of a Preset: (*receiveID, G, A, identifier, ... identifier; cs16*)

There are two ways to view favorite presets: from a Zone centric view or from a Preset centric view. To see which presets are favorite to a particular Zone, query the Zone Specific favorite preset bitmaps. See **Zone Specific Settings: (receiveID, G, Zzz, identifier, ... identifier;cs16)** section of this document for more details.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

The Get fAavorite command, like the Zone Specific favorite preset bitmaps, also indicates favorite settings, but from a Preset centric point of view. This command indicates in which logical zones a particular preset is favorite. By contrast, the Zone Specific favorite preset bitmaps indicate which presets are favorite for a particular zone.

NOTE: The specifier A is used, as the F specifier was already used for Format Specification.

For example, the following depicts querying the Favorite Settings of preset 10h (16 decimal) from a factory default CT 610 which as Logical Zones 0, 3, 4, 11, 12, 13, 14, 15, and 16:

```
(0,G,A=10;01E9)           Request Favorite Settings of Preset 10h (16 decimal)
(0,E,G,A=10,01E9;0365)    Echo response
(0,R,A=10,0=0,3=0,4=0,B=0,C=0,D=0,E=0,F=0,10=0;09A1)
                           Preset 16 is not favorite in Logical Zones 0, 3, 4, 11
                           (Bh), 12 (Ch), 13 (Dh), 14 (Eh), 15 (Fh), or 16 (10h).
```

NOTE: If no identifiers are specified, the favorite settings for all zones of the specified preset are returned to the host device.

As another example, the following is a Get for just zone 4 and 11 of preset 10h.

```
(0,G,A=10,4,B;02B7)       Request Favorite Settings of Preset 16, Z4 and Z11
(0,E,G,A=10,02B7;0361)    Echo response
(0,R,A=10,4=0,B=0;039C)   Preset 16 is not favorite in Logical Zones 4 or 11
                           (Bh)
```

S (set) Command

The "S", set, command is sent by the host to change the state of the B&K Components' device. This is the counterpart of the "G", get, command (see the **G (get) Command** section for further details). The host may set different types of information: Presets, System Settings, Zone Specific Settings, Macro Settings, Favorite Settings, Tuner Station Settings, Override Settings, and IR and Front Panel Commands.

Presets: (receiveID, S, Pz=nn, identifier = value, ... identifier = value; cs16)

Presets data can be set using the Pz=nn specifier. Similar to the "G" get command, nn can range from 00h – FDh, or FFh for the current preset, and z specifies the zone.

NOTE: Pz=FE is reserved for future expansion.

NOTE: Pz=FF is a special preset. It is the CURRENT PRESET of the unit, which indicates the CURRENT STATE of the unit. When a user recalls a preset, the recalled preset is copied into the current preset. Subsequent changes are to this current preset. It is not until the current preset is saved that these changes are written to a user preset location.

The *identifier / value* portion of the message has the following format:

```
(00, S, P1=01, 00="Zone 1 Title", 01=60, 03=1, ... ;cs16)
```

Each parameter is and its respective value are delimited by the ASCII equal sign, "=". The parameter's identifier is to the left of the equal sign, while the parameter value is to the right of the equal sign. If the parameter is a string, the parameter value is a string denoted by being surround in double quotes.

Dissecting the previous example:

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

..., 00="Zone 1 Title", ...	
00	parameter identifier (in this case, the Z1 preset title)
=	delimits identifier on left, value on right
"Zone 1 Title"	parameter value (in this case a string)
..., 01=60, ...	
01	parameter identifier (in this case, Z1 volume)
=	delimiter
60	parameter value (in this case, 60h or 0 dB)

Note that parameter identifier, equal sign, and parameter value are delimited by ",", the ASCII comma character. All of the parameter identifiers do not need to be specified. This is to allow only specific parameters to be updated.

For example:

(00, S, P2=0A, 00="New Z2 Title", 01=4D;cs16)

where only the parameter 00 (Z2 preset title) and parameter 01 (Z2 volume) are modified.

NOTE: For a complete listing of preset parameter identifiers and maximum values for applicable zones see the complete listing in the product specific **Appendix A**.

System Settings: (*receiveID, S, S, identifier=value,...identifier=value; cs16*)

Analogous to setting presets, system settings may also be modified.

In the following Reference 30 example, parameter 00 (V1 Input title) and parameter 08 (left speaker offset level) are modified in units with Receive IDs of 00h.

(00, S, S, 00="VCR1", 08=03;04F6)

In this example, the V1 Input title has been modified to "VCR1" and the left speaker offset level is now 03h (or -10.5 dB).

NOTE: For a complete listing of system parameter identifiers and maximum values see the complete listing in the product specific **Appendix B**.

Zone Adjustment (Hardware Special) Settings: (*receiveID, S, H, identifier=value,...identifier=value; cs16*)

Analogous to setting presets, zone adjustment (hardware special) settings may also be modified.

In the following CT600.3 example, parameter 00 (Zone A Room EQ Bass Gain) and parameter 02 (Zone C Room EQ Bass Gain) are modified in units with Receive IDs of 00h.

(00, S, H, 00=00, 02=01;)

In this example, the Zone A Room EQ Bass Gain is now at -18.0 dB and Zone C Room EQ Bass Gain is now at -17.5 dB.

NOTE: For a complete listing of zone adjustment (hardware special) parameter identifiers and maximum values see the complete listing in the product specific **Appendix R**.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Zone Specific Settings: (*receiveID*, *S*, *Zzz*, *identifier = value*, ... *identifier = value*; *cs16*)

Just as there are parameters which are associated with preset (i.e. Preset Parameters), there are other parameters which are associated with Logical Zones. These parameters are called Zone Specific settings.

The zone number, *zz*, can take on the values 00h to 7Fh (Zone 0 to Zone 128). If a particular Logical Zone does not exist in the current device, the command will be ignored and no echo will be generated.

In the following CT 610 example, the Zone 7 parameter 0 (Zone title) is modified in units with Receive IDs of 01h.

```
(1, S, Z7, 0="Living Room");
```

NOTE: For a complete listing of zone specific parameter identifiers and maximum values see the complete listing in the product specific **Appendix N**.

Macro Settings: (*receiveID*, *S*, *Mt*, *identifier = value*, ... *identifier = value*; *cs16*)

The macro number, *mm*, can take on the values 00h to FFh (0 to 255) depending on the amount of memory used by each macro. The macro type, *t*, specifies which of the various kinds of macros are being referenced.

In the following CT 610 example, the serial macro (type 0) number 10 is setup for a unit with Receive ID of 00h:

```
(0, S, M0=A, 0=1, 1=C4, 5="(0,S,S,0="Laser");");
```

The above command setup serial macro 10 which will be triggered when Zone 1 with an IR payload of C4h (Volume -) is received. When triggered, it will transmit the serial payload

```
(0,S,S,0="Laser");
```

via the serial port of the B&K Components' device.

NOTE: A complete list of macro identifiers and supported macro types is found in the product specific **Appendix O**.

Serial Macro

The Serial Macro capability allows B&K IR commands to send ASCII serial commands to control other devices such as lighting controllers, or even other B&K Component devices.

Each serial macro can be of arbitrary length up to the amount of non-volatile memory allocated for this feature. Refer to **Appendix O** of the appropriate product specific document for maximum lengths.

NOTE: For a type 0 macro (serial macro), unspecified identifiers have the default values as specified in the product specific appendices **Appendix O**.

Escape Characters in Serial Macros

Since all BKC-DIP strings are surrounded by double quotes, “”, these characters must be

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

escaped in order to appear in the serial macro. The escape character is the backslash, \, character. This also implies that backslashes must be escaped to differentiate its two meanings: escape or the actual backslash character.

For example, if you wanted a serial macro to emit the string

String in “double quotes”

The syntax to set serial macro 0 with this payload would look like

```
(0, S, M0=0, 5="String in \"double quotes\"");
```

Notice the addition of the backslash before the double quotes embedded in the string.

Another example demonstrates the use of escape characters for both backslashes and double quotes in order to emit the string

\backslashed\ and “quoted”

The corresponding set command for serial macro 1 would be

```
(0, S, M0=1, 5="\backslashed\ and \"quoted\"");
```

IR Macro

NOTE: Currently no V2.0 BKC-DIP product has the hardware capable of transmitting IR macros. This will be a future enhancement.

Tuner Station Settings: (*receiveID*, S, *Tnn*, *identifier = value*, ... *identifier = value*; *cs16*)

Tuner data can be set using the *Tnn* specifier. Similar to the "G" get command, *nn* can range from 00h – 13h.

In the following example, parameter 01 (FM frequency) of station 5 is modified in units with Receive IDs of 02h.

```
(02, S, T04, 01=20;032C)
```

In this example, tuner station 5's FM frequency has been set to 20h (93.9 MHz).

NOTE: For a complete listing of tuner station parameter identifiers and maximum values see the complete listing in the product specific **Appendix C**.

NOTE: In later B&K Component devices, the concept of Tuner Stations was discontinued. These newer devices do not respond to the Tuner Station specifier.

Favorite Settings of a Preset: (*receiveID*, S, A, *identifier=value*, ... *identifier=value*; *cs16*)

Similar to the two views for getting favorite presets, there are two views for setting favorite presets: from a Zone centric view or from a Preset centric view. To attribute presets as favorite in a particular Zone, the Zone Specific favorite preset bitmaps may be set. See the **Zone Specific**

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Settings: (*receiveID, S, Zzz, identifier = value, ... identifier = value; cs16*) section of this document for more details.

The Set favorite command, like the Zone Specific favorite preset bitmaps, can also be used to attribute favorite settings to zones, but from a Preset centric point of view. This command allows setting the favorite preset attribute of particular logical zones for a specific preset. By contrast, the Zone Specific favorite preset bitmaps allow attributing various presets as favorite for a particular zone.

NOTE: The specifier A is used, as the F specifier was already used for Format Specification.

For example, the following depicts setting the Favorite Settings of preset 10h (16 decimal) in an otherwise factory default CT 610 which as Logical Zones 0, 3, 4, 11, 12, 13, 14, 15, and 16:

(0,S,A=10,0=1,3=1,4=0;0459)	Attribute Zones 0 and 3 as favorite, and 4 as not for Preset 10h (16 decimal)
(0,E,S,A=10,0459;0364)	Echo response
(0,G,A=10;01E9)	Get command to verify previous Set example
(0,E,G,A=10,01E9;0365)	Echo response
(0,R,A=10,0=1,3=1,4=0,B=0,C=0,D=0,E=0,F=0,10=0;09A3)	Indicates that Zones 0 and 3 are favorite, and Zones 4, 11 (Bh), 12 (Ch), 13 (Dh), 14 (Eh), 15 (Fh) and 16 (10h) are not attributed as favorite for preset 16 (10h)

Override Settings: (*receiveID, S, O, identifier=value,...identifier=value; cs16*)

The settings of the various RS-232 and BKC-DIP options are available in the System Settings. The question arises, "How can the RS-232 and BKC-DIP options of the connected B&K Components' device be modified via RS-232 and BKC-DIP?" This dilemma can be addressed using the Override Settings.

The Override Setting parameters mirror (or shadow) particular key System Setting parameters. When the Override Settings are activated, by setting the Override Active parameter, the system ignores various System Settings and uses the corresponding Override Settings instead. An example will help clarify.

Suppose in a particular application it is required that the user be able to change the System Setting parameters BKC-DIP Echo Enabled, Front Locked, and IR Locked (for a complete listing of system parameter identifiers and maximum values see the complete listing in the product specific **Appendix B**). However, simultaneously, the RS-232 application requires Echo commands to verify proper transmission and regulate flow control while the front panel and IR commands should be locked to assure the device under control does not respond to outside (non RS-232) stimuli. The following command allow this:

```
(00, S, O, 0=1, 4=1, 6=1, 7=1, FF=A;04CE)
```

Dissecting the previous command reveals (see refer to the product specific **Appendix P** for details regarding the Override Parameter values):

.. 0=1 ..	Override Active is activated
.. 4=1 ..	Override Echo Enabled is enabled
.. 6=1 ..	Override Front Locked is locked

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

.. 7=1 .. Override IR Locked is locked
 .. FF=A.. Activate Override Timeout in 1.0 second

So long as Override Active is activated, the system ignores the System Setting parameters Echo Enabled, Front Locked, and IR Locked. This allows the user to freely change these System Settings without interfering with current serial communication parameters. When the user is finished modifying the device settings, the following command deactivates the Override Settings, and the device reverts to using the corresponding System Settings:

(00, S, O, 0=0;025E) Override Active is deactivated, use System Settings

NOTE: The Override Settings revert to their default parameter values after a “cold boot” (i.e. power cycle) **NOT** a “warm boot” (i.e. awakening from “Sleep” state). See product specific **Appendix P** for a listing of the default parameter values.

NOTE: If the Override Settings changes the baud rate, the Echo response will be transmitted at the new overridden baud rate.

Override Timeout

One use for the Override Setting Baud Rate can be to negotiate higher baud rates. The issue that arises is what to do if the Override Baud Rate is not reliable. The following scenario could occur:

The System is communicating at 9600 Baud.
 The Override command is issued (at 9600 Baud) to change the Override Baud Rate to 115200 Baud.
 For whatever reason (long cable, noisy environment, etc.) the unit cannot communicate at 115200 Baud, however the unit is now in Override mode at 115200 Baud.
 RS-232 communication is now lost with the unit with no remedy.

The answer to the above dilemma is the use of the Override Timeout parameter. The Override Timeout parameter specifies a timeout period in which, if the Override Timeout is not cleared, the BKC-DIP device will drop out of Override mode. This provides the means for a software acknowledge of the new Override state and a means of recovering from Override Baud Rate communication loss. The following is an example of the use of the Override Timeout feature:

(0, S, O, 0=1,1=8, FF=A; cs16) Activate Override 115200 Baud, 1.0 second timeout
 (transmitted at the non-override Baud rate)
 (0, S, O, FF=0; cs16) Clear Override Timeout (transmitted at the new
 Override Baud Rate of 115200)

If the previous clearing of the Override Timeout was received within 1.0 seconds

At Override Baud Rate:

(0, G, O, 0; cs16) Get Override Active state
 (0, R, O, 0=1; cs16) Reply indicates still in override mode

Else Override Timeout occurred because clearing of timeout was not received

At Override Baud Rate:

(0, G, O, 0; cs16) Get Override Active state
 No response from unit

At non-Override Baud Rate:

(0, G, O, 0; cs16) Get Override Active state

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

(0, R, O, 0=0; cs16) Reply indicates NOT in override mode

NOTE: The use of the Override Timeout is not mandatory, but **very strongly recommended** especially when using Override commands to modify Baud Rate.

IR Command: (*receiveID, S, I, z=ir, cs16*)

(only applicable to units with IR Control capabilities)

The BKC-DIP can be used to send virtual IR commands to the attached B&K Components device.

For example, the Zone 2 IR code for B&K volume down is C4h, thus:

(00, S, I, 2=C4;02A1)

would appear to the device as if the user had issued a Zone 2 Volume down command from the IR remote to a unit of Receive ID 00h.

NOTE: z of 1 is Zone 1, z of 2 is Zone 2, z of C is Zone 12.

NOTE: For a complete listing of IR commands, see the complete listing in the product specific **Appendix F**.

Front Panel Commands: (*receiveID, S, F, z=fp; cs16*)

(only applicable to units with Front Panel Control capabilities)

The BKC-DIP can be used to send virtual front panel button pushes to the attached B&K Components device.

For example, the Zone 1 front panel code for volume down is 0Ah, thus:

(01, S, F, 1=0A; 0298)

would appear to the device as if the user had turned the volume down from the front panel of the Receive ID 01h unit.

NOTE: z of 1 is Zone 1, z of 2 is Zone 2.

NOTE: For a complete listing of front panel commands, see the complete listing in the product specific **Appendix G**.

Error Logs: (*receiveID, S, E, identifier=value,...identifier=value; cs16*)

It is possible to clear the Error Logs via a Set command with a value of 0.

For example:

(0, S, E, 0=0, 2=0; 02EF) Reset the Preserved State and Non-Volatile Memory Error logs of a Series II product to zero.

NOTE: It is possible to set the Error Logs to ANY value from 00h – FFh, so it is possible to test Error response logic via artificially generating non-zero Error Log values. However, the most typical application would be value of 0 to reset an Error Log.

NOTE: Error Logs are **NOT** cleared by a factory reset sequence in order to preserve this important information which B&K Components' customer service may request if the unit

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

requires servicing (however, upgrading to new software **WILL** automatically clear the Error Logs). The only way to clear Error Logs the use of this Set command.

NOTE: For a complete listing of Error Log parameters and their meanings see the complete listing in the product specific **Appendix M**.

D (display) Command

The BKC-DIP can be used to display ASCII text to either the Front Panel Display (FP), or the On Screen Display (OSD), or to change the states of the LEDs on the front panel.

NOTE: For a complete list of displayable ASCII characters see the product specific **Appendix H**.

On Screen Display (O): (*receiveID*, D, O, *Ttt*, *Mm*, *Xcc*, *Yrr*, "*text*", ... *Xrr*, *Ycc*, "*text*"; *cs16*)(only applicable to units with On Screen Display capabilities)

B&K Component units featuring On Screen Displays can display text positioned on the On Screen Display.

Ttt where *tt* * 100ms is the timeout before the display is cleared, and T00 indicates the display should not timeout. Valid *tt* values are from 00 (no timeout) to FF (25.5 seconds).
Mm where *m* is the video overlay mode
0 is non-overlay mode, text is displayed over background color "blue screen"
1 is overlay mode, text is displayed over video (if video present)
Xcc where *cc* is the column where the text is positioned
Yrr where *rr* is the row where the text is positioned

The following is an example:

```
(00, D, O, T64, M0, X02, Y04, "Hello World"; 0974)
```

where

00 is the Receive ID, so text will only be displayed on units with receive IDs of 00h
T64 will clear the display after 64h * 100ms (10seconds)
M0 indicates the text will displayed over background color "blue screen"
X02 indicates the displayed text will start at column 02h (the third column)
Y04 indicated the displayed text will start at row 04h (the fifth row)

NOTE: T00 indicates text will not timeout.

NOTE: There is only one display timeout per unit in the system. Therefore, timeouts for the OSD and Front Panel can interact. For example:

```
(00, D, O, T64, M0, X0, Y0, "10 sec timeout";cs16)  
(00, D, F, T32, X0, Y0, "5 sec timeout";cs16)
```

The text "10 sec timeout" would appear on the OSD and "5 sec timeout" would be displayed on the Front Panel, however, **BOTH** displays would be cleared in 5 seconds when the Front Panel timed out.

The last timer value supercedes any previous timer values. For example, a variation on the previous example:

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

(00, D, F, T32, X0, Y0, "5 sec timeout";cs16)
(00, D, O, T64, M0, X0, Y0, "10 sec timeout";cs16)

would clear **BOTH** displays after 10 seconds when the OSD timed out.

NOTE: Text cannot be displayed when zone 1 is off.

NOTE: The X and Y coordinates are zero based, with x00, y00 being in the upper left corner of the display (see exception below for Overlay Mode and 16:9 Aspect Ratio).

NOTE: Currently the On Screen dimensions are 28 characters by 11 characters. Valid OSD coordinates are 00h to 1Bh by 00h to 0Ah (see exception below for Overlay Mode and 16:9 Aspect Ratio).

NOTE: Important Notes when using Overlay Mode with System Setting Monitor Aspect Ratio of 16:9:

NOTE: When Monitor Aspect Ratio is set to 16:9, the OSD rows 0 and 3 are not displayed when in Overlay mode. This implies that when the Monitor Aspect Ratio is set to 16:9 and an OSD Overlay message is displayed, effectively x04, y00 is the upper left corner and that valid (visible) coordinates are 00h to 1Bh by 04h to 0Ah.

NOTE: Some older versions of code permit writing to rows 02h and 03h while in Overlay mode. This practice is highly discouraged for compatibility issues, and as it may interfere with some monitors' proper display of 16:9 ratio material (i.e. writing to rows 02h – 03h may force the monitor back to 4:3 ratio temporarily).

NOTE: Non-overlay mode always uses the full OSD resolution, and thus valid OSD coordinates for Non-overlay mode are always 00h to 1Bh by 00h to 0Ah (X columns and Y rows respectively) regardless of the Monitor Aspect Ratio setting in System parameters.

NOTE: The display is blanked with each D (display) command.

To display a multi-line message, use the following form:

(00, D, O, T00, M0, X04, Y01, "Multiple", X05, Y02, "Lines of", X06, Y4, "Text";1181)

NOTE: The B&K Component's device has priority over its OSD. Thus, system events can overwrite BKC-DIP displayed text. For example:

(00, D, O, T00, M0, X0, Y0, "No Timeout", X0, Y1, "But System can overwrite";13AF)

The text will appear on the On Screen Display. If, however, the unit must display information (such as when the user changes volume), the OSD will be overwritten (in this case with the volume information).

Front Panel Display (F): (*receiveID*, D, F, T*tt*, X*cc*, Y*rr*,*text*";cs16)
(only applicable to units with Front Panel Display capabilities)

B&K Components Device Interface Protocol (BKC-DIP) Specification
Version 2.01.00
Updated 01/24/07

Ttt where *tt* * 100ms is the timeout before the display is cleared, and T00 indicates the display should not timeout. Valid *tt* values are from 00 (no timeout) to FF (25.5 seconds).
Xcc where *cc* is the column where the text is positioned
Yrr where *cc* is the row where the text is positioned

Text may be displayed and positioned on the Front Panel Display using the following display message:

(0, d, f, t0, x0, y2, "Testing";0756)

where

0 receive ID, text will only be displayed on the Front Panels of units with receive IDs of 00h
t0 indicates the display will *NOT* be clear by a timeout
x0 indicates the displayed text will start at row 00h (the first row)
y2 indicated the displayed text will start at column 02h (the third column)

NOTE: T00 indicates text will not timeout.

NOTE: The X and Y coordinates are zero based. Currently, the Front Panel Display dimensions are 16 characters by 1 character.

NOTE: Valid screen FP coordinates are 00h to 0Fh by 00h.

NOTE: The B&K Component's device has priority over its Front Panel Display. Thus, system events can overwrite BKC-DIP displayed text. For example:

(0, D, F, T00, X0, Y0, "No Timeout";07CA)

The text will appear on the Front Panel Display. If, however, the user then changes the volume, the FP will be overwritten with the volume information.

LED display: (*receiveID*, D, L, *Ttt*, *n=bitmap*; *cs16*)

B&K Component units' front panel LEDs may be individually controlled.

Ttt where *tt* * 100ms is the timeout before the display is cleared, and T00 indicates the display should not timeout. Valid *tt* values are from 00 (no timeout) to FF (25.5 seconds).
n indicates which LED buffer
bitmap indicates which of the LEDs are active (1 = active, 0 = inactive)

NOTE: T00 indicates LEDs will not timeout.

For example, to activate the DOWN LED and the REAR LEVEL LED, send the following command:

(00, D, L, T00, 1=21; 0360)

1 LED Buffer 1
21h 01h (the DOWN LED) + 20h (the REAR LEVEL LED)

NOTE: Due to the front panel electronics, only one of each of the following electrical banks of

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

LEDs should be active at a time:

Electrical Bank A

UP, LEVEL, MODE, SOURCE, PRESET, SLEEP, ENTER, MENU, DOWN

Electrical Bank B

CENTER LEVEL, SUB LEVEL, GROUP LEVEL, REAR LEVEL, ZONE 2

Therefore:

(00, D, L, T00, 0=48;cs16)	Invalid, both PRESET and ENTER cannot be active
(00, D, L, T00, 0=04;cs16)	Valid, only MODE active
(00, D, L, T32, 0=02, 1=01;cs16)	Invalid, both LEVEL and DOWN cannot be active. Different LED buffers, but the same electrical bank
(00, D, L, T64, 1=41;cs16)	Valid, DOWN and ZONE 2 are in different electrical banks, but the same LED buffer

NOTE: For a complete listing of the LED mapping, see the product specific **Appendix K**.

X (executive) Command

The "X", eXecutive, commands are sent by the host to access various high level functions directly. As the number of supported eXecutive commands varies per product, please see the product specific **Appendix L** for details. In general, some or all of the following eXecutive commands may be supported:

Recall Preset Command: (*receiveID*, X, 0, *z=nn*; *cs16*)

Save Preset Command: (*receiveID*, X, 1, *z=nn, autoNameMode*; *cs16*)

Power State Command: (*receiveID*, X, 2, *z=onOff*; *cs16*)

Noise Generator State Command: (*receiveID*, X, 3, *state*; *cs16*)

Noise Steering Command: (*receiveID*, X, 4, *speakerIndex=onOff, ... speakerIndex=onOff*; *cs16*)

Noise Increment Command: (*receiveID*, X, 5; *cs16*)

Cold Boot Command: (*receiveID*, X, 6; *cs16*)

Factory Reset Command: (*receiveID*, X, 7; *cs16*)

WARNING!: Issuing a Factory Reset Command will destroy all user modified data in the unit (preset, system settings, etc.).

Reinitialize BKC-DIP State Command: (*receiveID*, X, 8; *cs16*)

Test Tone State Command: (*receiveID*, X, 9, *level*; *cs16*)

Mute State Command: (*receiveID*, X, A, *z=muteState*; *cs16*)

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

M (Macro Trigger) Command: (receiveID, M, t=mm, ... ,t=mm;cs16)

As its name implies, the “M”, Macro Trigger, Command is used to trigger macros in the device via BKC-DIP. This allows BKC-DIP to manually fire a macro in addition to the matching of the Trigger ID and Trigger Code from a B&K Components IR remote.

The Macro type is *t*, and *mm* is the macro number ranging from 00h – FEh.

NOTE: Currently the only supported macro type is 0, Serial Macro.

Assuming the payloads of Macro 1, 6, and 9 are “multiple”, “macros”, and “fired.” Respectively, the following example would result in:

(0,M,0=1,0=6,0=9;)	Command to trigger serial macros 1,6, and 9
multiple macros fired	Output of macros
(0,E,M,0=9,034F;0330)	Echo response of trigger

NOTE: When triggering multiple macros in a single command, the order in which the macros are triggered is based upon the order they are in the command.

(0,M,0=9,0=1,0=6;)	Command to trigger serial macros 9, 1, and 6
fired multiple macros	Output of macros (note the order)
(0,E,M,0=6,034F;032D)	Echo response of trigger

B&K Device to Host Commands

There are three basic commands that the B&K Components device can transmit to the host: E, R, and U. Each of these, and their format specifiers, are explained in detail below.

E (echo) Command

The "E", echo, command provides feedback to the host if the developer would like a closed loop system. The "E" command simply echoes back the previously received command, format specifier, and calculated checksum. The host can then compare this information to its transmitted message to confirm the correct message was received. If an error occurred, the host can choose to retransmit the message.

For example:

(from host)	(01, G, P1=00; 0259)	"G" get Z1 preset 00 command
	from host from a unit with receive ID of 01h	
(from unit)	(2, E, G, P1=00, 0259;0397)	"E" a unit with a Transmit ID of 02h echoed get Z1 preset 00 command
(from unit)	(2, R, P1=00, 0=...;cs16)	"R" reply containing preset info from same unit with Transmit ID of 02h

The echo command contains only the previously received command, format specifier, and checksum which are echoed with a newly calculated checksum:

(from host)	(00, S, P2=01, 0="Z2 Title", 1=4;06BF)	"S" set Z2 preset 01 command to unit with receive ID of 00h
(from unit)	(1, E, S, P2=01, 06BF; 03C2)	"E" echoed set command by unit with Transmit ID of 01h, no parameter data

NOTE: The echo command is sent after the unit has processed the message. Since certain operations take some time to complete (such as saving presets), the echo command can serve as an indicator that the B & K Components' device has complete the most recent task.

NOTE: The echo feature may be disabled via the RS-232 PORT SETUP menu screen (under the ADVANCED SYSTEM SETUP menu).

Implementing Software Flow Control using Echo Commands

Since the echo command is sent after the unit has processed the message, it is an effective way to implement software flow control protocol (since the hardware does not currently support hardware flow control).

To implement such a scheme, subsequent messages destined for the device can be "stalled" until the echo from the previous command is received. In doing so, the developer is assured that the B&K Components' device has emptied its receive buffer.

NOTE: If the message "RS232 RX OVRFLOW" appears in the vacu-fluorescent display, it indicates that the device's receiver buffer has overflowed, and the previously described software flow control should be implemented.

R (reply) Command

The "R", reply, command is sent by the device to the host to return information from a "G", get, host command.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

Using the above example:

(from host)	(01, G, P1=0, 1;0286)	"G" get Z1 preset 00 command from host destined for units with 01h receive IDs
(from unit)	(1, E, G, P1=0, 0286;0366)	"E" echoed get Z1 preset 00 command from unit with 01h Transmit ID
(from unit)	(1, R, P1=0, 1=47;0309)	"R" reply containing preset info from unit with 01h Transmit ID

Another example would be in reply to a host get system:

(from host)	(00, G, S;018D)	"G" get system info command from host from units with 00h receive IDs
(from unit)	(2, E, G, S,018D; 02D9)	"E" echoed get system info command from unit with 02h Transmit ID
(from unit)	(2, R, S, 0=...;cs16)	"R" reply containing system info from same unit with 02h Transmit ID

Replies also occur in response to get format requests from the host:

(from host)	(00, G, F1=0;021E)	"G" get Z1 preset format command from host from units with 00h receive IDs
(from unit)	(1, E, G, F1=0,021E ,0364)	"E" echoed get preset format command from unit with 01h Transmit ID
(from unit)	(1, R, F1=0, 0="D"...;cs16)	"R" reply containing system preset info from the same unit with 01h Transmit ID

Reply from the Get Display command (*transmitID*, G, D, d; cs16)

New to V2.0 BKC-DIP, there are now three different reply types: BKC-DIP V1.0 compliant, BKC-DIP V2.0 with no attributes, and BKC-DIP V2.0 with attributes.

With the development of V2.0 BKC-DIP, there were two goals with regards to Get Display Reply messages: minimize data transmitted and address the shortcomings of indicating the attributes of the text from BKC-DIP V1.0. These design requirements are diametrically opposed, thus 2 reply modes are available in BKC-DIP V2.0 to address these differing goals: **BKC-DIP V2.0 Compliant Display Reply without Attributes** and **BKC-DIP V2.0 Compliant Display Reply with Attributes**.

The reply format of each of these reply types will be discussed below, as well as pros/cons of each type, plus the system settings required to enable each reply type.

The following documentation will assume the following On Screen Display buffer (currently Bh x 1Ch in size) content:

```
row 0="          CONTROL OUT B          "  
row 1="Input 1  On   Input 2  On "  
row 2="Input 3  On   Input 4  On "  
row 3="Input 5  On   Input 6  On "  
row 4="Input 7  On   Input 8  On "  
row 5="Input 9  On   Zone In  On "  
row 6="FM Tuner On   AM Tuner On "  
row 7="
```

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00

Updated 01/24/07

```

row 8="
row 9="^_ next item      adjust <>"
row A="  MENU setup control B  "

```

This display is from the Selected Input setup menu of Control Out B of a CT 610. Notice that the text "Input 1 On" is selected, which is indicated by the red color above.

The front panel display depicts a rendition of selected portion the menu, which is:

```
"CB INPUT 1  ON"
```

BKC-DIP V1.0 Compliant Display Reply

This display reply format is to maintain backwards compatibility with BKC-DIP V1.0 interfaces.

NOTE: BKC-DIP V1.0 Compliant Display Reply Mode is **forced regardless** of the OSD and VFD reply mode **if** the BKC-DIP V2.0 Enabled parameter is **not enabled** (i.e. V1.0 compliant).

NOTE: If the BKC-DIP V2.0 Enabled parameter **is** enabled, the corresponding OSD and VFD reply modes must be set to BKC-DIP V1.0 Compliant Display Reply Mode to obtain this reply format.

The format of a BKC-DIP V1.0 Compliant Get Display reply is as follows:

```
(transmitID, R, D, d, 0="row 0 contents", 1="row 1 contents", ... n="row n contents",
80=row 0 selection, 81=row 1 selection, ... 8n=row n selection; cs16)
```

d where *d* is the display device specifier (currently F (front panel) or O (On Screen Display).

n where *n* is the last row of the display's buffer.

the return from our example OSD screen would be (with carriage returns added for clarity in this document):

```

(0,G,D,O; 01C9)
(0,E,G,D,01C9;02C8)

(0,R,D,O,
0=" CONTROL OUT B ",
1="Input 1 On Input 2 On",
2="Input 3 On Input 4 On",
3="Input 5 On Input 6 On",
4="Input 7 On Input 8 On",
5="Input 9 On Zone In On",
6="FM Tuner On AM Tuner On",
7=" ",
8=" ",
9="^_ next item adjust <>",
A=" MENU setup control B ",
80=0,81=1,82=0,83=0,84=0,85=0,86=0,

```

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

87=0,88=0,89=0,8A=0;6168)

The above example indicates the primary shortcoming with the BKC-DIP V1.0 Display Reply format, mainly that it assumed entire lines were selected at a time. This is indicated by the 81=1 in the latter portion of the reply. As a historical note, this assumption was true in Series I and PT 3 B&K devices, but not Series II and forward.

Using the same example for the Front Panel display reply:

```
(0,G,D,F; )
(0,E,G,D,01C0;02BF)

(0,R,D,F,0="CB Input 1      On          ",80=1;09ED)
```

NOTE: Selection is depicted by another video color (used primarily by the OSD in menus). The selection index is offset by 80h, therefore the selection index is (row – 80h). If the row is selected, the value will be 1 otherwise the value will be 0.

For example:

... 81=0,82=1, ... indicates row 1 is not selected, row 2 is selected

NOTE: The front panel display buffer is actually 20h x 1h. Thus the reason for the 10h extra "whitespace" characters in the previous example. This is due to the hardware of front panel display and how it handles decimal points. Decimal points do not occupy a character cell by themselves, but rather are associated with the previous character. Thus worse case, the return buffer could be 2h x 10h (32 (decimal) characters).

For example, assume the following front panel buffer:

```
Row 0 "0.1.2.3.4.5.6.7.8.9.A.B.C.D.E.F. "
```

This would fit in the front panel display because the 0th decimal point shares the 0th character cell, the 1st decimal point shares the 1st character cell, etc. In this case, 20h characters are displayed in 10h locations. So the reply stream would look like:

```
(0,R,D,F,0="0.1.2.3.4.5.6.7.8.9.A.B.C.D.E.F. ";cs16)
```

NOTE: See the product specific **Appendix I** for special characters returned from the Front Panel (FP) and On Screen Display (OSD).

BKC-DIP V2.0 Compliant Display Reply without Attributes

BKC-DIP V2.0 Display Replies without attributes contain less information than its V1.0 counterpart, because no attempt is made to try to indicate attributes about the displayed text, only the raw text itself.

The display reply from the OSD of the example menu screen results in:

```
(0,G,D,O; 01C9)
(0,E,G,D,01C9;02C8)

(0,R,D,O,
0=" CONTROL OUT B          ",
1="Input 1  On  Input 2  On",
```

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

```

2="Input 3   On   Input 4   On",
3="Input 5   On   Input 6   On",
4="Input 7   On   Input 8   On",
5="Input 9   On   Zone In   On",
6="FM Tuner  On   AM Tuner  On",
7="
8="
9="^_ next item      adjust <>",
A="   MENU setup control B   ";561E)

```

Notice that in contrast to BKC-DIP V1.0 display replies, there are no 80 through 8A parameters indicating selection.

Similarly for the front panel display contents:

```

(0,G,D,F;01C0)
(0,E,G,D,01C0;02BF)

(0,R,D,F,0="CB Input 1   On";06EB)

```

Notice that for the front panel display (sometimes referred to as VFD (Vacuum-Fluorescent Display) because of the front panel's display technology) reply does not include any additional padding characters to account for the hardware being able to display a decimal point with each character. In the event a decimal point is present, the returned string expands accordingly.

```

(0,D,F,T0,X0,Y0,"Decimal Pnts. 1.2.";0957)
(0,E,D,F,0957;02BF)

(0,G,D,F;01C0)
(0,E,G,D,01C0;02BF)
(0,R,D,F,0="Decimal Pnts. 1.2. ";0849)

```

In many applications selection is unimportant (such as those where BKC-DIP exclusively writes messages to the unit's display, since writing via BKC-DIP does not allow selection). Selecting this format will decrease Get Display message traffic, and will increase the speed at which Display information can be captured (especially at lower baud rates).

NOTE: This reply format is **only** available if the BKC-DIP V2.0 Enabled parameter **is** enabled and the appropriate OSD and VFD reply modes are set to BKC-DIP V2.0 Compliant Display Reply without Attributes.

BKC-DIP V2.0 Compliant Display Reply with Attributes

BKC-DIP V2.0 Display Replies with attributes is the most verbose of the display reply modes. The benefit of this reply mode is that it fully describes the attributes of each character of the display.

The display reply from the OSD of the example menu screen results in:

```

(0,G,D,O;01C9)
(0,E,G,D,01C9;02C8)

0,R,D,O,
0="   CONTROL OUT B   ",

```

B&K Components Device Interface Protocol (BKC-DIP) Specification
Version 2.01.00
Updated 01/24/07

should additional character attributes become available in the future. Selecting this format will increase Get Display message traffic, and will decrease the speed at which Display information can be captured (especially at lower baud rates).

NOTE: This reply format is **only** available if the BKC-DIP V2.0 Enabled parameter is enabled and the appropriate OSD and VFD reply modes are set to BKC-DIP V2.0 Compliant Display Reply with Attributes

U (update) Command

The "U", update, command is generated by the device to inform the host of various events. These events include: Status messages (including the BKC-DIP Active message), the reception of an IR message, the reception of a front panel button message, and the change in realtime status (such as detection of various bitstreams, audio present, video present, etc.).

NOTE: The update feature may be disabled via the RS-232 PORT SETUP menu screen (under the ADVANCED SYSTEM SETUP menu). This is recommended for low baud rates, as the Update command overhead can make the system less responsive.

NOTE: Due to its importance in the initialization of host applications, the BKC-DIP Active message (see below for more details) is transmitted regardless of the Update Enable setting.

Status message: (*transmitID*, U, S, *n*="status message";*cs16*)

As the name implies, Status messages are generated by the unit to indicate a change in the status of the unit. The number and types of Status messages each device can generate is product specific. For a complete detailed list of the Status messages, refer to **Appendix Q** of the appropriate BKC-DIP Product Specific Appendices document.

BKC-DIP Active message: (*transmitID*, U, S, 0="BKC-DIP ACTIVE";*cs16*)

One Status message that is supported by all B&K Component BKC-DIP devices is the BKC-DIP Active message.

When the BKC-DIP device exits a Cold Boot power sequence (either from the application of power to the unit from the Power On/Off switch, the issuing of a Cold Boot Command, or the occurrence of a Factory Reset (either via eXecutive Command or Front Panel command)), there is a period of time before the communication port is initialized and ready to receive BKC-DIP command. When the device is capable of receiving BKC-DIP commands, the following update message is generated:

(*transmitID*, U, S, 0="BKC-DIP ACTIVE";*cs16*) where *transmitID* is the unit's Transmit ID and *cs16* is the 16 bit checksum.

NOTE: In cases where the host application is running during a Cold Boot sequence (either from the application of power to the unit from the Power On/Off switch, the issuing of a Cold Boot Command, or the occurrence of a Factory Reset (either via eXecutive Command or Front Panel command)), it is recommended that the host application poll for the Update BKC-DIP Active Message before issuing any BKC-DIP commands.

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

IR message: (*transmitID*, U, I, *z=ir*, *cs16*)

When the BKC-DIP device receives an IR message, the following message is generated:

(*transmitID*, U, I, *z=ir*, *cs16*) where *transmitID* is the unit's Transmit ID, *ir* is the received IR command, *z* is the zone number, and *cs16* is the 16 bit checksum.

For example:

(0, U, I, I=C4; 0261) "U" update to host indicating a Zone 1 <Volume -> key, C4h, received from unit with Transmit ID of 00h

NOTE: For a complete listing of IR commands, see the complete listing in the product specific **Appendix F**.

Front Panel message: (*transmitID*, U, F, *z=ir*, *cs16*)

When the BKC-DIP device receives a front panel message, the following message is generated:

(*transmitID*, U, F, *z=fp*; *cs16*) where *transmitID* is the unit's Transmit ID, *fp* is the received front panel, *z* is the zone number, and *cs16* is the 16 bit checksum

For example:

(1, U, F, 1=A; 023A) "U" update to host indicating Zone 1 front panel <Volume ->, 0Ah, received from unit with Transmit ID of 01h

NOTE: For a complete listing of front panel commands, see the complete listing in the product specific **Appendix G**.

Realtime Status message: (*transmitID*, U, R, *identifier=value*; *cs16*)

When an enabled realtime event occurs in the BKC-DIP device, the following message is generated:

(*transmitID*, U, R, *identifier=value*; *cs16*) where *transmitID* is the unit's Transmit ID, *identifier* is the identifier as specified in **Appendix D**, *value* its the value, and *cs16* is the 16 bit checksum.

NOTE: For a complete listing of Realtime Status identifiers, see the complete listing in the product specific **Appendix D**.

NOTE: The Realtime Enable registers are initialized to all DISABLED on power-up. Therefore, the events that are to generate Update messages must be ENABLED via the Set command and the Realtime Enable *n* register specifiers (see the product specific **Appendix B**).

For example, to have the B&K device generate an Update message every time the Sample Rate changes and OSD Display Update occurs:

(00, S, S, 59=20, 5A=04; *cs16*) Set bit 5 of Realtime Enable 0 register
Set bit 2 of Realtime Enable 1 register
(enabling Sample Rate and OSD Display Update respectively on receive ID 00h units)
(1, U, R, 5=*sample rate*; *cs16*) Update from sample rate change from 01h

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

(1, U, R, A=1;cs16)

Transmit ID unit
Update indicating OSD update from 01h
Transmit ID unit

NOTE: Realtime status registers can be read using the (*receiveID*, G,R, ...; *cs16*) command regardless of settings in the Realtime Enable registers.

Use of Receive and Transmit IDs

The primary use of the BKC-DIP Receive and Transmit IDs is to differentiate multiple units on a common serial bus.

NOTE: The terms "receive" and "transmit" are relative to B&K Components device's perspective. Host to unit commands (such as G, S, and D) are **received** by the B&K unit and therefore contain the **Receive ID**. Conversely, data from the B&K unit to the host are **transmitted** by the unit and therefore contain the **Transmit ID** of the unit.

The Receive ID

The first token of a host to B&K unit command is the Receive ID. The purpose of the Receive ID is to allow commands to be sent to a specific unit on a common serial bus with multiple units. The Receive ID is 00h by default. The Receive ID can be changed to any of 128 settings (00h – 7Fh) on the RS-232 PORT SETUP menu.

NOTE: It is conceivable of a setup where multiple units could have the same Receive ID. This is the case if it is desirable to have multiple units respond to the same commands. See the Multiple Unit Example below for a detailed example.

The Transmit ID

The first token of a B&K unit to host command is the Transmit ID. The purpose of the Transmit ID is to determine which unit generated a message a common serial bus with multiple units. The Transmit ID is 00h by default. The Transmit ID can be changed to any of 128 settings (00h – 7Fh) on the RS-232 PORT SETUP menu.

NOTE: Unlike the Receive ID, each should have a unique Transmit ID, otherwise it is impossible to determine the source unit of a generated message. See the Multiple Unit Example below for a detailed example.

A Multiple Unit Example

The following is an example of four B&K Components units (denoted as UNIT0, UNIT1, UNIT2 and UNIT3) on a common serial bus with the following settings:

Unit	Receive ID	Transmit ID
UNIT0	00h	00h
UNIT1	01h	01h
UNIT2	00h	02h
UNIT3	02h	03h

In this example, Host to B&K unit commands are sent to 3 different groups of units: UNIT0 and UNIT2, UNIT1, and UNIT3. It is very important to note that UNIT0 and UNIT2 **both** respond to the same commands from the host because they have the same Receive IDs. It is also important to note that each unit has a **unique** Transmit ID (even UNIT0 and UNIT2).

The following example commands (and comments) should help clarify:

(01, G, S, 00;)	request of UNIT1's V1 Title (0 th system parameter)
(1, E, G, S, <i>received cs16;cs16</i>)	echo confirming reception of command by UNIT1
(1, R, S, 0="V1 "; <i>cs16</i>)	UNIT1 replies with its V1 Title
(02, G, P1=FF, 1;)	request of UNIT3's Z1 current preset Volume
(3, E, G, P1=FF, <i>received cs16; cs16</i>)	echo confirming reception of command by UNIT3

B&K Components Device Interface Protocol (BKC-DIP) Specification

Version 2.01.00
Updated 01/24/07

(3, R, P1=FF, 0=60; <i>cs16</i>)	UNIT3 replies with its current preset Z1 Volume
(0, S, S, 1="DAT"; <i>cs16</i>)	command to set both UNIT0 and UNIT2 V2 Title
(0, E, S, <i>received cs16; cs16</i>)	UNIT0 confirms reception of command
(2, E, S, <i>received cs16; cs16</i>)	UNIT2 confirms reception of command
(0, G, P1=00, 1, 2; <i>cs16</i>)	request Z1 Preset 0 Volume and Balance from UNIT0 and UNIT2
(0, E, G, P1=00, <i>received cs16; cs16</i>)	UNIT0 confirms reception of command
(2, E, G, P1=00, <i>received cs16; cs16</i>)	UNIT2 confirms reception of command
(0, R, P00, 1=60, 2=18; <i>cs16</i>)	UNIT0 replies with its Z1 Volume and Balance
(2, R, P00, 1=56, 2=6; <i>cs16</i>)	UNIT2 replies with its Z1 Volume and Balance
(0A, G, F4; <i>cs16</i>)	request for unit format for Receive ID 0Ah, but since no such ID on the serial bus, no response. UNIT0, UNIT1, UNIT2, and UNIT3 all ignore this command.
(FF, G, F4, C; <i>cs16</i>)	request BKC-DIP version number from all units
(0, E, G, F4, <i>received cs16; cs16</i>)	UNIT0 confirms reception of command
(1, E, G, F4, <i>received cs16; cs16</i>)	UNIT1 confirms reception of command
(2, E, G, F4, <i>received cs16; cs16</i>)	UNIT2 confirms reception of command
(3, E, G, F4, <i>received cs16; cs16</i>)	UNIT3 confirms reception of command
(0, R, F4, C="BKC-DIP V1.01"; <i>cs16</i>)	UNIT0 replies with BKC-DIP version
(1, R, F4, C="BKC-DIP V1.01"; <i>cs16</i>)	UNIT1 replies with BKC-DIP version
(2, R, F4, C="BKC-DIP V1.01"; <i>cs16</i>)	UNIT2 replies with BKC-DIP version
(3, R, F4, C="BKC-DIP V1.01"; <i>cs16</i>)	UNIT3 replies with BKC-DIP version