


POS TERMINAL

# UP-3301

# **INSTRUCTION MANUAL**



#### WARNING

FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at their own expense.

#### **CAUTION**

The AC power socket-outlet should be installed near the equipment and should be easily accessible.

#### FOR YOUR RECORDS

Please record below the model number and serial number for easy reference in case of loss or theft. These numbers are located on the right side of the unit. Space is provided for further pertinent data.

Model Number	
Serial Number	
Date of Purchase	
Place of Purchase	

# INTRODUCTION

Thank you very much for your purchase of the SHARP POS Terminal Model UP-3301. Please read this Manual carefully before operating your machine in order to gain full understanding of functions and features. Please keep this manual for future reference. It will help you if you encounter any operational problems.

# **IMPORTANT**

- Install your POS terminal in a location that is not subject to direct radiation, unusual temperature changes, high humidity or exposure to water sources. Please keep the POS terminal away from heat and magnetic sources.
  - Installation in such locations could cause damage to the cabinet and the electrical components.
- The POS terminal should not be operated by an individual with wet hands.

  The water could seep into the interior of the POS terminal and cause component failure.
- Do not apply excessive pressure to the display.
   Do not use a sharp-pointed object on the display, or the touch panel and/or LCD may become damaged.
- When cleaning your POS terminal, use a dry, soft cloth. Never use solvents, such as benzine and/ or thinner.
  - The use of such chemicals will lead to discoloration or deterioration of the cabinet.
- The POS terminal plugs into any standard wall outlet (120V ±10% AC) with a dedicated earth-guard. Other electrical devices on the same electrical circuit could cause the POS terminal to malfunction.
- If the POS terminal malfunctions, call your authorized SHARP dealer for service do not try to repair the POS terminal yourself.
- · For a complete electrical disconnection, remove the AC power cord from the wall outlet.

# **PRECAUTION**

This POS terminal has a built-in memory protection circuit which is operated by a rechargeable battery pack. Please note that all batteries will, in time, dissipate their charge even if not used. Therefore to insure an adequate initial charge in the protection circuit and to prevent any possible loss of memory upon installation, it is recommended that each unit be allowed to be recharged for a period of 24 to 48 hours prior to use by the customer.

After installation, the battery pack is charged when the machine is plugged in and its power switch is set to the "ON" position. This recharging precaution can prevent unnecessary initial service calls.

#### **BATTERY DISPOSAL**

Contains Nickel Metal Hydride Battery. Must be Disposed of Properly.

Contact Local Environmental Officials for Disposal Instructions.

This product utilizes tin-lead solder, and fluorescent lamp containing a small amount of mercury.

Disposal of these materials may be regulated due to environmental considerations.

For disposal or recycling information, please contact your local authorities or the Electronics Industries Alliance: www.eiae.org

# **CONTENTS**

NTRODUCTION	
MPORTANT	1
PRECAUTION	1
1. Part Names and Functions	7
External View ·····	
Front view ·····	7
Rear view ·····	····· 7
Displays ·····	8
Operator display (touch panel)	
Customer display	
Screen save mode ·····	10
2. Before Operating the POS Terminal	11
Display Adjustment	
Connecting the Printer and Installing the Paper Rolls	11
3. Selecting an Operating Mode	12
Operating Modes	
Mode Selection	
Selecting a mode	
Entering a secret code	
Returning to the mode selection window	13
4 Time Display and Automotic Hadating of the Date	4.4
4. Time Display and Automatic Updating of the Date	
5. Prior to Entries	15
Preparations for Entries Preparations for Entries	
Error Warning	
Sample Receipt	
Sample Receipt	
6. Entries	16
Function Key Description	
Touch-panel keyboard	
Function keys list ······	
How to Use the Touch Panel	
Cursor control by touching option(s) or item(s) in the window	
Server Code Entries	20
Item Selection from the Menu Window	
Item Entries	
Single item entries	
Repeat entries	
Multiplication entries	
Fast food sale entries	
Scale entries	
Special Entries for PLUs	
Mix-and-match function	
Link PLU entries	
Combo meal entries	
PLU level shift (for direct PLUs)	
PLU price level shift	
Condiment entries	
Display of Subtotals	
werchandise subtotal ·····	

Taxable subtotal ·····	
Including-tax subtotal	
Tray subtotal	
Eat-in subtotal ·····	
Finalization of Transaction	
Cash or check tendering	
Mixed tendering (check + cash)	
Cash or check sale that does not need any tender entry	39
Charge (credit) sale ·····	
Mixed-tender sale (cash or check tendering + charge tendering)	
Tax Calculations	
Automatic tax	
Manual tax ·····	
Tax deletion ·····	
Tax status shift ·····	
Guest Check (GLU/PBLU) ·····	
GLU/PBLU system ·····	
Drive-through function	
Deposit entries ·····	
Transferring guest checks out or in (Transfer-in/out)	44
Bill totalizing/bill transfer	
Bill separating	
Auxiliary Entries	46
Percent calculations (premium or discount)	46
Discount entries	
Refund entries	
Return entries	
Printing of non-add code numbers	
Gratuity	
Payment Treatment	
Tip-in entries	
Tip editing	
Tip paid entries	
Currency conversion	
Received-on-account entries	
Paid-out entries ······	
No-sale (exchange) ·····	
Cashing a check	
Employee Function ······	
Server/manager sign-on	
Employee's working time recording	
Sales entry for employees	
WASTE mode	
7. Correction ·····	54
Correction of the Last Entry (Direct Void)	54
Correction of the Next-to-Last or Earlier Entries (Indirect Void)	55
Subtotal Void ·····	57
Correction of Incorrect Entries Not Handled by the Direct or Indirect Void Function	57
8. Special Printing Function	59
Copy Receipt Printing	
	30
9. Manager Mode	59
Entering the Manager Mode	
Override Entries	

10. Cor	rrection after Finalizing a Transaction	60
11. Rea	ading (X) and Resetting (Z) of Sales Totals ······	61
	How to take a reading (X1, X2) or resetting (Z1, Z2) report	
Dai	illy Sales Totals	64
	Transaction report ······	
	Department report ·····	
	Individual group total report on departments	
	Full group total report on departments	
	Department markdown report	
	PLU report by designated range	
	PLU report by associated department	
	Individual group total report on PLUs	71
	Full group total report on PLUs	
	PLU stock report	
	PLU cost report ·····	
	PLU top 20 report ·····	
	PLU zero sales report (full)	
	PLU zero sales (by dept.) report ······	
	PLU minimum stock report	
	PLU group total report by hour ······	
	Cash in drawer report	
	Tax report	
	Individual server report	
	Full server report ·····	
	Employee report ······	
	Employee over-time report ······	
	Employee active status report ······	
	Hourly report ······	
	Labor cost % report ·····	
	Ingredient stock report ·····	
	GLU/PBLU report ·····	
	GLU/PBLU report by server ·····	
	Closed GLU/PBLU report ·····	
	Closed GLU/PBLU report by server ·····	
	Drive-through report ·····	
	Drive-through service time report ······	
	Drive-through report by server ·····	
	Closed drive-through report ·····	
	Closed drive-through report by server	
	X1/Z1 stacked reports ·····	88
Per	riodic Consolidation	
	Transaction report ·····	
	Daily net report	
	Employee time adjustment report	
	Employee sales report (detailed)	
	Employee sales report (full)	
	Employee summary report ······	
	Payment period report ······	
	Payment period summary report ······	
	X2/Z2 stacked report ······	
12. Hov	w to Use the Programming Keyboard ······	95
	ogramming Keyboard Layout	
Ho	w to Program Alphanumeric Characters	96
	Using character keys on the keyboard ······	
	Entering character codes	97

13. Programming Basic Instructions	
Programming example ······	98
Article Programming	
Department	
PLU	
PLU range	
PLU stock ·····	
Ingredient ·····	108
Ingredient stock ·····	
Link PLU table	
Condiment table ······	111
Mix & Match table ·····	112
Recipe table ·····	
Combo meal table ·····	
Scale table ·····	115
Direct Key Programming	116
Direct PLU/COMBO/dept. key (except menu PLU/condiment PLU)	
Direct condiment/menu PLU key	
PLU Menu Key Programming	
PLU menu key	
Functional Programming	
Discount key ((-)1 thru (-)9)	121
Percent key (%1) thru (%9)	122
Gratuity	123
Tip	
RA	
PO	
Manual tax ·····	125
Media Key Programming	126
Cash key ·····	127
Check key ·····	130
Charge key ·····	133
Employee charge key	136
Currency conversion key ······	139
Eat-in key ·····	
Service key ·····	
Final key ·····	
Cash in drawer ·····	
Check change ·····	
Check cashing	145
Text Programming	147
Function text ·····	
Department group text	150
PLU group text ·····	
PLU hourly group text ······	
Server group text ·····	
Personnel Programming	
Server	
Manager ·····	
Employee ·····	
Job location table	
Terminal Programming	
Machine number ·····	
Consecutive number ·····	
Interval timer ·····	
Bill number ·····	

	Date/Time Setting	161
	Date/time	161
	Optional Feature Selection	162
	Function prohibition ·····	
	Function selection ·····	
	Printing selection ·····	165
	Secret Code Programming	166
	Z1 reports	
	PGM2-mode operations ·····	167
	System Z1 reports ·····	168
	System PGM2-mode operations	
	Initial down-loading (with clearing of memory)	
	Maintenance down-loading (without clearing of memory)	169
	CAT#2 execute ·····	170
	Report Programming ·····	171
	Zero skip	172
	Hourly report ·····	172
	Stacked report ·····	173
	Employee report ······	176
	Logo Text Programming	177
	Receipt logo ······	
	Bill logo	
	Printer Programming ·····	179
	Printer	
	GLU/PBLU Code Programming	
	GLU/PBLU code ·····	
	Drive-through code ·····	182
	Tax Programming	183
	Table tax ······	
	Rate (%) tax ·····	186
	Doughnut tax exempt (for the Canadian tax system)	186
	Function Key Programming	187
	TRAINING Mode Selection	188
	TRAINING mode ·····	
	Backup Data Send Programming	189
	Backup data send	
	Backup Data Receive Programming	190
	Backup data receive	
	PLU Updating (in the PGM1 Mode)	
	Unit Price Mode Programming	
	Automatic Sequencing Key Programming	193
	Reading of Stored Programs	194
	Program reading sequence	194
	Sample printouts ·····	196
14.	Operator Maintenance ·····	
	In Case of Power Failure	
	Before Calling for Service	209
15.	Options	
	List of Options	210
4.0	Considerations	04.4
16.	Specifications	211
17	Appendix	010
17.	Error Messages	
	LITUI INICOSAYES	212
10	Index	21/
10.	HIUCA	<b>~14</b>




# **Part Names and Functions**


This chapter describes the part names and functions of this POS terminal.

# **External View**

#### Front view



#### Rear view



# **Displays**

This POS terminal is equipped with a color LCD operator display and a two-line customer display.


The operator display is a touch panel.

The operations can be performed by touching the screen (that shows keys or items in the receipt window) of the operator display.


#### ■ Operator display (touch panel)

The display can be tilted to the best viewing angle by sliding the rear stand.

Be sure to push the button on the rear stand when sliding it.



#### · Screen example (REG mode)




Williaovi


NOTE

The size of a display area depends on the layout of a touch-panel keyboard (ex. key size) or the function mode (ex. drive-through function).

#### Display example 1 (REG mode)



#### Display example 2 (PGM mode)



#### ■ Customer display

The customer display consists of a 16-position dot-matrix display (upper) and a 11-position 7-segment display (lower).

#### ■ Screen save mode

To save the electrical power or the display's life, your POS terminal is provided with the screen save function. This function can turn the LCD backlight off when the POS terminal is left idle for an extended period of time. You can program the time for which your POS terminal should keep the normal status (in which the backlight is "ON") before it goes into the screen save mode.


To exit the screen save mode, touch a key.

# **Before Operating the POS**Terminal

This chapter describes those steps required prior to using the POS terminal for the first time.

# **Display Adjustment**

You can adjust the brightness and contrast of the display by using the corresponding controls.



#### Contrast control

Turning the control backwards darkens the display and turning it forwards lightens the display.

# **Connecting the Printer and Installing the Paper Rolls**


This POS terminal may be configured with multiple types of printers offered in the market. For specific instructions related to the handling and care of the printer, please refer to the applicable printer instruction manual.

3

# Selecting an Operating Mode

The POS terminal will display the following listing by touching the MODE key.

#### Mode selection window



# **Operating Modes**

You can select any mode other than REG from the list in the mode selection window. Your POS terminal supports the following 13 operating modes:

REG mode	This mode allows you to enter various sales information. The mode selection window does not list this mode. To select this mode from the mode selection window, touch the <code>CANCEL</code> key.
OPXZ mode	This mode allows servers to take X or Z reports on their sales information. It can also be used for employee time function.
OFF mode	This mode locks all operations of the POS terminal. When you select this mode, the window will disappear. Touching any key turns the POS terminal ON.
X1 mode	This mode is used to take various daily reading reports (X1 reports).
Z1 mode	This mode is used to take various daily resetting reports (Z1 reports).
X2 mode	This mode is used to take various weekly or monthly reading reports (X2 reports).
Z2 mode	This mode is used to take various weekly or monthly resetting reports (Z2 reports).
UNIT PRICE mode	This mode allows you to program unit price of PLUs.
PGM1 mode	This mode allows you to program those items which need to be changed often such as unit prices and discount percentages.
PGM2 mode	This mode allows you to program those items which can be programmed in the PGM1 mode and do not require frequent changes such as date, time, and terminal functions.
AUTO KEY mode	This mode allows you to program automatic sequencing keys.
CAT#2 EXECUTE	This mode is used to execute CAT#2.
CAT#2 REPORT	This mode is used to obtain CAT#2 report.

## **Mode Selection**

#### **Procedure**





#### ■ Selecting a mode

Use one of the following three methods:

- 1. Touch the desired option line in the window.
- 2. Move the cursor to a desired option by using the 1, 1, FUP or FDOWN key. Then touch the ENTER key.
- **3.** Enter the desired option number by using a numeric key. Then touch the ENTER key.

#### NOTE

When you want to enter the REG mode, simply touch the CANCEL key.

#### Procedure



#### Entering a secret code

When a secret code has been set for the selected mode, you must enter the secret code and touch the ENTER key.

#### Procedure



#### ■ Returning to the mode selection window

To return to the mode selection window, use the following procedure:

- **1.** Touch the MODE or CANCEL key with the menu screen of the selected mode displayed.
  - · You will enter the REG mode.
- 2. Touch the MODE key.
  - You will return to the mode selection window.



# 4 Time Display and Automatic **Updating of the Date**

#### Time display

The screen always displays the time at the top (next to the mode indicator) as shown below.

GLU#00000005 REG 0001 SERV.001 SHARP UP3301 PDS 9:57AM  ***PBAL 0.00 1 PL000003 1.75 1 PL000002 1.00 MDSE ST 2.75 MDSE ST 2.75 TAX1 0.11 TAX2 0.07 CASH 2.93							Time
1 PL000003 1.75 1 PL000002 1.00 MDSE ST 2.75 BAL FWD 2.75 MDSE ST 2.75 TAX1 0.11 TAX2 0.07	GLU#00000005	RE	EG 00 <u>01</u>	SERV,001	SHARP UP33	01 POS	9:57AM
BALANCE 0.00 ***TOTALCHECK CLOSED 9:56AM 2.93	1 PL000003 1 PL000002 BAL FWD MDSE ST TAX1 TAX2 CASH BALANCE	1.75 1.00 MDSE ST 2.75 2.75 0.11 0.07 2.93 0.00 ***TDTAL					
CASH 2.93 P1L1	Cash						

#### Automatic updating of the date

Once the internal clock unit is started at the correct time, it continues to run as long as the battery pack is charged and will also update the date properly.

REG MODE

# **5** Prior to Entries

# **Preparations for Entries**


- 1. Select the REG mode from the mode selection menu by touching the CANCEL key.
- **2.** Insure that all printers in your system have adequate paper rolls prior to beginning entries. For more information, please refer to the applicable printer's manual.

## **Error Warning**

In the following examples, your POS terminal will go into an error state accompanied with a warning beep and the error message on the display. Clear the error state by touching the <code>QLEAR</code> key and take the proper action.

- When you exceed a 32-digit number (entry limit overflow):
  - Cancel the entry and re-enter a correct number.
- When you make an error in key operation:
  - Clear the error and try the entry again.
- When you make an entry beyond a programmed amount entry limit:
  - Check to see if the entered amount is correct. If it is correct, it can be rung up in the MGR mode. Contact your manager.
- When an including-tax subtotal exceeds eight digits:
  - Delete the subtotal by touching the [CLEAR] key and touch a media key to finalize the transaction.

# **Sample Receipt**



REG MODE

# 6 Entries

# **Function Key Description**

#### **■** Touch-panel keyboard


This POS terminal provides the following types of keyboards for various functions or modes.

- · Home keyboard
- · Main-2 keyboard
- · Main-3 keyboard
- · Sub keyboard
- · Sub-2 keyboard
- · Sub-3 keyboard
- · Condiment/ Menu keyboard
- · Condiment/ Menu-2 keyboard
- · Condiment/ Menu-3 keyboard
- · Function menu 1 keyboard

- · Function menu 2 keyboard
- · Function menu 3 keyboard
- · Function menu 4 keyboard
- · Function menu 5 keyboard
- · Function menu 6 keyboard
- · Function menu 7 keyboard
- · Payment menu keyboard
- · Drive thru keyboard
- · PGM/XZ mode keyboard
- · Character keyboard

**NOTE** If you want to change the layout, consult your authorized SHARP dealer.

#### Transition of the keyboard



#### **Keyboard layout (default)**

#### · Home keyboard

This keyboard appears when you touch the HOME key.

					QTY	DISC.	MISC	G. CHK	MGR
					MENU01	MENU02	MENU03	MENU04	MENU05
					L1	L2	L3	SI	JB
					000	001	000	006	000011
					000	002	000	007	000012
1	1	P UP	VOID	D-THRU	000003		000	800	000013
MODE	CLEAR	P DOWN	RFND	PAYMEN	000	004	000	009	000014
HOME	CANCEL	←MORE	MORE→	I A I WILIN	000	005	000	010	000015

#### · Main2 keyboard

This keyboard appears when you touch the wife key on the Home keyboard.

		•							
					QTY	DISC.	MISC	G. CHK	MGR
					MENU01	MENU02	MENU03	MENU04	MENU05
					L1	L2	L3	SI	JB
					000	016	000	021	000026
					000	017	000	022	000027
Ţ	1	P UP	VOID	D-THRU	000018		000023		000028
MODE	CLEAR	P DOWN	RFND	PAYMEN	000	019	000	024	000029
НОМЕ	CANCEL	←MORE	MORE→	FATIVIEN	000	020	000	025	000030

#### · Main3 keyboard

This keyboard appears when you touch the MORE+ key on the Function2 keyboard.

				QTY	DISC.	MISC	G. CHK	MGR
				MENU01	MENU02	MENU03	MENU04	MENU05
				L1	L2	L3	SI	JB
				000	031	000	036	000041
					032	000037		000042
1	P UP	VOID	D-THRU	000033		000038		000043
CLEAR	P DOWN	RFND	DAVMEN	000	034	000	039	000044
CANCEL	←MORE	MORE→	FAINEN	000035		000	040	000045
		CLEAR P DOWN	CLEAR P DOWN RFND	CLEAR P DOWN RFND PAYMEN	MENU01   L1   000   000     000       000       000       000       000       000       000       000       000       000       000	MENU01   MENU02   L1   L2	MENU01   MENU02   MENU03	MENU01   MENU02   MENU03   MENU04

#### · Sub keyboard

This keyboard appears when you touch the SUB key on the Home keyboard.

on the Home keyboard.									
		-			P1	P2	P3	P4	P5
					COMB01		COMB06		000101
					COMB02 CO		COV	/IB07	000102
					COMB03		COMB08		000103
					COV	/IB04	COV	/IB09	000104
Ţ	1	P UP	VOID		COV	/IB05	CON	/IB10	000105
MODE	CLEAR	P DOWN	RFND	DAVMEN	w		AIT		
HOME	CANCEL	MOI	RE→	PAYMEN				FIN	IAL

#### · Sub2 keyboard

This keyboard appears when you touch the MORE-) key on the Sub keyboard.

					P1	P2	P3	P4	P5
					COM	1B11	COV	/IB16	000106
					COM	/IB12	CON	/IB17	000107
					COM	1B13	CON	/IB18	000108
					COM	1B14	CON	/IB19	000109
Ţ	1	P UP	VOID	SUB	COM	1B15	COV	/B20	000110
MODE	CLEAR	P DOWN	RFND	PAYMEN		·	·	W	AIT
HOME	CANCEL ←MORE		PATMEN				FIN	IAL	

#### · Sub3 keyboard

This keyboard appears when you touch the MORE-) key on the Sub2 keyboard.

Ţ	1	P UP	VOID	SUB			
MODE	CLEAR	P DOWN	RFND	PAYMEN			
HOME	CANCEL	←MORE	MORE→	FAINEN	·	·	

#### · Condiment/Menu keyboard

This keyboard appears when you touch the MENU key in a condiment PLU entry. The Condiment/Menu2 keyboard appears when you touch the MORE key on the

Condiment/Menu keyboard.	KEY002
The Condiment/Menu3 keyboard appears	KEY003
when you touch the MORE-) key on the	1/5)/00.4
Condiment/Menu2 keyboard.	KEY004

					KEY005		KEY010		KEY015
Ţ	1	P UP	VOID	SUB					
MODE	CLEAR	P DOWN	RFND	PAYMEN				W	AIT
HOME	CANCEL	C N	EXT	PATIVIEN	MORE→			FIN	IAL

KEY001

KEY006

KEY007

KEY008

KEY009

KEY011

KEY012

KEY013

KEY014

#### · Function menu 1 (QTY) keyboard

This keyboard appears when you touch the QTY key on the Home, Main2, or Main3 keyboard.

1

CLEAR

CANCEL

P UP P DOWN

	X/TIMES		
7	8	9	
4	5	6	
1	2	3	
0	00	-	
	X/TIMES		

#### · Function menu 2 (DISC.) keyboard

1

MODE

HOME

1

MODE

HOME

This keyboard appears when you touch the DISC. key on the Home, Main2, or Main3 keyboard.

1

CLEAR

CANCEL

P UP

P DOWN

M. FUNC

VOID

RFND

	%	51	%5	(–)3		
	%	52	%6	(-)4		
	%	.3	(-)1	(–)5		
	%	54	(-)2	(-	)6	
	7 8		9	MDS	ST	
SUB	4	5	6			
DAVMEN	1	2	3			
PAYMEN	0	0 00		EN	ΓER	

· Function menu 3 (MISC) keyboard

This keyboard appears when you touch the MISC key on the Home, Main2, or Main3 keyboard.

1

CLEAR

CANCEL

P UP

P DOWN

VOID

RFND

D-THRU

		TAX1SF	PLU	/SB	WAS	STE	
		TAX2SF	RCP	.SW	REP	EAT	
		TAX	RC	PT	RP SND		
		SRV#		MGR#			
		7	8	9			
	SUB	4	5	6			
PAYMEN		1	2	3			
		0	00	-	ENT	ΓER	

· Function menu 4 (G.CHK) keyboard

ļ

MODE

HOME

This keyboard appears when you touch the G.CHK key on the Home, Main2, or Main3 keyboard.

l.					QTY	DISC.	MISC		MGR
					SF	lV#	MGR#		
					7	8	9	N.	C.
Ţ	1	P UP	VOID	SUB	4	5	6	CV	CNT
MODE	CLEAR	P DOWN	RFND	PAYMEN	1	2	3	РВ	AL
HOME	CANCEL	M. F	UNC	PATMEN	0	00	-	ENT	ΓER

· Function menu 5 (MGR) keyboard

ļ

MODE

HOME

This keyboard appears when you touch the MGR key on the Home, Main2, or Main3 keyboard.

1

P UP

CLEAR P DOWN

CANCEL RETURN

	-					
		EM	PL#	SF	M. FUNC	
		E.S	ALE	TIM	E-IN	WASTE
		В	AL	TIMI	#	
		MG	GR#	BRI	NS	
		7	8	9	SE	BTL
VOID	RCP.SW	4	5	6	PAYMEN	IT MENU
RFND	RCPT	1	2	3	EN <sup>-</sup>	ΓER
ST VD	BILL	0	00	-	CA	SH

· Function menu 6 or Function menu 7 keyboard

This keyboard appears when you touch the FUNC® or FUNC? key on the Home, Main2, or Main3 keyboard.

yboard.						
Ţ	1	P UP				
MODE	CLEAR	P DOWN				
HOME	CANCEL		·			

· Payment menu (PAYMENT MENU) keyboard

This keyboard appears when you touch the PAYMENT MENU key on the Home, Main2, or Main3

keyboard	i.					QTY	DISC.	MISC	WAIT
						CI	H1	EATIN1	FINAL
						CI	H2	EATIN2	\$5
						CI	H3	EATIN3	\$10
						7	8	9	\$20
	1	1	P UP	VOID	SUB	4	5	6	NEXT\$
	MODE	CLEAR	P DOWN	RFND	M. FUNC	1	2	3	SBTL
	HOME	CANCEL	ST	VD	IVI. I OINO	0	00	-	CASH

#### · Drive thru (D-THRU) keyboard

This keyboard appears when you touch the billion key on the Home, Main2 or Main3 keyboard.

1	1		N.C.2	WAIT
MODE	CLEAR		PBAL2	RECALL
HOME	CANCEL		SUB	ENTER

#### · PGM/XZ mode keyboard


This keyboard appears when you touch the MODE key on the Home, Main2, or Main3 keyboard.

				1	P UP	MODE	AUT	O21
				Ţ	P DOWN	LIST	AUT	O22
				EMPL#		CANCEL	AUT	O23
				SRV#	X/TIME	CLEAR	AUT	O24
				7	8	9	AUT	O25
				4	5	6	NEXT	HOME
	UPDATE	PREV	CALL	1	2	3	ENTER	
	INS	DEL	BKSPC	0	00	-	CASH	

These keys will not appear in the OPXZ, X1, Z1, X2, or Z2 mode.

#### · Character keyboard

This keyboard is used when you need to enter text data during PGM2 mode entries.



# ■ Function keys list (default keyboard and labels)

Caption (default)	Function			
HOME	Used to return to HOME keyboard.			
CANCEL	Used to cancel your current operation or menu or return to previous menu.			
CLEAR	Used to clear the entered data (amounts/rates/parameters, etc.) and the error state.			
MODE	Used to go to MODE selection window or to return to HOME keyboard.			
1	Used to control the cursor (up arrow).			
1	Used to control the cursor (down arrow).			
←MORE	Used to change the keyboard.			
MORE→	Used to change the keyboard.			
ENTER	Used to select item/menu or entered data.			
SUB	Used to go to the sub-keyboard.			
CASH	Used to enter the direct cash/ amount tendered operation, or to finalize the PGM job.			
0 thru 9	Used to enter a numeric data (0 thru 9).			
00	Used to enter a numeric data (00).			
000	Used to enter a numeric data (000).			
•	Used to enter a fractional part, or to toggle between two or more options.			
X/TIMES	Used to enter a quantity or times.			
SBTL	Used to display subtotals.			
P UP	Used to scroll page up.			
P DOWN	Used to scroll page down.			
BKSPC	Used to backs up the cursor for deleting the character or figure at the left of the cursor.			
DEL	Used to delete a character or figure in the cursor position.			
MDS ST	Used to display the merchandise subtotal.			
TRY ST	Used to display the tray subtotal.			
#	Used to enter a non-add code.			
NS	Used to execute a no-sale function.			
SCALE	Used to enter a weight for the item entry.			
PLU/SB	Used to enter a PLU/subdepartment from the list by using a code.			
L1 thru L10	Used to shift the direct PLU key level (level 1 thru 10).			
P1 thru P5	Used to shift the PLU price level (level 1 thru 5).			
TAX1SF	Used to shift the taxability 1.			
TAX2SF	Used to shift the taxability 2.			
TAX3SF	Used to shift the taxability 3.			
TAX4SF	Used to shift the taxability 4.			
BILL	Used to print the bill.			
RCPT	Used to print the receipt after transaction.			
CH TIP	Used to enter the charge tip.			
CA TIP	Used to enter the cash tip.			
TIP PD	Used to execute the tip paid function.			
VOID	Used to void a last item, or used for the cursor void function.			
I.VOID	Used to void a past item, or used for the cursor void function.			

Caption (default)	Function
ST VD	Used to void an entire transaction (subtotal void).
RFND	Used to enter the refund item.
RETURN	Used to enter the returned item
%1 thru %9	Used to enter the percent calculation (percent 1 thru 9).
(-)1 thru (-)9	Used to execute the discount entry (discount 1 thru 9).
TAX	Used to enter the manual tax.
CV CNT	Used to enter the cover count.
AUTO to AUTO7	Used to enter the automatic sequencing (auto 1 thru auto 7).
\$5	Used to enter the speed tender (\$5).
\$10	Used to enter the speed tender (\$10).
\$20	Used to enter the speed tender (\$20).
AUTO11 to AUTO25	Used to enter the automatic sequencing (auto 11 thru auto 25).
CA2	Used to enter the cash 2 payment.
CHK thru CHK4	Used to enter the check payment (check 1 thru 4).
CH1 thru CH8	Used to enter the charge payment (charge 1 thru 8).
EMP CH	Used to enter the employee charge payment.
CONV1 to CONV4	Used to creates a subtotal in foreign currency (conversion 1 thru 4).
PBAL	Used to lookup the guest check.
PBAL2	Used to lookup the guest check (for drive-thru function).
N.C.	Used to open a new guest check.
N.C.2	Used to open a new guest check (for drive-thru function).
SRVC	Used to finalize the guest check temporarily.
FINAL	Used to finalize the guest check temporarily (with the tax calculation).
DEPO	Used to enter the deposit.
DEP.RF	Used to refund the deposit.
B.T.	Used to enter the bill transfer/ bill totalizing.
RA and RA2	Used to enter the received-on-account (RA 1 and 2).
PO and PO2	Used to enter the paid-out (PO 1 and 2).
SRV#	Used to enter the server code.
MGR#	Used to enter the manager code.
EMPL#	Used to enter the employee code.
EATIN1 thru EATIN3	Used to display the eat-in subtotal (eat-in 1 thru 3).
RP SND	Used to send a partial order to the remote printer.
GRT EX	Used to exempt a customer from the gratuity.
OPN TR	Used to enter the open tare.
BAL	Balance key
REPEAT	Used to repeat a last item entry.
TR.OUT	Used to enter the transfer-out function.
TR.IN	Used to enter the transfer-in function.
PERSN#	Used to enter the person number.
I.PAY	Individual payment key
E.SALE	Used to enter the sales for employees.

Caption (default)	Function
M.FUNC	Used to display the miscellaneous function menu.
RCP.SW	Used to switch the receipt printing state (ON/OFF).
WAIT	Used to shift the corresponding guest check to the wait mode (for drive-thru).
RECALL	Used to re-call the corresponding guest check to the registration mode (for drive-thru).
B.S.	Used to separate the bill.
WASTE	Used to enter/release the WASTE mode.
C NEXT	Used to skip the next table of condiments.
TIME-IN	Used to enter time-in operation.
TIME-OUT	Used to enter time-out operation.
BREAK	Break key
QTY	Used to go to the function menu 1 keyboard (q'ty entry).
DISC.	Used to go to the function menu 2 keyboard (discount/percentage entry).
MISC	Used to go to the function menu 3 keyboard (the miscellaneous function keyboard).
G.CHK	Used to go to the function menu 4 keyboard (guest check entry).
MGR	Used to go to the function menu 5 keyboard (Manager/Server/Employee entry).
FUNC.6	Used to go to the function menu 6 keyboard (empty).
FUNC.7	Used to go to the function menu 7 keyboard (empty).
PAYMENT MENU	Used to go to the payment menu keyboard.
D-THRU	Used to go to the drive-thru menu keyboard (guest check entry for drive-thru).
MENU01 to MENU50	Used to go to the direct PLU menu (menu 1 thru 50).
NEXT\$	Used to enter the next high-dollars (for including-tax subtotal).
ED TIP	Used to edit the tip.

## **How to Use the Touch Panel**

Operations can be performed by touching corresponding key(s) and/or selecting option(s) or item(s) in the window.

NOTE Do not use extreme force when touching the display or the keyboard.

Do not use any sharp or pointed objects, and avoid using your fingernails to touch them.

#### ■ Cursor control by touching option(s) or item(s) in the window

You can select an option or item by using the  $\uparrow$ ,  $\downarrow$  and ENTER keys.


To move the cursor, touch the  $\uparrow$  or  $\downarrow$  key. To select an option or item, touch the ENTER key.

You can also select option(s) or item(s) by touching corresponding line(s) in the window as follows:

#### • In the PGM/XZ mode




To select an option, touch a corresponding line.
 (When you release the touch panel, the option will be selected.)



 To scroll up or down the window, touch the bottom or top of the frame (▼ or ▲).

To scroll down the window

#### In the REG mode




NOTE

- To deselect all of the selected items, touch the CANCEL key.
- To deselect a selected item, touch a corresponding line again.

Indicate items below the receipt window




- The function is performed successively for the bottom line of the selected item.
- If an error occurs, the incorrect item and remaining item(s) cannot be transacted.



## **Server Code Entries**

Prior to an item entry, the server may be compelled to enter his or her assigned server code. However, this may not be necessary when the POS terminal has been programmed for "stay-down server mode."

### Procedure



#### NOTE

- When the server entry system is programmed for "stay-down server mode," no other server can sign on unless the server who has signed on is signed off.
- When the server entry system is programmed for "automatic server sign-off mode," any other server is able to sign on even when some servers have signed on without making entries. At this time the current server is automatically signed off.

The sign-off operation can be performed by using the following procedure in the REG or MGR mode.


To sign off a server: → SRV#

• If the item entry is made when the server has signed off, the server entry pad will open in the window and server entry will be required.


## **Item Selection from the Menu Window**

Your POS terminal allows you to select functions from a menu window. For example, if you want to enter an item for Paid-out 1, select the option "PO" from the "M.FUNC" menu instead of touching the PO key. Each menu can be opened as follows:

#### PLU menu window



#### · Miscellaneous menu window



## **Item Entries**


#### ■ Single item entries

#### **Department entries**

Enter a unit price and touch a department key.

If you use a programmed unit price, touch a department key only.

#### **Procedure**



<sup>\*</sup>Less than the programmed upper limit amount

#### NOTE

When those departments for which the unit price has been programmed as zero (0) are entered with the preset unit price, only the sales quantity is added.

#### **Direct PLU entries (PLU entries)**

Follow this procedure:

#### Procedure

#### FF method (for speedy entries in fast food restaurants)

→ Direct PLU

#### Normal method


When using a programmed unit price

Unit price Direct PLU (for subdept.)

#### PLU menu-based entries (PLU entries and subdepartment entries)

Follow this procedure:


#### **Procedure**



#### PLU number entries (PLU entries and subdepartment entries)

Follow this procedure:

#### **Procedure**



<sup>\*</sup>Less than the programmed upper limit amount

#### NOTE

When those PLUs for which the unit price has been programmed as zero (0) are entered, only the sales quantity is added.

#### Repeat entries

You can use this function for repetitive entries of the same items.

#### Multiplication entries

Use this feature when you need to enter two or more of the same items.

This feature helps you when you sell a large quantity of items or need to enter quantities that contain decimals.


#### **Procedure**

#### FF method (for quick multiplication of direct PLUs)



The FF method cannot be used for a COUPON-LIKE PLU entry.

#### Normal method



- · Q'ty: Up to four-digit integer + three-digit decimal
- · Unit price: Less than a programmed upper limit
- · Q'ty x unit price: Up to seven digits

#### Fast food sale entries

This function is used to enter multiples of sales items with and without the XTIMES key.


#### **Procedure**

#### FF method (for speedy entries in fast food restaurants)



• The FF method cannot be used for a COUPON-LIKE PLU entry.

#### Normal method



- Selling quantity: Up to four-digit integer + three-digit decimal
- · Base quantity: (Programmed)

#### Scale entries


Scale entries may be made by the automatic method only.

The weight is automatically read from the connected scale (option) and appears in the POS terminal display. If you require the auto scale entry function, please contact your authorized SHARP dealer.


#### i) Auto scale entries

#### **Procedure**

#### FF method



#### Normal method



Tare weight: Up to 5 digits (integer + decimal)
Net weight: Up to 5 digits (integer + decimal)


· Base weight: Up to 2 digits (integer)

• Tare number: 1 to 9

#### NOTE

- The POS terminal can be programmed with up to nine tare tables and allows different tares to be assigned to them.
- When the SCALE key is touched, the net weight is automatically read from the connected scale (option) and appears in the POS terminal display.
- When the PLU is programmed for "Compulsory scale entry," it is not necessary to touch the SCALE key.
- To issue a receipt which shows only a tare weight, touch OPN TR, enter a tare weight, then touch SCALE and CASH.

#### ii) Manual scale entries for refunds only



Net weight: Up to 5 digits (integer + decimal) which is from the customer's receipt.

· Base weight: Up to 2 digits (integer)

# **Special Entries for PLUs**

#### ■ Mix-and-match function

This function is convenient for matching several PLU items and selling them at a special price (e.g. bundle sale, multi-packed sale). The base q'ty and unit price are assigned to a mix-and-match table. All items that are programmed into the same table are treated as if they belong to one group.

#### Link PLU entries

The operation is the same as that for normal PLU entries. When a link PLU is entered, the linked PLU's amount is included and the linked PLU's label is printed automatically. Only the 1st-ranking PLU is affected by the tax shift keys (TAXISF), TAXISF) and TAXISF keys). The percent calculation is in effect for the amount of the 1st-ranking PLU.

#### Combo meal entries

The operation is the same as that for normal PLU entries.

When a combo meal is entered with the Combo key, the labels of those PLUs linked to the Combo key are printed automatically. The sum of all adjusted prices (of those PLUs linked to the Combo key) becomes the "combo meal" price setting.



When combo meal is registered, q'ty totalizer of the combo key and amount totalizer of each PLU are updated.

#### ■ PLU level shift (for direct PLUs)

This shift can double or triple the number of direct PLUs on your POS terminal without adding additional direct PLU keys. You can use direct PLUs in ten levels by utilizing the PLU level shift keys L1 thru L10. Level key shifts the PLU level from the other nine to the required level. (The normal level is the level 1.) You must program your machine in the PGM mode to select one of the two PLU level shift modes — automatic return mode\* and lock shift mode\*\* — and decide whether to allow PLU level shift in both the REG and MGR modes or in the MGR mode alone.


- \* The automatic return mode automatically shifts the PLU level back to level 1 after touching a direct PLU key or finalizing each transaction.
- \*\* The lock shift mode holds the current PLU level until a PLU level shift key is touched.

#### Automatic return mode (for PLU levels)

If your terminal has been programmed for PLU level in the automatic return mode, touch a desired PLU level shift key before a numeric entry.

#### **Procedure**

(Returning every item entry)




#### NOTE

When you use the FF method, you need not touch the XTIMES key on numeric entry.

#### Lock shift mode (for PLU levels)

If your terminal has been programmed for PLU level in the lock shift mode, touch a desired PLU level shift key before a numeric entry.

#### **Procedure**



- If you select the automatic return mode (Retuning every item entry), it is not necessary to use the L1 key
  on the keyboard.
- When you use the FF method, you need not touch the XTIMES key for multiplication entries.

#### ■ PLU price level shift

Five different price levels can be programmed for each PLU.

The price levels can be changed for PLU registrations.

These keys have the following functions:


- P1: Shifts the PLU price level from level 2, 3, 4, or 5 to level 1 (base level).
- P2: Shifts the PLU price level from level 1, 3, 4, or 5 to level 2. When you touch this key, the price level shift indicator will turn to "P2."
- P3: Shifts the PLU price level from level 1, 2, 4, or 5 to level 3. When you touch this key, the price level shift indicator will turn to "P3."
- P4: Shifts the PLU price level from level 1, 2, 3 or 5 to level 4. When you touch this key, the price level shift indicator will turn to "P4."
- P5: Shifts the PLU price level from level 1, 2, 3 or 4 to level 5. When you touch this key, the price level shift indicator will turn to "P5."
- \* The automatic return mode automatically shifts the PLU price level back to level 1 after a PLU entry. You can select whether the PLU price level should return each time you enter one item or each time you finalize one transaction.
- \*\* The lock shift mode holds the current PLU price level until touching a price level shift key.

For selection of "automatic return" or "lock shift" modes, please consult your authorized SHARP dealer.

#### Automatic return mode (for price shifts)

If your terminal has been programmed for PLU price level in the automatic return mode, touch a desired price level shift key before a numeric entry.

#### **Procedure**




#### NOTE

When you use the FF method, you need not touch the [XTIMES] key on numeric entry.

#### Lock shift mode (for price shifts)

If your terminal has been programmed for PLU price level in the lock shift mode, touch a desired price level shift key before a numeric entry.

#### Procedure



- If you select the automatic return mode, it is not necessary to use the P1 key on the keyboard, but if you select the lock shift mode, it is necessary to use the key.
- When you use the FF method, you need not touch the [XTIMES] key on numeric entry.

#### Condiment entries

Your terminal may be programmed for prompting condiment and preparatory instructions for a menu-item PLU.

#### Example:

When you enter a menu-item PLU, a prompting message such as "HOWCOOK?" and a list of the "Following PLUs" will appear. You must specify one of the "Following PLUs" such as "without mustard" to meet a special order of the guest. In an example of the condiment table shown below, it is assumed that the condiment table no.1 is assigned to PLU number 21 (programmed text "STEAK") and table no. 4 is assigned to table no. 1 as the next table no. When you enter the PLU number 21, the message "HOWCOOK?" will appear to prompt you to specify one of "RARE," "MED.RARE," and "WELLDONE." If the guest chooses "RARE," select it from the list. Then the next message "POTATO?" will appear to prompt you to specify one of "P.CHIPS," "MASHED.P," and "BAKED.P." If the guest chooses mashed potato, select it. Then touch the CASH] key to end this entry.

Here is an example of how to perform a condiment entry when your condiment table is as shown below.

Table number	PLU numbe	Next table no.				
4	22	23	25	27	4	
ı	(HOWCOOK? 0.00)	(RARE 0.00)	(MED.RARE 0.00)	(WELLDONE 0.00)		
4	31	33	37	38		
	(POTATO? 0.00)	(P. CHIPS 0.60)	(MASHED.P 0.60)	(BAKED.P 0.50)		
Menu-item PLUs	First PLU		Following PLUs			

- Your POS terminal will continue to operate for the condiment entry until you finish the entire condiment entry programmed for the PLU. During the condiment entry, if you enter a normal PLU, which is not in the condiment table, an error message will appear.
- When REPEAT TIMES of the condiment table is programmed either of 2 thru 9, its table shows repeatedly until accomplishment of a programmed times, then the next table will show.
- When the [C NEXT] key is touched, the entry skips to the next table which is programmed.
- When the [CANCE] key is touched, its condiment entry is canceled in the programmed mode (REG/MGR or MGR).
- When you enter a PLU priced at "0.00," only the text will be printed on the receipt.
- No multiplication entry is possible for any condiment entries.
- No refund entry is possible for any condiment entries. When you perform a refund entry with a menu-item PLU, the "First PLU" and the "Following PLUs" assigned to the menu-item PLU are automatically registered as a refund entry.
- You may omit the compulsory condiment entry by touching the SBTL key. (Please consult your dealer for more details.)
- The cursor void entry is allowed for those PLUs that are entered as condiments (menu and condiment).

## **Display of Subtotals**

Your POS terminal provides these five types of subtotals:

#### ■ Merchandise subtotal

Touch the MDS ST key at any point during a transaction.

The net sales subtotal - not including tax - and the symbol "MDSE ST" will appear in the display.

#### ■ Taxable subtotal

#### Taxable 1 subtotal

Touch the TAXISF and SBTL keys in this order at any point during a transaction. The sales subtotal of taxable 1 items will appear in the window and the caption "TAX1" and the tax 1 amount will appear in the outside of the window.

#### Taxable 2 subtotal

Touch the TAX2F and SBTL keys in this order at any point during a transaction. The sales subtotal of taxable 2 items will appear in the window and the caption "TAX2" and the tax 2 amount will appear in the outside of the window.

#### Taxable 3 subtotal

Touch the TAXSF and SBTL keys in this order at any point during a transaction. The sales subtotal of taxable 3 items will appear in the window and the caption "TAX3" and the tax 3 amount will appear in the outside of the window.

#### Taxable 4 subtotal

Touch the TAXASF and SBTL keys in this order at any point during a transaction. The sales subtotal of taxable 4 items will appear in the window and the caption "TAX4" and the tax 4 amount will appear in the outside of the window.

### ■ Including-tax subtotal (full subtotal)

Touch the SBTL key at any point during a transaction. The sales subtotal including tax and the symbol "SUBTOTAL" will appear in the display.

### ■ Tray subtotal

Touch the TRY ST key during a transaction in the REG or MGR mode.

The contents of the tray total itemizer which include tax are printed and displayed.

#### ■ Eat-in subtotal

Touch an eat-in key prior to entering a payment. Your POS terminal will calculate a subtotal according to the programmed tax exemption status and display the subtotal, the symbol "EAT IN," and a corresponding caption ("EAT IN 1," "EAT IN 2," or "EAT IN 3").

For the transaction with the eat-in subtotal, you must finalize the transaction by making a payment entry. Just after touching the eat-in key, however, you can cancel the entry of that key by touching the CLEAR key or another eat-in key.

## **Finalization of Transaction**

#### Cash or check tendering

Touch the SBTL key to get an including-tax subtotal, enter the amount tendered by your customer, then touch the CASH or CAZ key if it is a cash tender or touch the CHK thru CHK4 key if it is a check tender. When the amount tendered is greater than the amount of the sale, your POS terminal will show the change due amount and the symbol "CHANGE." Otherwise your POS terminal will show the symbol "DUE" and a deficit. Make a correct tender entry.

#### NOTE

- Touch the PAYMENT key and select a pertinent check key.
- Mixed tendering (check + cash)

#### ■ Cash or check sale that does not need any tender entry

Enter items and touch the CASH or CA2 key if it is a cash sale or touch the CHK thru CHK4 keys if it is a check sale. Your POS terminal will display the total sales amount.

#### Charge (credit) sale

Enter items and touch the corresponding charge keys (CH1 thru CH8).

#### NOTE

- Amount tendering operations (i.e. change calculations) can be achieved by the CH1 thru CH8 key when PGM2-mode programming allows them.
- Touch the PAYMENT key and select a pertinent charge key.

### ■ Mixed-tender sale (cash or check tendering + charge tendering)

#### NOTE

Touch the CHK thru CHK4 keys or the CH1 thru CH8 keys in place of the CASH key when your customer makes payment by checks or by charge account.

## **Tax Calculations**

#### Automatic tax

When your POS terminal is programmed with a tax table (or tax rate) and the tax status of an individual department or PLU is set for taxable, it computes the tax automatically on any item that is entered into the department directly or indirectly via a related PLU.

#### Manual tax

Your POS terminal allows you to enter tax manually after item entries.

#### ■ Tax deletion

You can delete the automatic tax on the taxable 1, taxable 2, taxable 3, or taxable 4 subtotal of each transaction by touching the corresponding TAX SHIFT key followed by the subtotal, then the TAX key after the subtotal is displayed.

#### NOTE

If any of the media keys (i.e. cash, check 1 thru check 4, or charge 1 thru charge 8) are programmed for tax delete in the PGM2 mode, the tax can be deleted without using the procedures above. In this case touching a corresponding media key that has been programmed will always cause the selected tax to be deleted.

#### ■ Tax status shift

Your POS terminal allows you to shift the programmed tax status of each department, discount, or percent key or of the PLU key by touching the TAXISF, TAXISF, and/or TAXISF keys before those keys are touched. After each entry is completed, the programmed tax status of each key is resumed.

#### NOTE

The entry of a multi-taxable item for PST or GST will be prohibited as follows (for Canada):

In case of; Tax 1: PST, Tax 2: PST,	In case of; Tax 1: PST, Tax 2: PST,
Tax 3: PST, Tax 4: GST	Tax 3: GST, TAX 4: GST
Taxable 1 and 2 item prohibited	Taxable 1 and 2 item prohibited
Taxable 1 and 3 item prohibited	Taxable 1 and 3 itemallowed
Taxable 2 and 3 item prohibited	Taxable 2 and 3 itemallowed
Taxable 1 and 4 itemallowed	Taxable 1 and 4 itemallowed
Taxable 2 and 4 itemallowed	Taxable 2 and 4 itemallowed
Taxable 3 and 4 itemallowed	Taxable 3 and 4 item prohibited

## **Guest Check (GLU/PBLU)**

Two different guest check entry systems are available: the guest lookup (GLU) and previous balance lookup (PBLU) systems. It depends on how your POS terminal has been programmed which of these is used. (Contact your authorized SHARP dealer for this selection.)

GLU system: If this system is selected, the balance due and the details of the order are placed in the

guest check file. The information can be automatically recalled by entering a guest check

code (= a GLU code) when additional ordering occurs.

PBLU system: If this system is selected, the previous balance is stored in the previous balance lookup file

(PB lookup file). The information can be automatically recalled by entering a previous


balance lookup code (= a PBLU code) when additional ordering occurs.

#### ■ GLU/PBLU system

#### **New guest**

For a new guest;

#### **Procedure**



- The GLU/PBLU code refers to a code that will be used whenever the guest check must be accessed for re-ordering or final payment.
- Your POS terminal can be programmed to generate GLU/PBLU codes in a sequential fashion. If your POS terminal has not been programmed to do so, each GLU/PBLU code can be entered manually.
  - \*1 The cover count refers to the number of people in the party. When the cover count entry is compulsory, enter the cover count (max. 2 digits) and touch the ENTER key. When it is non-compulsory, enter the cover count and touch the COUNT key.
  - \*2 The table number indicates a table where the guest will be seated.
  - \*3 The person number is assigned to each person. To enter the first person number, enter the person number (max. 2 digits) and touch the ENTER key. To enter the second person number or later, enter the number and touch the PERSHIP key.
  - \*4 This is the optional function (Temporary finalization).

    You can temporarily finalize a guest check by touching the SRVC or FINAL key. It is recommended to use the SRVC key to temporarily finalize a guest check when printing is not desired and to use the FINAL key when printing the current balance including tax is desired. The guest check, however, is still "open." This means you can still make additional orders to it.


#### NOTE

After a payment operation is achieved, a bill number is created for the closed GLU/PBLU. It is printed on the receipt or journal and printed on the bill when issued. The bill number should be used to refer the closed GLU/PBLU on a sales report.

#### **Reorder entries**

For making additional guest check entries;

#### **Procedure**



#### Settlement

Use the following procedure:

#### **Procedure**

#### NOTE

You can make a tip-in entry before a tender entry. If a tip-in entry is made, the tip amount must be tendered by using the associated media key e.g. CH1 thru CH8 for the charge tip and CASH 1 or CASH 2 for the cash tip.

### ■ Drive-through function

A second GLU/PBLU function can be used as the drive-through function. This system looks up drive-through codes automatically (First In/First Out).

This drive-through system provides three types of POS terminal functions (Order taker, cashier station and counter).

#### **Drive-through screen**


The drive-through screen can be displayed by touching the DTHN key or by finalizing the drive-through registration (refer to PGM: FUNC.SELECTING).

When the HOME, SUB or Function menu key is touched, the screen is changed to the ordinary screen from the drive-through screen. The screen can also be changed to the ordinary screen by beginning the drive-through registration with touching the N.C.2 key.

#### New car

For a new car, open a new drive-through balance (the code is automatically generated).

#### **Procedure**



\* This is the optional function (temporary finalization).
You can temporarily finalize a guest check by touching the FINAL key. Depending upon your terminal's programming this prints out a guest check to show the current balance, including tax. The guest check, however, is still "open." This means you can still make additional orders to it.

#### Reorder entries

For making additional drive-through entries, use the following procedure:

#### Procedure



#### Settlement

Use the following procedure:

#### Procedure

#### NOTE

After a payment operation is achieved, a bill number is created for the closed drive-through. It is printed on the receipt or journal and printed on the bill when issued. The bill number should be used to refer the closed drive-through on a sales report.

#### ■ Deposit entries

Deposit refers to a prepayment on a guest check. It can be received in cash or by check or charge 1 through charge 8.

You can make a deposit entry only when entering a guest check. It cannot be done during handling of a tendered amount.

A received deposit can be refunded by touching the PR key. You cannot attempt to refund an amount larger than the deposit balance.

#### **Procedure**



#### ■ Transferring guest checks out or in (Transfer-in/out)

#### Transferring guest checks out

At the end of a server shift or whenever a server is relieved, one or more open guest checks can be transferred from the server to the open check file until the responsibility for the check(s) is assigned to another server.

#### **Procedure**



#### Transferring guest checks in

When the second server is assigned to be responsible for guest checks that have been transferred out:

#### **Procedure**




#### ■ Bill totalizing/bill transfer

#### Bill totalizing

The bill totalizing function is used to totalize multiple bills when, for example, a particular guest pays not only his or her bill, but also the bills of other guests.

#### **Procedure**




- All #1 bills are added to a #2 bill. A maximum of 5 bills may be added to a #2 bill.
- The GLU/PBLU code of #1 must be in use. If the guest check(s) of #1 or #2 has already been handled by another server, the guest check(s) must have been made "Transferring out."
- After the bill totalizing operation, the individual payment function is not allowed.

#### Bill transfer

This function is used to change the GLU/PBLU code of a particular bill.

#### **Procedure**




#### NOTE

- This function requires that the current GLU/PBLU code be entered for #1 and a new GLU/PBLU code be entered for #2.
- A #1 bill is transferred to a #2 bill. The #1 bill is then cleared and set free.

#### ■ Bill separating

The function is used when each guest of a group pays his or her own order. With this function, you can select some items from a guest check and make an entry for the payment. Also, you can transfer the items you have selected to other guest checks. This function is available only in the GLU system.

#### Procedure



- If the receiving GLU code is not entered during the bill separating operation, it is considered that the payment function has been made by touching the CASH or other payment key.
- If a particular receiving GLU code is already in use, a lock error occurs when that code is entered.
- You cannot specify the quantity of an item for selection when the stored quantity has decimal fraction.

## **Auxiliary Entries**

#### ■ Percent calculations (premium or discount)

- Your POS terminal provides percent calculations for a merchandise subtotal or each item entry. You need
  to specify in advance for which of a merchandise subtotal and each item entry your POS terminal should
  perform a percent calculation.
- For percent calculations (premium, discount, merchandise subtotal or individual), you may use the %1 thru \( \frac{\( \text{\gamma} \)}{\( \text{\gamma} \)} \) key.
- Percentage: 0.01 to 100.00%

NOTE Touch the DISC. key and select a pertinent percent key.

NOTE

- For the ST % entry:
  - The % entry will be allowed only when all PLUs which is associated to the % key have been entered.
- For the Item % entry:
   The % entry will be allowed only for a PLU which is associated to the % key.

**NOTE** Percent calculation operation may be limited to manager only. If you need this function, please consult your authorized SHARP dealer.

#### Discount entries

For discount or coupon tenderings, you may use the (-)1 thru (-)9 keys.

If the discount or tendered coupon is the one applicable to sales, use the vendor coupon; and if it is

applicable to each item entry, use the store coupon.

NOTE Touch the DISC. key and select a pertinent discount key.

NOTE

- For the vendor coupon entry:
   The coupon entry will be allowed only when all PLUs which is associated to the (-) key have been entered.
- For the store coupon entry:
   The coupon entry will be allowed only for a PLU which is associated to the (-) key.

#### Refund entries

If a refunded item is to be entered into a department, enter the amount of the refund, then touch the RFND key and a corresponding department key or open PLU in this order; and if an item entered into a preset PLU is returned, enter a corresponding PLU number, then touch the RFND and PLUSB keys, or touch the RFND and direct PLU keys in this order without entering any PLU number.

#### Return entries

If a returned item is the one entered into a department, enter the amount of the return, then touch the key and a corresponding department key or open PLU in this order; and if an item entered into a preset PLU is returned, enter a corresponding PLU number, then touch the RUNN and PLUSB keys, or touch the RUNN and direct PLU keys in this order without entering any PLU number.

## ■ Printing of non-add code numbers

Enter a non-add code number such as a customer reference number and credit card number within a maximum of 16 digits and touch the # key at any point during the entry of a sale.

#### Remote printer send function

This function enables a partial order to be sent to the kitchen for preparation while the remaining order is still being placed.

## Procedure

Remaining items will be sent to the remote printer when the transaction is finalized.

When this function is used, the subtotal void operation is not allowed.

#### Gratuity

#### Calculation

When the payment operation is made for sales registrations, the gratuity amount is calculated and printed. You can program a percent rate for calculating the gratuity.

If the percent rate is programmed as 0%, the POS terminal does not print any gratuity.

You can program a tax status (taxable 1/taxable 2/taxable 3/taxable 4/non-taxable) for gratuity.

#### Exemption

Your POS terminal allows you to exempt a customer from the gratuity by touching the (GRTEX) key prior to a payment operation.

## **Payment Treatment**

### ■ Tip-in entries

Your POS terminal allows the entry of tips that your guests give to servers in cash or by credit card.


A tip entry must be done before a payment entry.

You must use the corresponding media key e.g. CH1 thru CH8 for the charge tip and CASH 1 or CASH 2 for the cash tip.

You cannot make any previous or credit balance entry after making a tip-in entry.

Two different tip-in entry systems are available: the tip amount entry system and the tip percent rate entry system. It depends on how your POS terminal has been programmed which of these systems is used.

#### Procedure



#### Tip editing

This function is used for entering tip amounts after finalizing a guest check transaction. This function is available when the guest check transaction is finalized in charge tender, and also when the tip is paid in charge tender. The bill number which is issued when the SRVO or FINAL key is touched in guest check entry must be used in order to identify the guest to edit or add tip amount. For the operation, touch the EDTP key. When the display prompt appears, enter the bill number and tip amount.

#### Tip paid entries

This operation is used when tips that guests have paid by using credit card are paid to respective servers in cash. To perform a tip paid entry, enter the server code, then touch the PD key. You can prohibit the tip paid operation in the REG mode by the PGM2 programming.


NOTE

When the tip amount remains unchanged in Individual Server Resetting, the tip paid function is automatically executed and tip receipt is issued to the report printer prior to report printing.

#### **■** Currency conversion

Your POS terminal allows payment entries in foreign currency. Touching the will thru keys creates a subtotal in foreign currency. Cash alone can be handled after currency conversion.

#### **Procedure**




- When the amount tendered is short, its equivalent in deficit is shown in domestic currency.
- Change amount will be displayed in domestic currency.


#### Received-on-account entries

#### **Procedure**

#### **Direct key entries**



#### Menu-based entries




#### NOTE


You may also choose the RA procedure instead of the above procedure only for cash payment. Contact your authorized SHARP dealer to change the procedure.

#### Procedure

#### **Direct key entries**




#### **Menu-based entries**




#### Paid-out entries

#### **Procedure**

#### **Direct key entries**



#### Menu-based entries




#### NOTE

You may also choose the PO procedure instead of the above procedure only for cash payment. Contact your authorized SHARP dealer to change the procedure.

#### **Procedure**

#### **Direct key entries**



#### Menu-based entries



## ■ No-sale (exchange)

Simply touch the NS key without any entry. The drawer will open and the printer will print the caption "NO SALE." If your POS terminal is programmed to allow a non-add code entry and you enter a non-add code number before touching the NS key, a no-sale entry will be achieved with a non-add code number printed.

#### NOTE


You can also enter "No-sale" from the miscellaneous menu window. Touch the MFMC key and select "10 NO SALE" from the window.

#### Cashing a check

Enter the check amount, then touch the CHK thru CHK4 keys.

## Procedure

#### **Direct key entries**



#### Menu-based entries



## **Employee Function**

You can use the following functions by using employee codes:

#### ■ Server/manager sign-on


Servers or managers can be signed on by entering employee codes, or they can be signed on by using employee cards. To use an employee card, you need a magnetic card reader (MCR). Contact your authorized SHARP dealer.

Use the following procedures:

#### • Server sign-on



#### • Manager sign-on




#### **■** Employee's working time recording

You can manage the number of hours for which employees work.

The working time can be recorded by the following operations:

#### Time-in/out and break-in/out operations




#### NOTE

You can select a job location by using the • key or list the selections by touching the LIST key.

#### Time-edit operation


A manager can edit employee's time-in/out data to record his or her time correctly.



### ■ Sales entry for employees

You can track employee purchases by this function. Use the following procedure:

#### To start the sales entry for employees:




#### NOTE

When the item is entered, the limitation check is executed (that the employee sales total is not over the programmed limit). The checking method is:


[Programmed limit amount] [Previous sales total] + [The merchandise subtotal of the current transaction]

#### To pay for charge sales (After entering employee sale function and entering employee code):

• When the cash-only entry is selected:



• When the mixed-media entry is selected:



## **WASTE** mode

This mode is used to throw away an article which has already been prepared and is no longer serviceable.

## Procedure



- PLU entries are only allowed in the WASTE mode, and direct and indirect void operations are also allowed in this mode.
- When a WASTE-mode transaction is finalized, the drawer does not open.
- The consecutive number is incremented every WASTE-mode transaction.
- When the WASTE mode is activated by touching the [WASTE] key, the mode caption "WASTE" is displayed.


REG MODE

MGR MODE

## **Correction of the Last Entry (Direct Void)**

If you make an incorrect entry relating to a department, PLU/subdepartment, percentage ((%1) thru (%9)), discount ((-)1) thru (-)9), manual tax, or tip, you can void this entry by touching the (%0) key immediately.

#### **Example**




## **Correction of the Next-to-Last or Earlier Entries (Indirect Void)**

With the LVOD key you can void any incorrect plus department, plus PLU/subdepartment, or item refund entry made during a transaction if you find it before finalizing the transaction (e.g. before touching the CASH) key). This function is applicable to plus department and PLU/subdepartment entries only.


Example

Indirect void by keyboarding



#### NOTE

To void entries that include a tax status shift, touch the [LVOID] key. [TAX2SF], [TAX2SF], and/or [TAX4SF] keys prior to the [LVOID]




## **Subtotal Void**

With the ST VD key you can void an entire transaction. Once subtotal void is executed, the transaction is canceled and the POS terminal issues a receipt.



## 1310 6 1755 7 10 PLUSB 35 PLUSB

ST VD



## **Correction of Incorrect Entries Not Handled by the Direct or Indirect Void Function**

Any errors found after the entry of a transaction has been completed or during an amount tendered entry, cannot be voided. These errors must be handled by the manager.

The following steps should be taken.

- 1. If you are making an amount tendered entry, finalize the transaction.
- 2. Hand the incorrect receipt to your manager for recording purposes.

8

## **Special Printing Function**

REG MODE

## **Copy Receipt Printing**

If your customer wants a receipt after you have finalized a transaction with the receipt ON-OFF function in the "OFF" status (no receipting), touch the RCPT key. This will make a copy receipt. Your POS terminal can also print a copy receipt when the receipt ON-OFF function is in the "ON" status.

#### NOTE

To toggle the receipt ON-OFF status, use one of the following procedures:

- Select "01 RCP SW." from the window which is opened by touching the MFUNC key.
- Touch the RCP.SW key to open the "RCP SW." window.

#### Example

Printing a copy receipt after making the entries shown below with the receipt ON-OFF function "OFF" status

#### **Key Operation** Print 000002 000003 08/27/03 #1073 11:05AM CASH JACK0001 PL000002 \$12,50 Print on the 3.000@ 11.60 journal PL000003 \$34.80 CASH \$47.30 For receipting → RCPT 08/27/03 123456 #1073 11:05AM JACK0001 PL000002 \$12,50 Print on the receipt 3.000@ 11.60 PL000003 \$34.80 \$47.30 CASH

The "COPY" symbol is printed on the copy receipt.

<b>08/2</b> 7	7/03 11:05AM	123456 Jackooo1
PL000002 PL000003 CASH		* \$12.50 000@ 11.60 \$34.80

## **Manager Mode**

MGR MODE

The manager mode is used when managerial decisions must be made concerning POS terminal entries, for example, for overriding limitations and for other various non-programming managerial tasks.

#### NOTE

Normal POS terminal operations may also be performed in this mode. However, a receipt is issued whether the receipt function is ON or OFF.

## **Entering the Manager Mode**


To enter the manager mode, touch the MGR key, then use the following procedure:

#### Procedure



The manager code is stored in the manager file in advance. If the code entered is not found in this file, an error occurs. If the code is correct, it is printed on the journal and the POS terminal enters the manager mode (the manager is signed on).

The manager is signed off automatically each time a transaction is finalized.



NOTE


If the manager code entry is compelled, the manager entry pad will be opened in the window.

## **Override Entries**

Programmed limits (such as maximum amounts) for functions can be overridden by placing the POS terminal in the manager mode.

#### **Example**

Selling a \$15.00 item (PLU no. 9) for cash and subtracting the coupon amount \$2.50 from the sales amount (This example presumes that the POS terminal has been programmed not to allow coupon entries over \$2.00.)



REG 00

1 PL000009 15.00
(-) 2
1 PL000009 -2.50 MDSE ST 12.50
CASH 12.50

\*\*\*\*\*TOTAL
12.50

CASH 12.50

P1L1


Display

# 10 Correction after Finalizing a **Transaction**

MGR MODE

When you need to void incorrect entries that servers cannot correct (incorrect entries that are found after finalizing a transaction or cannot be corrected by direct or indirect void), follow this procedure in the MGR mode.

- 1. Enter the manager code and touch the MGR# key, then enter the secret code if applicable.
- 2. Touch the VOID key to put your POS terminal in the VOID mode. The background of mode indication "VOID" is colored red. (Note the indication on the display.)
- 3. Repeat the entries that are recorded on an incorrect receipt. (All data in the incorrect receipt is removed from POS terminal memory; the voided amounts are added to the void mode totalizer.)



Your POS terminal leaves the VOID mode when a transaction is completed (i.e. finalized in the VOID mode). To void additional transactions, repeat steps 2. and 3. above.

## Reading (X) and Resetting (Z) of Sales Totals OPXZ MODE

X1 MODE Z1 MODE X2 MODE Z2 MODE

- Use the reading function (X) when you need to take the reading of sales information entered after the last resetting. You can take this reading any number of times. It does not affect the POS terminal's memory.
- Use the resetting function (Z) when you need to clear the POS terminal's memory. Resetting prints all sales information and clears the entire memory except for the GT1 thru GT3, reset count, and consecutive number.
- X1 and Z1 reports show daily sales information. You take these reports in the X1 or Z1 mode.
- X2 and Z2 reports show periodic (monthly) consolidation information. You take these reports in the X2 or Z2 mode.

#### ■ How to take a reading (X1, X2) or resetting (Z1, Z2) report

#### [To take a reading (X1 or X2) report]

- Select "X1 MODE" or "X2 MODE" in the mode menu window to display the report list.
- 2. Select a report from the table shown on the next page.
- 3. If needed, enter corresponding values described in the "Data to be entered" column on the table shown later.
- 4. Select a device ("DISPLAY" or "REPORT PRINTER") to receive the output.

#### [To take a resetting (Z1 or Z2) report]

- Select "Z1 MODE" or "Z2 MODE" in the mode menu window to display the report list.
- 2. Select a report from the table shown on the next page.
- 3. If needed, enter corresponding values described in the "Data to be entered" column on the table shown later.
- 4. Select a device ("DISPLAY" or "REPORT PRINTER") to receive the output. The message "ARE YOU SURE?" will appear. Take one of the following actions:
  - Select "YES" to take a resetting (Z1, Z2) report.
  - Select "NO" to cancel the generation of a resetting (Z1, Z2) report.

NOTE

When a secret code has been set for the corresponding report, enter the secret code and touch the [ENTER] key.

Item	Description	Job code of available report type in each mode				Data to be entered
iteiii	Description	X1	<b>Z</b> 1	X2	Z2	Data to be entered
1 DEPARTMENT	Full department	110	110	210	210	Start department no./end department no.
2 DEPT. IND. GROUP	Individual group total of departments	112		212		Department group no.
3 DEPT. GROUP TOTAL	Full group total of departments	113		213		
4 M-DOWN FOR DEPT.	Department markdown	119		219		Start department no./end department no.
5 PLU	PLU by designated range	120	120	220	220	Start PLU no./end PLU no.
6 PLU BY DEPT	PLU by associated dept.	121	121	221	221	Department no.
7 PLU IND. GROUP				222		PLU group no.
8 PLU GROUP TOTAL	Full group total of PLUs	123		223		
9 PLU STOCK	PLU stock	124				Start PLU no./end PLU no.
10 PLU COST	PLU cost	125		225		Start PLU no./end PLU no.
11 PLU TOP 20	PLU top 20	126		226		Amount or q'ty
12 PLU ZERO SALES	PLU zero sales	127		227		All
SALES	PLU zero sales by department	127		227		Department no.
13 PLU MIN. STOCK	PLU minimum stock	128				Start PLU no./end PLU no.
14 PLU HOURLY GROUP	PLU group by hour	129	129			Start time/end time
15 TRANSACTION	Transaction	130	130	230	230	
16 CID	Cash in drawer	131				
17 TAX	Tax	133		233		
18 ALL SERVER	Full server	140	140	240	240	
19 IND. SERVER	Individual server	141	141	241	241	Server code
		<op xz=""> 41</op>				
20 EMPLOYEE	Employee	155		255	255	Start employee code/end employee code
21 EMP. ACTIVE STS.	Employee active status	157				Start employee code/end employee code
22 HOURLY	Hourly (full)	160				
	Hourly (by range)	160	160			Start time/end time


Item		Description	Job code of available report type in each mode				Data to be entered
		Description	X1	<b>Z</b> 1	X2	Z2	Data to be entered
23 LABO COST		Labor cost %	161				
24 OVER	TIME	Employee over time	162		262	262	Start employee code/end employee code
25 INGRE STOC		Ingredient stock	175				Ingredient table no.
26 GLU		GLU/PBLU	180	180			Start GLU/PBLU code/ end GLU/PBLU code
27 GLU E SERV		GLU PBLU by server	181	181			Server code
28 CLOS	ED GLU	Closed GLU/PBLU	182	182			Start bill number/ end bill number
29 CL-GL SERV	_	Closed GLU/PBLU by server	183	183			Server code
30 DRIVE	ETHRU	Drive-through	185	185			Start drive-through code/ end drive-through code
31 D-THF SERV		Drive-through by server	186	186			Server code
32 CLOS D-THF		Closed drive-through	187	187			Start bill number/ end bill number
33 CL-DT SERV		Closed drive-through by server	188	188			Server code
34 SERV	ICE TIME	Drive-through service time	189	189			
	35 STACKED	Stacked report 1	190	190	290	290	
REPO	PRI	Stacked report 2	191	191	291	291	
36 EMP. ADJUS	STMENT	Employee time adjustment			256		Start employee code/end employee code
	37 EMPLOYEE	Employee sales (detailed)			258	258	
SALES	S	Employee sales (full)				259	
38 EMPL SUMM	OYEE MARY*1	Employee summary			265	265	Start employee code/end employee code
39 PAY P	PERIOD*2	Payment period			266	266	Start employee code/end employee code
40 PAY P SUM.*		Payment period summary			267	267	Start employee code/end employee code
41 DAILY	NET	Daily net			270	270	

<sup>\*1:</sup> Valid only when payment period is set to "NOT USED".

<sup>\*2:</sup> Valid only when payment period is set to "MONTHLY" or "SEMI-MONTHLY".

## **Daily Sales Totals**

#### ■ Transaction report




COMBO20	20	\$15.40	
(-) 5 (-) 6 (-) 7 (-) 8 (-) 9	10 10 10 10	-0. 12 - -0. 21 -0. 22 -0. 35 -0. 36	(-)5 counter and total (Item(-))
(-) TL %5 %6 %7 %8 %9 % TL	10 50 10 10 10 10 50	-1.26 -0.04 -0.06 -0.10 -0.08 -0.07 -0.35 -	Total for item(-)  %5 counter and total (Item %)  Total for item %
CP PLU EAT IN 1	1Q 1Q	-1. 20 - \$30. 25 -	Coupon-like PLU counter and total  Eat-in 1 counter and total
EAT IN 2 EAT IN 3 DIR YD PAST YD SBTL YD MGR YD VOID REFUND RETURN HASH YD HASH RF HASH RT	10 10 20 10 40 10 240 10 20 20	\$61.11 \$55.50 \$15.90 - \$8.90 - \$43.40 - \$31.80 - \$34.98 - \$7.65 - \$1.20 - \$2.40 - \$1.20 -	Direct void counter and total Indirect void counter and total Subtotal void counter and total Manager item void counter and total Void-mode transaction counter and total Refund counter and total Return counter and total Hash item void counter and total Hash item indirect void Hash item refund counter and total Hash item refund counter and total
NO SALE BILL CNT TRAY CNT ***PBAL ***PBAL2 SERVICE SERVICE2 COVER CT TRAN. OUT TRAN IN	2Q — 1Q — 4Q — 9Q — 1Q — 1Q — 88Q — 2Q	\$20.86 <sup>-</sup> \$4.96 <sup>-</sup>	No-sale (exchange) counter  Bill print counter  Tray subtotal print counter  GLU/PBLU counter  Drive-through counter  Service counter (for GLU/PBLU)  Service counter (for drive-through)  Cover counter  Transfer-out counter and total  Transfer-in counter and total
TRANS CT AVE SALE	720 —	\$39. 28	Transaction counter
GRATUITY NET3 HASH TTL WASTE TL	90 110	\$251.78 - \$3093.06 - \$6.40 - -105.70 -	Gratuity total Sales total (including hash dept. total) Hash counter and total Waste counter and total
CASH Cash2 Cash tl	40Q 1Q 41Q	\$2159.06 - \$30.25 - \$2189.31 -	Cash counter and total Cash 2 counter and total Total for cash
***RA ***RA2 RA TL ***PO ***PO2 PO TL	10 10 20 10 10 20	\$150.00 - \$100.00 \$250.00 - \$50.00 - \$60.00 \$110.00 -	Total for received-on-account     Paid-out counter and total


To be continued on the next page

CA/CHK1 CA/CHK2 CA/CHK3	1Q 1Q 1Q	\$50.00 - \$35.00 \$30.00	Check cashing 1 counter and total
CA/CHK4 CA/CK TL CHK/CG CONV 1 CONV 2 CONV 3	1Q 4Q	\$55.00 \$170.00 - \$19.50 - 96.35 - 80.00 50.00	Total for check cashing Cash change total for check and charge 1-8 tendering Currency conversion 1 total (by programmed rate)
CONV 4 CONV TL EMPL CH EMPL CH-	1Q 1Q	80.00 - 306.35 - \$25.25 -8.42	Currency conversion 4 total (by manual rate)  Total for conversion
CHARGE1 CHARGE2- CHARGE2- CHARGE3- CHARGE3- CHARGE4- CHARGE5- CHARGE5- CHARGE6- CHARGE7- CHARGE7- CHARGE8	30 10 10 10 10 10 10 10 10 10	\$78. 4917. 49 - \$47. 14 -26. 51 \$35. 34 -21. 84 \$55. 91 -17. 49 \$30. 25 -16. 83 \$55. 55 -25. 25 \$73. 04 -27. 50 \$68. 70	Gross charge 1 counter and total  Refund charge 1 counter and total
CHARGEB- CHR TL CHECK1 CHECK2 CHECK3 CHECK4 CHECK TL CA+CH ID ****CID	10 180 30 10 10 10 60	-33. 94 \$257. 57 - \$356. 55 - \$61. 57 \$65. 59 \$94. 33 \$578. 04 - \$2528. 35 - \$1950. 31 -	Total for charge Check 1 sale counter and tendering counter  Total for check Cash+check in drawer Cash in drawer
DEPOSIT DPST RF TIP PAID CA TIP CH TIP	10 10 10 20 20	\$50.00 - -20.00 - \$7.00 - \$8.00 - \$7.50 -	Deposit counter and total  Deposit refund counter and total  Tip-paid counter and total  Cash tip-in counter and total  Charge tip-in counter and total


#### Department report




## Individual group total report on departments




# ■ Full group total report on departments



#### ■ Department markdown report




#### PLU report by designated range




#### ■ PLU report by associated department

#### Sample X report



#### Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

Total sales q'ty and total sales amount for price level 1


# ■ Individual group report on PLUs

<b>08/26/03</b> #1328 9:43PM	123456 Jackooo1	
#0122 * <b>* 1</b> * PLU IND. GROUP		Dille
P000002   13.000Q   1000002   13.000Q   4.000Q   4.000Q   10000Q   100000000000000000000000	\$149. 45 - \$31. 80 \$26. 00 \$9. 75 \$43. 40 \$952. 82 \$26. 00 \$17. 40 \$33. 75	PLU no.  Sales q'ty and amount for price level Item label
PL000005 4.000Q PLU GR02 172.000Q	\$22.60 \$1312.97 -	Group 2 sales


# ■ PLU stock report



# ■ Full group total report on PLUs




# ■ PLU cost report



NOTE The cost is calculated from recipe and ingredient table.

# ■ PLU top 20 report


### • By amount




### • By q'ty

<b>08/26</b> #1343	5/ <b>03</b> 9:56PM	123456 Jackooo1
#0126 *> PLU TOP 2 QUANTITY		
P000001 PL000001 PL000001	4. 000Q 3. 000Q 5. 000Q 4. 000Q 75. 000Q 5. 000Q 4. 000Q 4. 000Q	\$17. 40 \$33. 75 \$22. 60 \$85. 86 \$3. 70 \$9. 15 \$9. 80
*20* P000012 PL000012 PL000012 PL000012 PL000012 PL000012	1.000Q 1.000Q 1.000Q 1.000Q 1.000Q	\$1.10 \$1.15
***TOTAL	521.000Q	\$3494.24 \$78.80 \$71.10


# ■ PLU zero sales report (full)



# ■ PLU minimum stock report



# ■ PLU zero sales (by dept.) report




# ■ PLU group total report by hour

### Sample X report

<b>08/26</b> #1352	5/03 10:05PM	123456 Jackooo1	
#0129 * <b>&gt;</b> PLU HOURL	<b>&lt; 1</b> * Y Group		
12:00AM HOUR GR1 HOUR GR2 HOUR GR3 HOUR GR4 HOUR GR5 HOUR GR6 HOUR GR7 HOUR GR8 HOUR GR8	2.000Q 2.000Q 2.000Q 1.000Q 1.000Q 1.000Q 1.000Q 1.000Q	\$9.50 - \$13.75 \$13.75 \$12.50 \$11.60 \$11.60 \$8.25 \$8.25	- PLU hourly group 1 q'ty and amount
HOUR GR1 HOUR GR2 HOUR GR3 HOUR GR4 HOUR GR5 HOUR GR6 HOUR GR7 HOUR GR8 HOUR GR9	10.000Q 8.000Q 8.000Q 10.000Q 10.000Q 10.000Q 10.000Q 10.000Q	\$82.50 \$100.00 \$100.00 \$100.00 \$116.00 \$116.00 \$82.50 \$82.50	
9:30PM HOUR GR1 HOUR GR2 HOUR GR3 HOUR GR4 HOUR GR5 HOUR GR7 HOUR GR7 HOUR GR8	64. 000Q 82. 000Q 82. 000Q 23. 000Q 8. 000Q 8. 000Q 5. 000Q 5. 000Q	\$135. 40 \$255. 92 \$255. 92 \$160. 40 \$50. 42 \$50. 42 \$39. 88 \$39. 88	


### Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# ■ Cash in drawer report

### • Sample X report




# ■ Tax report




# Individual server report

NOTE




When the tip amount remains unchanged in Individual Server Resetting, the tip paid function is automatically executed and a tip receipt is printed on the report printer prior to report printing.

# **■** Full server report




The subsequent printout occurs in the same format as in the sample report shown in the "Individual server report"; and sales data on servers print in this sequence.


# Employee report



# **■** Employee over time report




# **■** Employee active status report




# ■ Hourly report

### Sample X report



### Sample Z report




The subsequent printout occurs in the same format as in the sample X report.


### NOTE

The hourly report can be formatted by 15 min., 30 min., or 1 hour intervals depending upon programming.

# ■ Labor cost % report




# ■ Ingredient stock report




# ■ GLU/PBLU report






# ■ GLU/PBLU report by server

Sample X report




Sample Z report

Sample Z report




# ■ Closed GLU/PBLU report

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# ■ Closed GLU/PBLU report by server

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# Drive-through report

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# **■** Drive-through service time report




# ■ Drive-through report by server

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# Closed drive-through report

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# Closed drive-through report by server

### Sample X report



### Sample Z report



The subsequent printout occurs in the same format as in the sample X report.

# ■ X1/Z1 stacked reports

You can print multiple X1/Z1 reports in sequence by selecting the stacked report option from the menu. In this case, you need to program in advance which X1/Z1 reports should be printed. Refer to "Stacked report" under the section "Report Programming" in Chapter 13.


# **Periodic Consolidation**

Your POS terminal allows you to take consolidation X and Z reports of a chosen period (the period is usually one week or month).

#### · General overview

The periodic reading or resetting reports are the same in format as those in the X1/Z1 report for daily sales information except report no. (#02XX) and mode indication ("X2" or "Z2").


# ■ Transaction report




The subsequent printouts are the same in format as those in the X/Z report on daily totals.

# ■ Daily net report

### Sample X report




### Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# **■** Employee time adjustment report




# ■ Employee sales report (detailed)

### Sample X report




### • Sample Z report



The subsequent printout occurs in the same format as in the sample X report.

# **■** Employee sales report (full)


• Sample Z report




The subsequent printouts are the same in format as those in the detailed report.

# **■** Employee summary report

### Sample X report




### • Sample Z report




The subsequent printout occurs in the same format as in the sample X report.

# Payment period report




# ■ Payment period summary report

### Sample X report



### Sample Z report



The subsequent printout occurs in the same format as in the sample X report.

# ■ X2/Z2 stacked report

You can print multiple X2/Z2 reports in sequence by selecting the stacked report option from the menu. In this case you need to program in advance which X2/Z2 reports should be printed. Refer to "Stacked report" under the section "Report Programming" in Chapter 13.

# 12 How to Use the Programming Keyboard

When the PGM1 or PGM2 mode is selected, the programming keyboard will appear.

# **Programming Keyboard Layout**

			1	P UP	MODE	AUTO21			
			1	P DOWN	LIST	AUTO22			
					CANCEL	AUT	O23		
			SRV#	X/TIME	CLEAR	AUT	O24		
			7	8	9	AUTO25			
			4	5	6	NEXT	HOME		
UP DATE	PREV	CALL	1	2	3	ENT	ER		
INS	DEL	BKSPC	0	00		CA	SH		

												J
					INS	DEL	BKSPC	0	00	•	CASH	
INS BKSPC  DEL	:	Backs termina	up the cal is in the	cursor fo ne inser	or deleti t mode,	ng the c this key	haracte	r or figui s the cha	re at the		he cursor. Whe	•
→		]		ve the c	J							
CALL	:	Used to	o call up	a desir	ed code	э.						
PREV			-	ck to the	-		_	from the	e depart	ment 2 ¡	orogramming w	indow back to
NEXT	:	Used to	•	the next	record	for exa	mple, in	order to	o progra	ım unit p	orices for seque	ential
ENTER	:	Used to	o progra	am each	setting							
CLEAR	:	Used to	o clear t	the last	setting	you hav	e progra	ımmed o	or clear	the erro	r state.	
CANCEL	:	Used to	o cance	l progra	mming	and to g	jet back	to the p	revious	screen.		
PUP	:	Used to	o scroll	the wind	dow to g	o back	to the p	revious	page.			
P DOWN	:	Used to	o scroll	the wind	dow to g	o to the	next pa	age.				
HOME	:	Used to	o go bad	ck to the	HOME	screen						
•	:	Used to	o toggle	betwee	n two c	r more	options.					
LIST	:	Used to	o list the	se optio	ons whi	ch you c	an togg	le by the	e 🔸 k	сеу.		

[CASH]: Used to finalize programming.


Numeric keys: Used for entering figures.

For more information about using these keys, see the "Basic Instructions" selection in Chapter 13 "Programming."

# **How to Program Alphanumeric Characters**

This section discusses how to program alphanumeric characters such as "DESCRIPTION," "NAME" and "TEXT."





# Using character keys on the keyboard

### **Entering alphanumeric characters**

To enter a character, simply touch a corresponding character key on the character keyboard.

### **Entering upper-case letters**

SHIFT]: You can enter an upper-case letter by using this key. Touch this key just before you enter the upper-case letter. You should touch this key each time you enter an upper-case letter.

### **Entering double-size characters**

DC: This key toggles the double-size character mode and the normal-size character mode. The default is the normal-size character mode. When the double-size character mode is selected, the letter "W" appears at the bottom of the display.

# **Editing text**

You can edit the text you have entered by deleting and/or inserting characters.

To select a text editing mode: Use the [INS] key.

To move the cursor: Use the  $\leftarrow$  or  $\rightarrow$  key.

To delete a character or figure: Use the DEL or B.S. key.

# **■** Entering character codes

Numerals, letters and symbols are programmable by touching the ODE key and character codes. Use the following procedure with the cursor placed at the position where you want to enter characters:

CODE → XXX XXX: Character code (3 digits)

# Character code:

	032	033	034	035	036	037	038	039	040	041	042	043	044	045	046	047
032 - 047		ţ	4 /	#	\$	7	&	J	(	)	<del>`</del> ₩	-	J	_		/
	048	049	050	051	052	053	054	055	056	057	058	059	060	061	062	063
048 - 063	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
	064	065	066	067	068	069	070	071	072	073	074	075	076	077	078	079
064 - 079	e	A	В	C	D	E	F	G	Н	I	J	K	L	M	Н	0
	080	081	082	083	084	085	086	087	088	089	090	091	092	093	094	095
080 - 095	P	Q	R	S	T	U	Ų	W	X	Y	Z		•	]	^	_
	096	097	098	099	100	101	102	103	104	105	106	107	108	109	110	111
096 - 111	•	a	Ъ	C	d	C	f	g	h	i	j	k	1	m	n	0
	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
112 - 127	p	q	r	S	t	u	V	W	X	y	Z	-{		}		Δ
	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
128 - 143	Ç	ü	é	â	ä	à	å	G	ê	e	è	1	î	ì	A	Å
	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
144 - 159	É	æ	Æ	ô	ö	ò	û	ù	ij	Ö	Ü	¢	£	¥	R	$ \mathbf{f} $
	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
160 - 175	á	í	Ó	ú	ñ	Ñ	<u> </u>	•	Ł		7	Ŋ٩	4	i	≪	<b>&gt;&gt;</b>
	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
176 - 191					-	1		П	7			1		Ш	4	7
	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
192 - 207	L	┸	<b>T</b>		_	+	│ <b>╞</b>		L	F	1	ĪĪ		=	₩	╅
	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
208 - 223	Ш	T	π	Ш	F	F	П	╫	丰	▋	Г					
	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
224 - 239	Œ	ß	Г	Π	Σ	T	μ	T	Φ	θ	Ω	δ	•	ø	€	П
	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255
240 - 255	≡	<u>+</u>	2	≤	ſ	J	÷	æ	•	-	-	1	n	2		(DC)

\*(DC): Double-size character code

# 13

# **Programming**

UNIT PRICE MODE

PGM1 MODE

PGM2 MODE

AUTO KEY MODE


This chapter explains how to program various items. Before you start programming, select the UNIT PRICE, PGM1, PGM2, or AUTO KEY mode from the mode selection window depending on the item you are going to program.

# **Basic Instructions**

This section illustrates the basic programming by using an example of programming for departments.

# **Procedure**











CANCEL

# ■ Programming example

The following example shows how to program \$2.00 for the unit price, "ABCDE" for the description, and the scale entry to be enabled for department 1.

- 1. In the PGM2 MODE window, select "2 SETTING" by using the 1 or 1 key and touch the ENTER key.
  - · The SETTING window will appear.

### NOTE

- You can also select "2 SETTING" simply by touching a corresponding line in the window.
- You can also select "2 SETTING" by touching the 2 and ENTER keys.
- If you return to the previous screen, touch the CANCEL key.
- 2. Select "1 ARTICLE."
  - The ARTICLE window will appear.


### NOTE

The mark  $(\P)$  in the lower-right corner of the window shows that the window contains more options than are now on the screen. To scroll the window, touch the PDDNN key.


To return to the previous page, touch the PUP key.

- 3. Select "1 DEPT."
  - The DEPT window will appear, listing programmable departments.


[ENTER]
















- **4.** Select "01" to program for department 1.
  - The "01" window will appear.

**5.** On the first page of the "01" window, program the unit price and description as follows:

### NOTE

There are three entry patterns for the programming: the numeric entry, character entry, and selective entry.

- Move the cursor to "PRICE," enter "200" by using numeric keys, then touch the ENTER key. → Numeric entry
- Move the cursor to "DESCRIPTION," enter "ABCDE" by using character keys, then touch the ENTER key. → Character entry

If you want to clear the setting, touch the <code>CLEAR</code> key before you touch the <code>ENTER</code> key.

- **6.** On the first page of the "01" window, program the machine to enable the scale entry as follows:

### NOTE

The ullet key toggles between three options as follows: INHIBIT  $\rightarrow$  ENABLE  $\rightarrow$  COMPULSORY  $\rightarrow$  INHIBIT  $\rightarrow$  .... Touching the LIST key displays all pertinent options.

- **7.** Select one of the following actions:
  - To cancel the programming, touch the MEE key. Select "YES" in the "ARE YOU SURE?" window.
  - To finalize the programming, touch the CASH key, then touch the CANCE key. You will return to the "DEPT" window.
  - To program for the following department, touch the NEXT key. The "02" window will appear. To return to the "01" window, touch the PREV key.

The following sections describe how to program each item which is contained in a programming group.

# **Article Programming**

Use the following procedures to select any option included in the article programming group.

# Procedure




- 1. In the SETTING window, select "1 ARTICLE."
  - The ARTICLE window will appear.









2. Select any option from the following options list:

1 DEPT: Departments 2 PLU: PLUs

3 PLU RANGE: A range of PLUs
4 PLU STOCK: PLU stock quant


4 PLU STOCK: PLU stock quantity
 5 INGREDIENT: Ingredients of PLUs
 6 INGREDIENT STOCK: Ingredient stock quantity

7 LINK PLU TABLE: Link PLU table
8 CONDIMENT TABLE: Condiment table
9 MIX&MATCH TABLE: Mix & match table
0 RECIPE TABLE: Recipe table

11 COMBO MEAL TABLE: Combo meal table

12 SCALE TABLE: Scale table

The following illustration shows those options included in the article programming group.





# Department

Your machine is equipped with 10 standard departments. Use the following procedure to program for departments.

# Procedure

Select a pertinent dept. no. from the departments list.





Program each item as follows:

### NOTE

For more information about the entry patterns, see the "Basic Instructions" section.

### PRICE (Use the numeric entry)

Unit price (max. 6 digits)

### NOTE

When the zero-value department entry (unit price "0") is made, a text of the department is only displayed/printed.

### SIGN (Use the selective entry)

- +: Assigns a plus sign to departments for normal sales transactions.
- Assigns a minus sign for minus transactions.

### • DESCRIPTION (Use the character entry)

Description for a department. Up to 16 characters can be entered.

### • KEY DESCRIPTION (Use the character entry)

Description of the key label for a department. Up to 16 characters can be entered.

### KEY COLOR (Use the selective entry)

Select a key color from the colors list (16 different colors). BLACK/BLUE/GREEN/CYAN/RED/MAGENTA/ORANGE/LIGHT GRAY/SLATE GRAY/DODGER BLUE/LIGHT GREEN/LIGHT CYAN/SALMON/LIGHT MAGENTA/YELLOW/WHITE

### • TARE TABLE No. (Use the numeric entry)

Tare table number associated with scale entry (1 thru 9).

### • SCALE (Use the selective entry)

INHIBIT: Inhibits a scale entry.

COMPULSORY: Makes a scale entry compulsory.

ENABLE: Enables a scale entry.

### • DEPT. TYPE (Use the selective entry)

Department type selection
HASH: Hash department
NORMAL: Normal department

 A hash department is used to enter the amount of a special "sale," such as a gift certificate, etc., i.e. "no-sale" entries.
 Any amounts entered in this department are not added to the grand total exclusive of tax amounts.

# ■ Department (continued)

### AMT. ENTRY TYPE (Use the selective entry)

Type of unit price entry for departments
OPEN & PRESET: Open & preset
PRESET: Preset only
OPEN: Open only
INHIBIT: Inhibited

### • TAXABLE 1 thru 4 (Use the selective entry)

Tax status

NO : Non-taxable YES: Taxable

 When an entry of a taxable department is made in a transaction, tax is automatically computed according to the associated tax table or rate.

### • HALO (Use the numeric entry)

- You can set an upper limit amount (HALO) for each department. The limit is effective for the REGmode operations and can be overridden in the MGR mode.
- AB is the same as A x 10<sup>B</sup>
- A: Significant digit for HALO (1 thru 9)
- B: Number of zeros to follow the significant digit for HALO (0 thru 7)

### • LALO (Use the numeric entry)

- You can set a lower limit amount (LALO). The limit is effective for the REG-mode operations and can be overridden in the MGR mode.
- AB is the same as A x 10<sup>B</sup>
- A: Significant digit for LALO (1 thru 9)
- B: Number of zeros to follow the significant digit for LALO (0 thru 7)

### • SERVER Gr. No. (Use the numeric entry)

Server group number (0 thru 9)

Every department can be assigned to any of the server department groups. The sales total of each department group is printed on the server group.

### GROUP No. (Use the numeric entry)

Group number (0 thru 9)

You can assign departments to a maximum of nine groups. This programming enables you to take group sales reports.

### MODIFIED OUTPUT (Use the selective entry)

NO: Disables output to network remote printers. YES: Enables output to network remote printers.

### OUTPUT KP No. 1 and 2 (Use the numeric entry)

ID number of the network remote printer 1 or 2 (1 thru 9) If the number "0" is entered, no remote printer will operate.

### • CHIT RECEIPT (Use the selective entry)

YES: Prints the department sales information on the chit receipt in the remote printer format.

NO: Prints nothing on the chit receipt.

### CVM CTRL CHAR. (Use the numeric entry)


CVM (Color Video Monitor) control character (0 thru 255)


 This programming enables you to assign each department with a number that can be used as a CVM control character. This number is converted to a two-digit character code that is transmitted for use with a CVM device.


### ■ PLU

### **Procedure**

Select a pertinent PLU no. from the PLUs list.







Program each item as follows:

### ASSOCIATED DEPT. (Use the numeric entry)

Department number to be associated with the entered PLU (01 through 50)

When a PLU is associated with a department, the following functions of the PLU depend on the programming for the department.

- Type (Hash/normal)
- HALO (only for subdepartments)

### • SIGN (Use the selective entry)

- +: Plus PLU/subdepartment
- -: Minus PLU/subdepartment

The function of every PLU/subdepartment varies according to the combination of its sign and the sign of its associated department as follows:

Department: + Serves as a normal plus PLU/subdept.: + PLU/subdepartment

Department:

PLU/subdept.:

- Serves as a normal minus
PLU/subdepartment

Department: + - Accepts store coupon entries, but PLU/subdept.: - - Accepts store coupon entries, but

not split-pricing entries

Department: - Not valid; not accepted + Not valid;

### • PRICE 1 thru 5 (Use the numeric entry)

Unit price of each price level (max. 6 digits).


### • NAME FOR PRICE 1 thru 5 (Use the character entry)


Name for each price level (max. 8 characters). Up to 16 characters can be entered (ex: SMALL, MEDIUM, LARGE, etc.).

### • KEY NAME PRICE 1 thru 5 (Use the character entry)

Description of the key label for each price level. Up to 16 characters can be entered.

# ■ PLU (continued)





The screen continues.

### KEY COLOR (Use the selective entry)

Select a key color from the colors list (16 different colors). BLACK/BLUE/GREEN/CYAN/RED/MAGENTA/ORANGE/LIGHT GRAY/SLATE GRAY/DODGER BLUE/LIGHT GREEN/LIGHT CYAN/SALMON/LIGHT MAGENTA/YELLOW/WHITE

### AMT. ENTRY TYPE (Use the selective entry)

Mode parameter

OPEN & PRESET: PLU/subdepartment mode

PRESET: PLU mode

OPEN: Subdepartment mode

INHIBIT: Inhibit mode

### • BASE QTY (Use the numeric entry)

Base quantity for each PLU/subdepartment which is counted each time the item is entered. (max. 2 digits)

### MINIMUM STOCK (Use the numeric entry)

Minimum stock quantity for a PLU (max. 7 digits)

### • PRICE SHIFT (Use the selective entry)

COMPULSORY: Makes PLU price level shift compulsory.

INHIBIT: Inhibits PLU price level shift. ENABLE: Enables PLU price level shift.

### NOTE

When "COMPULSORY" is selected for a PLU, repeat entries of the PLU are inhibited.

### ZERO PRICE OF P1 thru 5 (Use the selective entry)

ALLOW: Allows a zero-price entry. DISALLOW: Disallows a zero-price entry.

### • CP OBJECT PLU (Use the numeric entry)

Select an object PLU number (max. 6 digits).

A coupon-like PLU is able to link to another PLU (object PLU).

By this programming, the associated coupon PLU cannot be entered unless the object PLU has been rung up.

(However, the quantity is not affected.)

### NOTE

 Any object PLU should not be programmed as a minus PLU or belong to any minus department.

# ■ PLU (continued)

### • MENU TYPE (Use the selective entry)

PLU menu type selection LINK: Link PLU NORMAL: Normal PLU

### • LINK TBL# (Use the numeric entry)

Table number for link PLUs (1 thru 99)

### • MIX&MATCH TBL# (Use the numeric entry)

Table number for mix and match (1 thru 99)

### • CONDIMENT TBL# (Use the numeric entry)

Table number for condiment entry (1 thru 99)

### • RECIPE TBL#1 thru 5 (Use the numeric entry)

Table number for recipe (1 thru 500)

### • TARE TBL# (Use the numeric entry)

Tare table number associated with scale entry (1 thru 9)

### • CONDIMENT TYPE (Use the selective entry)

YES: Condiment type
NO: Non-condiment type

### • CONDIMENT ENTRY (Use the selective entry)

COMPULSORY: Makes a condiment entry compulsory. NON-COMPULSORY: Makes a condiment entry non-compulsory.

### • SCALE (Use the selective entry)

COMPULSORY: Makes a scale entry compulsory.

ENABLE: Enables a scale entry. INHIBIT: Inhibits a scale entry.

#### TAXABLE 1 thru 4 (Use the selective entry)

YES: Makes the PLU taxable.

NO: Makes the PLU non-taxable.

### HOURLY Gr.#1 thru 3 (Use the numeric entry)

PLU group number to classify PLUs for PLU hourly group reports (1 thru 9)

### • GROUP 1 thru 3 (Use the numeric entry)

PLU group number (00 thru 99)

### • PRIORITY GROUP (Use the numeric entry)

PLU group which is to be given the highest priority to in printing on the remote printer (1 thru 9)

### MODIFIED OUTPUT (Use the selective entry)

NO: Will not follow previous PLUs which has the remote printer assignment. YES: Will follow previous PLUs which has the remote printer assignment.

# ■ PLU (continued)

### OUTPUT KP No.1 and 2 (Use the numeric entry)

ID number of the network remote printer 1 or 2 (1 thru 9) If the number "0" is entered, no remote printer will operate.

### CHIT RECEIPT (Use the selective entry)

YES: Prints the PLU sales information on the chit receipt in the remote printer format.

NO: Prints nothing on the chit receipt.


### • CVM CTRL CHAR. (Use the numeric entry)


CVM (Color Video Monitor) control character (0 thru 255)

# ■ PLU range

You can program the PLUs by a range as follows:







The screen continues in the same format as screens shown in section

"■ PLU."

Enter a value or select an option for each item as follows:

### • START (Use the numeric entry)

Starting PLU number (max. 6 digits)

### • END (Use the numeric entry)

Ending PLU number (max. 6 digits)

### • OPERATION (Use the selective entry)

MAINTENANCE: Enables you to change the setting

you have programmed.

NEW&MAINTENANCE: Enables you to change the current

setting when the specified numbers have already been created or to create new numbers when the specified numbers have not been

created yet.


DEL: Enables you to delete a specified

range of PLUs.

# ■ PLU stock

You can assign a stock quantity to each PLU number. Shown below is an example of selecting "1 OVER WRITE."





After selecting "1 OVER WRITE," select a pertinent PLU number. Then the next screen will appear to show the following items:

#### CURRENT STOCK

The current stock is displayed.

#### • NEW STOCK (Use the numeric entry)

Enter a new stock quantity (max. 7 digits: 1 to 9999.999)


# NOTE

- If you need to add or subtract a stock quantity to or from the current stock quantity, select "2 ADD" or "3 SUB" and enter a value to be added or subtracted.
- You cannot enter any values for the item marked with "x."
- The entry of a new stock value will update to the PLU stock counter.

# ■ Ingredient

You can program an ingredient table number, description and cost for the ingredient of each PLU. The ingredient table numbers can be assigned to each recipe table. The cost needs to be programmed to analyze the food cost of each item.





Program each item as follows:

INGREDIENT (Use the numeric entry)
 Ingredient table number (1 thru 300)

#### NOTE

- When you create a new number, enter the number, then touch the ENTER key.
- If the DEL key is touched on the ingredient number selection menu, the ingredient in the cursor position will be deleted.
- DESCRIPTOR (Use the character entry)
   Description for each ingredient. Up to 8 characters can be entered.
- COST (Use the numeric entry)

  Cost for each ingredient (max. 6 digits: 1 thru 999999)


# NOTE

Food cost is calculated by the following equations: Food cost (PLU cost) = (Ingredient cost x Usage q'ty) Food cost% = (Sales q'ty x Food cost)/(Sales amount)

# ■ Ingredient stock

You can assign a stock quantity to each ingredient. Shown below is an example of selecting "2 ADD."





Program each item as follows:

#### • CURRENT STOCK

The current stock is displayed.

#### • ADD VALUE (Use the numeric entry)

Enter a value to be added (max. 7 digits: 1 thru 9999.999).


# NOTE

- If you need of overwrite or subtract a stock quantity to or from the current stock quantity, select "1 OVER WRITE" or "3 SUB" and enter a value to be overwritten or subtracted.
- You cannot enter any values for the item marked with "x."

# ■ Link PLU table

It is possible to link PLUs together so that all PLUs linked together are rung up upon a single key depression. However, the number of links is a maximum of five. Even if more than five PLUs are linked, the sixth or higher link is not actualized.





Program each item as follows:

• LINK PLU TABLE (Use the numeric entry)

Link PLU table number (1 thru 99)

LINKED PLU#X

Select linked PLUs (max. 5 PLUs) from the list.

#### NOTE

- PLU numbers should be defined before programming a link PLU table.
- If the DEL key is touched on the table number selection menu, the selected table will be deleted.

#### Condiment table

The "condiment entry" is intended to guide the operator in making menu entries which require special cooking instructions. For example, a server can make such entries as "garnishing potato," "with salad," and "grilling steak rate." When a server enters a menu-item PLU to which PLUs for the condiment entry have been assigned, these orders (such as "garnishing potato") will be printed on the receipt and conveyed to the kitchen.

Before you program for the condiment entry, prepare a condiment table. The following shows an example of a condiment table:

#### Condiment table

Table number	PLU numbers for condiment entry (programmed text)							
01	22 (HOWCOOK?)	23 (RARE)	25 (MED.RARE)	27 (WELLDONE)		02 -	— ta	
02	41 (WITH?)	44 (SALAD)	45 (FRUITS)					<ul><li>Condiment</li></ul>
=		- - - - -	- - - - - -	- - - - -		-		tables (Up to 99)
04	31 (POTATO?)	33 (P.CHIPS)	37 (MASHED.P)	38 (BAKED.P)		99 _		
99	62 (DRINK?)	63 (TEA)	65 (MILK)	67 (A.JUICE)		_		
	First PLU	Following PLUs (Up to 51)				Next condiment table number		

The condiment table should contain the following:


Condiment table:

The condiment table is a group of condiment PLUs, which is assigned to each menuitem PLU. A table consists of a "First PLU" and "Following PLUs." It can contain one "First PLU" and up to 51 "Following PLUs." Also, you can assign the next condiment table number to a condiment table to link them.

The "First PLU" is used for displaying a prompting message. The "Following PLU" is used for the special order setting. For example, when a server enters a menu-item PLU, a display message programmed for the "First PLU," such as "HOWCOOK?." will appear. Then specify one of the "Following PLUs" programmed for text such as "RARE."

Table number: The table number is intended to identify each condiment table.





Program each item as follows:

#### CONDIMENT TABLE (Use the numeric entry)

Condiment table number (1 thru 99)

#### • REPEAT TIMES


Repeat times (1 thru 9)

When REPEAT TIMES is programmed either of 2 thru 9, its table shows repeatedly until accomplishment of a programmed times, then next table will be shows.

#### NEXT TABLE# (Use the numeric entry)

Enter the next condiment table number (max. 2 digits).

# Condiment table (continued)




#### • PLU#XX (Use the numeric key)


Select condiment PLUs contained in the table (max. 51 PLUs) from the list.

#### NOTE

- The description of the first PLU is used as the display prompt.
- PLU numbers should be defined before programming a condiment table.
- If the DEL key is touched on the table number selection menu, the table in the cursor position will be deleted.

#### Mix & Match table





Program each item as follows:

#### • MIX&MATCH TABLE (Use the numeric entry)

Mix & match table number (1 thru 99)

#### BASE QTY (Use the numeric entry)

Base quantity for each mix & match table (max. 2 digits)

#### • PRICE (Use the numeric entry)

Unit price for each mix & match table (max. 7 digits)


#### NOTE

• If the DEL key is touched on the table number selection menu, the table in the cursor position will be deleted.

# ■ Recipe table

You can make a recipe table which contains up to twenty ingredients.





Program each item as follows:

• RECIPE TABLE (Use the numeric entry)

Recipe table number (1 thru 500)

• INGREDIENT #XX (Use the numeric entry)

Select ingredient numbers (max. 20 ingredients).

• QTY (Use the numeric entry)

Enter the quantity usage of each ingredient (max. 7 digits).


### NOTE


- Ingredient numbers should be defined before programming a recipe table.
- If the DEL key is touched on the table number selection menu, the table in the cursor position will be deleted.


#### Combo meal table


When two or more menu items, consisting of PLUs related to a special offered, are to be programmed together, the combo meal function should be specified. Up to 20 combo keys (tables) can be programmed. And each combo key can be associated with 9 PLUs (items).

# Procedure









Program each item as follows:

# • COMBO MEAL TBL (Use the numeric entry)

Combo meal table number (1 thru 20)

#### COMBO TITLE (Use the character entry)

Title of each combo meal table (max. 16 characters).

### KEY DESCRIPTION (Use the character entry)

Description of the key label for a combo key. Up to 16 characters can be entered.

#### KEY COLOR (Use the selective entry)

Select a key color from the colors list (16 different colors). BLACK/BLUE/GREEN/CYAN/RED/MAGENTA/ORANGE/LIGHT GRAY/SLATE GRAY/DODGER BLUE/LIGHT GREEN/LIGHT CYAN/SALMON/LIGHT MAGENTA/YELLOW/WHITE

#### CONDIMENT TBL# (Use the numeric entry)

Table number for condiment entry (1 thru 99)

#### CONDIMENT ENTRY (Use the selective entry)

COMPULSORY: Makes a condiment entry

compulsory.

NON-COMPULSORY: Makes a condiment entry non-

compulsory.

#### • PRIORITY GROUP (Use the numeric entry)

Combo group which is to be given the highest priority to in printing on the remote printer (1 thru 9).

#### MODIFIED OUTPUT (Use the selective entry)

NO: Will not follow previous PLUs which has the remote printer assignment.

YES: Will follow previous PLUs which has the remote printer assignment.

#### OUTPUT KP No.1 and 2 (Use the numeric entry)

ID number of the network remote printer 1 or 2 (1 thru 9). If the number "0" is entered, no remote printer will operate.

#### • CHIT RECEIPT (Use the selective entry)


YES: Print the combo sales information on the chit receipt in the remote printer format.

NO: Print nothing on the chit receipt.

#### • CVM CTRL CHAR. (Use the numeric entry)

CVM (Color Video Monitor) control character (0 thru 255)

# Combo meal table (continued)



• COMBO PLU#X (Use the numeric entry)

Select associated PLUs (max. 9 PLUs) from the list.

• PRICE (Use the numeric entry)

Unit price of each associated PLU (max. 6 digits).


#### NOTE

- PLU numbers should be defined before programming a combo meal table.
- If the DEL key is touched on the table number selection menu, the programmed data in the cursor position will be deleted.

#### ■ Scale table

The POS terminal can be programmed with up to nine tare tables and allows different tares to be assigned to scalable items (for auto scale entries).





Program each item as follows:

• SCALE TABLE (Use the numeric entry)

Tare table number (1 thru 9)

• WEIGHT (Use the numeric entry)

Enter a tare weight for the scale table number (max. 4 digits: 1 to 99.99).

#### NOTE

Your POS terminal may also be set to accommodate 1-integer + 3-decimal weights. For more details, please consult your authorized SHARP dealer.

# **Direct Key Programming**


Use the following procedures to select direct-key programming:

# **Procedure**



- PGM2 00 DIRECT KEY-1 HOME 2 MAIN2 3 MAIN3 4 SUB 5 SUB2 6 SUB3 7 CONDIMENT/MENU 8 CONDIMENT/MENU2 9 CONDIMENT/MENU3 10 FUNC.MENU01 11 FUNC, MENU02 CANCEL THE
- 1. In the SETTING window, select "2 DIRECT KEY."
  - The DIRECT KEY window will appear.
- **2.** Select a desired keyboard to program from the keyboard list.

PGM2 00



Leads to the programming for each key


# ■ Direct PLU/COMBO/dept. key (except menu PLU/condiment PLU)

You can assign PLUs, combo meals and departments directly to the keyboard. In the case of combo meals or PLUs, you may assign up to 10-levels to be accessed directly on the keyboard.



In the case of setting "000001 DIRECT PLU"

Take **STEP 1** thru **STEP 3** shown above to open the window for programming each direct key.



000016

000000

000000

000000

000000

000000

000000

000000

LEVEL1

LEVEL2

LEVEL3

LEVEL4

LEVEL5 LEVEL6

LEVEL7

LEVEL9

LEVEL10

CANCEL - ENTER

# • TYPE (Use the selective entry)

PLU: Assigns the key as a direct PLU key.

COMBO: Assigns the key as a direct combo key.

DEPT: Assigns the key as a direct department key.

#### NOTE

- When selecting a department, the screen on which a department number is to be entered (the message "DEPT. CODE") will appear.
- When selecting a combo, the screen on which a combo table number is to be entered ("COMBO TBL#") will appear.

#### • LEVEL1 thru 10 (Use the numeric entry)

Enter a PLU number or combo table number for each level. For example, if you want to use this key as PLU no.1 (level 1) and PLU no.101 (level 2), enter 1 for the "LEVEL1" and 101 for the "LEVEL2."

### NOTE

• You cannot assign a PLU, a combo meal, or a department to the position to which a function key has been assigned.


# ■ Direct condiment/menu PLU key

You can assign condiment PLUs or menu PLUs directly to the keyboard up to 50 keys.



In the case of setting "MENU1"

Take **STEP 1** thru **STEP 3** shown above to open the window for programming each direct key.



• KEY NO. (Use the numeric entry)

Enter a menu key number (1 thru 50).

# NOTE

 You cannot assign a condiment/menu PLU to the position to which a function key has been assigned.

# **PLU Menu Key Programming**

Use the following procedures to select PLU menu key programming:

# ■ PLU menu key

When you enter PLUs, using the PLU menu key makes it easy to find categorized PLU items from the menu

Your POS terminal allows you to program a max. of 50 PLU menu keys. You can program a max. of 30 PLUs/sub-menus for each PLU menu key.






Use the following procedure to program a PLU menu key:


In the SETTING window, select "3 PLU MENU KEY" and program each item as follows:











• PLU MENU KEY (Use the numeric entry)

PLU menu key number (1 thru 50) 1 thru 50 : For the direct PLU menu key.

MENU TITLE (Use the character entry)

Description for the PLU menu key. Up to 16 characters can be entered.

TYPE (Use the selective entry)

Selects to program a PLU. MENU: Selects to program a sub-menu.

PLU or MENU (Use the numeric entry)

Select a menu PLU or sub-menu from the list.

#### NOTE

When selecting a sub-menu, the screen on which a sub-menu number is to be entered (the message "MENU") will appear.


#### NOTE

- PLU number should be defined before programming a PLU
- If the DEL key is touched on the menu key number selection menu, the menu list will be canceled.
- If the [DEL] key is touched on the menu PLU number selection menu, the menu in the cursor position will be deleted.

# **Functional Programming**

Use the following procedures to select any option included in the functional programming group:

# Procedure



- 1. In the SETTING window, select "4 FUNCTION."
  - The FUNCTION window will appear.

- PGM2 00


  FUNCTION—
  1 (-)
  2 //
  3 GRATUITY
  4 TIP
  5 RA
  6 PD
  7 MANUAL TAX
  CANCEL—ENIER
- **2.** Select any option from the following options list:

1 (-): Discount key
2 %: Percent key
3 GRATUITY: Gratuity
4 TIP: Tip


5 RA: Received on account 6 PO: Paid out

7 MANUAL TAX: Manual tax

The following illustration shows those options included in the functional programming group.



# ■ **Discount key (**(-)1) thru (-)9)



The screen continues.

Program each item as follows:

#### AMOUNT (Use the numeric entry)

Discount amount (max. 6 digits: 0 to 999999)

#### • TEXT (Use the character entry)

Description for the discount key. Up to 8 characters can be entered.

#### SIGN (Use the selective entry)

Programming of the + or - sign assigns the premium or discount function to each discount key.

- -: Minus amount (discount)
- +: Plus amount (premium)

#### • TAXABLE1 thru 4 (Use the selective entry)

YES: Taxable NO: Non-taxable

# • HALO (High Amount Lockout: use the numeric entry)

A: Significant digit for HALO (1 thru 9)

B: Number of zeros to follow the significant digit for HALO (0 thru 7)

AB is the same as A  $\times$  10<sup>B</sup>.

#### • ENTRY TYPE (Use the selective entry)

ITEM: Item (-) SBTL: Subtotal (-)

#### ASSOCIATED PLU1 thru 20 (Use the numeric entry)

Program PLU number which is allowed for the corresponding (–) key. (1 thru 999999)

#### NOTE

For the Markdown coupon entry (item (-)):

The coupon entry will be allowed only for a PLU which is listed in this table.


For the Discount coupon entry (ST (-)):


The coupon entry will be allowed only when all PLUs which is listed in this table have been entered.

# ■ Percent key ( %1 thru %9 )

# **Procedure**

CANCEL-INII





The screen continues.

Program each item as follows:

#### RATE (Use the numeric entry)

Percent rate (0.00 to 100.00)

#### • TEXT (Use the character entry)

Description for the percent key. Up to 8 characters can be entered.

### • SIGN (Use the selective entry)

Programming of the + or - sign assigns the premium or discount function to each percent key.

- -: Minus (discount)
- +: Plus (premium)

#### • TAXABLE1 thru 4 (Use the selective entry)

YES: Taxable NO: Non-taxable

#### • %HALO (High Amount Lockout: use the numeric entry)

HALO (High Amount Lockout) for the percent key (0.00 to 100.00)

#### ENTRY TYPE (Use the selective entry)

ITEM: Item % SBTL: Subtotal %

# • ASSOCIATED PLU1 thru 20 (Use the numeric entry)

Program the PLU numbers which are allowed for the corresponding % key. (1 thru 999999)

#### NOTE

For the Markdown % entry (item %):


The % entry will be allowed only for a PLU which is listed in this table.

For the Discount % entry (ST %):

The % entry will be allowed only when all PLUs which is listed in this table have been entered.

# Gratuity

# Procedure



Program each item as follows:

#### • RATE (Use the numeric entry)

Percent rate (0.00 to 100.00)

#### • TEXT (Use the character entry)

Description for the gratuity. Up to 8 characters can be entered.

#### • SIGN (Use the selective entry)

Programming of the + or – sign assigns the premium or discount function for the gratuity.


- -: Minus (discount)
- +: Plus (premium)

#### TAXABLE1 thru 4 (Use the selective entry)

YES: Taxable NO: Non-taxable

# ■ Tip

# Procedure



Program each item as follows:

#### • RATE (Use the numeric entry)

Percent rate (0.00 to 100.00)

#### • TEXT(CASH TIP) (Use the character entry)

Description for the cash tip. Up to 8 characters can be entered.

#### • TEXT(CHARGE TIP) (Use the character entry)

Description for the non-cash tip. Up to 8 characters can be entered.

#### • HALO (High Amount Lockout: use the numeric entry)


- A: Significant digit for HALO (1 thru 9)
- B: Number of zeros to follow the significant digit for HALO (0 thru 8)

AB is the same as A  $\times$  10<sup>B</sup>.

#### ■ RA

You can program an upper limit amount and description for each received-on-account key.

# Procedure



Program each item as follows:

- HALO (High Amount Lockout: use the numeric entry)
  - A: Significant digit for HALO (1 thru 9)
  - B: Number of zeros to follow the significant digit for HALO (0 thru 8)

AB is the same as A  $\times$  10<sup>B</sup>.

#### • TEXT (Use the character entry)

Description for the received-on-account key. Up to 8 characters can be entered.

# **■** PO

You can program an upper limit amount and description for each paid-out key.

# Procedure

Select a paid-out key from the PO keys list.

PGM2 00

HALO
TEXT

CANCEL - STIER

Program each item as follows:

#### HALO (High Amount Lockout: use the numeric entry)

- A: Significant digit for HALO (1 thru 9)
- B: Number of zeros to follow the significant digit for HALO (0 thru 8)

AB is the same as A x 10<sup>B</sup>.


#### • TEXT (Use the character entry)

Description for the paid-out key. Up to 8 characters can be entered.

# Manual tax

You can program an upper limit amount and description for the manual tax key.





Program each item as follows:

# • HALO (High Amount Lockout: use the numeric entry)

- A: Significant digit for HALO (1 thru 9)
- B: Number of zeros to follow the significant digit for HALO (0 thru 8)

AB is the same as A  $\times$  10<sup>B</sup>.

# • TEXT (Use the character entry)

Description for the manual tax key. Up to 8 characters can be entered.

# **Media Key Programming**

Use the following procedures to select any option included in the media group:

PGM2 00

# Procedure

MEDIA-1 Cash 2 Check 3 Charge


4 EMPL CHARGE 5 CONVERSION

6 EAT-IN 7 SERVICE

8 FINAL

9 CID 10 CH/CG

11 CA/CK
CANCEL ENTER



- 1. In the SETTING window, select "5 MEDIA."
  - The MEDIA window will appear.


**2.** Select a media key from the following options list:

1 CASH: Cash key
2 CHECK: Check key
3 CHARGE: Charge key

4 EMPL CHARGE: Employee charge key
5 CONVERSION: Currency conversion keys

6 EAT-IN: Eat-in key
7 SERVICE: Service key
8 FINAL: Final key
9 CID: Cash in drawer
10 CH/CG: Check change
11 CA/CK: Check cashing


The following illustration shows those options included in the media key programming group.



- → See "■ Cash key" on page 127.
- See "■ Check key" on page 130.
- See "■ Charge key" on page 133.
- See "■ Employee charge key" on page 136.
- See "■ Currency conversion key" on page 139.
- ⇒ See "■ Eat-in key" on page 139.
- See "■ Service key" on page 140.
- ⇒ See "■ Final key" on page 142.
- See "■ Cash in drawer" on page 144.
- → See "■ Check change" on page 144.
- ⇒ See "■ Check cashing" on page 145.

# Cash key

# Procedure



The screen continues.

Program each item as follows:

#### • TEXT (Use the character entry)

Description for the cash key. Up to 8 characters can be entered.

#### • HALO (High Amount Lockout: use the numeric entry)

AB is the same as A  $\times$  10<sup>B</sup>.

A: Significant digit (1 thru 9)

B: Number of zeros to follow the significant digit (0 thru 8) You can set AB at 18 for no limitation.

#### • GLU/PBLU (Use the selective entry)

GLU/PBLU entry

COMPULSORY: Makes the GLU/PBLU entry

compulsory.

INHIBIT: Inhibits GLU/PBLU entry. ENABLE: Enables GLU/PBLU entry.

#### • SHORT TENDER (Use the selective entry)

Short amount tender

DISABLE: Disables short amount tender. ENABLE: Enables short amount tender.

#### • HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill. NO: Disables header printing on the bill.

#### FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill. NO: Disables footer printing on the bill.

#### CAT OPERATION (Use the selective entry)

You can select compulsory or non-compulsory CAT. Your machine allows you to select CAT1, CAT2, and CAT3.

CAT3 COMPULSORY: Compulsory CAT3
CAT2 COMPULSORY: Compulsory CAT2
CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2/

CAT1.

# • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

# ■ Cash key (continued)

#### • CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

#### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

#### • CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check
TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force

CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

#### • CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

#### • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

#### CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

#### SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

#### • CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

#### • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.

NO: Not prints the card expiration date.

## • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

# ■ Cash key (continued)

#### • CLOSED GC FILE (Use the selective entry)

RETAINED: Retains the closed GLU/PBLU/drive-through finalizing data.

NO RETAINED: Does not retain the closed GLU/PBLU/drive-through finalizing data.

#### • BILL PRINT (Use the selective entry)

Compulsory/non-compulsory bill printing

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

# • FOOTER ON RCPT (Use the selective entry)

This item decides whether or not your POS terminal should print a message at the foot of a receipt when a specified cash key is used.

YES: Enables footer printing on the receipt. NO: Disables footer printing on the receipt.

#### NON-ADD # ENTRY (Use the selective entry)

You can enforce the non-add code entry when a cash entry is accepted.

COMPULSORY: Compulsory non-add code entry NON-COMPULSORY: Non-compulsory non-add code entry

#### • TAXABLE1 thru 4 DELETE (Use the selective entry)

You can program each cash key to delete the tax (i.e. tax 1, tax 2, tax 3, and tax 4) when it finalized a transaction.

YES: Deletes tax X (1 thru 4). NO: Calculates tax X (1 thru 4).

#### • DRAWER OPENING (Use the selective entry)

You can program each cash key to open the drawer.

NO: Disables drawer opening.

YES: Opens the drawer.

#### • AMOUNT ENTRY (Use the selective entry)

You may select compulsory or non-compulsory amount tender.

COMPULSORY: Compulsory amount tendered entry

NON-COMPULSORY: Non-compulsory amount tendered entry

#### • OUTPUT KP No.1 and No.2 (Use the numeric entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.


#### • CHIT RECEIPT (Use the selective entry)

YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

# Check key

#### **Procedure**





The screen continues.

Program each item as follows:

#### TEXT (Use the character entry)

Description for the check key. Up to 8 characters can be entered.

#### • HALO (High Amount Lockout: use the numeric entry)

AB is the same as A  $\times$  10<sup>B</sup>.

A: Significant digit (1 thru 9)

B: Number of zeros to follow the significant digit (0 thru 8)

You can set AB at 18 for no limitation.

# • GLU/PBLU (Use the selective entry)

COMPULSORY: Makes GLU/PBLU entry compulsory.

INHIBIT: Inhibits GLU/PBLU entry. ENABLE: Enables GLU/PBLU entry.

#### SHORT TENDER (Use the selective entry)

DISABLE: Disables short amount tender. ENABLE: Enables short amount tender.

#### • HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill. NO: Disables header printing on the bill.

#### • FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill. NO: Disables footer printing on the bill.

#### CAT OPERATION (Use the selective entry)

CAT3 COMPULSORY: Compulsory CAT3 CAT2 COMPULSORY: Compulsory CAT2 CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2/CAT1

#### • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

#### CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

# ■ Check key (continued)

#### • CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

#### CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check

TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force

CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

#### CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

#### • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

#### CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

### • SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

#### CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

#### • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.
NO: Not prints the card expiration date.

#### • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

#### CLOSED GC FILE (Use the selective entry)

RETAINED: Retains the closed GLU/PBLU/drive-through finalizing data.

NO RETAINED: Does not retain the closed GLU/PBLU/drive-through finalizing data.

#### • BILL PRINT (Use the selective entry)

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

# ■ Check key (continued)

#### • FOOTER ON RCPT (Use the selective entry)

YES: Enables footer printing on the receipt. NO: Disables footer printing on the receipt.

#### NON-ADD # ENTRY (Use the selective entry)

COMPULSORY: Compulsory non-add code entry NON-COMPULSORY: Non-compulsory non-add code entry

#### • CHANGE DUE (Use the selective entry)

Either change enable or disable can be selected for each check key.

DISABLE: Disables change calculation. ENABLE: Enables change calculation.

#### • TAXABLE1 thru 4 DELETE (Use the selective entry)

You can program each check key to delete the tax (i.e. tax 1, tax 2, tax 3, and tax 4) when it finalized a transaction.

YES: Deletes tax X (1 thru 4). NO: Calculates tax X (1 thru 4).

#### DRAWER OPENING (Use the selective entry)

NO: Disables drawer opening. YES: Opens the drawer.

# AMOUNT ENTRY (Use the selective entry)

COMPULSORY: Compulsory amount tendered entry NON-COMPULSORY: Non-compulsory amount tendered entry

#### • OUTPUT KP No.1 and 2 (Use the numeric entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.


#### • CHIT RECEIPT (Use the selective entry)

YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

# Charge key

# Procedure



The screen continues.

Program each item as follows:

#### TEXT(GROSS) (Use the character entry)

Description for the charge (gross) key. Up to 8 characters can be entered.

#### • TEXT(REFUND) (Use the character entry)

Description for the charge (refund) key. Up to 8 characters can be entered.

#### • HALO (High Amount Lockout: use the numeric entry)

AB is the same as A x  $10^{B}$ .

A: Significant digit (1 thru 9)

B: Number of zeros to follow the significant digit (0 thru 8) You can set AB at 18 for no limitation.

#### GLU/PBLU (Use the selective entry)

COMPULSORY: Makes GLU/PBLU entry compulsory.

INHIBIT: Inhibits GLU/PBLU entry. ENABLE: Enables GLU/PBLU entry.

#### • SHORT TENDER (Use the selective entry)

DISABLE: Disables short amount tender. ENABLE: Enables short amount tender.

#### • HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill. NO: Disables header printing on the bill.

#### FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill.
NO: Disables footer printing on the bill.

#### CAT OPERATION (Use the selective entry)

CAT3 COMPULSORY: Compulsory CAT3
CAT2 COMPULSORY: Compulsory CAT2
CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2/

CAT1

#### • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

# ■ Charge key (continued)

#### CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

#### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

#### • CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check

TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force
CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

#### CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

# • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

# • CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

#### • SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

#### • CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

#### • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.
NO: Not prints the card expiration date.

#### • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

# Charge key (continued)

#### • CLOSED GC FILE (Use the selective entry)

RETAINED: Retains the closed GLU/PBLU/drive-through finalizing data.

NO RETAINED: Does not retain the closed GLU/PBLU/drive-through finalizing data.

# • BILL PRINT (Use the selective entry)

Compulsory/non-compulsory bill printing

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

# • FOOTER ON RCPT (Use the selective entry)

YES: Enables footer printing on the receipt. NO: Disables footer printing on the receipt.

#### • NON-ADD # ENTRY (Use the selective entry)

COMPULSORY: Compulsory non-add code entry NON-COMPULSORY: Non-compulsory non-add code entry

#### CHANGE DUE (Use the selective entry)

DISABLE: Disable change calculation. ENABLE: Enables change calculation.

#### • TAXABLE1 thru 4 DELETE (Use the selective entry)

YES: Deletes tax X (1 thru 4). NO: Calculates tax X (1 thru 4).

#### • DRAWER OPENING (Use the selective entry)

NO: Disables drawer opening. YES: Opens the drawer.

#### AMOUNT ENTRY (Use the selective entry)

COMPULSORY: Compulsory amount tendered entry INHIBIT: Inhibits amount tendered entry

#### • OUTPUT KP No.1 and 2 (Use the numeric entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.


#### • CHIT RECEIPT (Use the selective entry)

YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

# Employee charge key

# Procedure



The screen continues.

Program each item as follows:

#### TEXT(GROSS) (Use the character entry)

Description for the charge (gross) key. Up to 8 characters can be entered.

#### • TEXT(REFUND) (Use the character entry)

Description for the charge (refund) key. Up to 8 characters can be entered.

#### HALO (High Amount Lockout: use the numeric entry)

AB is the same as A x  $10^{B}$ .

A: Significant digit (1 thru 9)

B: Number of zeros to follow the significant digit (0 thru 8)

You can set AB at 18 for no limitation.

#### SHORT TENDER (Use the selective entry)

DISABLE: Disables short amount tender. ENABLE: Enables short amount tender.

#### HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill.
NO: Disables header printing on the bill.

#### • FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill. NO: Disables footer printing on the bill.

#### CAT OPERATION (Use the selective entry)

CAT3 COMPULSORY: Compulsory CAT3 CAT2 COMPULSORY: Compulsory CAT2 CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2/CAT1

#### CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

#### CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

#### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

# ■ Employee charge key (continued)

#### • CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check

TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force

CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

#### CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

#### • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

# • CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

# • SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

#### • CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

#### • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.
NO: Not prints the card expiration date.

#### • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

# • BILL PRINT (Use the selective entry)

Compulsory/non-compulsory bill printing

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

#### FOOTER ON RCPT (Use the selective entry)

YES: Enables footer printing on the receipt. NO: Disables footer printing on the receipt.

#### • NON-ADD # ENTRY (Use the selective entry)

COMPULSORY: Compulsory non-add code entry NON-COMPULSORY: Non-compulsory non-add code entry

# **■** Employee charge key (continued)

#### • CHANGE DUE (Use the selective entry)

DISABLE: Disable change calculation. ENABLE: Enables change calculation.

#### • TAXABLE1 thru 4 DELETE (Use the selective entry)

YES: Deletes tax X (1 thru 4). NO: Calculates tax X (1 thru 4).

# • DRAWER OPENING (Use the selective entry)

NO: Disables drawer opening. YES: Opens the drawer.

#### AMOUNT ENTRY (Use the selective entry)

COMPULSORY: Compulsory amount tendered entry INHIBIT: Inhibits amount tendered entry

# • OUTPUT KP No.1 and 2 (Use the numeric entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.

# • CHIT RECEIPT (Use the selective entry)

YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

# ■ Currency conversion key



Program each item as follows:

#### • RATE (Use the numeric entry)

Currency conversion rate (0.0000 to 9999.9999)

# • TEXT (Use the character entry)

Description for the currency conversion key. Up to 8 characters can be entered.

# • DESCRIPTOR (Use the character entry)

Currency descriptor. Up to 4 characters can be entered.

# ■ Eat-in key

# Procedure

Select an eat-in key from the eat-in keys list.

PGM2 00

EAT IN 1

TEXT EAT IN 1

TAXABLE1 DELETE NO TAXABLE2 DELETE NO TAXABLE3 DELETE NO TAXABLE3 DELETE NO TAXABLE4 DELETE NO TAXABL

Program each item as follows:

#### • TEXT (Use the character entry)


Description for the eat-in key. Up to 8 characters can be entered.

# • TAXABLE1 thru 4 DELETE (Use the selective entry)

YES: Deletes tax X (1 thru 4). NO: Calculates tax X (1 thru 4).

# ■ Service key

#### **Procedure**



The screen continues.

Program each item as follows:

#### • TEXT(GLU) (Use the character entry)

Description for the service key (GLU). Up to 8 characters can be entered.

# • TEXT(DRIVE THRU) (Use the character entry)

Description for the service key (drive-through). Up to 8 characters can be entered.

#### • HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill. NO: Disables header printing on the bill.

#### FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill. NO: Disables footer printing on the bill.

#### • BILL PRINT (Use the selective entry)

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

#### • CAT OPERATION (Use the selective entry)

CAT3 COMPULSORY: Compulsory CAT3
CAT2 COMPULSORY: Compulsory CAT2
CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2

#### • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

#### CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

#### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

# Service key (continued)

#### • CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check

TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force

CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

#### CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

#### • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

#### CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

#### • SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

#### • CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

#### • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.

NO: Not prints the card expiration date.

#### NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

#### • OUTPUT KP No.1 and 2 (Use the selective entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.


#### • CHIT RECEIPT (Use the selective entry)

YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

# ■ Final key

#### **Procedure**



The screen continues.

Program each item as follows:

#### HEADER ON BILL (Use the selective entry)

YES: Enables header printing on the bill. NO: Disables header printing on the bill.

#### FOOTER ON BILL (Use the selective entry)

YES: Enables footer printing on the bill. NO: Disables footer printing on the bill.

#### BILL PRINT (Use the selective entry)

COMPULSORY: Compulsory bill printing NON-COMPULSORY: Non-compulsory bill printing

#### • CAT OPERATION (Use the selective entry)

CAT3 COMPULSORY: Compulsory CAT3 CAT2 COMPULSORY: Compulsory CAT2 CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT3/CAT2

#### • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

#### CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

#### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

#### • CAT3 ACTION CODE (Use the selective entry)

Select the CAT3 ACTION CODE from the following items:

COMPANY CHECK: Company check
TIP ENTRY: Tip Entry
DEBIT-FORCE: Debit Force
CREDIT-FORCE: Credit Force
CHECK: Check

POST-AUTH: Post authorization

DEBIT-SALE: Debit Sale

CHG-SALE: Charge Sale (dial up)

## **■** Final key (continued)

## • CAT3 TRANS. TYPE (Use the character entry)

Enter the CAT3 transaction type (max. 3 characters).

## • CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

## • CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

## • SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

## CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

## EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.
NO: Not prints the card expiration date.

## • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

## • OUTPUT KP No.1 and 2 (Use the number entry)

KP number of the network remote printer 1 or 2 (1 digit: 1 to 9) If the number "0" is entered, no remote printer will operate.

## • CHIT RECEIPT (Use the selective entry)


YES: Prints a chit receipt in a remote printer format.

NO: Prints nothing on the chit receipt.

## Cash in drawer

You can program the description and the upper limit amounts for the cash in drawer (sentinel).





Program each item as follows:

• TEXT (Use the character entry)

Description for the cash in drawer. Up to 8 characters can be entered.


• HALO (High Amount Lockout: used the numeric entry)

Limit amount: 0 to 9999999.99

## ■ Check change

You can program the description and the upper limit amounts for the check change.





Program each item as follows:

• TEXT (Use the character entry)

Description for check change. Up to 8 characters can be entered.


• HALO (High Amount Lockout: used the numeric entry)

Limit amount: 0 to 999999.99

## Check cashing

You can program the description and the upper limit amounts for the check cashing.

# Procedure



The screen continues.

Program each item as follows:

#### • TEXT (Use the character entry)

Description for check cashing. Up to 8 characters can be entered.

## HALO (High Amount Lockout: used the numeric entry)

Limit amount: 0 to 999999.99

## • CAT OPERATION (Use the selective entry)

CAT2 COMPULSORY: Compulsory CAT2 CAT1 COMPULSORY: Compulsory CAT1

NON-COMPULSORY: Non-compulsory CAT2/ CAT1

## • CAT1 ACTION CODE (Use the selective entry)

Select the CAT1 ACTION CODE from the following items:

- DEBIT
- DIAL
- NOT TRANSMIT

### • CAT2 ACTION CODE (Use the selective entry)

Select the CAT2 ACTION CODE from the following items:

- AUTH-ONLY
- DIAL
- POST-AUTH

### CAT2 TYPE (Use the selective entry)

Select the CAT2 type from the following items:

- CHECK
- DEBIT
- CREDIT

#### CARD# PRT. (Use the selective entry)

YES: Prints the card number.
NO: Not prints the card number.

#### CARD# FORMAT (Use the selective entry)

FULL: Prints the entire card number.

PARTIAL: Prints only part of the card number.

### SIGN.LINE PRT. (Use the selective entry)

YES: Prints the signature line.
NO: Not prints the signature line.

## • CARD HOLDER PRT. (Use the selective entry)

YES: Prints the name of the card holder.
NO: Not prints the name of the card holder.

## ■ Check cashing (continued)

## • EXPIRATION PRT. (Use the selective entry)

YES: Prints the card expiration date.
NO: Not prints the card expiration date.


## • NUMBER OF RCPT (Use the numeric entry)

Number of authorization receipts to be issued (1 digit: 1 to 9) If the number "0" is entered, no authorization receipt is issued.

# **Text Programming**

Use the following procedures to select any option included in the text group:





- 1. In the SETTING window, select "6 TEXT."
  - The TEXT window will appear.




**2.** Select any option from the following options list:

1 FUNCTION TEXT: Function text

2 DEPT. GROUP: Department group text
3 PLU GROUP: PLU group text
4 PLU HOURLY GR: PLU hourly group text

5 SERVER GROUP: Server group text

The following illustration shows those options included in the text programming group.



- ⇒ See "■ Function text" on page 148.
- See "■ Department group text" on page 150.
- ⇒ See "■ PLU group text" on page 150.
- ⇒ See "■ PLU hourly group text" on page 151.
- → See "■ Server group text" on page 151.

## **■** Function text

You can program a maximum of eight characters for each function by using the following table:

## **Procedure**



The screen continues.

Function no.	Function	Default text
001	Net sales total	NET1
002	Net taxable 1 subtotal	TAX1 ST
003	Gross tax 1 total	GRS TAX1
004	Tax 1 total of refund entries	RFD TAX1
005	Net tax 1 total	TAX1
006	Exempt tax 1	TX1 EXPT
007	Net taxable 2 subtotal	TAX2 ST
008	Gross tax 2 total	GRS TAX2
009	Tax 2 total of refund entries	RFD TAX2
010	Net tax 2 total	TAX2
011	Exempt tax 2	TX2 EXPT
012	Net taxable 3 subtotal	TAX3 ST
013	Gross tax 3 total	GRS TAX3
014	Tax 3 total of refund entries	RFD TAX3
015	Net tax 3 total	TAX3
016	Exempt tax 3	TX3 EXPT
017	Net taxable 4 subtotal	TAX4 ST
018	Gross tax 4 total	GRS TAX4
019	Tax 4 total of refund entries	RFD TAX4
020	Net tax 4 total	TAX4
021	Exempt tax 4	TX4 EXPT
022	Gross manual tax total	GRS MTAX
023	Refund manual tax total	RFD MTAX
024	Exempt total from GST	GST EXPT
025	PST total	PST TTL
026	GST total	GST TTL
027	Tax total	TTL TAX
028	Net	NET

Function no.	Function	Default text
029	Sales total including tax total	NET2
030	COMBO 1 (for transaction report)	COMBO1
031	COMBO 2 (for transaction report)	COMBO2
032	COMBO 3 (for transaction report)	COMBO3
033	COMBO 4 (for transaction report)	COMBO4
034	COMBO 5 (for transaction report)	COMBO5
035	COMBO 6 (for transaction report)	COMBO6
036	COMBO 7 (for transaction report)	COMBO7
037	COMBO 8 (for transaction report)	COMBO8
038	COMBO 9 (for transaction report)	COMBO9
039	COMBO 10 (for transaction report)	COMBO10
040	COMBO 11 (for transaction report)	COMBO11
041	COMBO 12 (for transaction report)	COMBO12
042	COMBO 13 (for transaction report)	COMBO13
043	COMBO 14 (for transaction report)	COMBO14
044	COMBO 15 (for transaction report)	COMBO15
045	COMBO 16 (for transaction report)	COMBO16
046	COMBO 17 (for transaction report)	COMBO17
047	COMBO 18 (for transaction report)	COMBO18
048	COMBO 19 (for transaction report)	COMBO19
049	COMBO 20 (for transaction report)	COMBO20
050	Coupon-like PLU	CP PLU
051	Direct void	DIR VD
052	Past void	PAST VD
053	Subtotal void	SBTL VD
054	Manager void	MGR VD
055	Void mode	VOID
056	Refund	REFUND


# ■ Function text (continued)

Function		
no.	Function	Default text
057	Return	RETURN
058	Hash direct void	HASH VD
059	Hash past void	HA P.VD
060	Hash item refund	HASH RF
061	Hash item return	HASH RT
062	No sale	NO SALE
063	Bill counter	BILL CNT
064	Tray counter	TRAY CNT
065	Drawer counter	DRW CNT
066	Transfer out	TRAN.OUT
067	Transfer in	TRAN.IN
068	Previous balance (for GLU)	***PBAL
069	Previous balance (for drive-through)	***PBAL2
070	Cover count	COVER CT
071	Customer counter	TRANS CT
072	Sales total	NET3
073	Hash net total	HASH TTL
074	Cash+check in drawer	CA+CH ID
075	Deposit	DEPOSIT
076	Deposit refund	DPST RF
077	Tip paid	TIP PAID
078	(+) dept. total	*DEPT TL
079	(-) dept. total	DEPT(-)
080	Hash (+) dept. total	*HASH TL
081	Hash (-) dept. total	HASH(-)
082	Subtotal	SUBTOTAL
083	Merchandise subtotal	MDSE ST
084	Total	***TOTAL
085	Change	CHANGE
086	Due	DUE
087	Tip due	TIP DUE
088	Tray total	TRAY TL
089	Items	ITEMS
090	Balance	BALANCE
091	Сору	COPY
092	B.T. title	B.T.
093	B.S. title	B.S.
094	Final balance	FIN.BAL
095	Balance forward	BAL FWD
096	Close check	CLOSE CK
097	Open check	OPEN CK
098	Percent of net sales	(%)SALES
099	Remaining charge	CHARGE
100	Cost	COST

Function no.	Function	Default text
101	Cost %	COST%
102	Total cost	TTL COST
103	Location #	LOC#
104	Labor cost	L.COST
105	Total hours	TTL HOUR
106	Over time	OVR TIME
107	Time-in	TIME-IN
108	Time-out	TIME-OUT
109	Break-in	BRK-IN
110	Break-out	BRK-OUT
111	Labor %	LABOR%
112	Person code	PERSON#
113	Manager code	MANAGER#
114	Exempt VAT	VAT EXPT
115	Individual payment	IND.PAY
116	Tare weight	TARE WT.
117	Receipt switch	RCP S.W.
118	Free GLU	FREE GLU
119	WASTE title	WASTE
120	Average sales	AVE SALE
121	ST(-) total	ST(-) TL
122	ST% total	ST % TL
123	Item(-) total	(–) TL
124	Item% total	% TL
125	CASH total	CASH TL
126	RA total	RA TL
127	PO total	PO TL
128	CA/CK total	CA/CK TL
129	CONV total	CONV TL
130	CHARGE total	CHR TL
131	CHECK total	CHECK TL
132	COMBO (for PLU report)	COMBO
133	WASTE (for PLU report)	WASTE
134	RF (for PLU report)	RF
135	CP (for PLU report)	CP
136	NET SLS (for PLU report)	NET SLS
137	COMBO TL (for PLU report)	COMBO TL
138	WASTE TL (for PLU report)	WASTE TL
139	RF TL (for PLU report)	RF TL
140	NET TL (for PLU report)	NET TL
141	Over cost	OVR COST
142	GLU text	GLU#
143	Drive thru text	CAR#

## **■** Department group text

You can program a maximum of eight characters for each department group (1~9).




Program the item as follows:

#### • TEXT (Use the character entry)

Description for the department group. Up to 8 characters can be entered.

## ■ PLU group text

You can program a maximum of eight characters for each PLU group (1~99).




Program the item as follows:

## • TEXT (Use the character entry)

Description for the PLU group. Up to 8 characters can be entered.

## ■ PLU hourly group text

You can program a maximum of eight characters for each PLU hourly group (1~9).




Program the item as follows:

## • TEXT (Use the character entry)

Description for the PLU hourly group. Up to 8 characters can be entered.

# ■ Server group text

You can program a maximum of eight characters for each server group (1~9).



Program the item as follows:


## • TEXT (Use the character entry)

Description for the server group. Up to 8 characters can be entered.

# **Personnel Programming**

Use the following procedures to select any option included in the personnel group:





- 1. In the SETTING window, select "7 PERSONNEL."
  - The PERSONNEL window will appear.



**2.** Select any option from the following options list:

1 SERVER: Server
2 MANAGER: Manager
3 EMPLOYEE: Employee

4 JOB LOCATE TBL: Job location table


The following illustration shows those options included in the personnel programming group.


7 PERSONNEL 1 SERVER 2 MANAGER 3 EMPLOYEE 4 JOB LOCATE TBL

- → See "■ Server" on page 153.
- → See "■ Manager" on page 154.
- → See "■ Employee" on page 155.
- See "■ Job location table" on page 156.

## Server

## **Procedure**





Program each item as follows:

• SECRET CODE (Use the numeric entry)

Secret code (max. 4 digits: 0001 to 9999/0000)

NAME (Use the character entry)

Name for the server. Up to 8 characters can be entered.

• ENTRY COMPULSORY (Use the selective entry)

GLU(PBLU): Compulsory GLU(PBLU)
DRIVE THRU: Compulsory drive-through

NON-COMPULSORY: Non-compulsory GLU(PBLU)/drive-

through

• DRAWER# (Use the numeric entry)

Drawer number (1 or 2/0)

• START CODE(GLU) (Use the numeric entry)

Start GLU/PBLU code (max. 8 digits: 1 to 99999999)

• END CODE(GLU) (Use the numeric entry)

End GLU/PBLU code (max. 8 digits: 1 to 99999999)


• NET SALES%RATE (Use the numeric entry)

Net sales percent rate (max. 5 digits: 0.00 to 100.00)

## ■ Manager

You can program a secret code for each manager.






- MANAGER (Use the numeric entry)
   Manager code (max. 2 digits: 01 to 99)
- SECRET CODE (Use the numeric entry)
  Secret code (max. 4 digits: 0001 to 9999/0000)

## ■ Employee

You can program various items for each employee.





The screen continues.

Program each item as follows:

### • EMPLOYEE (Use the numeric entry)

Employee code (max. 10 digits: 000000001 to 999999999)

## • SECRET CODE (Use the numeric entry)

Secret code (max. 4 digits: 0001 to 9999/0000)

## NAME (Use the character entry)

Name for the employee. Up to 12 characters can be entered.

## • \*1 SERVER CODE (Use the numeric entry)

Server code (max. 4 digits: 0001 to 9999)

## • \*2 MANAGER CODE (Use the numeric entry)

Manager code (max. 2 digits: 01 to 99)

## • \*3 DAILY STD. HOURS (Use the numeric entry)

Standard number of hours for which the employee should work a day. (max. 3 digits: 0 to 999)

## • \*3 DAILY OT HOURS (Use the numeric entry)

Number of hours for which the employee may overtime-work a day. (max. 3 digits)

## • \*3 WEEKLY STD. HOURS (Use the numeric entry)

Standard number of hours for which the employee should work a week. (max. 3 digits)

## • \*3 WEEKLY OT HOURS (Use the numeric entry)

Number of hours for which the employee may overtime-work a week. (max. 3 digits)

### • \*4 LOCATION#1 thru #7 (Use the numeric entry)

Job location table number (max. 2 digits: 01 to 99/00)

#### • EMPL SAL. LIMIT (Use the numeric entry)

Program the limitation (HALO) amount for the employee sale.

AB is the same as A x 10<sup>B</sup>.

A: Significant digit (1 thru 9)

B: Number of zero to follow the significant digit (0 thru 8) You can set AB at 18 for no limitation.

### NOTE

The checking method is:

[Programmed limit amount] ≥ [Previous sales total] + [The merchandise subtotal of the current transaction]

## **■** Employee (continued)

## NOTE


- \*1 The server whom an employee code has been assigned cannot sign on unless the corresponding employee clocks in.
- \*2 Assign the manager who is responsible for adjustments to the employee's hours.
- \*3 For the details of these settings, refer to Note on "Job location table" described on the following page.
- \*4 If no job location table number is assigned for an employee time-in operation, job location no. 1 will automatically be assigned.

Make sure to assign a job location table number for "LOCATION#1."

## ■ Job location table

You can program three functions for each job location table number which is assigned to employees.





- JOB LOCATE TBL (Use the numeric entry)
  Job location table number (1 to 99)
- TEXT (Use the character entry)
   Description for the job location table. Up to 8 characters can be entered.
- SALARY AMOUNT (Use the numeric entry)
   Salary amount paid for the employee (max. 4 digits: 0 to 9999)
- \* OVER-TIME RATE-1 (Use the numeric entry)
  Rate 1 for overtime work (max. 3 digits: 0.01 to 9.99)
- \* OVER-TIME RATE-2 (Use the numeric entry)
  Rate 2 for overtime work (max. 3 digits: 0.01 to 9.99)

## Job location table (continued)

## NOTE

- \* You can use job location table settings for corresponding new labor law:
  - Use the job location table for allocation of days of a week; set Monday through Sunday to LOCATION #1 thru LOCATION #7, and set salary amount (per hour) which is paid for standard work hours. For employees' overtime control, you can program overtime rate 1 and overtime rate 2.
  - Overtime rate 1 and 2 are commonly used for employee's daily salary amount calculation and their weekly salary amount calculation.
  - When overtime rate is not set, and when an employee works longer than his or her standard hours, the salary amount is also applied to his or her overtime payment.
  - When overtime rate 2 only is set, overtime payment is calculated using overtime rate 2 rate only. When both the overtime rate 1 and overtime rate 2 are set, the overtime rate 1 is applied to the basic overtime hours set in DAILY OT HOURS and WEEKLY OT HOURS in EMPLOYEE programming, and the overtime rate 2 is applied to overtime hours that exceed the basic overtime hours.
  - However, note that the over time rate is applied only when employee's actual working time (daily and weekly) exceeded the standard number of hours set in DAILY STD HOURS and WEEKLY STD HOURS respectively in EMPLOYEE programming. Also, when both the overtime rate 1 and 2 are set, note that the overtime rate 2 is applied only when employee's overtime work time exceeded his basic overtime hours. Overtime payment is calculated as SALARY AMOUNT x OVER-TIME RATE.


Daily work starting time is controlled by setting in STARTING TIME in Hourly report programming. For example, it is set from 11:00 am, a day starts from 11:00 am and ends 11:00 am of the following day. And, if an employee worked from 10:00 am to 6:00 pm, one hour from 10:00 to 11:00 is calculated as working hour of the previous day.

For an actual operation, each employee must enter the time-in, time-out, break-in and break-out times, and job location number for time-in and break-out entry. (You can either include or exclude employees' break time for their salary amount calculation. For the programming details, refer to "Employee reports".)

# **Terminal Programming**

Use the following procedures to select any option included in the terminal group:

## Procedure



- 1. In the SETTING window, select "8 TERMINAL."
  - The TERMINAL window will appear.


**2.** Select any option from the following options list:

1 MACHINE#: Machine number
2 CONSECUTIVE#: Consecutive number
3 INTERVAL TIMER: Interval timer
4 BILL NUMBER: Bill number

TERMINAL

1 MACHINE#
2 CONSECUTIVE#
3 INTERVAL TIMER
4 BILL NUMBER
CANCEL - ENTER

The following illustration shows those options included in the terminal programming group.




- → See "■ Machine number" on page 159.
- → See "■ Consecutive number" on page 159.
- → See "Interval timer" on page 159.
- ⇒ See "■ Bill number" on page 160.

## ■ Machine number

When your store has two or more POS terminals, it is practical to assign a unique machine number for their identification.





Program the item as follows:


• MACHINE# (Use the numeric entry)

Machine number (max. 6 digits: 0 to 999999)

## **■** Consecutive number

The consecutive number increases by one each time a receipt is issued.





Program the item as follows:


## • CONSECUTIVE# (Use the numeric entry)

Enter a number (max. 4 digits: 0 to 9999) that is one less than a desired starting number.

## Interval timer

You can program the timer for THE TILL TIMER<sup>TM</sup> and the screen save mode timer.





Program each item as follows:

#### • TILL TIMER (Use the numeric entry)

The POS terminal counts the number of times the drawer is left open for longer than a programmed time limit. The counter will be incremented by one each time a programmed time limit is reached. The time limit for THE TILL TIMER<sup>TM</sup> can be preset for 0 to 255 seconds. The count is printed on the transaction report and server report. If the number "0" is entered, this function is unavailable.


## • SCREEN SAVE (Use the numeric entry)

Screen save mode timer (max. 2 digits: 0 to 99 minutes) If the number "0" is entered, the POS terminal will turn the display off after 100 min., if it remains idle.

## **■** Bill number

The consecutive bill number increases each time a bill is issued or GLU/PBLU/drive-through is opened.





Program the item as follows:

• BILL NUMBER (Use the numeric entry)

Enter a number (max. 4 digits: 0 to 9999) that is one less than a desired starting number.


# **Date/Time Setting**

Use the following procedures to set the date and time:

## ■ Date/time

You can set the date and time for the POS terminal.





Set each item as follows:

## • DATE (Use the numeric entry)

Enter the month (2 digits), day (2 digits), and year (2 digits) in this sequence.


## • TIME (Use the numeric entry)

Set the time (max. 4 digits) on the military time (24-hour) system. For example, to set the time to 2:30 AM, enter 0230; and to set the time to 2:30 PM, enter 1430. The time will be printed and displayed on the real-time system. Once you set the time, the internal clock unit will continue to run as long as the battery pack is charged and also update the date (month, day, year) properly.

# **Optional Feature Selection**

Use the following procedures to select any option included in the optional group:

## Procedure



- 1. In the SETTING window, select "10 OPTIONAL."
  - The OPTIONAL window will appear.



**2.** Select any option from the following options list:

1 FUNC.PROHIBIT.: Function prohibition 2 FUNC.SELECTING: Function selection 3 PRINTING SELECT: Printing selection

The following illustration shows those options included in the optional feature programming group.

1 FUNC.PROHIBIT.

2 FUNC.SELECTING

3 PRINTING SELECT

See "■ Function prohibition" on page 163.

⇒ See "■ Function selection" on page 164.

⇒ See "■ Printing selection" on page 165.

## **■** Function prohibition

Your POS terminal allows you to select whether to enable or disable various functions.

Program each item as follows:

## SRV REPO IN OPXZ (Use the selective entry)

DISABLE: Disables a server report printing in the OP X/Z

mode.

ENABLE: Enables a server report printing in the OP X/Z

mode.

### PO ENTRY IN REG (Use the selective entry)

DISABLE: Disables a paid-out entry in the REG mode. ENABLE: Enables a paid-out entry in the REG mode.

## RF/RETURN IN REG (Use the selective entry)

DISABLE: Disables a refund & return entry in the REG

mode.

ENABLE: Enables a refund & return entry in the REG

mode.

## • 1st LAST ITEM VD (Use the selective entry)

DISABLE: Disables first-item direct void. ENABLE: Enables first-item direct void.

## DIRECT VD IN REG (Use the selective entry)

DISABLE: Disables direct void in the REG mode. ENABLE: Enables direct void in the REG mode.

## • INDIR. VD IN REG (Use the selective entry)

DISABLE: Disables indirect void in the REG mode. ENABLE: Enables indirect void in the REG mode.

#### • SBTL VD IN REG (Use the selective entry)

DISABLE: Disables subtotal void in the REG mode. ENABLE: Enables subtotal void in the REG mode.

#### VD MODE IN REG (Use the selective entry)

DISABLE: Disables a void-mode entry in the REG mode. ENABLE: Enables a void-mode entry in the REG mode.

## • (-) ENTRY IN REG (Use the selective entry)

DISABLE: Disables a (–) entry in the REG mode. ENABLE: Enables a (–) entry in the REG mode.

#### NO SALE IN REG (Use the selective entry)

DISABLE: Disables no-sale operation in the REG mode. ENABLE: Enables no-sale operation in the REG mode.

#### PAY WHEN SBTL=0 (Use the selective entry)

DISABLE: Disables finalization in the REG mode when the subtotal is zero. ENABLE: Enables finalization in the REG mode when the subtotal is zero.

## • TIP PAID IN REG (Use the selective entry)

DISABLE: Disables a tip paid entry in the REG mode. ENABLE: Enables a tip paid entry in the REG mode.


## • TR IN/OUT IN REG (Use the selective entry)

DISABLE: Disables transfer in/out in the REG mode. ENABLE: Enables transfer in/out in the REG mode.

## • INDIR. VD IN GLU (Use the selective entry)

DISABLE: Disables the indirect void/refund/return entry at the GLU re-order. ENABLE: Enables the indirect void/refund/return entry at the GLU re-order.

## **Procedure**



The screen continues.

## ■ Function selection

Your POS terminal enables you to select various functional selections.

Program each item as follows:

## • LEVEL SFT METHOD (Use the selective entry)

MANUAL: Lock shift mode

AUTO: Automatic return mode

### LEVEL SFT IN (Use the selective entry)

MGR: Allows PLU level shift only in the MGR mode.
MGR&REG: Allows PLU level shift in the MGR and REG

modes.

## • PRICE SFT METHOD (Use the selective entry)

MANUAL: Lock shift mode

AUTO: Automatic return mode

## • PRICE SFT IN (Use the selective entry)

MGR: Permits PLU price level shift only in the MGR

mode.

MGR&REG: Permits PLU price level shift in the MGR and

REG modes.

## • RETURN TO LEVEL1 (Use the selective entry)

When the PLU level shift system is set to "AUTO," the PLU level can be returned to level 1 by one of the following methods:

BY ONE RECEIPT: Returns the PLU level to level 1 by one receipt. BY ONE ITEM: Returns the PLU level to level 1 by one item.

## • RETURN TO PRICE1 (Use the selective entry)

When the PLU price shift method is set to "AUTO," the price level can be returned to price 1 by one of the following methods:

BY ONE RECEIPT: Returns the price level to price1 by one receipt. BY ONE ITEM: Returns the price level to price 1 by one item.

## • PERSON NUMBER (Use the selective entry)

COMPULSORY: Compulsory person number entry (GLU operations) INHIBIT: Inhibited person number entry (GLU operations)

#### COVER COUNT (Use the selective entry)

COMPULSORY: Compulsory cover count entry (GLU operations)
NON-COMPULSORY: Non-compulsory cover count entry (GLU operations)

#### TABLE NUMBER (Use the selective entry)

COMPULSORY: Compulsory table number entry (GLU operations)
INHIBIT: Inhibited table number entry (GLU operations)

## • TIP ENTRY METHOD (Use the selective entry)

FIX RATE: Tip entry using a programmed rate

AMOUNT: Manual tip entry

#### SRVR DRW ASSIGN (Use the selective entry)

COMPULSORY: Compulsory server drawer assignment at sign-on INHIBIT: Inhibited server drawer assignment at sign-on


## • SHIFT KEY ACTION (Use the selective entry)

CAPS LOCK: Locks the upper-case letter mode once the shift key is touched.

SHIFT: Shifts the upper-case letter mode to the lower-case letter mode after a letter is

entered.

## Procedure



The screen continues.

## Function selection (continued)

## • EMPLOYEE SALE (Use the selective entry)

DETAIL: Selects "DETAIL" for employee sales.

CHARGE AMOUNT: Selects "CHARGE AMOUNT" for employee sales.

### AUTO HOURLY REPO (Use the selective entry)

DISABLE: Disables automatic hourly report. ENABLE: Enables automatic hourly report.

If "ENABLE" is selected, a hourly report may be issued at hourly intervals automatically.

### • DRIVE SCREEN (Use the selective entry)

MANUAL: Only when the function key for the drive-through screen is touched, the drive-through

screen appears.

AUTO: When the drive-through registration is made, the drive-through screen becomes the default

screen automatically. If the function key for the drive-through screen is touched, the drive-

through screen appears also.

## COMP.COND.CANCEL (Use the selective entry)


Select the active mode for the cancel operation from the following items.

MGR&REG: MGR or REG mode MGR: Only MGR mode

## Printing selection

You can program various printing functions.

# Procedure



Program each item as follows:

#### • # OF PURCHASE (Use the selective entry)

PRINT: Prints the number of purchases.

NOT PRINT: Does not print the number of purchases.

## • TIME (Use the selective entry)

NOT PRINT: Does not print the time on the receipt and

journal.

PRINT: Prints the time on the receipt and journal.

### • JOURNAL SELECT (Use the selective entry)

JOURNAL SELECT: Prints the summary information on

the journal.

FULL PRINT: Prints the detailed information on the

journal.

## • JOURNAL LETTER (Use the selective entry)

NORMAL: Prints the normal-size letters on the journal.

SMALL: Prints the compressed-size letters on the journal.

#### • ITEM ON BILL (Use the selective entry)

NOT PRINT: Prints no items in a GLU/PBLU transaction

on the bill printer.

PRINT: Prints items in a GLU/PBLU transaction on

the bill printer.

#### SHARE% (Use the selective entry)

NOT PRINT: Does not print the share percentages on

the department report.

PRINT: Prints the share percentages on the

department report.

# **Secret Code Programming**

Use the following procedures to program a secret code:



- PGM2 00

  SETTING—

  1 ARTICLE

  2 DIRECT KEY

  3 PLU MENU KEY

  4 FUNCTION

  5 MEDIA

  6 TEXT

  7 PERSONNEL


  8 TERMINAL

  9 DATE/TIME

  10 OPTIONAL

  11 SECRET CODE


  CANCEL—ENTER—— [V ]
- 1. In the SETTING window, select "11 SECRET CODE."
  - The SECRET CODE window will appear.



**2.** Select any option from the following options list:

1 Z1: Z1 reports
2 PGM2: PGM2 operations
3 SYS Z1: System Z1 reports
4 SYS PGM2: System PGM2 operations
5 INITIAL D/L: Initial down-loading
6 MAINTENANCE D/L: Maintenance down-loading
7 CAT#2 EXECUTE: CAT#2 execute

The following illustration shows those options included in the secret code programming group.



## ■ Z1 reports


You can assign a secret code for each report.

Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE

If "0" is entered, the "compulsory secret code entry" is inhibited.

## **Procedure**



The screen continues.

## Program each item as follows:

DEPARTMENT	Department report
PLU	PLU report
PLU BY DEPT	PLU by department report
PLU HOURLY GROUP	PLU hourly group report
TRANSACTION	Transaction report
ALL SERVER	All server report
IND. SERVER	Individual server report
HOURLY	Hourly report
GLU	GLU report
GLU BY SERVER	GLU by server report
CLOSED GLU	Closed GLU report
CL-GLU BY SERVER	Closed GLU by server report
DRIVE THRU	Drive-through report
D-THRU BY SERVER	Drive-through by server report
CLOSED D-THRU	Closed drive-through report
CL-DT BY SERVER	Closed drive-through by server report
SERVICE TIME	Service time report
STACKED REPORT	Stacked report

## PGM2-mode operations

You can assign a secret code for each programming operation in the PGM2 mode. Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE If "0" is entered, the "compulsory secret code entry" is inhibited.

# **Procedure**



The screen continues.

	<del> </del>
ARTICLE	Article programming
DIRECT KEY	Direct key programming
PLU MENU KEY	PLU menu key programming
FUNCTION	Function programming
MEDIA	Media programming
TEXT	Text programming
PERSONNEL	Personnel programming
TERMINAL	Terminal programming
DATE/TIME	Date/time programming
OPTIONAL	Optional programming
SECRET CODE	Secret code programming
REPORT	Report programming
LOGO TEXT	Logo programming
PRINTER	Printer programming
GLU CODE	GLU code programming
TAX	Tax programming
FUNCTION KEY	Function key programming
TRAINING	Training mode
DATA SEND	Data send
DATA RECEIVE	Data receive

## ■ System Z1 reports


You can assign a secret code for each system report.

Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE

If "0" is entered, the "compulsory secret code entry" is inhibited.

## **Procedure**



The screen continues.

Program each item as follows:


DEPARTMENT	Department report
PLU	PLU report
PLU BY DEPT	PLU by department report
PLU HOURLY GROUP	PLU hourly group report
TRANSACTION	Transaction report
ALL SERVER	All server report
IND. SERVER	Individual server report
HOURLY	Hourly report
GLU	GLU report
GLU BY SERVER	GLU by server report
CLOSED GLU	Closed GLU report
CL-GLU BY SERVER	Closed GLU by server report
DRIVE THRU	Drive-through report
D-THRU BY SERVER	Drive-through by server report
CLOSED D-THRU	Closed drive-through report
CL-DT BY SERVER	Closed drive-through by server report
SERVICE TIME	Service time report
STACKED REPORT	Stacked report

## **System PGM2-mode operations**

You can assign a secret code for each system programming operation in the PGM2 mode. Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE If "0" is entered, the "compulsory secret code entry" is inhibited.

## **Procedure**



KP SETTING	Kitchen printer setting
ONLINE SETTING	Online setting
CVM SETTING	CVM setting
CAT SETTING	CAT setting
MWS SETTING	Manager work station setting
INLINE SETTING	Inline setting


## ■ Initial down-loading (with clearing of memory)

You can assign a secret code for each preset data to be downloaded. Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE

If "0" is entered, the "compulsory secret code entry" is inhibited.

# Procedure



The screen continues.

Program each item as follows:


DEPT	Department preset
DIRECT KEY	Direct department/PLU preset
PLU	PLU/Link preset
LINK PLU	Link PLU preset
CONDIMENT	Condiment PLU preset
MIX&MATCH	Mix & Match preset
RECIPE	Recipe preset
INGREDIENT	Ingredient preset
PLU MENU KEY	PLU menu key preset
COMBO MEAL	Combo meal preset
TRANSACTION	Transaction preset
MANAGER	Manager preset
OPTION	Other preset
DATE/TIME	Date/time preset
LOGO	Logo text preset
FUNCTION KEY	Function key preset
TAX	Tax preset
ONLINE PRESET	Online preset
INLINE PRESET	Inline preset
KP PRESET	Kitchen printer preset
ALL PGM	All PGM preset

## ■ Maintenance down-loading (without clearing of memory)

You can assign a secret code for each preset data to be downloaded. Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

NOTE If "0" is entered, the "compulsory secret code entry" is inhibited.

## Procedure




DEPT	Department preset
DEPT PRICE	Department price preset
PLU	PLU preset
PLU PRICE	PLU price preset
LINK PLU	Link PLU preset
CONDIMENT	Condiment PLU preset
MIX&MATCH	Mix & Match preset
RECIPE	Recipe preset
INGREDIENT	Ingredient preset
COMBO MEAL	Combo meal preset
TRANSACTION	Transaction preset

## ■ CAT#2 execute

You can assign a secret code for execution of CAT#2. Secret code: max. 4 digits (0001 to 9999/0000) (Use the numeric entry)

**NOTE** If "0" is entered, the "compulsory secret code entry" is inhibited.

## **Procedure**




OPEN BATCH	Open batch processing
CLOSE BATCH	Close batch processing
CLEAR BATCH	Clear batch processing
CHANGE BATCH	Change batch processing
INITIALIZE	Initialization
DIAL OUT	Dial out
DIAL IN	Dial in

# **Report Programming**

Use the following procedures to select any option included in the report group:






- 1. In the SETTING window, select "12 REPORT."
  - The REPORT window will appear.



**2.** Select any option from the following options list:

0 SKIP: Zero skip
 HOURLY RPT: Hourly report
 STACKED RPT: Stacked report
 EMPLOYEE: Employee report

The following illustration shows those options included in the report programming group.




- → See "■ Zero skip" on page 172.
- → See "■ Hourly report" on page 172.
- → See "■ Stacked report" on page 173.
- → See "■ Employee report" on page 176.

## ■ Zero skip

You can program whether or not to skip "0" totals in each report.

# Procedure



Program each item as follows:

## SERVER (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the server report.

SKIP: Skips those data that are "0" sales in the server

report.

#### TRANSACTION (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the transaction report.

SKIP: Skips those data that are "0" sales in the

transaction report.

## DEPARTMENT (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the department report.

SKIP: Skips those data that are "0" sales in the

department report.

## • PLU (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the PLU report.

SKIP: Skips those data that are "0" sales in the PLU

report.

#### . HOURLY (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the hourly report.

SKIP: Skips those data that are "0" sales in the hourly

report.

## • DAILY NET (Use the selective entry)

NOT SKIP: Does not skip those data that are "0" sales in

the daily net report.


SKIP: Skips those data that are "0" sales in the daily

net report.

## ■ Hourly report

You can program the memory type and the starting time for the hourly report.

Procedure



Program each item as follows:

## MEMORY TYPE (Use the selective entry)

15MIN: Selects the 15-minute type.
30MIN: Selects the 30-minute type.
60MIN: Selects the 60-minute type.

## STARTING TIME (Use the numeric entry)

Starting time entry (max. 2 digits: 0 to 23)

NOTE


The hourly report must be cleared to change the memory type.

## Stacked report


Your POS terminal is equipped with the stacked report printing function that enables multiple X/Z reports to be printed in sequence with a single request.

# Procedure

Select a stacked report no. from the stacked reports list.



The screen continues.



The screen continues.

You can select a maximum of twenty reports from the stacked reports list. Some reports must be set with their parameters such as "START CODE" and "END CODE."

## • 01 DEPARTMENT (Use the numeric entry)

Full department report

Parameter: Start department no./end department no. (1 thru 50)

## • 02 DEPT.IND.GROUP (Use the numeric entry)

Individual group report on departments

Parameter: Department group no. (1 thru 9)

## • 03 DEPT.GROUP TOTAL

Full group total report on departments

## • 04 M-DOWN FOR DEPT. (Use the numeric entry)

Markdown for department report

Parameter: Start department no./end department no. (1 thru 50)

### • 05 PLU (Use the numeric entry)

PLU report by designated range

Parameter: Start PLU no./end PLU no. (1 thru 999999)

#### • 06 PLU BY DEPT (Use the numeric entry)

PLU report by associated departments

Parameter: Department no. (1 thru 50)

#### • 07 PLU IND. GROUP (Use the numeric entry)

PLU report by individual group

Parameter: PLU group no. (00 thru 99)

#### 08 PLU GROUP TOTAL

Full group total report on PLUs

## • 09 PLU STOCK (Use the numeric entry)

PLU stock report

Parameter: Start PLU no./end PLU no. (1 thru 999999)

## • 10 PLU COST (Use the numeric entry)

PLU cost report

Parameter: Start PLU no./end PLU no. (1 thru 999999)

## • 11 PLU TOP 20 (Use the numeric entry)

PLU top 20 report

Parameter: AMOUNT/QUANTITY

## ■ Stacked report (continued)

## • 12 PLU ZERO SALES (Use the selective/numeric entry)

PLU zero sales report

Parameter: 1 ALL/2 BY DEPT.

When "2 BY DEPT." is selected, enter a department no. (1 thru 50).

## • 13 PLU MIN. STOCK (Use the numeric entry)

PLU minimum stock report

Parameter: Start PLU no./end PLU no. (1 thru 999999)

## • 14 PLU HOURLY GROUP (Use the numeric entry)

PLU hourly group report

Parameter: Start time/end time (0 thru 2345)

#### 15 TRANSACTION

Transaction report

#### • 16 CID

Cash in drawer report

#### • 17 TAX

Tax report

#### • 18 ALL SERVER

Full server report

#### • 19 IND. SERVER (Use the numeric entry)

Individual server report

Parameter: Server code (1 thru 9999)

## • 20 EMPLOYEE (Use the numeric entry)

Employee report

Start employee code/end employee code (1 thru 999999999)

## • 21 EMP. ADJUSTMENT (Use the numeric entry)

Employee adjustment report

Parameter: Start employee code/end employee code (1 thru 999999999)

## • 22 EMP. ACTIVE STS. (Use the numeric entry)

Employee active status report

Parameter: Start employee code/end employee code (1 thru 999999999)

## • 23 EMP.SALE(DETAIL) (Use the numeric entry)

Detailed employee sales report

Parameter: Start employee code/end employee code (1 thru 999999999)

## • 24 EMP.SALE(ALL CL) (Use the numeric entry)

Employee sales (limited) report

Parameter: Start employee code/end employee code (1 thru 999999999)

## ■ Stacked report (continued)

## • 25 HOURLY (Use the numeric entry)

Hourly report

Parameter: Start time/end time (0 thru 2345)

### NOTE

To take the hourly Z report, you have to specify the full-range hourly report.

#### • 26 LABOR COST%

Labor cost percent report

#### • 27 OVER TIME (Use the numeric entry)

Employee over time report

Parameter: Start employee code/end employee code (1 thru 999999999)

## • 28 EMPLOYEE SUMMARY (Use the numeric entry)

Employee summary report

Parameter: Start employee code/end employee code (1 thru 999999999)

## • 29 PAY PERIOD (Use the numeric entry)

Payment period report

Parameter: Start employee code/end employee code (1 thru 999999999)

#### • 30 PAY PERIOD SUM. (Use the numeric entry)

Payment period summary report

Parameter: Start employee code/end employee code (1 thru 999999999)

#### • 31 DAILY NET

Daily net report

## • 32 INGREDIENT STOCK (Use the numeric entry)

Ingredient stock report

Parameter: Start ingredient code/end ingredient code (1 thru 999)

## • 33 GLU (Use the numeric entry)

GLU/PBLU report

Parameter: Start GLU code/end GLU code (1 thru 99999999)

## • 34 GLU BY SERVER (Use the numeric entry)

GLU/PBLU report by server

Parameter: Server code (1 thru 9999/Up to 255 servers can be assigned.)

## • 35 CLOSED GLU (Use the numeric entry)

Closed GLU/PBLU report

Parameter: Start bill number/end bill number (1 thru 9999)

## • 36 CL-GLU BY SERVER (Use the numeric entry)

Closed GLU/PBLU report by server

Parameter: Server code (1 thru 9999/Up to 255 servers can be assigned.)

## • 37 DRIVE THRU (Use the numeric entry)

Drive-through report

Parameter: Start drive-through code/end drive-through code (1 thru 99999999)

## Stacked report (continued)

## • 38 D-THRU BY SERVER (Use the numeric entry)

Drive-through report by server

Parameter: Server code (1 thru 9999/Up to 255 servers can be assigned.)

#### • 39 CLOSED D-THRU (Use the numeric entry)

Closed drive-through report

Parameter: Start bill number/end bill number (1 thru 9999)

### 40 CL-DT BY SERVER (Use the numeric entry)

Closed drive-through report by server

Parameter: Server code (1 thru 9999/Up to 255 servers can be assigned.)

#### • 41 SERVICE TIME

Drive-through service time report

## ■ Employee report

You can program items for payment for the employees' salary.



PGM2 EMPL NYEE PAYMENT PERIOD PERIOD-1 START PERIOD-2 START 01 PAY FOR BREAK

Program each item as follows:

## PAYMENT PERIOD (Use the selective entry)

NOT USED: Does not specify payment period. MONTHLY: Payment is done once a month. SEMI-MONTHLY: Payment is done twice a month.

## • PERIOD-1 START (Use the numeric entry)

Starting day of payment for monthly payment, or starting day of first-half payment for semi-monthly payment.

#### PERIOD-2 START (Use the numeric entry)

Starting day of second-half payment for semi-monthly payment.

#### PAY FOR BREAK (Use the selective entry)

Does not make payment for break period (that is, break period is not included in the working time.)


YES: Makes payment for break period (that is, break period

is included in the working time.)

# **Logo Text Programming**

Use the following procedures to select any option included in the logo text group.

# Procedure



- 1. In the SETTING window, select "13 LOGO TEXT."
  - The LOGO TEXT window will appear.



- **2.** Select any option from the following options list:
  - 1 RECEIPT LOGO: Receipt logo 2 BILL LOGO: Bill logo

The following illustration shows those options included in the logo text programming group.




- → See "■ Receipt logo" on page 178.
- → See "■ Bill logo" on page 178.

## ■ Receipt logo

Your POS terminal can print a programmed message on every receipt.





Program the item as follows:


RECEIPT LOGO (Use the character entry)
 Logo text for the receipt (max. 40 characters x 6 lines)

## NOTE

The programmable number of lines for a message varies according to the message type: the "3-line header message" type, "3-line footer message" type, "6-line header message" type and "Stamp only" type. Please contact your authorized SHARP dealer.

## ■ Bill logo

Your POS terminal can print a programmed message on the bill.





It is assumed that you have selected "1 HEADER."



When "1 HEADER" is selected:

BILL HEADER (Use the character entry)

Header text for the bill (max. 40 characters x 3 lines)

When "2 FOOTER" is selected:

BILL FOOTER (Use the character entry)
 Footer text for the bill (max. 40 characters x 6 lines)




Header/Footer text for bill printer programming.

## **Printer Programming**

Use the following procedures to select a printer programming:

## Procedure



- 1. In the SETTING window, select "14 PRINTER."
  - The PRINTER window will appear.




The screen continues.

**2.** Select any option from the following options list:

01	J PRINTER:	Journal printer
02	R PRINTER:	Receipt printer
03	BILL PRINTER:	Bill printer
04	REPORT PRINTER:	Report printer
05	KP#1:	Remote printer #1
06	KP#2:	Remote printer #2
07	KP#3:	Remote printer #3
80	KP#4:	Remote printer #4
09	KP#5:	Remote printer #5
10	KP#6:	Remote printer #6
11	KP#7:	Remote printer #7
12	KP#8:	Remote printer #8
13	KP#9:	Remote printer #9


The following illustration shows those options included in the printer programming group.



#### Printer

You can program various printing functions for each printer.

## Procedure



Program each item as follows:

#### • PRINTER NAME (Use the selective entry)

Select the printer to be used.

TM-T85/T88(3): TM-T85/T88 manufactured by EPSON TM-300: TM-300 manufactured by EPSON TM-T80: TM-T80 manufactured by EPSON UP-T80BP: UP-T80BP manufactured by EPSON TM-U200/U230: TM-U200/U230 manufactured by

**EPSON** 

ER-01PU: ER-01PU manufactured by SHARP

TM-T88(3)+LOGO: TM-T88(3) + Logo

#### AUTO CUTTER (Use the selective entry)

Auto cutter function

NO: Disables auto cutter function. YES: Enables auto cutter function.

#### • PAPER SHEET (Use the selective entry)

Select a paper type.

TWO OR MORE: Uses two or more sheets.

ONE SHEET: Uses one sheet.

#### NOTE

This option is available when the "TM-300" is selected.

#### • TRAY ST FEED# (Use the numeric entry)

Tray subtotal feed line (max. 1 digit: 0 to 9)

#### NOTE

This option is displayed only in the "R PRINTER" window.

#### LOGO TEXT PRINT (Use the selective entry)

Select the logo text printing status.

NOT PRINT: Logo text is not printed. PRINT: Logo text is printed.


#### NOTE

This option is displayed only in the "REPORT PRINTER" window.

# **GLU/PBLU Code Programming**

Use the following procedures to select any option included in the GLU code group:

## Procedure



- 1. In the SETTING window, select "15 GLU CODE."
  - The GLU CODE window will appear.



- **2.** Select any item from the following options list:
  - 1 GLU: GLU/PBLU code 2 DRIVE THRU: Drive-through code

The following illustration shows those options included in the GLU/PBLU code programming group.


15 GLU CODE 1 GLU 2 DRIVE THRU →

- ⇒ See "■ GLU/PBLU code" on page 182.
- ⇒ See "■ Drive-through code" on page 182.

#### ■ GLU/PBLU code

You can program the range of available guest check codes.





Program each item as follows:

START CODE (Use the numeric entry)

Start GLU code (max. 8 digits: 1 to 99999999)


END CODE (Use the numeric entry)

End GLU code (max. 8 digits: 1 to 99999999)

### ■ Drive-through code

You can program the range of available drive-through codes.

## Procedure



Program each item as follows:

START CODE (Use the numeric entry)

Start drive-through code (max. 8 digits: 1 to 99999999)

END CODE (Use the numeric entry)

End drive-through code (max. 8 digits: 1 to 99999999)

• TIME (Use the numeric entry)

Drive-through target time:

Enter the minute (2 digits) and the second (2 digits) in this sequence.


NOTE

When the waiting time exceeds the programmed target time, the terminal will display a warning.


# **Tax Programming**

Use the following procedures to select any option included in the tax group:





- 1. In the SETTING window, select "16 TAX."
  - The TAX window will appear.



**2.** Select any option from the following options list:

1 TAX1: Tax1 2 TAX2: Tax2 3 TAX3: Tax3 4 TAX4: Tax4

5 DOUGHNUT EXEMPT: Doughnut exemption (for the

Canadian tax system)

#### NOTE

- The option "DOUGHNUT EXEMPT" appears only when the Canadian tax system is selected.
- If the DEL key is touched on the tax number selection menu, the tax table or the tax in the cursor position will be deleted.

The following illustration shows those options included in the tax programming group.

#### ■ Table tax

Your POS terminal has an automatic tax calculation feature which allows you to program four tax tables to avoid calculating tax manually.

Automatic tax calculations require you to program, in addition to the tax table, the tax status of each department, PLU, and function keys.

#### Sample tax table

New Jersey tax table: 6%

	Range of s	of sales amount		Range of sales amount		A: Difference between a	
Tax	Minimum breakpoint	M	aximum breakpoint	minimum breakpoint and the next one (¢)			
.00	.01	to	.10	-	<b>+</b>		
.01T	11:–Q	to	.22	10 (0.11 - 0.01)	B: Non-cyclic		
.02	.23	to	.38	12 (0.23 - 0.11)			
.03	.39	to	.56	16 (0.39 - 0.23)			
.04	.57	to	.72	18 (0.57 - 0.39)	↓ C: Cyclic 1		
.05	.73	to	.88	16 (0.73 - 0.57)	O. Cyclic 1		
.06	.89	to	1.10	16 (0.89 - 0.73)			
.07	: 1.11:–M1	to	1.22	22 (1.11 - 0.89)			
.08	1.23	to	1.38	12 (1.23 - 1.11)			
.09	1.39	to	1.56	16 (1.39 - 1.23)			
.10	1.57	to	1.72	18 (1.57 - 1.39)	<b>↓</b>		
.11	1.73	to	1.88	16 (1.73 - 1.57)	D: Cyclic 2		
.12	1.89	to	2.10	16 (1.89 - 1.73)	l T		
.13	2.11-M2	to	2.22	22 (2.11 - 1.89)			

To program a tax table, first make a table like the right table shown above.

From the tax table, calculate the differences between a minimum breakpoint and the next one (A). Then, from the differences, find irregular cycles (B) and regular cycles (C and D). These cycles will show you the following items necessary to program the tax table:

T: Tax amount collected on the minimum taxable amount (Q)

O· Minimum taxable amount

M1: Maximum value of the minimum breakpoint on a regular cycle (C).


We call this point "MAX point."

**M2:** Maximum value of the minimum breakpoint on a regular cycle (D).

We call this point "MAX point."

M: Range of the minimum breakpoint on a regular cycle: difference between Q and M1 or between M1 and M2

#### Table tax (continued)



The screen continues.

Program each item as follows:

#### • TAX RATE (Use the numeric entry)

Tax rate for the tax table (max. 7 digits: 0.0000 to 999.9999)

#### • CYCLE (Use the numeric entry)

Range of the minimum breakpoint on a regular cycle for the tax table (max. 4 digits: 0.01 to 99.99)

See the description "M" shown on the previous page.

#### • INITIAL TAX (Use the numeric entry)

Initial tax amount for the tax table (max. 3 digits: 0.01 to 9.99)

See the description "T" shown on the previous page.

#### LOWER TAX LIMIT (Use the numeric entry)

Minimum taxable amount for the tax table (max. 5 digits: 0.01 to 999.99)

See the description "Q" shown on the previous page.


#### • BREAK POINT1 thru 72 (Use the numeric entry)

Breakpoints programmable for the tax table (max. 5 digits: 0.01 to 999.99)

Seventy-two breakpoints can be programmed for each tax table. When the interval between breakpoints is one dollar or more and less than one-hundred dollar, 36 breakpoints are programmed for each tax table.

### ■ Rate (%) tax

You can program a tax rate for the desired percent tax rate.



Program each item as follows:

• TAX RATE (Use the numeric entry)

Tax rate (max. 7 digits: 0.0000 to 999.9999%)

• LOWER TAX LIMIT (Use the numeric entry)

Lowest taxable amount (max. 5 digits: 0.01 to 999.99)

## ■ Doughnut tax exempt (for the Canadian tax system)



**Procedure** 

Program the item as follows:

QUANTITY (Use the numeric entry)

Quantity for the doughnut tax exempt (for Canadian tax) (max. 2 digits: 1 to 99/0)


NOTE

This option is available only when the Canadian tax system is selected.


# **Function Key Programming**

Use the following procedures to program a text (key label) or a color for the function key:


#### **Procedure**



- **1.** In the SETTING window, select "17 FUNCTION KEY."
  - The FUNCTION KEY window will appear.



2. Select any function key from the key list.



- **3.** Program a text or a color for the corresponding function key.
  - KEY TEXT (Use the character entry)

Enter a text for the function key.

The terminal is provided with various text-length in compliance with each key size. (max. 16 characters)

• KEY COLOR (Use the selective entry)

Select a key color from the colors list (16 different colors).

BLACK/BLUE/GREEN/CYAN/RED/MAGENTA/
ORANGE/LIGHT GRAY/SLATE GRAY/DODGER BLUE/
LIGHT GREEN/LIGHT CYAN/SALMON/LIGHT
MAGENTA/YELLOW/WHITE


## **TRAINING Mode Selection**


Use the following procedures to select the training mode:

#### **■ TRAINING mode**

The TRAINING mode is used to train someone with the machine operations without changing the POS terminal's memory. Reports are not available. When training is completed, exit this mode and put your POS terminal back in the normal mode operation.

## Procedure





Program the item as follows:

#### • TRAINING MODE (Use the selective entry)

YES: Allows entering the training mode.

NO: Disallows entering the training mode.

#### NOTE

- All operations in the training mode are the same as the REG-mode operations.
- In the training mode, the consecutive number is incremented.
- The cash drawer does not open in the training mode.

  Items normally sent to the remote printers are not sent.

## **Backup Data Send Programming**


Use the following procedures to select the menu option.

NOTE For more information, please consult your authorized SHARP dealer.

#### Backup data send

Your POS terminal can send data to another device.





Program each item as follows:

#### • SEND DATA (Use the selective entry)

Select one of the following options (data sources):

• ALL RAM • SSF

#### SPEED (Use the selective entry)

Select one of the following options (data transmission

speeds):

PROGRAMMED SPEED: Sends data at a programmed

speed.

115200bps: Sends data at 115200 bps.
57600bps: Sends data at 57600 bps.
38400bps: Sends data at 38400 bps.
19200bps: Sends data at 19200 bps.
9600bps: Sends data at 9600 bps.
4800bps: Sends data at 4800 bps.
2400bps: Sends data at 2400 bps.

# **Backup Data Receive Programming**


Use the following procedures to select the menu option.


NOTE For more information, please consult your authorized SHARP dealer.

### ■ Backup data receive

Your POS terminal can receive data from another device.







Program the item as follows:

#### SPEED (Use the selective entry)

Select one of the following options (data transmission speeds):

PROGRAMMED SPEED: Receives data at a programmed

speed.

115200bps: Receives data at 115200 bps.
57600bps: Receives data at 57600 bps.
38400bps: Receives data at 38400 bps.
19200bps: Receives data at 19200 bps.
9600bps: Receives data at 9600 bps.
4800bps: Receives data at 4800 bps.
2400bps: Receives data at 2400 bps.





The receiving unit must have equal or greater memories than the terminal sending the program.

# **PLU Updating (in the PGM1 Mode)**

The PLU UPDATE is mainly used for daily changes of the PLU's unit price or name by supervisor or manager.









To program a unit price or name for the PLU as follows:

- 1. In the PGM1 MODE window, touch the UPDATE key.
  - The PLU list will appear.


2. Select any PLU number from the list.

- **3.** Program a unit price or name for a corresponding price level.
  - PRICE1 thru 5 (Use the numeric entry)
     Unit price of each price level (max. 6 digits)
  - NAME FOR PRICE1 thru 5 (Use the character entry)
     Name of each price level (max. 8 characters). Up to 16 characters can be entered.

# **Unit Price Mode Programming**


The UNIT PRICE mode programming is mainly used for daily changes of the PLU's unit price.

**Procedure** 



To program a unit price for a PLU as follows:

- **1.** Select "7 UNIT PRICE MODE" from the mode selection window.
  - The UNIT PRICE MODE window will appear.




2. Select any PLU number from the list.



- **3.** Program a unit price for the corresponding price level.
  - PRICE1 thru 5 (Use the numeric entry)
    Unit price of each price level (max. 6 digits)

# **Automatic Sequencing Key Programming**

If you program a frequently performed key operation for the AUTO keys, you can enter those key operations simply by touching the corresponding AUTO keys in key operations.



To program an automatic sequencing key as follows:

**1.** Touch an automatic sequencing key which you want to program.

AUTO

**2.** Enter the desired sequence to program for the automatic sequencing key.

$$700 \rightarrow 00001 \rightarrow CASH$$

3. Touch the automatic sequencing key again.

AUTO

**4.** Touch the EXIT to finalize the programming.

# **Reading of Stored Programs**

You can read programs stored in the PGM1 or PGM2 mode.

## **■** Program reading sequence

To read those programs stored in the PGM1 or PGM2 mode, use the following procedures:

- 1. Select "1 READING" in the PGM1 or PGM2 mode menu window to display the items list.
- 2. Select an item listed in the table shown below.
- 3. If required, enter the start and end codes to specify the range of the selected item.
- 4. Select a device ("DISPLAY" or "REPORT PRINTER") to read the programs.

Item:	Description:	Available mode:
1 DEPT *	Department	PGM1 or PGM2
2 PLU*	PLU	PGM1 or PGM2
3 LINK PLU TABLE *	Link PLU table	PGM2
4 CONDIMENT TABLE *	Condiment table	PGM2
5 MIX&MATCH TABLE	Mix-and-match table	PGM2
6 RECIPE TABLE *	Recipe table	PGM2
7 INGREDIENT *	Ingredient table	PGM1 or PGM2
8 COMBO MEAL TABLE *	Combo meal table	PGM2
9 SCALE TABLE	Scale table	PGM2
10 FUNCTION	Function	PGM1 or PGM2
11 MEDIA	Media key	PGM2
12 SERVER	Server	PGM1 or PGM2
13 MANAGER	Manager	PGM2
14 EMPLOYEE *	Employee	PGM2
15 JOB LOCATE TBL	Job location table	PGM2
16 OPTIONAL	Optional feature	PGM2


Item:	Description:	Available mode:
17 FUNCTION TEXT	Function text	PGM2
18 DEPT. GROUP	Department group	PGM2
19 PLU GROUP	PLU group	PGM2
20 PLU HOURLY GR	PLU hourly group	PGM2
21 SERVER GROUP	Server group	PGM2
22 LOGO TEXT	Text	PGM2
23 TAX	Tax	PGM2
24 GLU CODE	GLU	PGM2
25 AUTO KEY	Automatic sequencing key	PGM2
26 PRINTER	Printer	PGM2
27 DIRECT KEY	Direct key	PGM2
28 PLU MENU KEY	PLU menu key	PGM2
29 FUNCTION KEY	Function key	PGM2

## NOTE

You can read those programmed items marked with " \* " by range.


### **■** Sample printouts

• Departments (PGM1 or PGM2 mode)




<sup>\*</sup> When you print this report in the PGM1 mode, the PGM2 indication is replaced by a "PGM1."


#### • PLUs (PGM1 or PGM2 mode)




• Link PLU table (PGM2 mode)




• Mix & Match table (PGM2 mode)




• Condiment table (PGM2 mode)



• Recipe table (PGM2 mode)




• Ingredient (PGM2 mode)




Scale tare table (PGM2 mode)

<b>08/2</b> #1017	6/ <b>03</b> 8:37PM	123456 Jackooo1	
	PGM2* E TABL	.E	Report type
#1— #2 #3 #4 #5 #6 #7 #8 #9		2. 75 - 3. 50 12. 00 0. 00 0. 00 0. 00 0. 00 0. 00	— Scale table no — Weight


• Combo meal table (PGM2 mode)




#### • Functions (PGM1 or PGM2 mode)




#### • Media (PGM2 mode)




• Server (PGM1 or PGM2 mode)




• Manager (PGM2 mode)



• Employee (PGM2 mode)



• Job location table (PGM2 mode)



## • Optional features (PGM2 mode)

#1056 9:00PM JACK0001 *PGM2*	00 /26 /02	122456	
OPTIONAL FUNC. PROHIBIT. SRV REPO IN OPXZ ENABLE RF/RETURN IN REG ENABLE 1st LAST ITEM VD ENABLE INDIR. VD IN REG ENABLE INDIR. VD IN REG ENABLE VD MODE IN REG ENABLE (-) ENTRY IN REG ENABLE INDIR. VD IN REG ENABLE NO SALE IN REG ENABLE IN DIR REG ENABLE ITP PAID IN REG ENABLE ITP PAID IN REG ENABLE INDIR. VD IN GLU ENABLE INDIR. VD IN GLU ENABLE FUNC. SELECTING LEVEL SFT METHOD AUTO LEVEL SFT IN MGR® PRICE SFT METHOD AUTO PRICE SFT IN MGR® RETURN TO PRICE1 BY ONE ITEM RETURN ASSIGN INHIBIT TIP ENTRY METHOD AMOUNT SRVR ORM ASSIGN INHIBIT SHIFT KEY ACTION CAPS LOCK EMPLOYEE SALE CHARGE AMOUNT AUTO HOURLY REPO DISABLE DRIVE SCREEN MANUAL COMP. COND. CANCEL MGR®  PRINTING SELECT # OF PURCHASE NOT PRINT JOURNAL SELECT JOURNAL SELECT JOURNAL SELECT JOURNAL SELECT JOURNAL FURLY ITEM ON BILL PRINT SHARE% PRINT  INTERVAL TIMER  TILL TIMER  O SCREEN SAVE  O  BILL NUMBER	08/26/03 #1056 9:00PM	123456 Jackooo1	
FUNC. PROHIBIT.  SRY REPO IN OPXZ PO ENTRY IN REG RF/RETURN IN REG STABLE 1st LAST ITEM VD DIRECT VD IN REG INDIR. VD IN REG SBTL VD IN REG SBTL VD IN REG VD MODE IN REG VD WHEN SBTL-O VD ENABLE VD WHEN SBTL-O VD WABLE  FUNC. SELECTING LEVEL SFT METHOD VD IN GLU VD WABLE  FUNC. SELECTING LEVEL SFT METHOD VD WABLE  FUNC. SELECTING LEVEL SFT METHOD VD WABLE  FURN TO LEVEL1 VD WA GRÆREG VD WA WAS INHIBIT VD WAS ASSIGN VD WAS INHIBIT VD WAS ASSIGN VD WAS INHIBIT VD WAS ASSIGN VD WAS AND VD WAS AUTO VD PRINT VD WAS ASSIGN VD WAS AUTO VD WAS AND VD WAS AUTO VD WAS AND VD WAS AUTO VD WAS AND VD WAS AUTO VD WAS ASSIGN VD WAS AND VD WAS AUTO			Report type
FUNC. SELECTING LEVEL SFT METHOD AUTO LEVEL SFT IN MGR® PRICE SFT METHOD AUTO PRICE SFT IN MGR® RETURN TO LEVEL1 BY ONE ITEM RETURN TO PRICE1 BY ONE ITEM PERSON NUMBER INHIBIT COVER COUNT NON-COMPULSORY TABLE NUMBER INHIBIT TIP ENTRY METHOD AMOUNT SRVR DRW ASSIGN INHIBIT SHIFT KEY ACTION CAPS LOCK EMPLOYEE SALE CHARGE AMOUNT AUTO HOURLY REPO DISABLE DRIVE SCREEN MANUAL COMP. COND. CANCEL MGR®  PRINTING SELECT # OF PURCHASE NOT PRINT TIME PRINT JOURNAL SELECT FULL PRINT JOURNAL SELECT FULL PRINT JOURNAL LETTER NORMAL ITEM ON BILL PRINT SHARE% PRINT  INTERVAL TIMER TILL TIMER O SCREEN SAVE O  BILL NUMBER	FUNC. PROHIBIT. SRY REPO IN OPXZ PO ENTRY IN REG RF/RETURN IN REG 1st LAST ITEM YD DIRECT YD IN REG INDIR. VD IN REG SBTL YD IN REG YD MODE IN REG (-) ENTRY IN REG NO SALE IN REG PAY WHEN SBTL=0 TIP PAID IN REG TR IN/OUT IN REG	ENABLE	Setting
# OF PURCHASE NOT PRINT TIME PRINT JOURNAL SELECT FULL PRINT JOURNAL LETTER NORMAL ITEM ON BILL PRINT SHARE% PRINT  INTERVAL TIMER TILL TIMER 0 SCREEN SAVE 0  BILL NUMBER	FUNC. SELECTING LEVEL SFT METHOD LEVEL SFT IN PRICE SFT METHOD PRICE SFT IN RETURN TO LEVEL1 RETURN TO PRICE1 PERSON NUMBER COVER COUNT NO TABLE NUMBER TIP ENTRY METHOD SRVR DRW ASSIGN SHIFT KEY ACTION EMPLOYEE SALE AUTO HOURLY REPO DRIVE SCREEN	AUTO MGR® AUTO MGR® BY ONE ITEM BY ONE ITEM INHIBIT N-COMPULSORY INHIBIT AMOUNT INHIBIT CAPS LOCK HARGE AMOUNT DISABLE MANUAL	
TILL TIMER 0 SCREEN SAVE 0 BILL NUMBER	# OF PURCHASE TIME JOURNAL SELECT JOURNAL LETTER ITEM ON BILL	PRINT FULL PRINT NORMAL PRINT	
	TILL TIMER	0	
J007	BILL NUMB		
		0004	

O SKIP SERVER TRANSACTION DEPARTMENT PLU HOURLY DAILY NET	SKIP SKIP SKIP SKIP SKIP
HOURLY RP MEMORY TYPE STARTING TIME	T 30 00
STACKED R	PT
DEPARTMENT PLU O EMP. SALE (DETAIL)	01-10 00001-000100 1-0000000100
2 PLU TOP 20 HOURLY GLU 00000	AMOUNT 1000-2200 001-00000100
EMPLOYEE PAYMENT PERIOD PERIOD-1 START PERIOD-2 START PAY FOR BREAK	MONTHLY 01 01 No


#### • Function text (PGM2 mode)

<b>08/26/</b> #1028	<b>'03</b> 1234 B:59PM JACK00	
	iM2* :ON TEXT-	Report type
NET 1 TAX1 ST GRS TAX1 RFD TAX1 TAX1 TX1 EXPT TAX2 ST GRS TAX2 RFD TAX2 TAX2 TX2 EXPT TAX3 ST GRS TAX3 RFD TAX3 TAX4 TX4 EXPT TAX4 ST GRS TAX4 TX4 EXPT GRS MTAX TAX4 TXA4 TXA4 TXA4 TXA4 TXA4 TXA4 T	TAX1 ST GRS TAX1 RFD TAX1 TAX1 TX1 EXPT TAX2 ST GRS TAX2 RFD TAX2 TAX2 TAX2 TAX3 TX2 EXPT TAX3 ST GRS TAX3 RFD TAX3 TAX3 TX3 EXPT TAX4 ST GRS TAX4 RFD TAX4 TX4 EXPT GRS MTAX RFD MTAX COMBO1	Function text (default)  Text (preset)
MDSE ST ***TOTAL CHANGE DUE TIP DUE TRAY TL ITEMS BALANCE	MDSE ST ***TOTAL CHANGE DUE TIP DUE TRAY TL ITEMS BALANCE	


COPY COPY B.T. B.S. FIN.BAL B.T. B.S. FIN.BAL BAL FWD BAL FWD CLOSE CK CLOSE CK OPEN CK OPEN CK (%) SALES (%) SALES CHARGE CHARGE COST COST COST% COST% TTL COST TTL COST LOC# LOC# L. COST L. COST TTL HOUR TTL HOUR OVR TIME OVR TIME TIME-IN TIME-IN TIME-OUT TIME-OUT BRK-IN BRK-IN BRK-OUT **BRK-OUT** LABOR% LABOR% PERSON# PERSON# MANAGER# MANAGER# VAT EXPT VAT EXPT IND. PAY IND. PAY TARE WT. TARE WT. RCP S.W. RCP S.W. FREE GLU FREE GLU WASTE WASTE AVE SALE ST(-) TL AVE SALE ST(-) TL ST % TL (-) TL ST % TL (-) IL % TL % TL CASH TL CASH TL RA TL RA TL PO TL PO TL CA/CK TL CA/CK TL CONV TL CONV TL CHR TL CHR TL CHECK TL CHECK TL COMBO COMBO WASTE WASTE RF RF CP CP NET SLS **NET SLS** COMBO TL COMBO TL WASTE TL RF TL WASTE TL RF TL NET TL NET TL OVR COST OVR COST GLU# GLU# CAR# CAR#

To be continued


• Department group text (PGM2 mode)




• PLU hourly group text (PGM2 mode)



• PLU group text (PGM2 mode)





Server group text (PGM2 mode)



#### • Text (PGM2 mode)


#### • GLU code (PGM2 mode)






#### • Tax rate (PGM2 mode)


#### • AUTO key (PGM2 mode)







• Printer (PGM2 mode)

• PLU menu key (PGM2 mode)



• Direct key (PGM2 mode)





## • Function key (PGM2 mode)

*PGM2* FUNCTION KEY  OO1 HOME — BLUE — CANCEL YELLOW OO3 CLEAR YELLOW	Report typ
OO2 CANCEL YELLOW CLEAR YELLOW	
OO2 CANCEL YELLOW OO3 CLEAR YELLOW	- Key text
OO3 CLEAR YELLOW	- Key color
YELLO#	
OO4 MODE	
CYAN CYAN	
OO6	
LIGHT GRAY	
OO7 MORE LIGHT CYAN	
OO8 MORE DODGER BLUE	
OO9 ENTER SLATE GLAY	
O1O SUB	
O11 CASH GREEN	
012 0	
013 LIGHT GRAY	
UIGHT GRAY	
LIGHT GRAY O15 3	
O16 LIGHT GRAY	
LIGHT GRAY 5	
LIGHT GRAY	
LIGHT GRAY	
LIGHT GRAY	
020 8 LIGHT GRAY	
O21 9	
O22 OO LIGHT GRAY	
023 000 LIGHT GRAY	
024 LIGHT GRAY	
LIMIT MISK!	

216	MENU39
217	CYAN Menu40
218	CYAN Menu41
219	CYAN Menu42
220	CYAN Menu43
221	CYAN Menu44
222	CYAN Menu45
223	CYAN Menu46
224	CYAN Menu47
225	CYAN Menu48
226	CYAN Menu49
227	CYAN Menu50
228	CYAN   ED TIP   YFILOW
	ILLLUM

To be continued

# 14 Operator Maintenance

## In Case of Power Failure

When power is lost, the POS terminal retains its memory contents and all information on sales totals.

 When power failure is encountered in the POS terminal idle state or during an entry, the POS terminal returns to the normal state of operation after power recovery.

# **Before Calling for Service**

The malfunctions shown on the left-hand column below, labeled "Fault," does not necessarily indicate functional faults of the machine. It is therefore advisable to refer to the "Checking" shown on the right-hand column before calling for service.

Fault	Checking
The display does not illuminate.	<ul> <li>Is power supplied to the electric outlet?</li> <li>Is the power cord plug out or loosely connected to the electrical outlet?</li> <li>Is the power switch in the "ON" position?</li> <li>Are the brightness control and the contrast control adjusted correctly?</li> <li>Is the terminal in screen-save mode?</li> </ul>
No receipt is issued.	See the printer manual.
No journal paper is taken up.	
Printing is unusual.	

# 15 Options

# **List of Options**

For your UP-3301 POS terminal, the following options are available: For details, contact your authorized SHARP dealer. Do no try to install any options yourself.

- 1. RAM memory board model UP-S02MB2M
- 2. External printer model ER-01PU
- 3. Remote drawer model ER-03DW or ER-04DW
- 4. Coin case model ER-75CC3 or ER-55CC2
- 5. Magnetic card reader model UP-E12MR2
- 6. Built-in printer model UP-T80BP
- 7. RS-232 I/F board model ER-A7RS2

# 16 Specifications

Model:	UP-3301			
External dimensions:	11.6(W) x 16.3(D) x 12.8(H) in. (295(W) x 414.5(D) x 325(H) mm)			
Weight:	14.6 lbs. (6.6 kg)			
Power source:	120 V AC ±10%, 60	) Hz		
Power consumption:	Stand-by: 29	W		
	Operating: 50	W		
Working temperatures:	32 to 104 °F (0 to 4	0 °C)		
Electronics:	LSI (CPU) etc.			
Built-in battery:	•	ery pack, memory holding time of approx. 1 month (with fully tery pack, at room temperature)		
Display:	Operator display:	Color LCD module and Touch panel 640(W) x 480(H) (dots)		
	Customer display:	16-position dot matrix display (5 x 7 dots) and 11-position 7-segment display		
Accessories:	Leaflet 1 copy			
	Ferrite cores 3 pieces (used for communications cabling installation)			
	Gum leg (for UP-E1	2MR2) 2 pieces		

<sup>\*</sup> Specifications and appearance subject to change without notice for improvement.

# 17 Appendix

# **Error Messages**

MISOPERATION Misoperation  ENTRY ERROR Entry error  ENTRY INHIBITED Entry is inhibited by PGM programming.  ENTRY OVERFLOW Entry data overflow  TRANS OVERFLOW One transaction limitation overflow  LACKING MEMORY Not enough file or memory size.  ENTRY COMPULSORY Entry compulsory  NO AUTHORITY No authority assigned  UNDEFINED CODE Undefined code  NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
ENTRY INHIBITED Entry is inhibited by PGM programming.  ENTRY OVERFLOW Entry data overflow  TRANS OVERFLOW One transaction limitation overflow  LACKING MEMORY Not enough file or memory size.  ENTRY COMPULSORY Entry compulsory  NO AUTHORITY No authority assigned  UNDEFINED CODE Undefined code  NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
ENTRY OVERFLOW TRANS OVERFLOW One transaction limitation overflow LACKING MEMORY Not enough file or memory size.  ENTRY COMPULSORY Entry compulsory NO AUTHORITY No authority assigned UNDEFINED CODE Undefined code NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free. OUT OF STOCK Stock overflow error OVER LIMITATION Digit limitation overflow TIP ERROR Tip error
ENTRY OVERFLOW TRANS OVERFLOW One transaction limitation overflow LACKING MEMORY Not enough file or memory size.  ENTRY COMPULSORY Entry compulsory NO AUTHORITY No authority assigned UNDEFINED CODE Undefined code NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free. OUT OF STOCK Stock overflow error OVER LIMITATION Digit limitation overflow TIP ERROR Tip error
LACKING MEMORY  Not enough file or memory size.  ENTRY COMPULSORY  Entry compulsory  NO AUTHORITY  No authority assigned  UNDEFINED CODE  Undefined code  NOT ASSIGNED  Not assigned.  CODE NOT FREE  The code is not free.  OUT OF STOCK  Stock overflow error  OVER LIMITATION  Digit limitation overflow  TIP ERROR  Not enough file or memory size.  Entry compulsory  No authority assigned  Undefined code  Stock overflow error  OVER LIMITATION  Tip error
ENTRY COMPULSORY Entry compulsory  NO AUTHORITY No authority assigned  UNDEFINED CODE Undefined code  NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
ENTRY COMPULSORY Entry compulsory  NO AUTHORITY No authority assigned  UNDEFINED CODE Undefined code  NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
NO AUTHORITY  No authority assigned  UNDEFINED CODE  Undefined code  NOT ASSIGNED  Not assigned.  CODE NOT FREE  The code is not free.  OUT OF STOCK  Stock overflow error  OVER LIMITATION  Digit limitation overflow  TIP ERROR  Tip error
UNDEFINED CODE Undefined code  NOT ASSIGNED Not assigned.  CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
CODE NOT FREE The code is not free.  OUT OF STOCK Stock overflow error  OVER LIMITATION Digit limitation overflow  TIP ERROR Tip error
CODE NOT FREE The code is not free. OUT OF STOCK Stock overflow error OVER LIMITATION Digit limitation overflow TIP ERROR Tip error
OVER LIMITATION Digit limitation overflow TIP ERROR Tip error
TIP ERROR Tip error
The state of the s
OFORET # EDDOR
SECRET # ERROR Secret code mismatch
PAPER EMPTY Printer's paper empty
NON RESET IRC initial download before resetting
OFF LINE Remote printer off-line error
MOTOR LOCK Remote printer motor lock error
TYPE ERROR IRC download file type mismatch
POWER OFF Power of the IRC terminal is off.
BUSY IRC communication busy
LINE ERROR Transmission error
SYSTEM OPENED Resetting executed in open store state (only when the resetting operation is inhibited).
IS SIGNED ON IRC server sign-on error (when all server resetting is executed.)
NO REPLY/MASTER The master does not reply to the request.
NO REPLY/BACKUP The backup master does not reply to the request.
SENDING DATA Data sending message
T-LOG FULL T-log file is full.
ATTEMPT RETRY? Manager retry message
IR SEND OK IR data has normally been sent.
IR RECEIVE OK IR data has normally been received.
IR COM.ERROR IR communication error
IR DATA ERROR IR data error
IR COM.TIME-OUT IR communication time out
IR COM.CANCELED IR communication has been canceled.
CHECK RS-PORT Assigned serial port was not found.
CHECK CONNECTION Printer connection error
CHECK LOW PAPER Printer paper near end error
INVALID RESPONSE CAT error message received from HOST
COMM.ERROR CAT communication error with HOST
CAN NOT VOID VOID operation can not be performed.
TIP EXIST Tip amount is entered.

Your POS terminal may also display the following messages:

- NON-ADD # CODE
- ZERO DATA PRESET
- ENTER AMOUNT
- GLU FILE CLOSED
- COVER COUNT
- DECIMAL POINT
- DEPARTMENT
- TYPE DEPARTMENT
- GLU BUFFER FILE
- GLU FILE
- OPEN PRICE
- PBLU
- TYPE PLU
- PRESET PRICE
- QTY
- REG BUFFER FILE
- SCALE
- SERVER
- TARE TABLE#
- WEIGHT
- KP BUFFER
- DRAWER IS OPEN
- Z-RESET
- SYSTEM CLOSED
- DRIVE-THRU

# 18 Index

A	Direct key 116 Drive-through 42, 43, 65, 85, 86, 87, 88, 140, 182
Automatic return mode 35, 36, 164	
Automatic sequencing key 193	E
В	Eat-in 65, 139
Backup data receive 190	Employee 51, 52, 79, 80, 90, 91, 92, 93, 94, 155, 165, 176
Backup data send 189	Employee charge 136
Base q'ty 104	Error messages 212
Bill number 42, 160	
Bill print 65, 129, 131, 135, 137, 140, 142	
Bill separating 45	F
Bill totalizing 44	
Bill transfer 45	Fast food sale 32
Break in/out 52, 90	FF method 31, 32
	Final 142
С	
	G
CAT 127, 128, 130, 131, 133, 134, 136, 137, 140,	
141, 142, 143, 145	GLU/PBLU 41, 42, 44, 45, 65, 82, 127, 130, 133,
CVM control character 102, 106, 114	140, 153, 164, 165, 182
Cash 39, 65, 127	Gratuity 47, 65, 77, 123
Cash in drawer 75, 144	Group (PLU) 71, 75, 105, 150, 151
Charge 39, 66, 133	Group (department) 68, 102, 150
Check 39, 66, 130	
Check cashing (cashing a check) 51, 66, 145	H
Check change 144 Closed GLU/PBLU/drive-through 77, 83, 84, 87, 88,	
129, 131, 135	Hash 65, 101
Combo meal 34, 69, 114	Hourly report 80, 172
Condiment 37, 105, 111	
Consecutive number 15, 159	
Copy receipt 58	1
Correction 54, 55, 57, 60	Ingredient 81, 108, 109, 113
Cost 72, 81, 108	ingrodione or, roo, roo, rro
Cover count 41, 43, 44, 65, 164	
Currency conversion 48, 66, 139	J
	111 " 70 455 450
D	Job location 79, 155, 156
Daily net report 90	L
Date/time 161	L
Department 30, 67, 68, 70, 101	Level shift 35, 164
Deposit 43, 66	Link PLU 34, 105, 110
Description 96, 101	Lock shift mode 35, 36, 164
Descriptor 108, 139	Logo 177

IVI	S
Manager 59, 60, 154, 155  Manual tax 40, 64, 76, 125  Menu 16, 17, 19, 20, 21, 29, 30, 31, 32, 33, 49, 50, 51  Minimum stock 74, 104  Mix & match 34, 105, 112	Scale entry 32, 33, 101, 105, 115 Screen save mode 10, 159 Secret code 13, 29, 59, 61, 153, 154, 155, 166 Server 29, 77, 78, 153 Server group 102, 151 Service 41, 42, 43, 65, 140 Service time report 85 Stacked report 88, 94, 173 Stock 71, 107, 109
Name 96, 103 No-sale 50, 65, 163 Non-add code 46, 129, 132, 135, 137	Т
Open GLU/PBLU/drive-through 77 Operating mode 12 Over-time 79, 155	TILL TIMER 159 Table number 41, 44, 45, 164 Table tax 184 Tare table 101, 105, 115 Tax 40, 76, 102, 105, 183 Tax deletion 40, 129, 132, 135, 138, 139 Text 96, 148 Time editing 52, 90
P	Time in/out 52, 90 Tip 47, 48, 66, 77, 123, 163, 164
PLU 30, 69, 103 PLU hourly group 75, 105 PLU menu key 119 PLU range 106 PLU top 20 73	Training mode 64, 82, 83, 188 Transaction report 64, 89, 172 Transfer in/out 44, 65, 77, 163 Tray subtotal 38, 65, 180
PLU update 191 PLU zero sales 74	U
Paid-out (PO) 50, 65, 124, 163 Person number 41, 164 Price level shift 36, 103, 104, 164, 191	Unit price mode 12, 192
Printer 11, 47, 180 Priority group 105 Program reading 194 Programming 98	<b>V</b> Void 54, 55, 57, 163
R	W
Receipt ON-OFF function 58	Waste mode 53
Received-on-account (RA) 49, 65, 124 Recipe 105, 113 Refund 46, 65, 163	Z
Report 64, 171 Return 46, 65, 163	Zero skip 172

#### NOTICE

BE SURE TO ASK YOUR AUTHORIZED SHARP DEALER ABOUT THE WARRANTY THAT IS EXTENDED TO YOU UPON PURCHASE. In order to assure you, the end-user, of warranty protection, Sharp extends a limited warranty to each of its authorized dealers, and in turn requires each of its authorized dealers to extend its own warranty to you on terms that are no less favorable than those given to the dealer by Sharp. Please be advised that Sharp itself does not extend any warranties, either express or implied, directly to you, the end-user, and no one is authorized to make any representations or warranties on behalf of Sharp. Specifically, SHARP DOES NOT EXTEND TO YOU, THE END-USER, ANY EXPRESS WARRANTY OR ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR USE OR FITNESS FOR ANY PARTICULAR PURPOSE IN CONNECTION WITH THE HARDWARE, SOFTWARE, OR FIRMWARE EMBODIED IN OR USED IN CONJUNCTION WITH THIS PRODUCT. Sharp is not responsible for any damages or loss, either direct, incidental or consequential, which you, the end-user, may experience as a result of your purchase or use of the hardware, software or firmware embodied in or used in conjunction with this product. Your sole remedy in the event that you encounter any difficulties with the product is against the authorized dealer from which you purchased the product. In the event that this authorized dealer does not honor its warranty commitments, please contact the Point of Sale Division, ISG, Sharp Electronics Corporation, Sharp Plaza, P.O. Box 650, Mahwah, NJ 07430-2135 so that Sharp can try to help you to assure complete satisfaction of all the warranty rights to which you are entitled from the authorized dealer.



Sharp Plaza, Mahwah, New Jersey 07430-2135 1-800-BE-SHARP http://www.sharp-usa.com

**SHARP CORPORATION**