

# **Room Air Conditioners**

## **R410A Split Type – Nouveau Series** DC INVERTER

## ECO930SDN ECO1230SDN



- Please read this installation manual completely before installing the product.
- When the power cord is damaged, replacement work shall be performed by authorized personnel only.
- Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
- Contact the authorised service technician for repair or maintenance of this unit.

Register your air conditioner
Model information can be found on the CE label.
Please register your product online at www.ecoair.org. For your future convenience, record the model information below.
MODEL NUMBER
SERIAL NUMBER
PURCHASE DATE

## Congratulations!

You have purchased the very latest in room air conditioner technology. Your new EcoAir high efficiency room air conditioner will give you many years of dependable service. Many features have been built into your EcoAir air conditioner to assure quiet operation, the best circulation of cool, dry air, functional controls, and the most economical operation.

## Table of contents

DISPOSAL	5
BS PLUG WIRING	6
SAFETY PRECAUTIONS	7
INSTALLATION OF INDOOR & OUTDOOR UNITS	8
ITEMS PACKED WITH THE UNITS	9
INSTALLATION INSTRUCTIONS	10
ELECTRICAL WORK	16
AIR PURGING	18
IMPORTANT INFORMATION REGARDING REFRIGERANT USED	19
TEST RUNNING	20
SERVICE & WARRANTY	21

## WARNING

- Do not install, remove and reinstall the unit by yourself.
- Improper installation will cause water leakage, electrical shock, or fire. Please consult authorized dealer or specialist for the installation work. Please note fault caused by improper installation is not covered by warranty.
- Unit must be installed in an easily accessible area. Any additional cost required to hire special equipment to service the unit will be the responsibility of the customer.

## Disposal

## When using this air conditioner in the European countries, the follow information must be followed:

**DISPOSAL:** Do not dispose this product as unsorted waste.

It is prohibited to dispose of this appliance in domestic household waste. For disposal:

- A) Contact your local council for disposal.
- B) The manufacturer will take back the old appliance for disposal when you replace with a new product.
- C) Old products contain valuable resources, which should be recycled as scrap metal.

Wild disposal of waste in forests and landscapes endangers your health when hazardous substances leak into the ground-water and find their way into the food chain.



## **BS Plug Wiring**

(For models up to 12000 Btu)

Wiring Instructions: Should it be necessary to change the plug please note the wires in the mains lead are coloured in accordance with the following code:

#### BLUE - NEUTRAL BROWN – LIVE GREEN AND YELLOW - EARTH

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

- 1. The **BLUE** wire is the **NEUTRAL** and must be connected to the terminal which is marked with the letter **N** or coloured **BLACK**.
- 2. The **BROWN** wire is the **LIVE** and must be connected to the terminal which is marked with the letter **L** or coloured **RED**.
- 3. The **GREEN/YELLOW** is the **EARTH** and must be connected to the terminal which is marked with the letter **E** or **GREEN/YELLOW**. ⊜ or coloured **GREEN** or **GREEN/YELLOW**.
- 4. Always ensure that the cord grip is positioned and fastened correctly.

If a **13A (BS 1363)** fused plug is used it must be fitted with a **13A** fuse. If in doubt consult a qualified electrician.

#### Wiring for a 13 Amp Plug (BS1363)

Please note. The Earth Terminal is marked with the letter **E** or  $\textcircled$  Earth Symbol.



### **Safety Precautions**

#### The following should be always observed for safety:

- Be sure to read the following WARNING before installing the air conditioner.
- Be sure to observe the cautions specified here as they include important items related to safety.
- After reading this instruction, be sure to keep it together with the owner's manual in a handy place for future reference.

## 

#### Installation only by Competent person.

 Incorrect installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or special installer

#### Install the unit securely in a place which can bear the weight of the unit.

• When installed in an insufficiently strong place, the unit could fall causing injury.

Use the specified wires to connect the indoor and outdoor units securely and attach the wires firmly to the terminal board connecting sections so the stress of the wires is not applied to the sections

•Incorrect connection and fixing could cause a fire.

## Be sure to use the part provided or specified parts for the installation work.

•The use of defective parts could cause an injury due to a fire, electric shock, the unit falling, etc.

## Perform the installation securely referring to the installation instruction.

 Incorrect installation could cause a personnel injury due to fire, electric shock, the unit falling or leakage of water.

Perform electrical work according to the installation manual and be sure to use an exclusive circuit.

• If the capacity of the power circuit is insufficient or there is incomplete electrical work, it could result in a fire or an electric shock.

Check that the refrigerant gas does not leak after installation is completed.

Attach the electrical part cover to the indoor unit and the service panel to the outdoor unit securely.

•If the electrical part covers of the indoor unit and/or the service panel of the outdoor unit are not attached securely, it could result in a fire or electrical shock due to dust, water, etc.

## 

#### Do not install the unit in a place where a flammable gas leaks.

• If gas leaks and accumulates in the area surrounding the unit, it could cause an explosion.

Perform the drainage/piping work according to the installation instruction.

•If there is a defect in the drainage/piping work, water could leak from the unit and household goods could get wet and be damaged.

## **Installation Of Indoor And Outdoor Units**

## Read completely, then follow step by step. Indoor unit

- Do not expose the indoor unit to heat or steam.
- Select a place where there are no obstacles in front or around the unit.
- Make sure that condensation drainage can be conveniently routed away.
- Do not install near a doorway.
- Ensure that the space on the left and right of the unit is more than 12cm.



- A minimum pipe run of 3 metres is required to minimise vibration & excessive noise. The indoor unit should be installed on the wall at a height of 2 metres or more from the floor.
- The indoor unit should be installed allowing a minimum clearance of 15cm from the ceiling.
- Any variations in pipe length will/may require adjustment to refrigerant charge.
- There should not be any direct sunlight. Otherwise, the sun will fade the plastic cabinet and affect its appearance. If unavoidable, sunlight prevention should be taken into consideration.

#### Outdoor unit

- If an awning is built over the outdoor unit to prevent direct sunlight or rain exposure, make sure that heat radiation from the condenser is not restricted.
- Ensure that the clearance around the back of the unit is more than 30cm and left side is more than 30cm. The front of the unit should have more than 200cm of clearance and the connection side (right side) should have more than 60cm of clearance.



More than30cm

- Do not place animals and plants in the path of the air inlet or outlet.
- Consider the weight of air conditioner when selecting the location because of its noise and vibration.
- Select a proper place so that the warm air and noise from the air conditioner do not disturb neighbours.

#### **Rooftop installation:**

- If the outdoor unit is installed on a roof structure, be sure to level the unit.
- Ensure the roof structure and anchoring method is adequate for the unit location.
- Consult local codes regarding rooftop mounting.
- If the outdoor unit is installed on roof structures or external walls, this may result in excessive noise and vibration, and may also be classed as a non serviceable installation.



### **Items Packed With The Unit**

Number	Name of Accessories		Qty		
1	Installation Plate		1		
2	Clip Anchor			8	
3	Self-tapping Screw A ST3.9X25			8	
4	Seal (some models without)			1	
5	Drain Joint		1		
	Connecting pipe assembly	Liquid	Φ 6.35	Parts you must purchase. Check	
		side	Φ 9.53	pipe sizes for each of the Liqui	
6		Gas Side	Φ 9.53	dealer or specification of models	
			Φ 12.7	you purchased.	
			Ф 16.0	(A minimum pipe wall-thickness of 0.7mm is required)	
7	Remote controller			1	
8	Self-tapping Screw B ST2.9X10 Remote controller holder		2		
9			1		

Note: Except the above parts provided, the other parts needed during installation you must purchase



### CAUTION

Ensure that the space around the left and right of the indoor unit is more than 12cm. The indoor unit should be installed allowing a minimum clearance of 15cm from the ceiling.

Use a stud finder to locate studs to prevent unnecessary damage to the wall. A minimum pipe run of 3 metres is required to minimise vibration & excessive noise. The indoor unit should be installed on the wall at a height of 2 metres or more from the floor.

Two of the A, B and C directions should be free from obstructions.

Remote Contro ler



Mounting screw B ST2.9x10-C-H

> Remote contro er ho der

- This illustration is for explanation purposes only.
- Copper lines must be insulated independently.

## **Indoor Unit Installation**

#### 1. Fit the Installation Plate

- 1. Fit the installation plate horizontally on structural parts of the wall with spaces around the installation plate.
- If the wall is made of brick, concrete or the like, drill eight (8) 5mm diameter holes in the wall. Insert Plastic Expansion Sheath for appropriate mounting screws.
- 3. Fit the installation plate on the wall with eight (8) type "A" screws

#### Note:

Fit the Installation Plate and drill holes in the wall according to the wall structure and corresponding mounting points on the installation plate. (Dimensions are in "mm" unless otherwise stated)



A:795, B:270(<12000Btu/h model); A:845, B:286(≥12000Btu/h model) \* Dimensions may vary.

#### 2. Drill a hole in the wall

1. Determine hole positions according to the diagram as shown above. Drill one (1) hole

(65mm) slanting slightly to outdoor side.

2. Always use wall hole conduit when drilling metal grid, metal plate or the like.



Wall



#### 3. Connective Pipe and Drainage Installation

#### Drainage

1. Run the drain hose sloping downward. Do not install the drain hose as illustrated below.



2. When connecting extension drain hose, insulate the connecting part of extension drain hose with a shield pipe, do not let the drain hose slack.

#### **Connective pipe**

- For the left-hand and right-hand piping, remove the pipe cover from the side 1. panel. Explain to clients that the pipe cover must be kept as it may be used when relocate the air conditioner to any other place.
- For the rear-right-hand and rear-left-hand piping, install the piping as shown. 2. Bend the connective pipe to be laid at 43mm height or less from the wall.
- 3. Fix the end of the connective pipe. (Refer to Tightening Connection in **REFRIGERANT PIPING CONNECTION**)



Fig.7



#### 4. Indoor unit installation

- 1. Pass the piping through the hole in the wall.
- Put the upper claw at the back of the indoor unit on 2. the upper hook of the installation plate, move the indoor unit from side to side to see that it is securely hooked.
- 3. For ease of fitting, insert a cushioning material between the indoor unit and the wall. Remove cushioning material after fitting.
- Push the lower part of the indoor unit up on the wall, 4. Then move the indoor unit from side to side, up and down to check if it is hooked securely.



#### 5. Piping and wrapping

Bundle the tubing, connecting cable, and drain hose with tape securely, evenly as shown in Fig.10.

Because the condensed water from rear of the indoor unit is gathered in ponding box and is piped out of room. Do not put anything else in the box





#### CAUTION

- Connect the indoor unit first, then the outdoor unit.
- Do not allow the piping to let out from the back of the indoor unit. Be careful not to let the drain hose slack as slack may cause water drippage.
- Both Copper pipes must be properly lagged/insulated. •
- Be sure that the drain hose is located at the lowest side of the bundle. • Locating at the upper side can cause water to overflow inside the unit.
- Never inter-cross nor inter-twist the power wire with any other wiring. •
- Run the drain hose on a downward sloping angle to ensure water runs at gravity pull straight to the water outlet outside.

#### **Outdoor Unit Installation**

#### Precaution

To prevent exposure to the wind, install the outdoor unit with its suction side facing the wall. Never install the outdoor unit at a site where the suction side maybe exposed directly to the wind. To prevent exposure to the wind, it is recommended to install a baffle plate on the air discharge side of the outdoor unit.



- Install the unit high enough off the ground to prevent burying in snow. Or use a bracket
- Install the outdoor unit on a rigid and level base to prevent excessive noise level and vibration. Determine the air outlet direction where the discharged air is not blocked.

 Where installation location is exposed to strong wind such as place near the seaside, make sure the fan operating properly by putting the unit lengthwise along the wall or using a dust or shield plates.



- Especially in windy area, install the unit to prevent the admission of wind.
- If need suspending installation, the installation bracket should accord with technique requirement in the installation bracket diagram. The installation wall should be solid brick, concrete or the same intensity construction, or actions to reinforce, damping supporting should be taken. The connection between bracket and wall, bracket and the air conditioner should be firm, stable and reliable.
- Be sure there are no obstacles which block radiating air.

#### **Settlement of outdoor unit**

Anchor the outdoor unit with a bolt and nut  $\phi 10$  or  $\phi 8$  tightly and horizontally on a concrete or rigid mount.

Check strength and level of the installation ground so that the unit will not cause operating vibration or noise after installed.

In accordance with the foundation drawing in fix the unit securely by means of the foundation bolts. (Prepare four sets of M8 or M10 foundation bolts, nuts and washers each which are available on the market.)

It is best to screw in the foundation bolts until their length are 20mm from the foundation surface



#### Drain joint installation

For the unit with the seal, first fit the seal onto the drain joint, and then insert the drain joint into the base pan hole of outdoor unit, rotate  $90_{\circ}$  to securely assemble them. Connecting the drain joint with an extension drain hose (Locally purchased), in case of the water draining off the outdoor unit during the heating mode.



**Oblique** Roughness

Fig.14

Burr

#### **REFRIGERANT PIPING CONNECTION**

#### 1. Flaring work

Main cause for refrigerant leakage is due to defect in the flaring work. Carry out correct flaring work using the following procedure:

#### A: Cut the pipes and the cable.

1. Use the piping kit accessory or pipes purchased locally.

2. Measure the distance between the indoor and the outdoor unit.

- 3. Cut the pipes a little longer than the measured distance.
- 4. Cut the cable 1.5m longer than the pipe length.

#### **B: Burr removal**

- 1. Completely remove all burrs from the cut cross section of pipe/tube.
- 2. Put the end of the copper tube/pipe in a downward direction as you remove burrs in order to avoid dropping burrs into the tubing.



#### C: Putting nut on

Remove flare nuts attached to indoor and outdoor unit, then put them on pipe/tube having completed burr removal.(not possible to put them on after flaring work)

#### **D: Flaring Work**

Firmly hold copper pipe in a die in the dimension shown in the table below.

Outer diam.	A (mm)		
(mm)	Max.	Min.	
Ф 6.35	1.3	0.7	
Ф 9.53	1.6	1.0	
Ф 12.7	1.8	1.0	
Ф 16.0	2.4	2.2	



Flare nut

Fig.16

Copper tube



#### **Tightening Connection**

- Align the centre of the pipes.
- Sufficiently tighten the flare nut with fingers, and then tighten it with a spanner and torque wrench as shown.





Fig.19

#### Caution

Excessive torque can break nut depending on installation conditions.

Outer diam.	Tightening	Additional tightening
	torque(N.cm)	torque(N.cm)
$\Phi$ 6.35	1570	1960
	(160kgf.cm)	(200kgf.cm)
<b>Ф</b> 9.53	2940	3430
	(300kgf.cm)	(350kgf.cm)
<b>Φ</b> 12.7	4900	5390
	(500kgf.cm)	(550kgf.cm)
<b>Φ</b> 16.0	7360	7850
	(750kgf.cm)	(800kgf.cm)

#### Note:

• Please check the Pipe sizes relevant to your model and follow tightening torque & flaring work as shown on tables above.

#### **ELECTRICAL WORK**

Electric safety regulations for the initial Installation

1. If there is serious safety problem about the power supply, the technicians should refuse to install the air conditioner and explain to the client until the problem is solved.

2. Power voltage should be in the range of 90%~110% of rated voltage.

3. The creepage protector and main power switch with a 1.5 times capacity of Max. Current of the unit should be installed in power circuit.

4. Ensure the air conditioner is grounded well.

5. According to the attached Electrical Connection Diagram located on the panel of the outdoor unit to connect the wire.

6. All wiring must comply with local and national electrical codes and be installed by qualified and skilled electricians.

7. An individual branch circuit and single receptacle used only for this air conditioner must be available. See the following table for suggested wire sizes and fuse specifications:

Model	Power Supply	Input Rating Amps (Switch/Fuse)
Up to 12,000 Btu/h (3.5kW)		13A
18,000 Btu/h (5kW)	220-240V ~ 50Hz	20A
More than 18,000 Btu/h (5kW)		32A

Minimum norminal cross-sectional

area of conducto	rs:
Rated current	Nominal cross-sectional
of appliance	area
(A)	(mm <sup>2</sup> )
>3 and <6	0.75
>6 and <10	1
>10 and <16	1.5
>16 and <25	2.5

**NOTE**: The supply voltage must be consistent with the rate voltage of the air conditioner.

#### Connect the cable to the indoor unit

- 1. Indoor/Outdoor connection cable should be H07RN-F type.
- 2. Remove the panel and Screw, then remove the window cover.
- 3. Connect cables according to their marks to terminals.
- 4. Wrap those cables not connected with terminals with insulation tapes, so that they will not touch any electrical components.



#### Connect the cable to the outdoor unit

- 1. Remove the electric parts cover from the outdoor unit.
- 2. Connect the connective cables to the terminals as identified with their respective matched numbers on the terminal block of indoor and outdoor units.
- 3. To prevent the ingress of water, from a loop of the connective cable as illustrated in the installation diagram of indoor and outdoor units.
- 4. Insulate unused cords (conductors) with PVC-tape. Process them so they do not touch any electrical or metal parts.





#### Caution

After the confirmation of the above conditions, prepare the wiring as follows:

- 1) Never fail to have an individual power circuit specifically for the air conditioner. As for the method of wiring, be guided by the circuit diagram posted on the inside of control cover.
- 2) The screws which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened. (If they are loose, it could cause burn-out of the wires.)
- 3) Specification of power source.
- 4) Confirm that electrical capacity is sufficient.
- 5) See to that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- 6) Confirm that the cable thickness is as specified in the power source specification.
- 7) Always install an earth leakage circuit breaker in a wet or moist area.
- 8) The following would be caused by voltage drop.

Vibration of a magnetic switch, which will damage the contact point, fuse breaking, disturbance of the normal function of the overload.

9) The means for disconnection from a power supply shall be incorporated in the fixed wiring and have an air gap contact separation of at least 3mm in each active(phase) conductors.

## **AIR PURGING**

Air and moisture in the refrigerant system have undesirable effects as indicated below:

- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing. Water may
- lead to corrosion of parts in the refrigeration system.

Therefore, the indoor unit and tubing between the indoor and outdoor unit must be leak tested and evacuated to remove any non-condensable and moisture from the system.

#### Air purging with vacuum pump

• Preparation

Check that each tube (both liquid and gas side tubes) between the indoor and outdoor units have been properly connected and all wiring for the test run has been completed. Remove the service valve caps from both the gas and the liquid side on the outdoor unit. Note that both the liquid and the gas side service valves on the outdoor unit are kept closed at this stage.

• Pipe length and refrigerant amount:

Connective pipe length	Air purging method	Additional amount of refrigerant to be charge
Less than 5m	Use vacuum pump	N/A
More than 5m	Use vacuum pump	R410A: (Pipe length-5) x 20g/m

- When relocate the unit to another place, perform evacuation using vacuum pump.
- Make sure the refrigerant added into the air conditioner is liquid form in any case. (Not applicable to the units with R22 refrigerant)

#### Leak test

- Do a leak test of all joints of the tubing (both indoor and outdoor) and both gas and liquid side service valves.
- Bubbles indicate a leak. Be sure to wipe off the soap with a clean cloth. After the system is found to be free of leaks, relieve the nitrogen pressure by loosening the charge hose connector at the nitrogen cylinder. When the system pressure is reduced to normal, disconnect the hose from the cylinder.

#### Gas leak check

1. Soap water method:

Apply a soap water or a liquid neutral detergent on the indoor unit connection or outdoor unit connections by a soft brush to check leakage of the connecting points of the piping. If bubbles come out, the pipes have leakage.

2. Leak detector Use the leak detector to check for leakage.

#### CAUTION

A: Lo packed valve B: Hi packed valve

C and D are ends of indoor unit connection.



### **Evacuation**

- Connect the charge hose end described in the preceding steps to the vacuum pump to evacuate the tubing and indoor unit. Confirm the "LO" knob of the manifold set is open. Then run the vacuum pump. The operation time for evacuation varies with tubing length and capacity of the pump.
- When the desired vacuum is reached, close the "LO" knob of the manifold set and stop the vacuum pump.



### Important information regarding the refrigerant used

This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.

Refrigerant type: R410A

GWP \* value: 1975 \**GWP = global warming potential* 



The filled out label must be adhered in the proximity of the product charging port (e.g. onto the inside of the stop valve cover).

1 factory refrigerant charge of the product: see unit name plate

2 additional refrigerant amounts charged in the field

(Refer to the above information for the quantity of refrigerant replenishment.)

- 3 total refrigerant charge
- 4 Contains fluorinated greenhouse gases covered by the Kyoto Protocol
- **5** outdoor units
- 6 refrigerant cylinder and manifold for charging

## Finishing the job

- With a service valve wrench, turn the valve stem of liquid side valve counter-clockwise to fully open the valve.
- Turn the valve stem of gas side valve counterclockwise to fully open the valve.
- Loosen the charge hose connected to the gas side service port slightly to release the pressure, then remove the hose.
- Replace the valve cap on the gas side service port and fasten the cap securely.
- This process is very important to prevent leakage from the system. Replace the valve caps at both gas and liquid side service valves and fasten them tightly.



• This completes air purging with a vacuum pump. The air conditioner is now ready to test run.

#### **Test running**

Perform test operation after completing gas leak check at the flare nut connections and

electrical safety check.

- Check that all tubing and wiring have been properly connected.
- Check that the gas and liquid side service valves are fully open.
- 1. Connect the power, press the ON/OFF button on the remote controller to turn the unit on.
- 2. Use the MODE button to select COOL, HEAT, AUTO and FAN to check if all the functions works well.
- 3. When the ambient temperature is too low(lower than 17 C), the unit cannot be controlled by the remote controller to run at cooling mode, manual operation can be taken. Manual operation is used only when the remote controller is disable or maintenance necessary.
- Grasp both sides of the panel and pull it down, the panel opened upward to an angle of 15. Push the panel upward and then lift it up.
- Press the Manual control button to select the AUTO or COOL, the unit will operate under Forced AUTO or COOL mode(see User Manual for details).
- 4. The test operation should last about 30 minutes.



### Service & Warranty

### ONE (1) YEAR LIMITED WARRANTY SAVE THIS WARRANTY INFORMATION

EcoAir guarantees this product free from defects in materials and workmanship for a period of one (1) year from the date of purchase, limited to parts only.

Faults arising from a faulty installation is specifically excluded.

This unit must be operated under conditions as recommended, at voltages indicated on the unit. Any attempts made to service or modify the unit by unqualified technician, will render this **WARRANTY VOID**. The actual product may differ slightly from the illustration. This warranty is in addition to, and does not affect, your statutory rights.

For after sales needs, please visit www.ecoair.org/service or email technical@ecoair.org or contact +44 845 474 3574.

We recommend that you note the details of your purchase below and retain your original proof of purchase receipt with this manual. Keep these documents safe in the event of a warranty claim.

Date of purchase:	
Purchased from (Dealer Name):	
Retailer name:	
Model number:	
Serial number:	
Date of installation:	

21

**Copyright Reserved** 



AIR CONDITION NOUVEAU SERIES INSTALLATION MANUAL